


Baldwin
Piano *Novelle*

PS1500

**OWNER'S
MANUAL**

Cod. 271101
U.S.English



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

IMPORTANT SAFETY INSTRUCTIONS

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS

1. Read all the instructions (Safety, Installation and FCC if applicable) before using the product.
2. Do not use this product near water (example, near a swimming pool, spa, tub, sink or wet basement) and do not expose to rain.
3. This product should be used only with a cart or stand that is recommended by the manufacturer, or should be used with the components supplied. If this product requires assembly before being played, take special care to follow the assembly instructions found at the back of the manual.
4. This product, whether alone or in combination with an amplifier and headphones or speakers, may be capable of producing sound levels that could cause permanent hearing loss. Do not operate for long periods of time at a high volume level or at a level that is uncomfortable. If you experience any hearing loss or ringing in the ears, you should consult an audiologist.
5. **WARNING:** Do not place this product or any other objects on the power cord, or place it in a position where one could walk on, trip over or roll anything over power or connecting cords of any kind.
6. This product should be located so that its location does not interfere with its proper ventilation.
7. This product should be located away from heat sources such as radiators, heat registers, or other products that produce heat.
8. This product should be connected to a power supply only of the type described in the operating instructions or as marked on the product.
9. This product may be equipped with a polarised line plug (one blade wider than the other). This is a safety feature. If you are unable to insert the plug into the wall outlet, contact an electrician to replace your obsolete outlet. Do not defeat the safety purpose of the plug.
10. The power supply cord of the product should be unplugged from the outlet when left unused for long periods of time.
11. Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
12. This product should be serviced by qualified service personnel when:
 - a) the power supply cord or the plug has been damaged; or
 - b) objects have fallen, or liquid has been spilled into the product; or
 - c) the product has been exposed to rain; or
 - d) the product does not appear to operate normally or exhibits marked changes in performance; or
 - e) the product has been dropped, or the enclosure damaged.
13. Do not attempt to service the product beyond that described in the user-maintenance instructions. All servicing should be referred to qualified service personnel.
14. Some Generalmusic products may have benches and/or accessory mounting fixtures that are either supplied as part of the product or as optional accessories. Please ensure that benches are correctly assembled and stable and any optional fixtures (where applicable) are well secured before use.
15. Electromagnetic Interference (RFI) This electronic product utilises digital sample wave processing technology (S.W.P.) that may adversely affect radio/TV reception. Read the FCC note on the inside back cover of the owner’s manual for additional information.

SAVE THESE INSTRUCTIONS

FEDERAL COMMUNICATIONS COMMISSION

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this instrument does cause harmful interference to radio or television reception, which can be determined by turning the instrument off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications to this product not expressly approved by the manufacturer could void the user's authority to operate this product.

Stock Code 271101
Specifications are subject to change without prior notice.
PRINTED IN ITALY

Baldwin

Baldwin Piano & Organ Company, 422 Wards Corner Rd., Loveland, Ohio, 45140 - 8390 - USA

Contents

USER GUIDE

Introduction

How to use the owner's manual i
Specifications ii
Update the Operating System with OS-Disks v
System Reset v

• 1 Quick Guide 1. 1

Power up and get to know the basics. 1. 1
The initial status (default) 1. 2
Adjusting the General Volume 1. 2
Play with Auto Accompaniment Styles 1. 3
Listen to the Demo Styles 1. 5
Demo Style 1. 5
Multimedia 1. 6
Selecting instrument Sounds 1. 8
Selecting the Programmable Presets 1. 10
Change the touch sensitivity 1. 12
Play the Programmable Pads 1. 12
Play with Effects or bypass them 1. 13
Play with headphones 1. 14
Play with the pedals 1. 14
Regulate the general Effect
volumes and activate loudness 1. 15
Transpose the instrument (Semitones) 1. 16
Play All Songs 1. 17
Song Play - Direct from Disk 1. 18
Recording a Song/Style 1. 20

• 2 Front & Rear Panel 2. 1

Front Panel (buttons & controls) 2. 6
Rear Panel (Connections) 2. 10

• 3 Basic concepts 3. 1

Play modes 3. 1
Presets 3. 3
Tracks 3. 5
Sounds 3. 5
Edit Modes 3. 6
Connections 3. 7
The Display 3. 10
Data Entry 3. 13

• 4 Sounds & Presets	4. 1
	The Sounds and Tracks 4. 1
	Selecting Single Sounds 4. 3
	Selecting Presets 4. 6
	The Grand Piano Preset 4. 8
	How to Program Presets 4. 10
	How to Store Presets 4. 19
	Restore Preset 4. 23
• 5 The Styles	5. 1
	About PS1500 Styles 5. 1
	Selecting Styles 5. 2
	The Accompaniment tracks 5. 5
	The Style Controls 5. 6
	Variation, Fill, Style Lock 5. 8
	The Accompaniment section 5. 9
	Examples of using Styles 5. 16
	Tempo 5. 23
	Restore Sequencer 5. 24
• 6 Disk	6. 1
	Floppy disk formats 6. 1
	Files 6. 1
	Load operations - Play directly from disk 6. 5
	Load Song, SMF, Style 6. 5
	Load Styles, Load Presets 6. 9
	Load Sample 6. 10
	Load All 6. 11
	Loading WS and CD compatible files 6. 13
	Save operations 6. 16
	Save Song, SMF, Style 6. 18
	Save Styles, Save Presets 6. 20
	Save Sample 6. 21
	Save All 6. 22
	Utility functions 6. 23
	General disk handling information 6. 28
	Precautions to observe when using PS disks with a computer 6. 30
• 7 Songs & MIDI Files	7. 1
	What is a Song 7. 1
	What is a MIDI File 7. 1
	Selecting Songs 7. 3
	Song Playback 7. 4
	Displaying lyrics 7. 10
	Restore Songs memory 7. 13
• 8 Song/Styles	8. 1
	What is a Song/Style 8. 1
	Selecting Song/Styles 8. 2

	Song/Style Playback	8. 3
	Restore Song/Style memory	8. 9
• 9 Digital Effects	9. 1	
	Selecting the effect types	9. 2
	Bypassing the effects	9. 4
	Regulating the Send levels	9. 5
• 10 MIDI	10. 1	
	What is MIDI?	10. 1
	Playing PS1500 with a master keyboard	10. 4
	PS1500 in Song mode used as a controlling device	10. 7
	Programming Songs on an external sequencer	10. 8
	MIDI Panic	10. 10

REFERENCE GUIDE

• 11 Selection/Display Hold/Metronome	11. 1	
	Selection	11. 1
	Display Hold	11. 6
	Metronome	11. 6
• 12 Edit Preset section	12. 1	
	Overview	12. 1
	• Preset	12. 3
	<i>The Preset functions</i>	12. 3
	• MIDI	12. 7
	<i>The MIDI functions</i>	12. 8
	• Mixer	12. 15
	• Sound	12. 17
	<i>The Sound parameters</i>	12. 20
	<i>Clear Sound and Clear All</i>	12. 24
	• Drumkit	12. 27
	<i>The Drumkit parameters</i>	12. 31
	<i>Erase "Drumkit" and Clear "Drumkit"</i>	12. 34
• 13 General	13. 1	
• 14 Edit effects	14. 1	
• 15 User Style recording	15. 1	
	Recording User Styles	15. 3
	Programming the User Style Preset	15. 7
• 16 Song/Style Recording	16. 1	
	Recording Song/Styles	16. 2
	Programming the Song/Style Preset	16. 7
• 17 Song Recording	17. 1	
	Recording Songs	17. 2
	Programming the Song Preset	17. 7

.....

• **18 Song Edit 18.1**

- Quantize function 18. 2
- Clear function 18. 4
- Master Track function 18. 9
- Copy function 18.1 3

• **19 SAMPLE / RECORD 19.1**

- Regulating the Mic/Line signal 19. 3
- Preparing to sample - select the Splits 19. 4
- Programmable Pads Assign 19. 12

• **20 Play All Songs - Restore 20. 1**

- Play all Songs 20. 1
- Restore 20. 2
- Software Release Date 20. 3

APPENDIX

- Tables A i
- MIDI Implementation Chart A. xiv
- Glossary A. xvii
- Index A. xxi

CONGRATULATIONS!

Congratulations and thanks for purchasing Baldwin's Pianovelle **PS1500**. This instrument provides high quality sounds and accompaniments, and a simple user interface with a 2x40 LCD backlit display which allows total control of all performance and programming activities.

MULTIMEDIA FACILITIES


PS1500 is a multimedia piano workstation which offers several ways of interfacing with the instrument. With the optional Audio/Video Interface, a guitar player can connect to the Mic/Line inputs of the **PS1500** and mix his sounds with those of the workstation (complete with effects processing). At the same time, a group of singers can follow the lyrics projected on a television (or other video projection device) by the **PS1500**.

THE OWNER'S MANUAL

The Owner's Manual is supplied as a 3-ring binder with instructions inserted inside.

How to use the manual

Do not use it as a paperweight: read it. If you understand how **PS1500** operates, you can save a lot of time. You are encouraged to experiment with alternative operating methods: the **PS1500** is sufficiently flexible to permit several choices to obtain the same results. The User Guide offers information on three different levels of complexity: as numbered images or pictures, as brief instructions and as detailed instructions. You can limit yourself to following the images only, or by reading the bold black type, or by referring to the normal text containing detailed instructions.



The second part of the manual contains the **Reference Guides** which describe all the instrument's functions in detail without discussing procedures. Experienced users can limit themselves to the Reference chapters.

At the end of the manual is the **Appendix** containing tables, midi specs, a Glossary and an Index.

SPECIFICATIONS

- **Polyphony & multitimbricity**

Maximum polyphony: **32 voices**. Multitimbricity: **8 parts** (Style/Preset modes) or **16 parts** (Song mode). Each part is assigned to a track. In Style/Preset mode, 3 tracks (maximum) are assigned to the keyboard and the other 5 to the auto-accompaniments.

- **Sound Generation**

The Sounds are based on sampled waveforms (PCM, Wavetables and Subtractive Synthesis technology) and elaborated by a series of macro functions. The instrument's 32 oscillators generate "single" Sounds (32-note polyphonic) or "layered" Sounds (16 note polyphonic), depending on the number of oscillators used to elaborate the Sound (1 or 2).

- **ROM Sounds**

ROM (permanent memory) contains 4 Megabytes of ROM Sounds, totalling almost 400 permanent Sounds and Drumkits.

- **Sound Edit**

PS1500's macro-edit facilities permit rapid and easy Sound and Drumkit editing to produce edited Sounds (E-Sounds) which are stored in the Presets. The modifications are stored in the Presets to allow Songs, Styles or Presets to load the correct sounds. You can also opt to recall your modified Presets with original Sounds instead of edited ones.

- **Sample-RAM**

PS1500 is fitted with a battery-backed Sample-RAM dedicated to the storage of Samples. PCM Sample kits can be loaded into Sample-RAM from disk, or can be recorded with the **PS1500** sampler, accessed via the Audio/Video Interface.

- **Digital Effects Processor**

Two Digital Effects Processors, controlled in real time, enrich the sound with effects (reverbs and modulations). Two different effects (1 Reverb and 1 Modulation) can be assigned to each Preset and an editor is available to create user-effects which are stored in the Presets.

- **16 Track Recording Studio**

The 16-track Sequencer includes a series of functions that allow Style, Song/Style and Song recording (real time system), playback and editing. Also featured is a Text function (to display Song lyrics). Song/Style recording allows the rapid recording of an 8-track song by using existing Styles. Sequence data is conserved in the battery-backed System-RAM.

- **Play All Songs, Chain**

The **Play All Songs** function allows the direct playback of all Songs or MidiFiles present on disk without loading the data into memory. The Songs or MidiFiles play as a medley which you can stop at any time with the Play All Songs button. Song/Styles and Songs feature the **Chain** function which allows you to chain the Song or Song/Styles in memory and play them one after the other with a single command.

- **Automatic Accompaniment**

Styles provide automatic musical accompaniment, consisting of 5 tracks. Every Style has 4 Variations. Up to 16 disk based Styles (User programmable) can be loaded and automatically stored in the battery-backed System-RAM.

- **Disk Drive**

Data can be stored on 3.5" HD Floppy disks on **PS1500** format (1.4 Megabytes - Ms-Dos standard) or Atari/Falcon format (720 Kbytes

- Ms-Dos format). **PS1500** is able to initialize disks for both formats. If the Sample-RAM is installed, it is also possible to load Sample-kits from disk. Ms-Dos compatibility permits MIDI File exchange with other instruments and computers. The Disk Drive features the 'Slow' and 'Fast' loading options; Slow allows data to be loaded without blocking the instrument (background loading) while 'Fast' provides faster loading times without background loading.

- **Sampling**

The Audio/Video Interface (AVI) renders the Microphone/Line inputs operational for **Sampling**. The captured sample can be edited with specific Sample Edit parameters and processed by the on-board Digital Effects Processor. PCM Samples can also be loaded directly to the Sample-RAM from disk.

- **Updateable Operating System (OS) from floppy disk**

Since the operating system resides in a flash-ROM, it is possible to load updates from floppy disk. Operating System updates can add new functions to the instrument.

- **Karaoke**

The **Karaoke** function allows Song and Midi-File lyrics to be displayed on the instrument's 2x40 LCD display. The AVI allows lyrics to be projected onto a television or other video device during a performance to allow others to sing along with the player. The AVI is configured by default for the USA NTSC video standard.

- **Audio Inputs**

PS1500 is fitted with a set of audio inputs suitable for the connection of musical instruments, mixer or home stereo outputs. The level of the input signal can be regulated by an appropriate volume control situated close to the inputs. The signal can be directed to

the outputs for further external amplification. The Audio/Video Interface renders the Mic/Line input operational, suitable for sampling purposes and processing the input signals with the instrument's on-board Digital Effects processor.

- **MIDI operation**

PS1500 is fully implemented for MIDI operation. The instrument can act as a Master controlling device, or as a 16 part multi-timbral slave device, regardless of the currently selected playing mode. A General MIDI compatibility switch, MIDI Filters and MIDI Dump facilities completes the MIDI features.

- **Direct Connection with a computer**

The Computer jack permits the connection of computers (MAC/PC/Atari) not fitted with a MIDI interface to **PS1500** via a single serial cable. The communication speeds can also be configured to suit your specific computer system.

IMPORTANT INFORMATION

1. The PS1500 should contain the following items from the factory.
 - a) Instrument;
 - b) Bench;
 - c) 3 Floppy disks (2 OS-Disks, 1 Demo);
 - d) Owner's manual.
2. When contacting your retailer or authorized Baldwin technical assistance center, always provide the model name and serial number of your instrument (found on the identification plate).

The information in this publication has been carefully prepared and checked. The manufacturers however decline all liability for eventual errors. All rights are reserved. This publication may not be copied, photocopied or reproduced in part or in whole without prior written consent from Baldwin Piano & Organ Company. Baldwin reserves the right to apply any aesthetic, design or function modifications it considers necessary to any of its products without prior notice. Baldwin declines all liability for damage to property or persons resulting from improper use of the instrument.

Make sure that all electronic options are installed by an authorised Baldwin Pianovelle service technician. Check with the authorised Baldwin Pianovelle dealer for information on the closest service center.

Baldwin Piano & Organ Company © 1996. All rights reserved.

Apple, IBM, Macintosh, Microsoft, MS-DOS, Windows, Atari, are registered trademarks of the respective companies.

IMPORTANT PRELIMINARY NOTES

Observe these important preliminary notes before using your instrument.

AVOID PLACING DISKS NEAR MAGNETS - Do not place floppy disks on top of speakers, near magnets, telephones or other sources of electromagnetic fields. The disk contents could be damaged.

UPDATEABLE OPERATING SYSTEM - two disks containing the operating system are supplied with the instrument. The disks can contain a more recent version of the operating system than the one contained in the instrument's Flash ROM.



To load the operating system contained in the floppy disks:

(1) turn off the instrument, (2) insert OS-disk 1 in the drive, (3) turn on the instrument, (4) When the message "Loading OS-DISK clears ALL MEMORY !! < Enter to load / Escape to abort >" appears, press ENTER to start the OS update, (5) when the message, "INSERT NEXT OS-DISK please < Enter to load >" appears, extract the first disk, insert OS-Disk 2 and press ENTER to continue (6) when the operation is complete, the instrument sets to the default Style/Preset situation. After completing this process, proceed with the reset that follows below to ensure proper operation. Remember to extract the second disk and store both OS-disks in a safe place.

SYSTEM RESET

SYSTEM RESET - If the data contained in the instrument's memory has been damaged, either by being exposed to the effects of a strong magnetic field, or other unknown reason, the instrument may not operate properly. The remedy is a System Reset:

(1) press and hold the UPPER 1 selector button located to the right of the LCD display, (2) simultaneously press the three buttons 2, 3 & 4 of the PROGRAMMABLE PADS section while still holding the UPPER 1 selector button, (3) the message «System Reset» appears for an instant then the instrument resets to the factory-set situation. All user-programmed data is irremediably lost.





User Guide

- 1 Quick Guide
- 2 Layouts
- 3 Basic concepts
- 4 Sounds & Presets
- 5 Styles
- 6. Disk
- 7. Songs & MIDI Files
- 8 Song/Styles
- 9 Digital Effects
- 10 MIDI

PS1500

Baldwin
Piano*velle*

GENERAL SAFETY INSTRUCTIONS

Power source

- Be sure that your local AC mains voltage matches the voltage specified on the name plate before connecting to the mains.
- DC power cannot be used to power this instrument.
- If the instrument is to remain unused for long periods of time, remove the power cord from its wall outlet. For safety purposes, remove the power cord in cases of storms with lightning.

Handling the power cord

- Never touch the power cord or its plug with wet hands.
- Never pull on the cord to remove it from the wall socket, always pull the plug.
- Never forcibly bend the power cord.
- If the power cord is scarred, cut or broken, or has a bad contact, it will be a potential fire hazard or source of serious electric shock. NEVER use a damaged power cord; have it replaced by a qualified technician.

If water (or other liquid) gets into the instrument

- Do not allow liquids to penetrate the instrument. Do not place containers of liquids on the instrument. If water or liquids penetrate the instrument, remove the power cord from the wall socket at once, and contact the store where the unit was purchased.
- As a general precaution, never open the unit and touch or tamper with the internal circuitry.

If the instrument plays in an abnormal way

- Turn off the power immediately, remove the power cord from the mains outlet and contact the store where it was purchased.
- Discontinue using the unit at once. Failure to do so may result in additional damage or other unexpected damage or accident.

Important notes

- Do not place heavy objects on the instrument and avoid leaning on it.
- Before turning on the instrument, be sure to set the volume to a reasonable level (master volume slider at about two thirds of the course).
- Before connecting your instrument to other devices, always remember to turn off the power to all units; this will help to prevent damage or malfunction.

General user maintenance

- Clean the outer surface of your instrument using a soft, clean, slightly damp cloth and polish with a soft, dry cloth.
- Never use industrial cleaners, detergents, abrasive cleansers, waxes, solvents or polishes as they may damage the instrument finish.
- Always turn off the power supply after use and never turn the unit on and off repeatedly in quick succession as this places an undue load on the electronic components.

• 1 Quick Guide


POWER UP AND GET TO KNOW THE BASICS

1. Be sure that the power switch on the left key block is in the "OFF" position before connecting the power cord.
2. Insert the instrument's power cord into a suitable grounded wall outlet.
3. Press the power switch to turn on **PS1500**.

After a few seconds the instrument sets to the default situation.

If necessary, regulate the display contrast using the DISPLAY CONTRAST panel knob on the left of the display. Different viewing angles may require an adjustment of the display contrast.

At this point, **PS1500** is ready to play.




PLAY WITH AUTO ACCOMPANIMENT STYLES

PS1500 has 96 auto accompaniment Styles with four Variations four Intros, a Fill and four Endings for each Style. You can also load up to 16 disk based User Styles of your choice into the 2 User Style banks available.

1. Press SINGLE TOUCH PLAY.

Pressing this button activates the KEY START function automatically. The EASY PLAY and MEMORY buttons will activate if not already on.


When SINGLE TOUCH PLAY is on, the sound memorized in the Style Preset are assigned to all the tracks. Selecting a Style changes the sounds of the accompaniment section as well as those of the keyboard sections.



2. Press a Style Group button in the SONG/STYLE GROUPS (Swing, Country, Rock, etc.).


3. Select a Style.

Use Function buttons F1...F8 under the display to select one of the 8 Style names.




4. Play a single note or a chord (at least three notes) below the Chord Split Point (note F#3) to start Style play.

A single note or chord triggers a fully orchestrated auto accompaniment pattern. The KEY START function allows you to start the Style by playing a note or chord on the keyboard area below the Split point.



In default conditions, the keyboard's chord recognition mode is set to "One Finger" which allows you to play Styles using "one finger" chords on a split keyboard.

You can change the chord recognition mode from "One Finger" to "Fingered1", "Fingered



2" or "Free", either by selecting a Preset or by entering the PIANO STYLE options. See the PIANO STYLE function in the Styles chapter 5, page 12.

5. Play a different chord.

Note how the accompaniment pattern is transposed.



6. Start to play a melody with the right hand.

The combination of sounds that play and the current keyboard mode will depend on the Style selected.

7. Stop the Style with Start/Stop or Ending.

If you use the Ending, the KEY START function is cancelled.

Styles are discussed in detail in the relative chapter afterwards.



Demo Style

LISTEN TO THE DEMO STYLES

You can listen to the automatic playback of your **PS1500** to get an idea of what the instrument is capable of doing.

1. Press the DEMO button in the SYSTEM section.

The 2x40 backlit Liquid Crystal Display (LCD) shows three Styles and the "ALL" options to choose from.

2. Select a Style with the corresponding Function button.





The selected demo Style playback starts. When the end is reached, the demo stops.

3. Select the "ALL" option to chain all three demos.

Playback starts automatically from the first Style (TodayStyle). The demo current playing is shown flashing in the display.

While the demo plays, all the buttons on the control panel (except DEMO, the Function buttons and ESCAPE) and the keyboard are disabled.


4. To stop the Demo Style without closing the DEMO display, press the corresponding Function button. To stop the Demo Style and close the DEMO display, press ESCAPE or DEMO.



Multimedia

PS1500 can display Lyrics when playing PS Series Disks. There are a large number of disks that display lyrics when played. Furthermore, if you connect the RGB socket of the Audio/Video Interface to a domestic TV or computer monitor, you can project the Lyrics onto the external monitor. You may have to load a Song into memory.

1. Insert a disk containing PS Songs into the disk drive and press DISK.




2. Select the FAST Disk option (optional step) and the SONG option from the Disk Load page.

Use Function button F1 to select FAST and Function button F2 to select LOAD SONG


3. Select a Song by rotating the DIAL.

The Dial scrolls through all the songs present on disk.




4. Press ENTER twice to load the Song into memory.

If you select the FAST loading option, the instrument's panel buttons and keyboard will be temporarily disabled while data is loaded into memory.




5. Press SONG in the Style/Song Groups section.

6. Select the SONG with the corresponding Function button.




7. Press **PLAY** or **START/STOP** to start the **SONG** playback.




8. Press **TEXT** in the Song Edit section.

While the Song plays, the lyrics are scrolled across the display in synchronization with the Song.

If you have connected to an external monitor, the lyrics can also be shown on the screen in larger type. In «Edit General», you can choose from 4 different Video color setups.



9. Press **TEXT** or **ESCAPE** to close the lyrics display. Stop the Song playback with **START/STOP** or **STOP**.



SELECTING INSTRUMENT SOUNDS

PS1500 has almost 400 instrument Sounds, including orchestral, percussion and contemporary musical instruments. You can customize any sound to your tastes with the built in sound edit capabilities.

1. Press the GRAND PIANO button.

The display shows the GRAND PIANO PRESET for a short period then returns to the default situation automatically with the EASY PLAY, MEMORY and STYLE LOCK buttons activated (LED on) and VARIATION 2 of Style Soul BB from the POP group selected.

The GRAND PIANO button always returns you to a single instrument sound (Piano 1) playing across the full keyboard. You may use the "Grand Piano" button as a 'return to start' button whenever you wish to have only one sound active across all 88 keys.




The Grand Piano Preset is discussed in detail in chapter 4, "Sounds and Presets".

2. Press a SOUND GROUPS button.

Select a Sound by pressing the Function button corresponding to the Sound name in the display (Organ 2 in this example).


3. Play on the keyboard and listen to the Sound

The Sound plays across the full keyboard



4. Repeat step 2 and listen to other Sounds.

This time, after pressing a SOUND GROUPS button, select a Sound Bank with the PAGE+ / BANK+ button once or twice then select a Sound. Each Sound Group button consists of 3 Sound Banks, each containing 8 Sounds.




5. Press the UPPER 2 keyboard activator button then press a single note anywhere along the keyboard.

You'll hear two sounds for each single note played.

Activating Upper 2 introduces a second Sound (String) layered with the first.

If you press the LOWER button, it won't activate and a user message appears in the display - more about this later. The user message cancels automatically after 2/3 seconds..



SELECTING THE PROGRAMMABLE PRESETS

The Pianovelle **PS1500** contains 64 Programmable Presets organized into eight different banks: 32 programmed at the factory (buttons 1 - 4) and the other 32 "empty" (buttons 5 - 8), ready to be user-programmed. These presets feature combinations of up to 3 keyboard Sounds, custom effect settings, split keyboard combinations and more. You can create your own Presets or load new ones from disk.

1. Press button 1 in the PROGRAMMABLE PRESETS section.

The display shows 8 Presets to choose from, each with a different name.

2. Select the Preset called "GrandP".

Use Function button F1 to select the Preset. The display shows a change of keyboard sounds and a change in the name of the Preset in the bottom left hand corner of the display (from "GPiano" to "GrandP").




► **Note:** If you do not select a Preset within the first 2/3 seconds, the display returns to the previous situation with no changes.

3. Play on the keyboard.

This time you'll hear a different piano sound with respect to the previous. The "Piano1" sound plays across the full keyboard extension as before.


To play with the Metronome

If you want to practice using a Metronome, press the METRONOME button in the SONG EDIT section. The top left hand side of the display shows the symbol "MT" to indicate the activation of the metronome. For live playing, you can activate or deactivate the Metronome whenever you want. In record mode, the Metronome is activated automatically.



4. Press the UPPER 2 activator.

A second sound is introduced (String), layered with the first.



5. Press the LOWER activator.


A: In the case of the GrandP Preset (F1), the LOWER activator will be disabled because this Preset recalls the Full keyboard mode.

B: If, in point 2 overleaf, you selected a different Preset, say Preset PnoStr (F2), the keyboard mode recalled will be Split mode.

In this case, the LOWER activator will introduce a third sound and the keyboard will be divided with a Split Point at note F#3.

The LOWER keyboard plays a Sound over the range A0 - F#3. The UPPER 1 and UPPER 2 sections are assigned to the range G3 - C8.

Repeat steps 2 and 3 to make additional changes.



Observations

Depending on the Preset selected, the keyboard sound combinations will change and the keyboard mode may change from Full to Split and vice versa. The chord recognition mode may also change from "Free" to "One finger" or "Fingered 1" or "Fingered 2".

If Full mode is recalled, the Lower keyboard section is automatically disabled for selection leaving Upper 1 and Upper 2 only active for selection or muting.

If Split mode is recalled, all three keyboard sections will be enabled for selection or muting.

CHANGE THE TOUCH SENSITIVITY

If the keyboard of your **PS1500** is too “hard” or “soft”, you may want to modify the touch sensitivity setting.

1. Press TOUCH SENSITIVITY

The display shows four settings to choose from.




2. Select the setting required.

Use the corresponding Function button to select the setting and play on the keyboard at the same time. The options are:

Off, Soft, Medium, Hard.

3. Close the display with TOUCH SENSITIVITY or ESCAPE.

The setting remains in memory until changed again and also after power down.



PLAY THE PROGRAMMABLE PADS


The four Programmable Pads buttons provide quick and easy ways of adding extra sounds to your playing. You can program each pad to produce an instrumental sound, a percussive sound or sample.

• Strike the Pads freely.

While you play, add additional sounds from the pads in real time.

The configuration of the Programmable Pads can be stored in the Programmable Presets.

The sound configuration of the pads is user-programmable. (Refer to the Sample/Record chapter 19).



PLAY WITH EFFECTS OR BYPASS THEM

One or both effects buttons in the **Digital Effect** section will be active (LED on), showing that the current Preset is being processed by one or both effect types (Reverb and/or Mod/Delay effect).

You can temporarily modify the way in which a Preset is processed by changing the On/Off configuration of the **Reverbs** and **Effects** buttons.

When the LEDs are on, the current Preset is being processed by the effects; when off, the respective effect is bypassed.

Bypass

1. To bypass an effect, press an active button.



The LED of the button goes off, indicating that the current Preset is no longer processed by the relative Digital Effect.

To activate an effect

2. Press a deactivated button.

The LED of the button turns on to indicate that the current Preset is processed by the relative Digital Effect.

22 Reverbs and 22 Mod/Delays are available and both Effects units are user-programmable (See chapter 15, «Edit Effects»). How to select the effects is discussed in chapter 9, «Digital Effects».




PLAY WITH HEADPHONES

- Plug a set of headphones into the left headphone socket.

The headphones sockets panel is located on the left side of the instrument, under the keyboard. Inserting the headphones plug into the PHONES 1 jack excludes the internal speakers to allow you to play in total silence without disturbing others in the same room. Plugging into the PHONES 2 jack does not exclude the internal speakers.

Use the **Master Volume** slider to control the headphone volume.



PLAY WITH THE PEDALS


The group of three pedals, denoted Ped1, Ped2 and Damper, provide preset functions.

The default configuration of the pedals is as follows:

- Ped1 = Soft
- Ped2 = Sostenuto
- Damper = Damper (sustain)

The pedals are function assignable and can be independently enabled or disabled to react with the keyboard sections of a Preset.

All three pedals are switch action controls.



► **Note:** If the Pedals do not appear to operate, check that the cable running from the pedal groups is properly connected to the PEDALS socket on the rear panel of the instrument.

REGULATE THE GENERAL EFFECT VOLUMES AND ACTIVATE LOUDNESS

It is possible to regulate the general effect volumes to suit the surroundings and activate the Loudness function.

Although each Preset recalls appropriate effect volume settings for each track, a general setting can be applied to render the effects more or less intense with a single command.

The Loudness control introduces a particular equalisation (a simultaneous control of the Bass and Treble tones - similar to that found on home stereo units). When Loudness is ON, it favours certain frequencies at low volume.

1. Press the **GENERAL** button in the EDIT section).
2. Press the **PAGE+ / BANK** button once.

3. Select the parameters with the Function buttons:
Rev=Reverb (F1/F2), Eff=Effect (F3/F4), Loud=Loudness (F5/F6).

4. Modify the selected parameter, either with the Dial, or with the Sliders F1 ... F8.




DIAL: Rotate the DIAL to change the status of the selected parameter.

SLIDERS F1...F8: When you enter any Edit situation, the Sliders F1...F8 activate as data entry devices automatically. Use the sliders to change the parameter values directly without selecting them first.

TOGGLE THE F BUTTON: You can toggle between the ON and OFF status of the LOUDNESS option by pressing Function button F7 or F8 repeatedly.

5. Press **ESCAPE** or **GENERAL** to exit Edit General.

The settings remain in memory (RAM) after turning off the instrument.



TRANPOSE THE INSTRUMENT (SEMI-TONES)

If you would like to play a Song in a different key, or a song is too high or too low for a singer or other instrument, you can transpose **PS1500** to play the song in an easier key.

The TRANPOSE +/- buttons allow real time semitone adjustments (transpositions) of the overall pitch (range ± 12 semitones = 1 octave).


1. Press TRANPOSE+ to raise the pitch or TRANPOSE- to lower the pitch.

TRANPOSE+ pressed once displays an increase of +01.

TRANPOSE- pressed once displays a decrease of -01:

Holding either button changes the value continually until +12 or -12 is reached.

The LED on one of the buttons will be on to indicate that the instrument is currently in a Transposed status (sharp # or flat ♭).




Clear the keyboard transpose setting

2. Press both TRANPOSE buttons simultaneously.

The LED on the active button goes off and the instrument's normal pitch is restored. The display shows the 0 setting for a few seconds then returns to normal.

► **Note:** Pressing both Transpose buttons at the same time also provides a PANIC function. See Edit MIDI.



Play All Songs

Use the PLAY ALL SONGS button (located in the 16 Track Recording Studio section) to play all the Songs or MidiFiles directly from a disk. No need to enter Disk mode; just insert the disk and press PLAY ALL SONGS.

1. Insert a PS Songs disk or MidiFile data disk into the drive.

Check the disk label for the type of data contained on the disk.

Refer to the section entitled "General Disk handling information" in Disk chapter 6 for information regarding the precautions to take when inserting and extracting floppy disks from the drive.

2. Press PLAY ALL SONGS.

PS1500 starts to scan the disk contents and, shortly a Song starts to play back.


When the first Song or MidiFile ends, a second sequence begins.

Playback continues non-stop until all the Songs or MidiFiles on disk have been played.

When the last Song or MidiFile reaches the end, playback stops automatically.

3. You can stop the playback at any time by pressing PLAY ALL SONGS, STOP or START/STOP.

Playback stops instantly.



Song Play - Direct from Disk


PS1500 can also play a preselected Song or MidiFile directly from disk.

The Demo disk supplied with **PS1500** contains a **PS1500** format Song.


If you have a Standard MIDI File data disk, you can use this instead of the supplied disk.

“Direct-from-disk” is particularly useful for Song files that are larger than the available sequencer memory.

1. Insert the disk into the **PS1500** disk drive.




2. Press the DISK button.



3. Select the “Song” (a) or “MidiFile” (b) option from the Load page.


Press Function button F2 for **Song** or Function button F4 for **MidiFile**.

The display shows the first Song (a) or MidiFile (b) on disk.



4. Rotate the DIAL to select a Song or MidiFile.

Scroll through the files and select a Song or MidiFile.




5. Press START/STOP or PLAY to start the playback.

The PLAY button is located in the 16 Track Recording Studio.

The START/STOP button is the big red button on the left of the display.

The message "Wait!!" appears for a few seconds.



► **Note:** If you press Escape during the "WAIT!" period, you can abort the Direct play function.


Shortly after, **PS1500** enters Song mode and playback begins. The display flashes the message "Playing" for the entire playback period.

If the Song contains a Lyrics track, it will not be possible to display the lyrics in "Direct from disk" mode. To see the lyrics, load the Song into memory (see page 6 of this chapter).

6. To stop the "direct" playback at any time, press STOP or START/STOP.

PS1500 exits Disk mode and returns to the mode selected before pressing DISK.

Don't forget to remove the Floppy disk from the drive.




Recording a Song/Style


PS1500 allows you to record a simple 8 track song (Song/Style) using recording method that exploits existing Styles. In practice, the Song/Style recording can record from 1 to 3 real time tracks accompanied by all the backing tracks of a Style to create an 8 track Song/Style.

This is the quickest and most direct recording method.


1. Press **GRAND PIANO PRESET** to set the instrument to Style/Preset mode.



2. Activate **SINGLE TOUCH PLAY** and press a **STYLE** button in the Style/Song Groups to enter the relative Style bank (Swing, Country, Rock, etc.).




3. Select the Style that you want to record.
Use the corresponding Function button.



4. Press RECORD in the Sequencer.

On the top line of the Song/Style display appear the letters "MT" to indicate that the Metronome is active. On the bottom line at the center, the chord track is shown as being active to record data by the indication "Chord=Rec". If you don't want to play with the metronome, press the METRONOME button in the SONG EDIT section.




5. Press either PLAY or START/STOP to start the recording.

Pressing PLAY starts the sequencer to record the keyboard track(s) only.

Pressing START/STOP starts the sequencer to record the chords that trigger the auto accompaniments of the Style.

A metronome will beat time (drum sticks) and you will have a one measure lead into the recording to get ready.

► **Note:** If you want to synchronize the start of the recording with the keyboard tracks and accompaniments, press KEY START and start to play on the keyboard. Recording starts instantly with no countdown into the recording.




6. Start playing after the one bar lead.

Any notes you play during the lead-in will not be recorded.

During the recording, use the Style controls as you would when playing a Style:

- Use the Fills;
- Change Variation;
- Change Style (even with a different Time Signature - e.g. from 4/4 to 3/4), etc.....






7. When you have finished, stop the recording either with STOP or START/STOP.

START/STOP stops the recording of the Chord events while the sequencer continues to be active for the keyboard tracks.

STOP stops the sequencer recording for both Chord and keyboard track events.

8. Press RECORD or ESCAPE to escape the Sequencer.

9. Listen to the Song/Style playback by pressing either PLAY or START/STOP.



Save the Song/Style to disk

Although **PS1500** retains user-programmed data in the battery-backed RAM after turning off, you can save recorded sequence data to floppy disk for future use.

The «Disk» chapter explains in detail how to save your sequence data to Disk.

• 2 Front & Rear Panel

Each button on the **Pianovelle PS1500** control panel activates a specific function, selects an item in the display, or interacts with the currently selected *operating mode* to assist with the operations.

This chapter explains what happens when you press the buttons.



BUTTONS WITH LEDS

Functions represented by a button with a LED (light emitting diode) indicate the on/off status of the respective function. Pressing these type of buttons repeatedly toggles between the "On" and "Off" status. When the LED is on, the respective function is active. In some cases, the LED flashes to indicate a special situation.


BUTTONS WITHOUT LEDS

Buttons without LEDS normally gain access to a selection environment, or an editor belonging to one of the operating modes. In both cases, an appropriate display is activated showing items that are selected with the underlying Function buttons (F1...F8).

Front panel




Rear Panel




Control panel

(left section)



Control panel

(central section)



Control panel




(right section)

26

25

24

23



33

32

31

30

29

28

27

Front Panel (buttons & controls)

1. VOLUME SLIDERS

MASTER VOLUME. Adjusts the general volume (speakers, headphones and outputs). Not transmitted or received via MIDI.

MIC/LINE. Controls the volume of the signal fed into the Mic/Line Input of the optional Audio/Video Interface.

2. ACCOMPANIMENT SLIDERS

DRUM, BASS, ACCOMP1, ACCOMP2, ACCOMP3, LOWER, UPPER2, UPPER1. Independent volume controls for the keyboard sections (Upper 1, Upper 2, Lower) and Style Tracks (Drum, Bass, Acc1, Acc2, Acc3). A LED indicator shows when the sliders are active for Style track volume control.

F1...F8 SLIDERS: In multi-track mode (Song) or in one of the Edit modes, sliders F1...F8 control the volumes of tracks 01-08 or 09-16 and operate as data entry controls in edit situations. A LED indicator shows when the sliders F1...F8 are active as Song volume and Data Entry controls.

3. SINGLE TOUCH PLAY

When ON, Style-Preset sounds are assigned to all the tracks. When OFF, selecting Styles recalls sounds for the accompaniment sections only while those of the keyboard tracks remain unchanged.

4. STYLE/SONG GROUPS

Each button corresponds to a bank of 8 Styles (**Swing, Country, Rock**, etc.), User Styles (**User1-8 & User9-16**), Song/Styles (**Song/Style**) or Songs (**Song**). Press a button to display the contents of the bank and select an item with the function button corresponding to the name in the display.

5. ACCOMPANIMENT

Buttons which control the Styles.

- **EASY PLAY:** Enables (On) or disables (Off) the Style arrangements.

- **PIANO STYLE:** Gains access to the Piano Style programming page where you can program the chord recognition modes for the Style accompaniment.

- **MEMORY:** When ON, releasing the keys from the keyboard causes the Style accompaniments to continue playing; when OFF, all accompaniments except the Drum track stop instantly after key release.

- **LOWER MEMORY:** When ON, the sounds assigned to the Lower keyboard track continues playing after releasing the keys; when OFF, the Lower sound stops instantly after key release.

- **TEMPO LOCK:** When ON, this button locks the current tempo setting for all Style and Preset selections. When OFF, each Style or Preset recalls memorized Tempo data.

- **FADE IN/OUT:** Starts and stops a Style with a gradual increase or decrease of volume. Starting requires pressing the Start button.

- **MIXER LOCK:** When ON, this button locks the current Track volume settings for all Style and Preset selections. When OFF, each Style or Preset recalls memorized Mixer settings.

- **BASS FOLLOW:** When ON, the Bass track of the Style auto accompaniment follows the lowest left note of the chord played, allowing real time changes of the bass accompaniment according to the lowest note played. When OFF, the bass track follows the programmed pattern of the Style, regardless of the chord inversion played.

6. VAR 1, VAR 2, VAR 3, VAR 4

1, 2, 3, 4: These buttons allow you to switch from one Style Variation to another.

7. STYLE LOCK

When ON, selecting Presets recalls keyboard sounds only without changing Style. When OFF, Presets can change Style as well as the keyboard sounds.

8. FILL

- **FILL <** (Fill-to-previous-variation): Recalls a Fill pattern then moves to the previous Variation.

- **FILL** (Fill-to-current-variation): Recalls a Fill pattern then continues with the same variation.

- **FILL >/TAP TEMPO** (Fill-to-next-variation): **FILL >** - pressed during Style play recalls a Fill pattern then moves to the next variation. **TAP TEMPO** - sets the Style playing speed by tapping on the button and starts the Style auto accompaniment automatically.

9. TRANSPOSE +, TRANSPOSE -

Raises (+) or lowers (-) the pitch of the instrument as a whole in semitone steps, over a range of ± 12 semitones. Pressing both buttons at the same time resets to 0.

Panic: In MIDI situations, pressing both buttons at the same time provides a PANIC function.

Name write: In name writing situations when the keyboard activates as a source of alphanumeric data, Transpose – moves the cursor backwards while Transpose + moves it forwards.

10. DISPLAY CONTRAST

Adjusts the display contrast. Different display viewing angles and lighting conditions may require a slight adjustment of the contrast.

11. PAGE+/BANK+, PAGE-/BANK-

These buttons select Presets in increasing (Page+) or decreasing (Page-) order when PS1500 is set to Style/Preset mode. In Sound selection situations, they select the Sound Banks 1, 2 and 3 in cyclic order (Bank+, Bank-). In the various Edit modes, they pass from one edit page to another.

12. THE DISPLAY

A 2x40 LCD (Liquid Crystal Display) display which communicates the current status of the instrument at all times. In Style/Preset mode, the display's contents are defined by the silkscreened markings around the perimeter.

13. SELECT - UPPER 1, UPPER 2, LOWER

These buttons allow you to select the respective keyboard sections to enable them for a sound change. The Lower keyboard section is selected by pressing both buttons at the same time. A SELECTED KEYBOARD SECTION IS SHOWN FLASHING IN THE DISPLAY.

14. START/STOP, INTRO, ENDING, KEY START CONTINUE

- **START/STOP:** Starts and stops the playback of a Style, Song/Style or Song. In sequencer recording processes, the Start/Stop button and the Play and Stop buttons of the sequencer operate in the same manner.
- **INTRO:** Places the introduction of a Style on "standby" before Style start.
- **ENDING:** Stops a Style with an Ending.
- **KEY START/CONTINUE:** Synchronizes the start of a Style with a note (or chord) pressed on the lower keyboard area. Pressing **Continue** in Song or Song/Style mode restarts the Song or Song/Style from the current stop point.

15. DISPLAY HOLD

ON: locks the selection displays (Sound, Preset, Style, Song/Style, Song) for multiple selection possibilities. ESCAPE cancels Display Hold. OFF: the temporary selection display closes after a selection, or after a few sec-

onds if no selection has been made.

16. TOUCH SENSITIVITY

Enables/disables the keyboard velocity sensitivity according to the current setting. Holding the button pressed for a few seconds opens a selection display where you can choose from 3 different sensitivity settings and Off.

17. SYSTEM

- **RESTORE:** Enters a restore display where you can choose to restore part of the instrument's RAM to the original factory settings (All, Sequencer, Preset). The display also shows the release date of the operating system.
- **DEMO:** Gains access to the demonstration Styles which you can listen to one at a time or as a medley.

18. FUNCTION BUTTONS F1...F8

Buttons which allow you to select the displayed data corresponding to the relative button.

19. HARMONY

- **HARMONY ON/OFF:** Enables/disables the melody harmony function according to the current Harmony Type setting. In Style/Preset modes, the chord notes are coupled to the melody played with the right hand.
- **HARMONY TYPE:** Activates a selection display where you can select one of the 8 Harmony Types available.

20. DIGITAL EFFECT

- **REVERB:** activates (LED on) or bypasses (LED off) the Reverb effect assigned to the current Preset.
- **EFFECTS:** activates (LED on) or bypass (LED off) the Modulation/Delay effect assigned to the current Preset.
- **EFFECTS EDITOR:** Holding down either buttons gains access to the effects selectors, the effect send controls and the effects editor.

21. UPPER 1, UPPER 2, LOWER (ACTIVATORS)

These buttons activate (LED on) or mute (LED off) the respective keyboard sections and, therefore, determine the configuration of the keyboard sounds.

22. DIAL, ENTER, ESCAPE

- **DIAL:** active for Tempo changes in Style, Song/Style or Song modes, or operates as a data entry control in Edit and Record situations.
- **ENTER:** confirms specified data in edit situations.
- **ESCAPE:** cancels specified data and/or escapes an edit situation.

23. SOUND GROUPS

Each button comprises a group of 8 Sounds. Each Sound Group consists of 3 banks which are selected with the Page/Bank buttons, or via MIDI with BankSelect messages MSB (CC00). Bank 1 Sounds conform to General MIDI standards, while all other banks contain sound variations of Bank 1 Sounds.

24. EDIT

Each button gives you access to the edit of the function specified on the button (except the Sample button).

- **GENERAL:** edit of the General parameters which affect the instrument as a whole.
- **SOUND:** edit of the macro Sound & Drumkit parameters.
- **MIDI:** edit of the MIDI parameters.
- **PRESET:** edit of the Preset parameters.
- **MIXER:** edit of the Mixer parameters.
- **SAMPLE:** gains access to the Samples bank (battery-backed Sample-RAM).
- **SAMPLE/RECORD:** gains access to the Sampling and the Programmable Pads assign functions.

25. SONG EDIT

Each button gains access to a sequencer editing facility when PS1500 is in Style, Song/Style or Song Record mode.

- **TEXT:** displays Song Lyrics (active for Songs or MIDI Files with a Lyrics track only);
- **QUANTIZE:** an auto corrector of timing errors;
- **ERASE:** facilities for cancelling recorded events;
- **MASTER TRACK:** "Ghost track" which determines the initial status of a Style, Song/Style or Song before recording;
- **COPY:** facilities for copying recorded data;
- **METRONOME:** activates/deactivates a metronome to practice with or to use in recording sessions.

26. THE DISK DRIVE

The Disk Drive, located on the extreme right hand side of the control panel, handles 3.5" double density (2DD) or high density (2HD) floppy disks.

27. GRAND PIANO

Recalls the Grand Piano preset for the Upper 1 keyboard section and overrides the currently selected Preset. The keyboard sets to Full mode, regardless of the current mode prior to the selection of the button. The Upper 2 section turns off and Lower is disabled.

28. PROGRAMMABLE PRESETS

These buttons gain access to the Programmable Presets, arranged in 8 groups of 8 Presets each. Each Preset can memorize a configuration of keyboard sounds (up to 3) and a Style Preset.

29. PROGRAMMABLE PADS

4 buttons which provide sounds or samples that can be played in real time in any mode. The configuration of the Pads is programmable and can be stored to the Presets.

30. STORE PRESET

Saves the modifications applied to the Presets in RAM and allows the Preset name to be changed. The modifications can be stored to the current Preset, or any other Preset destination. Modified Style Presets can also be stored to the same locations.

31. 16 TRACK RECORDING STUDIO

This section represents the on-board sequencer.

- **RECORD:** Activates the sequencer for Style, Song/Style or Song recording.
- **STOP:** Stops the recording and playback process.
- **PLAY:** Starts the recording and playback process.
- **<<, >>:** Fast forward (>>) or "rewind" (<<) buttons for Songs. When pressed together, the "Measure" function activates, opening an active zone where you can specify a measure of the current Song. Confirming with Enter passes directly to the measure and closes the active zone.
- **LEDs 1 - 16, TRACK SELECT:** Activators for tracks 1 - 08 and 9 - 16 when recording Styles, Song/Styles and Songs. **TRACK SELECT** toggles between the first and second set of 8 tracks; used in Song recording only (multi-track recording).


32. DISK

Enters the Disk operating functions (Load, Save, Utility [Format, Erase]) which allow the transfer of files to and from disk and other utility functions.


33. PLAY ALL SONGS

If a Song or MidiFile disk is inserted in the Disk drive, this button triggers the playback of all the Songs or MidiFiles directly from disk, playing them back one after the other as a medley.

Rear Panel



Rear Panel (model with Speakers box)



Rear Panel (Connections)

1. AUDIO/VIDEO INTERFACE

- **RGB:** VIDEO OUTPUT IN RGB/Composite Video STANDARD.
- **SVHS:** Video output in SVHS/Composite Video standard.
- **Mic/LINE In:** Audio Input for Microphone or Line signals for sampling operations. The general volume of the signal is regulated with the front panel MIC/LINE control.
- **GAIN:** Controls the volume of the signal fed into the Mic/Line Input.

2. COMPUTER

Serial port which permits PS1500 to be connected directly to a computer (Apple Macintosh or IBM PC and compatibles.) Data interchange between **PS1500** and PC or Mac requires appropriate setting in Edit General.

3. MIDI

Standard MIDI interface used to control other MIDI instruments or to communicate with a Computer. IN: receives data from another instrument. OUT: transmits data to another instrument. THRU: retransmits data received at MIDI IN. MIDI cables are not supplied with the instrument.

When using **PS1500** on its own, these jacks do not require connection.

4. PEDALS

The Function assignable Pedal Group consisting of three pedals is connected by means of the appropriate jack connector. If your pedals do not appear to operate, check that the Pedals cable is connected to this jack.

5. INPUT

- **Right/Mono - Left:** Stereo Audio Inputs for a musical instrument, cassette recorder or CD player. For mono connections use the Right/Mono jack.
- **Volume** Controls the level of the signals fed into the Input jacks.

6. OUTPUT

- **Right/Mono - Left:** Stereo Audio Outputs to listen to the **PS1500** sound through an external device such as a mixer or audio amplifier. For Mono reproduction, use the Right/Mono jack.

7. SPEAKERS (for PS1500 models with Speakers box)

Connection for the internal speakers. Connect the cable running from the speakers box to this jack.

• 3 Basic concepts

In this chapter, you'll find information regarding the principal elements that make the **Pianovelle PS1500** work, including useful information which will help you to understand the structure of the instrument.

PLAY MODES: STYLE/PRESET, SONG/STYLE & SONG

PS1500 offers three different play modes:

Style/Presets mode: to use **PS1500** as a conventional keyboard or to play with the automatic accompaniments. **PS1500** powers up in this mode every time it is turned on. Press the GRAND PIANO button to activate Style/Presets mode if the instrument is set to a different mode. Select Styles from the Style banks (Swing, Country, Rock, etc.).

Song/Style mode: to record the Styles with up to 3 keyboard sounds and create 8 track Songs to use as backings. Press SONG/STYLE then select or record a Song/Style to set this mode.

Song mode: to play Songs to work via MIDI with an external sequencer to create 16 track Songs. Press SONG then select a Song to set to Song mode.

▶ **Note:** Via MIDI, an external sequencer (or other controlling device) has access to 16 PS1500 tracks at all times, regardless of the current mode.

STYLE/PRESET MODE

In this mode, you can play with Styles, or use the **PS1500** as a conventional keyboard. If the auto-accompaniments are playing, the Style mode is on: if not, Style mode is off and Preset mode is on.

Real Time and Style modes have a *Presets* in common. Styles can play up to 8 tracks at the same time while Presets up to 3. Both modes have identical Preset editing tasks.

Style Presets are always divided into two parts: the first 5 tracks are associated to the auto-accompaniment, the remaining 3 are dedicated to the keyboard (Upper 1, Upper 2, Lower).

tracks 1-5 contain...	tracks 6-8 contain...
Auto-accomp sounds	Keyboard Sounds
effects	effects
Programmable drumkit	
Tempo	Tempo
Selected Style	

Sounds and accompaniments can be recalled by selecting a Style (from the STYLE GROUP buttons) or a Preset (from the PROGRAMMABLE PRESETS buttons when Style Lock is off).


If you press Start/Stop when Styles are disabled (EASY PLAY LED off), you will only hear the drum track of the selected Style.

The STYLE LOCK and SINGLE TOUCH PLAY buttons

In Style/Presets mode the selection of the Sounds and the Accompaniments is determined by the status of STYLE LOCK and SINGLE TOUCH PLAY buttons.


STYLE LOCK on. Selecting Presets selects live keyboard sounds only.

STYLE LOCK off. Selecting a Preset selects live keyboard sounds and also accompaniment Sounds. The relative Style, Variation and Tempo are selected. Sounds are those stored in the Preset.



SINGLE TOUCH PLAY on. Selecting a Style changes keyboard and accompaniment Sounds. The Sounds are those of the Style-Preset. The Tempo stored in the Style is recalled.

SINGLE TOUCH PLAY off. Selecting a Style changes the accompaniment Sounds, Tempo data and the relative pattern. The live keyboard Sounds remain unchanged.



SONG/STYLE MODE

A **Song/Style** is an 8 track (max) Song created by recording the keyboard sounds with existing Styles. The chords that trigger the Styles are captured by the sequencer on a "Chords" track. Up to 3 keyboard tracks can be recorded. Song/Styles are excellent providers of backing tracks for singers or solo instruments.

Up to 7 Song/Styles can reside in memory. The 8th location is reserved for the Chain function which chains the Song/Styles into a "medley".

SONG MODE

A Song is sequenced data consisting of one or more tracks (instrumental parts). A Song can be loaded from disk as a **PS** Song or as a Standard MIDI-file, and it can be recorded one track at a time (multitrack recording).

Up to 16 tracks are available in Song mode. Via MIDI, **PS1500** can be also used as a multitimbral (16 parts) sound generator for Song recording with an external sequencer, regardless of the current play mode.

Up to 7 Songs can be stored in the **PS1500** song memory. The 8th memory location is reserved for the Chain function which plays back all the Songs in memory as a medley.

PRESETS

A Preset is a combination of sounds (for the keyboard, for the accompaniments, for a Song/Style or Song). It also contains the status of the effects, the assignments of the controlling devices (pedals, pads), MIDI channel configuration, track status, Tempo data and the current status of the panel buttons. Selecting a Preset instantly changes all the sounds of the tracks and the relative preset settings.

Presets are divided into three types: the Grand-Piano preset, a "single" non-programmable element, those residing in the PROGRAMMABLE PRESETS which govern the keyboard sounds and those associated to the Styles, Song/Styles and Songs which are recalled by selecting the respective element. With exception of the Grand-Piano Preset, the structure and programming procedures of all are practically identical.

Grand Piano preset

The Grand Piano preset, recalled every time you turn **PS1500** on, sets the instrument to play as a conventional piano, with the Grand Piano sound active across the full keyboard (assigned to Upper 1). In addition, the Upper 2 keyboard section is turned off and the Lower section is disabled. The Grand Piano Preset recalls factory settings for the Reverb effect, Volume and Pan and a preset panel situation.

Whatever modifications are applied to the Grand Piano preset (reverb effect change, volume change, different sound assignment, etc.) cannot be stored to the Grand Piano Preset, but to the Programmable Presets with the STORE PRESET function.

If **PS1500** is set to Style/Preset mode, selecting the Grand Piano Preset cancels the current preset and substitutes it with Grand Piano. Upper 2 turns off and the Lower section is disabled.

If **PS1500** is set to Song or Song/Style mode, recalling the Grand Piano Preset escapes the current mode and returns the instrument to Style/Preset mode with Grand Piano active to play on the Upper 1 section in Full mode.

Programmable Presets (Real Time)

64 user-programmable Presets are stored in the eight PROGRAMMABLE PRESETS banks 32 of which are factory-programmed. Presets recall programmed combinations of the keyboard sounds (maximum 3), memorized panel settings and also change the keyboard mode (full or split).

Given that the Presets store the current Style, Variation and Tempo at the moment of activating the STORE PRESET command, the Presets can also be utilized to recall a Style and a Variation. User-programmed Style Presets can be memorized to the Presets.

Style Preset

112 Presets associated to the Styles and User Styles and stored in the STYLE GROUPS (Style/Song Groups section: Swing, Country, Rock, etc., User 1-8, User 9-16). Style-Presets assign sounds to the auto-accompaniments and keyboard that suit the Style to which they are associated. If the SINGLE TOUCH PLAY LED is on, the keyboard Sounds can be changed. The User Styles are programmable.

Song/Style Preset

8 Presets associated to the Song/Styles and stored in the SONG/STYLE GROUP (Style/Song Groups). Song/Style Presets assign sounds to the auto-accompaniments and keyboard and recall the chords that trigger the auto-accompaniments.

For editing purposes, Song/Style Presets cannot be accessed from the PROGRAMMABLE PRESETS; they are accessed by pressing the PRESET button in the EDIT section. A modified Song/Style Preset can be saved to any of the 7 Song/Style slots available in memory.

Song Preset

Song-Presets can combine up to 16 sounds. They can be applied to two types of operating mode: the assignment of a sound to each track of the sequencer, or the reception via MIDI of 16 different parts.

For editing purposes, Song Presets cannot be accessed from the PROGRAMMABLE PRESETS; they are accessed by pressing the PRESET button in the EDIT section. A modified Song Preset can be saved to any of the 7 Song slots available in memory.

The Presets via MIDI?.....

Via MIDI, the Programmable Presets are a source of 16 Sounds, regardless of the status of the instrument. The Grand Piano Preset, however, cannot be selected via MIDI and does not transmit MIDI data. You can, however, save the Grand Piano Preset situation to a Programmable Preset then select the Preset via MIDI.

Whenever you enter «Edit Preset», you will always have access to 16 tracks. If you are programming **PS1500** for Preset or Style modes, the configuration of tracks 9-16 does not influence either playing mode, but if you are programming **PS1500** for use as a multitimbral slave device, all 16 tracks are taken into consideration and the programmed configurations memorized to the Presets will be recalled as programmed. Therefore, you can program all 16 tracks of your Presets, regardless of how you intend using them

when you play **PS1500** as a stand-alone unit. Selecting Sounds and Presets via MIDI is discussed in a later chapter.

TRACKS

A Track is the smallest part of a Preset. Programmable Presets have up to 3 tracks (for the keyboard), Style-Presets have a maximum of 8 tracks (3 tracks for the keyboard and 5 engaged by the sequencer for the accompaniments). A Song-Preset can contain up to 16 tracks.

A Preset is a configuration of several tracks, so that different Sounds can be combined to play at the same time. In Style/Preset and Song/Style modes, the Sound names of the keyboard tracks appear in the main display. In Song mode, the Sounds of all the tracks appear in the form of a ProgramChange number. Sometimes, a track is not assigned to a **PS** Sound, but it controls an expander connected to the MIDI OUT. In this case, the relative ProgramChange is shown on the main display.

In the first page of «Edit Preset», it is possible to see the sounds assigned to all the tracks of the current Preset in the form of a ProgramChange number. For the selected track, the corresponding Sound name and Bank number is also shown on the top line of the display. The Tracks are shown from 01-08 and from 09-16. The Track Select button in the 16 Track Recording Studio section allows you to switch from the track set 01-08 to 09-16.

Most of the operating modes display the tracks which can be selected and can be programmed for Sound assignments, a transposition, an effect selection or a performance control.

The status of the keyboard tracks (active or mute) can be changed by intervening directly on the corresponding keyboard activators (Upper 1, Upper 2 and Lower), or Function buttons F8, F7 and

F4/F5 respectively. The active/mute status of all other tracks (Styles, Song/Style and Songs) is changed by direct intervention on the corresponding track buttons of the sequencer.

SOUNDS

PS1500 Sounds are divided in four different types:

- ROM-Sounds
- E-Sounds (edited ROM-Sounds)
- Drumkits
- Samples

Rom-Sound

Sounds contained in ROM. These sounds are permanent and cannot be cancelled. They are based on the internal samples archive (ROM-Waves)

E-Sound

E-Sounds are created by modifying ROM-Sounds or by loading the data from disk (loading Presets containing E-Sounds). A Preset can store up to 8 E-Sounds and it can be programmed to recall E-Sounds or the original sounds.

Drumkit

Drumkits assign a different percussive sound to each note of the keyboard.

A Preset can store up to 4 modified percussive sounds of a Drumkit. **PS1500** contains 16 Drumkits memorized in Banks 2 and 3 of the Percussive Sound Groups.

Samples

The **PS1500** on-board sampler can capture a Sample which is stored in location 8 of the Sample-RAM.

PS1500 Sample kits are also available to load

PCM Samples to the first 6 locations of the Sample-Ram (in replacement of an eventual sample occupying location 8).

Location 7 can accept PCM Samples originating from CD Series instruments.

EDIT MODES

PS1500 offers several Edit modes to modify various aspects of the instrument. Each mode consists of a set of parameters spread across several edit pages.

The Edit Modes are:

- Edit Preset (program changes, track transpose and tunings and pedal assignments, etc.);
- Edit MIDI (MIDI channel settings, Common channel, Local off, General MIDI compatibility, etc.);
- Edit Mixer (track levels, pan settings);
- Edit Sound (macro edit of sound and drumkit parameters);
- Edit General (parameters that affect the instrument as a whole);
- Edit Effects (parameters that modify the Reverb and Effects units of the Digital Effects processor);
- Edit Samples/Pads (Sample editing and Pad assignment functions);
- Edit Song (editing functions for User Style, Song/Style and Song recordings);

- Disk (file handling operations to and from

RAM and disk).

The various Edit modes are explained in detail in the relevant chapters of the owner's manual.

Connections

This section takes a brief look at the types of connections that can be achieved with your **PS1500** using the rear-panel connectors.

POWER SUPPLY

Insert the instrument's power cord into a suitable grounded outlet.

OUTPUT

Right/Mono, Left

Right - Left Stereo outputs for amplified speakers, amplifiers or domestic hi-fi units.

► **WARNING** - Before connecting the outputs, be sure that the volume of the external amplification devices is turned down. Connecting to the jacks causes noise which can damage an amplification device.

For stereo reproduction, use both LEFT and RIGHT jacks. For mono reproduction, use only the RIGHT/M jack.

To use the audio outputs only and exclude the instrument's internal amplification, plug a set of headphones into the left HEADPHONES 1 jack.

PEDALS

The group of three pedals is connected to the appropriate jack via the special cable that runs from the pedal group assembly. Check that the cable is properly connected to the PEDALS jack for the correct operation of the three pedals.

The pedals, denoted P1 (Soft), P2 (Sostenuto), P3 (Damper) are preset to provide the following three functions:

Soft	Soft Pedal (generates CC67);
Sostenuto	Sostenuto (generates CC 66);
Damper	Damper (generates CC64).

The pedals are function assignable and can be independently programmed to react with the keyboard tracks of a Preset.

All three pedals are of the switch action type.

MIDI

PS1500 is fitted with a standard MIDI interface consisting of In, Out and Thru ports for MIDI connections. Specific instructions for MIDI connections are found in the relevant chapters further ahead. The following setups show some of the principal connections.

- To pilot another instrument with **PS1500**, connect the **PS1500** MIDI OUT to the MIDI IN of the other instrument.



- To pilot **PS1500** by a master keyboard, connect the **PS1500** MIDI IN to the MIDI OUT of the master keyboard. If the master keyboard has to simulate the **PS1500** keyboard, the master keyboard must transmit MIDI on

a channel that corresponds to the **PS1500** Common Channel (refer to the chapters dedicated to MIDI).



- To record Songs on external computers or sequencers, connect the **PS1500** MIDI IN to the MIDI OUT of the external device, the **PS1500** MIDI OUT to the MIDI IN of the external device. This configuration is called a "closed MIDI loop".



Set **PS1500** to Song mode and set a track for Local Off operation (in «Edit MIDI») in order to send **PS1500** keyboard data to its own internal sound engine via the external computer/sequencer.

INPUT

Right/M, Left + Volume

Right - Left Stereo inputs for the connection of external audio sources (a musical instrument, cassette recorder or CD player, etc.) which can play through **the PS1500** internal amplification system. For stereo connections use both LEFT and RIGHT/MONO jacks. For mono connections use only the RIGHT/MONO jack.

The small VOLUME knob controls the level of the signal fed into the INPUT jacks. The signal received at these jacks is fed to the instrument's main mix and delivered by the internal speakers as well as the LEFT-RIGHT/M outputs. The input signals are not, however, processed by the internal effects processor.


COMPUTER

It is possible to connect **PS1500** directly to a computer via the COMPUTER port.

This connection is alternative to MIDI; both types of communication are not simultaneously permitted.

Macintosh and compatibles. Use a standard serial cable DB8-DB8 or the Baldwin serial cable (optional). Program the sequencer to communicate with **PS1500** at the velocity of [1 MHz].

PC IBM and compatibles. Use the Baldwin serial cable (optional). Select the appropriate communication velocity in **PS1500** to communicate with the PC («Edit General»).



SPEAKERS

(Only for **PS1500** models whose cabinet includes a speaker box).


Check that the special cable which runs from the speakers box is connected to this jack.

► **Note:** If, after turning on your PS1500, you hear no sound, before doing anything else, check for the correct connection of the speakers cable.

HEADPHONES

Two headphones jacks are available under the keyboard on the extreme left of the instrument. Each jack can accept a standard pair of stereo headphones.

Private listening is achieved by inserting the headphones into the HEADPHONES 1 jack (the internal speakers are automatically disinserted only by this jack).



AUDIO/VIDEO INTERFACE

The Baldwin Audio/Video Interface provides PS1500 with additional connection possibilities as well as a Sampling feature.

RGB, S-VHS Video outputs

Connect an RGB monitor, a domestic television or a closed circuit video system to these jacks. The domestic TV has to operate in A/V mode.

The possible connections are shown in the table set out below.

Mic/Line Input + Gain

The **Mic/Line** audio input is intended mainly for Sampling but can also be used to input Microphone and/or Line signals in order to sing or play through the **PS1500** internal amplification. The signals can be processed by the on-board Digital Effects processor.

Recorded Samples are stored in the instrument's battery-backed Sample-RAM.

The **Gain** control regulates the volume of the input signal before entering the system.

The general volume of the Mic/Line input signal is controlled with the front panel MIC/LINE panel slider. The Mic/Line Input parameter must be set to "ON" in «Edit General» in order to process the incoming signal.

PS1500

The Display

The main display

The main display activates every time **PS1500** is turned on and is what is shown in normal playing conditions. The power-up status shows the Grand Piano preset selected for the Upper 1 section.

The main display shows the sounds assigned to the keyboard tracks (Upper 1, Upper 2, Lower), regardless of their active/mute status, the name of the current Preset, the Tempo setting (valid for Styles and Songs), the name of the selected Style, Song/Style or Song and the Chord/Measures indicator which monitors Style chords in Style mode or the measures in Song playback mode.

When a Style is disabled, "E.Play=Off" is displayed on the top line to indicate that the EASY PLAY button is deactivated.

Selection windows

Selection windows are opened when a GROUPS button is pressed in order to select an element related to the selected GROUP (Sound, Style & User Style, Song/Style, Song and Programmable Preset).

Selection windows are "timeout" displays, shown for a short period of time, enough to select the displayed items with the Function buttons (F1...F8). After selection, the main display is restored. If you don't select an item during the timeout period, the main display is restored automatically after approx. 3/4 seconds.

Other types of Selection windows

The "Harmony Type", "Restore", "Easy Play/Split", Touch Sensitivity", "Digital Effects" and "Disk" buttons also open selection windows, but with a structure specific to the function. These type of windows are permanent and require pressing the ESCAPE button or the corresponding function button to close them.

TEMPO	STYLE/SONG	CHORDS / MEASURES	UPPER 2
178	Sou1BB	*****	Bk1: SLOSTR
PRESET	GROUP	LOWER	UPPER 1
GPiano	POP	Bk1: SLOSTR	Bk1: PIANO1

Main display showing the Grand Piano preset

TEMPO	STYLE/SONG	CHORDS / MEASURES	UPPER 2
178	Sou1BB	EasyPlay=Off	Bk1: SLOSTR
PRESET	GROUP	LOWER	UPPER 1
GPiano	POP	Bk1: SLOSTR	Bk1: PIANO1

Main display showing Styles disabled

178	Sou1BB	C maj7-9	Bk1: SLOSTR
GrandP	POP	Bk1: SLOSTR	Bk1: PIANO1

Main display showing the current Style chord

120	Fres01	Mes=1 :1	Bk1: BRASS
			Bk1: ORGAN3
			Bk1: SOFSAX

Main Song display showing the Measure counter

Bk1	PIANO2	HONKY	EL.PN2	CLAVIN
PIANO1	PIANO3	EL.PN1	HARPSI	

Sound selection window showing 8 Sound names of Bank 1 arranged in correspondence with the Function buttons.

1/1	HARMONY TYPE:[OPEN 2]
	Clse Opn1 Opn2 Bloc Oct. Oscar Jazz Rock

Harmony Type selection window

1/1	MODE/SPLIT POINT:
	Mode=Full Split Point=F#3

The Mode/Split Point window showing two variable parameters

1/1	TOUCH SENSITIVITY
	Off Soft Medium Hard

The Touch Sensitivity window showing four parameters

1/4	LOAD: Styles	Style	Sample
	SLOW Song	MidiFile	Presets All

Disk Load window showing various load functions. The Save page is identical.

RECORD WINDOWS

These types of windows appear when **PS1500** is set to record a User Style, Song/Style or Song. The display differs slightly for each specific element. In all cases, the metronome is activated automatically when the RECORD button is pressed. The top line of the display shows "MT" to indicate the activation. A recorded track is set to "play" and a mute track to "off".

The **User Style Record** window shows (on the top line) the Tempo setting, the Metronome activation symbol (MT), the User-Style name, the Measure counter and the name & bank of the Sound assigned to the selected track. The bottom line shows the five parameters representing the Style tracks that can be recorded (Drums, Bass, Acc1, Acc2, Acc3). The selected parameter is shown as a Program Change number. On the extreme right is the Style Variation and Riff being recorded (Variation: Maj, Min, 7th, etc.).

The **Song/Style Record** window shows (on the top line) the Tempo setting, the Metronome activation symbol (MT), the Song/Style name, the Measure counter and the name & bank of the Sound assigned to the selected keyboard track in record. The bottom line shows the name of the Style being recorded, the record status of the Chord track (in this case active to record chord events) and three parameters representing the keyboard sections (Upper 1, Upper 2, Lower). The selected track is shown as a Program Change number.

The **Song Record** window shows (on the top line) the Tempo setting, the Metronome activation symbol (MT), the Song name, the Measure counter and the name & bank of the Sound assigned to the selected track. The bottom line shows eight parameters representing the Song Tracks (tracks 01-08). Tracks 09-16 are shown by pressing the Track Select button in the 16 Track Recording Studio. The selected parameter in record is shown as a Program Change number.

```
120 MT User01 Mes=00 :1 Bk2Stand1:Tr01
113 Off Off Off Off VAR1:Maj
```

User Style Record window showing the Major riff of Variation 1 of the Drums track selected for recording

```
120 MT Free01 Mes=00 :1 Bk1PIANO1:Tr08
8btStd Chord=Rec off off 1
```

Song/Style Record window showing the Upper 1 keyboard section selected for recording

```
120 MT Empty1 Mes=00 :1 Bk1FINGER:Tr02
Play 34 off off off off off off
```

Song Record window showing Song Track 1 recorded and Track 2 selected for recording

EDIT PAGES

The Edit environments consist of several parameters spread across more than one "Edit page". The pages are scrolled with the Page+/Bank+ and Page-/Bank- buttons. Each page is identified by a respective number and name of the selected parameter.

Edit pages differ from one another but they have in common a set of parameters (in abbreviated form) arranged across the display in correspondence with the Function buttons. The parameters are selected with the Function buttons and each selection shows the name of the parameter in full on the top line.

The status of the "On/Off" type parameters is changed by pressing the corresponding Function button repeatedly. The value of numerical parameters is changed by rotating the Dial or using the corresponding Slider (F1...F8).

```
3/9 PRESET:DETUNE [Tk07]
00 00 00 00 00 00 +04 00
```

Page 3 of «Edit Preset» showing Detune parameter independently assignable for each track

```
1/1 EDIT DSP:[REVERBS]
Hall 1 Chorus 1 RevSend EffSend EDIT
```

Effects selection page showing the Effects parameters (variable) and the Editor which activates a typical Edit page.

```
1/3 SOUND EDIT:STRING [VOLUME]
Vol=127 Dyn=Off Cut=100 Res=100
```

Sound Edit page showing the 4 macro parameters which modify the selected Sound

USER MESSAGES AND WARNINGS

These types of windows show confirmation requests for a current operation, information regarding the next step to take, warnings against a malfunction or bad operation, etc.

These messages are closed with ENTER or ESCAPE.

```
ERASE:SONG INITIALIZE MySong
Are you sure? Press [ENT] or [ESC]
```

Confirmation request for the Erase Song operation

```
LOAD:MySong.WK3
[PRESS START TO PLAY OR ENTER TO LOAD]
```

User Message showing the next step to take

```
*** CORRUPTED DATA ON DISK ***
Retry, or change Disk
```

Warning against a disk failure

Data Entry

Inserting numeric values, selecting options and navigating between the **PS1500** parameters of the edit pages is achieved with specific controls:

- Navigation (Function Select buttons F1...F8), Page+/Bank+, Page-/Bank- buttons.
- Data Entry (DIAL, Function buttons F1...F8, Sliders F1...F8, Keyboard, ENTER and ES-CAPE buttons).

NAVIGATING


Use the **Function buttons** to navigate from one parameter to another in the Edit pages.

Selecting a parameter with the corresponding Function button activates the parameter for a change of value or status.


For example, you can change the Sound (Program Change) assigned to the Tracks of a Preset in Page 1 of «Edit Preset» by activating the required track with the corresponding Function button. The selected track starts to flash, indicating that it is ready to accept a change.

In some cases, the location of a parameter corresponds to two (or more) function buttons: the parameter can, therefore, be selected by one of the corresponding Function buttons.


Use the **Page+/Bank+**, **Page-/Bank-** buttons to pass from one edit page to another. Use the same buttons to change Sound bank in Sound selection situations.



Preset: Program Change page showing Track 3 selected with F1



Edit Hall (Reverb) page: Vol parameter can be selected by either F1 or F2, RevTime by F3 or F4, etc..



Use of the Page+/Bank+ and Page-/Bank- buttons to change edit page.

MODIFYING THE PARAMETER VALUES

The value or status of a selected parameter can be changed with the Dial. For On/Off situations, the corresponding Function button toggles between the two states. In many situations, the Sliders F1...F8 can be used to change parameter values without having to select the parameter beforehand. In Edit situations, the bottom LED indicator of the Sliders F1...F8 turns on to show that the Sliders are enabled as Data Entry devices.

Modifying parameters with the DIAL

Change the values of the selected parameter by rotating the DIAL. In normal playing conditions, the DIAL is active for real time Tempo changes, while in Edit situations, it enters data continually: clockwise rotation increases while counter-clockwise rotation decreases.

Modifying On/Off parameters with the Function button



If the parameter is an On/Off function, toggle between the two states with the corresponding Function button after selecting the parameter.

For example, the Local Off parameter setting of the tracks in the page shown opposite can be toggled between ON and OFF by pressing the corresponding Function button repeatedly.


Modifying parameters with the Sliders

In most Edit situations, the Sliders F1...F8 activate as data entry devices for the parameters that correspond to the function buttons F1...F8.

In such cases, the Sliders intervene directly on the corresponding parameter without having to select the parameter beforehand.




MIDI: MIDI Channel page. Assign a different MIDI channel to the selected track using the DIAL.



Edit General Pedal page: Pedal 1 functions selected with the Dial



MIDI: Section Local Off page showing On/Off parameters



MIXER: Pan page. Use the sliders to change the pan settings without selecting the corresponding parameter

INSERTING ALPHANUMERIC DATA

In Name Write situations (Presets, Songs, User Styles, Disk files, etc.), the keyboard activates as a source of alphanumeric data. Each note of the keyboard corresponds to a letter of the alphabet or a number.

The relative display shows a flashing active zone ("New name") where a name of up to 6 characters can be inserted. Disk files accept up to 8 characters. Characters are inserted in the active zone using the keys of the keyboard.



Preset Name display



User Style name display

The alphanumeric keyboard configuration

The configuration of the alphanumeric data is shown in the diagram below.

The notes from D2 - G2 on the left provide some word processing functions:

- D2: CAPS - Toggles between Capitals On and Capitals Off.
- D#2: INS/OVER - Toggles between Insert and Overwrite. Insert inserts a character between two entries. Overwrite cancels a character at the cursor position. The display shows the status of this option in name write situations.


- E2: SPACE - inserts a space
- F2: DELETE - cancels an entry at the flashing cursor position.
- G2: ← (BACKSPACE) - cancels the previous entry.

The Transpose +/- buttons are also utilized.

Transpose+/Transpose-: These two buttons move the flashing cursor forwards and backwards respectively.

Press ESCAPE to close the name write page.

Press STORE PRESET to store the new name to the Preset.




Inserting measures

In Song mode, as an alternative to the Fast Forward and Fast Reverse functions, you can pass directly to any measure of a Song by specifying the measure number in an appropriate "active zone", activated by pressing both >> and << buttons at the same time.

The required measure number is specified using the black numerical keys on the right of the keyboard.

Specify the required number and press ENTER to confirm.

After confirming with ENTER, the active zone closes and the Song pointer passes directly to the specified measure. Press PLAY or CONTINUE to start the Song from the specified point.




Song display showing the "Insert measure" active zone flashing

ENTER/ESCAPE

ENTER confirms an operation and the values assigned to modified parameters. In some edit pages, Enter confirms a parameter value and executes an operation (for example, a Load operation in the Disk environment, or a quantize entry).

ESCAPE cancels a selected operation or the values assigned to a selected parameter. In most cases, pressing Escape returns to a main display.



ENTER, ESCAPE buttons

• 4 Sounds & Presets


THE SOUNDS AND TRACKS

A Sound is assigned to each track of a Preset. (The **Grand Piano Preset** is an exception that is discussed separately on page 8).


Keyboard modes

The keyboard tracks can be configured to play on the keyboard in two different ways, called keyboard modes:

- **Full keyboard mode** - the Upper tracks (7 and 8) play across the entire keyboard range. The Lower section is disabled for activation (in Full keyboard mode only).




- **Split mode** - the Upper tracks (7 and 8) play to the right of the split point while the Lower track (6) plays to the left from the Split point down. If you deactivate the Lower track when Easy Play is off, the Upper tracks are assigned to the entire keyboard. If you deactivate the Lower track when Easy Play is on, the Upper tracks remain assigned to the part of the keyboard above the split point while the Lower does not play.



Keyboard Activators

The three Keyboard Activators (Upper 2, Upper 1, Lower), located to the right of the display under the Select buttons, activate or deactivate the keyboard tracks. For example, if an Upper track is muted, by pressing the corresponding Activator button, the sound assigned to the track will activate for play (press once to activate, press again to deactivate).

The Sounds and the Keyboard modes can be changed instantly by selecting a Preset or a Style.



WAYS OF SELECTING SOUNDS

PS1500 allows you to select single sounds or a combination of different sounds.

- To select a single sound, select the track that will accommodate it, press one of the buttons of the SOUND GROUPS section and select a sound with the corresponding Function button.
- To select a sound combination, select a Preset or a Style. Along with the sounds, the keyboard modes, the track status, the effects and the general settings also change.

Selecting Single Sounds


To assign a Sound to a keyboard track (Upper 1, Upper 2 or Lower) in Style/Preset mode, you must first *select* the track with the **SELECT** buttons (Upper 2, Upper 1; Lower) located to the right of the display. The **SELECT** buttons enable the displayed keyboard tracks for a Sound change. A selected track is shown flashing and only one section at a time can be in an enabled state. A selected track (flashing) is not necessarily active for play.

To assign a Sound to any track, including one not displayed and regardless of the current mode, you must first enter Edit Preset mode (press the Preset button) to enter the ProgramChange page. The procedure is explained in detail on page 11.

Assign a Sound to a keyboard track


1. Press one of the SELECT buttons.

- A** Press UPPER 2 to select the Upper 2 keyboard track;
- B** Press UPPER 1 to select the Upper 1 keyboard track;
- C** Press UPPER 1 + UPPER 2 together to select the LOWER keyboard track.



2. Press a SOUND GROUPS button.

The display shows a bank of 8 Sounds belonging to the selected Group. The current Sound Bank is shown in the top left hand corner of the display.



3. Select a Bank containing the desired Sound using the PAGE+/BANK+ or PAGE-/BANK- buttons.

Each Group can contain up to 3 banks. The Bank number corresponds to the BankSelect MSB (CC00) MIDI message.

Bank 1 sounds are General MIDI compatible, while Banks 2 and 3 contain variations of Bank 1. Banks 2 and 3 of the Percussive Sound group contain Drumkits.

► **Note:** *PS1500* houses 16 Drumkits in memory (Banks 2 and 3). Consult the Drumkit tables in the Appendix for the relative percussive sound mappings.

4. Select the desired Sound or Drumkit with the Function button.

The selected Sound is assigned to the selected track (flashing). The display returns to normal.

► **Note:** *If a Sound is not selected from the selection window within the first 2/3 seconds, the display returns to the previous situation automatically.*

► **Note:** *You cannot assign a Sound to a keyboard section that is not selected (flashing).*




► **IMPORTANT:** *A Drumkit must be assigned to a keyboard section active to play across the full keyboard (Upper 1 or 2 in Single or Dual mode).*

5. Play on the keyboard.

Play and repeat the selection procedure to listen to other sounds.

If you assign a Drumkit to Upper 1 or Upper 2, you'll hear a different drum sound for each note played. If other keyboard sections are active, mute them to hear the drum sounds alone.

► **Note:** *To avoid the closure of the selection window each time you select a Sound, press DISPLAY HOLD.*



Assigning a Sound to the GRAND PIANO preset

The GRAND PIANO Preset accepts a sound change using the method already described. However, whatever change you make remains temporary and is instantly cancelled if you either select the GRAND PIANO preset again, select a Preset from the PROGRAMMABLE PRESETS, or enter Song/Style or Song modes.

For example, you can assign a Guitar sound to the Upper 1 section in order to play Guitar with the Grand Piano parameters (effect, volume, etc.), BUT, you cannot store the change to the Grand Piano Preset.

To assign Sounds to tracks other than the keyboard tracks

To assign sounds to tracks 1-16, use the method described on page 11.




Selecting Presets

Select a Preset when you want to change the whole keyboard sound combination, not just a single sound.

1. Press one of the PROGRAMMABLE PRESETS buttons.

The timeout display shows 8 Presets to choose from.




2. Select a Preset using the corresponding Function button.

Once a Preset has been selected, the selection window closes and the display returns to its previous status showing the keyboard sounds of the current Preset.

The setting recalled by the Preset include: the keyboard mode, the track status, the Sounds assigned to the tracks and the track assignments for the action of the pedals.

The name of the selected Preset appears on the bottom line of the display.




USE PAGE+ / BANK+ AND PAGE- / BANK- TO SELECT THE PRESETS

You can select Presets in increasing or decreasing order with the **Page+ / Bank+** or **Page- / Bank-** buttons.

1. Press PAGE+ / BANK+ select the next Preset.

The Preset advances one step. Press the same button repeatedly to scroll through the Presets in increasing order.

► **Note:** This operation is valid only for the Presets of the PROGRAMMABLE PRESETS. Once you reach the last Preset of button 8 with Page+, it is not possible to proceed. Similarly, when you select Presets in decreasing order, once you reach the first Preset of button 1 with Page-, you cannot proceed further. With the GRAND PIANO PRESET, the Page buttons are disabled.




2. Press PAGE- / Bank- to select the previous Preset.

The previous Preset is selected. Press the same button repeatedly to scroll through the Presets in decreasing order.

► **Note:** You can assign one of the programmable pedals to perform this operation. "Pedal Function assign" «Edit General».

► **Hint:** If you programme your Presets to change Styles (with Style Lock off), you can change Styles using the Page+/- buttons, or an appropriately programmed Pedal (Preset+ or Preset-).



THE GRAND PIANO PRESET

The Grand Piano Preset is an exception to the rule because, unlike the Presets of the PROGRAMMABLE PRESETS section, this preset recalls the Grand Piano sound with fixed parameter values (volume, pan setting, reverb effect, etc.) which, if modified, cannot be memorized to the Grand Piano Preset. If you attempt to store any modifications that you apply to the GRAND PIANO Preset, the instrument “invites” you to save to the Programmable Presets.

What happens when you press the GRAND PIANO button depends on the current mode selected.

Select Grand Piano in Preset mode

If you are currently playing in Preset mode and you select the GRAND PIANO preset, the current Preset is cancelled and substituted by GRAND PIANO. The GRAND PIANO PRESET is displayed for a short period then the display switches to the standard default situation. In addition, the Upper 2 keyboard section is cancelled and the Lower keyboard section is disabled. Upper 1 activates across the Full keyboard.

Select Grand Piano in Style mode


If you are currently in Style mode and the Style is not playing, selecting GRAND PIANO recalls Variation 2 of the Style 8 Beat Standard from the 8 BEAT Style Group (unless already selected). The keyboard sounds are substituted by GRAND PIANO, the Upper 2 section is cancelled and the Lower section is disabled. Upper 1 activates across the Full keyboard.

If the Style is playing, the current Style remains unchanged while the keyboard sounds are substituted by the GRAND PIANO preset as above.

Select Grand Piano in Song/Style or Song modes

If you are currently playing with Songs or Song/Styles and you select the GRAND PIANO preset, the current mode is cancelled and the instrument sets to Real Time mode with GRAND PIANO selected to play across the full keyboard.

You can, therefore, select GRAND PIANO whenever you want to escape the current mode to play a single sound.



SELECT SOUNDS, PRESETS OR STYLES USING DISPLAY HOLD

Normally, after selecting an item from a selection window, the display returns to the previous situation automatically.

If you activate DISPLAY HOLD (LED on), the selection window remains locked after selecting an item. This allows you to continue selecting items until you are satisfied with the result.

1. Press DISPLAY HOLD.

The LED of the button turns on.

2. Press a button from the SOUND GROUPS, the PROGRAMMABLE PRESETS or the STYLE GROUPS.

In this case, a Sound.

3. Select an item.





The selection window remains locked.

4. Select other items as required.

5. Press another Group button to open a different selection window and select another item.

6. Press ESCAPE to close the selection window without cancelling Display Hold.

Press DISPLAY HOLD to cancel the function (LED off).



How to Program Presets

PS1500 contains 64 Programmable Presets stored in ROM memory. 32 of these are factory-programmed to recall various combinations of keyboard sounds (maximum 3) for real time playing. The remaining 32 are "empty", ready to receive user-programmed data. In the Appendix, you'll find a table showing the names of the factory set Presets, the memorized Sound combinations and keyboard mode.

This section describes the most common changes that can be applied to the Programmable Presets.

Once a Preset has been modified, it can be saved to RAM by pressing STORE PRESET. Without saving, the modifications remain temporary and are lost when you select a different Preset, or reselect the same one.

NOTE: The STORE PRESET operation is not valid for the GRAND PIANO preset.

HOW THE SOUNDS ARE ARRANGED

In default conditions, the Presets recall factory-set Sound combinations. You can change one or more Sounds of any Preset and store the modifications to memory so that the Preset recalls your preferred Sound combination when it is selected.

The Sounds are arranged in 16 Groups of 3 Banks each. Each Bank contains 8 Sounds.

The Sounds of Bank 1 are arranged according to General MIDI standards, while those that reside in other Banks (2 and 3) are variations of Bank 1. The table shown opposite lists the **PS1500** Sound Group names.

Sound Group name	ProgramChange
Piano	1 ... 8
Mallet (percussion)	9 ... 16
Organ	17 ... 24
Guitar	25 ... 32
Bass	33 ... 40
Strings	41 ... 48
Ensemble	49 ... 56
Brass	57 ... 64
Reed	65 ... 72
Flute	73 ... 80
Synth lead	81 ... 88
Synth pad	89 ... 96
Synth SFX	97 ... 104
Ethnic	105 ... 112
Percussive	113 ... 120
Special SFX	121 ... 128

PS1500 Sound Group names

ASSIGNING SOUNDS TO TRACKS

The method described on page 3 refers to the direct method applied to the three keyboard tracks.

To assign Sounds to the tracks not shown in the main display (Style, Song/Style, Song or a MIDI Preset used by an external MIDI device), use the method described below.

1. Press PRESET in the EDIT section.

The first page of «Edit Preset» opens showing the Program Changes assigned to tracks 1-8 of the current Preset.

Press TRACK SELECT to view tracks 9-16.

The selected track is shown by the flashing ProgramChange number (PC). The corresponding name and Track number is also displayed in the top right hand corner.

2. Select a track (Pr. Change) with the corresponding Function button.

The Pr. Change number starts to flash.

3. Press a SOUND GROUPS button.





The timeout display shows 8 Sounds to choose from.

4. Select a Sound using the Function buttons.


Each Group contains 3 Banks. Use the Page+/Bank+ or Page-/Bank- buttons until the required sound is displayed.

The Sound is assigned to the selected (flashing) track. The display returns to the previous status showing the updated situation.

The new situation remains in memory as a temporary status until changed again, or until you recall the default conditions by selecting the same Preset again.




5. Press **ESCAPE** to close the Edit Preset: Program Change page.



6. To save the change, press **STORE PRESET** followed by **ENTER** to confirm.

The new situation is permanently memorized.

You can restore the original settings of the Preset using the Restore Preset command, explained at the end of this chapter.



CHANGING THE TRACK STATUS

The keyboard tracks (Upper 1, Upper 2, Lower = Tracks 8, 7, 6 respectively) of a Preset can be set to either **active** or **mute** status.

An active track can play, while a muted one cannot. It is possible to toggle between the active and mute status in order to instantly add or remove a Sound while playing.


For the keyboard tracks, it is possible to toggle between the active and mute status by intervening directly on the keyboard activators (Upper 1, Upper 2, Lower buttons).

To change the status of the keyboard tracks

- Press **UPPER 1** to activate/mute the Upper 1 section and press again to return to the previous status.

The same applies for the Upper 2 and Lower buttons.

▶ *Reminder: When FULL MODE is selected, LOWER is disabled. In SPLIT MODE, LOWER is enabled.*



The modified status of the tracks can be memorized to a Programmable Preset by pressing **STORE PRESET**. See page 19 for information regarding storing Style Presets.

Changing the Track status

The tracks not normally shown on the main display (Style, Song/Style or Song tracks) can be activated/muted by intervening on the corresponding track buttons in the 16 Track Recording Studio (sequencer). The Style, Song/Style and Song tracks engaged by the sequencer are identified by the status of the LED of the corresponding track button (tracks 1 - 16).

The change the status of a Style, Song/Style or Song track


- Press one of the active track buttons in the Sequencer to mute a track and press again to return to the previous status.

The Style accompaniment tracks correspond to tracks 1, 2, 3, 4 and 5 (Drums, Bass, Accomp. 1, Accomp. 2, Accomp. 3 respectively).

The Song/Style tracks correspond to tracks 1 - 8.

The Song tracks correspond to tracks 1 - 16.

The LED shows the active/mute status of the track. When the LED is on, the track is active; when off, the track is mute.



CHANGING THE KEYBOARD MODE

The keyboard Sounds can be set to one of two keyboard modes:



- **Full Mode**- The tracks Upper 1 and Upper 2 play across the entire keyboard range. The Lower section is disabled for activation.
- **Split Mode** - The tracks Upper 1 and Upper 2 play to the right of the split point while the Lower track plays to the left from the Split point down. When Easy Play is off (LED off), deactivating the Lower track assigns the Upper tracks to the entire keyboard. When Easy Play is on (LED on), deactivating the Lower track does not change the status of the Upper tracks (they remain assigned to the part of the keyboard above the split point), while Lower does not play.

The following example outlines how to select the keyboard modes.

1. Press and hold EASY PLAY/SPLIT.


The display changes to the MODE/SPLIT POINT window showing two parameters: Mode and Split. The Mode parameter (which determines the Full or Split modes) will already be selected (flashing).

2. If the Mode parameter is not selected (flashing), press the corresponding Function button F1 or F2.




3. Rotate the DIAL to set MODE to FULL or SPLIT as required.

You can also toggle between the two states by pressing the corresponding Function button repeatedly.




4. Press ESCAPE to close the window.

The display returns to the previous status.




5. Set the Keyboard sections as required.

Activate/deactivate the keyboard sections by intervening on the Keyboard activators. In Full mode, Lower is disabled. If you attempt to activate Lower by pressing the button, the display shows an appropriate timeout warning which deactivates automatically after 2/3 seconds.



6. Press STORE PRESET followed by ENTER if you want to store the new setting to the current Preset.

Each Preset can store a different configuration of the Keyboard Mode and Keyboard activators. If you select another Preset, or select the same Preset before memorising the settings, they will be lost.



BALANCE THE SECTION VOLUMES WITH THE ACCOMPANIMENT SLIDERS

Presets also memorize the track volumes, but you can modify the recalled settings in real time by moving the Accompaniment sliders as required.

When working with Styles, Song/Style or Songs, or playing in real time with the Presets, mix the tracks with the sliders. In Style and Song/Style modes, the markings across the top correspond to the accompaniment and keyboard tracks. Drums, Bass, Accomp 1, Accomp 2, Accomp 3 regulate the Style accompaniment tracks while Upper 1, Upper 2, Lower mix the keyboard Sounds. In Song mode, Drums=Track 1, Bass=Track 2 and so on. In this situation, the top LED of the sliders turns on.


In Edit Mixer, you can see the status of the track volumes and modify them with the corresponding sliders (top LED on). Use Track Select to view the remaining 8 tracks (9 ... 16) and use the same sliders to obtain the required overall mix.

To save the volume changes, save the Preset using STORE PRESET.

Lock the mixer setting for all Presets

Once you have balanced your tracks, you can lock the settings for all Presets by using the MIXER LOCK function in the ACCOMPANIMENT section.

Simply press the button to turn MIXER LOCK on. When this button is on, all Preset and Style selections that you make play with the locked mixer settings. Whatever changes you make to the mixer settings remain memorized until changed again.



TRANSPOSING THE TRACKS (BY SEMITONES)

The Preset tracks can be individually transposed in semitone steps using the "Section Transposer" function in «Edit Preset».





The range over which a section can be transposed is ± 24 semitones (2 octaves) and the settings can be stored to the Preset.

1. Press PRESET in the EDIT section.
2. Press PAGE+/BANK+ to enter the SECTION TRANSPOSER on page 2.
3. Select the track that requires transposing using the Function buttons.
4. Rotate the Dial to set the required transposition (+ value = transpose UP, - value = transpose DOWN).

Instead of using the DIAL, you can change the track transpose setting by means of the corresponding sliders (F1...F8). The bottom LED of the sliders turns on to indicate that they are enabled as data entry controls. If you use the sliders, it is not necessary to select the tracks first.

5. Escape «Edit Preset» by pressing ESCAPE.

To save the transposition settings, save the Preset using STORE PRESET.



How to Store Presets

Use the STORE PRESET button to save a Preset, to create a new one or to change the name

Save a Preset if you want to conserve the changes that have been applied. The temporary changes made to a Preset are lost if you select a different one or the same one again or select a Style.

You can save the changes to the current Preset, or to a different one. The changes can be memorized to any of the 64 Programmable Presets available.

► **Note:** The Store Preset operation memorizes all modifications made to the keyboard tracks as well the Style tracks. If you modify the tracks of a Style, you can store the modified Style Preset to the Preset slots.

► **Note:** The GRAND PIANO preset cannot memorize modifications.


Presets can memorize the following data:

Data saved to a Preset

- The panel status;
- EDIT parameters (Preset, MIDI, Mixer, Sound, Effect - some General parameters);
- Tempo (for eventual enabled Style);
- Style and Variation (for eventual enabled Style);

Presets containing Sounds or a Drumkit modified in «Edit Sound» show the letter "E" as a prefix before the corresponding Pr. Change number in the first page of «Edit Preset».

For example:



► **Note:** The changes made to the factory-set Presets do not damage the original **PS1500** data in any way because they are modified RAM copies. The original data can always be restored with the "Restore Original Preset" or "Restore Original Block" commands in «SYSTEM RESTORE».

► **WARNING** - STORE PRESET saves the Preset to RAM and not to disk. The memorized data is lost when (a) the backing battery runs flat, (b) re-initialisation takes place (the command "Reset All" is given).

Save the Preset that you intend to keep to disk. Use the "Save Preset" procedure in "Disk" mode.


SAVING CHANGES TO THE CURRENT PRESET

Save a Preset to itself if you want to conserve the applied changes (e.g. a section transposition or a section volume change, etc.).

1. Press STORE PRESET.

The «Preset Store» window opens showing the same source and destination Preset.

To save changes to the original Preset, the display parameters need not be changed.




2. Press ENTER to confirm, or ESCAPE to cancel.

Once ENTER has been pressed, the Preset retains the new settings. When this Preset is recalled, it will set **PS1500** with memorized settings.

Presets also memorize the current Tempo and the selected Style and Variation as well as data from the edit pages.

.....
► **Note:** A Style selected from the Style Groups with Single Touch Play active recalls a default Style Preset. If you modify the accompaniment tracks of the Style Preset, you cannot memorize the modifications to the original Style in the ROM locations. The modified Style Preset is stored to the Programmable Preset locations. This provides a means of recalling the same Style arrangement patterns with different Style Presets. See also the Styles chapter.
.....




SAVING CHANGES TO A DIFFERENT PRESET (OR CREATING A NEW ONE)

1. Press STORE PRESET.


The «Preset Store» window opens showing the current Preset at the centre and the destination Preset at the "TO:" location.

Preset numbers 1...8 correspond to Preset 1, 9...16 to Preset 2 and so on.....



2. Rotate the Dial to select the Preset destination.


You can choose from the 64 memory locations available.



3. Press ENTER to confirm, or ESCAPE to cancel.

After the save operation, the display returns to normal showing the new Preset.

► *Note: Whatever Preset data is present at the selected destination will be cancelled by the incoming modified Preset.*



CHANGE THE NAME OF A PRESET

1. Press PRESET. in the EDIT section.
2. Hold PAGE+/BANK+ pressed to scroll to the last page (Page 9) to open the "Preset name" window.

The current Preset name is shown at the "Old name" position.

The "NewName" position will be active, ready to accept your character insertions.






3. Change the Preset name using the keys of the keyboard.

In Name Write mode, the keyboard transforms into a source of alphanumeric data. Each note corresponds to a letter, number or symbol.

Write in a new name by striking corresponding keys of the keyboard. Up to 6 characters can be used to write a name.

How the keys are used for writing in data is explained in the section entitled "Data entry" of Chapter 3 (Basic Concepts - page 3-15).

4. Press ESCAPE to close the window.
5. Press STORE PRESET followed by ENTER to save the Preset name.



RESTORING THE ORIGINAL PRESET SETTINGS

Is it possible to cancel all modifications made to the Presets and restore factory settings.


1. Press RESTORE in the SYSTEM section.

The RESTORE ORIGINAL BLOCK display activates.




2. Press F7 or F8 to select the PRESET command.

The display shows "Restore Original Preset".



3. Press ENTER to confirm the Restore Preset procedure, or ESCAPE to cancel.

All the changes stored to the Presets of the PROGRAMMABLE PRESETS section are cancelled. The original ROM settings of all the Preset parameters are restored.



► **Hint:** If you want to cancel the entire contents of RAM in a single operation, use the "Restore ALL" command. Be sure, however, to save all data that you wish to conserve to disk before confirming the operation.

.....

• 5 The Styles

You can enjoy playing the **Pianovelle PS1500** keyboard sounds in real time while **PS1500** takes care of the auto accompaniment, as if you were playing with a band of musicians. The auto accompaniments are provided by the **PS1500** Styles.

This chapter describes the Style auto accompaniments, how to select them and how to modify the Style Preset which governs each Style.

ABOUT PS1500 STYLES

Styles are a collection of musical patterns representing many types of music, ranging from rock and pop to traditional and ethnic music.

Each Style has 4 Variations consisting of various Intro, Fill-in and Ending patterns. A Style, therefore, provides a complete range of musical structures with which you can create an entire song.

Styles provide automatic accompaniments triggered by chord information received from the **PS1500** keyboard and the patterns change to suit the current chord.

Styles engage 8 tracks: 3 belonging to the real time keyboard sections and 5 engaged by the sequencer for the auto accompaniments. The 5 accompaniment tracks are divided into a Drums track (drum sets widely used in all types of music), a bass track and three accompaniment tracks (Acc1, Acc2, Acc3 - general accompaniment instruments).

PS1500 contains 96 permanent Styles in memory (flash-ROM) and 16 User-programmable Styles in RAM. The Styles are contained in 14 Banks of 8 (12 Rom and 2 User).

The Style accompaniment tracks have several items that can be set, such as the Sound, volume, pan, effects, tempo, muting, tuning, etc. The arrangement patterns are fixed for the ROM Styles while for the User-programmable Styles, they can be freely modified.

User Styles are discussed in a separate chapter.

THE STYLE DISPLAY

The Style Display activates every time the instrument is turned on. When Styles are disabled (EASY PLAY LED off), the top line shows "EasyPlay=Off".

```
178   Sou1BB   EasyPlay=Off  Bk1: SLOSTR
GrandP   POP   Bk1: SLOSTR  Bk1: PIANO1
```

When the Styles are enabled (EASY PLAY LED on), the display shows a string of asterisks until a note or chord is pressed on the keyboard area dedicated to Style chords (below the Split point).

```
178   Sou1BB   *****      Bk1: SLOSTR
GPiano  POP   Bk1: SLOSTR  Bk1: PIANO1
```

```
178   Sou1BB   C maj7-9     Bk1: SLOSTR
GrandP   POP   Bk1: SLOSTR  Bk1: PIANO1
```

All Styles display the currently selected Style Group directly under the Style name.


Selecting Styles

You can choose to select Styles and recall appropriate keyboard sounds automatically (option A), or select Styles without changing the keyboard sounds (option B).

OPTION A: RECALL KEYBOARD SOUNDS AUTOMATICALLY


1. Press SINGLE TOUCH PLAY (LED on).

When SINGLE TOUCH PLAY is on, the sounds memorized in the Style Preset are assigned to all the tracks. Selecting a Style changes the sounds of the accompaniment tracks as well as the keyboard sections. Pressing SINGLE TOUCH PLAY automatically activates the EASY PLAY and MEMORY buttons and the KEY START button.




2. Press one of the STYLE/SONG GROUPS buttons.

Use the first 12 banks of the Style/Song Groups: Swing, Country ... World, Ethnic. A timeout selection window appears showing 8 Styles belonging to the selected Group.



3. Select a Style with the corresponding Function button.

Selecting a Style instantly changes the automatic accompaniment, the accompaniment and keyboard sounds and the effects. If TEMPO LOCK is off, the Tempo also changes. If MIXER LOCK is off, the track volumes also change.



If the arrangements are playing, the new Style enters at the next measure.



OPTION B: SELECT STYLES WITHOUT CHANGING THE KEYBOARD SOUNDS

1. Turn off SINGLE TOUCH PLAY.

When SINGLE TOUCH PLAY is off, selecting a Style changes the accompaniment patterns, sounds and effects of the accompaniment tracks. If TEMPO LOCK is off, the tempo also changes.

The Sounds of the live keyboard tracks remain unchanged.


2. Press one of the buttons of the STYLE / SONG GROUPS section (Swing, Country, Rock, etc.).



3. Select a Style with the corresponding Function button.

Selecting a Style instantly changes the automatic accompaniment pattern together with the sounds and effects of the automatic accompaniment tracks. The Sounds of the live keyboard tracks remain unchanged.

If TEMPO LOCK and MIXER LOCK are off, the tempo and track volumes also change.



Select Presets to recall Styles

Styles can also be recalled by selecting the Programmable Presets. See over.


SELECT A STYLE WITH THE PROGRAMMABLE PRESETS

The Programmable Presets memorize the status of the instrument when the STORE PRESET button is pressed, therefore, they also 'remember' which Style and Variation were active at the time.

► **Note:** Most of the Programmable Presets are factory-set to recall the "8bt Sid" Style, therefore, you may not observe a change of Style.


1. Deactivate STYLE LOCK.

To change Style and Variation by selecting a Programmable Preset, STYLE LOCK must be off.



2. Press one of the PROGRAMMABLE PRESET buttons.

8 Presets are displayed.




3. Select a Preset.

If on, SINGLE TOUCH PLAY deactivates automatically.

The sounds, volumes and effects of the tracks change (revert to those contained in the Programmable Presets).

The Style and Variation that were active at the time of saving the Preset are recalled. If TEMPO LOCK is off, the tempo also changes.



► **Note:** You can also use the PAGE+/BANK+, PAGE-/BANK- buttons to select Presets in increasing/decreasing order.

The Accompaniment tracks

In the Style/Preset mode, 3 tracks are assigned to the keyboard and 5 to the automatic accompaniment. The accompaniment tracks and the keyboard tracks can be changed in the same manner and saved in the Presets (Style Preset or Preset).

To view the Accompaniment tracks

Press the PRESET button in the EDIT section to view all 8 tracks of the Style. The Sound assigned to each track is shown as the corresponding Program Change number.


Press ESCAPE to close the Edit Preset display.

The Style tracks engaged by the sequencer correspond to a specific part of the accompaniment, while those corresponding to the keyboard sections are available for playing in real time.

The following table shows the default configuration of the Style tracks.

Track	Part	MIDI channel
1	Drum	10 (engaged by seq)
2	Bass	2 (engaged by seq)
3	Acc1	3 (engaged by seq)
4	Acc2	4 (engaged by seq)
5	Acc3	5 (engaged by seq)
6	Lower	6 (free for real time play)
7	Upper 2	7 (free for real time play)
8	Upper 1	8 (free for real time play)

Default configuration of tracks and MIDI channels



The Style Controls

Certain buttons on the control panel are dedicated to the control of the Styles and the selection of the variation, fill, intro and ending.

START/STOP

Starts or stops the Style accompaniment playback as well as Song/Style and Song playback. The two LEDs under the button act as a visual metronome: the left LED flashes on the first beat of the measure and the right LED flashes every successive beat.

In User Style record mode, this button also starts the recording (see User Style Recording).


Before pressing START/STOP to start the accompaniment, you can pre-select one of either INTRO, ENDING or FILL to play as an Introduction.

KEY START/CONTINUE

Synchronizes the start of the automatic accompaniment with a note or chord pressed on the keyboard without having to press START/STOP.

When KEY START is selected, the LED turns on to indicate the activation of the function. This button activates automatically when you select SINGLE TOUCH PLAY.

The CONTINUE function operates for Song/Styles and Songs only and is explained afterwards.



KEY START can be turned off by:

- pressing START/STOP to start the accompaniment.
- pressing ENDING while the accompaniment is running.
- pressing KEY START once more to deactivate the function.

KEY START is not turned off by:

- pressing START/STOP while the accompaniment is running.
- pressing INTRO, ENDING or FILL before starting the accompaniment.

KEY START can be used in various situations. The most common use is as follows:

1. Make sure that MEMORY or LOWER MEMORY are on.
Note: If MEMORY or LOWER MEMORY are off, the accompaniment plays while your notes are pressed on the keyboard and stops instantly when the notes are released. If, instead, one of these two functions are active, the accompaniment of the Drum track will continue playing after releasing the keys.
2. When the accompaniment is not playing, press KEY START (if not already activated).
3. You can press one of INTRO, FILL or ENDING to preset the relative function. The LED of the function activated remains on.
4. Play a chord or note with your left hand. The accompaniment starts immediately (eventually preceded by the introductory pattern if selected). The LED of the intro function selected remains on until the cycle of the relative intro function is complete.
5. Stop the accompaniment with START/STOP if KEY START is still on.

6. Play a note or chord with your left hand. The accompaniment starts playing again.
7. Press ENDING or START/STOP to stop the accompaniment. ENDING turns KEY START off.
8. If you have stopped the accompaniment with START/STOP, press KEY START to turn it off.

NOTE: The STOP and PLAY buttons in the 16 Track Recording Studio are disabled in Style/Preset and User Style mode. If you press either of these two buttons in Style/Preset or User Style mode, the display shows the following message:

```

* * * * STOP & PLAY DISABLED * * * *
* *   IN STYLE & USER STYLE MODE   * *
    
```

Press ESCAPE to close the window.

INTRO

Selects an introductory pattern lasting one or more measures. After pre-selecting the INTRO, to start the Style you will need to press START/STOP (or play the left hand notes if KEY START is selected).

Pressed while the Style is playing, the INTRO pattern can play as a Fill.


ENDING

Stops the Style playback with an ending (a 'coda'). With the accompaniment stopped, you can pre-select the Ending to play as an introduction.

You can use the Ending as a fill when passing from one Style to another. While the Style is playing, press ENDING and immediately select another Style. The ENDING cycle plays to the end of the current measure then passes directly over to the new Style.

THE DIAL (TEMPO)

In the display of all play modes (Style/Preset, Song/Style and Song modes), the DIAL is permanently active as a tempo control. Turn if clockwise to increase the tempo or counter-clockwise to slow it down.




► **Note:** If TEMPO LOCK is off when a Style is selected, the tempo also changes when selecting new styles.

Variation, Fill, Style Lock

VARIATION 1,2,3,4

These buttons control the Style Variations. Each button recalls a different version of the same accompaniment.

Each variation includes different patterns for the Basic, Intro, Fill and Ending sections.




FILL<, FILL, FILL>/TAP TEMPO

FILL< plays the Fill cycle then breaks into the previous Variation. If variation 1 is selected, Variation 4 will be recalled.

FILL plays the Fill cycle then continues with the current Variation. When the accompaniment is not playing, this fill can be preset as an Intro.

FILL>[Tap Tempo] plays the Fill cycle then breaks into the next Variation. If variation 4 is selected, Variation 1 will be recalled.

Normally, the Fill cycles plays once only. If you hold the FILL button pressed, it will repeat the Fill cycle continually until released.



TAP TEMPO [FILL>]


This button also acts as the TAP TEMPO function.

With the accompaniment off, beat time on the button. The tempo is established according to

the timing of the last two taps, the relative Tempo value is displayed and the Style accompaniment starts automatically.


The tempo is established according to the current Time Signature, i.e. four taps for 4/4, three for 3/4, etc..

As an audio indication to the rest of the band, the time is tapped out with the sound of drumsticks.



STYLE LOCK

This button determines whether the current Style accompaniment pattern changes or rests unchanged when you select Presets from the PROGRAMMABLE PRESETS.



If STYLE LOCK is off, selecting Presets changes the Style accompaniment patterns, the accompaniment and keyboard Sounds, the effects and track volumes. If STYLE LOCK is on, selecting Presets changes the keyboard sounds only while the Style accompaniment pattern and effects rest unchanged.

The Accompaniment section

This section provides functions which control and simplify Style playing.

EASY PLAY / SPLIT

EASY PLAY/SPLIT is a dual action button.

When this button is on (LED on), all the accompaniment parts of a Style are enabled. If it is not on, you will only hear the Drum track when a Style is started.

SPLIT: If you hold EASY PLAY pressed for about 2 seconds, the display presents two options to choose from: MODE and SPLIT POINT.

MODE: This function allows you to choose from two keyboard modes : FULL and SPLIT.

When FULL MODE is set, the Upper 1 and/or Upper 2 keyboard sections are assigned to the full keyboard while the Lower section is disabled. This allows you to play Styles with the keyboard sounds over the full keyboard range. If you attempt to activate the Lower keyboard section by pressing the LOWER button, the display shows a user-message informing that Lower is disabled in Full Mode.

When SPLIT MODE is set, the Lower section is enabled and allows you to play Styles with one real time sound on the Left hand and one or two different Sounds on the right. If Easy Play is on and Lower is off, the Upper sections do not extend over the full keyboard. If Easy Play is off

and Lower is off, the Upper 1 and Upper 2 sections extend over the full keyboard range.

The Mode setting can be memorized to the Presets.

How to set the keyboard mode is detailed on page 15 in chapter 4 "Sounds & Presets" of the User Guide.

SPLIT POINT

This option allows you to set a new chord split point for the Styles and, therefore, the chord recognition area of the keyboard, extending or shortening it as required.


The Split Point is a general setting which is not stored to the Presets, but remains memorized until changed again.

See "How to set a new Split Point" on page 13.

PIANO STYLE

PS1500 can recognize the chords used in the automatic accompaniment in various different ways. These are: **One Finger, Fingered 1, Fingered 2** and **Free**. These four options are selected in the PIANO STYLE menu which is activated by holding down the PIANO STYLE button for about 2 seconds.

See "The Chord Recognition Modes" on page 11.



MEMORY

When this button is on (LED on), the accompaniment continues to play after releasing the left hand from the keyboard. When off, releasing your left hand causes the accompaniment to stop.

LOWER MEMORY

If this is on (LED on), the notes of the track assigned to the left hand (Lower) are held even if the left hand is taken away from the keys.

The Lower Memory function is useful for holding on 'background' sounds without having to use a Damper pedal (which may be of more use with the Upper sounds).

When off, releasing your left hand will cause the Lower sound to stop playing.

TEMPO LOCK

If Tempo Lock is off, when a Style or a Preset is selected the tempo changes. If the function is on, the tempo will not change.

FADE IN/OUT

FADE IN/OUT fades the accompaniment with a gradual increase or decrease of volume.

Press the button before starting the accompaniment. The Style track volumes are instantly set to zero. Use either START/STOP or KEY START to start the accompaniment. After the start, the accompaniment track volumes gradually increase and reach their programmed peak after a 2 measure (bar) cycle.

Press FADE IN/OUT while the accompaniment is running; all the track volumes gradually decrease and the accompaniment automatically stops at the end of the Fade Out cycle.

During the Fade cycle, the relative LED flashes.

MIXER LOCK

A Preset also memorizes the track volumes. If MIXER LOCK is off, when a Style or Preset is selected the track volumes change too. If it is on, all the volumes of the tracks assigned to the keyboard and accompaniment rest unchanged.

BASS FOLLOW

If BASS FOLLOW is on, the bass part of the auto accompaniment of the current Style plays according to the lowest note of the current chord. If you play a different inversion of the same chord, the lowest note also changes resulting in a different bass note being played.

If off, the bass will follow the original programmed pattern of the Style.

Bass Follow permits real time changes to the otherwise fixed bass pattern of a Style, by playing different chord inversions.

THE CHORD RECOGNITION MODES

There are four possible chord recognition modes available.

- One Finger, Fingered 1 and Fingered 2 require the chord to be played below the Split Point.
- Free allows the chord to be played anywhere on the keyboard, ignoring the Split point.

One Finger - A single note played below the Split Point is interpreted as the root of a major chord. The relative chord symbol is shown as a single letter (e.g. C = C Major).

To obtain a minor chord play the root and the minor third (e.g. C and Eb). For a diminished, play the root and the diminished fifth (C + Gb above or below C). For a seventh chord play the root and the seventh (C + Bb above or below C). For a major 7th, play the root and the augmented seventh (C + B above or below C).

Fingered 1 - Needs at least three notes for the chord to be recognized. If less than three notes are played, the chord is not recognized and the notes played in the left hand are considered 'stray' notes.

Fingered 2 - At least three notes must be played to obtain the full programmed pattern of the Style. If less than three notes are played, the arranger recognizes the chord but only triggers a light accompaniment. Two fingers provides a slightly richer accompaniment than one finger.

One Finger Chords

  C (major)	  C min
  C dim	  C7
  C maj7	

Free (FreeStyle) - The chord is recognized anywhere along the keyboard, even if played in the right hand or using both hands. The chord must comprise a minimum of three notes.


You can play your melody anywhere along the keyboard with the Upper 1 and /or Upper 2 keyboard sounds. Free disables the Lower keyboard section.

The GRAND PIANO PRESET recalls the Free mode by default.

MODIFYING THE CHORD RECOGNITION MODES

The three chord recognition modes are accessed by holding the PIANO STYLE button pressed for approximately 2 seconds.

1. Press and hold PIANO STYLE.




2. Select the required chord recognition mode with the corresponding Function buttons.

F1/F2 select ONE FINGER;


F2/F3 select FINGERED 1;

F3/F4 select FINGERED 2;

F7/F8 select FREESTYLE.



3. Press ESCAPE to close the PIANO STYLE display.




4. Press STORE PRESET and ENTER to save to the current Preset.

The chord recognition modes are Preset parameters, therefore, the Programmable Presets can be independently programmed to recall different chord recognition modes.

► **N.B.:** The recognized chord symbols appear on the main Style display. If an unrecognized chord is played, the chord symbol for the lowest note appears followed by a series of asterisks. For example: "C*****".

► **N.B.:** In order for the chord to be recognized (and for its symbol to be shown on the display) .EASY PLAY must be on.



CHANGING THE SPLIT POINT

The Split Point is:

- the point that separates the Upper and Lower keyboard sections in Style/Preset mode and,
- the point below which the keyboard recognizes chords which trigger the Style automatic accompaniments (*in One Finger and Fingered chord recognition modes*).





The current Split Point setting can be viewed in the MODE/SPLIT POINT display by holding pressed the EASY PLAY button for about 2 seconds. The setting can be modified as required.

- Press and **hold** EASY PLAY/SPLIT to open the option page.
- Press Function button F7 or F8 to activate the Split Point function.
- Rotate the DIAL or play a note on the keyboard (corresponding to the highest note of the Lower split zone) to modify the setting.

The new Split Point is shown in the display. If you entered the wrong note, simply play another.

- Press ENTER to confirm the new Split Point and close the display. Press ESCAPE if you want to cancel the operation (and retain the original setting).

► **Note:** The Split Point is a general parameter (not linked to a particular Preset) which is conserved in memory when the instrument is turned off. The new setting is lost when the "Restore Original Block" operation is carried out or if the back-up memory loses its data due to the total discharge of the battery.



SINGLE TOUCH PLAY

The SINGLE TOUCH PLAY button recalls all the memorized parameters associated to the ROM Styles, including the sounds assigned to the keyboard sections.

If the EASY PLAY and MEMORY buttons are off, pressing SINGLE TOUCH PLAY activates both buttons. Activating SINGLE TOUCH PLAY also turns on KEY START.

If SINGLE TOUCH PLAY is off, you can select STYLES from the STYLES Groups without changing the keyboard sounds.

If you select Presets from the PROGRAMMABLE PRESETS, the SINGLE TOUCH PLAY button deactivates automatically.

HARMONY

Harmony can orchestrate your Style playing, making simple one-note melodies sound as if they are being played by a full orchestra. This button is associated to the Styles and Song/Styles only. Songs cannot exploit this function.

► **Important:** *Harmony operates only when the Easy Play button is on and when the keyboard mode is set to SPLIT.*

On/Off

This button enables (LED on) or disables (LED off) the current Harmony Type selected in the Harmony Type options.

Harmony Type

HARMONY TYPE gains access to the 8 Harmony options. The structure of the automatic harmony is based on the current Harmony Type setting and operates in two different ways:

- **A:** according to the note (or chord) played below the Split Point with Arrange On/Off selected.
- **B:** regardless of the note played or not played below the Split Point.

Type A:

Close: The notes played on the left hand are added to the melody note exactly as played. The harmonizing chord is a closed (or tight) position (notes fall within the same octave).

Open 1: same as close but with an open chord (notes spread over 2 octaves).

Open 2: similar to Open 1 but with the notes played on the left hand randomly assigned to the right .

Block: transforms the melody note into a full four or five note chord, each note in perfect harmony.

Type B:

Octave 1: doubles the note of the right hand by playing an octave higher. No left hand chord required.

Oscar: doubles the note of the right hand with a note two octaves below. No left hand chord required. This structure is based on the harmony typically used by the jazz musician Oscar Peterson.


Jazz: adds two notes above the note played by the right hand, at intervals of a fourth and a minor seventh. No left hand chord required.

Rock: creates a three note chord consisting of the melody note, a fifth interval and an octave interval (e.g. C-G-C'). No left hand chord required.


How to select a Harmony Type option

1. Press HARMONY TYPE

The display shows 8 Harmony options with the selected option flashing.




2. Select the option with the corresponding Function button.



3. Press ESCAPE to close the Harmony Type display.

The selected option remains memorized even after turning off the instrument.




SELECTING PROGRAMMABLE PRESETS DURING STYLE PLAY

You can select Programmable Presets while the accompaniment is playing to change the combination of the keyboard sounds.

1. Activate SINGLE TOUCH PLAY.


EASY PLAY, MEMORY and KEY START activate automatically. Turn off TEMPO LOCK and MIXER LOCK (if on).



2. Activate STYLE LOCK.


If STYLE LOCK is on, the Style and Tempo rest unchanged when you select a Programmable Preset.

If STYLE LOCK is off, when you select a Preset, the Style, Variation and Tempo memorized in the Preset are recalled.




3. Select a Style.

The 16 Track Recording Studio (sequencer) will show the accompaniment tracks recalled by the Style.




4. Press INTRO, ENDING or FILL to activate the introduction.




5. Play a note or chord on the left keyboard area (below the current split point) to start the accompaniment running.

The Intro starts then breaks into the auto accompaniment.

If you press START/STOP to start the accompaniment, the KEY START function deactivates.




6. Play freely.



7. Select a Preset from the PROGRAMMABLE PRESETS section.


The SINGLE TOUCH PLAY button deactivates and the combination of keyboard sounds, the keyboard mode and effects memorized in the Preset are recalled. The sounds and arrangements of the Style accompaniment tracks rest unchanged.



8. Select other Programmable Presets.

Examples: *Selecting Presets during Style play*

9. Stop the accompaniment with **ENDING** or **START/STOP**.




MUTE ONE OR MORE ACCOMPANIMENT TRACKS

While playing Styles, you may want to temporarily deactivate (mute) one or more accompaniment tracks to play the keyboard sounds with, for example, Drums and Bass accompaniment only.

1. Select a Style.


The 16 Track Recording Studio section will show the accompaniment tracks recalled by the Style.



2. Deactivate tracks 3, 4 and 5.


Press each button to cancel the LED.

The relative accompaniment pattern will be excluded from the overall arrangement.



3. Start to play the Style.


Start to play with both hands right away and you'll hear Drums and Bass accompaniment only while other accompaniment instruments are excluded.



4. Introduce the muted tracks at will.

The tracks muted before starting the Style can be introduced at any time during Style play.

You can also mute the accompaniment tracks while the Style is playing.




CHANGING STYLE WITHOUT STOPPING THE ACCOMPANIMENT

It is not necessary to stop the automatic accompaniment when you want to change Style.


You can recall a new Style during the cycle of a Variation, a Fill, Intro or Ending without interrupting it.

An example.


1. Select a Style.



2. Press INTRO, ENDING or FILL to program the Style introduction.




3. Press START/STOP (or use KEY START) to start the auto accompaniment.




Examples: Changing Style without stopping the accompaniment

4. Play normally.




5. Press one of the STYLE GROUP buttons and select a different Style.


The new Style cuts in at the end of the current measure.



6. Play freely with the new Style.




7. Press FILL, INTRO or ENDING.




8. Before the Fill, Intro or Ending cycle finishes, select a different Style and one of its Variations.

The new Style interrupts the cycle and starts playing at the end of the current Fill, Intro or Ending measure. The selected Variation now starts playing.

► **Hint** The Fill breaks into the arrangement immediately and the relative cycle usually plays for one measure only, unless the Fill button is held pressed for a period. The Intro and Ending patterns start their relative cycles at the end of the current measure and can last for more than one measure. Therefore, when changing Styles, the Intros and Endings give you more time to select a different Style.




9. Play freely.




10. Select another Style and press INTRO or ENDING immediately.

The Intro and Ending of the new Style are played, then the new Style starts to play the selected Variation.

► **Hint:** You can switch Styles quickly by activating DISPLAY HOLD to lock the Style selection window



11. Press START/STOP or ENDING to stop the accompaniment.



Tempo

The Style Tempo, shown in the display, can be adjusted while playing by rotating the DIAL.

The current tempo setting can be saved to a Preset.

By saving the Tempo to a Preset, in practice you modify the tempo setting of a ROM Style.

Thanks to the battery-backed RAM, the tempo setting remains memorized after turning off the instrument.

CHANGING THE TEMPO OF A STYLE

- Use the DIAL to change the tempo setting, either before or after starting the Style.

To recall the original tempo, select the same Style again.

► *Note: If a different tempo has been memorized in the Preset, when a Style is recalled by selecting a Preset, the tempo will be that of the Preset and not the original Style.*

SAVE THE TEMPO TO A PRESET

A tempo setting that differs to the default tempo data of the ROM Style can be saved to the Programmable Presets.

1. Select a Style.
2. Modify the tempo with the DIAL.
3. Press START/STOP to listen to the Style.

If the tempo needs further adjustment, rotate the DIAL until you obtain the desired tempo.

4. Press STORE PRESET to save the Preset.

You are prompted to save to the current Preset or to select a different destination Preset.

5. Rotate the DIAL to select a destination Preset and press ENTER to confirm.

To store to the current Preset, press ENTER without rotating the DIAL.

ESCAPE cancels the operation.


► *Hint: Save the Preset to disk to conserve the changes. The Presets remain in RAM after power down but are cancelled when you save other Presets to the same locations.*

RESTORING THE ORIGINAL PRESET SETTINGS

It is possible to cancel all modifications made to the Presets and restore factory settings.


1. Press RESTORE in the SYSTEM section.

The RESTORE ORIGINAL BLOCK display activates.




2. Press F5 or F6 to select the PRESET command.

The display shows "Restore Original Preset".



3. Press ENTER to confirm the Restore Preset procedure, or ESCAPE to cancel.

All the changes stored to the PROGRAMMABLE PRESETS are cancelled. The original ROM settings of all the Preset parameters are restored.



.....
▶ **Hint:** If you want to cancel the entire contents of RAM in a single operation, use the "Restore ALL" command. Be sure, however, to save all data that you wish to conserve to disk before confirming the operation.
.....