



33-1180 Stereo Headphones and Earbuds

OWNER'S MANUAL — Please read before using this equipment.

Your RadioShack 2 Cool Personal Listening Gift Pack contains two quality headphones—one for home and one for on the go.

- Closed cup ear cushions with adjustable headband provide better isolation and deep bass performance.
- Ultra lightweight earbuds with wind-up carrying case for convenient storage.

Your local Radio Shack store has a full line of adapters, splitters, replacement ear pads, and cable extensions to enhance your enjoyment of your headphones.

OPERATION



Caution: Turn down the volume on the sound source you plan to use before plugging in the headphone.

Note: Both headphones have $\frac{1}{8}$ -inch (3.5 mm) stereo plugs. To connect them to $\frac{1}{4}$ -inch (6.35 mm) stereo output jacks, use an adapter (available at your local Radio Shack store).

1. Insert the headphone plug into the EARPHONE (or similarly marked output jack) on your sound source.
2. Adjust the headband for the best fit, or place the earbuds in your ears.

LISTENING SAFELY

To protect your hearing, follow these guidelines when you use headphones.

- Set the volume at the lowest setting before you begin listening. After you begin listening, adjust the volume to a comfortable level.
- Do not listen at extremely high volume levels. Extended high-volume listening can lead to permanent hearing loss.
- Once you set the volume, do not increase it. Over time, your ears adapt to the volume level, so a volume level that does not cause discomfort might still damage your hearing.

Traffic Safety



Do not wear headphones while operating a motor vehicle or riding a bicycle. This can create a traffic hazard and could be illegal in some areas.

Even though some headphones let you hear some outside sounds when listening at normal volume levels, they still can present a traffic hazard.



 **RadioShack**[®]
www.radioshack.comsm

© 1999, 2001 RadioShack Corporation. All Rights Reserved.
RadioShack and RadioShack.com are trademarks
used by RadioShack Corporation.

SPECIFICATIONS

Headphone

Frequency Response 45-12,000 Hz
Maximum Input Power 100 mW
Impedance 36Ω
Nominal Sensitivity 95 dB
Total Harmonic Distortion <0.5 at 95 dB SPL,
400 Hz, and 1KHz
Cord Length 8.0 ft.

Earbuds

Frequency Response 80-20,000 Hz
Maximum Input Power 100 mW
Impedance 32Ω
Nominal Sensitivity 82 dB
Total Harmonic Distortion <1.0 at 95 dB SPL,
400 Hz, and 1KHz
Cord Length 4.0 ft.

Limited Ninety-Day Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, 200 Taylor Street, 6th Floor, Fort Worth, TX 76102

We Service What We Sell

12/99

RadioShack Corporation
Fort Worth, Texas 76102

33-1180
Printed in USA