



Avaya Call Management System
Sun Fire V880 Computer
Hardware Installation, Maintenance, and
Troubleshooting

585-215-116
Issue 2.0
June 2004

© 2004 Avaya Inc.
All Rights Reserved.

Notice

While reasonable efforts were made to ensure that the information in this document was complete and accurate at the time of printing, Avaya Inc. can assume no liability for any errors. Changes and corrections to the information in this document may be incorporated in future releases.

Documentation disclaimer

Avaya Inc. is not responsible for any modifications, additions, or deletions to the original published version of this documentation unless such modifications, additions, or deletions were performed by Avaya. Customer and/or End User agree to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation to the extent made by the Customer or End User.

Link disclaimer

Avaya Inc. is not responsible for the contents or reliability of any linked Web sites and does not necessarily endorse the products, services, or information described or offered within them. We cannot guarantee that these links will work all of the time and we have no control over the availability of the linked pages.

Warranty

Avaya Inc. provides a limited warranty on this product. Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this product, while under warranty, is available through the following Web site:

<http://www.avaya.com/support>

Preventing toll fraud

"Toll fraud" is the unauthorized use of your telecommunications system by an unauthorized party (for example, anyone who is not a corporate employee, agent, subcontractor, or person working on your company's behalf). Be aware that there may be a risk of toll fraud associated with your system and that, if toll fraud occurs, it can result in substantial additional charges for your telecommunications services.

Avaya fraud intervention

If you suspect that you are being victimized by toll fraud and you need technical assistance or support, call Technical Service Center Toll Fraud Intervention Hotline at +1-800-643-2353 for the United States and Canada. For additional support telephone numbers, see the Avaya Web site:

<http://www.avaya.com/support>

Providing telecommunications security

Telecommunications security (of voice, data, and video communications) is the prevention of any type of intrusion to (that is, either unauthorized or malicious access to or use of) your company's telecommunications equipment by some party.

Your company's "telecommunications equipment" includes both this Avaya product and any other voice/data/video equipment that could be accessed via this Avaya product (that is, "networked equipment").

An "outside party" is anyone who is not a corporate employee, agent, subcontractor, or person working on your company's behalf. Whereas, a "malicious party" is anyone (including someone who may be otherwise authorized) who accesses your telecommunications equipment with either malicious or mischievous intent.

Such intrusions may be either to/through synchronous (time-multiplexed and/or circuit-based) or asynchronous (character-, message-, or packet-based) equipment or interfaces for reasons of:

- Use (of capabilities special to the accessed equipment)
- Theft (such as, of intellectual property, financial assets, or toll-facility access)
- Eavesdropping (privacy invasions to humans)
- Mischief (troubling, but apparently innocuous, tampering)
- Harm (such as harmful tampering, data loss or alteration, regardless of motive or intent)

Be aware that there may be a risk of unauthorized intrusions associated with your system and/or its networked equipment. Also realize that, if such an intrusion should occur, it could result in a variety of losses to your company (including, but not limited to, human and data privacy, intellectual property, material assets, financial resources, labor costs, and legal costs).

Your responsibility for your company's telecommunications security

The final responsibility for securing both this system and its networked equipment rests with you, an Avaya customer's system administrator, your telecommunications peers, and your managers. Base the fulfillment of your responsibility on acquired knowledge and resources from a variety of sources, including, but not limited to:

- Installation documents
- System administration documents
- Security documents
- Hardware-/software-based security tools
- Shared information between you and your peers
- Telecommunications security experts

To prevent intrusions to your telecommunications equipment, you and your peers should carefully program and configure:

- Your Avaya-provided telecommunications systems and their interfaces
- Your Avaya-provided software applications, as well as their underlying hardware/software platforms and interfaces
- Any other equipment networked to your Avaya products.

Trademarks

Avaya is a trademark of Avaya Inc.

All non-Avaya trademarks are the property of their respective owners.

Document ordering information:

Avaya Publications Center

Voice: +1-207-866-6701
1-800-457-1764 (Toll-free, U.S. and Canada only)

Fax: +1-207-626-7269
1-800-457-1764 (Toll-free, U.S. and Canada only)

Write: Globalware Solutions
200 Ward Hill Avenue
Haverhill, MA 01835 USA
Attention: Avaya Account Manager

Web: <http://www.avaya.com/support>

E-mail: totalware@gwsmail.com

Order: Document No. 585-215-116, Issue 2.0
June 2004

For the most current versions of documentation, go to the Avaya support Web site:

<http://www.avaya.com/support>

COMPAS

This document is also available from the COMPAS database. The COMPAS ID for this document is 91851.

Avaya support

Avaya provides a telephone number for you to use to report problems or to ask questions about your contact center. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site:

<http://www.avaya.com/support>

**Avaya Call Management System
Sun Fire V880 Computer
Hardware Installation, Maintenance, and Troubleshooting**

Contents

Preface	7
Reasons for reissue	7
Organization	8
Availability	9
Related documentation	10
Change description	10
Software documents	10
Administration documents	11
Avaya CMS upgrade documents	11
Base load upgrades	11
Platform upgrades and data migration	12
Avaya Call Management System Upgrade Express (CUE)	12
Hardware documents	13
Communication Manager documents	13
Documentation Web sites	14
Support	15
Installation	17
Preparing for installation	18
Safety precautions	18
System precautions	19
Required tools	19
Electrical specifications	20
Physical specifications	20
Service access specifications	21
Environmental specifications	21
Unpacking and inventorying the equipment	22
Parts list	23
Computer layout	24
Front panel	25
Back panel	26
Hardware options	27
Rack mounting	27
Setting up power	28
Peripheral connectivity	29
Parts list	30
Connecting the monitor, keyboard, and mouse	31

Contents

Connecting the remote console modem	32
Connecting the RSC for remote access (optional)	33
Connecting the switch link	34
Turning on the system and verifying POST	35
Identifying installed PCI cards	39
Setting the remote console modem options	41
Sportster 33.6 faxmodem options	41
Paradyne Comsphere 3910 modem options	43
Recommended options	43
Option buttons	43
Setting the options	44
Turning the system over for provisioning	48
Maintenance	49
Precautions	50
Computer layout	51
Front panel	51
Rear panel	52
Turning the computer off and on.	53
Accessing components inside the computer	55
Opening and removing a side door.	55
Replacing and closing a side door	57
Using an ESD wrist strap	58
Maintaining PCI cards	59
Required references	59
Precautions.	60
PCI card configuration.	61
Maintaining hot-plug PCI cards	62
PCI slot LEDs for hot-plug operation.	63
Preparing a hot-plug card for removal	64
Removing a hot-plug PCI card	65
Installing a hot-plug PCI card	68
Configuring the new or replacement card	70
Replacing the graphics card	71
Installing the XVR-100 software packages	75
Replacing older Dual Ethernet and Dual SCSI cards	76
Maintaining HSI/P cards.	80
Replacing an HSI/P card	80
Installing the first HSI/P card or a pair of HSI/P cards.	85
Installing HSI/P software and patches	88
Setting up the switch link for each ACD	88
Adding a second HSI/P card	90
Replacing the RSC card	94
Required references	94
Replacing the RSC card.	94
Maintaining disk drives	99
Disk drive compatibility with CMS loads	99

Prerequisites	99
Disk drive configurations	100
Required references	101
Replacing disk drives	101
Replacing a single boot disk or replacing data disks	101
Replacing both boot disks	108
Setting up replacement disk drives	112
Partitioning replacement disk drives	113
Adding disk drives (optional)	119
Replacing the DVD-ROM drive	122
Maintaining tape drives	126
Tape drive compatibility	126
Ordering tapes	126
Cleaning the tape drive	127
Replacing the internal tape drive	128
Adding and removing an external tape drive for data migration	131
Maintaining CPU/Memory boards	136
CPU and memory configurations	136
Checking the current memory and CPU configuration	137
Shutting down the system	138
Removing a CPU/Memory board	139
Replacing memory	140
Installing a CPU/Memory board	142
Restarting the system	145
Replacing a power supply	147
Troubleshooting	151
Using the remote console	152
Redirecting the console using Solaris	152
Redirecting the local console to the remote console	152
Redirecting the remote console back to the local console	154
Redirecting the console using OpenBoot mode	155
Redirecting the local console to the remote console	155
Redirecting the remote console back to the local console	156
Using the RSC	159
Redirecting the local console to the RSC	159
Redirecting the RSC to the local console	160
Tools	161
Using the prtdiag command	162
Using the cfgadm command	165
System messages	166
OpenBoot PROM firmware tests	167
Using the OpenBoot PROM tests	167
Test descriptions	168
Probing disk drives	169
Probing all media devices	170
OpenBoot diagnostic tests	172
POST diagnostic messages	175

Contents

Memory failure	175
OpenBoot initialization commands	176
Diagnosing LED patterns	177
Front panel LEDs.	177
PCI slot LEDs	179
Power supply LEDs	181
Disk drive LEDs	182
Tape drive LEDs	184
Sun Validation Test Suite (VTS)	185
Prerequisites	185
Using SunVTS	185
Troubleshooting disk drives and DVD-ROM drives	186
Troubleshooting tape drives.	189
Checking tape status	189
Reassigning device instance numbers for tape devices	191
Recovery procedures.	192
Preserving data after a system failure	192
Loss of power.	193
Probe command warnings.	195
Reseating HSI/P cards	196
Resetting a device alias	198
Remote console port problems	200
Glossary	203
Index	205

Preface

Avaya Call Management System Sun Fire V880 Computer Hardware Installation, Maintenance, and Troubleshooting is written for technicians who install and maintain call center applications such as Avaya Call Management System (CMS).

Note:

The Sun Fire V880 computer is compatible with CMS R3V11 and later.

Reasons for reissue

Issue 2.0 of this document was changed for the following reasons:

- To add information about the new DAT 72 tape drive.
- To note that CMS R12 does not support X.25 switch links (see [Connecting the switch link](#) on page 34).
- To update information that the newer Dual FastEthernet and Dual SCSI card supports hot plug operation (see [Maintaining hot-plug PCI cards](#) on page 62).
- To update the tape ordering procedures (see [Ordering tapes](#) on page 126).
- To make general wording and format corrections.

Issue 1.1 of this document was changed for the following reasons:

- To add information about the new Dual FastEthernet and Dual SCSI card. This card is replacing the SunSwift card. See the following sections for more information:
 - [Computer layout](#) on page 24
 - [Peripheral connectivity](#) on page 29
 - [Parts list](#) on page 30
 - [Computer layout](#) on page 51
 - [PCI card configuration](#) on page 61
- To update the remote console setup procedure (see [Setting the remote console modem options](#) on page 41).

Preface

- To add a procedure for installing the XVR-100 graphic accelerator card software (see [Installing the XVR-100 software packages](#) on page 75).
- To update the tape ordering procedures (see [Ordering tapes](#) on page 126).
- To make general wording and format corrections.

Organization

This document is organized as follows:

- [Installation](#) on page 17 - Describes how to assemble the computer, connect external devices, and turn on the computer.
- [Maintenance](#) on page 49 - Describes how to maintain the computer.
- [Troubleshooting](#) on page 145 - Describes how to troubleshoot the computer.
- [Glossary](#) on page 199
- [Index](#) on page 201

Availability

Copies of this document are available from one or both of the following sources:

Note:

Although there is no charge to download documents through the Avaya Web site, documents ordered from the Avaya Publications Center must be purchased.

- The Avaya online support Web site, <http://www.avayadocs.com>
- The Avaya Publications Center, which you can contact by:

Voice:

+1-207-866-6701

+1-800-457-1764 (Toll-free, U.S. and Canada only)

Fax:

+1-207-626-7269

+1-800-457-1764 (Toll-free, U.S. and Canada only)

Mail:

GlobalWare Solutions
200 Ward Hill Avenue
Haverhill, MA 01835 USA
Attention: Avaya Account Manager

E-mail:

totalware@gwsmail.com

Related documentation

You might find the following Avaya CMS documentation useful. This section includes the following topics:

- [Change description](#) on page 10
- [Software documents](#) on page 10
- [Administration documents](#) on page 11
- [Avaya CMS upgrade documents](#) on page 11
- [Hardware documents](#) on page 13
- [Communication Manager documents](#) on page 13
- [Documentation Web sites](#) on page 14

Change description

For information about the changes made in Avaya CMS R12, see:

- *Avaya Call Center 2.1 and CMS Release 12 Change Description, 07-300197*

Software documents

For more information about Avaya CMS software, see:

- *Avaya Call Management System Release 12 Software Installation, Maintenance, and Troubleshooting Guide, 585-215-117*
- *Avaya CMS Open Database Connectivity, 585-780-701*
- *Avaya Call Management System Release 12 LAN Backup User Guide, 585-215-721*
- *Avaya Call Management System Release 12 External Call History Interface, 07-300064*
- *Avaya CMS Custom Reports, 585-215-822*
- *Avaya CMS Forecast, 585-215-825*
- *Avaya Visual Vectors Release 12 Installation and Getting Started, 07-300069*
- *Avaya Visual Vectors Release 12 User Guide, 07-300200*
- *Avaya Business Advocate Release 12 User Guide, 07-300063*
- *Avaya CMS Release 12 Report Designer User Guide, 07-300068*

Administration documents

For more information about Avaya CMS administration, see:

- *Avaya Call Management System Release 12 Administration*, 07-300062
- *Avaya Call Management System Database Items and Calculations*, 07-300011
- *Avaya CMS Supervisor Release 12 Reports*, 07-300012
- *Avaya CMS Supervisor Release 12 Installation and Getting Started*, 07-300009
- *Avaya Call Management System High Availability User Guide*, 07-300065
- *Avaya Call Management System High Availability Connectivity, Upgrade and Administration*, 07-300065

Avaya CMS upgrade documents

There are several upgrade paths supported with Avaya CMS. There is a document designed to support each upgrade. None of the following upgrade documents are available from the publications center.

This section includes the following topics:

- [Base load upgrades](#) on page 11
- [Platform upgrades and data migration](#) on page 12
- [Avaya Call Management System Upgrade Express \(CUE\)](#) on page 12

Base load upgrades

Use a base load upgrade when upgrading CMS to the latest load of the same version (for example, R3V9 ak.g to R3V9 al.k). A specific set of instructions is written for the upgrade and is shipped to the customer site with the CMS software CD-ROM as part of a Quality Protection Plan Change Notice (QPPCN).

For more information about base load upgrades, see:

- *Avaya CMS R12 Base Load Upgrades*

Platform upgrades and data migration

Use a platform upgrade when upgrading to a new hardware platform (for example, upgrading from a SPARCserver 5 to a Sun Blade 150). The new hardware platform is shipped from the Avaya factory with the latest CMS load. Therefore, as part of the upgrade you will have the latest CMS load (for example, R3V9 to R12 or the latest load of the same CMS version). For R12, a specific set of instructions is written for the upgrade and is shipped to the customer site with the new hardware.

For more information about platform upgrades and data migration, see:

- *Avaya Call Management System Release 12 Platform Upgrade and Data Migration, 07-300067*

Avaya Call Management System Upgrade Express (CUE)

Use CUE in the following conditions:

- CMS is being upgraded from an earlier version (for example R3V6) to the latest version (for example, R12).
- The hardware platform is not changing.

A specific set of upgrade instructions is written for the upgrade and is shipped to the customer site with the CUE kit.

For more information about CUE upgrades, see:

- *Avaya Call Management System (CMS) Release 12 CMS Upgrade Express (CUE) Customer Requirements, 07-300010*
- *Avaya Call Management System Release 12 Sun Blade 100 Workstation CMS Upgrade Express*
- *Avaya Call Management System Release 12 Sun Blade 100 Workstation Mirrored System CMS Upgrade Express*
- *Avaya Call Management System Release 12 Sun Enterprise 3500 Computer CMS Upgrade Express*
- *Avaya Call Management System Release 12 Sun Enterprise 3500 Computer Mirrored System CMS Upgrade Express*
- *Avaya Call Management System Release 12 Sun Fire V880 Computer CMS Upgrade Express*

Hardware documents

For more information about Avaya CMS hardware, see:

- *Avaya Call Management System Sun Fire V880 Computer Hardware Installation, Maintenance, and Troubleshooting*, 585-215-116
- *Avaya Call Management System Sun Fire V880 Computer Connectivity Diagram*, 585-215-612
- *Avaya Call Management System Sun Blade 100/150 Computer Hardware Installation, Maintenance, and Troubleshooting*, 585-310-783
- *Call Management System Sun Blade 100/150 Computer Connectivity Diagram*, 585-310-782
- *Avaya Call Management System Sun Enterprise 3500 Computer Hardware Installation, Maintenance, and Troubleshooting*, 585-215-873
- *Call Management System Sun Enterprise 3500 Computer Connectivity Diagram*, 585-215-877
- *Avaya Call Management System Terminals, Printers, and Modems*, 585-215-874

Communication Manager documents

For more information about Avaya CMS communication servers, see:

- *Avaya Call Management System Switch Connections, Administration, and Troubleshooting*, 585-215-876
- *Avaya Communication Manager Call Center Software - Call Vectoring and Expert Agent Selection (EAS) Guide*, 07-300186
- *Avaya Communication Manager Call Center Software - Automatic Call Distribution (ACD) Guide*, 07-300185
- *Avaya Communication Manager Call Center Software - Basic Call Management System (BCMS) Operations*, 07-300061

Documentation Web sites

For product documentation for all Avaya products and related documentation, go to <http://www.avayadocs.com>. Additional information about new software or hardware updates will be contained in future issues of this book. New issues of this book will be placed on the Web site when available.

Use the following Web sites to view related support documentation:

- Information about Avaya products and service

<http://www.avaya.com>

- Sun hardware documentation

<http://docs.sun.com>

- Okidata printer documentation

<http://www.okidata.com>

- Informix documentation

<http://www.informix.com>

- Tivoli Storage Manager documentation

<http://www.tivoli.com>

Support

Contacting Avaya technical support

Avaya provides support telephone numbers for you to report problems or ask questions about your product.

For United States support:

1- 800- 242-2121

For international support:

See the [1-800 Support Directory](#) listings on the Avaya Web site.

Escalating a technical support issue

Avaya Global Services Escalation Management provides the means to escalate urgent service issues. For more information, see the [Escalation Management](#) listings on the Avaya Web site.



Installation

This section describes how to install the computer and related peripheral equipment. Use the following table to check off each required procedure after completion.

Procedure	Completed
Preparing for installation on page 18	
Unpacking and inventorying the equipment on page 22	
Setting up power on page 28	
Peripheral connectivity on page 29	
Connecting the monitor, keyboard, and mouse on page 31	
Connecting the remote console modem on page 32	
Connecting the RSC for remote access (optional) on page 33	
Connecting the switch link on page 34	
Turning on the system and verifying POST on page 35	
Identifying installed PCI cards on page 39	
Setting the remote console modem options on page 41	
Turning the system over for provisioning on page 48	

Preparing for installation

This section contains the following information that will help you prepare for the computer installation:

- [Safety precautions](#) on page 18
- [System precautions](#) on page 19
- [Required tools](#) on page 19
- [Electrical specifications](#) on page 20
- [Physical specifications](#) on page 20
- [Service access specifications](#) on page 21
- [Environmental specifications](#) on page 21

Safety precautions

For your protection, observe the following safety precautions when setting up your equipment:

- Follow all cautions, warnings, and instructions that are marked on the equipment.
- Never push objects of any kind through openings in the equipment. Objects could touch dangerous voltage points or short out components, resulting in fire or electric shock.
- When moving the computer, be careful not to unplug any power or data cables.
- Refer servicing of equipment to qualified personnel.
- To protect both yourself and the equipment, observe the following precautions.

Item	Problem	Precaution
Wrist or foot strap	ESD	Wear a conductive wrist strap or foot strap when handling printed circuit boards.
Cover panels	System damage and overheating	Reinstall all cabinet cover panels after you perform any service work on the system.
Card slot filler panels	System damage and overheating	Make sure that a filler panel is installed on all empty card slots.

System precautions

Ensure that the voltage and frequency of the power outlet that is used matches the electrical rating labels on the equipment.

Wear antistatic wrist straps when handling any magnetic storage devices, CPU/Memory boards, or other printed circuit boards.

The computer has three autoranging power supplies that use nominal input voltages of 100 to 240 V AC at 47 to 63 Hz. Sun products are designed to work with single-phase power systems with a grounded neutral conductor. To reduce the risk of electric shock, do not plug Sun products into another type of power source. Contact your facilities manager or qualified electrician if you are unsure of what type of power is supplied to your building.

Avaya recommends that you use one of the following power schemes:

- Connect the computer using two (2) 2KVA Uninterruptible Power Supplies (UPS) (or equivalent), each powered by a nonswitched, dedicated, 15-amp circuit. Connect two of the power supplies to one UPS, and the third power supply to the second UPS. The monitor and external peripherals can also be connected to the second UPS.
- If not using a UPS, each power supply should be connected to a nonswitched, dedicated, 15-amp circuit. The monitor and external peripherals should be connected to a separate circuit.

Each of the following items require a separate power cord:

- Power supplies in the computer (3 power cords)
- External peripherals
- Monitor

 **WARNING:**

Do not make mechanical or electrical modifications to the cabinet. Sun Microsystems is not responsible for regulatory compliance of modified cabinets.

Required tools

You need the following tools to do the installation:

- Phillips #2 screwdriver
- Needle-nose pliers
- ESD grounding wrist strap
- Antistatic mat

Electrical specifications

Parameter	Value
Input <ul style="list-style-type: none"> ● Nominal voltage range ● Maximum current AC RMS ● AC operating range ● Nominal frequencies 	<ul style="list-style-type: none"> ● 100-240 V AC, autoranging ● 15.0 A @100 VAC (each power supply) ● 90-264 V rms, 47-63Hz ● 50 Hz or 60 Hz
Maximum DC power output	2240 W
Maximum AC power consumption	3000 W
Maximum heat dissipation	10308 BTU/hr
Volt-ampere rating	1515 VA with 1120 Watt load (PF=0.99)
Wall plug type <ul style="list-style-type: none"> ● United States ● Non-United States 	<ul style="list-style-type: none"> ● NEMA 5-15P ● Power cords must be obtained locally
CPU plug type	IEC 320

Physical specifications

Parameter	English value	Metric value
Height (with casters)	28.1 inches	71.4 centimeters
Width	18.9 inches	48.0 centimeters
Depth	32.9 inches	83.6 centimeters
Weight (min-max) ¹	194-288 pounds	88-130.6 kilograms
Power cords	8.2 feet	2.5 meters

1. The actual weight depends on the installed options.

Service access specifications

Parameter	English value	Metric value
Front	36 inches	91 centimeters
Rear	36 inches	91 centimeters
Left	36 inches	91 centimeters
Right	36 inches	91 centimeters

Environmental specifications

For the most reliable system operation:

- The room must have sufficient air conditioning capacity to support the cooling needs of the entire system.
- The air conditioning system must have controls that prevent excessive temperature changes.
- Do not turn on the computer until it has acclimated to the room temperature for at least 24 hours.

Follow the guidelines in the table below for temperature, humidity, and altitude limits for units in operation and for units that are not in operation (that is, units that are in transit or in storage).

Parameter	Operating (in service)	Nonoperating (not in service)
Temperature	41°F to 95°F (5°C to 35°C) IEC 68-2-1, 68-2-2	-4°F to 140°F (-20°C to 60°C) IEC 68-2-1, 68-2-2
Humidity (max)	20% to 80% RH noncondensing; 27°C max wb IEC 68-2-2, 68-2-3	93% RH noncondensing at 40°C IEC 68-2-2, 68-2-3
Altitude (max)	10,000 feet (3 kilometers) IEC 68-2-40, 68-2-41	40,000 feet (12 kilometers) IEC 68-2-40, 68-2-41

Unpacking and inventorying the equipment

 **WARNING:**

Never move the system when the power is on. Excessive movement can cause catastrophic disk drive failure. Always turn the power off before moving cabinets.

 **WARNING:**

Always wear an electrostatic discharge (ESD) wrist strap when handling internal components.

 **CAUTION:**

Always have up-to-date system backups before turning the computer off and moving the computer.

Inspect all shipping cartons for evidence of physical damage. If a shipping carton is damaged, request that the carrier representative be present before the carton is opened.

Unpack the computer and the associated peripheral equipment. Compare the contents of the carton to the shipping inventory list to verify that all equipment was delivered.

In the United States, contact Avaya technical support if any parts are defective on arrival. Contact Avaya customer service if any parts are missing.

Outside of the United States, contact your Avaya representative or distributor if any parts are missing or defective.

This section includes the following topics:

- [Parts list](#) on page 23
- [Computer layout](#) on page 24
- [Hardware options](#) on page 27
- [Rack mounting](#) on page 27

Parts list

Verify that you have the following components before you begin the installation:

 **Important:**

DO NOT install internal hardware shipped loose with the Sun machine at this time. This will be done under the direction of the CMS Provisioning Engineer at a scheduled appointment time.

- Sun Fire V880 cabinet (including installed cards and disk drives)
- Computer power supply AC power cords (3)
- Monitor, cable, and monitor AC power cord
- USB keyboard and cable
- USB mouse and cable
- A package of blank tapes for backups
- One tape that contains the Avaya factory configuration CMSADM filesystem backup
- Category 5 LAN cable
- Modem and cables
- Keys
- Sun and CMS software

Note:

Starting around June, 2004, CMS servers will no longer ship with tape drive cleaning tapes. Avaya recommends that customers purchase at least one cleaning tape as soon as the server is installed and in service.


Computer layout

Familiarize yourself with the layout of the computer. The minimum configuration for the computer is as follows:

- One CPU/Memory board (with two UltraSPARC III processors and 4-GB memory)
- Four disk drives, mirrored two plus two
- One built-in ethernet port
- One graphics PCI card installed in slot 7
- Either:
 - One SunSwift PCI card installed in slot 0, or
 - One Dual FastEthernet and Dual SCSI card installed in slot 0
- Three power supplies and power cords
- One DVD-ROM drive
- One tape drive
- Two USB ports
- One serial port

Front panel


The following figure shows the front of the computer with the disk drive door open.



Installation

Back panel

The following figure shows the back panel of the computer.



Hardware options

The following table lists the hardware options for the computer.

Option	Quantity		Comments
	Minimum	Maximum	
CPU/Memory boards	1	4	The minimum configuration is one CPU/Memory board. Each board has two CPU modules and 4-GB memory.
PCI I/O cards	2	7	There are nine slots, but only seven slots may be used. For a listing of where the PCI cards can be installed, see PCI card configuration on page 58.
Disk drives	4	6	A pair of data disks can be added to the system. This will be offered in the future.

Rack mounting

The computer can be rack mounted. For information about rack mounting, see *Sun Fire 880 Server Rackmounting Guide* at the Sun documentation Web site:

<http://docs.sun.com>


Note:

When rack mounting the computer, the technician must remove all CPU/Memory boards, all power supplies, all CPU fan trays, and all I/O fan trays, as described in the rack mounting guide.

Setting up power

To set up the AC power:

1. Locate the key switch, insert the key, and turn the key switch to the Forced Off position. See the following figure.




2. Connect the IEC 320 end of each power cord to the AC connector of each power supply.
For installations outside of the United States and Canada, obtain three power cords for your local configuration.
3. Route the power cord through the strain-relief tie-wrap loop located to the right of the supply. Tighten the tie-wrap to secure the connection.
4. Plug the power cords from the computer using one of the following schemes:
 - Connect the computer using two (2) 2KVA Uninterruptible Power Supplies (UPS) (or equivalent), each powered by a nonswitched, dedicated, 15-amp circuit. Connect two of the power supplies to one UPS, and the third power supply to the second UPS. The monitor and external peripherals can also be connected to the second UPS.
 - If not using a UPS, each power supply should be connected to a nonswitched, dedicated, 15-amp circuit. The monitor and external peripherals should be connected to a separate circuit.

⚠ Important:

Do not turn on power at this time.

Peripheral connectivity

The following figure shows in general how equipment is connected to the computer. The callouts are described in [Parts list](#) on page 30.



sunfire880conn.cdr

Parts list

The following table lists the parts that are required to connect most of the external devices to the computer. For information about connecting terminals, printers, and modems to the computer, see *Avaya CMS Terminals, Printers, and Modems*. For information about switch connections for CMS, see *Avaya Call Management System Switch Connections, Administration, and Troubleshooting*.

Connectivity diagram call out	Comcode or part of comcode	Description
A ¹	408128288	HSI/P card (up to two may be installed)
B ¹		HSI/P quad cable (1 per HSI/P card)
C	407086818	RS-449 cable (10 feet, 3 meters)
D	N/A ²	SunSwift card, or Dual FastEthernet and Dual SCSI card
E ¹	700230105	FastEthernet 10/100 Mbps card
F	407086826	Category 5 UTP cable (10 feet, 3 meters)
G	846362754	DB25-to-RJ45 ACU modem adapter
H	846983039	10-wire modular cord (10 feet, 3 meters)
I	846362770	RJ45-to-DB25 remote console adapter
J	407633999 Varies	Sportster Model 839 33.6 remote console modem Comsphere 3910 remote console modem
K ¹	N/A ²	Graphics card
L ¹	N/A ²	Monitor cable
M ¹	N/A ²	Monitor
N ¹	N/A ²	Monitor AC power cord
O ¹	N/A ²	USB keyboard with cable
P ¹		USB mouse with cable


1. Sun Microsystems provides maintenance sparing for these parts.

2. The comcode for this bundle changes regularly and may not be ordered for maintenance spares, so it is not listed in the table. This bundle includes the processor, peripherals, and other equipment.


Connecting the monitor, keyboard, and mouse

To connect the monitor, keyboard, and mouse to the computer:

1. Attach the monitor video cable to the graphics card, which is installed in slot 7. Tighten the thumbscrews to secure the connection. See the following figure.



2. Connect the monitor power cord to an approved AC power outlet.
3. Attach the USB keyboard cable to one of the USB ports.




4. Attach the USB mouse cable to the other USB port.

Connecting the remote console modem

The remote console modem allows personnel at a remote support center to dial in and perform maintenance on the computer. The modem is a U.S. Robotics Sportster 33.6 Faxmodem, a Paradyne Comsphere 3910 modem, or a modem provided locally.

The following figure shows remote console modem connectivity.



To connect the remote console modem:

1. Connect the DB25-to-RJ45 ACU modem adapter (A) to the serial port on the back of the computer.
2. Connect the 10-wire modular cord (B) to the modular end of the ACU modem adapter (A).
3. Connect the other end of the 10-wire modular cord (B) to the modular end of the RJ45-to-DB25 remote console adapter (C).
4. Connect the remote console adapter (C) to the RS-232C port on the modem. The RS-232C port on the Comsphere 3910 is labeled "DTE1."
5. Connect the telephone line to the jack labeled "LINE" on the Sportster modem, or labeled "DIAL" on the Comsphere 3910 modem.
6. Connect the power cable to the modem and plug it into a socket.

Do not turn on the power yet. Instructions for turning on the modem are given in [Setting the remote console modem options](#) on page 41.

Connecting the RSC for remote access (optional)


The RSC card provides the following optional connections:

- An ethernet connection to the customer network that allows personnel to `telnet` into the RSC to perform provisioning, maintenance, and troubleshooting. This connection can also be used to set up e-mail alerts for system problems. For more information about e-mail alerts, see *Sun Remote System Control (RSC) User's Guide* at the Sun documentation Web site, <http://docs.sun.com>.
- A built-in modem that allows personnel to dial in to the RSC and perform provisioning, maintenance, and troubleshooting. This connection can also be used to set up pager alerts for system problems. For more information about pager alerts, see *Sun Remote System Control (RSC) User's Guide* at the Sun documentation Web site, <http://docs.sun.com>.

Note:

The serial port on the RSC is not used for CMS.

The following figure shows the connections to the RSC card.



Connecting the switch link

Use either of the following two ways to connect the CMS computer to a switch:

- TCP/IP over a local area network (LAN)
- X.25 protocol over a hard-wired or switched link (not supported for CMS R12 and later)

One CMS computer can collect data from several switches. To the CMS computer, each switch represents one ACD. You can have all switches connected using TCP/IP, all switches connected using X.25 protocol (not supported for CMS R12 and later), or some combination of the two protocols.


For detailed information about how to connect and administer the switch link, see *Avaya Call Management System Switch Connections, Administration, and Troubleshooting*.

Turning on the system and verifying POST

Once you assemble the system, including the loose hardware that is shipped with the system that you installed with help from CMS Provisioning, turn on the system and verify the results of the Power-On Self Test (POST).

To turn on the system and verify POST:


1. Verify that the key switch is in the Forced Off position. See the following figure.



2. If using one or more UPSs, plug the power cord of each UPS into a dedicated circuit. If not using a UPS, plug the power cords for each power supply into an outlet on a dedicated 15-amp circuit.
3. Turn on the power to the UPS units, if UPS units are installed.
4. Turn on the system monitor.

Installation

5. Turn the key switch to the normal On position. See the following figure.



6. Press and release the power button to the left of the key switch to turn on the system.

Note:

The POST diagnostics occurs each time that you turn on the system. The POST tests the basic system components. This may take several minutes.

As the system powers up, the power LED on the monitor flashes.

7. Press **Stop+A** simultaneously as soon as the monitor power LED lights steadily and the Sun logo is displayed on the monitor.

The `ok` prompt is displayed.

8. Enter the following commands:

```
setenv auto-boot? false
```

```
reset-all
```

The system resets to the `ok` prompt.

9. Enter:

```
probe-scsi-all
```

This verifies that the system sees the disk drives and backplane, the tape drive, and the DVD-ROM drive. A message that is similar to the following is displayed:

```
/pci@8,600000/SUNW,qlc@2
LiD HA LUN --- Port WWN --- -----Disk description -----
 0  0  0  21000004cf72f08f SEAGATE ST373405FSUN3660438
 1  1  0  21000004cf721553 SEAGATE ST373405FSUN3660438
 6  6  0  508002000016b5b1 SUNW      SUNWGS INT FCBPL9224
 3  3  0  21000004cf72114b SEAGATE ST373405FSUN3660438
 4  4  0  21000004cf7211ae SEAGATE ST373405FSUN3660438

/pci@8,700000/scsi@1
Target 5
  Unit 0   Removeable Tape      HP      C5683A    C005
Target 6
  Unit 0   Removeable Read Only device  TOSHIBA DVD-ROM SD-M14011009
/pci@8,700000/pci@5/SUNW,lsptwo@4
```

10. Verify that all of the devices are recognized. If the devices are not recognized, see [Troubleshooting disk drives and DVD-ROM drives](#) on page 180 for more information.
11. When you have verified that the system recognizes all of its devices, enter the following commands:

⚠ CAUTION:

If you fail to reset the auto-boot option, any reboots that you do in the future will stop at the boot prompt instead of proceeding through the normal boot-up process.


```
setenv auto-boot? true
```

```
boot
```

The system reboots.

Installation

12. Turn the key switch to the Locked position. This prevents anyone from accidentally turning off the system. See the following figure.



Identifying installed PCI cards

If there are problems with the PCI cards, do the following to troubleshoot the problem. If all PCI cards are operational, you can skip this procedure.

At the command prompt, enter:

```
/usr/platform/`uname -m`/sbin/prtdiag -v | pg
```

In the section IO Cards, there is a listing of the PCI cards. The following are examples of some of the entries you may see. The display you see depends on your specific configuration.

```
.
.
===== IO Cards =====

      Bus  Max
      IO  Port Bus      Freq Bus  Dev,
Brd Type ID  Side Slot MHz  Freq Func State Name
Model
-----
I/O PCI  8   B   3   33  33  2,0 ok pci1214,334-pci1214,334.10
I/O PCI  8   B   1   33  33  4,0 ok pci108e,1000-pci108e,1000.1
I/O PCI  8   B   1   33  33  4,1 ok SUNW,hme-pci108e,1001 SUNW,qsi-cheerio
I/O PCI  9   B   0   33  33  3,0 ok pci-pci8086,b154.0/network (netw+PCI-BRIDGE
I/O PCI  9   B   0   33  33  0,0 ok network-pci100b,35.30 SUNW,pci-ce/pci-bridge
I/O PCI  9   B   0   33  33  1,0 ok network-pci100b,35.30 SUNW,pci-ce/pci-bridge
I/O PCI  9   B   0   33  33  2,0 ok scsi-pci1000,b.7/disk (block) device on pci-bridge
I/O PCI  9   B   0   33  33  2,1 ok scsi-pci1000,b.7/disk (block) device on pci-bridge
I/O PCI  9   A   7   66  66  2,0 ok SUNW,XVR-100 SUNW,375-3181
.
.
```

In this example:

- Slot 0 has a Dual FastEthernet and Dual SCSI card. There is more than one entry for a this card because the card has two SCSI ports and two Ethernet ports.
- Slot 1 has a FastEthernet card. There is more than one entry for the FastEthernet card because the card has the ethernet port and a Media Independent Interface (MII) port (not used with CMS).
- Slot 3 has an HSI/P card.
- Slot 7 has a graphics card.

Installation

You can also use the `cfgadm` command to display the following information about the cards in the PCI slots:

Ap_Id	Type	Receptacle	Occupant	Condition
.				
.				
pcisch0:hpc1_slot0	pci-pci/hp	connected	configured	ok
pcisch0:hpc1_slot1	bridge/hp	connected	configured	ok
pcisch0:hpc1_slot2	unknown	empty	unconfigured	unknown
pcisch0:hpc1_slot3	unknown/hp	connected	configured	ok
pcisch2:hpc2_slot4	unknown	empty	unconfigured	unknown
pcisch2:hpc2_slot5	unknown	empty	unconfigured	unknown
pcisch2:hpc2_slot6	unknown	empty	unconfigured	unknown
pcisch3:hpc0_slot7	vgs8514/hp	connected	configured	ok
pcisch3:hpc0_slot8	unknown	empty	unconfigured	unknown
.				
.				

In the above example:

- Slot 0 has a Dual FastEthernet and Dual SCSI card.
- Slot 1 has a FastEthernet card.
- Slot 3 has an HSI/P card.
- Slot 7 has a graphics card.

Setting the remote console modem options

The computer uses the U.S. Robotics Sportster 33.6 Faxmodem or the Paradyne Comsphere 3910 modem for remote console access. The options for any other modems must be set based on local instructions.

For instructions for connecting the modem, see [Connecting the remote console modem](#) on page 32.

This section includes the following topics:

- [Sportster 33.6 faxmodem options](#) on page 41
- [Paradyne Comsphere 3910 modem options](#) on page 43

Sportster 33.6 faxmodem options

To set the options on the Sportster 33.6 faxmodem:

1. Set DIP switches 1, 3, 7, and 8 on the back panel of the Sportster modem to the down (ON) position, and switches 2, 4, 5, and 6 to the up (OFF) position.
2. Turn on the remote console modem.
3. At the system console, log in as root.
4. Enter:

```
/cms/install/bin/abcadm -r ttya
```

The following message is displayed:

```
ttya is currently set to be incoming
Are you sure you want to change it? [y,n,?]
```

5. Enter: **y**

The following message is displayed:

```
ttya administration removed
```

The port monitor turns off.

Installation

6. Enter:

```
cu -s 9600 -b 8 -l cua/a
```

The following message is displayed:

```
Connected
```

7. Enter the following commands:

```
at&f1 (loads the factory default configuration into active memory)
```

```
at&w0 (writes the current configuration to NVRAM template Y0)
```

Note:

Use numerical ones and zeros when entering the options.

8. After you enter the options, disconnect from the modem by entering a tilde and a period (~.).

9. Set DIP switches 4 and 8 on the back panel of the Sportster modem to the down (ON) position. Set all other DIP switches to the up (OFF) position.

10. Reset the modem by turning the power off and back on.

11. Enter:

```
/cms/install/bin/abcadm -i -b 9600 ttya
```

The Terminal Ready (TR) LED lights on the modem and the following message is displayed:

```
ttya set to incoming port 9600 baud
```

12. If the TR LED is not lit, enter:

```
ps -ef | grep sac
```

A message similar to the following should be displayed:

```
root  377      1  0 14:39:30 ?          0:00 /usr/lib/saf/sac -t 300
root  9723  9666  0 09:16:26 pts/9    0:00 grep sac
```

Additional references - For additional information, see the *U.S. Robotics Sportster Modems Users Guide*.

Paradyne Comsphere 3910 modem options

The Paradyne Comsphere 3910 modem is used for many locations outside of the United States.

This section includes the following topics:

- [Recommended options](#) on page 43
- [Option buttons](#) on page 43
- [Setting the options](#) on page 44

Recommended options

The recommended options for the Comsphere 3910 modem include selecting the factory-preset defaults for "UNIX_Dial" with the following two changes:

- Change Asynchronous DTE Rate to 9600
- Change Dial Line Rate to 9600 (V32b)


Option buttons

The seven buttons that are used to set the modem options are:

- Single up arrow - Move up one level in the menu tree.
- Double up arrow - Move to the top-level menu.
- Left arrow - Move to the previous choice for the current level in the menu tree.
- Right arrow - Move to subsequent choice for the current level in the menu tree.
- Function 1 (**F1**) - Select the choice, if any, that is currently displayed above **F1**.
- Function 2 (**F2**) - Select the choice, if any, that is currently displayed above **F2**.

Installation

- Function 3 (**F3**) - Select the choice, if any, that is currently displayed above **F3**.



Setting the options

To set the options on the Comsphere 3910, use the following procedures:

Configuring Factory/Async_Dial

1. Press **F2** to select "Configure."
"Ld EditArea frm" is displayed.
2. Press the **Right Arrow** four times.
"Factory" is displayed.
3. Press **F1** to select "Factory."
"Ld Fact Preset:" is displayed.
4. Press **Right Arrow** four times.
5. Press **F1** to select "UNIX_Dial."
6. Press **F3** to select "Save."
"Sav EditArea to" is displayed.
7. Press **F1** to save to "Active(Saved)."

Since you are changing the active area to a new set of options (that is, "Factory/Async_Dial"), the modem automatically performs another Power-On-Self-Test (POST). Since the new options match the way the modem is connected, the ALRM LED does not turn red. "Idle: 19.2" and "Status Configure" are displayed. To return to the top-level menu, press the **Double Up Arrow**.

Setting the data rate

1. Press **F2** to select "Configure."
"Ld EditArea frm" is displayed.
2. Press the **Right Arrow** once.
"Active(Saved)" is displayed.
3. Press **F1**.
"Choose Function" is displayed.
4. Press **F1** to select "Edit."
"Edit StrapGroup" is displayed.
5. Press **F1** to select "DTE_Interface."
"Async/Sync Mode" is displayed.
6. Press **F1** to select "Nxt."
"Async DTE Rate" is displayed.
7. Press the **Right Arrow** five times to display "9600."
8. Press **F2** to select "9600."

Setting the handshake options

1. Press **F1** for "Nxt."
"Asyn #Data Bits (8)" is displayed.
2. Press **F1** for "Nxt."
"Asyn Parity Bit (None)" is displayed.
3. Press **F1** for "Nxt."
"Asyn #Stop Bits (1)" is displayed.
4. Press **F1** for "Nxt."
"DTR Action (Ignore)" is displayed.
5. Press **F1** for "Nxt."
"DSR Control (Forced_On)" is displayed.
6. Press **F1** for "Nxt."
"RTS Action (Ignore)" is displayed.
7. Press **F1** for "Nxt."
"CTS Control (WinkWhenDisc)" is displayed.
8. Press **F1** for "Nxt."
"RTS/CTS Delay (0 msec)" is displayed.

Installation

9. Press **F1** for "Nxt."
"LSD Control (WinkWhenDisc)" is displayed.
10. Press **F1** for "Nxt."
"CT111_Rate Cntl (Disable)" is displayed.
11. Press **F1** for "Nxt."
"DTE_Rate=VF (Disable)" is displayed.
12. Press **F1** for "Nxt."
"Extend Main Ch. (Disable)" is displayed.
13. Press **F1** for "End."
"Edit StrapGroup" is displayed.

Setting the Dial_Line strap group

1. Press the **Right Arrow** three times to get to the "Dial_Line" strap group. Nothing needs to be changed for CMS in the "DTE_Dialer" or "Line_Dialer" strap groups, so you can skip them.
2. Press **F1** to edit the "Dial_Line" strap group.
"Dial Line Rate" is displayed.
3. Press the **Right Arrow** four times for "9600(V32b)."
4. Press **F2** to select "9600(V32b)."
5. Press **F1** for "Nxt."
"V32bis Automode (Enable)" is displayed.
6. Press **F1** for "Nxt."
"V32bis Autorate (Enable)" is displayed.
7. Press **F1** for "Nxt."
"Dial Tx Level (Permissv (-9))" is displayed.
8. Press **F1** for "Nxt."
"V22b Guard Tone (Disable)" is displayed.
9. Press **F1** for "Nxt."
"V32bis Train (Long)" is displayed.
10. Press **F1** for "End."
"Edit StrapGroup" is displayed. Do not change the other strap groups ("V42/MNP/Buffer," "Test," "Misc," and "Security") for CMS.

Saving your settings

1. Press the **Single Up Arrow** to display "Choose Function" and "Edit Save."
2. Press **F3** to select "Save."
"Save EditArea to" is displayed.
3. Press **F1** to select "Active(Saved)."
"Command Complete" is displayed.
4. Press the **Single Up Arrow** again to display "Save EditArea to."
5. Press the **Right Arrow** once to select "Customer 1."
6. Press **F1** to save to "Customer 1."
"Command Complete" is displayed.
7. Press the **Double Up Arrow**.
"Idle: 9600" and "Status Configure" are displayed. If the modem is turned off, it should return to this state when it is turned on.
8. To check the status of the Comsphere 3910 modem, use the "Status" choice in the top-level menu, or use the Right and Left Arrow buttons to view other top-level menu choices.

Turning the system over for provisioning

After completing the physical installation of the system, the installation continues with software provisioning. This is often done with the support of the Avaya CMS Provisioning group. Provisioning the system consists of the following:

- Setting up CMS
- Authorizing features
- Setting up the RSC (optional)
- Adding logins and passwords
- Testing the software

To continue with provisioning, see the chapter "Turning the system over to the customer" in the CMS software installation, maintenance, and troubleshooting document for your CMS release.



Maintenance

This section describes the following maintenance procedures:

- [Precautions](#) on page 50
- [Computer layout](#) on page 51
- [Turning the computer off and on](#) on page 53
- [Accessing components inside the computer](#) on page 55
- [Using an ESD wrist strap](#) on page 58
- [Maintaining PCI cards](#) on page 59
- [Replacing the RSC card](#) on page 94
- [Maintaining disk drives](#) on page 99
- [Replacing the DVD-ROM drive](#) on page 122
- [Maintaining tape drives](#) on page 126
- [Maintaining CPU/Memory boards](#) on page 136
- [Replacing a power supply](#) on page 147

Precautions



DANGER:

Hazardous energy levels are present inside the system when the system remains connected to a power source, regardless of the key switch position. Also, hazardous energy levels are present in the system's batteries even when all AC power cords are disconnected. Be sure to follow the safety procedures in the owner's guide or service manual.



WARNING:

The graphics card, older Dual FastEthernet and Dual SCSI cards, High-Speed Serial Interface/PCI (HSI/P) card, and RSC card are not hot-pluggable cards. Before replacing these cards, you must turn off the computer and, in the case of the RSC card, disconnect all AC power cords.



CAUTION:

Printed circuit boards and hard disk drives contain electronic components that are extremely sensitive to static electricity. Ordinary amounts of static from your clothes or the work environment can destroy components. Do not touch the components or any metal parts without taking proper antistatic precautions. See [Using an ESD wrist strap](#) on page 58 for more information.



CAUTION:

Avoid keeping doors open for extended periods of time while the system is operating. All doors must be closed to prevent automatic thermal shutdown.


Computer layout

The following figures identify the basic hardware components of the computer:

- [Front panel](#) on page 51
- [Rear panel](#) on page 52


Front panel

The following figure shows the front of the computer with the disk drive door open.



Rear panel

The following figure shows the back panel of the computer.



Turning the computer off and on

Use the following procedures to turn the computer off and on.


Turning off the computer

1. Log in to the system as root.
2. Enter:

```
/usr/sbin/shutdown -y -i0 -g0
```

This shuts down the system. The `ok` prompt is displayed at the local console.

3. Press and release the front panel power button to turn off the system.
Wait for the front panel Power/OK LED to turn off.
4. Turn the key switch to the Forced Off position. See the following figure.




⚠ DANGER:

Be sure to turn the key switch to the Forced Off position before handling any internal components. Otherwise, it is possible for a user to restart the system remotely while you are working inside it. The Forced Off position is the only key switch position that prevents a Remote System Control (RSC) user from restarting the system.

5. Turn off the system monitor.
6. Turn off any external SCSI devices, starting with the device that is closest to the system and working toward the farthest device.

Turning on the computer

1. Turn on any external SCSI devices, starting with the device that is farthest from the system and working toward the system.
2. Turn on the system monitor.
3. Turn the key switch to the normal On position. See the following figure.



4. Press and release the power button to the left of the key switch to turn on the system.

Note:

The POST diagnostics occurs each time that you turn on the system. The POST tests the basic system components. This may take several minutes.

If the system is operating properly, a banner screen is displayed, as shown below, up to 3 minutes after it is turned on.

```
|-----| Sun Fire 880, Keyboard Present
|       | Copyright 1998-2001 Sun Microsystems, Inc. All rights reserved.
|       | OpenBoot 4.4, XXX MB memory installed, Serial #XXXXXXXXXX
|-----| Ethernet address X:X:XX:XX:XX:XX, Host ID: XXXXXXXXX
```

5. Log in to the system as root.

Accessing components inside the computer

For most of the maintenance procedures, you must open the side doors and, in some cases, remove the side doors.

This section includes the following topics:

- [Opening and removing a side door](#) on page 55
- [Replacing and closing a side door](#) on page 57

Opening and removing a side door

 **CAUTION:**


Avoid keeping doors open for extended periods of time while the system is operating. All doors must be closed to prevent automatic thermal shutdown.

To open and remove a side door:

1. Unlock the side door of the computer using the system key.
2. Swing the side door open.

Maintenance

3. Open the door 90 degrees and pull it up until the mounting pins clear the brackets on the rear panel. See the following figure.




4. Set the door in a safe place.

Replacing and closing a side door

To replace and close a side door:

1. Position the side door mounting pins over the corresponding holes in the chassis rear panel and lower the side door into place. See the following figure.



2. Close the side door.
3. Lock the side door of the computer using the system key.
4. Replace the system key to the key switch.

Using an ESD wrist strap

Before you work on components inside the computer:

1. Unless otherwise instructed, make sure that the computer is plugged in to AC power.
2. Unless hot-plugging a device, make sure that the power is off.
3. Attach the ESD wrist strap to the chassis frame and to your wrist. See the following figure.



Maintaining PCI cards

This section includes the following topics:

- [Required references](#) on page 59
- [Precautions](#) on page 60
- [PCI card configuration](#) on page 61
- [Maintaining hot-plug PCI cards](#) on page 62
- [Replacing the graphics card](#) on page 71
- [Installing the XVR-100 software packages](#) on page 75
- [Replacing older Dual Ethernet and Dual SCSI cards](#) on page 76
- [Maintaining HSI/P cards](#) on page 80

 **WARNING:**

The graphics card, Dual FastEthernet and Dual SCSI card, High-Speed Serial Interface/PCI (HSI/P) card, and RSC card are not hot-pluggable cards. Before replacing these cards, you must turn off the computer and, in the case of the RSC card, disconnect all AC power cords. For information on how to replace the graphics card, see [Replacing the graphics card](#) on page 71. For information on how to replace the older Dual Ethernet and Dual SCSI card that does not support hot-plug operation, see [Replacing older Dual Ethernet and Dual SCSI cards](#) on page 76. For information on how to install HSI/P cards, see [Maintaining HSI/P cards](#) on page 80. For information on how to replace an RSC card, see [Replacing the RSC card](#) on page 94.

Required references

You need access to the following documents:

- *Sun Fire 880 Server Service Manual* at the Sun documentation Web site:
<http://docs.sun.com>
- The CMS software installation, maintenance, and troubleshooting document for your CMS release
- *Avaya Call Management System Switch Connections, Administration, and Troubleshooting*

Precautions

 **WARNING:**

The graphics card, Dual FastEthernet and Dual SCSI card, High-Speed Serial Interface/PCI (HSI/P) card, and RSC card are not hot-pluggable cards. Before replacing these cards, you must turn off the computer and, in the case of the RSC card, disconnect all AC power cords. For information on how to replace the graphics card, see [Replacing the graphics card](#) on page 71. For information on how to replace the older Dual Ethernet and Dual SCSI card that does not support hot-plug operation, see [Replacing older Dual Ethernet and Dual SCSI cards](#) on page 76. For information on how to install HSI/P cards, see [Maintaining HSI/P cards](#) on page 80. For information on how to replace an RSC card, see [Replacing the RSC card](#) on page 94.

 **CAUTION:**

Printed circuit boards and hard disk drives contain electronic components that are extremely sensitive to static electricity. Ordinary amounts of static from your clothes or the work environment can destroy components. Do not touch the components or any metal parts without taking proper antistatic precautions. See [Using an ESD wrist strap](#) on page 58 for more information.

PCI card configuration

The cards are installed in the slots shown in the following table. The minimum configuration has the graphics card in slot 7 and either a SunSwift card in slot 0 or a Dual FastEthernet and Dual SCSI card in Slot 8.

Slot		Card		
Number	Type	Name	Supports hot-plug? ¹	Device name
8	33/66MHz, 3.3V	Reserved for future use	N/A	N/A
7	33/66MHz, 3.3V	Graphics (required)	No	N/A
6	33MHz, 5V	Empty	N/A	N/A
5	33MHz, 5V	Empty	N/A	N/A
4	33MHz, 5V	Second HSI/P ² (optional)	No	N/A
3	33MHz, 5V	First HSI/P ² (optional)	No	N/A
2	33MHz, 5V	Second FastEthernet ³ (optional)	Yes	ce1
1	33MHz, 5V	First FastEthernet ³ (optional)	Yes	ce0
0	33MHz, 5V	SunSwift (required), or	Yes	eri0
		Dual FastEthernet and Dual SCSI (required)	Yes ⁴	eri0

1. Hot-plug operation for a PCI card requires that the card have detach-safe drivers. If the card does not have detach-safe drivers, the system must be shut down to add, remove, or replace the card.

2. The computer supports a maximum of two HSI/P cards for CMS. The first card must be in Slot 3. CMS R12 and later do not support HSI/P cards and X.25.

3. The computer supports a maximum of two FastEthernet cards for CMS. The first card must be in Slot 1.

4. The older Dual FastEthernet and Dual SCSI cards do not support hot-plug operation.

Maintaining hot-plug PCI cards

Some of the PCI cards used with the computer can be added, removed, or replaced without shutting down the computer. This procedure is called "hot-plugging" and uses a feature called "Dynamic Reconfiguration" that enables you to reconfigure system hardware while the system is running. The procedures in this section describe how to add and remove PCI cards that support hot-plug operation.

The following PCI cards support hot-plug operation:

- SunSwift
- FastEthernet
- Dual FastEthernet and Dual SCSI (newer versions)

Tip:


The hot-plug procedures are summarized on the inside panel of the left door.

This section includes the following topics:

- [PCI slot LEDs for hot-plug operation](#) on page 63
- [Preparing a hot-plug card for removal](#) on page 64
- [Removing a hot-plug PCI card](#) on page 65
- [Installing a hot-plug PCI card](#) on page 68
- [Configuring the new or replacement card](#) on page 70

PCI slot LEDs for hot-plug operation

The PCI slot LEDs are located on the vertical bracket on the right side of the PCI slots and are visible when the left door is open. There is a hot-plug button and three LEDs for each PCI slot, as shown below.



The PCI slot LEDs are defined as follows:

Icon	Name	LED function
	Power on	Lights when the slot is receiving power.
	Fault	Blinks while the card is being tested, when a hot-plug operation is in progress, or when the card is turned on but logically detached from the operating system. Stays lit if the card encounters a fault.
	OK-to-Remove	Lights when it is safe to remove the card. ▲ Important: If this LED stays lit after inserting a card, you must shut down the system, reinsert the card, and reboot the system. Consult the customer before you shut down the system.

The following table shows how to interpret the PCI slot LED patterns.

Icon			Interpretation
			
Off	Off	Off	The slot power is off. A card can be safely inserted to start a hot-plug operation.
On	Blinking	Off	The installed card is being tested, configured, or unconfigured, or the card is turned on but logically detached from the operating system.
On	Off	Off	The slot power is on and the card is operating normally.
Off	On	On	The PCI card has encountered a fault. The card can be safely removed.
Off	Off	On	The card can be safely removed.

Preparing a hot-plug card for removal

Before you remove a hot-plug card, you must verify that the devices residing on the card are not currently in use. In most cases, the card you are removing is faulty and not operating, but you must still first check to make sure the card is not in use by the operating system. With the SunSwift or Dual FastEthernet and Dual SCSI card, do not use the external tape drive, if installed, when removing the card. Make sure the tape drive does not have a tape installed.

To prepare a hot-plug card for removal:

1. Enter:

```
cfgadm
```

This displays the PCI card configuration before you remove a card. Check the Condition column for cards that are displaying `failed`, `failing`, or `unusable` status.

2. Enter:

```
ifconfig -a
```

Information similar to the following is displayed:

```
lo0: flags=1000849<UP,LOOPBACK,RUNNING,MULTICAST,IPv4> mtu 8232 index 1
    inet 127.0.0.1 netmask ff000000
eri0: flags=1000843<UP,BROADCAST,RUNNING,MULTICAST,IPv4> mtu 1500 index 2
    inet 135.9.88.83 netmask ffffffff broadcast 135.9.88.255
    ether 0:3:ba:a:fe:85
hme0: flags=1000843<UP,BROADCAST,RUNNING,MULTICAST,IPv4> mtu 1500 index 5
    inet 135.9.88.63 netmask ffffffff broadcast 135.9.88.255
    ether 0:3:ba:3:e6:18
```

The example above shows two administrable ethernet devices. Device `hme0` represents the built-in ethernet port and `eri0` represents the ethernet port on a SunSwift or Dual FastEthernet and Dual SCSI card. Any additional ethernet interfaces will be labeled `eri1` or `eri2`.

3. When you determine which device you are removing, enter the following commands:

```
ifconfig <device> down
```

```
ifconfig <device> unplumb
```

Where `<device>` is the device displayed with `ifconfig -a`.

4. If you are removing a SunSwift or Dual Ethernet and Dual SCSI card, enter the following command to verify that the external tape drive, if attached, is not being used:

```
mt -f /dev/rmt/1 status
```

If the device is busy, wait until all backups or restores running on the tape drive are completed before removing the card.

5. Continue with [Removing a hot-plug PCI card](#) on page 65.

Removing a hot-plug PCI card

To remove a card:

1. Make sure that the front panel key switch is *not* in the locked position. If it is, move the key switch to the diagnostic or normal position.
2. Open the left door.
3. Attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 58 for more information.
4. Identify which card you want to remove.
5. Disconnect the external cables connected to the card.

Maintenance

6. Press the hot-plug button for the card you are removing.


The Fault LED for the slot blinks while the card is being unconfigured.

7. When the OK-to-Remove LED lights, the card can be removed from the computer.


⚠ CAUTION:

Do not remove the card until the OK-to-Remove LED lights. If you remove the card when the OK-to-Remove LED is off, the system will fail.

8. Pinch the purple PCI card retaining clip until it releases from the back of the card and rotate the clip outward. See the following figure.



9. Carefully pull the card from the I/O board. See the following figure.



10. A message similar to the following is displayed in the console window:

```
Jun  6 12:55:24 sys_name picld[98]: Device PCI1_CARD removed
```

11. Place the card on an antistatic mat or in an antistatic bag.

12. Do one of the following:

- If you are replacing the card, continue with [Installing a hot-plug PCI card](#) on page 68.
- If you are not replacing the card, install a filler panel into the system rear panel, rotate the purple PCI retaining clip over the back of the filler panel until it snaps into place, remove the ESD wrist strap, close the side door, and return the key switch to its original position.

Installing a hot-plug PCI card


To install a card:

1. Enter:

```
cfgadm
```


This displays the PCI card configuration before you add a card. Make sure the slot is available for a new card. Recheck the configuration after you have added the card.

2. Make sure that the front panel key switch is *not* in the locked position. If it is, move the key switch to the diagnostic or normal position.
3. Open the left door.
4. Attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 58 for more information.
5. Identify the slot in which you want to install a card.
6. If not already done, pinch the purple PCI card retaining clip until it releases from the back of the card and rotate the clip outward. See the following figure.



7. If not already done, remove the filler panel from the slot.
8. Confirm that all three LEDs for the slot are off.

9. Insert the PCI card into the slot on the I/O board. Make sure that the card is fully seated. See the following figure.



When the card is inserted, the amber OK-to-Remove LED lights and a message similar to the following is displayed on the console window:

```
Jun  6 12:55:24 sys_name picld[98]: Device PCI1_CARD inserted
```

10. Rotate the purple PCI retaining clip over the back of the card faceplate until it snaps into place.
11. Press the hot-plug button for the card you are installing.

After the button is pressed, the following should occur:

- The amber Fault LED for the slot may blink briefly and then turn off.
- The green Power LED lights.
- A message similar to the following is displayed on the console window:

```
Jun  6 12:57:11 sys_name pcihp: NOTICE: pcihp (pcisch0): card is powered on in the slot hpcl_slotX
```

⚠ Important:

If the Fault LED remains off or stays lit after inserting a card, you must shut down the system, reinsert the card, and reboot the system.

Maintenance

12. Connect the external cables to the card.
13. Remove the ESD wrist strap.
14. Return the key switch to its original position.
15. Close the side door.

Configuring the new or replacement card

After you install a new or replacement card, do the following to configure the card:

1. Enter:

```
cfgadm
```

This displays the PCI card configuration after you add a card. Make sure the new card is displayed.

2. Set up the network interface using the procedures in "Setting up LAN connections" in the software installation chapter of the CMS software installation, maintenance, and troubleshooting document for your CMS release.
3. Enter the following commands:

```
ifconfig <device> plumb
```

```
ifconfig <device> inet <IP_address> netmask 255.255.255.0  
broadcast + up
```

Where:

- *<device>* is the device name
 - *<IP_address>* is the IP address being assigned to the card
4. Perform a CMSADM file system backup to back up the updated system configuration. See your CMS software installation, maintenance, and troubleshooting document for details.

Replacing the graphics card

The graphics card provides an interface for the local monitor.

⚠ Important:

The graphics card does *not* support hot-plug operation. You must shut down the system and turn off power before installing or replacing a card.

To replace a graphics card:

1. Log in to the system as root.

2. Enter:

```
cfgadm
```

This displays the PCI card configuration before you replace a card. Recheck the configuration after you have replaced the card.

3. Enter:


```
/usr/sbin/shutdown -y -i0 -g0
```

This shuts down the system.

4. Press and release the front panel power button to turn off the system.

Wait for the front panel Power/OK LED to turn off.


5. Turn the key switch to the Forced Off position. See the following figure.




⚠ DANGER:

Be sure to turn the key switch to the Forced Off position before handling any internal components. Otherwise, it is possible for a user to restart the system remotely while you are working inside it. The Forced Off position is the only key switch position that prevents an RSC user from restarting the system.

6. Open the left door.
7. Attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 58 for more information.
8. Disconnect the monitor cable connected to the card. The graphics card is installed in slot 7.
9. Pinch the purple PCI card retaining clip until it releases from the back of the card and rotate the clip outward. See the following figure.




10. Carefully pull the card from the I/O board. See the following figure.



11. Place the card on an antistatic mat or in an antistatic bag.

Maintenance

12. Insert the new graphics card into the slot on the I/O board. Make sure that the card is fully seated. See the following figure.



13. Rotate the purple PCI retaining clip over the back of the card faceplate until it snaps into place.
14. Connect the monitor cable to the card.
15. Remove the ESD wrist strap.
16. Close the left door.
17. Reattach the monitor cable.
18. Turn on any external SCSI devices, starting with the device that is farthest from the system and working toward the system.
19. Turn on the system monitor.
Turn on the system.
20. When the system comes back up, log in as root.
21. Enter:

```
cfgadm
```

This displays the PCI card configuration after you replace the card. Make sure that the new card is displayed.
22. If you just installed an XVR-100 graphics accelerator card, continue with [Installing the XVR-100 software packages](#) on page 75.

Installing the XVR-100 software packages

The XVR-100 software packages must be installed after you install a new XVR-100 graphics accelerator card. If you are replacing an existing XVR-100 graphics accelerator card, you do not have to reinstall this software.

To install the XVR-100 software packages on a Sun Fire V880 system:

1. Verify that your CMS system is running CMS R3V11 by entering:

```
pkginfo -x cms
```

Note:

Do not perform this procedure if your CMS system is running a later load of CMS. The software packages were installed with the Solaris operating system.

2. Verify that the XVR-100 graphics accelerator card is installed.

Note:

For information on how to install the XVR-100 graphics accelerator card, see the Sun documentation that was shipped with the card.

3. Load the CD-ROM, *Sun XVR-100 FCS* into the CD-ROM drive.

4. Enter:

```
cd /cdrom/cdrom0
```

5. Enter:

```
./install
```

The system installs the **SUNWpfbx.u**, **SUNWpfbcf**, **SUNWpfbw**, and **SUNWpfbmn** packages.

6. Enter:

```
/usr/sbin/shutdown -y -i0 -g0
```

The system shuts down and displays the `ok` prompt.

7. Enter:

```
boot -r
```

8. Log into the system as **root**.

The system reboots and displays the `#` prompt.

9. Enter:

```
eject cdrom
```

Replacing older Dual Ethernet and Dual SCSI cards

A Dual Ethernet and Dual SCSI card supports ethernet and SCSI connections.

Note:

The older versions of the Dual Ethernet and Dual SCSI cards do *not* support hot-plug operation. You must shut down the system and turn off power before installing or replacing a card. If you are replacing a newer card that does support hot-plug operation, see [Maintaining hot-plug PCI cards](#) on page 62.

To replace older Dual Ethernet and Dual SCSI cards:

1. Log in to the system as root.

2. Enter:

```
cfgadm
```

This displays the PCI card configuration before you replace a card. Recheck the configuration after you have replaced the card.

3. Enter:


```
/usr/sbin/shutdown -y -i0 -g0
```

This shuts down the system.

4. Press and release the front panel power button to turn off the system.

Wait for the front panel Power/OK LED to turn off.


5. Turn the key switch to the Forced Off position. See the following figure.



⚠ DANGER:


Be sure to turn the key switch to the Forced Off position before handling any internal components. Otherwise, it is possible for a user to restart the system remotely while you are working inside it. The Forced Off position is the only key switch position that prevents an RSC user from restarting the system.

6. Open the left door.
7. Attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 58 for more information.
8. Identify which card you want to remove.
9. Disconnect and label the cables connected to the card.
10. Pinch the purple PCI card retaining clip until it releases from the back of the card and rotate the clip outward. See the following figure.




Maintenance

11. Carefully pull the card from the I/O board. See the following figure.



12. Place the card on an antistatic mat or in an antistatic bag.

13. Insert the new Dual Ethernet and Dual SCSI card into the slot on the I/O board. Make sure that the card is fully seated. See the following figure.



14. Rotate the purple PCI retaining clip over the back of the card faceplate until it snaps into place.
15. Remove the ESD wrist strap.
16. Close the left door.
17. Reattach the cables.
18. Turn on any external SCSI devices, starting with the device that is farthest from the system and working toward the system.
19. Turn on the system monitor.
20. Turn on the system.
21. When the system comes back up, log in as root.
22. Enter:

```
cfgadm
```

This displays the PCI card configuration after you replace the card. Make sure that the new card is displayed.

Maintaining HSI/P cards

An HSI/P card supports X.25 switch links. For eight links, two HSI/P cards and two quad cables are needed. If the system uses TCP/IP signaling for all links, HSI/P cards are not needed. HSI/P cards are not supported beginning with CMS R12.

 **Important:**

The HSI/P card does *not* support hot-plug operation. You must shut down the system and turn off power before installing or replacing a card.

This section includes the following topics:

- [Replacing an HSI/P card](#) on page 80
- [Installing the first HSI/P card or a pair of HSI/P cards](#) on page 85
- [Installing HSI/P software and patches](#) on page 88
- [Setting up the switch link for each ACD](#) on page 88
- [Adding a second HSI/P card](#) on page 90

If you are replacing a defective HSI/P card, see [Replacing an HSI/P card](#) on page 80. If this is the initial installation of one or two HSI/P cards, start with [Installing the first HSI/P card or a pair of HSI/P cards](#) on page 85. If a second HSI/P card is being added to a system already in operation, see [Adding a second HSI/P card](#) on page 90.

Replacing an HSI/P card

To replace an HSI/P card:

1. Log in to the system as root.
2. Enter:

```
cfgadm
```

This displays the PCI card configuration before you replace a card. Recheck the configuration after you have replaced the card.


3. Enter:

```
/usr/sbin/shutdown -y -i0 -g0
```

This shuts down the system.

4. Press and release the front panel power button to turn off the system.
Wait for the front panel Power/OK LED to turn off.

5. Turn the key switch to the Forced Off position. See the following figure.




⚠ DANGER:

Be sure to turn the key switch to the Forced Off position before handling any internal components. Otherwise, it is possible for a user to restart the system remotely while you are working inside it. The Forced Off position is the only key switch position that prevents an RSC user from restarting the system.


6. Open the left door.
7. Attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 58 for more information.
8. Identify which card you want to remove.
9. Disconnect the HSI/P quad cable connected to the card.

Maintenance

10. Pinch the purple PCI card retaining clip until it releases from the back of the card and rotate the clip outward. See the following figure.




11. Carefully pull the card from the I/O board. See the following figure.



12. Place the card on an antistatic mat or in an antistatic bag.

Maintenance

13. Insert the new HSI/P card into the slot on the I/O board. Make sure that the card is fully seated. See the following figure.



14. Rotate the purple PCI retaining clip over the back of the card faceplate until it snaps into place.
15. Remove the ESD wrist strap.
16. Close the left door.
17. Reattach the HSI/P quad cable.
18. Turn on any external SCSI devices, starting with the device that is farthest from the system and working toward the system.
19. Turn on the system monitor.
20. Turn on the system.
21. When the system comes back up, log in as root.
22. Enter:

```
cfgadm
```

This displays the PCI card configuration after you replace the card. Make sure that the new card is displayed.

Installing the first HSI/P card or a pair of HSI/P cards

To install the first HSI/P card or a pair of HSI/P cards:

1. Verify that you have a recent CMSADM file system backup before you change card configurations.
2. Log in to the system as root.
3. Enter:

```
cfgadm
```


This displays the PCI card configuration before you add a card. Recheck the configuration after you have added the card.

4. Enter:

```
/usr/sbin/shutdown -y -i0 -g0
```

This shuts down the system.

5. Press and release the front panel power button to turn off the system.
Wait for the front panel Power/OK LED to turn off.
6. Turn the key switch to the Forced Off position. See the following figure.




⚠ DANGER:

Be sure to turn the key switch to the Forced Off position before handling any internal components. Otherwise, it is possible for a user to restart the system remotely while you are working inside it. The Forced Off position is the only key switch position that prevents an RSC user from restarting the system.

7. Turn off the system monitor.
8. Turn off any external SCSI devices, starting with the device that is closest to the system and working toward the farthest device.


Maintenance

9. Open the left door.
10. Attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 58 for more information.
11. Identify the slot in which you want to install the HSI/P cards. Slot 3 is recommended for the first HSI/P card and slot 4 is recommended for the second HSI/P card.
12. Pinch the purple PCI card retaining clip until it releases from the back of the card and rotate the clip outward. See the following figure.



13. Remove the filler panel from the slot.

14. Insert the first HSI/P card into slot 3 on the I/O board. Make sure that the card is fully seated. See the following figure.



15. Rotate the purple PCI retaining clip over the back of the card faceplate until it snaps into place.
16. If installing a second HSI/P card in slot 4, repeat Steps 12 through 15.
17. Remove the ESD wrist strap.
18. Close the left door.
19. Attach the HSI/P quad cables, and connect the switch links to the quad cables by following the instructions described in *Avaya Call Management System Switch Connections, Administration, and Troubleshooting*.
20. Turn on any external SCSI devices, starting with the device that is farthest from the system and working toward the system.
21. Turn on the system monitor.
22. Turn on the system. Do *not* put the keyswitch in the locked position.
As the system powers up, the power LED on the monitor flashes.
23. Press **Stop+A** simultaneously as soon as the monitor power LED lights steadily and the Sun logo is displayed on the monitor.
The `ok` prompt is displayed.

Maintenance

24. Enter:

```
boot -r
```

This reboots the system so that it recognizes the new HSI/P cards.

Note:

Sometimes the system fails to recognize a newly installed HSI card. If this happens, the command `show-devs` does not show the HSI card and `/var/adm/messages` fails to recognize the card upon bootup. See the troubleshooting chapter of *Avaya Call Management System Switch Connections, Administration, and Troubleshooting* for information about troubleshooting HSI/P cards.

25. When the system comes back up, log in as root.

26. Enter:

```
cfgadm
```

This displays the PCI card configuration after you add the card. Make sure that the new card is displayed.

27. Continue with [Installing HSI/P software and patches](#) on page 88.

Installing HSI/P software and patches

Use the following procedures in the CMS software installation, maintenance, and troubleshooting document to:

- Install the HSI/P software
- Reinstall the Solaris patches

After installing the software and patches, continue with [Setting up the switch link for each ACD](#) on page 88

Setting up the switch link for each ACD

To change the switch link administration for each ACD:

1. Enter:

```
cmssvc
```

The CMS Services menu is displayed.

2. Select the `run_cms` option.

3. Turn off CMS.

4. Enter:

```
cmssvc
```

The CMS Services menu is displayed.

5. Select the `swsetup` option.
6. Select the ACD that you want to set up.
7. Accept the existing defaults for the following:
 - Switch name
 - Switch model (release)
 - Vectoring
 - Expert agent
 - Central office disconnect supervision
 - Local port
 - Remote port
8. Select "X.25" and a specific link number when prompted for the link information.
9. Repeat Steps 4 through 8 for each ACD that will use the HSI card.
10. Enter:

```
cmssvc
```

The CMS Services menu is displayed.
11. Select the `run_cms` option.
12. Turn on CMS.
13. Test and troubleshoot each switch connection using the procedures in *Avaya Call Management System Switch Connections, Administration, and Troubleshooting*.
14. Perform a CMSADM file system backup to back up the updated system configuration. See your CMS software installation, maintenance, and troubleshooting document for details.

Adding a second HSI/P card

Use the following procedure to add a second HSI/P card to a system that is already in operation.

To add a second HSI/P card:

1. Verify that you have a recent CMSADM file system backup before you change card configurations.
2. Log in to the system as root.
3. Enter:

```
cfgadm
```


This displays the PCI card configuration before you add a card. Recheck the configuration after you have added the card.

4. Enter:

```
/usr/sbin/shutdown -y -i0 -g0
```

This shuts down the system.

5. Press and release the front panel power switch to turn off the system.
Wait for the front panel Power/OK LED to turn off.
6. Turn the key switch to the Forced Off position. See the following figure.




⚠ DANGER:

Be sure to turn the key switch to the Forced Off position before handling any internal components. Otherwise, it is possible for a user to restart the system remotely while you are working inside it. The Forced Off position is the only key switch position that prevents an RSC user from restarting the system.

7. Turn off the system monitor.


8. Turn off any external SCSI devices, starting with the device that is closest to the system and working toward the farthest device.
9. Open the left door.
10. Attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 58 for more information.
11. Identify the slot in which you want to install the HSI/P card. Slot 4 is recommended for the second HSI/P card.
12. Pinch the purple PCI card retaining clip until it releases from the back of the card and rotate the clip outward. See the following figure.



13. If not already done, remove the filler panel from the slot.

Maintenance

14. Insert the HSI/P card into slot 4 on the I/O board. Make sure that the card is fully seated. See the following figure.



15. Rotate the purple PCI retaining clip over the back of the card faceplate until it snaps into place.
16. Remove the ESD wrist strap.
17. Close the left door.
18. Attach the HSI/P quad cable, and connect the switch links to the quad cable by following the instructions described in *Avaya Call Management System Switch Connections, Administration, and Troubleshooting*.
19. Turn on any external SCSI devices, starting with the device that is farthest from the system and working toward the system.
20. Turn on the system monitor.
21. Turn on the system. Do *not* put the keyswitch in the locked position.
As the system powers up, the power LED on the monitor flashes.
22. Press **Stop+A** simultaneously as soon as the monitor power LED lights steadily and the Sun logo is displayed on the monitor.
The `ok` prompt is displayed.

23. Enter:

```
boot -r
```

This reboots the system so that it recognizes the new HSI/P card.

Note:

Sometimes the system fails to recognize a newly installed HSI card. If this happens, the command `show-devs` does not show the HSI card and `/var/adm/messages` fails to recognize the card upon bootup. See the troubleshooting chapter of *Avaya Call Management System Switch Connections, Administration, and Troubleshooting* for information about troubleshooting HSI/P cards.

24. When the system comes back up, log in as root.

25. Enter:

```
cfgadm
```

This displays the PCI card configuration after you add the card. Make sure that the new card is displayed.

26. Administer the switch links as shown in [Setting up the switch link for each ACD](#) on page 88.

Replacing the RSC card

This section shows how to replace an RSC card. The RSC card is located below the nine PCI card slots on the I/O board. It is labeled "RSC" on the rear panel of the computer.

 **DANGER:**

The system supplies hazardous voltage to the RSC card even when the system is turned off. To avoid personal injury or damage to the RSC card, you must disconnect the AC power cords before servicing the RSC card.

This section includes the following topics:

- [Required references](#) on page 94
- [Replacing the RSC card](#) on page 94

Required references

For additional information about replacing the RSC card, see *Sun Fire 880 Server Service Manual* at the Sun documentation Web site:

<http://docs.sun.com>

Replacing the RSC card

To replace the RSC card:

1. Log in to the system as root.
2. Enter:


```
/usr/sbin/shutdown -y -i0 -g0
```

This shuts down the system.

3. Press and release the front panel power button to turn off the system.

Wait for the front panel Power/OK LED to turn off.

4. Turn the key switch to the Forced Off position. See the following figure.




⚠ DANGER:

Be sure to turn the key switch to the Forced Off position before handling any internal components. Otherwise, it is possible for a user to restart the system remotely while you are working inside it. The Forced Off position is the only key switch position that prevents an RSC user from restarting the system.

5. Turn off the system monitor.
6. Turn off any external SCSI devices, starting with the device that is closest to the system and working toward the farthest device.
7. Disconnect the AC power cords from all power supplies.
8. Open the left door.
9. Attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 58 for more information.
10. Disconnect any external cables connected to the RSC card.
11. Using a Phillips No. 1 screwdriver, remove the screw that secures the card to the system rear panel.


Maintenance

12. Remove the RSC card from the slot. See the following figure.



13. Place the RSC card on an antistatic mat or in an antistatic bag.

14. Insert the faceplate end of the new RSC card into the appropriate opening in the rear panel. See the following figure.



15. Insert the opposite end of the card into the appropriate card guide so that the RSC card is aligned evenly with the connectors on the I/O board.
16. Push the card into the connectors on the system I/O board, applying even pressure along the edge of the card.
17. Secure the RSC card faceplate to the rear panel with the Phillips screw.
18. Connect the Ethernet, serial, and modem cables to the appropriate connector on the RSC card.
19. Reconnect the AC power cords to the power supplies.
20. Remove the ESD wrist strap.
21. Close the side door.

Maintenance

22. Turn on any external SCSI devices, starting with the device that is farthest from the system and working toward the system.
23. Turn on the system monitor.
24. Turn on the system.
25. When the system comes back up, log in as root.

After replacing the RSC card, you must restore the RSC configuration settings. These procedures are described in the following sections of the CMS software installation, maintenance, and troubleshooting document for your CMS release:

- "Customizing Sun Remote System Control" and "Testing Sun Remote System Control" in the chapter "Turning the system over to the customer"
- "Backing up and restoring the RSC card configuration" in the chapter "Maintaining the Avaya CMS software"

In addition, the replacement card has a new Ethernet MAC address, which may necessitate configuration changes to other network devices. To determine the Ethernet MAC address for the new RSC card, use the RSC command `shownetwork`. For more information, see the *Sun Remote System Control User's Guide* at the Sun documentation Web site:

<http://docs.sun.com>

Maintaining disk drives

This section includes the following topics:

- [Disk drive compatibility with CMS loads](#) on page 99
- [Prerequisites](#) on page 99
- [Disk drive configurations](#) on page 100
- [Required references](#) on page 101
- [Replacing disk drives](#) on page 101
- [Adding disk drives \(optional\)](#) on page 119

Disk drive compatibility with CMS loads

When a new or replacement disk drive is installed in an older system, the CMS load may not be compatible with the disk drive if the CMS configuration files have not been updated. Two configuration files (`/olds/disk.conf` and `/olds/olds-funcs`) must be edited or replaced with the correct information. Contact the Avaya technical support organization for assistance.

Prerequisites


If possible, do a CMSADM backup before you add or replace a disk drive. See your CMS software installation, maintenance, and troubleshooting document for this procedure.

Before you attempt to replace defective data (nonboot) disks, try to print the current setup for all ACDs. This information must be readministered after you install replacement disks.

Disk drive configurations

The computer supports a four-disk mirrored configuration that can be expanded to six disks with a field upgrade.

The following diagram shows a six-disk configuration:



The disks are mirrored as follows:

	Primary	Mirror
Boot disk pair	Slot 0	Slot 3
First data disk pair	Slot 1	Slot 4
Second data disk pair (optional)	Slot 2	Slot 5

! Important:

Each pair of disks must be the same size. For example, if the disk in slot 0 is 73-GB, the disk in slot 3 must also be 73-GB.

Required references

You need access to the following documents to do the disk maintenance procedures:

- The CMS software installation, maintenance, and troubleshooting document for your CMS release
- *Sun Fire 880 Server Service Manual* at the Sun documentation Web site:
<http://docs.sun.com>

Replacing disk drives

The procedures for replacing disk drives is different for the following scenarios:

Replacing a single boot disk - If at least one of the boot disk drives (primary or mirror) is in operation, you can hot-plug a replacement boot disk drive without turning off the system. See [Replacing a single boot disk or replacing data disks](#) on page 101.

Replacing data disk drives - When replacing one or more data disk drives, you can hot-plug the replacement disk drives without turning off the system. See [Replacing a single boot disk or replacing data disks](#) on page 101.

Replacing both boot disks - If both boot disk drives are defective, you must shut down and turn off the system before replacing the disk drives. See [Replacing both boot disks](#) on page 108.

After replacing the disk drives, continue with [Setting up replacement disk drives](#) on page 112.

Replacing a single boot disk or replacing data disks

If you are replacing a single boot disk or a data disk, you can hot-plug the disk drives without shutting down the system.

To remove and replace a single boot disk or a data disk:

1. Unlock and open the front door.
2. Identify which disk drives must be replaced.

Maintenance

3. Enter the following commands:

```
cd /
```

```
luxadm probe
```

The name of the fiber channel loop is displayed.

```
Found Enclosure:  
SUNWGS INT FCBPL   Name:FCloop   Node WWN:508002000016b5b0   Logical Path:/  
dev/es/ses0
```

4. Record the name of the fiber channel loop. In this example, the name is FCloop.

5. Enter:

```
luxadm display loop_name
```

where *loop_name* is the name of the fiber channel loop.

Example:

```
luxadm display FCloop
```

The slot number for every disk in the system is displayed.

Note:

The system will display a warning if a problem is detected with any of the disk drives.

```

SUNWGS INT FCBPL
DISK STATUS
SLOT  DISKS                (Node WWN)
0      On (O.K.)          20000004cf81e68a
1      On (O.K.)          20000004cf81e851
2      Not Installed
3      On (O.K.)          20000004cf81e4d4
4      On (O.K.)          20000004cf81e910
5      Not Installed
6      On (Login failed)
7      On (Login failed)
8      On (Login failed)
9      On (Login failed)
10     On (Login failed)
11     On (Login failed)

SUBSYSTEM STATUS
FW Revision:9224   Box ID:0
Node WWN:508002000016b5b0   Enclosure Name:FCloop
SSC100's - 0=Base Bkpln, 1=Base LoopB, 2=Exp Bkpln, 3=Exp LoopB
SSC100 #0:   O.K.(9224/ 3FA5)
SSC100 #1:   O.K.(9224/ 3FA5)
SSC100 #2:   Not Installed
SSC100 #3:   Not Installed
Temperature Sensors - 0 Base, 1 Expansion
0:24°C
1Not Installed
Default Language is USA English, ASCII

```

6. Record the faulty disk number.

7. Enter:

```
luxadm remove loop_name,snumber
```

where *loop_name* is the name of the fiber channel loop, and

where *number* is the slot number for the disk drive.

Example:

```
luxadm remove FCloop,s3
```

A message similar to the following is displayed:

```
WARNING!!! Please ensure that no filesystems are mounted on these device(s).  
All data on these devices should have been backed up.
```

```
The list of devices which will be removed is:
```

```
1: Box Name:      "FCloop" slot 3  
   Node WWN:      20000004cf81e4d4  
   Device Type:   Disk device  
   Device Paths:  
     /dev/rdisk/c1t3d0s2
```

```
Please verify the above list of devices and  
then enter 'c' or <CR> to Continue or 'q' to Quit. [Default: c]:
```

Note:

If a "device is busy" message is displayed, verify that the correct device is being removed. Retry the command using the **-F** option. For example, enter `luxadm remove -F FCloop,s3`.

8. Verify that the disk you want to remove is displayed.

9. Choose one of the following:

- If the correct device is displayed, enter: **c**
- If the correct device is *not* displayed, enter: **q**


If you removed the device, a message similar to the following is displayed:

```
stopping: Drive in "FCloop" slot 3...Done  
offlining: Drive in "FCloop" slot 3...Done  
  
Hit <Return> after removing the device(s).
```

The amber LED for the disk turns on when the disk can be safely removed from the computer. The green LED for the disk starts blinking slowly.

10. Attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 58 for more information.

- Using your thumb and forefinger, push the drive latch upward to release the drive handle. Swing the handle away from the drive until you feel the drive connector disengage from the backplane. Do not use excessive force. See the following figure.



- Holding the drive by the handle, carefully slide it out of the drive bay.
- Place the drive on an antistatic mat or in an antistatic bag.
- Press **Enter**.

A message similar to the following is displayed:

```
Drive in Box Name "FCloop" slot 3
Logical Nodes being removed under /dev/dsk/ and /dev/rdisk:
Logical Nodes being removed under /dev/dsk/ and /dev/rdisk:
c1t3d0s0
c1t3d0s1
c1t3d0s2
c1t3d0s3
c1t3d0s4
c1t3d0s5
c1t3d0s6
c1t3d0s7
```

Maintenance


15. Enter:

```
luxadm insert
```

The following message is displayed:

```
Please hit <RETURN> when you have finished adding Fibre Channel Enclosure(s) /  
Device(s) :
```

16. Release the drive handle on the replacement disk drive. Use your thumb and forefinger to pinch the drive latch upward to open it.
17. Align the disk drive with its drive bay. Orient the drive so that the drive handle hinge faces the bottom of the drive bay.
18. Holding the drive by its handle, fit the drive into the guide rails at the top and bottom of the drive bay. See the following figure.



19. Slide the drive into the bay until it barely contacts the backplane.
20. Press carefully on the center of the drive. The drive handle begins to close as the drive engages its backplane connector.
21. Press the handle toward the drive until the latch closes, securing the drive in place.

22. Press Enter.

A message similar to the following is displayed:

```
Waiting for Loop Initialization to complete...
New Logical Nodes under /dev/dsk and /dev/rdisk :
    c1t3d0s0
    c1t3d0s1
    c1t3d0s2
    c1t3d0s3
    c1t3d0s4
    c1t3d0s5
    c1t3d0s6
    c1t3d0s7
No new enclosure(s) were added!!
```

Note:

Ignore the message No new enclosure(s) were added!!.

23. If you are installing more than one disk drive, wait for the green light on the drive you just installed to light steadily (not flashing) before installing another drive. Repeat Steps 3 through 22.
24. Close the front door and, if necessary, lock it.
25. Continue with [Setting up replacement disk drives](#) on page 112.

Replacing both boot disks


To replace both boot disk drives:

1. If the system is operating, enter:

```
/usr/sbin/shutdown -y -i0 -g0
```

The system shuts down and displays the `ok` prompt.

2. Press and release the front panel power button to turn off the system.
Wait for the front panel Power/OK LED to turn off.
3. Turn the key switch to the Forced Off position. See the following figure.




⚠ DANGER:

Be sure to turn the key switch to the Forced Off position before handling any internal components. Otherwise, it is possible for a user to restart the system remotely while you are working inside it. The Forced Off position is the only key switch position that prevents an RSC user from restarting the system.

4. Turn off the system monitor.
5. If any external SCSI devices are installed, turn off the SCSI devices starting with the device that is closest to the system and work towards the farthest device.
6. Unlock and open the front door.
7. Attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 58 for more information.
8. Using your thumb and forefinger, push the drive latch upward to release the drive handles for the disks in slots 0 and 3. Swing the handle away from the drive until you


feel the drive connector disengage from the backplane. Do not use excessive force. See the following figure.



9. Holding the drive by the handle, carefully slide it out of the drive bay.
10. Place the drive on an antistatic mat or in an antistatic bag.
11. Release the drive handle on the replacement disk drive. Use your thumb and forefinger to pinch the drive latch upward to open it.
12. Align the disk drive with its drive bay. Orient the drive so that the drive handle hinge faces the bottom of the drive bay.

Maintenance

13. Holding the drive by its handle, fit the drive into the guide rails at the top and bottom of the drive bay. See the following figure.



14. Slide the drive into the bay until it barely contacts the backplane.
15. Press carefully on the center of the drive. The drive handle begins to close as the drive engages its backplane connector.
16. Press the handle toward the drive until the latch closes, securing the drive in place.
17. Repeat this procedure for both boot disk drives.
18. Close the front door and, if necessary, lock it.
19. Turn on any external SCSI devices, starting with the device that is farthest from the system and working toward the system.
20. Turn on the system monitor.
21. Turn on the system. Do *not* put the keyswitch in the locked position.
As the system powers up, the power LED on the monitor flashes.
22. Press **Stop+A** simultaneously as soon as the monitor power LED lights steadily and the Sun logo is displayed on the monitor.
The `ok` prompt is displayed.

23. Enter the following commands:

```
setenv auto-boot? false
reset-all
```

The system reboots to the `ok` prompt.

24. Enter:

```
probe-scsi
```

This verifies that the system recognizes all of the disk devices, including the newly installed ones. A message that is similar to the following example is displayed:

LiD	HA	LUN	---	Port	WWN	---	-----Disk description	-----
0	0	0		21000004cf72f08f			SEAGATE ST373405FSUN3660438	
1	1	0		21000004cf721553			SEAGATE ST373405FSUN3660438	
6	6	0		508002000016b5b1			SUNW SUNWGS INT FCBPL9224	
3	3	0		21000004cf72114b			SEAGATE ST373405FSUN3660438	
4	4	0		21000004cf7211ae			SEAGATE ST373405FSUN3660438	

The devices listed depends on the number of disks that are installed in the system.

25. Enter the following commands:

⚠ CAUTION:

If you fail to enter these commands, any reboots that you do in the future will stop at the boot prompt instead of proceeding through the normal boot-up process.

```
setenv auto-boot? true
boot -r
```

The system reboots.

26. Log in as root.

27. Continue with [Setting up replacement disk drives](#) on page 112.

Setting up replacement disk drives

After you replace defective disk drives, do one of the following, depending on drives replaced:

Drives replaced	Procedure
One boot disk	Partition the new boot disk drive (see Partitioning replacement disk drives on page 113). Continue with the procedures in "Recovering a mirrored system after disk failure" in the maintenance chapter of the CMS software installation, maintenance, and troubleshooting document for your CMS release.
Both boot disks	Continue with the procedures in "Performing a CMSADM restore of a mirrored or non-mirrored system" in the maintenance chapter of the CMS software installation, maintenance, and troubleshooting document for your CMS release.
Data disks	Partition and administer the drive so that it works with the existing disk drives (see Partitioning replacement disk drives on page 113). Continue with the procedures in "Recovering a mirrored system after disk failure" in the maintenance chapter of the CMS software installation, maintenance, and troubleshooting document for your CMS release.

Partitioning replacement disk drives

If you are replacing a defective data disk drive in a system and CMS is not operational, or if you are replacing a single defective boot disk (primary or mirror), you must manually partition the disk drive. Use the following information:

- [Disk partition values, R3V11 and later boot disks](#) on page 113 or [R3V11 and later data disks](#) on page 114.
- [Partitioning and formatting a replacement disk](#) on page 115.

Disk partition values

During the disk partitioning procedure, you must enter the size of each partition. Since disk models change often, see the software installation, maintenance, and troubleshooting document for your current CMS release to verify the correct disk partitioning values.

R3V11 and later boot disks - The following table lists the boot disk drives that are used with R3V11 and later. These partition sizes are entered in Gigabytes (gb).

Disk	Partition	ID tag	Permission flag	Starting cylinder	Value
73-GB	0	root	wm	0	4gb
	1	swap	wu	825	1gb
	2 ¹	backup	wm	Use the default values for partition 2.	
	3	un	wm	1032	3gb
	4	un	wm	1651	2gb
	5-7	un	wm	Do not enter a value for partitions 5 through 7. These values are populated automatically when the boot disks resynchronize during the restore procedure.	

1. The value that is displayed for the backup partition shows the size of the disk drive. If the disk drive you are partitioning does not closely match the size of the disk you are partitioning (for example, 68-GB for a 73-GB disk), you have a nonstandard disk. Escalate the issue to Avaya technical support.

Maintenance

R3V11 and later data disks - The following table lists the data disk drives that are supported with R3V11 and later. These partition sizes are entered in Gigabytes (gb) and cylinders (c).

Disk	Partition	ID tag	Permission flag	Starting cylinder	Value
73-GB	0	un	wm	0	2gb
	1	un	wm	413	2gb
	2 ¹	backup	Do not enter a value for partition 2.		
	3	un	wm	826	2gb
	4	un	wm	1239	2gb
	5	un	wm	1652	2gb
	6	un	wm	2065	2gb
	7	un	wm	2478	11609c

1. The value that is displayed for the backup partition shows the size of the disk drive. If the disk drive you are partitioning does not closely match the size of the disk you are partitioning (for example, 68-GB for a 73-GB disk), you have a nonstandard disk. Escalate the issue to Avaya technical support.

Partitioning and formatting a replacement disk

To partition and format a disk:

1. At the system prompt, enter:

```
format
```

A message that is similar to the following example is displayed:

```
Searching for disks...done

AVAILABLE DISK SELECTIONS:
  0. c1t0d0 <SUN72G cyl 14087 alt 2 hd 24 sec 424>
     /pci@8,600000/SUNW,qlc@2/fp@0,0/ssd@w21000004cf81e931,0
  1. c1t1d0 <SUN72G cyl 14087 alt 2 hd 24 sec 424>
     /pci@8,600000/SUNW,qlc@2/fp@0,0/ssd@w21000004cf81e17f,0
  3. c1t3d0 <SUN72G cyl 14087 alt 2 hd 24 sec 424>
     /pci@8,600000/SUNW,qlc@2/fp@0,0/ssd@w21000004cf707d9f,0
  4. c1t4d0 <SUN72G cyl 14087 alt 2 hd 24 sec 424>
     /pci@8,600000/SUNW,qlc@2/fp@0,0/ssd@w21000004cf81e2f0,0
Specify disk (enter its number):
```

2. Enter the disk number that corresponds to the disk that you added. Be sure to specify the number that *exactly* matches the disk added.

```
Specify disk (enter its number): 1
```

The device number of the disk that you are partitioning, for example, `c0t1d0`, and the Format Menu are displayed:

```
selecting c1t1d0
[disk formatted]

FORMAT MENU:
  disk      - select a disk
  type      - select (define) a disk type
  partition - select (define) a partition table
  current   - describe the current disk
  format    - format and analyze the disk
  repair    - repair a defective sector
  label     - write label to the disk
  analyze   - surface analysis
  defect    - defect list management
  backup    - search for backup labels
  verify    - read and display labels
  save      - save new disk/partition definitions
  inquiry   - show vendor, product and revision
  volname   - set 8-character volume name
  !<cmd>    - execute <cmd>, then return
  quit

format>
```

3. Enter:

partition

The partition menu is displayed:

```

PARTITION MENU:
    0      - change `0' partition
    1      - change `1' partition
    2      - change `2' partition
    3      - change `3' partition
    4      - change `4' partition
    5      - change `5' partition
    6      - change `6' partition
    7      - change `7' partition
select - select a predefined table
modify - modify a predefined partition table
name    - name the current table
print   - display the current table
label   - write partition map and label to the disk
!<cmd> - execute <cmd>, then return
quit
partition>
    
```

4. At the `partition>` prompt, enter:

print

The default partition table is displayed. The table for a 72-GB FC-AL data disk will look similar to the following example:

```

Current partition table (original):
Total disk cylinders available: 14087 + 2 (reserved cylinders)

Part      Tag      Flag      Cylinders      Size      Blocks
 0 unassigned  wm        0 - 412        2.00GB    (413/0/0)    4202688
 1 unassigned  wm       413 - 825        2.00GB    (413/0/0)    4202688
 2 backup      wm        0 - 14086      68.35GB   (14087/0/0) 143349312
 3 unassigned  wm       826 - 1238        2.00GB    (413/0/0)    4202688
 4 unassigned  wm      1239 - 1651        2.00GB    (413/0/0)    4202688
 5 unassigned  wm      1652 - 2064        2.00GB    (413/0/0)    4202688
 6 unassigned  wm      2065 - 2477        2.00GB    (413/0/0)    4202688
 7 unassigned  wm      2478 - 14086      56.33GB   (11609/0/0) 118133184

partition>
    
```

5. Partition the disk by completing the following Steps a through e for all partitions specified in the [Disk partition values](#) on page 113.

- a. At the `partition>` prompt, enter the partition number from the table. For example:

```
partition> 0
```

The system prompts for the partition ID tag.

- b. Enter the partition ID tag from the table. For partition 0, press **Enter** to accept the default of unassigned.

```
Enter partition id tag [unassigned]:
```

The system prompts for permission flags.

- c. Enter the permission flag, usually `wm` or `wu`.

The system prompts for the starting cylinder.

- d. Enter the number of the starting cylinder from the table. For example:

```
Enter new starting cyl [0]: 0
```

The system prompts for the partition size.

- e. Enter the partition size from the table. For example:

```
Enter partition size [0b, 0c, 0mb]: 2gb
```

The `partition>` prompt is displayed.

6. When you have sized all of the partitions, enter:

```
print
```

7. Compare the partition table that is now displayed to the [Disk partition values](#) on page 113. If there are any discrepancies, correct them by repeating the disk partitioning.

8. When you determine that the disk partitioning is correct, enter:

```
label
```

The system prompts you to continue.

 **Important:**

Do not forget to label the disk drive.

9. Enter: `y`

The `partition>` prompt is displayed.

Maintenance

10. Enter: **q**

The `format>` prompt is displayed.

11. Enter:

format

The following message is displayed:

```
Ready to format. Formatting cannot be interrupted
and takes XX minutes (estimated). Continue? (y or n)
```

12. Enter: **y**

A message similar to the following is displayed:

```
Begin format. The current time is <timestamp>

Formatting...
done

Verifying media...
    pass 0 - pattern = 0xc6dec6de
    4923/26/7

    pass 1 - pattern = 0x6db6db6d
    4923/26/7

Total of 0 defective blocks repaired.
format>
```

13. If you added more than one disk drive, enter `disk`, and repeat Steps 2 through 12 for each drive.

14. After you have partitioned each drive, enter: **q**

15. Continue with the restore procedures as described in [Setting up replacement disk drives](#) on page 112.

Adding disk drives (optional)

If you are adding a pair of data disks (optional), you can hot-plug the disk drives without shutting down the system.

To add a pair of data disks:

1. Unlock and open the front door.
2. Enter the following commands:

```
cd /
```

```
luxadm insert
```


The following message is displayed:

```
Please hit <RETURN> when you have finished adding Fibre Channel Enclosure(s)/  
Device(s):
```

3. Attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 58 for more information.
4. Release the drive handle on the replacement disk drive. Use your thumb and forefinger to pinch the drive latch upward to open it.
5. Align the disk drive with slot 2. Orient the drive so that the drive handle hinge faces the bottom of the drive bay.

Maintenance

6. Holding the drive by its handle, fit the drive into the guide rails at the top and bottom of the drive bay. See the following figure.



7. Slide the drive into the bay until it barely contacts the backplane.
8. Press carefully on the center of the drive. The drive handle begins to close as the drive engages its backplane connector.
9. Press the handle toward the drive until the latch closes, securing the drive in place.
10. Press **Enter**.

A message similar to the following is displayed:

```
Waiting for Loop Initialization to complete...
New Logical Nodes under /dev/dsk and /dev/rdisk :
  c1t2d0s0
  c1t2d0s1
  c1t2d0s2
  c1t2d0s3
  c1t2d0s4
  c1t2d0s5
  c1t2d0s6
  c1t2d0s7
No new enclosure(s) were added!!
```

Note:

Ignore the message `No new enclosure(s) were added!!`.

11. Wait for the green light on the drive you just installed to light steadily (not flashing) before installing another drive.
12. Repeat Steps 2 through 11 for the data disk installed in slot 5.
13. Close the front door and, if necessary, lock it.
14. Enter:

```
cmssvc
```

The CMS Services menu is displayed.

Note:

If the system also displays the following message, you must first turn on IDS before continuing with Step 15.

```
cmssvc: Warning IDS off-line. It will take approx 30 seconds to start
cmssvc. IDS can be turned on with the run_ids command on the cmssvc
menu.
```

15. Enter the number that corresponds to the `disk_space` option.
16. Enter the number that corresponds to the `Add new disks` option.
The disks to be added are displayed.
17. Enter the number that corresponds to the disks you want to add.

The system administers the new disks, which may take several minutes depending on the number and size of the disks. The following message is displayed:

```
added new disk cXtXd0
disk_space command completed.
```

Note:

Depending on the size of the disks, the system may run slowly until all disks are synchronized.

Replacing the DVD-ROM drive


To replace the DVD-ROM drive:

1. Remove any CD-ROMs from the drive.
2. Log in to the system as root.
3. Enter:

```
/usr/sbin/shutdown -y -i0 -g0
```

This shuts down the system. The `ok` prompt is displayed at the local console.

4. Press and release the front panel power button to turn off the system.
Wait for the front panel Power/OK LED to turn off.
5. Turn the key switch to the Forced Off position. See the following figure.




⚠ DANGER:

Be sure to turn the key switch to the Forced Off position before handling any internal components. Otherwise, it is possible for a user to restart the system remotely while you are working inside it. The Forced Off position is the only key switch position that prevents an RSC user from restarting the system.

6. Open both side doors of the computer. See [Accessing components inside the computer](#) on page 55 for more information
7. Attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 58 for more information.


8. Remove the two screws securing the front cover to the front of the system. See the following figure.



9. Remove the front cover.
10. Disconnect the data and power cables from the back of the drive.


Maintenance

11. Remove the two screws that secure the drive to the chassis. See the following figure.



12. Slide the drive out through the front of the chassis.

13. Set the SCSI address on the new drive using the jumpers on the back of the drive. Set DVD-ROM drive to 6. See the following figure.



dvd_cd_jumpers.cdr

14. Slide the replacement drive into the chassis and secure it with the screws that were removed earlier.
15. Connect the drive data and power cables to the back of the drive.
16. Replace the front cover.
17. Remove the ESD wrist strap.
18. Close the side doors.
19. Turn on the system. Do *not* put the keyswitch in the locked position.
As the system powers up, the power LED on the monitor flashes.
20. Press **Stop+A** simultaneously as soon as the monitor power LED lights steadily and the Sun logo is displayed on the monitor.
The `ok` prompt is displayed.
21. Enter the following commands:

```
setenv auto-boot? false
reset-all
```

This resets the system and the `ok` prompt is displayed.
22. Enter:

```
probe-scsi-all
```

This checks to see that the system recognizes the new drive. If the new drive is not listed, make sure there is a secure cable connection.
23. Reboot the system by entering the following commands:
⚠ CAUTION:
If you fail to enter these commands, any reboots that you do in the future will stop at the boot prompt instead of proceeding through the normal boot-up process.

```
setenv auto-boot? true
boot
```

This reboots the system.

Maintaining tape drives

This section includes the following topics:

- [Tape drive compatibility](#) on page 126
- [Ordering tapes](#) on page 126
- [Cleaning the tape drive](#) on page 127
- [Replacing the internal tape drive](#) on page 128
- [Adding and removing an external tape drive for data migration](#) on page 131

Tape drive compatibility

The DDS-4 tape drive used with the Sun Fire V880 is *not* the same model used with the Sun Enterprise 3500. When replacing a DDS-4 tape drive in the Sun Fire V880, make sure you order the correct replacement.

Ordering tapes

Replacement backup data and tape drive cleaning cartridge tapes can be ordered from your local computer or office supply store. Depending on your tape drive model, order the following cartridge tapes:

Description	Tape drive
DAT 72 36/72-GB, 4mm, 170m	DAT 72
DDS-4 20/40-GB, 4mm, 150-155m	DDS-4 and DAT 72
DDS 4mm cleaning cartridge	DDS-4 and DAT 72

 **Important:**

If you are using the CMS High Availability feature and one of your systems uses a DDS-4 tape drive while the other uses a DAT 72 tape drive, you must use DDS-4 tape cartridges in both systems. Using the same size backup tapes allows you to do manual data restores on both systems, no matter which one may need the restore.

Cleaning the tape drive

This section describes how you clean the tape drive.

Note:

Starting around June, 2004, CMS servers will no longer ship with tape drive cleaning tapes. Avaya recommends that customers purchase at least one cleaning tape as soon as the server is installed and in service.

The number of cleaning cycles available on a cleaning cartridge depends on the manufacturer of the cartridge. Regular cleaning is recommended to maximize tape drive performance. Avaya recommends that you clean the tape drive once a week or every five (5) data backups, whichever comes first.

The LEDs on the tape drives indicate when the tape drives need cleaning. See [Tape drive LEDs](#) on page 178. If the Clean LED flashes, either the tape drive heads need cleaning, or the backup tape needs replacing.

To clean the tape drive:

1. Load the cleaning cartridge into the tape drive.

The cleaning cycle begins automatically, and the Tape LED flashes. When the cleaning cycle is complete, the cleaning cartridge is ejected automatically. If the cleaning cartridge does not eject automatically, it may be defective and may need replacing.

2. The first time you use the cleaning cartridge, record the date on the cleaning cartridge. Each time you clean the tape drive, mark an X in the box. After all boxes are filled, replace the cleaning cartridge.

3. Return the cleaning cartridge to the plastic protection box.

If the Clean LED continues to flash, repeat the cleaning procedure using a different cleaning cartridge. If the Clean LED is still flashing, repeat the backup operation with a different tape. If this clears the signal, the first backup tape is nearing the end of its life. Discard the old tape.

Replacing the internal tape drive


To replace the internal tape drive:

1. Remove any tapes from the drive.
2. Log in to the system as root.
3. Enter:

```
/usr/sbin/shutdown -y -i0 -g0
```

This shuts down the system. The `ok` prompt is displayed at the local console.

4. Press and release the front panel power button to turn off the system.
Wait for the front panel Power/OK LED to turn off.
5. Turn the key switch to the Forced Off position. See the following figure.




⚠ DANGER:


Be sure to turn the key switch to the Forced Off position before handling any internal components. Otherwise, it is possible for a user to restart the system remotely while you are working inside it. The Forced Off position is the only key switch position that prevents an RSC user from restarting the system.

6. Open both side doors of the computer. See [Accessing components inside the computer](#) on page 55 for more information
7. Attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 58 for more information.

8. Remove the two screws securing the front cover to the front of the system. See the following figure.



9. Remove the front cover.
10. Disconnect the data and power cables from the back of the drive.
11. Remove the two screws that secure the drive to the chassis.
12. Slide the drive out through the front of the chassis.
13. Set the SCSI address on the new drive using the jumpers on the back of the drive. Set the tape drive to 5. See the following figure.



14. Slide the replacement drive into the chassis and secure it with the screws that you removed earlier.

Maintenance

15. Connect the drive data and power cables to the back of the drive.
16. Replace the front cover.
17. Remove the ESD wrist strap.
18. Close the side doors.
19. Turn on the system. Do *not* put the keyswitch in the locked position.
As the system powers up, the power LED on the monitor flashes.
20. Press **Stop+A** simultaneously as soon as the monitor power LED lights steadily and the Sun logo is displayed on the monitor.

The `ok` prompt is displayed.

21. Enter the following commands:

```
setenv auto-boot? false
```

```
reset-all
```

This resets the system and the `ok` prompt is displayed.

22. Enter:

```
probe-scsi-all
```

This checks to see that the system recognizes the new drive. If the new drive is not listed, make sure there is a secure cable connection.

23. Reboot the system by entering the following commands:

 **CAUTION:**

If you fail to enter these commands, any reboots that you do in the future will stop at the boot prompt instead of proceeding through the normal boot-up process.

```
setenv auto-boot? true
```

```
boot
```

This reboots the system.

Adding and removing an external tape drive for data migration

To temporarily add an external tape drive for data migration, and remove the tape drive when the migration is complete:

1. Log in to the system as root.
2. Enter the following commands:

```
cd /dev/rmt
```

```
pwd
```

The `pwd` command verifies that you are in the `/dev/rmt` directory.

3. Enter:

```
rm *
```

This removes tape drive device files. If you do not remove the tape drive device files before rebooting the system, the tape drive device files may not match the hardware configuration.

4. Enter:


```
/usr/sbin/shutdown -y -i0 -g0
```

The system shuts down.

5. Press and release the front panel power button to turn off the system.

Wait for the front panel Power/OK LED to turn off.

6. Turn the key switch to the Forced Off position. See the following figure.



 **DANGER:**

Be sure to turn the key switch to the Forced Off position before handling any internal components. Otherwise, it is possible for a user to restart the system remotely while you are working inside it. The Forced Off position is the only key switch position that prevents an RSC user from restarting the system.

7. Turn off the system monitor.
8. Turn off any external SCSI devices, starting with the device that is closest to the system and working toward the farthest device.
9. Using the Target Address Switch on the back of the external tape drive, set the SCSI ID to 4.
10. Connect the tape drive to the SCSI port on the SunSwift card or the Dual FastEthernet and Dual SCSI card.
11. Connect the power cord from the tape drive to a power source.
12. Turn on any external SCSI devices, starting with the device that is farthest from the system and working toward the system.
13. Turn on the system monitor.
14. Turn on the system. Do *not* put the keyswitch in the locked position.
As the system powers up, the power LED on the monitor flashes.
15. Press **Stop+A** simultaneously as soon as the monitor power LED lights steadily and the Sun logo is displayed on the monitor.
The `ok` prompt is displayed.
16. Enter the following commands:

```
setenv auto-boot? false  
reset-all
```

The system resets and displays the `ok` prompt.
17. Enter:

```
probe-scsi-all
```

This checks to see that the system recognizes the new tape drive. The resulting display should list the new drive as Target 4. If the new drive is not listed, check for a secure connection between the SCSI port and the new drive.
18. Reboot the system by entering the following commands:

⚠ CAUTION:

If you fail to enter these commands, any reboots that you do in the future will stop at the boot prompt instead of proceeding through the normal boot-up process.

```
setenv auto-boot? true
```

```
boot -r
```

This reboots the system so that it recognizes the new configuration.

19. Use the external tape drive to migrate data onto the system.
20. When finished migrating the data, enter the following commands:

```
cd /dev/rmt
```

```
pwd
```

The `pwd` command verifies that you are in the `/dev/rmt` directory.

21. Remove any tapes from the drive.

22. Enter:

```
rm *
```

This removes tape drive device files. If you do not remove the tape drive device files before rebooting the system, the tape drive device files may not match the hardware configuration.

23. Enter:

```
/usr/sbin/shutdown -y -i0 -g0
```


The system shuts down.

24. Press and release the front panel power button to turn off the system.

Wait for the front panel Power/OK LED to turn off.

Maintenance

25. Turn the key switch to the Forced Off position. See the following figure.



⚠ DANGER:

Be sure to turn the key switch to the Forced Off position before handling any internal components. Otherwise, it is possible for a user to restart the system remotely while you are working inside it. The Forced Off position is the only key switch position that prevents an RSC user from restarting the system.

26. Turn off the system monitor.
27. Turn off any external SCSI devices, starting with the device that is closest to the system and working toward the farthest device.
28. Disconnect the tape drive from the SCSI port.
29. Turn on any external SCSI devices, starting with the device that is farthest from the system and working toward the system.
30. Turn on the system monitor.
31. Turn on the system. Do *not* put the keyswitch in the locked position.
As the system powers up, the power LED on the monitor flashes.
32. Press **Stop+A** simultaneously as soon as the monitor power LED lights steadily and the Sun logo is displayed on the monitor.
The `ok` prompt is displayed.
33. Enter the following commands:

```
setenv auto-boot? false  
reset-all
```

The system resets.

34. Enter:

```
probe-scsi-all
```

In its default configuration, the computer should list two SCSI devices: the internal tape drive (Target 5) and the DVD-ROM drive (Target 6).

35. Reboot the system by entering the following commands:

 **CAUTION:**

If you fail to enter these commands, any reboots that you do in the future will stop at the boot prompt instead of proceeding through the normal boot-up process.

```
setenv auto-boot? true
```

```
boot -r
```

This reboots the system so that it recognizes the new configuration.

Maintaining CPU/Memory boards

This section describes how to replace or add memory modules and CPU/Memory boards.

This section includes the following topics:

- [CPU and memory configurations](#) on page 136
- [Checking the current memory and CPU configuration](#) on page 137
- [Shutting down the system](#) on page 138
- [Removing a CPU/Memory board](#) on page 139
- [Replacing memory](#) on page 140
- [Installing a CPU/Memory board](#) on page 142
- [Restarting the system](#) on page 145

 **WARNING:**

You must wear an ESD wrist strap when installing or removing hardware components to prevent electrical discharge that can damage the system.

CPU and memory configurations

The minimum memory configuration of the computer is one CPU/Memory board that has two processors and 4-GB of memory.

The computer can be upgraded to four total CPU/Memory boards, each with two processors and 4-GB memory. The maximum memory is 16-GB.

 **Important:**

The CPUs in all memory boards must match. You cannot, for example, mix a 900 MHz CPU with a 1.2 GHz CPU.

Checking the current memory and CPU configuration

To check the current memory size, memory configuration, and CPU configuration:

1. Enter:

```
/usr/platform/`uname -m`/sbin/prtdiag -v | pg
```

The current memory size, memory configuration, and CPU configuration are displayed.

```
System Configuration: Sun Microsystems sun4u Sun Fire 880
System clock frequency: 150 MHz
Memory size: 4096 Megabytes

===== CPUs =====

```

Brd	CPU	Run MHz	E\$ MB	CPU Impl.	CPU Mask
A	0	1200	8.0	US-III+	11.1
A	2	1200	8.0	US-III+	11.1

```
===== Memory Configuration =====

```

Brd	MC ID	Logical Bank num	Logical Bank size	Logical Bank Status	DIMM Size	Interleave Factor	Interleaved with
A	0	0	512MB	no_status	256MB	8-way	0
A	0	1	512MB	no_status	256MB	8-way	0
A	0	2	512MB	no_status	256MB	8-way	0
A	0	3	512MB	no_status	256MB	8-way	0
A	2	0	512MB	no_status	256MB	8-way	0
A	2	1	512MB	no_status	256MB	8-way	0
A	2	2	512MB	no_status	256MB	8-way	0
A	2	3	512MB	no_status	256MB	8-way	0
.							
.							

2. Record the current memory size, memory configuration, and CPU configuration.

Shutting down the system

To shut down the system:

1. Enter:


```
/usr/sbin/shutdown -y -i0 -g0
```

The system shuts down.

2. Press and release the front panel power button to turn off the system.

Wait for the front panel Power/OK LED to turn off.

3. Turn the key switch to the Forced Off position. See the following figure.



⚠ DANGER:

Be sure to turn the key switch to the Forced Off position before handling any internal components. Otherwise, it is possible for a user to restart the system remotely while you are working inside it. The Forced Off position is the only key switch position that prevents an RSC user from restarting the system.

4. Turn off the system monitor.


5. Turn off any external SCSI devices, starting with the device that is closest to the system and working toward the farthest device.

Removing a CPU/Memory board

To add memory or replace a CPU/Memory board, you must first remove the CPU/Memory board.

To remove a CPU/Memory board:

1. Open the right door.
2. Attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 58 for more information.
3. Identify the CPU/Memory board that you want to remove.
4. Loosen, but do not remove, the two captive screws securing the CPU/Memory board. See the following figure.



Maintenance

5. Rotate the CPU/Memory board ejection levers out so that the CPU/Memory board connectors disengage from the motherboard. See the following figure.



6. Pull the CPU/Memory board from the chassis.
7. Place the CPU/Memory board on an antistatic mat or in an antistatic bag.

Replacing memory

This section describes the procedures used to replace memory on a CPU/Memory board that you have already removed from the system (see [Removing a CPU/Memory board](#) on page 139). The board contains 4-GB of memory. When replacing memory modules, you must replace modules in groups of four within a bank of memory.


Tip:

The procedure for replacing memory is summarized on the top of the CPU/Memory board.

To replace memory modules:

1. Attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 58 for more information.

2. Remove the plastic cover on the CPU/Memory board. Push the tabs in until you can lift the cover free of the CPU/Memory board shroud. See the following figure.



3. Identify which modules you are removing.
4. Applying even pressure on both levers, push down on the ejector levers at each end of the memory module until the memory module pops out of the socket. See the following figure.



5. Grasp the top corners of the memory module and pull it up and out of the socket.
6. Place the memory module on an antistatic mat or in an antistatic bag.
7. Push down on the ejector levers at each end of the sockets.

8. Holding the bottom edge of the module parallel to the socket, align the module so that each of the contacts is centered on a socket pin. See the following figure.



9. Push firmly and evenly on both ends of the memory module until the bottom edge is firmly seated in the socket. You will hear a click when the ejection levers are in the locked position.
10. Replace the plastic cover on the CPU/Memory board.
11. Continue with [Installing a CPU/Memory board](#) on page 142.

Installing a CPU/Memory board

Use this procedure to install a new CPU/Memory board or to reinstall a CPU/Memory board that was removed for maintenance.

To install a CPU/Memory board:



1. If not already done, open the right door.
2. If not already done, attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 58 for more information.
3. Locate the CPU/Memory board slot into which you want to install the CPU/Memory board.
4. If a CPU/Memory board connector yellow dust cover is installed on the slot's motherboard CPU/Memory board connectors, remove it.

⚠ WARNING:

If you do not remove the dust cover from the motherboard CPU/Memory board connectors, installing a CPU/Memory board in that slot may damage the motherboard and the CPU/Memory board.


5. If a CPU air baffle is installed in the CPU/Memory board slot, remove the air baffle. Pull the plastic tab on the air baffle and rotate the baffle from its slot. Place the CPU air

baffle into an empty CPU air baffle slot on the underside of the chassis top. See the following figure.



Maintenance

6. Make sure that the ejection levers on the CPU/Memory board are pointed out, rotated at 90 degrees. See the following figure.



7. Slide the CPU/Memory board into the guides in the chassis. Slide the board into the system until the connectors on the board begin to engage the sockets on the motherboard and the ejection levers begin to contact the bracket.
8. Push in the two ejection levers simultaneously until the board is fully engaged in its slot.
9. Hand-tighten the two captive screws on the CPU/Memory board.
10. Using a No. 2 Phillips screwdriver, fully tighten the right captive screw and repeat for the left captive screw.
11. Remove the ESD wrist strap.
12. Close the side door.

Restarting the system

To restart the system:

1. Turn on any external SCSI devices, starting with the device that is farthest from the system and working toward the system.
2. Turn on the system monitor.
3. Turn on the system.

This reboots the system so that it recognizes the new configuration.

4. When the system comes back up, log in as root.
5. Enter:

```
/usr/platform/`uname -m`/sbin/prtdiag -v | pg
```

The new memory size, memory configuration, and CPU configuration are displayed.

```
System Configuration: Sun Microsystems sun4u Sun Fire 880
System clock frequency: 150 MHz
Memory size: 4096 Megabytes

===== CPUs =====

```

Brd	CPU	Run MHz	E\$ MB	CPU Impl.	CPU Mask
A	0	1200	8.0	US-III+	11.1
A	2	1200	8.0	US-III+	11.1

```

===== Memory Configuration =====

```

Brd	MC ID	Logical Bank num	Logical Bank size	Logical Bank Status	DIMM Size	Interleave Factor	Interleaved with
A	0	0	512MB	no_status	256MB	8-way	0
A	0	1	512MB	no_status	256MB	8-way	0
A	0	2	512MB	no_status	256MB	8-way	0
A	0	3	512MB	no_status	256MB	8-way	0
A	2	0	512MB	no_status	256MB	8-way	0
A	2	1	512MB	no_status	256MB	8-way	0
A	2	2	512MB	no_status	256MB	8-way	0
A	2	3	512MB	no_status	256MB	8-way	0

```

.
```

6. Verify that the memory size that is displayed is correct, and compare it to the value that you recorded before you added the new memory. If the new memory size is not correct, shut down the system, turn off the power, and verify that all the memory modules are properly seated.

Maintenance

7. If a one or more CPU/Memory board is added to the system, readminister the Informix IDS tunables as described in the section "Setting the Informix configuration parameters for CMS" in the CMS software installation, maintenance, and troubleshooting document for your CMS release.

Replacing a power supply

A power supply can be replaced without shutting down the system.

⚠ WARNING:

A power supply must always occupy bays 0 and 1. If a power supply in bay 0 or 1 fails, you must leave the failed power supply in its bay until you are able to install a functioning replacement power supply. A failed power supply in bay 0 or 1 continues to act as an air baffle, channeling airflow to cool the bottom row of disk drives in the disk cage. Replace the failed power supply as soon as possible to regain power redundancy.

To replace a power supply:


1. Identify the power supply that you want to remove. See [Power supply LEDs](#) on page 175 for information about diagnosing power supplies.
2. Release the AC power cord from the strain-relief tie-wrap on the power supply. Press the tab on the head of the tie-wrap to release it. See the following figure.



3. Unplug the AC power cord from the power supply.

Maintenance

4. Loosen the two captive Phillips screws securing the power supply to the system rear panel. See the following figure.




5. Pull the power supply out from its bay. Use one hand to pull the power supply out while using the other hand to support the power supply as it is removed from the system.

⚠ Important:

When hot-swapping a power supply, do not disengage and reengage the supply in rapid succession. Rapid seating and unseating of power supplies will result in false error conditions.

6. After removing a supply, wait for an acknowledgement message on the system console before installing a new supply. Otherwise, the environmental monitoring software will not recognize the new device, and false error conditions will result.

7. Slowly slide the new power supply into its bay until the connectors on the power supply are fully engaged with the connectors on the power distribution board. See the following figure.



8. Tighten the two captive screws that secure the power supply to the chassis.
9. Connect the AC power cord to the power supply. Insert the power cord through the strain-relief tie-wrap loop, located to the right of the supply. Tighten the tie-wrap to secure the connection.

Note:

You can also replace a power supply when the system is at the boot level (that is, the `ok` prompt is displayed). If a power supply is replaced at the boot level, you must reboot the system using the `reset-all` command.

■ ■ ■ ■ ■ ■ Troubleshooting

This section includes the following topics:

- [Using the remote console](#) on page 152
- [Using the RSC](#) on page 159
- [Tools](#) on page 161
 - [Using the prtdiag command](#) on page 162
 - [Using the cfgadm command](#) on page 165
 - [System messages](#) on page 166
 - [OpenBoot PROM firmware tests](#) on page 167
 - [OpenBoot diagnostic tests](#) on page 172
 - [POST diagnostic messages](#) on page 175
 - [OpenBoot initialization commands](#) on page 176
 - [Diagnosing LED patterns](#) on page 177
 - [Sun Validation Test Suite \(VTS\)](#) on page 185
- [Troubleshooting disk drives and DVD-ROM drives](#) on page 186
- [Troubleshooting tape drives](#) on page 189
- [Recovery procedures](#) on page 192

Additional troubleshooting - See the *Sun Fire 880 Service Manual* at the Sun documentation Web site for additional troubleshooting procedures:

<http://docs.sun.com>

Using the remote console

If your system does not boot, or if the system cannot be diagnosed locally, remote support personnel might want to redirect control of the console port from the local console to a dialed-in remote console. Redirecting the console allows support personnel to do maintenance remotely as if they were at the local console. You can redirect the console using either:

- The Solaris operating system
- OpenBoot diagnostics

This section consists of the following procedures:

- [Redirecting the console using Solaris](#) on page 152. Use this procedure when the system will boot up to the Solaris operating system.
- [Redirecting the console using OpenBoot mode](#) on page 155. Use this procedure when the system will not boot up to the Solaris operating system.

Redirecting the console using Solaris

The following procedure describes how to use the Solaris operating system to redirect the local console to the serial port and is usually done from the remote console that has dialed in to the system. Should you encounter any problems setting up the remote console, see [Remote console port problems](#) on page 200 for troubleshooting procedures.

 **CAUTION:**

Use the following procedure only when absolutely necessary. If the console redirects and the modem line drops, you may not be able to get back into the system.

Redirecting the local console to the remote console

To redirect control of the console port from the local console to a dialed-in remote console:

1. Dial in from the remote console to the remote console modem, and log in as root.
2. At the remote console, enter:

```
/cms/install/bin/abcadm -r ttya
```

The following message is displayed at the remote console:

```
ttya is currently set to be incoming
Are you sure you want to change it? [y,n,?]
```

3. At the remote console, enter: **y**

The following message is displayed at the remote console:

```
ttya administration removed
```

4. At the remote console, enter:

```
/cms/install/bin/abcmadm -c -b 9600 ttya
```

The following message is displayed at the remote console:

```
This change requires a reboot to take affect  
Are you ready to reboot? [y,n,?]
```

5. At the remote console, enter: **y**

The following message is displayed at the remote console:

```
done  
desktop auto-start disabled  
Proceeding to reboot.
```

The following occurs:

- The system begins to shut down.
- Shutdown, reset, and reboot messages are displayed on the local console.
- When the system starts to come back up, the local console goes blank.
- The system boot diagnostics are displayed on the remote console.
- After the system reboots, a `console login:` prompt is displayed on the remote console.

6. Log in to the remote console as root.

Redirecting the remote console back to the local console

⚠ CAUTION:

Do not enter **Ctrl+D** from the remote console to exit the system without first redirecting control back to the local console. If you do, you may lock yourself from using the console locally or remotely.

To redirect control of the console port from the remote console back to the local console:

1. At the remote console, enter:

```
/cms/install/bin/abcadm -c local
```

The following message is displayed at the remote console:

```
Console set to local

This change requires a reboot to take affect

Are you ready to reboot? [y,n,?]
```

2. At the remote console, enter: **y**

The following occurs:

- The system begins to shut down.
 - Shutdown, reset, and reboot messages are displayed on the local console.
 - When the system starts to come back up, the system boot diagnostics are displayed on the local console.
 - After the system reboots, the `console login:` prompt is displayed on the remote console.
 - The login screen is displayed on the local console.
3. Log in to the local console as root.
 4. Log in to the remote console as root.

Control of the console port is redirected from the remote console back to the local console.

Redirecting the console using OpenBoot mode

This procedure describes how to use the OpenBoot mode to redirect the local console to serial port A. Use the OpenBoot mode to redirect the remote console port when the Solaris method does not work. This typically occurs when the system will not boot.

Redirecting the local console to the remote console

To redirect control of the console port from the local console to a dialed-in remote console:

1. If the system is not already at the `ok` prompt, enter:

```
/usr/sbin/shutdown -y -i0 -g0
```

The system shuts down to the `ok` prompt.

⚠ CAUTION:

If the shutdown command fails, press **Stop+A** simultaneously after the console banner is displayed, but before the operating system starts booting.

2. At the local console, enter the following commands to set the remote console configuration parameters:

```
setenv input-device ttya
setenv output-device ttya
setenv ttya-rts-dtr-off true
setenv ttya-ignore-cd true
setenv ttya-mode 9600,8,n,1,-
```

3. To verify the parameter changes, enter:

```
printenv
```

The following message is displayed:

Parameter Name	Value	Default Value
output-device	ttya	screen
input-device	ttya	keyboard
.		
.		
.		

4. If not already dialed in, dial in to the system from the remote console.
5. Log in to the system as root.

Troubleshooting

6. At the local console, enter:

```
boot
```

The following occurs:

- The system begins to shut down.
- Shutdown, reset, and reboot messages are displayed on the local console.
- When the system starts to come back up, the local console goes blank.
- The system boot diagnostics are displayed on the remote console.
- After the system reboots, a `console login:` prompt is displayed on the remote console.

7. Log in to the remote console as root.

Redirecting the remote console back to the local console

CAUTION:

Do not enter **Ctrl+D** from the remote console to exit the system without first redirecting control back to the local console. If you do, you may lock yourself from using the console locally or remotely.

Using OpenBoot mode, there are two ways to redirect control of the console port from the remote console back to the local console:

- [Method 1: from the remote console](#) on page 157 (recommended)
- [Method 2: from the local site](#) on page 158 (not recommended)

Method 1: from the remote console - To redirect control of the console port from the remote console back to the local console:

1. Do one of the following:

- If the system is in UNIX, enter the following commands at the remote console:

```
eeeprom output-device=screen
eeeprom input-device=keyboard
eeeprom ttya-rts-dtr-off=true
eeeprom ttya-ignore-cd=false
/usr/sbin/shutdown -y -i6 -g0
```

- If the system is in OpenBoot mode, enter the following commands at the remote console:

```
setenv output-device screen
setenv input-device keyboard
setenv ttya-rts-dtr-off true
setenv ttya-ignore-cd false
reset
```

The following occurs:

- The system begins to shut down.
- Shutdown, reset, and reboot messages are displayed on the remote console.
- When the system starts to come back up, the system boot diagnostics are displayed on the local console.
- The login screen is displayed on the local console.

2. At the remote console, hang up the modem connection.

3. Log in to the system as root at the local console.

4. To see what is on the ttya port, enter:

```
/cms/install/bin/abcadm -k
```

5. To start a port monitor on ttya, enter:

```
/cms/install/bin/abcadm -i -b 9600 ttya
```

Method 2: from the local site - The onsite technician will use this procedure from the local site. Use this method only when Method 1 will not work.

 **CAUTION:**

This method of redirecting the console port should be done only as a last resort. This procedure resets the NVRAM defaults to the Sun factory settings. These settings will remain in effect until the next reboot. This procedure could also cause loss of data and disk failure, and could require a disk restore.

To redirect control of the console port from the remote console back to the local console:

1. Turn the power off and back on for the CMS computer.
2. As the computer begins to boot up, double-click the power button on the front of the system.

Note:

Double-clicking the power button during power-up is the equivalent to **Stop+N** on a system that has a non-USB keyboard.

The prompt is displayed on the local console.

3. At the `ok` prompt, enter:

```
boot
```

4. When the system boots up, log in to the system as root at the local console.
5. To see what is on the `ttya` port, enter:

```
/cms/install/bin/abcadm -k
```

6. To start a port monitor on `ttya`, enter:

```
/cms/install/bin/abcadm -i -b 9600 ttya
```

The following message is displayed:

```
ttya set to incoming port 9600 baud
```

Using the RSC

The RSC software works in conjunction with the RSC card to allow remote administration of the computer. You will be able to access the Solaris and OpenBoot console functions and control the power-on self-test (POST) and OpenBoot diagnostics.

This section includes the following topics:

- [Redirecting the local console to the RSC](#) on page 159
- [Redirecting the RSC to the local console](#) on page 160

Redirecting the local console to the RSC

To redirect the local console to the RSC:

 **Important:**

Do not redirect the console to the RSC unless the RSC card has as been configured for a second ethernet interface or phone line. If you redirect the console to an incorrectly configured RSC card, you will not be able to access the system through the local console or the RSC card.

1. Enter from the local console:

```
/usr/sbin/shutdown -y -i0 -g0
```

The `ok` prompt is displayed.

2. Enter the following commands to set the RSC environment:

```
setenv diag-console rsc
setenv input-device rsc-console
setenv output-device rsc-console
```

3. Enter:

```
reset-all
```

The system reboots and the local console is directed to the RSC.

4. Log in to the RSC.

Redirecting the RSC to the local console

To redirect the RSC to the local console:

1. Enter from the RSC:

```
/usr/sbin/shutdown -y -i0 -g0
```

The `ok` prompt is displayed.

 **CAUTION:**

If the shutdown command fails, press **Stop + A** simultaneously after the display console banner is displayed, but before the operating system starts booting.

2. Enter the following commands to set the local console environment:

```
setenv diag-console ttya
```

```
setenv input-device keyboard
```

```
setenv output-device screen
```

3. Enter:

```
reset-all
```

The system reboots and the RSC is directed to the local console.

Additional references - For more information about the RSC card and software, see *Sun Remote System Control (RSC) User's Guide* at the Sun documentation Web site:

<http://docs.sun.com>

Tools

There are several tools available to help diagnose hardware problems. The tools are described in the following sections:

- [Using the prtdiag command](#) on page 162
- [Using the cfgadm command](#) on page 165
- [System messages](#) on page 166
- [OpenBoot PROM firmware tests](#) on page 167
- [OpenBoot diagnostic tests](#) on page 172
- [POST diagnostic messages](#) on page 175
- [OpenBoot initialization commands](#) on page 176
- [Diagnosing LED patterns](#) on page 177
- [Sun Validation Test Suite \(VTS\)](#) on page 185

Using the prtdiag command

The `prtdiag` command displays system diagnostic information.

To display this diagnostic information, enter:

```
/usr/platform/`uname -m`/sbin/prtdiag -v | pg
```

The following is an example of the results for the computer.

```
System Configuration: Sun Microsystems sun4u Sun Fire 880
System clock frequency: 150 MHz
Memory size: 4096 Megabytes
===== CPUs =====
```

Brd	CPU	Run MHz	E\$ MB	CPU Impl.	CPU Mask
A	0	1200	8.0	US-III+	11.1
A	2	1200	8.0	US-III+	11.1

```
===== Memory Configuration =====
```

Brd	MC ID	Logical Bank num	Logical Bank size	Logical Bank Status	DIMM Size	Interleave Factor	Interleaved with
A	0	0	512MB	no_status	256MB	8-way	0
A	0	1	512MB	no_status	256MB	8-way	0
A	0	2	512MB	no_status	256MB	8-way	0
A	0	3	512MB	no_status	256MB	8-way	0
A	2	0	512MB	no_status	256MB	8-way	0
A	2	1	512MB	no_status	256MB	8-way	0
A	2	2	512MB	no_status	256MB	8-way	0
A	2	3	512MB	no_status	256MB	8-way	0

```
===== IO Cards =====
```

Brd	IO Type	Port ID	Bus Side	Slot	Bus Freq MHz	Max Bus Freq	Bus Dev, Func	State	Name
I/O	PCI	8	B	3	33	33	2,0	ok	pci1214,334-pci1214,334.10
I/O	PCI	8	B	2	33	33	3,0	ok	pci108e,1000-pci108e,1000.1
I/O	PCI	8	B	2	33	33	3,1	ok	SUNW,hme-pci108e,1001SUNW,psi-cheerio
I/O	PCI	8	B	1	33	33	4,0	ok	pci108e,1000-pci108e,1000.1
I/O	PCI	8	B	1	33	33	4,1	ok	SUNW,hme-pci108e,1001SUNW,psi-cheerio
I/O	PCI	8	B	0	33	33	5,0	ok	pci-pci8086,b152.0/pci108e,1000PCI-BRIDGE
I/O	PCI	8	B	0	33	33	0,0	ok	pci108e,1000-pci108e,1000.1device on pci-bridge
I/O	PCI	8	B	0	33	33	0,1	ok	SUNW,hme-pci108e,1001SUNW,cheerio/pci-bridg+
I/O	PCI	8	B	0	33	33	4,0	ok	SUNW,isptwo-pci1077,1020/sd (blo+QLGC,ISP1040B/pci-bridg+
I/O	PCI	9	B	4	33	33	4,0	ok	pci1214,334-pci1214,334.10
I/O	PCI	9	A	7	33	66	2,0	ok	SUNW,m64BSUNW,370-4362

```
No failures found in System
=====
```

```

===== Environmental Status =====
System Temperatures (Celsius):
-----
Device           Temperature      Status
-----
CPU0              63              OK
CPU2              70              OK
MB                29              OK
IOB               25              OK
DBP0              24              OK

=====

Front Status Panel:
-----
Keyswitch position: NORMAL

System LED Status:

                GEN FAULT                REMOVE
                [OFF]                    [OFF]

                DISK FAULT                POWER FAULT
                [OFF]                    [OFF]

                LEFT THERMAL FAULT        RIGHT THERMAL FAULT
                [OFF]                    [OFF]

                LEFT DOOR                 RIGHT DOOR
                [OFF]                    [OFF]

=====

Disk Status:

                Presence          Fault LED          Remove LED
DISK  0: [PRESENT]          [OFF]              [OFF]
DISK  1: [PRESENT]          [OFF]              [OFF]
DISK  2: [ EMPTY]
DISK  3: [PRESENT]          [OFF]              [OFF]
DISK  4: [PRESENT]          [OFF]              [OFF]
DISK  5: [ EMPTY]
DISK  6: [ EMPTY]
DISK  7: [ EMPTY]
DISK  8: [ EMPTY]
DISK  9: [ EMPTY]
DISK 10: [ EMPTY]
DISK 11: [ EMPTY]

=====

```

Troubleshooting

Fan Bank :

Bank	Speed (RPMS)	Status	Fan State
CPU0_PRIM_FAN	2158	[ENABLED]	OK
CPU1_PRIM_FAN	2307	[ENABLED]	OK
CPU0_SEC_FAN	0	[DISABLED]	OK
CPU1_SEC_FAN	0	[DISABLED]	OK
IO0_PRIM_FAN	4054	[ENABLED]	OK
IO1_PRIM_FAN	4000	[ENABLED]	OK
IO0_SEC_FAN	0	[DISABLED]	OK
IO1_SEC_FAN	0	[DISABLED]	OK
IO_BRIDGE_PRIM_FAN	3448	[ENABLED]	OK
IO_BRIDGE_SEC_FAN	0	[DISABLED]	OK

=====

Power Supplies:

Supply	Status	Fan Fail	Temp Fail	CS Fail	3.3V	5V	12V	48V
PS0	GOOD				6	4	2	2
PS1	GOOD				6	4	2	2
PS2	GOOD				6	4	2	2

===== HW Revisions =====

System PROM revisions:

OBP 4.13.0 2004/01/19 18:26

IO ASIC revisions:

Brd	Model	Port		
		ID	Status	Version
IB-1	unknown	8	ok	7
IB-1	unknown	9	ok	7

Using the `cfgadm` command

The `cfgadm` command displays diagnostic information about CPU/Memory boards, SCSI controllers, and PCI cards.

To display this diagnostic information, enter:

```
cfgadm
```

The following is an example of the results for the computer.

Ap_Id	Type	Receptacle	Occupant	Condition
SBa	cpu/mem	disconnected	configured	ok
SBb	none	empty	unconfigured	ok
SBc	none	empty	unconfigured	ok
SBd	none	empty	unconfigured	ok
c0	scsi-bus	connected	configured	unknown
c2	scsi-bus	connected	configured	unknown
pcisch0:hpc1_slot0	pci-pci/hp	connected	configured	ok
pcisch0:hpc1_slot1	bridge/hp	connected	configured	ok
pcisch0:hpc1_slot2	bridge/hp	connected	configured	ok
pcisch0:hpc1_slot3	unknown/hp	connected	configured	ok
pcisch2:hpc2_slot4	unknown/hp	connected	configured	ok
pcisch2:hpc2_slot5	unknown	empty	unconfigured	unknown
pcisch2:hpc2_slot6	unknown	empty	unconfigured	unknown
pcisch3:hpc0_slot7	vgs8514/hp	connected	configured	ok
pcisch3:hpc0_slot8	unknown	empty	unconfigured	unknown
usb0/1	usb-mouse	connected	configured	ok
usb0/2	usb-kbd	connected	configured	ok
usb0/3	unknown	empty	unconfigured	ok
usb0/4	unknown	empty	unconfigured	ok

- SBa through SBd show the status of the four CPU/memory boards. In this example there is one CPU/Memory board in Slot A.
- c0 shows the status of the internal SCSI controller.
- c2 shows the status of the SCSI controller on the SunSwift card.
- pcisch0 through pcisch3 show the status of the PCI slots. In this example, the following cards are installed:
 - Slot 0 - Dual FastEthernet and Dual SCSI card
 - Slot 1 - FastEthernet card
 - Slot 2 - FastEthernet card
 - Slot 3 - HSI/P card
 - Slot 4 - HSI/P card
 - Slot 7 - Graphics card

System messages

System messages can alert you to system problems, such as a device that is about to fail. By default, many of the messages are displayed on the system console and are stored in `/var/adm`.

You can display system messages with the `dmesg` command. Here are some factors to keep in mind:

- A list of the most recent messages is displayed.
- The `/var/adm` directory contains several message files. The most recent messages are in `/var/adm/messages` and in `/var/adm/messages.0`. The oldest are in `/var/adm/messages.3`.
- Periodically, a new file is created, and the `/var/adm/messages.3` file is deleted, `/var/adm/messages.2` is renamed `/var/adm/messages.3`, `/var/adm/messages.1` is renamed `/var/adm/messages.2`, and `/var/adm/messages.0` is renamed `/var/adm/messages.1`.

The message files may contain not only system messages, but also core dumps and other data, which can cause `/var/adm` to grow quite large. To keep the directory to a reasonable size and ensure that future core dumps can be saved, you should remove unneeded files periodically. You can automate the task by using `crontab`. See your Sun system documentation for information on `crontab`.

OpenBoot PROM firmware tests

The OpenBoot PROM (OBP) on-board firmware performs a routine set of firmware and hardware tests.

Note:

Different versions of Solaris have different versions of the OpenBoot commands. Not all commands are available with every version.

This section includes the following topics:

- [Using the OpenBoot PROM tests](#) on page 167
- [Test descriptions](#) on page 168
- [Probing disk drives](#) on page 169
- [Probing all media devices](#) on page 170

Using the OpenBoot PROM tests

To use the OpenBoot PROM tests:

1. From the root login, turn off CMS.
2. Enter:

```
/usr/sbin/shutdown -y -i0 -g0
```

The system shuts down.

3. At the `ok` prompt, enter the following commands:

```
setenv auto-boot? false
```

```
reset-all
```

The system resets and displays the `ok` prompt.

4. Enter any of the commands that are shown in [Test descriptions](#) on page 168.
5. When you finish testing, enter the following commands:

⚠ CAUTION:

If you fail to enter these commands, any reboots that you do in the future will stop at the boot prompt instead of proceeding through the normal boot-up process.

```
setenv auto-boot? true
```

```
boot
```

The system reboots.

Test descriptions

The following table lists some of the OpenBoot PROM On-Board firmware test commands. Note that for some commands, test results are displayed. For other commands, the `ok` prompt is displayed when the test is finished.

Command	Description
<code>probe-scsi</code>	Displays the recognized disk drives and backplanes.
<code>probe-scsi-all</code>	Displays the recognized disk drives, backplanes, tape drives, and DVD-ROM drives.
<code>show-devs</code>	Displays all the devices known to the system directly beneath a given device in the device hierarchy. When using <code>show-devs</code> by itself, the command shows the entire device tree.
<code>show-disks</code>	Displays all disk devices.
<code>test-all</code>	Runs a series of tests on the network and on hardware components. The test may take several minutes to complete. You can use Stop+A to stop the tests.
<code>test devalias</code>	Runs the self-test method of the specified device. Use the <code>devalias</code> command to display a list of device aliases that can be tested. You must enter the full path name of the device alias to run the test. For example, to test the DVD-ROM drive, enter: <code>test /pci@8,700000/scsi@1/disk@6,0:f</code>
<code>watch-clock</code>	Tests the clock function.
<code>watch-net</code> <code>watch-net-all</code>	Runs a loopback test, a transceiver test, and a packet transmission test.

Additional references - See *Sun OpenBoot 4.x Command Reference Manual* at the following Sun documentation Web site for more information:

<http://docs.sun.com>

Probing disk drives

This test checks all disk drives.

Symptom - The internal disk drives are reporting errors.

Solution - To check the status of the disk drives:

1. Enter:

```
/usr/sbin/shutdown -y -i0 -g0
```

This shuts down the system.

2. At the `ok` prompt, enter the following commands:

```
setenv auto-boot? false
```

```
reset-all
```

The system resets.

3. Enter:

```
probe-scsi
```

The program displays a message that is similar to the following:

LiD	HA	LUN	---	Port	WWN	---	-----Disk description	-----
0	0	0		21000004cf72f08f			SEAGATE ST373405FSUN3660438	
1	1	0		21000004cf721553			SEAGATE ST373405FSUN3660438	
2	2	0		21000004cf7213ea			SEAGATE ST373405FSUN3660438	
6	6	0		508002000016b5b1			SUNW SUNWGS INT FCBPL9224	
3	3	0		21000004cf72114b			SEAGATE ST373405FSUN3660438	
4	4	0		21000004cf7211ae			SEAGATE ST373405FSUN3660438	
5	5	0		21000004cf7214a3			SEAGATE ST373405FSUN3660438	

Note:

The actual response depends on the number of disk drives that are installed in the system. This example shows six disk drives and the disk drive backplane.

4. Fix any obvious errors, such as disconnected backplane cables or disk drives not completely inserted.

Troubleshooting

5. When you finish testing, enter the following commands:

 **CAUTION:**

If you fail to enter these commands, any reboots that you do in the future will stop at the boot prompt instead of proceeding through the normal boot-up process.

```
setenv auto-boot? true
```

```
boot -r
```

The system reboots.

Probing all media devices

This test checks all media devices.

Symptom - The tape, DVD-ROM, or external disk drives are reporting errors.

Solution - To check the status of the media devices:

1. Enter:

```
/usr/sbin/shutdown -y -i0 -g0
```

to shut down the system.

2. At the `ok` prompt, enter the following commands:

```
setenv auto-boot? false
```

```
reset-all
```

The system resets.

3. Enter:

```
probe-scsi-all
```

The program displays a message that is similar to the following:

```
/pci@8,600000/SUNW,qlc@2
LiD HA LUN --- Port WWN --- -----Disk description -----
 0  0  0  21000004cf72f08f SEAGATE ST373405FSUN3660438
 1  1  0  21000004cf721553 SEAGATE ST373405FSUN3660438
 2  2  0  21000004cf7213ea SEAGATE ST373405FSUN3660438
 6  6  0  508002000016b5b1 SUNW     SUNWGS INT FCBPL9224
 3  3  0  21000004cf72114b SEAGATE ST373405FSUN3660438
 4  4  0  21000004cf7211ae SEAGATE ST373405FSUN3660438
 5  5  0  21000004cf7214a3 SEAGATE ST373405FSUN3660438

/pci@8,700000/scsi@1
Target 5
  Unit 0  Removeable Tape      HP      C5683A    C005
Target 6
  Unit 0  Removeable Read Only device TOSHIBA DVD-ROM SD-M14011009
/pci@8,700000/pci@5/SUNW,1sptwo@4
```

Note:

The actual devices that are listed depends on the devices that are installed in the system. This example shows six disk drives, the disk backplane, the tape drive (target 5), and the DVD-ROM drive (target 6).

4. Fix any obvious errors, such as disconnected cables or external drives without power.
5. When you finish testing, enter the following commands:

⚠ CAUTION:

If you fail to enter these commands, any reboots that you do in the future will stop at the boot prompt instead of proceeding through the normal boot-up process.

```
setenv auto-boot? true
```

```
boot -r
```

The system reboots.

OpenBoot diagnostic tests

OpenBoot Diagnostics (OBDiag) is a menu-driven diagnostic tool that diagnoses system hardware.

OBDiag performs root-cause failure analysis on the referenced devices by testing internal registers, confirming subsystem integrity, and verifying device functionality.

To use the OpenBoot diagnostic tests:

1. From the root login, turn off CMS.

2. Enter:

```
/usr/sbin/shutdown -y -i0 -g0
```

The system shuts down and the `ok` prompt is displayed.

3. Enter:

```
obdiag
```

This loads the test program and the test menu is displayed.

4. Enter:

```
obtest <command number>
```

See the following table for a summary of OpenBoot Diagnostic test commands.

Command number	Command name	Description
1	SUNW,hme@0,1	<ul style="list-style-type: none"> ● Resets the Ethernet channel. ● Performs Ethernet channel engine internal loopback. ● Enables the LAN data to be routed back to the receive MII data outputs. ● Enables MII transmit data to be routed to the MII receive data path. ● Forces the twisted-pair transceiver into loopback mode.
2	SUNW,isptwo@4	Tests the external SCSI interfaces.
3	SUNW,m64B@13	Tests the video monitor port.
4	SUNW,qlc@2	Tests the registers of the on-board FC-AL controller and subsystem (Loop A).
5	bbc@1,0	Tests all writable registers in the boot bus controller and then verifies that at least one processor has boot bus access.
6	bbc@1,500000	

Command number	Command name	Description
7	controller@0,16	Tests the base backplane firmware and SSC-100 SES controllers.
8	controller@0,1a	
9	controller@0,1c	Tests the expansion backplane firmware and SSC-100 SES controllers. Use only on 12-disk systems.
10	controller@0,1e	
11	ebus@1	Tests the PCI configuration registers, DMA control registers, ebus mode registers, and DMA controller functions.
12	flashprom@0,0	Performs a checksum of the flash PROM containing the OpenBoot firmware.
13	gpio@1,300600	Tests the registers of the super I/O subsystem.
14	hot plug-controller@0,	<p>⚠ CAUTION:</p> <p>After the hot-plug test, the PCI cards in the slots are not usable until you reset the system.</p>
15	hot plug-controller@0,	
16	hot plug-controller@0,	
17	hot plug-controller@0,	
18	i2c@1,2e	Tests the devices monitored by the I ² C environmental monitoring bus (temperature sensors, fans, power supplies, system fault LEDs, thermal fault LEDs, and front panel key switch).
19	i2c@1,30	
20	i2c@1,50002e	
21	i2c@1,500030	
22	keyboard@1	Tests the USB keyboard.
23	network@1	Tests the on-board Gigabit Ethernet (GBE) logic, including internal and external loopback tests.
24	network@1,1	Tests the on-board Fast Ethernet logic, including internal and external loopback tests.
25	pmc@1,300700	Tests the registers of the power management controller.
26	rsc-control@1,3062f8	Tests RSC hardware, including RSC serial and Ethernet ports.
27	rtc@1,300700	Tests the registers of the real-time clock and then tests the interrupt rates.
28	scsi@1	Tests the on-board SCSI controller and SCSI bus subsystem for internal removable media devices. Checks associated registers and performs a DMA transfer.

Troubleshooting

Command number	Command name	Description
29	serial@1,400000	Tests all possible data rates supported by the ttya and ttyb serial lines and performs an internal and external loopback test on each line at each speed.
30	USB@1,3	Tests the writable registers of the USB open host controller.
N/A	exit	Exits from the OpenBoot diagnostics.

Additional references - See *Sun OpenBoot 4.x Command Reference Manual* at the following Sun documentation Web site for more information:

<http://docs.sun.com>

POST diagnostic messages

To use the Power On Self Test (POST) messages (during a reboot) to diagnose remote hardware problems:

1. At the `ok` prompt, enter:

```
boot
```

2. Scan the displayed messages on the screen. Watch for error messages.

You can identify problems more accurately if you are familiar with the system power-on initialization messages. These messages show you the types of functions the system performs at various stages of system start-up. These messages can also show the transfer of control from OpenBoot firmware to POST.

Memory failure

If POST detects an error, it displays an error message indicating the failing part. If POST detects an error that prevents the system from booting, POST halts execution and returns control to OpenBoot. The last message displayed by POST prior to the `ok` prompt indicates the part you need to replace.

The following is a sample error message for a failed test at DIMM J7900.

```
1>Data Bitwalk on Slave 3
1>          Test Bank 0
3>Bank 0 DIMM 0
3>ERROR: TEST = Bank 0 DIMM 0
3>H/W under test = CPU3 Bank 0 Dimm 0, J7900 side 1
3>MSG =
          *** Test Failed!! ***
3>END_ERROR

1>ERROR: TEST = Data Bitwalk on Slave 3
1>H/W under test = CPU3 Memory
1>MSG = ERROR:      miscompare on mem test!
          Address: 00000030.001b0038
          Expected: 00000000.00100000
          Observed: 00000000.00000000

1>END_ERROR

1>ERROR: TEST = Data Bitwalk on Slave 3
1>H/W under test = CPU3 Memory
1>MSG =
          *** Test Failed!! ***
1>END_ERROR
```

OpenBoot initialization commands

The following table describes OpenBoot initialization commands that are provided by the system. These commands are useful in some situations in which the system fails to boot.

Command	Description
Press Stop	Bypasses POST. This command does not depend on the security mode. Note: Some systems bypass POST as a default. In such cases, use the Stop+A key combination to start POST.
Press Stop+A	Stops POST. This command does not work during the first few seconds after the system is reset or when the key switch is in the Locked position.
After the yellow System Fault LED starts to flash at a steady, rapid rate, press the power button twice, waiting one second between each press.	Enters diagnostic mode (formerly Stop plus D) and reset the NVRAM to Sun factory defaults (formerly Stop plus N). This resets the NVRAM settings for only this boot session. The next time you reboot, the Avaya factory settings will be used.


Diagnosing LED patterns

Many hardware components of the computer have LEDs that can be used to diagnose problems. This section describes the following patterns:

- [Front panel LEDs](#) on page 177
- [PCI slot LEDs](#) on page 179
- [Power supply LEDs](#) on page 181
- [Disk drive LEDs](#) on page 182
- [Tape drive LEDs](#) on page 184

Front panel LEDs

The system status and control panel, shown in the following figure, includes several LED status indicators, a power button, and a security key switch.



Troubleshooting

Several LED status indicators provide general system status, alert you to system problems, and help you to determine the location of system faults:

- At the top of the status and control panel, three general status LEDs provide a snapshot of the system status.
- Below the power button and security key switch, a graphical display provides additional LED icons to indicate specific fault conditions and locations.

The general status LEDs work in conjunction with the specific fault LED icons. For example, a fault in the disk subsystem illuminates both the system fault LED at the top of the panel and the disk fault icon in the graphical display below it. Fault LEDs within the enclosure help pinpoint the location of the faulty device. Since all front panel status LEDs are powered by the system's 5-volt standby power source, fault LEDs remain lit for any fault condition that results in a system shutdown.


During system startup, the front panel LEDs are individually toggled on and off to verify that each one is working correctly. After that, the front panel LEDs operate as described in the following table.

Name	Icon	LED function
Power/OK		This green LED lights when the system is turned on.
System fault		This amber LED lights to indicate a serious system fault. When this LED is lit, one or more icons in the display panel may also light to indicate the specific nature and location of the fault.
OK-to-remove		This amber LED lights to indicate that an internal hot-pluggable component is ready for removal.
Disk fault		This amber LED lights to indicate a serious disk subsystem fault that is likely to bring down the system. When this LED is lit, one or more disk LEDs may also be lit at the front of the disk cage, indicating the source of the fault. See Disk drive LEDs on page 182.
Power fault		This amber LED lights to indicate a serious power subsystem fault that is likely to bring down the system. When this LED is lit, one or more power supply LEDs may also be lit on the system rear panel. See Power supply LEDs on page 181.
Thermal fault		This amber LED lights to indicate a serious thermal fault (fan fault or overtemperature condition) that is likely to bring down the system. There are two Thermal Fault LEDs in the display to indicate whether the fault is located on the left or right side of the system. In the event of a fan fault, a fault LED inside the system will indicate the faulty fan assembly.

Attention left side		This amber LED lights to indicate that an internal component on the left side of the system requires servicing.
Attention right side		This amber LED lights to indicate that an internal component on the right side of the system requires servicing.

PCI slot LEDs

The PCI slot LEDs are located on the vertical bracket on the right side of the PCI slots and are visible when the left door is open. There is a hot-plug button and three LEDs for each PCI slot, as shown below.



Troubleshooting

The PCI slot LEDs are defined as follows:


Name	Icon	LED function
Power on		Lights when the slot is receiving power.
Fault		Blinks while the card is being tested, when a hot-plug operation is in progress, or when the card is turned on but logically detached from the operating system. Stays lit if the card encounters a fault.
OK-to-remove		Lights when it is safe to remove the card. ▲ Important: If this LED stays lit after inserting a card, you must shut down the system, reinsert the card, and reboot the system. Consult the customer before you shut down the system.

The following table shows how to interpret the PCI slot LED patterns.

Icon			Interpretation
Power on	Fault	OK-to-remove	
			
Off	Off	Off	The slot power is off. A card can be safely inserted to start a hot-plug operation.
On	Blinking	Off	The installed card is being tested, configured, or unconfigured, or the card is turned on but logically detached from the operating system.
On	Off	Off	The slot power is on and the card is operating normally.
Off	On	On	The PCI card has encountered a fault. The card can be safely removed.
Off	Off	On	The card can be safely removed.

Power supply LEDs

There are three LEDs located on the rear panel of each power supply. See the following figure.



The following table describes the function of each LED.

Name	Icon	LED Function
Fault		Lights when the power supply encounters a fault.
AC-present status		Lights when AC power input is present and within acceptable operating limits.
DC status		Lights when all DC outputs are functional and within acceptable operating limits.

Disk drive LEDs

The disk fault LED on the system status and control panel indicates the general status of the disk subsystem. The disk fault LED lights when a fault is detected in the disk subsystem. LEDs inside the system indicate the fault status of individual disk drives.

There are three LEDs (Activity, Fault, OK-to-remove) for each disk drive. The disk drive LEDs are located on the front of the disk cage, as shown below.



The disk drive LEDs are defined as follows:

Name	Icon	LED function
Activity		Blinks slowly while the disk drive is being tested, configured, or unconfigured during a hot-plug operation. Blinks rapidly as the disk drive spins up or spins down. Stays lit when the disk drive is at speed and operating normally but experiencing no read or write activity. Blinks rapidly and irregularly in response to disk read or write activity.
Fault		Lights when the disk drive encounters a fault.
OK-to-remove		Lights when it is safe to remove the disk drive during a hot-plug operation. Blinks (under software control) to direct attention to a disk drive.

The following table shows how to interpret the disk drive LED patterns.

Icon			Interpretation
Activity	Fault	OK-to-remove	
			
Off	Off	Off	The slot power is off. A disk drive can be safely inserted as part of a hot-plug operation.
Rapid blinking	Off	Off	The disk drive is spinning up or down.
Slow blinking	Off	Off	The disk drive is being configured or unconfigured during a hot-plug operation.
On	Off	Off	The disk drive is up to speed and operating normally.
Irregular blinking	Off	Off	The disk drive is experiencing read or write activity. This is normal operation.
On	On	Off	The disk drive has encountered a fault.
Off	Off	On	The disk drive can be safely removed as part of a hot-plug operation.

Tape drive LEDs

This section describes the LED status patterns for the tape drive.

The tape drive LEDs show the following status:

- Tape LED (green) - The LED flashes to show activity (loading, unloading, reading, and writing). The LED is steady when a cartridge is loaded and the tape drive is ready to begin operation.
- Clean LED (amber) - The LED flashes to indicate that a cartridge is near the end of its life, or that the heads need cleaning.

The following table describes the LED combinations that occur during normal tape drive operation.

	Tape drive state					
	Activity (load or unload)	Activity (read or write)	Cartridge loaded	Media caution signal	Fault	Power is turned on (starts with two steady lights)
Tape LED (green)	Flashing	Flashing Fast	On	Any	Any	Flashing
Clean LED (amber)	Off	Off	Off	Flashing	On	Off

The tape drive monitors the number of correctable errors that occur during reading and writing. If the number of errors becomes excessive, the tape may be nearing the end of its useful life, or the tape heads may need cleaning. The media caution signal reports the following:

- If the media caution signal displays (flashing amber), clean the tape drive.
- If the signal remains after cleaning the heads, repeat the operation with a different tape. If this clears the signal, the first tape is nearing the end of its life. Copy the data onto a new tape and discard the old one.

The media caution signal is cleared when a new tape is loaded or when the drive is turned off and then turned on.

Sun Validation Test Suite (VTS)

The SunVTS supports diagnostics in the following areas:

- Connection test - Minimal access of device to verify its accessibility and availability.
- Functional test (default) - Detailed tests to thoroughly test the device or system when the system is offline (CMS must be turned off). A stress mode in the system or test option can be set only within the offline mode. The stress mode is an extension of offline.
- Functional test (from system monitor) - Safe tests that can be executed on the device or system when it is online (CMS can be on, but testing is safer when it is turned off).

There are two ways to run SunVTS. Avaya recommends that you use either local access through the Common Desktop Environment (CDE) interface, or remote access using an ASCII interface.

Prerequisites

CMS must be turned off.

Using SunVTS

To use SunVTS:

1. Enter:

```
BYPASS_FS_PROBE=1; export BYPASS_FS_PROBE
```

This bypasses the file system probe.

2. Do one of the following:

- Enter:

```
/opt/SUNWvts/bin/sunvts
```

This accesses the CDE interface.

- Enter:

```
/opt/SUNWvts/bin/sunvts -t
```

This accesses the TTY mode (ASCII interface).

Additional references - For more information about using SunVTS, see `/opt/SUNWvts/README` and `/opt/SUNWvts/bin/vtstty.help`.

Troubleshooting disk drives and DVD-ROM drives

This section describes the symptoms of disk drive and DVD-ROM drive failures and suggests solutions to correct the problem.

Symptom - The operating system reports a disk drive read, write, or parity error or reports a DVD-ROM drive read error or parity error.

Solution - Replace the drive that is indicated in the failure message. The operating system identifies the internal drives as shown in the following table.

Operating system address	Drive physical location and target
c1t<X>d0s0	Disk drive, target <X> (<X> represents the target number and slot number, 0 to 5)
c0t6d0s0	DVD-ROM drive, target 6

Symptom - The disk drive fails to respond to commands.

Solution - To test the disk drives:

1. Enter:

```
/usr/sbin/shutdown -y -i0 -g0
```

The system shuts down.

2. At the `ok` prompt, enter the following commands:

```
setenv auto-boot? false
```

```
reset-all
```

The system resets.

3. Enter:

```
probe-scsi
```

The program displays a message that is similar to the following:

LiD	HA	LUN	---	Port	WWN	---	-----Disk description	-----
0	0	0		21000004cf72f08f	SEAGATE		ST373405FSUN3660438	
1	1	0		21000004cf721553	SEAGATE		ST373405FSUN3660438	
2	2	0		21000004cf7213ea	SEAGATE		ST373405FSUN3660438	
6	6	0		508002000016b5b1	SUNW		SUNWGS INT FCBPL9224	
3	3	0		21000004cf72114b	SEAGATE		ST373405FSUN3660438	
4	4	0		21000004cf7211ae	SEAGATE		ST373405FSUN3660438	
5	5	0		21000004cf7214a3	SEAGATE		ST373405FSUN3660438	

4. Verify that all of the disk drives are recognized. This example indicates that the system controller has successfully probed the device and that the motherboard is operating correctly.

If the `probe-scsi` test fails to show all of the installed disk drives, you may have to replace the disk drive.

5. When you finish testing, enter the following commands:

 **CAUTION:**

If you fail to enter these commands, any reboots that you do in the future will stop at the boot prompt instead of proceeding through the normal boot-up process.

```
setenv auto-boot? true
```

```
boot -r
```

The system reboots.

Symptom - The DVD-ROM drive fails to respond to commands.

Solution - To test the DVD-ROM drive:

1. Enter:

```
/usr/sbin/shutdown -y -i0 -g0
```

The system shuts down.

2. At the `ok` prompt, enter the following commands:

```
setenv auto-boot? false
```

```
reset-all
```

The system resets.

Troubleshooting

3. Enter:

```
probe-scsi-all
```

The program displays a message that is similar to the following:

```
/pci@8,600000/SUNW,qlc@2
LiD HA LUN --- Port WWN --- -----Disk description -----
 0  0  0  21000004cf72f08f SEAGATE ST373405FSUN3660438
 1  1  0  21000004cf721553 SEAGATE ST373405FSUN3660438
 2  2  0  21000004cf7213ea SEAGATE ST373405FSUN3660438
 6  6  0  508002000016b5b1 SUNW     SUNWGS INT FCBPL9224
 3  3  0  21000004cf72114b SEAGATE ST373405FSUN3660438
 4  4  0  21000004cf7211ae SEAGATE ST373405FSUN3660438
 5  5  0  21000004cf7214a3 SEAGATE ST373405FSUN3660438

/pci@8,700000/scsi@1
Target 5
  Unit 0  Removeable Tape      HP      C5683A    C005
Target 6
  Unit 0  Removeable Read Only device TOSHIBA DVD-ROM SD-M14011009
/pci@8,700000/pci@5/SUNW,1sptwo@4
```

4. Verify that the DVD-ROM drive is recognized. This example shows the default SCSI devices, the tape drive (target 5), and the DVD-ROM drive (target 6).

If the test fails to show all of the installed SCSI drives, you may have to replace the drive.

5. When you finish testing, enter the following commands:

 **CAUTION:**

If you fail to enter these commands, any reboots that you do in the future will stop at the boot prompt instead of proceeding through the normal boot-up process.

```
setenv auto-boot? true
```

```
boot -r
```

The system reboots.

Troubleshooting tape drives

Use the following procedures to troubleshoot tape drives:

- [Checking tape status](#)
- [Reassigning device instance numbers for tape devices](#) on page 191

Checking tape status

For many procedures, you must identify what tape drive, by device path, you will use for the procedure. Tape drives are assigned to particular device paths, usually one of the following:

- `/dev/rmt/0`
- `/dev/rmt/0c`
- `/dev/rmt/1`
- `/dev/rmt/1c`

Note:

The letter `c` at the end of the device name indicates that the tape device can operate in compressed mode. Avaya recommends that you use compressed mode at all times.

Troubleshooting

To determine what device paths are available on your system:

1. Insert a tape into the tape drive.
2. Enter the following commands:

```
mt -f /dev/rmt/0 status
```

```
mt -f /dev/rmt/1 status
```

If the device path is correct, a message that is similar to the following is displayed:

```
HP DAT-72 tape drive:
sense key(0x0)= Unit Attention      residual= 0   retries= 0
file no= 0   block no= 0
```

If the device path is incorrect, a message that is similar to the following is displayed:

```
/dev/rmt/0c: No such file or directory
```

If there is no tape in the tape drive, a message that is similar to the following is displayed:

```
/dev/rmt/0c: No tape loaded or drive offline
```

If the tape drive is busy, a message that is similar to the following is displayed:

```
/dev/rmt/0c: Device busy
```

Reassigning device instance numbers for tape devices

As tape drives are added to and removed from a system, the device instance numbers can get out of sequence with the number of tape drives. For example, if a system has two tape drives, and one is removed, the system may accidentally try to use a tape drive that no longer exists.

To reassign device instance numbers for tape devices:

1. Log in to the system as root.
2. Make sure that the target addresses for any SCSI tape drives are set correctly.
Typically, the internal tape drive is SCSI address 5, and an external tape drive is SCSI address 4. If you change the SCSI address, you must turn the tape drive power off and back on.
3. Insert the Solaris CD-ROM into the DVD-ROM drive.
4. After about 15 seconds, enter the following commands:

```
boot cdrom -sw
fsck -y /dev/dsk/c1t0d0s0
mount /dev/dsk/c1t0d0s0 /a
devfsadm -vCc tape -r /a -p /a/etc/path_to_inst
```

This reassigns the device instance numbers for the tape devices.

5. Enter:

```
eject cdrom
```

6. Remove the Solaris CD-ROM.

Recovery procedures

This section provides solutions for the following problems:

- [Preserving data after a system failure](#) on page 192
- [Loss of power](#) on page 193
- [Probe command warnings](#) on page 195
- [Reseating HSI/P cards](#) on page 196
- [Resetting a device alias](#) on page 198
- [Remote console port problems](#) on page 200

Preserving data after a system failure

Enter the `sync` command at the `ok` prompt to force any information on its way to the hard disk to be written out immediately. This command is useful if the operating system fails or is interrupted before preserving all data.


The `sync` command returns control to the operating system and performs the data-saving operations. After the disk data is synchronized, the operating system begins to save a core image of itself. If you do not need this core dump, you can interrupt the operation by pressing **Stop+A**.

Loss of power

If the system loses power, it is recommended (but not required) that you empty the DVD-ROM and tape drives. The system boots from the hard disk drive by default.

Turning on the computer

1. Turn on any external SCSI devices, starting with the device that is farthest from the system and working toward the system.
2. Turn on the system monitor.
3. Turn the key switch to the On position. See the following figure.



4. Press and release the power button to the left of the key switch to turn on the system.

Note:

The POST diagnostics occurs each time that you turn on the system. The POST tests the basic system components. This may take several minutes.

If the system is operating properly, a banner screen is displayed up to 3 minutes after it is turned on.


```
|-----| Sun Fire 880, Keyboard Present
|       | Copyright 1998-2001 Sun Microsystems, Inc. All rights reserved.
|       | OpenBoot 4.4, XXX MB memory installed, Serial #XXXXXXXXX
|-----| Ethernet address X:X:XX:XX:XX:XX, Host ID: XXXXXXXXX
```

Turning off the computer

1. Log in to the system as root.
2. Enter:

```
/usr/sbin/shutdown -y -i0 -g0
```

This shuts down the system.
3. Press and release the front panel power button to turn off the system.
Wait for the front panel Power/OK LED to turn off.
4. Turn the key switch to the Forced Off position. See the following figure.



⚠ DANGER:

Be sure to turn the key switch to the Forced Off position before handling any internal components. Otherwise, it is possible for a user to restart the system remotely while you are working inside it. The Forced Off position is the only key switch position that prevents an RSC user from restarting the system.

5. Turn off the system monitor.
6. Turn off any external SCSI devices, starting with the device that is closest to the system and working toward the farthest device.

Probe command warnings

Symptom - When running any of the `probe` commands, the following message is displayed:

```
This command may hang the system if a Stop-A or halt command has
been executed. Please type reset-all to reset the system before
executing this command. Do you wish to continue [Y/N].
```

 **CAUTION:**

Do not continue. Answer `n`. Do not answer `y`.

Solution - To recover from this condition:

1. Enter: `n`

This stops the `probe` command.

2. Enter the following commands:

```
setenv auto-boot? false
reset-all
```

3. It is now safe to run any of the `probe` commands and perform any other boot PROM-level diagnostics.
4. After you finish probing the system devices, enter the following commands:

 **CAUTION:**

If you fail to enter these commands, any reboots that you do in the future will stop at the boot prompt instead of proceeding through the normal boot-up process.

```
setenv auto-boot? true
boot -r
```

The system reboots.

Reseating HSI/P cards

The HSI/P cards may appear to be faulty when they just need to be reseated in the PCI slot. Before you replace the card, try reseating the card.

To reseat an HSI/P card:

1. Log in to the system as root.

2. Enter:


```
/usr/sbin/shutdown -y -i0 -g0
```

This shuts down the system.

3. Press and release the front panel power button to turn off the system.

Wait for the front panel Power/OK LED to turn off.

4. Turn the key switch to the Forced Off position. See the following figure.



⚠ DANGER:

Be sure to turn the key switch to the Forced Off position before handling any internal components. Otherwise, it is possible for a user to restart the system remotely while you are working inside it. The Forced Off position is the only key switch position that prevents an RSC user from restarting the system.

5. Open the left door.

6. Attach one end of an ESD antistatic wrist strap to the system chassis sheet metal and attach the other end to your wrist. See [Using an ESD wrist strap](#) on page 56 for more information.

7. Disconnect the HSI/P quad cable connected to the card.

8. Carefully pull the card from the I/O board.

9. Reinsert the HSI/P card into the slot on the I/O board. Make sure that the card is fully seated.
10. Rotate the purple PCI retaining clip over the back of the card faceplate until it snaps into place.
11. Remove the ESD wrist strap.
12. Close the left door.
13. Reattach the HSI/P quad cable.
14. Turn on any external SCSI devices, starting with the device that is farthest from the system and working toward the system.
15. Turn on the system monitor.
16. Turn on the system. Do *not* put the keyswitch in the locked position.
17. When the system comes back up, log in as root.
18. Test the card to see if it is now working. If the card is still not working, see [Replacing an HSI/P card](#) on page 73.

Resetting a device alias

If a boot disk is replaced, or if the NVRAM chip is ever reset permanently to the Sun factory defaults, the boot disk and EEPROM values must be reset to the Avaya factory defaults. This can happen when any of the following occurs:

- The boot disk (primary or alternate) is defective and is replaced with a new disk
- The NVRAM chip has been replaced
- The `set-defaults` or `setenv use-nvramrc? false` command is run
- A PROM patch is applied

To reset the NVRAM to bootable options for the boot disks:

1. At the `ok` prompt, enter:

```
show-disks
```

The disk devices are displayed.

2. Select the letter for the proper boot device. For example:

```
/pci@8,600000/SUNW,qlc@2/fp@0,0/disk
```

This copies the boot device string into the editor clipboard.

3. Enter:

```
nvalias disk Ctrl+Y (that is, press and hold the Ctrl key and the y key)
```

4. Add `@0,0` at the end of the line as shown in the following example:

```
nvalias disk /pci@8,600000/SUNW,qlc@2/fp@0,0/disk@0,0
```

Adding the `@0,0` gives the command the target and slice of the primary boot device.

5. If needed, repeat the above procedure for the boot drive on a mirrored system using `bootdevice2` as your mirror boot device alias, as shown in the following example:

```
nvalias bootdevice2 /pci@8,600000/SUNW,qlc@2/fp@0,0/disk@3,0
```

Adding the `@3,0` gives the command the target and slice of the mirror boot device.

6. Enter:

```
devalias
```

The device aliases are displayed. Verify that `disk` and `bootdevice2` are set to the correct alias values.

7. Enter:

```
setenv boot-device disk bootdevice2
```

8. Enter:

```
reset-all
```

The system resets and boots up to the operating system.

9. After setting the disk device alias, check the EEPROM values as described in "Displaying and setting the EEPROM parameters" of the CMS software installation, maintenance, and troubleshooting document for your CMS release. Reset any values that do not match the values described in that section.

Remote console port problems

This section contains problems you may encounter with the remote console port.

Symptom - The remote console port will not initialize for dialing in or dialing out.

Solution - To correct this problem:

1. Enter:

```
sacadm -l
```

If the system status reports `NO_SAC`, the port is not working properly.

2. Enter:

```
/cms/install/bin/abcadm -i -b 9600 ttya
```

The following message should be displayed:

```
ttya set to incoming port 9600 baud
```

If this message is not displayed, continue with Step 3.

3. Enter:

```
/cms/install/bin/abcadm -r ttya
```

The following message is displayed:

```
ttya is currently set to be incoming
Are you sure you want to change it? [y,n,?]
```

4. Enter: `y`

The following message is displayed:

```
ttya administration removed
```

The port monitor turns off.

5. Enter:

```
ps -ef | grep sac
```

This finds any SAC processes that are running. If any processes are found, continue with Step 6. Otherwise, continue with Step 7.

6. Enter:

```
kill -9 <pid>
```

Use this command to kill any SAC processes still running. Process numbers are represented by <pid>.

7. Enter:

```
/usr/lib/saf/sac -t 300
```

This restarts SAC.

8. Enter:

```
sacadm -l
```

Confirm that SAC is running. The system should report the port status as `ENABLED`.

9. Enter:

```
/cms/install/bin/abcadm -i -b 9600 ttya
```

The following message should be displayed:

```
ttya set to incoming port 9600 baud
```

If this message is not displayed, escalate the problem using the normal channels.

Symptom - The system cannot dial out to report alarms using the Alarm Origination Manager (AOM).

Solution - To correct this problem:

1. Enter:

```
tail /etc/uucp/Devices
```

The system should display the following:

```
ACU cua/b - Any Hayes  
Direct cua/a - Any Direct  
Direct cua/b - Any Direct
```

2. Check the settings on the remote console modem. For the U.S. Robotics modem, make sure that DIP switches 1 and 8 are down (ON). If these switches are not set correctly, you may still be able to dial in, but it may not dial out.

3. Enter:

```
/opt/cc/install/aot/r1vXxx.x/bin/setup
```

This restarts AOM. The release number `Xxx.x` depends on your installation.

Troubleshooting

To send a test alarm:

1. Enter the following commands to set up the test environment:

```
. /opt/cc/aot/bin/aom_env
cd /opt/cc/aot/bin
aom start
export PRODUCT_TYPE=TEST
```

2. Enter:

```
./log_error -e 30001 -d "test alarm"
```

This sends a test alarm.

3. Enter:

```
./alarm_view -p TEST -a TEST_ALARM
```

This will display the test alarm.

4. Enter:

```
./alarm_resolve -p TEST -a TEST_ALARM
```

This resolves the test alarm.

5. Enter:

```
tail -f aom_log
```

The AOM log file is displayed.

6. If you change an AOM parameter, such as the product ID or the telephone number, you must turn AOM off and back on again to recognize the new parameters. These parameters are in `/opt/cc/aot/data/admin/sysSetup.cfg` file. Be sure to set the port to value 1 for ttya.

7. If the `/opt/cc/aom/data/log` file has the message "aom cms alarm is disabled", enter:

```
export PRODUCT_TYPE=TEST
```

This enables the alarm.

Glossary

Automatic Call Distribution (ACD)

A switch feature. ACD is software that channels high-volume incoming call traffic to agent groups (splits or skills).

Also an agent state where the extension is engaged in an ACD call (with the agent either talking to the caller or the call waiting on hold).

Boot

To load the system software into memory and start it running.

Boot disk

A disk that contains the Solaris operating system and customer data.

CMS

Call Management System (CMS). A software product used by business customers that have an Avaya telecommunications switch and receive a large volume of telephone calls that are processed through the Automatic Call Distribution (ACD) feature of the switch.

Data disk

A nonbootable disk. A data disk contains only customer data.

DIMM

Dual In-line Memory Module. A narrow printed circuit board that holds memory chips. It plugs into a DIMM socket on the motherboard or memory board.

FC-AL

Fiber channel arbitrated loop. This is the loop device that controls the disk drives.

High Speed Serial Interface/PCI (HSI/P)

The HSI/P controller card is a 4-port serial communications PCI card. Each of the four ports is used for a single physical X.25 link. It is an add-on package that is needed by CMS for multiple ACDs.

Non-volatile random access memory (NVRAM)

A random access memory (RAM) system that holds its contents when external power is lost.

PCI

Peripheral Component Interconnect

PCI Bus

The interface bus for the computer. Provides slots for additional I/O cards.

RSC	
RSC	Remote System Control
SCSI	See Small computer system interface (SCSI) .
SCSI Bus	An industry standard peripheral bus that is used to connect intelligent peripherals to a computer. It uses a daisy-chained cabling arrangement that originates at the Host Adapter to interconnect up to seven intelligent peripheral controllers on the bus. The Sun computer uses a fast SCSI-2 implementation.
SCSI ID	Each tap on the SCSI bus is required to have a unique identification or address, which is the SCSI ID. The ID is set by a switch located on each controller.
SCSI single-ended bus	A version of the SCSI bus designed to minimize cost and space. Cable lengths up to 6 meters are supported. It is not compatible with the differential version of the SCSI bus.
Small computer system interface (SCSI)	A hardware interface that allows the connection of peripheral devices (such as hard disks, tape drives, CD-ROM drives, and DVD-ROM drives) to a computer system.
Solaris	The operating system package on the Sun computer. Solaris is a version of the UNIX [®] System V Release 4. CMS requires Solaris to run on the Sun computers.
SSO	Services Support Organization. The Avaya organization that provides technical support for Avaya products.
TPE	Twisted-pair Ethernet

Index

A

accessing components inside the computer	55
ACD switch link setup	88
adding	
disk drives	101, 119
external tape drive for data migration	131
pair of data disks	119
second HSI/P card	90

B

back panel	26
boot disks	113

C

checking	
CPU configuration	137
current amount of memory	137
current memory	137
tape status	189
cleaning the tape drive	127
clearances for service access	21
closing a side door	57
computer layout	24, 51
Comsphere 3910 modem options	43
configuring	
I/O cards	61
new card	70
replacement card	70
connecting	
AC power cord	28
modem	32
monitor	31
remote console modem	32
RSC for remote access (optional)	33
switch link	34
USB keyboard	31
USB mouse	31
console	
redirecting in OpenBoot mode	155
redirecting with Solaris	152
CPU and memory configurations	136

D

data disks	114
diagnosing LED patterns	177
disk drive	
compatibility with CMS loads	99
configurations	100
device alias	198
LEDs	182
partition values	113
partitioning	115
resetting the device alias	198
troubleshooting	186
drivers	
XVR-100	75
DVD-ROM drive	122

E

electrical specifications	20
environmental specifications	21

F

front panel	25, 51
LEDs	177

H

hardware options	27
hardware-related problems	
DVD-ROM drive failure	
failure to respond to commands	186, 187
hard drive failure	
failure to respond to commands	186, 187
helplines	15
HSI/P card	88, 93
ACD switch links	88
installing	
first card	85
second card	90
software and patches	88

I

I/O cards	59, 62
identifying installed PCI cards	39
installation	17
checklist	17
installing	
CPU/Memory board	142
first HSI/P card	85
hot-plug PCI card	68
HSI/P card	85
HSI/P software and patches	88
I/O cards	62
pair of HSI/P cards	85
inventory of parts	22

K

keyboard commands	176
-----------------------------	-----

L

LED status patterns	177
local console	154
loss of power	193

M

maintenance	49
adding external SCSI tape drive	131
cleaning the tape drive	127
CPU/Memory boards	136
disk drives	99
DVD-ROM drive	122
hot-plug PCI cards	62
HSI/P cards	76, 80
I/O cards	59
PCI cards	59
replacing internal tape drive	128
tape drive	126
tape drives	126
memory failure	175
minimum configuration	24
modem options	
Comsphere 3910	43
Sportster 33.6	41

N

NVRAM	198
-----------------	-----

O

OpenBoot	
commands	176
diagnostic tests	172
initialization commands	176
PROM firmware tests	167
redirecting the console	155
opening a side door	55
option buttons	43
ordering tapes	126
organization	8

P

Paradyne Comsphere 3910 modem	43
partitioning disk drives	113, 115
parts list	23, 29, 30
PCI	
card configuration	61
slot LEDs	179
slot LEDs for hot-plug operation	63
peripheral connectivity	29
physical specifications	20
POST	35, 175
diagnostic messages	175
power supply	
LEDs	181
replacing	147
power supply LEDs	181
precautions	18, 19, 50, 60
preface	7
preparing	
environment	21
hot-plug card for removal	64
installation	18
preserve data after a system failure	192
preserving data after a system failure	192
probe command	169, 170
warnings	195
probing	
all media devices	170
disk drives	169
prtdiag command	162, 165

R

rack mounting	27
rear panel	52
reasons for reissue	7
reassigning device instance numbers for tape devices	191
recovery procedures	192

loss of power	193
NVRAM chip	198
preserving data after a system failure	192
redirecting	
console	152
from the local site	158
from the remote console.	157
in OpenBoot mode	155
using OpenBoot mode	155
using Solaris	152
local console to the remote console	152, 155
local console to the RSC	159
remote console back to the local console	154, 156
RSC to the local console	160
remote console	
port problems	200
redirecting the port	152
remote console port problems	200
removing	
CPU/Memory board	139
external tape drive for data migration	131
hot-plug PCI card	65
side door	55
replacing	
boot disks	108
both boot disks	108
data disks	101
disk drives	101
DVD-ROM drive	122
graphics card	71
HSI/P card	80
internal tape drive	128
memory	140
power supply.	147
RSC card	94
side door	57
single boot disk	101
required tools	19
reseating HSI/P cards	196
resetting a device alias.	198
restarting the system.	145

S

safety precautions	18
service access specifications	21
setting	
data rate.	45
dial_line strap group	46
handshake options	45
remote console modem options	41

setting up	
disk drives	112
power	28
replacement disk drives	112
switch link for each ACD.	88
shutting down the system.	138
software installation	
XVR-100	75
specifications	20
Sportster 33.6 faxmodem	41
Sportster 33.6 faxmodem options	41
Sun Validation Test Suite (VTS)	185
system fails to boot properly	192
system messages	166
system precautions.	19

T

tape drive	
adding external SCSI	131
cleaning	127
compatibility	126
LED status patterns	184
maintenance	126
replacing	128
test descriptions	168
tools.	19, 161
troubleshooting	151
disk drives	186
DVD-ROM	186
DVD-ROM drives	186
keyboard commands	176
LED status patterns	177
OpenBoot diagnostic tests.	172
OpenBoot PROM firmware tests	167
POST diagnostic messages	175
probe command	169, 170
prtdiag command	162, 165
Sun Validation Test Suite (VTS)	185
system messages.	166
tape drives	189
tools	161
turning off the computer	53, 194
turning on the computer	35, 53, 54, 193
verifying POST	35
turning the system over for provisioning	48

U

unpacking and inventorying the equipment.	22
using	
cftadm command	165

ESD wrist strap	58
OpenBoot PROM tests	167
prtdiag command	162
remote console	152
RSC	159

V

verifying POST.	35
-------------------------	----

X

XVR-100 driver installation	75
---------------------------------------	----