



## **Cisco AC/DC Power System User Guide**

Release 1.0

Last Updated: May 15, 2005

### **Corporate Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 526-4100

Text Part Number: 78-16641-02



THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The following information is for FCC compliance of Class A devices: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to correct the interference at their own expense.

The following information is for FCC compliance of Class B devices: The equipment described in this manual generates and may radiate radio-frequency energy. If it is not installed in accordance with Cisco's installation instructions, it may cause interference with radio and television reception. This equipment has been tested and found to comply with the limits for a Class B digital device in accordance with the specifications in part 15 of the FCC rules. These specifications are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

Modifying the equipment without Cisco's written authorization may result in the equipment no longer complying with FCC requirements for Class A or Class B digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

You can determine whether your equipment is causing interference by turning it off. If the interference stops, it was probably caused by the Cisco equipment or one of its peripheral devices. If the equipment causes interference to radio or television reception, try to correct the interference by using one or more of the following measures:

- Turn the television or radio antenna until the interference stops.
- Move the equipment to one side or the other of the television or radio.
- Move the equipment farther away from the television or radio.
- Plug the equipment into an outlet that is on a different circuit from the television or radio. (That is, make certain the equipment and the television or radio are on circuits controlled by different circuit breakers or fuses.)

Modifications to this product not authorized by Cisco Systems, Inc. could void the FCC approval and negate your authority to operate the product.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

CCSP, CCVP, the Cisco Square Bridge logo, Follow Me Browsing, and StackWise are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn, and iQuick Study are service marks of Cisco Systems, Inc.; and Access Registrar, Aironet, BPX, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, FormShare, GigaDrive, GigaStack, HomeLink, Internet Quotient, IOS, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, LightStream, Linksys, MeetingPlace, MGX, the Networkers logo, Networking Academy, Network Registrar, Packet, PIX, Post-Routing, Pre-Routing, ProConnect, RateMUX, ScriptShare, SlideCast, SMARTnet, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0601R)



## CONTENTS

### About this Guide xi

Document Objectives	xi
Audience	xi
Document Organization	xi
Document Conventions	xii
Where to Find Safety and Warning Information	xiii
Obtaining Documentation	xiii
Cisco.com	xiii
Ordering Documentation	xiii
Documentation Feedback	xiv
Obtaining Technical Assistance	xiv
Cisco Technical Support Website	xiv
Submitting a Service Request	xv
Definitions of Service Request Severity	xv
Obtaining Additional Publications and Information	xvi

---

### CHAPTER 1

### Introduction 1-1

1.1 System Description	1-1
1.1.1 System Shelf	1-2
1.1.2 Rectifier Modules	1-3
1.1.3 GMT Fuses	1-4
1.1.4 1 RU Distribution Shelf	1-4
1.1.5 System Configurations	1-5
1.1.6 General Specifications	1-6
1.2 Safety Recommendations	1-8
1.2.1 Installation Warning	1-9
1.2.2 Operating Temperature Warnings	1-9
1.2.3 Electrical Safety Warnings	1-10

---

### CHAPTER 2

### System Installation 2-1

2.1 Pre-Installation	2-1
2.1.1 Ground Symbol	2-1
2.1.2 Tools Required	2-1
2.1.3 Installation and Commissioning Checklist	2-2

2.1.4 Installation Materials	2-2
2.2 Install AC/DC Power System Components	2-3
2.2.1 Install the System Shelf	2-4
2.2.2 Install the 1 RU Distribution Shelf	2-6
2.2.2.1 Install the Communications Cabling (Optional)	2-7
2.2.2.2 Install the DC Power Cabling (Optional)	2-8
2.2.3 Install the Ground Cable	2-9
2.2.3.1 Install the Cabinet/Rack Ground	2-10
2.2.3.2 Install the System Shelf Ground	2-10
2.2.3.3 Install the 1 RU Distribution Shelf Ground	2-11
2.3 Install AC Power Cables	2-12
2.3.1 Install the Rectifiers	2-16
2.4 Install Circuit Breakers	2-18
2.4.1 Install the Alarm Cable	2-21
2.5 Install Load-and-Return Connections	2-24
2.5.1 Install GMT Fuse Connections	2-25
2.5.2 Install 1 RU Distribution Shelf Load Connections	2-26
2.6 System Upgrades	2-28
2.6.1 GMT Fuses	2-28
2.6.2 Small to Medium System Upgrade	2-28
2.6.3 Medium to Large System Upgrade	2-29
2.6.4 Small to Large System Upgrade	2-29

---

CHAPTER 3

**Component Replacement** 3-1

3.1 Safety	3-1
3.2 Component Replacement	3-1
3.2.1 Replace the 1 RU Distribution Shelf	3-1
3.2.2 Replace the Controller Tray	3-3
3.2.3 Replace Circuit Breakers	3-6
3.2.4 Replace a Rectifier	3-8
3.2.5 Replace GMT Fuses	3-10

---

CHAPTER 4

**System Operation** 4-1

4.1 System Commissioning	4-1
4.2 General Information	4-1
4.2.1 Alarm Interface Board and Connections	4-2
4.2.2 Basic Controller Functions	4-2
4.2.2.1 Start the Controller	4-2

4.2.2.2 Add Modules	4-2
4.2.2.3 Remove Modules	4-3

---

<b>CHAPTER 5</b>	<b>System Troubleshooting</b>	<b>5-1</b>
------------------	-------------------------------	------------

---

<b>CHAPTER 6</b>	<b>System Parts List</b>	<b>6-1</b>
------------------	--------------------------	------------

---

<b>APPENDIX A</b>	<b>Translated Safety Warnings</b>	<b>A-1</b>
-------------------	-----------------------------------	------------

Statement 12—Power Supply Disconnection Warning	A-1
Statement 43—Jewelry Removal Warning	A-3
Statement 1006—Chassis Warning for Rack-Mounting and Servicing	A-4
Statement 1017—Restricted Area	A-9
Statement 1024—Ground Conductor	A-11
Statement 1030—Equipment Installation	A-13
Statement 1033—SELV-IEC 60950 DC Power Supply	A-14
Statement 1047—Overheating Prevention	A-15
Statement 1074—Comply with Local and National Electrical Codes	A-17





## FIGURES

- Figure 1-1 Cisco AC/DC Power System (with Optional 1RU DC Distribution Shelf) **1-2**  
Figure 1-2 Component Locations (Front View) on the System Shelf with LCD Screen **1-2**  
Figure 1-3 Component Locations (Front View) on the System Shelf without an LCD Screen **1-3**  
Figure 1-4 CSCO-PWR-RECT Rectifier Module **1-4**  
Figure 1-5 GMT Fuse Panel **1-4**  
Figure 1-6 1 RU Distribution Shelf **1-5**  
Figure 1-7 Circuit Breaker **1-5**  
Figure 1-8 ESD Wrist Strap Connection Point **1-9**  
Figure 1-9 Two-Inch Clearance Around Front Ventilation Opening **1-10**  
Figure 2-1 Ground Symbol **2-1**  
Figure 2-2 Cisco AC/DC Power System Front View **2-4**  
Figure 2-3 ETSI Shelf Ear Mounts (system shelf and 1RU Distribution Shelf) **2-5**  
Figure 2-4 Installing the System Shelf **2-5**  
Figure 2-5 1 RU Distribution Cable Dressing **2-6**  
Figure 2-6 1 RU Distribution Shelf Installation **2-7**  
Figure 2-7 1 RU Distribution Shelf Alarm Cabling **2-8**  
Figure 2-8 Installing 1 RU DC Cabling **2-9**  
Figure 2-9 Removing the System Shelf Rear Cover **2-10**  
Figure 2-10 Installing the System Shelf Ground **2-11**  
Figure 2-11 Installing the 1 RU Distribution Shelf Ground **2-12**  
Figure 2-12 Installing the AC Cable Shelf **2-14**  
Figure 2-13 Routing AC Cables **2-15**  
Figure 2-14 Installing a Rectifier **2-17**  
Figure 2-15 Removing a Rectifier Blank Faceplate **2-18**  
Figure 2-16 Circuit Breaker On/Off Positions **2-19**  
Figure 2-17 Removing the 1 RU Distribution Shelf Faceplate **2-19**  
Figure 2-18 Installing a Circuit Breaker **2-20**  
Figure 2-19 Removing the Controller Faceplate **2-22**  
Figure 2-20 Installing an Alarm Cable **2-23**  
Figure 2-21 Alarm Board Connection Points **2-24**  
Figure 2-22 GMT Drawer **2-25**

## ■ Figures

Figure 2-23	Installing GMT Cabling	<b>2-26</b>
Figure 2-24	Installing Fuses	<b>2-26</b>
Figure 2-25	Installing Load Connections	<b>2-27</b>
Figure 3-1	Removing the 1 RU DC Cable	<b>3-2</b>
Figure 3-2	Removing the 1 RU Distribution Shelf	<b>3-3</b>
Figure 3-3	Removing the Controller Faceplate	<b>3-4</b>
Figure 3-4	Removing the Alarm Interface Board Cable on the Version 1 of the Controller Hardware	<b>3-5</b>
Figure 3-5	Removing the Alarm Interface Board Cable on the Version 2 of the Controller Hardware	<b>3-5</b>
Figure 3-6	Circuit Breaker On/Off Positions	<b>3-6</b>
Figure 3-7	Removing the 1 RU Distribution Shelf Faceplate	<b>3-7</b>
Figure 3-8	Removing a Circuit Breaker	<b>3-8</b>
Figure 3-9	Removing a Rectifier	<b>3-9</b>
Figure 3-10	Removing a GMT Fuse	<b>3-10</b>
Figure 4-1	System Control Unit	<b>4-1</b>
Figure 5-1	Module Locations	<b>5-3</b>



## T A B L E S

<a href="#">Table 1-1</a>	System Configurations	<b>1-6</b>
<a href="#">Table 1-2</a>	Cabling Specifications	<b>1-6</b>
<a href="#">Table 1-3</a>	Electrical Specifications	<b>1-6</b>
<a href="#">Table 1-4</a>	Protection Specifications	<b>1-7</b>
<a href="#">Table 1-5</a>	Status and Alarm Specifications	<b>1-7</b>
<a href="#">Table 1-6</a>	Mechanical Specifications	<b>1-7</b>
<a href="#">Table 1-7</a>	Environmental Specifications	<b>1-7</b>
<a href="#">Table 1-8</a>	Compliance Specifications	<b>1-8</b>
<a href="#">Table 2-1</a>	Supplied Materials for the System Shelf	<b>2-2</b>
<a href="#">Table 2-2</a>	Supplied Materials for the 1 RU Distribution Shelf	<b>2-3</b>
<a href="#">Table 2-3</a>	Non-Supplied Materials	<b>2-3</b>
<a href="#">Table 2-4</a>	Individual AC Feed Specifications	<b>2-16</b>
<a href="#">Table 2-5</a>	Circuit Breaker Positions	<b>2-20</b>
<a href="#">Table 2-6</a>	Alarm and Jumper Designations	<b>2-23</b>
<a href="#">Table 2-7</a>	Recommended Wire Sizes	<b>2-24</b>
<a href="#">Table 6-1</a>	Parts List	<b>6-1</b>





## About this Guide

---

This section explains objectives, intended audience, and organization of this publication and describes conventions that convey instructions and other information.

This section provides the following information:

- [Document Objectives](#)
- [Audience](#)
- [Document Organization](#)
- [Document Conventions](#)
- [Where to Find Safety and Warning Information](#)
- [Obtaining Documentation](#)
- [Documentation Feedback](#)
- [Obtaining Technical Assistance](#)
- [Obtaining Additional Publications and Information](#)

## Document Objectives

This user guide explains installation, operation, and troubleshooting for the Cisco AC/DC Power System.

## Audience

To use this publication, you should be familiar with Cisco or equivalent AC/DC power systems hardware and cabling, telecommunications hardware and cabling, electronic circuitry and wiring practices, and preferably have experience as a telecommunications technician.

## Document Organization

This *Cisco AC/DC Power System User Guide, R1.0* is organized into the following chapters:

- [Chapter 1, “Introduction,”](#) provides system and component descriptions, system configurations, system specifications, and safety considerations.

## ■ Document Conventions

- [Chapter 2, “System Installation,”](#) provides the unpacking procedure, safety considerations, installation process, system upgrade information, and initial system startup for the power system.
- [Chapter 3, “Component Replacement,”](#) provides maintenance procedures and component replacement procedures.
- [Chapter 4, “System Operation,”](#) provides procedures for using the XCS control system. This includes normal system control and monitoring.
- [Chapter 5, “System Troubleshooting,”](#) provides troubleshooting procedures.
- [Chapter 6, “System Parts List,”](#) provides a part numbers list for the Cisco AC/DC Power System.
- [Appendix A, “Translated Safety Warnings,”](#) provides translations of all the warnings used in this document.

# Document Conventions

This publication uses the following conventions:

<b>Convention</b>	<b>Application</b>
<b>boldface</b>	Commands and keywords in body text.
<i>italic</i>	Command input that is supplied by the user.
[ ]	Keywords or arguments that appear within square brackets are optional.
{ x   x   x }	A choice of keywords (represented by x) appears in braces separated by vertical bars. The user must select one.
Ctrl	The control key. For example, where Ctrl + D is written, hold down the Control key while pressing the D key.
screen font	Examples of information displayed on the screen.
<b>boldface screen font</b>	Examples of information that the user must enter.
< >	Command parameters that must be replaced by module-specific codes.



### Note

---

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the document.

---



### Caution

---

Means *reader be careful*. In this situation, the user might do something that could result in equipment damage or loss of data.

---



Warning

---

**IMPORTANT SAFETY INSTRUCTIONS**

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device. Statement 1071

---

**SAVE THESE INSTRUCTIONS**

---

## Where to Find Safety and Warning Information

For safety and warning information, refer to the *Cisco Optical Transport Products Safety and Compliance Information* document that accompanied the product. This publication describes the international agency compliance and safety information for the Cisco ONS 15xxx systems. It also includes translations of the safety warnings that appear in the ONS 15xxx system documentation.

## Obtaining Documentation

Cisco documentation and additional literature are available on Cisco.com. Cisco also provides several ways to obtain technical assistance and other technical resources. These sections explain how to obtain technical information from Cisco Systems.

### Cisco.com

You can access the most current Cisco documentation at this URL:

<http://www.cisco.com/univercd/home/home.htm>

You can access the Cisco website at this URL:

<http://www.cisco.com>

You can access international Cisco websites at this URL:

[http://www.cisco.com/public/countries\\_languages.shtml](http://www.cisco.com/public/countries_languages.shtml)

### Ordering Documentation

You can find instructions for ordering documentation at this URL:

[http://www.cisco.com/univercd/cc/td/doc/es\\_inpck/pdi.htm](http://www.cisco.com/univercd/cc/td/doc/es_inpck/pdi.htm)

**■ Documentation Feedback**

You can order Cisco documentation in these ways:

- Registered Cisco.com users (Cisco direct customers) can order Cisco product documentation from the Ordering tool:  
<http://www.cisco.com/en/US/partner/ordering/index.shtml>
- Nonregistered Cisco.com users can order documentation through a local account representative by calling Cisco Systems Corporate Headquarters (California, USA) at 408 526-7208 or, elsewhere in North America, by calling 1 800 553-NETS (6387).

## Documentation Feedback

You can send comments about technical documentation to [bug-doc@cisco.com](mailto:bug-doc@cisco.com).

You can submit comments by using the response card (if present) behind the front cover of your document or by writing to the following address:

Cisco Systems  
Attn: Customer Document Ordering  
170 West Tasman Drive  
San Jose, CA 95134-9883

We appreciate your comments.

## Obtaining Technical Assistance

For all customers, partners, resellers, and distributors who hold valid Cisco service contracts, Cisco Technical Support provides 24-hour-a-day, award-winning technical assistance. The Cisco Technical Support Website on Cisco.com features extensive online support resources. In addition, Cisco Technical Assistance Center (TAC) engineers provide telephone support. If you do not hold a valid Cisco service contract, contact your reseller.

## Cisco Technical Support Website

The Cisco Technical Support Website provides online documents and tools for troubleshooting and resolving technical issues with Cisco products and technologies. The website is available 24 hours a day, 365 days a year, at this URL:

<http://www.cisco.com/techsupport>

Access to all tools on the Cisco Technical Support Website requires a Cisco.com user ID and password. If you have a valid service contract but do not have a user ID or password, you can register at this URL:

<http://tools.cisco.com/RPF/register/register.do>



**Note** Use the Cisco Product Identification (CPI) tool to locate your product serial number before submitting a web or phone request for service. You can access the CPI tool from the Cisco Technical Support Website by clicking the **Tools & Resources** link under Documentation & Tools. Choose **Cisco Product Identification Tool** from the Alphabetical Index drop-down list, or click the **Cisco Product Identification Tool** link under Alerts & RMAs. The CPI tool offers three search options: by product ID

or model name; by tree view; or for certain products, by copying and pasting **show** command output. Search results show an illustration of your product with the serial number label location highlighted. Locate the serial number label on your product and record the information before placing a service call.

## Submitting a Service Request

Using the online TAC Service Request Tool is the fastest way to open S3 and S4 service requests. (S3 and S4 service requests are those in which your network is minimally impaired or for which you require product information.) After you describe your situation, the TAC Service Request Tool provides recommended solutions. If your issue is not resolved using the recommended resources, your service request is assigned to a Cisco TAC engineer. The TAC Service Request Tool is located at this URL:

<http://www.cisco.com/techsupport/servicerequest>

For S1 or S2 service requests or if you do not have Internet access, contact the Cisco TAC by telephone. (S1 or S2 service requests are those in which your production network is down or severely degraded.) Cisco TAC engineers are assigned immediately to S1 and S2 service requests to help keep your business operations running smoothly.

To open a service request by telephone, use one of the following numbers:

Asia-Pacific: +61 2 8446 7411 (Australia: 1 800 805 227)

EMEA: +32 2 704 55 55

USA: 1 800 553-2447

For a complete list of Cisco TAC contacts, go to this URL:

<http://www.cisco.com/techsupport/contacts>

## Definitions of Service Request Severity

To ensure that all service requests are reported in a standard format, Cisco has established severity definitions.

Severity 1 (S1)—Your network is “down,” or there is a critical impact to your business operations. You and Cisco will commit all necessary resources around the clock to resolve the situation.

Severity 2 (S2)—Operation of an existing network is severely degraded, or significant aspects of your business operation are negatively affected by inadequate performance of Cisco products. You and Cisco will commit full-time resources during normal business hours to resolve the situation.

Severity 3 (S3)—Operational performance of your network is impaired, but most business operations remain functional. You and Cisco will commit resources during normal business hours to restore service to satisfactory levels.

Severity 4 (S4)—You require information or assistance with Cisco product capabilities, installation, or configuration. There is little or no effect on your business operations.

# Obtaining Additional Publications and Information

Information about Cisco products, technologies, and network solutions is available from various online and printed sources.

- Cisco Marketplace provides a variety of Cisco books, reference guides, and logo merchandise. Visit Cisco Marketplace, the company store, at this URL:  
<http://www.cisco.com/go/marketplace/>
- The Cisco *Product Catalog* describes the networking products offered by Cisco Systems, as well as ordering and customer support services. Access the Cisco Product Catalog at this URL:  
<http://cisco.com/univercd/cc/td/doc/pcat/>
- *Cisco Press* publishes a wide range of general networking, training and certification titles. Both new and experienced users will benefit from these publications. For current Cisco Press titles and other information, go to Cisco Press at this URL:  
<http://www.ciscopress.com>
- *Packet* magazine is the Cisco Systems technical user magazine for maximizing Internet and networking investments. Each quarter, Packet delivers coverage of the latest industry trends, technology breakthroughs, and Cisco products and solutions, as well as network deployment and troubleshooting tips, configuration examples, customer case studies, certification and training information, and links to scores of in-depth online resources. You can access Packet magazine at this URL:  
<http://www.cisco.com/packet>
- *iQ Magazine* is the quarterly publication from Cisco Systems designed to help growing companies learn how they can use technology to increase revenue, streamline their business, and expand services. The publication identifies the challenges facing these companies and the technologies to help solve them, using real-world case studies and business strategies to help readers make sound technology investment decisions. You can access iQ Magazine at this URL:  
<http://www.cisco.com/go/iqmagazine>
- *Internet Protocol Journal* is a quarterly journal published by Cisco Systems for engineering professionals involved in designing, developing, and operating public and private internets and intranets. You can access the Internet Protocol Journal at this URL:  
<http://www.cisco.com/ij>
- World-class networking training is available from Cisco. You can view current offerings at this URL:  
<http://www.cisco.com/en/US/learning/index.html>



## CHAPTER

# 1

## Introduction

---

The Cisco AC/DC Power System is a rack-mounted, AC-to-DC power system that provides a scalable, compact solution for powering optical platforms at site locations with only AC power available. The system accepts AC inputs and converts them to nominal -48 VDC for DC-powered equipment. This compact system provides N+1 redundancy in rectifiers, automated alarm generation, and integrated DC power distribution through a GMT fuse panel and available four-position 1RU circuit breaker distribution shelf. This system provides nominal -48 VDC service to DC-powered network elements (NEs) through redundant feeds, complementing the resiliency of Cisco's line of Carrier Class optical products.

The Cisco AC/DC Power System is designed to be mounted in a variety of rack types including IEC, ANSI (19 inches), ANSI (23 inches), and ETSI configurations and requires only 177.8mm (7.0in.) of vertical space for medium and large systems and 133.4mm (5.25in.) for small systems. The system is based on the CSCO-PWR-RECT rectifier module and allows three different configurations based on load requirements that range from 13.3A to 96A. Additionally, power distribution is accomplished using a GMT fuse block and/or an optional 1 RU distribution shelf (depending on system size).

The Cisco AC/DC Power System offers these features:

- AC input (A) 100-120VAC
- AC input (B) 200-250VAC
- Nominal -48 VDC rectifier providing up to 1600W
- Front access design
- Temperature hardened -40°C to +55°C
- Available in 19in. (IEC and ANSI), ETSI (21in. inside [610mm]), or 23in. mounting arrangements
- Available external distribution shelf with up to 4 load circuit breakers
- 10 position GMT fuse panel
- Active high power factor correction
- 90% or greater efficiency
- Front panel LCD interface

## 1.1 System Description


This section provides descriptions of the system shelf, rectifier modules, GMT fuses, and the 1 RU distribution shelf.

### 1.1.1 System Shelf

## 1.1.1 System Shelf

The AC/DC power system shelf consists of four rectifier slots and system monitoring/control interfaces. The system controller provides rectifier monitoring, operational data collection, alarm generation, and intra-system communications regulation.

**Figure 1-1 Cisco AC/DC Power System (with Optional 1RU DC Distribution Shelf)**



There are two system shelves, one of which has an LCD display on the front of the shelf.

Figure 1-2 shows a front view of the version of the system shelf with the LCD screen. The optional 1 RU DC distribution shelf is also shown.

**Figure 1-2 Component Locations (Front View) on the System Shelf with LCD Screen**





Figure 1-3 shows a front view of the version of the system shelf that does not have an LCD screen. The optional 1 RU DC distribution shelf is also shown.

**Figure 1-3 Component Locations (Front View) on the System Shelf without an LCD Screen**



## 1.1.2 Rectifier Modules


AC-to-DC power conversion is accomplished using two, three, or four hot-swappable CSCO-PWR-RECT rectifiers, each with an output voltage of nominal -48 VDC. Figure 1-4 shows a CSCO-PWR-RECT rectifier module.



**Note** The output voltage range is set at the factory and is not user configurable.

### 1.1.3 GMT Fuses


**Figure 1-4 CSCO-PWR-RECT Rectifier Module**



## 1.1.3 GMT Fuses


The system shelf is equipped with a 10-position GMT fuse panel. The GMT fuse panel has a 50A maximum total capacity with a maximum fuse rating of up to 15A (for up to three positions). The fuses are alarmed and are reported through the system controller.

**Figure 1-5 GMT Fuse Panel**




## 1.1.4 1 RU Distribution Shelf

The optional 1RU Distribution Shelf is installed in systems that contain more than 2 rectifiers and acts as an additional protection point for system loads. The shelf has a rating of 96A and can be equipped with up to four circuit breakers (up to a maximum rating of 30A each). The breakers are alarmed through the system controller.

**Figure 1-6 1 RU Distribution Shelf**

The 1RU External Distribution Shelf can accommodate up to four Series-Trip circuit breaker positions. These breakers have “bullet type” connectors for quick connect and disconnect ([Figure 1-7](#)). Circuit breakers can be rated from 5A-30A.

**Figure 1-7 Circuit Breaker**

## 1.1.5 System Configurations

[Table 1-1](#) lists the configurations available for the Cisco AC/DC Power System.

### 1.1.6 General Specifications

**Table 1-1 System Configurations**

<b>Configuration</b>	<b>Rectifiers</b>	<b>Distribution</b>	<b>Output at 220V AC</b>	<b>Output at 110V AC</b>
Small Systems	2 CSCO-PWR-RECT Modules	10-position GMT Fuse Block	32A	13.3A
Medium Systems	3 CSCO-PWR-RECT Modules	10-position GMT Fuse Block 4- position 1RU DC Distribution Shelf	64A	26.6A
Large Systems	4 CSCO-PWR-RECT Modules	10-position GMT Fuse Block 4- position 1RU DC Distribution Shelf	96A	40A

## 1.1.6 General Specifications

Table 1-2 provides cabling specifications for the Cisco AC/DC Power System.

**Table 1-2 Cabling Specifications**

<b>From</b>	<b>To</b>	<b>Wire Gauge</b>	<b>Ampacity</b>
System Shelf	1U DC Distribution Shelf	4 x 6AWG (16mm <sup>2</sup> ) (intra-shelf cabling)	96A (max)
Circuit Breakers	Load	10 - 8AWG (6mm <sup>2</sup> - 10mm <sup>2</sup> )	30A (max)
GMT Fuse Block	Load	16 - 14AWG (1.5mm <sup>2</sup> - 2.5mm <sup>2</sup> )	15A (max)
AC Service Panel	System Shelf	3 conductor 14AWG (2.5mm <sup>2</sup> ) per AC input	9.1A x (4) inputs <37A Total

Table 1-3 provides electrical specifications for the Cisco AD/DC Power System.

**Table 1-3 Electrical Specifications**

<b>Electrical</b>	<b>Value</b>
Input Voltage	(A) 100-120VAC (B) 200-250VAC
Input Frequency	44-66 Hz.
Transient Response	+/- 4%, recovery time 2ms
Load Sharing	+/- 5% of nominal current

Table 1-4 provides protection specifications for the Cisco AC/DC Power System.

**Table 1-4 Protection Specifications**

<b>Protection</b>	<b>Description</b>
Overcurrent (output)	Short circuit and automatic current limiting
Oversupply	Selective shutdown of modules at excessive output voltages

Table 1-5 provides status and alarm specifications for the Cisco AC/DC Power System.

**Table 1-5 Status and Alarm Specifications**

<b>Status &amp; Alarms</b>	<b>Description</b>
Alarm Contacts	Four form-C alarm contacts (Low Voltage, Mains Error, Module Failure, Fuse/Circuit Breaker Failure), maximum 60 VDC, rated at 1A
Status (Rectifier)	Green LED indicates power is within acceptable range Yellow LED indicates current limit/thermal protection Red LED indicates oversupply shutdown or rectifier alarm

Table 1-6 provides mechanical specifications of the Cisco AC/DC Power System.

**Table 1-6 Mechanical Specifications**

<b>Mechanical</b>	<b>Description</b>
Shelf Dimensions WxHxD	17.4 x 5.25 x 10.8in. (442 x 132.9 x 274mm)
1RU Shelf WxHxD	17.1 x 1.69 x 9.175in. (434 x 43 x 233mm)
Mounting	ETSI, 19in. (IEC and ANSI) or 23in.

Table 1-7 provides environmental specifications for the Cisco AC/DC Power System.

**Table 1-7 Environmental Specifications**

<b>Environment</b>	<b>Description</b>
Shock/Vibration	(NEBS) Level 3, Class B Certification
Earthquake	Zone 4 Compliant
Audible Noise	<60 dBA
Ambient Temperature	-40°C to 55°C
Storage Temperature	-40°C to +85°C
Relative Humidity	10-90%, non-condensing

Table 1-8 provides compliance specifications for the Cisco AC/DC Power System.

**1.2 Safety Recommendations****Table 1-8 Compliance Specifications**

<b>Compliance</b>	<b>Description</b>
Radiated EMC	EN 61000-6-2, EN 61000-6-3, FCC Part 15 Class B
EMC	EN 61000-6-2, EN 61000-6-4
Safety	CSA C22-2 No. 60950-1, UL 60950-1 and IEC60950-1/EN60950-1
ESD Immunity	EN61000-4-2
RF Immunity	EN61000-4-3
Surge Immunity	IEC/EN61000-4-5
Fast Transient/Burst Immunity	IEC/EN61000-4-4
Immunity	EN61000-4-2
ETSI	300-386-TC

## 1.2 Safety Recommendations

Any device that uses electricity requires proper guidelines to ensure safety.


**Warning**

**Only trained and qualified personnel should be allowed to install, replace, or service this equipment.**  
Statement 1030

**Warning**

**This unit is intended for installation in restricted access areas. A restricted access area can be accessed only through the use of a special tool, lock and key, or other means of security.**  
Statement 1017

- The Cisco AC/DC Power System should only be installed or serviced by qualified personnel.
- An ESD wrist strap is included to protect sensitive electronics and should be connected to a metal surface to act as a ground. This ensures that all components have the same charge. An ESD wrist strap should be used when working with internal components that are installed in the shelf. The wrist strap connects at the rear of the system shelf as shown in [Figure 1-8](#). If rear access is not available, the ESD wrist strap can be connected to the shelf mounting ears or the controller faceplate thumbscrews.

**Figure 1-8 ESD Wrist Strap Connection Point**

- Keep the system area clear and dust-free during and after the installation.
- Always check for possible hazards before beginning work.
- This equipment is designed to permit the connection of a grounded conductor for the DC supply circuit at the equipment.

## 1.2.1 Installation Warning

The following safety guidelines should be observed when transporting or moving the system to the install location:

- Before moving the Cisco AC/DC Power System, read the system specifications sheet to determine if the site meets all the size, environmental, and power requirements.
- The Cisco AC/DC Power System should be properly mounted to the equipment rack.

The Cisco AC/DC Power System is designed for installation in restricted access locations. A restricted access location is defined as an equipment location where both of the following conditions apply:

- Access can only be gained by service persons or users who understand the restrictions applied to the location and any precautions that must be taken.
- Access to the system is obtained through the use of a tool or lock and key, or other means of security, and is controlled by the authority responsible for the location.

## 1.2.2 Operating Temperature Warnings



**To prevent the system from overheating, do not operate it in an area that exceeds the maximum recommended ambient temperature of: 55° Celsius.**


Statement 1047

## 1.2.3 Electrical Safety Warnings

**Warning**

**To prevent airflow restriction, allow clearance around the ventilation openings to be at least 2.0 inches (50.8 mm).**

**Figure 1-9 Two-Inch Clearance Around Front Ventilation Opening**



This power system is intended for use in a restricted location where the ambient temperature falls between -40° and +55° Celsius. It is not recommended to continually operate the power system in an area that exceeds the maximum recommended operating temperature. To prevent the Cisco AC/DC Power System from overheating, the rectifier automatically shuts down when a thermal alarm is tripped.

## 1.2.3 Electrical Safety Warnings

The following are electrical safety recommendations for working near the Cisco AC/DC Power System:

**Warning**

**Before working on equipment that is connected to power lines, remove jewelry (including rings, necklaces, and watches). Metal objects will heat up when connected to power and ground and can cause serious burns or weld the metal object to the terminals.** Statement 43

**Warning**

**This equipment must be grounded. Never defeat the ground conductor or operate the equipment in the absence of a suitably installed ground conductor. Contact the appropriate electrical inspection authority or an electrician if you are uncertain that suitable grounding is available.** Statement 1024

**Warning**

**Installation of the equipment must comply with local and national electrical codes.** Statement 1074

**Warning**

**Before working on a chassis or working near power supplies, unplug the power cord on AC units; disconnect the power at the circuit breaker on DC units.** Statement 12

**Warning**

**This product requires short-circuit (overcurrent) protection, to be provided as part of the building installation. Install only in accordance with national and local wiring regulations.** Statement 1045

**Warning**

**Installation of the equipment must comply with local and national electrical codes.** Statement 1074

- Before connecting the AC input source to the power system, always verify frequency and voltage.
- When making AC connections, all AC power and DC load distribution breakers should be in the OFF position.
- Ensure that the proper size circuit protection is being used.

**■ 1.2.3 Electrical Safety Warnings**



# System Installation

This provides step-by-step instructions for installing a Cisco AC/DC Power System. If you are installing a new system, begin with the “[2.1 Pre-Installation](#)” section on page [2-1](#). If you are upgrading an existing system, go to the “[2.6 System Upgrades](#)” section on page [2-28](#) for instructions.

## 2.1 Pre-Installation

The following information should be reviewed before attempting to install the Cisco AC/DC Power System. This section includes shelf markings, tools, equipment, and an installation checklist. Refer to the “[1.2 Safety Recommendations](#)” section on page [1-8](#) before beginning installation.




**Note** Each system installation is unique, so please review specific site requirements and system configurations before installing the system.

### 2.1.1 Ground Symbol

[Figure 2-1](#) shows the ground symbol located on the Cisco AC/DC Power System.

**Figure 2-1**

**Ground Symbol**



124774

### 2.1.2 Tools Required

The following tools and parts are required for safe installation of the Cisco AC/DC Power System:

- Digital multimeter

**2.1.3 Installation and Commissioning Checklist**

- Insulated Phillips and flathead screwdriver sets
- Insulated wire & cable strippers/crimpers (for ground lug, DC cable, alarm, and GMT cable installations)
- 8mm socket or wrench for ground cable installation

**2.1.3 Installation and Commissioning Checklist**

- AC/DC system shelf mounted securely in rack
- 1 RU Distribution Shelf mounted securely in rack directly above the system shelf (if applicable)
- AC and DC cabling meets local and national electrical code specifications
- Installation in ETSI racks allows for front-to-back ventilation and the use of a ventilated door and cabinet top
- System alarm cabling is installed and secure
- Power cables are secure and installed correctly
- Rectifiers are installed and seated correctly in the system shelf
- The controller and 1 RU Distribution faceplates are installed and secure (if applicable)
- System shelf rear cover is installed and secured
- System powers up and all red LEDs are extinguished after a few minutes

**2.1.4 Installation Materials**

[Table 2-1](#) and [Table 2-2](#) list the Cisco supplied installation materials that ship with the Cisco AC/DC Power System. [Table 2-3](#) lists materials that will need to be furnished at the install location.

**Table 2-1 Supplied Materials for the System Shelf**

Description	Qty	Use
M6 0x20mm screw (thread forming)	6	Shelf mounting screws (ETSI racks/cabinets)
12-24 x1/2" screw (thread forming)	6	Shelf mounting screws (ANSI, IEC racks/cabinets)
M6 cage nut	6	Shelf mounting nut (ETSI racks/cabinets)
Mounting bracket 600mm ETSI rack	2	Ear mounts (ETSI racks/cabinets)
2A GMT fuse	2	GMT fuse panel
5A GMT fuse	2	GMT fuse panel
10A GMT fuse	2	GMT fuse panel
15A GMT fuse	2	GMT fuse panel
Standard AC plug	4	AC plugs that meet local requirements
Cable ties	12	Securing cables
ESD wrist strap	1	ESD protection

**Table 2-1 Supplied Materials for the System Shelf (continued)**

Description	Qty	Use
Quick Installation Guide	1	Installation instructions
System documentation	1	Installation, provisioning, and troubleshooting

**Table 2-2 Supplied Materials for the 1 RU Distribution Shelf**

Description	Qty	Use
M6 0x20mm screw (thread forming)	4	Shelf mounting screws (ETSI racks/cabinets)
12-24 x 1/2" screw (thread forming)	4	Shelf mounting screws (ANSI, IEC racks/cabinets)
M6 cage nut	4	Shelf mounting nut (ETSI racks/cabinets)
Mounting bracket 600mm ETSI rack	2	Ear mounts (ETSI racks/cabinets)
Quick disconnect circuit breakers	2	1RU Distribution Shelf
Cable ties	4	Securing cables
ESD wrist strap	1	ESD protection
Quick Installation Guide	1	Installation instructions

**Table 2-3 Non-Supplied Materials**


Description	Qty	Use
6AWG (16mm <sup>2</sup> ) grounding cable	1	system shelf grounding
6AWG (16mm <sup>2</sup> ) grounding cable	1	1RU Distribution grounding (if applicable)
10 to 8 AWG (6 to 10mm <sup>2</sup> ) cables	<8	DC load breaker connections (-48V and return)
22 AWG (0.34mm <sup>2</sup> ) cables	n/a	2A GMT fuse cabling
18 AWG (0.75mm <sup>2</sup> ) cables	n/a	5A GMT fuse cabling
14 AWG (2.5mm <sup>2</sup> ) cables	n/a	10/15A GMT fuse cabling
26 to 22AWG (0.14mm <sup>2</sup> - 0.34mm <sup>2</sup> ) cables	4	Alarm cabling
UL Listed double-hole lug 1/4in and 5/8in. center-to-center (lug part # Panduit LCD6 -14A-L or equivalent)	2	Ground cable installation

## 2.2 Install AC/DC Power System Components

The following sections contain instructions for installing components. [Figure 2-2](#) shows a drawing of the Cisco AC/DC Power System without rectifiers.

## 2.2.1 Install the System Shelf

**Figure 2-2 Cisco AC/DC Power System Front View**



## 2.2.1 Install the System Shelf




**To prevent bodily injury when mounting or servicing this unit in a rack, you must take special precautions to ensure that the system remains stable. The following guidelines are provided to ensure your safety:**

- This unit should be mounted at the bottom of the rack if it is the only unit in the rack.
- When mounting this unit in a partially filled rack, load the rack from the bottom to the top with the heaviest component at the bottom of the rack.
- If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the unit in the rack. Statement 1006

The system shelf should be installed first, followed by the 1 RU Distribution Shelf (if this option is included as part of the installation).


### Step 1

Determine if the correct ear mounts are installed on the system shelf. Ear mounts are shipped mounted on the shelf and support 19in. and 23in. IEC and ANSI standards (for 23in. shelves, ears should be removed, reversed and reinstalled). Two additional plates are also included to accommodate ETSI racks (Figure 2-3). To install ETSI mounting ears, remove existing ears and attach ETSI mounting ears using included hardware.

**Figure 2-3 ETSI Shelf Ear Mounts (system shelf and 1RU Distribution Shelf)**

124770

- Step 2** Move the system shelf to the desired rack/cabinet slot (allowing 1RU above the shelf if a 1 RU Distribution shelf will be installed).
- Step 3** Secure the system shelf to the rack using the six included mounting screws (Figure 2-4).


**Figure 2-4 Installing the System Shelf**

124779

- Step 4** Continue with the “[2.2.2 Install the 1 RU Distribution Shelf](#)” procedure on page [2-6](#) if applicable. If this system has no external distribution, place the 4 power connectors and alarm cables on the top of the system shelf to aid in future 1 RU Distribution Shelf installation ([Figure 2-5](#)) and continue with the “[2.2.3 Install the Ground Cable](#)” section on page [2-9](#).

## 2.2.2 Install the 1 RU Distribution Shelf

**Figure 2-5 1 RU Distribution Cable Dressing**



## 2.2.2 Install the 1 RU Distribution Shelf


Systems equipped with an optional 1 RU Distribution Shelf require power connections from the system shelf to the 1 RU Distribution Shelf using four cables terminated with Anderson power pole connectors. These cable connectors are pre-wired to the system shelf and should be connected to the 1 RU Distribution Shelf during installation.



**Note** In pre-installed system shelves, the DC cabling should be located at the top of the system shelf. Cable labels are provided (-48V and Return) for ease of installation.

In addition, the distribution alarm connection is made via a pre-wired 10 pin Molex™ connector from the system shelf and should be connected to the 1 RU Distribution Shelf at the indicated connection point.

- Step 1** Determine if the correct ear mounts are installed on the system shelf. Ear mounts are shipped mounted on the shelf and support 19in. and 23in. IEC and ANSI standards (for 23in. shelves, ears should be removed, reversed, and reinstalled). Two additional plates are also included to accommodate ETSI racks ([Figure 2-3 on page 2-5](#)). To install ETSI mounting ears, remove existing ears and attach ETSI mounting ears using included hardware.
- Step 2** Make sure that all circuit breakers are in the OFF position (see [Figure 2-16 on page 2-19](#)).
- Step 3** Move the 1 RU Distribution Shelf to the desired rack slot (directly above the system shelf).
- Step 4** Secure the 1 RU Distribution Shelf to the rack using the four included mounting screws ([Figure 2-6](#)). See for more information.

**Figure 2-6** 1 RU Distribution Shelf Installation

### 2.2.2.1 Install the Communications Cabling (Optional)

If the power system is equipped with the 1 RU Distribution Shelf, follow the instructions below. For power systems without the 1 RU Distribution Shelf, skip this procedure and go to the “[2.2.3 Install the Ground Cable](#)” procedure on page 2-9.

Intra-system shelf communication is accomplished using a 10 pin Molex™ connector originating from the system shelf and connecting to the 1 RU Distribution Shelf. Use the following instructions to install the communications cabling:

**Step 1** Locate the distribution alarm cable at the rear of the system shelf.


**Step 2** This cable is a prewired 10 pin Molex™ connector and is installed into the 1RU at the indicated location ([Figure 2-7](#)).



**Note** The Molex™ alarm connector is keyed and can only be inserted one way. If the connector does not insert easily into the mount, make certain that the connector is being inserted with the key side up.

## 2.2.2 Install the 1 RU Distribution Shelf

**Figure 2-7 1 RU Distribution Shelf Alarm Cabling**




### 2.2.2.2 Install the DC Power Cabling (Optional)

If the system is equipped with the 1 RU Distribution Shelf, follow the instructions below. For systems without the 1 RU Distribution Shelf, skip this procedure and go to the “[2.2.3 Install the Ground Cable](#)” procedure on page 2-9.

- 
- Step 1** Locate the four 6AWG (16mm<sup>2</sup>) power cables provided at the rear of the system shelf (on top of the system shelf in preinstalled systems). These are terminated with Anderson Powerpole™ Connectors (to install these connectors, remove the heat shrink from the ends of the connector).
- Step 2** Connect to the appropriate connection points on the 1RU Distribution Shelf labeled load (-48V) and return (RETURN) ([Figure 2-8](#)).



- Note** Anderson Powerpole™ Connectors are keyed and can only be inserted one way. If the connector does not insert easily into the mount, make certain that the connector is being inserted with the key side up.
-

**Figure 2-8** *Installing 1 RU DC Cabling*

## 2.2.3 Install the Ground Cable



**Warning** This equipment must be grounded. Never defeat the ground conductor or operate the equipment in the absence of a suitably installed ground conductor. Contact the appropriate electrical inspection authority or an electrician if you are uncertain that suitable grounding is available. Statement 1024

The equipment rack/cabinet, system, and optional distribution shelf need to be properly grounded to ensure the safe and efficient operation of the Cisco AC/DC Power System. Refer to NEC, CEC, ANSI T1-333, ETSI 300-386-TC, and local codes for guidelines on bonding telecom DC power equipment to building ground.

The system shelf should be connected to the rack/cabinet frame by a UL-listed 6 AWG (16mm<sup>2</sup>) wire with an insulation rating of at least 75° Celsius. Two #10 studs are provided at the rear of the shelf. The connection at the shelf end is made using a UL-listed double-hole lug 1/4in and 5/8in. center-to-center (lug part # Panduit LCD6-14A-L or equivalent).

The optional 1 RU Distribution Shelf should be bonded to the frame by a UL-listed 6 AWG (16mm<sup>2</sup>) wire with an insulation rating of at least 75° Celsius. Two #10 studs are provided at the rear of the shelf for this purpose. The connection at the shelf end is made using a UL-listed double-hole lug 1/4in. and 5/8in. center-to-center (lug part # Panduit LCD6-14A-L or equivalent).

■ 2.2.3 Install the Ground Cable


### 2.2.3.1 Install the Cabinet/Rack Ground

The equipment rack should be bonded to the building principal ground busbar. Refer to the NEC, CEC, ANSI T1-333, ETSI 300-386-TC, and local codes for guidelines on bonding telecom DC power equipment to the building ground.


### 2.2.3.2 Install the System Shelf Ground

- Step 1** Loosen the cover from the rear of the system shelf by loosening the four screws ([Figure 2-9](#)).

**Figure 2-9** *Removing the System Shelf Rear Cover*



- Step 2** Pull out from the bottom and lift up to remove.
- Step 3** Locate the #10 studs at the rear of the system shelf ([Figure 2-10](#)).
- Step 4** Using a UL-listed 6 AWG (16mm<sup>2</sup>) wire with an insulation rated to at least 75°C, connect the shelf to the appropriate cabinet connection point. The connection at the shelf end is made using a UL-listed double-hole lug 1/4in and 5/8in. center-to-center (lug part # Panduit LCD6-14A-L or equivalent) ([Figure 2-10](#)).

**Figure 2-10** *Installing the System Shelf Ground*


- Step 5** Determine if the system is equipped with the optional 1 RU Distribution Shelf; if so, continue with the “[2.2.3.3 Install the 1 RU Distribution Shelf Ground](#)” section on page [2-11](#). If not continue with the “[2.3 Install AC Power Cables](#)” section on page [2-12](#).

### 2.2.3.3 Install the 1 RU Distribution Shelf Ground

- Step 1** Locate the #10 studs at the rear of the 1 RU Distribution Shelf.
- Step 2** Using a UL-listed 6 AWG (16mm<sup>2</sup>) wire with an insulation rating of at least 75° C, connect the 1 RU Distribution Shelf to the appropriate cabinet connection point.
- Step 3** The connection at the shelf end is made using a UL-listed double-hole lug 1/4in and 5/8in. center-to-center (lug part # Panduit LCD6-14A-L or equivalent) ([Figure 2-11](#)).
- Step 4** To accommodate future upgrades, leave a service loop (1.5ft [60cm]) at the side of the shelf.

### 2.3 Install AC Power Cables

**Figure 2-11** *Installing the 1 RU Distribution Shelf Ground*



## 2.3 Install AC Power Cables

Each rectifier in the system shelf is individually powered through a 110/230 V AC single phase 15A circuit and draws a maximum of 9.1A.

Each rectifier position in the shelf can be powered by either:

- 208/220/240V AC split phase
- 230V single phase
- 110V single phase
- Max current per position (9.1A)



**Note** Rectifier output capacity at 110 VAC is reduced to less than half of the maximum output.

- Locate the power shut-off switch for the installation area
- Install the system using the following electrical codes:
  - United States National Electrical Code (NEC)
  - Canadian Electrical Code (CEC)

- International Electromechanical Commission (IEC)
- Any local or site specific codes
- EN60950

**Warning**

**Installation of the equipment must comply with local and national electrical codes.** Statement 1074

- Never install damaged or malfunctioning equipment.


To install AC power to the Cisco AC/DC Power System:

- 
- Step 1** Ensure that input circuit breakers or fuses are off or removed and the cable is not connected to the outlet.
- Step 2** To aid in future expansion, all AC cable positions should be connected to the rear of the shelf during installation.
- Step 3** The system shelf is supplied with four AC cables. Each AC cable provides power to individual rectifier positions. The cable is terminated to allow for local plug requirements.




**Note** A 15A circuit (for both 110 and 208V AC) should be used based on maximum AC input per rectifier (9.1A).

- 
- Step 4** The rear system shelf cover should already be removed, if not, remove it.
- Step 5** Locate the cables at the rear of the system shelf.
- Step 6** Attach the ferrule end of the cables (Ground (G), L1, and L2 (neutral) to the system shelf AC receptacle by inserting (the ferrule will only fit in one direction) and tightening with a flat screwdriver ([Figure 2-12](#)).

**2.3 Install AC Power Cables****Figure 2-12** *Installing the AC Cable Shelf*

**Step 7** After attaching the AC cables, route the cables at the rear of the shelf using the supplied tie-offs to secure the cables and exit at the sides of the shelf ([Figure 2-13](#)).

**Figure 2-13 Routing AC Cables**

124793

**Step 8** AC cabling is routed through either side of the system shelf and secured using tie off points.

**Step 9** AC cabling should be tied off inside the cabinet/rack.

**Step 10** Repeat for all AC cables.

**Step 11** Connect the terminated AC plug to the AC receptacle at the install location.

**Note**

A separate AC receptacle is required for each AC cable, and each receptacle should be on its own circuit breaker to maximize protection against AC circuit breaker failure.

### 2.3.1 Install the Rectifiers


**Table 2-4 Individual AC Feed Specifications**

Shelf Size	Rectifier Positions	AC Input (Fuse or Breaker) 110/208 VAC Single Phase	Minimum AC Wire Gauge UL Style SOOW
19 inch	1	15A	14 AWG (2.5mm <sup>2</sup> ) 3 conductor
19 inch	2	15A	14 AWG (2.5mm <sup>2</sup> ) 3 conductor
19 inch	3	15A	14 AWG (2.5mm <sup>2</sup> ) 3 conductor
19 inch	4	15A	14 AWG (2.5mm <sup>2</sup> ) 3 conductor

## 2.3.1 Install the Rectifiers


To install the rectifiers in the Cisco AC/DC Power System:

- 
- Step 1** Locate the first (left-most when viewed from the front) rectifier install location.
  - Step 2** Make sure that the rectifier handle is in the OPEN position (handle pulled away from the rectifier body).
  - Step 3** Place the module in front of the correct mounting slot on the shelf with the handle facing out ([Figure 2-14 #1](#)).
  - Step 4** Slide the module until it contacts the interface connection at the rear of the shelf.
  - Step 5** Fully insert the rectifier by pushing the module handle towards the shelf; the handle will rise up and lock the module into place ([Figure 2-14 #2](#)).

**Figure 2-14** *Installing a Rectifier*

- Step 6** Tighten the handle-mounted common screws into the rectifier to ensure a firm connection ([Figure 2-14 #2](#)).
- Step 7** Repeat this procedure for any additional modules (two total for small systems, three for medium systems, and four for large systems. Some systems may require removing blank rectifier faceplates. To do this, remove the two Phillips screws from the blank rectifier faceplate ([Figure 2-15 #1](#)). Remove the blank rectifier faceplate mounting bracket by removing the two Phillips screws ([Figure 2-15 #2](#)).

## 2.4 Install Circuit Breakers

**Figure 2-15** Removing a Rectifier Blank Faceplate

**Step 8** Install additional rectifiers using the instructions in Steps 2 through 5.

For more information on installing rectifiers in a powered system, see the “[4.2.2.2 Add Modules](#)” section on page [4-2](#).


## 2.4 Install Circuit Breakers




**Note** This procedure is optional for large systems.

Large systems equipped with the 1 RU Distribution Shelf require the installation of circuit breakers to ensure proper system protection (the 1 RU Distribution Shelf is shipped with circuit breakers installed for use in medium systems). To install circuit breakers in a large system:

**Step 1** Make certain all breakers to be installed are in the OFF position ([Figure 2-16](#)).

**Figure 2-16** Circuit Breaker On/Off Positions

- Step 2** Remove the 1 RU Distribution Shelf faceplate by loosening the two thumbscrews on the shelf faceplate ([Figure 2-17](#)).

**Figure 2-17** Removing the 1 RU Distribution Shelf Faceplate

- Step 3** Locate the circuit breaker installation locations inside the 1 RU Distribution Shelf (positions A1, A2, B1, and B2) (see [Table 2-5 on page 2-20](#)). Circuit breakers should be installed with the protective hood (covering the ON position) on the left side of the shelf ([Figure 2-16](#)) to allow the 1 RU Distribution Shelf faceplate to be correctly installed.
- Step 4** Attach the circuit breaker alarm cables to the rear of the circuit breaker; the alarm cables are labeled C (Common) and NC (Normally Closed) and are attached to the positions shown in [Figure 2-16](#).


**2.4 Install Circuit Breakers****Table 2-5 Circuit Breaker Positions**

System Size	A1	A2	B1	B2
Small	n/a	n/a	n/a	n/a
Medium	X	<sup>1</sup>	X	<sup>2</sup>
Large	X	X	X	X

1. Future Upgrade

2. Future Upgrade

- Step 5** Gently glide the breaker so that the quick disconnect plugs are aligned with the mounting holes (Figure 2-18).

**Figure 2-18 Installing a Circuit Breaker**

124756

- Step 6** Push the breaker until the quick disconnect plugs are firmly seated in the mounting holes.

- Step 7** Repeat for additional breaker.

**Step 8** Replace the 1 RU Distribution Shelf faceplate and tighten the thumbscrews.

## 2.4.1 Install the Alarm Cable

The following explains how to install alarm communication cabling to the Cisco AC/DC Power System Controller.



**Warning**

**Connect the unit only to DC power source that complies with the safety extra-low voltage (SELV) requirements in IEC 60950 based safety standards.** Statement 1033




**Note**

Alarm cables run from the rear right of the shelf through the power shelf ([Figure 2-20](#)) to the front alarm interface board connectors; remove the controller faceplate and slide the controller tray forward to access the alarm interface board.


To install alarm cabling to the Cisco AC/DC Power System:

**Step 1**

Remove the system shelf faceplate (by loosening the two front thumbscrews) to access the controller sliding drawer ([Figure 2-19](#)).

**2.4.1 Install the Alarm Cable****Figure 2-19 Removing the Controller Faceplate**

- Step 2** Slide the drawer out and away from the system shelf to access the alarm interface board.
- Step 3** The terminal block may be removed to make alarm cable connections ([Figure 2-20](#)).

**Figure 2-20** *Installing an Alarm Cable*

**Step 4** Alarm contacts labeled 1 through 4, NO, C, and NC refer to the OFF state of the power system and alarmed condition ([Table 2-6](#)).

**Table 2-6** *Alarm and Jumper Designations*

Jumper (System with LCD)	Jumper (System without LCD)	Alarm Designation	1	2	3	4
J16 (1-3)	J16 (1-3)	Low Voltage	X			
J15 (1-3)	J15 (1-3)	Mains Error		X		
J14 (1-3)	J14 (1-3)	Module Failure			X	
J14 (4-6)	J13 (1-3)	Fuse/Circuit Breaker Failure				X




**Note** Either NO or NC can be used for alarming. [Figure 2-20](#) depicts the NC connection in the 1 and 3 positions on the connectors.

**Step 5** The terminal blocks (green) will accept 26AWG (0.14mm<sup>2</sup>) to 22AWG (0.34mm<sup>2</sup>) cables. Remove the terminal block ([Figure 2-20 #1](#)).

**Step 6** Insert the stripped alarm cables and tighten using a flat screwdriver ([Figure 2-20 #2](#)). Refer to [Figure 2-21](#) (Version 2 of the controller) and [Figure 3-4 on page 3-5](#) (Version 1 of the controller) for information on alarm connection locations.

## 2.5 Install Load-and-Return Connections

**Figure 2-21 Alarm Board Connection Points**



124764

- Step 7** Reinsert the terminal block ([Figure 2-20 #3](#)).
- Step 8** Alarm cables run from the rear of the system shelf (leaving enough of a service loop to allow the drawer to slide out) through the access window (between the controller drawer and the GMT drawer area) ([Figure 2-20](#)).
- Step 9** Secure the alarm cables using the provided strain relief tie-offs to aid in cable management.

## 2.5 Install Load-and-Return Connections

The following section contains information on installing different distribution options available for the power system. [Table 2-7](#) provides a list of recommended wire gauges for both the GMT fuse panel and the 1 RU Distribution Shelf.

**Table 2-7 Recommended Wire Sizes**

Wire Gauge Stranded	Applications
10 to 8 AWG (6mm <sup>2</sup> to 10mm <sup>2</sup> )	Breaker Load (up to 30A)
22 AWG (0.34mm <sup>2</sup> )	2A GMT Fuses
18 AWG (0.75mm <sup>2</sup> )	5A GMT Fuses


**Table 2-7 Recommended Wire Sizes (continued)**

Wire Gauge Stranded	Applications
14 AWG (2.5mm <sup>2</sup> )	10A GMT Fuses
14 AWG (2.5mm <sup>2</sup> )	15A GMT Fuses

## 2.5.1 Install GMT Fuse Connections

Load connections to the GMT fuse panel are made using spring loaded terminals that do not require the use of connection lugs.


- Step 1** Locate the GMT fuse connections by removing the controller faceplate (Figure 2-19) and sliding the GMT drawer out (Figure 2-22).

**Figure 2-22 GMT Drawer**

- Step 2** Route the GMT load-and-return cabling from the rear of the system shelf (leaving enough of a service loop to allow the drawer to slide out) through the fuse panel channel and secure using the supplied tie-downs.
- Step 3** Connect the wires to the appropriate terminal by using a flat screwdriver to open the terminal (Figure 2-23) and inserting the appropriate cable into the spring-loaded terminals. Terminals correspond to fuses: Side A (1-5) and Side B (1-5) from left to right (viewed from the front of the system).


## 2.5.2 Install 1 RU Distribution Shelf Load Connections

**Figure 2-23** *Installing GMT Cabling*



- Step 4** Connect cables to equipment that requires the supplied DC Power per that equipment's specifications.
- Step 5** Install fuses by sliding them into the appropriate slot (Figure 2-24).

**Figure 2-24** *Installing Fuses*




An empty space should be left on each side of any 15A GMT fuse used for thermal considerations.

## 2.5.2 Install 1 RU Distribution Shelf Load Connections

The following section is for systems that use the 1 RU Distribution Shelf. For systems without the 1 RU Distribution Shelf, go to [Chapter 4, “System Operation.”](#)

- Step 1** Select the wire gauge for the application. See [Table 2-7 on page 2-24](#) for wiring information.
- Step 2** Locate the load-and-return connections at the rear of the 1 RU Distribution Shelf ([Figure 2-25](#)).
- Step 3** Remove the Phoenix Contact PC6™ connectors from the 1 RU Distribution Shelf by loosening the flat screws and pulling the connectors away from the 1 RU Distribution Shelf ([Figure 2-25 #1](#)).

**Figure 2-25** *Installing Load Connections*



- Step 4** Connect the wires to the appropriate terminal for the load-and-return connections by inserting and then tightening the connector (Phoenix Contact PC6™ connectors) ([Figure 2-25 #2, #3](#)). Allow enough of a service loop to allow for the removal of the 1 RU Distribution Shelf.
- Step 5** Reinstall the Phoenix Contact PC6™ connector to the 1 RU Distribution Shelf ([Figure 2-25 #3](#)).
- Step 6** Reconnect to the 1RU Distribution Shelf ([Figure 2-25 #4](#)).
- Step 7** Connect the load-and-return cables to the equipment that requires the supplied DC Power per that equipment's specifications.

**Step 8** Repeat for additional DC cabling.

---

## 2.6 System Upgrades

If the installation is an upgrade of a pre-existing system, the following sections give a list of the procedures needed to upgrade the system:

- [2.6.1 GMT Fuses, page 2-28](#)
- [2.6.2 Small to Medium System Upgrade, page 2-28](#)
- [2.6.3 Medium to Large System Upgrade, page 2-29](#)
- [2.6.4 Small to Large System Upgrade, page 2-29](#)

Review the following sections before attempting a system upgrade:

- [2.1.1 Ground Symbol, page 2-1](#)
- [2.1.2 Tools Required, page 2-1](#)
- [2.1.4 Installation Materials, page 2-2](#)



**Note** Some upgrade connections may require access to the rear of the system. If rear access is not available, all rear connections are required to have a service loop that allows the 1 RU Distribution Shelf to be pulled out (after unscrewing the cabinet/mounting screws) to allow for access. For information on removing the 1 RU Distribution Shelf see [3.2.1 Replace the 1 RU Distribution Shelf, page 3-1](#).

---

### 2.6.1 GMT Fuses

To add fuses to the GMT fuse block, see the “[2.5.1 Install GMT Fuse Connections](#)” procedure on [page 2-25](#).

### 2.6.2 Small to Medium System Upgrade

To upgrade a small system (2 rectifiers, no 1 RU Distribution Shelf) to a medium system (3 rectifiers, 1 RU Distribution Shelf with 2 circuit breakers), use the following sections:

- [2.2.2 Install the 1 RU Distribution Shelf, page 2-6](#)
- [2.2.2.1 Install the Communications Cabling \(Optional\), page 2-7](#)
- [2.2.2.2 Install the DC Power Cabling \(Optional\), page 2-8](#)
- [2.2.3.3 Install the 1 RU Distribution Shelf Ground, page 2-11](#)
- [2.3.1 Install the Rectifiers, page 2-16](#)
- [2.5.2 Install 1 RU Distribution Shelf Load Connections, page 2-26](#)

## 2.6.3 Medium to Large System Upgrade

To upgrade a medium system (3 rectifiers, 1 RU Distribution Shelf with 2 circuit breakers) to a large system (4 rectifiers, 1 RU Distribution Shelf with 4 circuit breakers), use the following sections:

- [2.3.1 Install the Rectifiers, page 2-16](#)
- [2.4 Install Circuit Breakers, page 2-18](#)
- [2.5.2 Install 1 RU Distribution Shelf Load Connections, page 2-26](#)

## 2.6.4 Small to Large System Upgrade

To upgrade a small system (2 rectifiers, no 1 RU Distribution Shelf) to a large system (4 rectifiers, 1 RU Distribution Shelf with 4 circuit breakers), use the following sections:

- All of the steps for upgrading from the “[2.6.2 Small to Medium System Upgrade](#)” section on [page 2-28](#)
- All of the steps for upgrading from the “[2.6.3 Medium to Large System Upgrade](#)” section on [page 2-29](#)

**2.6.4 Small to Large System Upgrade**



# Component Replacement

This chapter contains information about replacing Cisco AC/DC Power System components in the field. Consult this chapter in the event of a system malfunction.

## 3.1 Safety

The following warning should be followed to ensure personal safety and to protect the Cisco AC/DC Power System:



**Only trained and qualified personnel should be allowed to install, replace, or service this equipment.**  
Statement 1030

The following guideline should be followed to ensure personal safety and to protect the Cisco AC/DC Power System:

Keep the system area clear and dust-free during and after the installation.

See the “[1.2 Safety Recommendations](#)” section on page [1-8](#) for more warnings.


## 3.2 Component Replacement

The following section contains information about replacing components in the Cisco AC/DC Power System.

### 3.2.1 Replace the 1 RU Distribution Shelf

- 
- Step 1** Locate the 1 RU Distribution Shelf installation location.
  - Step 2** Ensure that all the circuit breakers are in the OFF position.
  - Step 3** Ensure that equipment being powered by the Cisco AC/DC Power System is OFF and not drawing DC power.
  - Step 4** Locate the load-and-return connections at the rear of the 1 RU Distribution Shelf. Remove the Phoenix Contact PC6™ connectors from the 1 RU Distribution Shelf by loosening the flat screws and pulling the connectors away from the 1 RU Distribution Shelf ([Figure 3-1 #2](#)).

## 3.2.1 Replace the 1 RU Distribution Shelf

**Figure 3-1** Removing the 1 RU DC Cable


124781

- Step 5** Locate the distribution alarm cable at the rear of the 1RU DC Distribution Shelf.
- Step 6** Remove the 10 pin Molex™ alarm cable by squeezing the top and pulling the cable away from the shelf ([Figure 3-1 #1](#)).
- Step 7** Locate the four 6AWG (16mm<sup>2</sup>) power cables provided at the rear of the 1RU Distribution Shelf.
- Step 8** Remove the power cables by pulling them out and away from the 1RU Distribution Shelf ([Figure 3-1 #3](#)).

**Note**

Cover the connectors to insulate the live current on the lugs.

- Step 9** Locate the ground cable attached to the #10 studs at the rear of the 1RU Distribution Shelf.
- Step 10** Using an 8mm socket or wrench remove the nuts and the ground cable ([Figure 3-1 #4](#)).
- Step 11** Remove the four screws that mount the shelf to the cabinet/rack ([Figure 3-2](#)).

**Figure 3-2** Removing the 1 RU Distribution Shelf


**Step 12** Slide the 1RU Distribution Shelf away from the cabinet/rack.

**Step 13** To reinstall a replacement 1RU Distribution Shelf, complete the “[2.2.2 Install the 1 RU Distribution Shelf](#)” procedure on page 2-6.

## 3.2.2 Replace the Controller Tray

**Step 1** Locate the controller faceplate on the system shelf.


**Step 2** Remove the controller faceplate by loosening the two front thumbscrews to access the sliding controller tray (Figure 3-3).

**3.2.2 Replace the Controller Tray****Figure 3-3** *Removing the Controller Faceplate*


- Step 3** Slide the controller tray out and away from the system shelf to access the Alarm Interface Board ([Figure 3-3 #2](#)).
- Step 4** Remove the Alarm Interface Board DC terminal block ([Figure 3-4](#) or [Figure 3-5 #1](#), depending on your controller hardware).
- Step 5** Remove the alarm cable connections ([Figure 3-4](#) or [Figure 3-5 #2](#)). If alarm cables are not labeled with the jumper number, label the cables with the appropriate jumper number: J16, J15, J14 (1,2,3), and J14 (4,5,6)/J13 (for the system without an LCD).
  - –J16 terminal block

- –J15 terminal block
- –J14/J13 terminal blocks

**Figure 3-4** Removing the Alarm Interface Board Cable on the Version 1 of the Controller Hardware



**Figure 3-5** Removing the Alarm Interface Board Cable on the Version 2 of the Controller Hardware



**Step 6** Remove the intra-shelf communications cabling:

- J9 terminal block (Figure 3-4 or Figure 3-5 #3)
- J8 terminal block (Figure 3-4 or Figure 3-5 #4)
- J1 Ethernet cable (Figure 3-4 or Figure 3-5 #5)
- J1 terminal block (Figure 3-4 or Figure 3-5 #6)

**Step 7** Remove the controller tray ground connection by removing the Phillips screw (Figure 3-4 or Figure 3-5 #7).

**Step 8** Remove the wire tie holding the controller tray in the system shelf (Figure 3-4 or Figure 3-5 #8).

**Step 9** Pull the controller tray out of the system shelf.

**Step 10** Install the replacement controller tray by placing it in the system shelf.

**Step 11** Reinstall the controller tray ground connection by connecting the Phillips screw (Figure 3-4 or Figure 3-5 #7).

**Step 12** Use a new wire tie to replace the one that was removed in Step 8.

**Step 13** Reconnect the intra-shelf communications cabling (cables are labeled with the appropriate jumper number):

- J9 terminal block (Figure 3-4 or Figure 3-5 #3)

**3.2.3 Replace Circuit Breakers**

- J8 terminal block ([Figure 3-4](#) or [Figure 3-5 #4](#))
- J1 Ethernet cable ([Figure 3-4](#) or [Figure 3-5 #5](#))
- J1 terminal block ([Figure 3-4](#) or [Figure 3-5 #6](#))

**Step 14** Reconnect the alarm cable connections ([Figure 3-4](#) or [Figure 3-5 #2](#)).

- –J16 terminal block
- –J15 terminal block
- –J14/J13 terminal blocks

**Step 15** Slide the controller tray back into the system shelf.

**Step 16** Replace the controller faceplate by attaching it to the system shelf with the two front thumbscrews.


**Step 17** After installing the controller, the controller and rectifier LEDs will blink. It may take a few minutes for the controller to communicate with all rectifiers. At this point, all rectifier output voltages will return to the programmed level. During this synchronization period output will not be affected.

---

## 3.2.3 Replace Circuit Breakers


**Step 1** Make certain all breakers to be replaced are in the OFF position ([Figure 3-6](#)).

**Figure 3-6** *Circuit Breaker On/Off Positions*




**Step 2** Remove the 1RU Distribution Shelf faceplate by loosening the two thumbscrews on the shelf faceplate ([Figure 3-7](#)).

**Figure 3-7** Removing the 1 RU Distribution Shelf Faceplate



**Step 3** Locate the breaker that is to be removed.

**Step 4** Grasp the breaker firmly at the front and pull out until the quick disconnects disengage from their mounts.

**3.2.4 Replace a Rectifier****Figure 3-8** *Removing a Circuit Breaker*


124757

- Step 5** Remove the alarm cable connections from the rear of the breaker (Figure 3-8).
- Step 6** Pull the breaker straight out from the 1RU Distribution Shelf.
- Step 7** To reinstall a replacement 1RU Distribution Shelf see the “[2.2.2 Install the 1 RU Distribution Shelf](#)” procedure on page [2-6](#).

**3.2.4 Replace a Rectifier**

**Note** For more information on uninstalling a rectifier, see the “[4.2.2.3 Remove Modules](#)” section on page [4-3](#).

- Step 1** Locate the rectifier that is to be removed.
- Step 2** Loosen the mounting screws to allow the rectifier handle to open (Figure 3-9 #1).
- Step 3** Grasp the top of the handle and pull down until the handle locks into the open position (Figure 3-9 #2).

**Figure 3-9** Removing a Rectifier

**Step 4** Grasp the handle and gently pull the module out and away from the shelf.



**Caution** The rectifier module may be hot when being pulled from the shelf. To avoid personal injury, wait until the rectifier has cooled before removing from the system shelf.

**Step 5** Continue to pull the rectifier until it is halfway out of the shelf. Grasp the bottom of the rectifier with one hand and continue using the other hand to pull the rectifier out.


**Step 6** Pull the rectifier out of the shelf. The system will generate a communication error, which will last until a new rectifier is inserted.

**Step 7** For information on installing a rectifier module, see the “2.3.1 Install the Rectifiers” procedure on page 2-16.

**3.2.5 Replace GMT Fuses**

- 
- Step 1** Locate the GMT fuse that is to be removed.
  - Step 2** Grasp the fuse firmly at the front and pull out ([Figure 3-10](#)).

**Figure 3-10** *Removing a GMT Fuse*



- Step 3** For information on installing GMT fuses, see the “[2.5.1 Install GMT Fuse Connections](#)” procedure on [page 2-25](#).



- Caution** When replacing GMT fuses, always use the same size fuse unless the GMT fuse output cabling is upgraded as well. For more information on the appropriate cable/fuse sizes, see [Table 1-2 on page 1-6](#).
-



## System Operation

### 4.1 System Commissioning

The following section should be used to power-up the system for the first time.


- 
- Step 1** Turn on AC breakers at the AC distribution panel to power up the shelf through the rectifiers.
  - Step 2** The controller and rectifier LEDs will start to blink. It may take a few minutes for the controller to communicate with all rectifiers.
  - Step 3** The system is now commissioned. If the controller RED LED is on, refer to “[Chapter 5, “System Troubleshooting.”](#)
- 

### 4.2 General Information

The Power Control System (XCS) ([Figure 4-1](#)) is a supervisory system that is designed to control AC/DC power systems that are based on XR1648 rectifier modules.

Communication is accomplished through an alarm interface board and a backplane that connects to the rectifier modules.

**Figure 4-1 System Control Unit**



## ■ 4.2.1 Alarm Interface Board and Connections

### 4.2.1 Alarm Interface Board and Connections

The alarm interface board is the main connection point for external communication inputs. The board is located inside the controller and can be accessed by removing the front controller cover and then sliding out the controller tray to expose the alarm connections (located on the right-hand side).

Alarm connections are made at the terminal block located on the Alarm/Interface PC board. The green connectors can be easily removed for ease in installing the wires into the connector; 22 AWG (0.34mm<sup>2</sup>) wire is recommended for connecting alarms to the alarm output terminals ([Figure 2-21 on page 2-24](#)). External connections are Form C relay which can be monitored either Normally Closed or Normally Open. The four alarms are numbered 1 through 4. (Refer to [Table 2-6 on page 2-23](#)).



**Note** All alarm connections are for the unpowered state. When the power is off the NC is normally closed and when the power is on, the NC is open.

The following is a list of alarm board connections including descriptions and cabling:

- Alarms - Up to four Form C alarm contacts for remote signaling
- Load fuse and breaker monitoring
- RS232 Interface - External communications port (not utilized in this application)

### 4.2.2 Basic Controller Functions

The following section contains basic controller functions including starting the controller, adding modules, and removing modules from the system.

#### 4.2.2.1 Start the Controller

When power is applied to the controller:

- 
- Step 1** The controller will spend several minutes analyzing the system and testing all addresses for connected rectifier modules. The green LED on the controller will blink. No alarms will be raised during this period.
- Step 2** When the controller finds a module it will add it to the inventory.
- 

#### 4.2.2.2 Add Modules

When a rectifier is added to the system it will remain off until the controller detects it.

- 
- Step 1** When a rectifier is added to the system, its output voltage will walk-in, increasing up to its default setting. This will occur within 60 seconds.
- Step 2** The controller constantly scans for new modules, but it may take a few minutes to recognize an inserted module.
-

- Step 3** During this recognition time the controller may report module-related alarms and the red LED on the rectifier may turn on. These alarms are caused by imbalances related to load sharing of the rectifiers (the new rectifier's output voltage is different than the existing rectifiers).
- Step 4** The rectifier module will take a few minutes to step up to the correct voltage. At this point the controller will locate and adjust the rectifier module voltage to the correct output voltage and any alarms will be extinguished.
- Step 5** To shorten the time that is needed to find new modules, the controller can be powered down and then powered up. This will cause the system to search for new modules faster. This is only recommended as a solution if it is important to shorten the time required for searching for new modules.

### 4.2.2.3 Remove Modules

Physically removing a module from the system creates a communication error indicated by the yellow LED on the controller. The yellow LED will remain on until a rectifier is installed.

**■ 4.2.2 Basic Controller Functions**



## System Troubleshooting

This chapter contains information about troubleshooting and should be consulted in the event of a system malfunction.

The following is a list of potential problems and resolutions. If the first recommendation does not solve the problem, continue on to the next. If further assistance is needed, see the “[Obtaining Technical Assistance](#)” section on page [xiv](#).

**Warning**

**Only trained and qualified personnel should be allowed to install, replace, or service this equipment.**

Statement 1030

**Note**

Most alarms will clear automatically when the cause has been cleared. Some alarms can be cancelled via the front panel push-buttons. In this case it will be indicated in the trouble shooting instructions.

**Error Message** Low System Voltage (Red light on controller, Relay #1)

**Explanation**

1. Rectifier failure
2. Loss of AC power on some or all rectifiers
3. Load exceeds rectifier capacity

**Recommended Action**

1. Replace faulty rectifier
2. Add one or more rectifiers to the system

**Error Message** Mains Error (Yellow light on controller, Relay #2)

**Explanation** AC supply off on two or more rectifiers**Recommended Action**

1. Verify that the AC supply is available at the correct voltage
2. Verify that the AC input breaker is in the ON position

**Error Message** Distribution Fuse/Breaker Failure (Red light on controller, Relay #4)

#### Explanation

1. Tripped breaker
2. Fuse blown

#### Recommended Action

1. Localize the faulty breaker or blown fuse
2. Verify there are no short circuits in the cabling to the load
3. Reset breaker. If it trips again there is a problem with the breaker or the load
4. Replace breaker if required
5. Verify that there is no blown fuse. (If so, replace the blown fuse.) If the fuse blows again, there may be a problem with the load



**Note**

Due to proprietary alarm wiring, a voltage will appear at the load terminal of the fuse even when the fuse is open. The voltage comes from a high impedance circuit used for blown fuse detection when a load is connected. This is not an energy hazard.

**Error Message** High Load (Yellow light on controller)

#### Explanation

Load current exceeds 75%

#### Recommended Action

1. Check load current versus installed rectifier capacity. The alarm is generated when output load reaches 75% of rectifier capacity.
2. Add rectifier or reduce load.


**Error Message** Module Failure (Red light on controller and Module, Relay #3)

#### Explanation

1. Module failure
2. AC Off on a single rectifier
3. Current sharing fault

#### Recommended Action

1. Verify that the AC supply to the failed module is present at the right voltage.
2. Remove the faulty module, wait 30 seconds, and re-insert it. Wait up to four minutes for the controller to re-establish communication. If the module is still faulty, replace it with a new module.
3. Verify module address and resolve any address duplication ([Figure 5-1](#)). Rectifier address DIP switches are located at the inside rear of the rectifier shelf.

**Figure 5-1 Module Locations**

**Note** Sometimes the rectifier that indicates a failure is not the cause of the failure. The failure may be caused by a current share imbalance. If the failure persists even after replacing the rectifiers showing a fault, replace each rectifier in turn with a known good unit until the fault clears. The replaced module that clears the fault is the defective one.

**Error Message** Urgent Module Failure (Red light on controller, Relay #3)

**Explanation** More than one rectifier is reporting a module failure.

**Recommended Action** See module failure.

**Error Message** Communication Failure (Yellow light on controller, flashing yellow light on module)

**Explanation**

1. Controller is looking for the installed module
2. A module has been removed and not replaced
3. Broken or disconnected communication wire

**Recommended Action**

1. Wait for 5 minutes.
2. Verify that the module address is properly set and is not a duplicate of another address ([Figure 5-1](#)). Rectifier address DIP switches are located at the inside rear of the rectifier shelf.
3. Verify that the communication cable at the back of the rectifier shelf is connected.
4. Replace communication cable if required.



**CHAPTER****6**


## System Parts List

This chapter contains a list of replacement parts and part numbers for the Cisco AC/DC Power System.

**Table 6-1    Parts List**

Description	Part Number
Main Shelf Assembly	CSCO-SM-PWR-SA
Rectifier Module	CSCO-PWR-RECT
Controller Module	CSCO-CNTRL-BRD
1RU DC Distribution Shelf	CSCO-EXP-PANEL
30A Circuit Breaker	CSCO-CKT-BRK
Ship Kit for Main Shelf Assembly	CSCO-SHP-KIT-1
Ship Kit for 1RU DC Distribution Shelf	CSCO-SHP-KIT-2
AC Power Cable for 110V AC North America	CSCO-PWR-CBL-NA1
AC Power Cable for 220V AC North America	CSCO-PWR-CBL-NA2
AC Power Cable for Argentina	CSCO-PWR-CBL-ARG
AC Power Cable for Australia	CSCO-PWR-CBL-AUS
AC Power Cable for China	CSCO-PWR-CBL-CHN
AC Power Cable for EU Member Nations	CSCO-PWR-CBL-EU
AC Power Cable for Italy	CSCO-PWR-CBL-ITL
AC Power Cable for Japan	CSCO-PWR-CBL-JPN
AC Power Cable for The United Kingdom	CSCO-PWR-CBL-UK





## APPENDIX

# A

## Translated Safety Warnings

This appendix contains the translated warnings included in the Cisco AC/DC Power System user documentation.

The translated safety warnings are listed in the following order:

<b>1</b>	English	<b>10</b>	Swedish	<b>19</b>	Croatian (in some)
<b>2</b>	Dutch	<b>11</b>	Hungarian	<b>20</b>	Czech (in some)
<b>3</b>	Finnish	<b>12</b>	Russian	<b>21</b>	Greek (in some)
<b>4</b>	French	<b>13</b>	Chinese	<b>22</b>	Hebrew (in some)
<b>5</b>	German	<b>14</b>	Japanese	<b>23</b>	Macedonian (in some)
<b>6</b>	Italian	<b>15</b>	Korean (in some)	<b>24</b>	Polish (in some)
<b>7</b>	Norwegian	<b>16</b>	Brazilian Portuguese (in some)	<b>25</b>	Slovakian (in some)
<b>8</b>	Portuguese	<b>17</b>	Danish (in some)		
<b>9</b>	Spanish	<b>18</b>	Arabic (in some)		

## Statement 12—Power Supply Disconnection Warning



Warning

**Before working on a chassis or working near power supplies, unplug the power cord on AC units; disconnect the power at the circuit breaker on DC units.** Statement 12

Waarschuwing

**Voordat u aan een frame of in de nabijheid van voedingen werkt, dient u bij wisselstroom toestellen de stekker van het netsnoer uit het stopcontact te halen; voor gelijkstroom toestellen dient u de stroom uit te schakelen bij de stroomverbreker.**

Varoitus

**Kytke irti vaihtovirtalaitteiden virtajohto ja katkaise tasavirtalaitteiden virta suojakytikellä, ennen kuin teet mitään asennuspohjalle tai työskentelet virtalähteiden läheisyydessä.**

Attention

**Avant de travailler sur un châssis ou à proximité d'une alimentation électrique, débrancher le cordon d'alimentation des unités en courant alternatif ; couper l'alimentation des unités en courant continu au niveau du disjoncteur.**



<b>Warnung</b>	<b>Bevor Sie an einem Chassis oder in der Nähe von Netzgeräten arbeiten, ziehen Sie bei Wechselstromeinheiten das Netzkabel ab bzw. schalten Sie bei Gleichstromeinheiten den Strom am Unterbrecher ab.</b>
<b>Avvertenza</b>	<b>Prima di lavorare su un telaio o intorno ad alimentatori, scollegare il cavo di alimentazione sulle unità CA; scollegare l'alimentazione all'interruttore automatico sulle unità CC.</b>
<b>Advarsel</b>	<b>Før det utføres arbeid på kabinetet eller det arbeides i nærheten av strømforsyningseenheter, skal strømledningen trekkes ut på vekselstrømsenheter og strømmen kobles fra ved strømbryteren på likestrømsenheter.</b>
<b>Aviso</b>	<b>Antes de trabalhar num chassis, ou antes de trabalhar perto de unidades de fornecimento de energia, desligue o cabo de alimentação nas unidades de corrente alternada (CA); desligue a corrente no disjuntor nas unidades de corrente contínua.</b>
<b>¡Advertencia!</b>	<b>Antes de manipular el chasis de un equipo o trabajar cerca de una fuente de alimentación, desenchufar el cable de alimentación en los equipos de corriente alterna (CA); cortar la alimentación desde el interruptor automático en los equipos de corriente continua (CC).</b>
<b>Varning!</b>	<b>Innan du arbetar med ett chassi eller nära strömförsljningsenheter skall du för växelströmsenheter dra ur nätsladden och för likströmsenheter bryta strömmen vid överspänningsskyddet.</b>
<b>Figyelem</b>	<b>Mielőtt elkezdene dolgozni a házon vagy tápegységek közelében, húzza ki a váltóáramú készülékek tápkábelét; egyenáramú készülék esetén szakítsa meg az áramot az árammegszakítónál.</b>
<b>Предупреждение</b>	<b>Перед выполнением монтажных работ или других работ в непосредственной близости от источников питания отключите кабель электропитания от устройств с питанием переменным током. Устройства с питанием постоянным током отключите с помощью выключателя питания.</b>
<b>警告</b>	<b>在机架或电源附近工作时, 请拔下交流设备的电源电缆, 断开直流设备断路器的电源。</b>
<b>警告</b>	<b>シャーシの作業を行うとき、または電源装置の付近で作業するときは、事前にAC装置から電源コードを外してください。DC装置の場合は、回路ブレーカーで電源を切断します。</b>

---

## Statement 43—Jewelry Removal Warning


**Warning**

**Before working on equipment that is connected to power lines, remove jewelry (including rings, necklaces, and watches). Metal objects will heat up when connected to power and ground and can cause serious burns or weld the metal object to the terminals.** Statement 43

**Waarschuwing**

**Alvorens aan apparatuur te werken die met elektrische leidingen is verbonden, sieraden (inclusief ringen, kettingen en horloges) verwijderen. Metalen voorwerpen worden warm wanneer ze met stroom en aarde zijn verbonden, en kunnen ernstige brandwonden veroorzaken of het metalen voorwerp aan de aansluitklemmen lassen.**

**Varoitus**

**Ennen kuin työskentelet voimavirtajohtoihin kytkettyjen laitteiden parissa, ota pois kaikki korut (sormukset, kaulakorut ja kelloet mukaan lukien). Metalliesineet kuumenevat, kun ne ovat yhteydessä sähkövirran ja maan kanssa, ja ne voivat aiheuttaa vakavia palovammoja tai hitsata metalliesineet kiinni liittäntänapoihin.**

**Attention**

**Avant d'accéder à cet équipement connecté aux lignes électriques, ôter tout bijou (anneaux, colliers et montres compris). Lorsqu'ils sont branchés à l'alimentation et reliés à la terre, les objets métalliques chauffent, ce qui peut provoquer des blessures graves ou souder l'objet métallique aux bornes.**

**Warnung**

**Vor der Arbeit an Geräten, die an das Netz angeschlossen sind, jeglichen Schmuck (einschließlich Ringe, Ketten und Uhren) abnehmen. Metallgegenstände erhitzen sich, wenn sie an das Netz und die Erde angeschlossen werden, und können schwere Verbrennungen verursachen oder an die Anschlußklemmen angeschweißt werden.**

**Avvertenza**

**Prima di intervenire su apparecchiature collegate alle linee di alimentazione, togliersi qualsiasi monile (inclusi anelli, collane, braccialetti ed orologi). Gli oggetti metallici si riscaldano quando sono collegati tra punti di alimentazione e massa: possono causare ustioni gravi oppure il metallo può saldarsi ai terminali.**

**Advarsel**

**Fjern alle smykker (inkludert ringer, halskjeder og klokker) før du skal arbeide på utstyr som er koblet til kraftledninger. Metallgjenstander som er koblet til kraftledninger og jord blir svært varme og kan forårsake alvorlige brannskader eller smelte fast til polene.**

**Aviso**

**Antes de trabalhar em equipamento que esteja ligado a linhas de corrente, retire todas as jóias que estiver a usar (incluindo anéis, fios e relógios). Os objectos metálicos aquecerão em contacto com a corrente e em contacto com a ligação à terra, podendo causar queimaduras graves ou ficarem soldados aos terminais.**

**¡Advertencia!**

**Antes de operar sobre equipos conectados a líneas de alimentación, quitarse las joyas (incluidos anillos, collares y relojes). Los objetos de metal se calientan cuando se conectan a la alimentación y a tierra, lo que puede ocasionar quemaduras graves o que los objetos metálicos queden soldados a los bornes.**

**Varning!**

**Tag av alla smycken (inklusive ringar, halsband och armbandsur) innan du arbetar på utrustning som är kopplad till kraftledningar. Metallobjekt hettas upp när de kopplas ihop med ström och jord och kan förorsaka allvarliga brännskador; metallobjekt kan också sammansvetsas med kontakterna.**

Figyelem	Mielőtt hálózati feszültséghez csatlakozó készülékkel kezd el dolgozni, vegye le magáról az ékszereket (például gyűrűt, nyakláncot, órát). A fém tárgyak felmelegsznek, ha hálózati feszültséghez és földhöz érnek, és súlyos égési sérülést okozhatnak, illetve a fém tárgyak hozzáforrhatnak a csatlakozókhöz.
Предупреждение	Прежде чем использовать оборудование, подключенное к электросети, снимите все украшения (включая кольца, ожерелья и часы). Металлические части нагреваются при соединении с источником питания и землей, что может привести к серьезным ожогам или привариванию металлических объектов к клеммам.
警告	在操作与电源线连接的设备以前，请取下首饰（包括戒指、项链和手表）。连接电源和接地后，金属物品会升温，可能导致严重灼伤，也可能使金属物品熔接在线端。
警告	電源に接続されている装置を取り扱う際は、事前に、指輪、ネックレス、腕時計などの装身具をはずしてください。金属のオブジェクトが電源とアースと接触すると、金属が過熱して大やけどをしたり、また金属類が端子に焼き付くことがあります。

## Statement 1006—Chassis Warning for Rack-Mounting and Servicing



### Warning

To prevent bodily injury when mounting or servicing this unit in a rack, you must take special precautions to ensure that the system remains stable. The following guidelines are provided to ensure your safety:

- This unit should be mounted at the bottom of the rack if it is the only unit in the rack.
- When mounting this unit in a partially filled rack, load the rack from the bottom to the top with the heaviest component at the bottom of the rack.
- If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the unit in the rack. Statement 1006

### Waarschuwing

Om lichamelijk letsel te voorkomen wanneer u dit toestel in een rek monteert of het daar een servicebeurt geeft, moet u speciale voorzorgsmaatregelen nemen om ervoor te zorgen dat het toestel stabiel blijft. De onderstaande richtlijnen worden verstrekt om uw veiligheid te verzekeren:

- Dit toestel dient onderaan in het rek gemonteerd te worden als het toestel het enige in het rek is.
- Wanneer u dit toestel in een gedeeltelijk gevuld rek monteert, dient u het rek van onderen naar boven te laden met het zwaarste onderdeel onderaan in het rek.
- Als het rek voorzien is van stabiliseringshulpmiddelen, dient u de stabilisatoren te monteren voordat u het toestel in het rek monteert of het daar een servicebeurt geeft.

<b>Varoitus</b>	<b>Kun laite asetetaan telineeseen tai huolletaan sen ollessa telineessä, on noudatettava erityisiä varotoimia järjestelmän vakavuuden säilyttämiseksi, jotta välttyään loukkaantumiselta. Noudata seuraavia turvallisuusohjeita:</b> <ul style="list-style-type: none"> <li>• Jos telineessä ei ole muita laitteita, aseta laite telineen alaosaan.</li> <li>• Jos laite asetetaan osaksi täytettyyn telineeseen, aloita kuormittaminen sen alaosasta kaikkein raskaimmalla esineellä ja siirry sitten sen yläosaan.</li> <li>• Jos telinettä varten on vakaimet, asenna ne ennen laitteen asettamista telineeseen tai sen huoltamista siinä.</li> </ul>
<b>Attention</b>	<b>Pour éviter toute blessure corporelle pendant les opérations de montage ou de réparation de cette unité en casier, il convient de prendre des précautions spéciales afin de maintenir la stabilité du système. Les directives ci-dessous sont destinées à assurer la protection du personnel:</b> <ul style="list-style-type: none"> <li>• Si cette unité constitue la seule unité montée en casier, elle doit être placée dans le bas.</li> <li>• Si cette unité est montée dans un casier partiellement rempli, charger le casier de bas en haut en plaçant l'élément le plus lourd dans le bas.</li> <li>• Si le casier est équipé de dispositifs stabilisateurs, installer les stabilisateurs avant de monter ou de réparer l'unité en casier.</li> </ul>
<b>Warnung</b>	<b>Zur Vermeidung von Körperverletzung beim Anbringen oder Warten dieser Einheit in einem Gestell müssen Sie besondere Vorkehrungen treffen, um sicherzustellen, daß das System stabil bleibt. Die folgenden Richtlinien sollen zur Gewährleistung Ihrer Sicherheit dienen:</b> <ul style="list-style-type: none"> <li>• Wenn diese Einheit die einzige im Gestell ist, sollte sie unten im Gestell angebracht werden.</li> <li>• Bei Anbringung dieser Einheit in einem zum Teil gefüllten Gestell ist das Gestell von unten nach oben zu laden, wobei das schwerste Bauteil unten im Gestell anzubringen ist.</li> <li>• Wird das Gestell mit Stabilisierungszubehör geliefert, sind zuerst die Stabilisatoren zu installieren, bevor Sie die Einheit im Gestell anbringen oder sie warten.</li> </ul>
<b>Avvertenza</b>	<b>Per evitare infortuni fisici durante il montaggio o la manutenzione di questa unità in un supporto, occorre osservare speciali precauzioni per garantire che il sistema rimanga stabile. Le seguenti direttive vengono fornite per garantire la sicurezza personale:</b> <ul style="list-style-type: none"> <li>• Questa unità deve venire montata sul fondo del supporto, se si tratta dell'unica unità da montare nel supporto.</li> <li>• Quando questa unità viene montata in un supporto parzialmente pieno, caricare il supporto dal basso all'alto, con il componente più pesante sistemato sul fondo del supporto.</li> <li>• Se il supporto è dotato di dispositivi stabilizzanti, installare tali dispositivi prima di montare o di procedere alla manutenzione dell'unità nel supporto.</li> </ul>
<b>Advarsel</b>	<b>Unngå fysiske skader under montering eller reparasjonsarbeid på denne enheten når den befinner seg i et kabinett. Vær øye med at systemet er stabilt. Følgende retningslinjer er gitt for å verne om sikkerheten:</b> <ul style="list-style-type: none"> <li>• Denne enheten bør monteres nederst i kabinetet hvis dette er den eneste enheten i kabinetet.</li> <li>• Ved montering av denne enheten i et kabinett som er delvis fylt, skal kabinetet lastes fra bunnen og opp med den tyngste komponenten nederst i kabinetet.</li> <li>• Hvis kabinetet er utstyrt med stabiliseringsutstyr, skal stabilisatorene installeres før montering eller utføring av reparasjonsarbeid på enheten i kabinetet.</li> </ul>

<b>Aviso</b>	<p><b>Para se prevenir contra danos corporais ao montar ou reparar esta unidade numa estante, deverá tomar precauções especiais para se certificar de que o sistema possui um suporte estável. As seguintes directrizes ajudá-lo-ão a efectuar o seu trabalho com segurança:</b></p> <ul style="list-style-type: none"> <li>• Esta unidade deverá ser montada na parte inferior da estante, caso seja esta a única unidade a ser montada.</li> <li>• Ao montar esta unidade numa estante parcialmente ocupada, coloque os itens mais pesados na parte inferior da estante, arrumando-os de baixo para cima.</li> <li>• Se a estante possuir um dispositivo de estabilização, instale-o antes de montar ou reparar a unidade.</li> </ul>
<b>¡Advertencia!</b>	<p><b>Para evitar lesiones durante el montaje de este equipo sobre un bastidor, o posteriormente durante su mantenimiento, se debe poner mucho cuidado en que el sistema quede bien estable. Para garantizar su seguridad, proceda según las siguientes instrucciones:</b></p> <ul style="list-style-type: none"> <li>• Colocar el equipo en la parte inferior del bastidor, cuando sea la única unidad en el mismo.</li> <li>• Cuando este equipo se vaya a instalar en un bastidor parcialmente ocupado, comenzar la instalación desde la parte inferior hacia la superior colocando el equipo más pesado en la parte inferior.</li> <li>• Si el bastidor dispone de dispositivos estabilizadores, instalar éstos antes de montar o proceder al mantenimiento del equipo instalado en el bastidor.</li> </ul>
<b>Varng!</b>	<p><b>För att undvika kroppsskada när du installerar eller utför underhållsarbete på denna enhet på en ställning måste du vidta särskilda försiktighetsåtgärder för att försäkra dig om att systemet står stadigt. Följande riktlinjer ges för att trygga din säkerhet:</b></p> <ul style="list-style-type: none"> <li>• Om denna enhet är den enda enheten på ställningen skall den installeras längst ned på ställningen.</li> <li>• Om denna enhet installeras på en delvis fyllt ställning skall ställningen fyllas nedifrån och upp, med de tyngsta enheterna längst ned på ställningen.</li> <li>• Om ställningen är försedd med stabiliseringar skall dessa monteras fast innan enheten installeras eller underhålls på ställningen.</li> </ul>
<b>Figyelem</b>	<p><b>A készülék rackbe történő beszerelése és karbantartása során bekövetkező sérülések elkerülése végett speciális óvintézkedésekkel meg kell őrizni a rendszer stabilitását. A személyes biztonságában érdekében tartsa be a következő szabályokat:</b></p> <ul style="list-style-type: none"> <li>• Ha a rackben csak ez az egy készülék található, a rack aljába kell beszerelni.</li> <li>• Ha nincs teljesen tele az a rack, amelybe beszerelik a készüléket, alulról fölfelé haladva töltse fel a racket úgy, hogy a legnehezebb készülék kerüljön a rack aljába.</li> <li>• Ha stabilizáló eszközök is tartoznak a rackhez, szerelje fel a stabilizátorokat, mielőtt beszerelné az egységet a rackbe, vagy karbantartást végezne rajta.</li> </ul>
<b>Предупреждение</b>	<p>Во избежание травм при монтаже и обслуживании устройства в стойке следует принять особые меры предосторожности, чтобы убедиться в устойчивости оборудования. Для обеспечения безопасности работ необходимо соблюдать следующие правила.</p> <ul style="list-style-type: none"> <li>• Если в стойке находится одно устройство, оно должно быть установлено в нижней части.</li> <li>• При монтаже устройств в частично заполненную стойку устанавливайте оборудование снизу вверх, размещая наиболее тяжелые устройства в нижней части.</li> <li>• Если стойка снабжена приспособлениями для стабилизации, их необходимо установить до начала монтажа или обслуживания оборудования.</li> </ul>
<b>警告</b>	<p>为避免在机架中安装或维修该部件时使身体受伤，您必须采取特殊的预防措施确保系统固定。以下是确保安全的原则：</p> <ul style="list-style-type: none"> <li>• 如果此部件是机架中唯一的部件，应将其安装在机架的底部。</li> <li>• 如果在部分装满的机架中安装此部件，请按从下往上的顺序安装各个部件，并且最重的组件应安装在机架的底部。</li> <li>• 如果机架配有固定装置，请先装好固定装置，然后再在机架中安装或维修部件。</li> </ul>

**警告** この装置をラックに設置したり保守作業を行ったりするときは、人身事故を防ぐため、システムが安定しているかどうかを十分に確認する必要があります。次の注意事項に従ってください。

- ラックにこの装置を単独で設置する場合は、ラックの一番下に設置します。
- ラックに別の装置がすでに設置されている場合は、最も重量のある装置を一番下にして、重い順に下から上へ設置します。
- ラックに安定器具が付属している場合は、その安定器具を取り付けてから、装置をラックに設置するか、またはラック内の装置の保守作業を行ってください。

**주의** 이 장치를 랙에 장착하거나 서비스할 때 신체 부상을 방지하려면, 시스템이 안정된 상태를 유지하도록 특별히 주의해야 합니다. 사용자의 안전을 위해 다음 지침 사항을 준수하십시오.

- 이 장치가 랙에 장착되는 유일한 것인 경우, 랙의 맨 아래 부분에 장착되어야 합니다.
- 부분적으로 차 있는 랙에 이 장치를 장착할 경우, 가장 무거운 장치를 랙의 맨 아래 부분부터 차례로 장착하십시오.
- 안정기가 랙과 함께 제공되는 경우, 이 안정기를 설치한 후 이 장치를 랙에 장착하거나 서비스하십시오

**Aviso** Para evitar lesões corporais ao montar ou dar manutenção a esta unidade em um rack, é necessário tomar todas as precauções para garantir a estabilidade do sistema. As seguintes orientações são fornecidas para garantir a sua segurança:

- Se esta for a única unidade, ela deverá ser montada na parte inferior do rack.
- Ao montar esta unidade em um rack parcialmente preenchido, carregue-o de baixo para cima com o componente mais pesado em sua parte inferior.
- Se o rack contiver dispositivos estabilizadores, instale-os antes de montar ou dar manutenção à unidade existente.

**Advarsel** For at forhindre legemesbeskadigelse ved montering eller service af denne enhed i et rack, skal du sikre at systemet står stabilt. Følgende retningslinjer er også for din sikkerheds skyld:

- Enheden skal monteres i bunden af dit rack, hvis det er den eneste enhed i racket.
- Ved montering af denne enhed i et delvist fyldt rack, skal enhederne installeres fra bunden og opad med den tungeste enhed nederst.
- Hvis racket leveres med stabiliseringsenheder, skal disse installeres for enheden monteres eller serviceres i racket.

**تحذير** لتجنب حدوث أي إصابات عند تركيب هذه الوحدة، يجب اتباع بعض الاحتياطات لضمان عمل النظام بشكل سليم.

يتم ذكر الإرشادات التالية لضمان الأمان.

يجب تركيب هذه الوحدة في الجزء السفلي من الدوّلاب المتضمن قصبان إذا كانت هذه الوحدة هي الوحدة الوحيدة في الدوّلاب الذي يحتوي على قصبان.

عند تركيب هذه الوحدة في دوّلاب شبه ممتنئ، قم برفع الدوّلاب من الجزء السفلي لأعلى بحيث يكون الجزء الأثقل وزناً أسفل الدوّلاب.

إذا كان الدوّلاب المتضمن قصباً يحتوي على أجهزة حفظ التوازن، قم بتنبيه هذه الأجهزة قبل تركيب الوحدة في الدوّلاب.

<b>Upozorenje</b>	Kako ne bi došlo do tjelesnih ozljeda kod postavljanja ili servisiranja uređaja na polici, potrebno je poduzeti mjere predostrožnosti kako bi sustav uvijek bio stabilan. Sigurnost se može osigurati poštivanjem sljedećih smjernica: <ul style="list-style-type: none"> <li>• Ovaj uređaj treba ugraditi na dno police, ukoliko je to jedini uređaj na polici.</li> <li>• Kod ugradnje uređaja u policu na kojoj se već nalaze drugi uređaji, policu treba opremati počevši od dna, te tako da se na dno stave najteži dijelovi.</li> <li>• Ukoliko su na polici ugrađeni stabilizatori, njih montirajte prije ugradnje ili servisiranja uređaja na polici.</li> </ul>
<b>Upozornění</b>	Abyste předešli poranění osob při montáži nebo opravě zařízení v montážním rámu, musíte dodržovat zvláštní preventivní opatření pro zajištění udržení stability systému. Pro zajištění bezpečnosti obsluhy jsou určeny následující zásady: <ul style="list-style-type: none"> <li>• Pokud je toto zařízení jedinou jednotkou v montážním rámu, musí být namontováno na nejnižší místo rámu.</li> <li>• Pokud je toto zařízení montováno do částečně obsazeného montážního rámu, obsazujte montážní rám ve směru zdola nahoru tak, aby byla nejtěžší součást nejníže.</li> <li>• Pokud je montážní rám vybaven stabilizačními zařízeními, nainstalujte stabilizátory ještě před montáží nebo opravou zařízení v montážním rámu.</li> </ul>
Προειδοποίηση	Για να αποφύγετε τον τραυματισμό κατά την τοποθέτηση ή τη συντήρηση αυτής της συσκευής σε αρθρωτό σύστημα, πρέπει να λάβετε ειδικές προφυλάξεις για να διασφαλίσετε τη σταθερότητα του συστήματος. Οι παρακάτω οδηγίες παρέχονται για να εξασφαλίσουν την ασφάλειά σας: <ul style="list-style-type: none"> <li>• Αυτή η συσκευή πρέπει να τοποθετείται στο κάτω μέρος του αρθρωτού συστήματος αν είναι η μοναδική συσκευή σε αυτό.</li> <li>• Όταν τοποθετείτε αυτήν τη συσκευή σε εν μέρει γεμάτο αρθρωτό σύστημα, τοποθετήστε συσκευές στο αρθρωτό σύστημα από κάτω προς τα επάνω, με τη βαρύτερη συσκευή στο κάτω μέρος του συστήματος.</li> <li>• Εάν το αρθρωτό σύστημα διαθέτει διατάξεις σταθεροποίησης, τοποθετήστε τους σταθεροποιητές πριν τοποθετήσετε ή συντηρήσετε τη συσκευή στο αρθρωτό σύστημα.</li> </ul>
אזהרה	כדי למנוע פגיעה בעת הרכבת יחידה זו במעמד או טיפול בה, עליך לנתקו אמצעי זהירות מוחדים כדי להבטיח את יציבות המערכת. הקווים המנחים הבאים יתנו לך להבטיח את ביטחונך: <ul style="list-style-type: none"> <li>• אם יחידה זו היא יחידה בודדת במעמד, יש להרכיב את היחידה בחלקן התחתון של המעמד.</li> <li>• בעת הרכבת יחידה זו במעמד המלא בחלקן, טען את המעמד החלק התחתון וככלפ' מעלה כאשר הרכיב הכבד ביותר נמצא בחלקן התחתון של המעמד.</li> <li>• אם המעמד מסופק עם התקני ייצוב, התקן את המיצבים לפני הרכבה היחידה במעמד או טיפול בה.</li> </ul>
Opomena	За да се не повредите кога го монтирате или го сервисирате уредот на полица, мора да бидете особено претпазливи за да ја обезбедите стабилноста на системот. Следите напатствија се дадени за да ја осигураат Вашата безбедност: <ul style="list-style-type: none"> <li>• Уредот треба да се монтира најдолу на полицата ако е единствен уред на полицата.</li> <li>• Кога го монтирате уредот на делумно пополната полица, пополнете ја полицата од дното кон врвот со најтешката компонента на дното на полицата.</li> <li>• Ако полицата има стабилизаторски делови, наместете ги стабилизаторите пред да го монтирате или сервисирате уредот на полицата.</li> </ul>

Ostrzeżenie	Aby zapobiec urazom podczas montażu lub serwisowania tego urządzenia w stojaku, należy zastosować szczególne środki ostrożności w celu zapewnienia stabilności układu. Poniżej przedstawiono wskazówki, których przestrzeganie zapewni bezpieczeństwo: <ul style="list-style-type: none"> <li>Jeśli urządzenie to jest jedynym urządzeniem w stojaku, powinno być zamontowane na dole.</li> <li>W przypadku montażu urządzenia w częściowo zapełnionym stojaku należy instalować kolejne urządzenia od najniższego do najwyższego, przy czym element najczęstszy powinien być zamontowany najniżej w stojaku.</li> <li>Jeśli stojak jest wyposażony w elementy stabilizujące, należy zamontować stabilizatory przed przystąpieniem do montażu lub serwisowania urządzeń w stojaku.</li> </ul>
Upozornenie	Aby ste predišli poraneniu osôb pri montáži alebo oprave zariadenia v montážnom ráme, musíte dodržiavať zvláštne preventívne opatrenia na zaistenie udržania stability systému. Na zaistenie bezpečnosti obsluhy sú určené nasledujúce zásady: <ul style="list-style-type: none"> <li>Pokiaľ je toto zariadenie jedinou jednotkou v montážnom ráme, musí byť namontované na najnižšie miesto v rámci.</li> <li>Pokiaľ je toto zariadenie montované do čiastočne obsadeného montážného rámu, obsadzujte montážny rám v smere zdola nahor tak, aby bola najľažšia súčasť najnižšie.</li> <li>Pokiaľ je montážny rám vybavený stabilizačnými zariadeniami, nainštalujte stabilizátory ešte pred montážou alebo opravou zariadenia v montážnom ráme.</li> </ul>

## Statement 1017—Restricted Area

 Warning	This unit is intended for installation in restricted access areas. A restricted access area can be accessed only through the use of a special tool, lock and key, or other means of security. Statement 1017
Waarschuwing	Deze eenheid is bestemd voor installatie in plaatsen met beperkte toegang. Toegang tot een dergelijke plaats kan alleen verkregen worden door middel van een speciaal instrument, een slot en sleutel of een ander veiligheidsmiddel.
Varoitus	Tämä laite on tarkoitettu asennettavaksi paikkaan, johon pääsy on rajoitettua. Tällaiseen paikkaan pääsee vain erikoistyökalua, lukkoon sopivaa avainta tai jotakin muuta turvalaitetta käyttämällä.
Attention	Cet appareil est à installer dans des zones d'accès réservé. L'accès à une zone d'accès réservé n'est possible qu'en utilisant un outil spécial, un mécanisme de verrouillage et une clé, ou tout autre moyen de sécurité.
Warnung	Diese Einheit ist zur Installation in Bereichen mit beschränktem Zutritt vorgesehen. Der Zutritt zu derartigen Bereichen ist nur mit einem Spezialwerkzeug, Schloss und Schlüssel oder einer sonstigen Sicherheitsvorkehrung möglich.



<b>Avvertenza</b>	<b>Questa unità è prevista per essere installata in un'area ad accesso limitato, vale a dire un'area accessibile solo mediante l'uso di un attrezzo speciale, come lucchetto e chiave, o altri dispositivi di sicurezza.</b>
<b>Advarsel</b>	<b>Denne enheten er beregnet på installasjon i områder med begrenset tilgang. Et begrenset tilgangsområde kan bare nås ved hjelp av et spesielt verktøy, lås og nøkkel, eller andre sikkerhetsanordninger.</b>
<b>Aviso</b>	<b>Esta unidade foi concebida para instalação em áreas de acesso restrito. Uma área de acesso restrito é uma área à qual apenas tem acesso o pessoal de serviço autorizado, que possua uma ferramenta, chave e fechadura especial, ou qualquer outra forma de segurança.</b>
<b>¡Advertencia!</b>	<b>Esta unidad ha sido diseñada para instalación en áreas de acceso restringido. Sólo puede obtenerse acceso a una de estas áreas mediante la utilización de una herramienta especial, cerradura con llave u otro medio de seguridad.</b>
<b>Varning!</b>	<b>Denna enhet är avsedd för installation i områden med begränsat tillträde. Ett område med begränsat tillträde kan endast tillträddas med hjälp av specialverktyg, lås och nyckel eller annan säkerhetsanordning.</b>
<b>Figyelem</b>	<b>A készülék korlátozottan hozzáférhető területre történő beszerelésre készült. A korlátozottan hozzáférhető területekhez csak speciális szerszám, zár és kulcs vagy más biztonsági berendezés segítségével lehet hozzáférni.</b>
<b>Предупреждение</b>	<b>Данное устройство предназначено для установки в помещениях с ограниченным доступом. В такие помещения можно попасть, только имея специальное устройство доступа, карту или ключ или пройдя проверку другими средствами обеспечения безопасности.</b>
<b>警告</b>	<b>此部件应安装在限制进出的场所。限制进出的场所指只能通过使用特殊工具、锁和钥匙或其它安全手段进出的场所。</b>
<b>警告</b>	<b>この装置は立ち入り制限区域内に設置することが前提になっています。立ち入り制限区域とは、鍵、錠、またはその他の保全手段を使用しないと立ち入ることができない区域です。</b>
<b>주의</b>	<b>이 장치는 접근이 제한된 영역에 설치하도록 제작되었습니다. 특수 도구, 잠금 장치 및 키, 또는 기타 보안 수단을 통해서만 이 접근 제한 영역에 액세스할 수 있습니다.</b>
<b>Aviso</b>	<b>Esta unidade deve ser instalada em áreas de acesso restrito. Uma área de acesso restrito só pode ser acessada com o uso de uma ferramenta especial, cadeado e chave ou outros meios de segurança.</b>
<b>Advarsel</b>	<b>Denne enhed er beregnet til installation i områder med begrænset adgang. Der kan kun opnås adgang til et begrænset område ved at bruge et særligt stykke værktøj, lås og nøgle, eller en anden form for sikkerhed.</b>
<b>تحذير</b>	<b>تم تخصيص هذه الوحدة ليتم تثبيتها في مناطق محظورة الوصول إليها. يمكن الوصول إلى المنطقة المحظورة فقط من خلال استخدام أداة خاصة أو قفل أو مفتاح أو أي وسيلة أخرى من التأمين.</b>

Upozorenje	Uređaj je namijenjen ugradnji na teško dostupnim mjestima. Teško su dostupna mjesta takva mesta koja su dostupna samo uz pomoć posebnih alata, lokota i ključa, ili nekog drugog načina osiguravanja sigurnosti.
Upozornění	Toto zařízení je určeno pro instalaci v prostorech s omezeným přístupem. Do prostoru s omezeným přístupem lze získat přístup pouze pomocí zvláštního nástroje, zámku a klíče nebo jiných zabezpečovacích prostředků.
Προειδοποίηση	Αυτή η συσκευή προορίζεται για να τοποθετηθεί σε χώρους στους οποίους η πρόσβαση είναι περιορισμένη. Η πρόσβαση σε ένα χώρο με περιορισμένη πρόσβαση είναι δυνατή μόνο με τη χρήση ενός ειδικού εργαλείου, κλειδαριάς και κλειδιού ή άλλου μέσου ασφαλείας.
ازهراהה	יחידה זו מיועדת להתקנה באזורי עם גישה מוגבלת. הגישה לאזורי המיעדים לגישה מוגבלת אפשרית רק באמצעות כל אחד מיוחד, מנעול ופתח, או אמצעי בטיחות אחרים.
Opomena	Уредот е наменет за мястеже во област со ограничен пристап. Во областите со ограничен пристап може да се влезе само со употреба на специјална алатка, брава и клуч или со други средства за обезбедување.
Ostrzeżenie	To urządzenie jest przystosowane do instalacji w miejscach o ograniczonym dostępie. Przez miejsce o ograniczonym dostępie rozumie się miejsce, do którego dostęp uzyskać można wyłącznie za pomocą specjalnego narzędzia, zamka z kluczem lub innego zabezpieczenia.
Upozornenie	Toto zariadenie je určené na inštaláciu v priestoroch s obmedzeným prístupom. Do priestoru s obmedzeným prístupom je možné získať prístup iba pomocou špeciálneho nástroja, zámku a kľúča, alebo iných zabezpečovacích prostriedkov.

## Statement 1024—Ground Conductor



Warning

This equipment must be grounded. Never defeat the ground conductor or operate the equipment in the absence of a suitably installed ground conductor. Contact the appropriate electrical inspection authority or an electrician if you are uncertain that suitable grounding is available. Statement 1024

Waarschuwing

Deze apparatuur dient geaard te zijn. De aardingsleiding mag nooit buiten werking worden gesteld en de apparatuur mag nooit bediend worden zonder dat er een op de juiste wijze geïnstalleerde aardingsleiding aanwezig is. Neem contact op met de bevoegde instantie voor elektrische inspecties of met een elektricien als u er niet zeker van bent dat er voor passende aarding gezorgd is.

Varoitus

Laitteiden on oltava maadoitettuja. Älä koskaan ohita maajohdinta tai käytä laitteita ilman oikein asennettua maajohdinta. Ota yhteys sähkötarkastusviranomaiseen tai sähköasentajaan, jos olet epävarma maadoituksen sopivudesta.

Attention	<b>Cet équipement doit être mis à la masse. Ne jamais rendre inopérant le conducteur de masse ni utiliser l'équipement sans un conducteur de masse adéquatement installé. En cas de doute sur la mise à la masse appropriée disponible, s'adresser à l'organisme responsable de la sécurité électrique ou à un électricien.</b>
Warnung	<b>Dieses Gerät muss geerdet sein. Auf keinen Fall den Erdungsleiter unwirksam machen oder das Gerät ohne einen sachgerecht installierten Erdungsleiter verwenden. Wenn Sie sich nicht sicher sind, ob eine sachgerechte Erdung vorhanden ist, wenden Sie sich an die zuständige Inspektionsbehörde oder einen Elektriker.</b>
Avvertenza	<b>Questa apparecchiatura deve essere dotata di messa a terra. Non escludere mai il conduttore di protezione né usare l'apparecchiatura in assenza di un conduttore di protezione installato in modo corretto. Se non si è certi della disponibilità di un adeguato collegamento di messa a terra, richiedere un controllo elettrico presso le autorità competenti o rivolgersi a un elettricista.</b>
Advarsel	<b>Dette utstyret må jordes. Omgå aldri jordingslederen og bruk aldri utstyret uten riktig montert jordingsleder. Ta kontakt med fagfolk innen elektrisk inspeksjon eller med en elektriker hvis du er usikker på om det finnes velegnet jording.</b>
Aviso	<b>Este equipamento deve ser aterrado. Nunca anule o fio terra nem opere o equipamento sem um aterramento adequadamente instalado. Em caso de dúvida com relação ao sistema de aterramento disponível, entre em contato com os serviços locais de inspeção elétrica ou um eletricista qualificado.</b>
¡Advertencia!	<b>Este equipo debe estar conectado a tierra. No inhabilite el conductor de tierra ni haga funcionar el equipo si no hay un conductor de tierra instalado correctamente. Póngase en contacto con la autoridad correspondiente de inspección eléctrica o con un electricista si no está seguro de que haya una conexión a tierra adecuada.</b>
Varning!	<b>Denna utrustning måste jordas. Koppla aldrig från jordledningen och använd aldrig utrustningen utan en på lämpligt sätt installerad jordledning. Om det föreligger osäkerhet huruvida lämplig jordning finns skall elektrisk besiktningsauktoritet eller elektriker kontaktas.</b>
Figyelem	<b>A berendezés csak megfelelő védőföldeléssel működtethető. Ne iktassa ki a földelés csatlakozóját, és ne üzemeltesse a berendezést szabályosan felszerelt földelő vezeték nélküli! Ha nem biztos benne, hogy megfelelő földelés áll rendelkezésbe, forduljon a helyi elektromos hatóságokhoz vagy egy villanyszerelőhöz.</b>
Предупреждение	<b>Данное устройство должно быть заземлено. Никогда не отключайте провод заземления и не пользуйтесь оборудованием при отсутствии правильно подключенного провода заземления. За сведениями об имеющихся возможностях заземления обратитесь к соответствующим контролирующими организациям по энергоснабжению или к инженеру-электрику.</b>
警告	<b>此设备必须接地。切勿使接地导体失效，或者在没有正确安装接地导体的情况下操作该设备。如果您不能肯定接地导体是否正常发挥作用，请咨询有关电路检测方面的权威人士或电工。</b>
警告	<b>この装置はアース接続する必要があります。アース導体を破損しないよう注意し、アース導体を正しく取り付けないまま装置を稼働させないでください。アース接続が適正であるかどうか分からぬ場合には、電気検査機関または電気技術者に相談してください。</b>

## Statement 1030—Equipment Installation

**Warning**

**Only trained and qualified personnel should be allowed to install, replace, or service this equipment.** Statement 1030

**Waarschuwing**

**Deze apparatuur mag alleen worden geïnstalleerd, vervangen of hersteld door bevoegd geschoold personeel.**

**Varoitus**

**Tämän laitteen saa asentaa, vaihtaa tai huoltaa ainoastaan koulutettu ja laitteen tunteva henkilökunta.**

**Attention**

**Il est vivement recommandé de confier l'installation, le remplacement et la maintenance de ces équipements à des personnels qualifiés et expérimentés.**

**Warnung**

**Das Installieren, Ersetzen oder Bedienen dieser Ausrüstung sollte nur geschultem, qualifiziertem Personal gestattet werden.**

**Avvertenza**

**Questo apparato può essere installato, sostituito o mantenuto unicamente da un personale competente.**

**Advarsel**

**Bare opplært og kvalifisert personell skal foreta installasjoner, utskiftninger eller service på dette utstyret.**

**Aviso**

**Apenas pessoal treinado e qualificado deve ser autorizado a instalar, substituir ou fazer a revisão deste equipamento.**

**¡Advertencia!**

**Solamente el personal calificado debe instalar, reemplazar o utilizar este equipo.**

**Varning!**

**Endast utbildad och kvalificerad personal bör få tillåtelse att installera, byta ut eller reparera denna utrustning.**

**Figyelem**

**A berendezést csak szakképzett személyek helyezhetik üzembe, cserélhetik és tarthatják karban.**

**Предупреждение**

Установку, замену и обслуживание этого оборудования может осуществлять только специально обученный квалифицированный персонал.

**警告**

只有经过培训且具有资格的人员才能进行此设备的安装、更换和维修。

**警告**

この装置の設置、交換、保守は、訓練を受けた相応の資格のある人が行ってください。

**주의**

교육을 받고 자격을 갖춘 사람만 이 장비를 설치, 교체, 또는 서비스를 수행해야 합니다.

**Aviso**

**Somente uma equipe treinada e qualificada tem permissão para instalar, substituir ou dar manutenção a este equipamento.**

<b>Advarsel</b>	<b>Kun uddannede personer må installere, udskifte komponenter i eller servicere dette udstyr.</b>
تحذير	يسعى للفنيين المختصين فقط بتركيب المعدة أو استبدالها أو إجراء الصيانة عليها.
<b>Upozorenje</b>	<b>Uredaj smije ugradivati, mijenjati i servisirati samo za to obučeno i osposobljeno servisno osoblje.</b>
<b>Upozornění</b>	<b>Instalaci, výměnu nebo opravu tohoto zařízení smějí provádět pouze proškolené a kvalifikované osoby.</b>
Προειδοποίηση	Η τοποθέτηση, η αντικατάσταση και η συντήρηση του εξοπλισμού επιπρέπεται να γίνονται μόνο από καταρτισμένο προσωπικό με τα κατάλληλα προσόντα.
ازهارہ	רק عوبدیم میونگیں و موسمیں رشائیں لہتکیں، لھچلیں، اور لٹپل بے چید جا۔
Опомена	Местењето, заменувањето и сервисирањето на оваа опрема треба да му биде дозволено само на обучен и квалификуван персонал.
<b>Ostrzeżenie</b>	<b>Do instalacji, wymiany i serwisowania tych urządzeń mogą być dopuszczone wyłącznie osoby wykwalifikowane i przeszkolone.</b>
<b>Upozornenie</b>	<b>Inštaláciu, výmenu alebo opravu tohto zariadenia smú vykonávať iba vyškolené a kvalifikované osoby.</b>

## Statement 1033—SELV-IEC 60950 DC Power Supply



### Warning

**Connect the unit only to DC power source that complies with the safety extra-low voltage (SELV) requirements in IEC 60950 based safety standards. Statement 1033**

### Waarschuwing

**Sluit de eenheid alleen maar aan op een gelijkstroombron die voldoet aan de veiligheidsvereisten voor extra-laag voltage (SELV) in de op IEC 60950 gebaseerde veiligheidsnormen.**

### Varoitus

**Liitä laite ainoastaan tasavirtalähteeseen, joka on yhdenmukainen IEC 60950:n suojaattujen erittäisen alhaisen jännitteenteen (SELV) turvavaatimusten kanssa.**

### Attention

**Connectez l'unité uniquement à une alimentation CC compatible avec les recommandations SELV (safety extra-low voltage) des normes de sécurité IEC 60950.**

<b>Warnung</b>	<b>Schließen Sie die Einheit nur an eine Gleichstrom-Stromquelle an, die mit den Safety Extra-Low Voltage (SELV)-Anforderungen in den auf IEC 60950 basierenden Sicherheitsstandards übereinstimmen.</b>
<b>Avvertenza</b>	<b>Collegare l'unità esclusivamente a una presa di corrente continua rispondente ai requisiti SELV (safety extra-low voltage) in base alle norme di sicurezza IEC 60950.</b>
<b>Advarsel</b>	<b>Koble bare enheten til en likestrømsforsyning som er i henhold til kravene for lavspenning (SELV) i IEC 60950-baserte sikkerhetsstandarder.</b>
<b>Aviso</b>	<b>Conecte a unidade apenas à fonte da energia de CC que se encontra em conformidade com os requisitos dos circuitos de segurança de baixa tensão (SELV) constantes dos padrões de segurança baseados no IEC 60950.</b>
<b>¡Advertencia!</b>	<b>Conecte la unidad sólo en una fuente de energía DC que cumpla con los requisitos de voltaje extra bajo (SELV - safety extra-low voltage) en los estándares de seguridad IEC 60950.</b>
<b>Varning!</b>	<b>Anslut enheten endast till en likströmsförsörjningsenhet som uppfyller kraven för SELV (skyddskretsar för mycket låg spänning) i IEC 60950-baserade säkerhetsstandarder.</b>
<b>Figyelem</b>	<b>Csak olyan, váltakozó feszültségű áramforráshoz csatlakoztassa a készüléket, amely megfelel az IEC 60950-es számú biztonsági szabványon alapuló biztonságos törpefeszültségi (SELV) követelményeknek.</b>
<b>Предупреждение</b>	<b>Это устройство можно подключать только к источнику постоянного тока, соответствующему требованиям к цепям безопасного низковольтного напряжения (SELV) стандарта безопасности IEC 60950.</b>
<b>警告</b>	<b>请只将该部件连接到符合基于 IEC 60950 的安全标准中安全特低电压 (SELV) 要求的直流电源上。</b>
<b>警告</b>	<b>この装置は、安全規格に基づくIEC 60950のSafety Extra-Low Voltage (SELV)要件を満たすDC電源にのみ接続してください。</b>

## Statement 1047—Overheating Prevention



**Warning**

**To prevent the system from overheating, do not operate it in an area that exceeds the maximum recommended ambient temperature of:  
55°C (131°F)** Statement 1047

**Waarschuwing**

**Om te voorkomen dat het systeem oververhit raakt, dient u het niet te gebruiken in een ruimte waar de maximaal aanbevolen omgevingstemperatuur van 55°C (131°F) wordt overschreden.**

■

Varoitus	Jotta järjestelmä ei kuumentuisi liikaa, sitä ei saa käyttää liian kuumassa ympäristössä. Suosituksen mukainen käyttölämpötila on enintään <b>55°C (131°F)</b>
Attention	Pour éviter toute surchauffe du système, il est recommandé de maintenir une température ambiante inférieure à <b>55°C (131°F)</b>
Warnung	Um das System vor Überhitzung zu schützen, vermeiden Sie dessen Verwendung in einem Bereich, in dem die Umgebungstemperatur das empfohlene Maximum von <b>55°C (131°F)</b> überschreitet.
Avvertenza	Per evitare che il sistema si surriscaldi, non utilizzatelo dove la temperatura ambiente sia superiore alla temperatura massima raccomandata di <b>55°C (131°F)</b>
Advarsel	For å hindre at systemet blir overopphevet, må det ikke brukes på et sted der temperaturen overstiger den maksimalt anbefalte temperaturen på <b>55°C (131°F)</b>
Aviso	Para evitar o sobreaquecimento do sistema, não o opere em áreas que excedam a temperatura ambiente máxima recomendada de <b>55°C (131°F)</b>
¡Advertencia!	Para impedir que el sistema se recaliente, no lo utilice en zonas en las que la temperatura ambiente llegue a los <b>55°C (131°F)</b>
Varning!	Förhindra att systemet överhettas genom att inte använda det på en plats där den rekommenderade omgivningstemperaturen överstiger <b>55°C (131°F)</b>
Figyelem	A túlmelegedés megelőzése végett ne üzemeltesse a rendszert olyan területen, ahol a hőmérséklet meghaladja a következő maximális ajánlott környezeti hőmérsékletet: <b>55°C (131°F)</b>
Предупреждение	Во избежание перегрева устройства его не следует использовать в помещениях, в которых температура воздуха выше максимальной рекомендованной: <b>55°C (131°F)</b>
警告	为了防止系统过热，不要在超过所建议的最大环境温度下运行该系统： <b>55°C (131°F)</b>
警告	システムが過熱状態にならないようにするために、最大気温が以下の温度を超える場所ではシステムを稼働させないでください。 <b>55°C (131°F)</b>

## Statement 1074—Comply with Local and National Electrical Codes


**Warning**

**Installation of the equipment must comply with local and national electrical codes.** Statement 1074

**Waarschuwing** **Bij installatie van de apparatuur moet worden voldaan aan de lokale en nationale elektriciteitsvoorschriften.**

**Varoitus** **Laitteisto tulee asentaa paikallisten ja kansallisten sähkömääräysten mukaisesti.**

**Attention** **L'équipement doit être installé conformément aux normes électriques nationales et locales.**

**Warnung** **Die Installation der Geräte muss den Sicherheitsstandards entsprechen.**

**Avvertenza** **L'installazione dell'impianto deve essere conforme ai codici elettrici locali e nazionali.**

**Advarsel** **Installasjon av utstyret må samsvare med lokale og nasjonale elektrisitetsforskrifter.**

**Aviso** **A instalação do equipamento tem de estar em conformidade com os códigos eléctricos locais e nacionais.**

**¡Advertencia!** **La instalación del equipo debe cumplir con las normativas de electricidad locales y nacionales.**

**Varning!** **Installation av utrustningen måste ske i enlighet med gällande elinstallationsföreskrifter.**

**Figyelem** **A berendezés üzembe helyezését a helyi és a nemzeti elektromossági előírások figyelembetével kell elvégezni.**

**Предупреждение** **Установка оборудования должна соответствовать местным и национальным электротехническим нормам.**

**警告** **设备安装必须符合本地与本国电气法规。**

**警告** **機器の取り付けは地域および国内の電気工事規定に遵守する必要があります。**

