

Installation Manual

P/N 20003402, Rev. D

April 2008

Micro Motion®

Model 2400S Transmitters

Installation Manual

Micro Motion®



EMERSON
Process Management

©2008, Micro Motion, Inc. All rights reserved. ELITE and ProLink are registered trademarks, and MVD and MVD Direct Connect are trademarks of Micro Motion, Inc., Boulder, Colorado. Micro Motion is a registered trade name of Micro Motion, Inc., Boulder, Colorado. The Micro Motion and Emerson logos are trademarks and service marks of Emerson Electric Co. All other trademarks are property of their respective owners.

Contents

Chapter 1	Before You Begin	1
1.1	Overview	1
1.2	Safety	1
1.3	Flowmeter components	1
1.4	Transmitter installation overview	2
1.5	Flowmeter documentation	2
1.6	Customer service	3
Chapter 2	Transmitter Orientation and Power Supply	5
2.1	Overview	5
2.2	Moisture protection	5
2.3	Rotating the transmitter on the sensor (optional)	5
2.4	Rotating the user interface module on the transmitter (optional)	6
2.5	Power supply requirements	7
2.5.1	DC power requirements for Model 2400S Analog and PROFIBUS-DP transmitters	8
2.6	Wiring the power supply	8
Chapter 3	I/O Wiring – Model 2400S Analog Transmitters	11
3.1	Overview	11
3.2	Moisture protection	11
3.3	I/O options	11
3.4	Wiring the outputs	12
3.4.1	mA output wiring	12
3.4.2	Frequency output wiring	16
3.4.3	Discrete output wiring	17
3.4.4	Discrete input wiring	19
Chapter 4	I/O Wiring – Model 2400S PROFIBUS-DP and DeviceNet Transmitters	21
4.1	Overview	21
4.2	Moisture protection	21
4.3	I/O wiring for Model 2400S PROFIBUS-DP transmitters	21
4.3.1	Enabling internal termination	22
4.4	I/O wiring for Model 2400S DeviceNet transmitters	23

Contents

Appendix A Dimensions and Specifications	25
A.1 Dimensions	25
A.2 Physical specifications	27
A.3 Power supply – Models 2400S Analog and PROFIBUS-DP	27
A.4 Electrical connections	28
A.5 User interface	29
A.6 Input/output signals	31
A.7 Digital communications	32
A.8 Host interface	32
A.9 Environmental limits	33
A.10 Environmental effects	33
A.11 Hazardous area classifications	33
Appendix B Return Policy	35
B.1 New and unused equipment	35
B.2 Used equipment	35
Index	37

Chapter 1

Before You Begin

1.1 Overview

This chapter provides an orientation to the use of this manual. This manual describes the procedures required to install the following transmitters:

- Model 2400S transmitter with analog outputs
- Model 2400S transmitter with PROFIBUS-DP
- Model 2400S transmitter with DeviceNet™

1.2 Safety

Safety messages are provided throughout this manual to protect personnel and equipment. Read each safety message carefully before proceeding to the next step.



Improper installation in a hazardous area can cause an explosion. When installing in a hazardous area, refer to Micro Motion approvals instructions, shipped with the product or available from the Micro Motion web site.



Hazardous voltage can cause severe injury or death. Make sure power is shut off before installing the transmitter.



Follow all instructions. Improper installation could cause measurement error or flowmeter failure.


1.3 Flowmeter components

The Model 2400S transmitter is mounted on a Micro Motion sensor. The transmitter and sensor together comprise the Micro Motion flowmeter.

Figure 1-1 provides a view of the Model 2400S transmitter mounted on a sensor.

Before You Begin

Figure 1-1 Model 2400S transmitter



1.4 Transmitter installation overview

The Model 2400S transmitter component is mounted integrally with the sensor and grounded via the sensor. To install and ground the sensor, see the sensor documentation.

Additional transmitter installation steps are documented in this manual:

- Rotate the transmitter on the sensor (optional) – see Chapter 2
- Rotate the user interface module on the transmitter (optional) – see Chapter 2
- Wire and ground the transmitter's power supply – see Chapter 2
- Wire the transmitter I/O:
 - For the Model 2400S Analog transmitter, see Chapter 3
 - For the Model 2400S PROFIBUS-DP and DeviceNet transmitters, see Chapter 4

1.5 Flowmeter documentation

Table 1-1 lists documentation sources for other required information.

Table 1-1 Flowmeter documentation resources

Topic	Document
Sensor installation	Sensor documentation shipped with sensor
Hazardous area installation	See the approval documentation shipped with the transmitter, or download the appropriate documentation from the Micro Motion web site (www.micromotion.com)
Transmitter configuration, flowmeter startup and use, and flowmeter troubleshooting	<ul style="list-style-type: none">• <i>Micro Motion® Model 2400S Transmitters with Analog Outputs: Configuration and Use Manual</i>• <i>Micro Motion® Model 2400S Transmitters with PROFIBUS-DP: Configuration and Use Manual</i>• <i>Micro Motion® Model 2400S Transmitters with DeviceNet™: Configuration and Use Manual</i>

Before You Begin

1.6 Customer service

For technical assistance, phone the Micro Motion Customer Service department:

- In the U.S.A., phone 800-522-MASS (800-522-6277) (toll free)
- In Canada and Latin America, phone +1 303-527-5200 (U.S.A.)
- In Asia:
 - In Japan, phone 3 5769-6803
 - In other locations, phone +65 6777-8211 (Singapore)
- In Europe:
 - In the U.K., phone 0870 240 1978 (toll-free)
 - In other locations, phone +31 (0) 318 495 555 (The Netherlands)

Customers outside the U.S.A. can also email Micro Motion customer service at *International.MMISupport@Emerson.com*.

Chapter 2

Transmitter Orientation and Power Supply

2.1 Overview

This chapter describes:

- Rotating the transmitter on the sensor (optional)
- Rotating the user interface module on the transmitter (optional)
- Power supply requirements and wiring

2.2 Moisture protection

When rotating or wiring the transmitter, guard against condensation or excessive moisture inside the transmitter housing. Be sure that the conduit openings are completely sealed after all installation and wiring procedures have been performed.



Improperly sealed housings can expose electronics to moisture, which can cause measurement error or flowmeter failure. Install the meter so that the conduit openings do not point upward, and install drip legs in conduit or cable. Inspect and grease all gaskets and O-rings. Fully close and tighten all housing covers and conduit openings.

2.3 Rotating the transmitter on the sensor (optional)


For easier access to the user interface or the wiring terminals, the transmitter can be rotated on the sensor in 45° increments, for eight different orientations.

To rotate the transmitter on the sensor:

1. Referring to Figure 2-1, unscrew the clamp that holds the transmitter to the feedthrough.
2. Gently lift the transmitter on the feedthrough until it disengages from the notches on the feedthrough. You will not be able to remove the transmitter completely.
3. Rotate the transmitter to the desired position.
4. Lower the transmitter, sliding it onto the notches on the feedthrough.
5. Replace the clamp and tighten the screw.

Transmitter Orientation and Power Supply

Figure 2-1 Rotating the transmitter on the sensor



Do not rotate the housing more than 360°. Excessive rotation can damage the wiring and cause measurement error or flowmeter failure.

2.4 Rotating the user interface module on the transmitter (optional)

For easier access, the user interface module (whether or not the transmitter has an LCD display) can be rotated on the transmitter up to 360° in 90° increments.

To rotate the user interface module on the transmitter:

1. Remove power from the unit.




Removing the transmitter housing cover in a hazardous area while the transmitter is powered up can cause an explosion. Shut off power to the transmitter before removing the housing cover in a hazardous area.

2. Referring to Figure 2-2, remove the transmitter housing cover and user interface module:
 - a. Loosen the four transmitter housing cover screws.
 - b. Remove the transmitter housing cover.
 - c. Loosen the two user interface screws.
 - d. Gently lift the user interface module, disengaging it from the user interface connector on the transmitter.
3. On the back of the user interface module, four user interface connectors are provided. Rotate the user interface module to the desired position and plug it into the user interface connector on the transmitter. (See Figure 2-3 for another view of the user interface connector on the transmitter.)
4. Tighten the user interface screws.
5. Replace the transmitter housing cover and tighten the transmitter housing cover screws.
6. Restore power to the transmitter if required.

Transmitter Orientation and Power Supply

Figure 2-2 Rotating the user interface module on the transmitter



2.5 Power supply requirements

Model 2400S Analog and Model 2400S PROFIBUS-DP transmitters can accept either AC or DC power. The transmitter automatically recognizes the source voltage. Power supply requirements are:

- AC power:
 - 85–265 VAC
 - 50/60 Hz
 - 4 watts typical, 7 watts maximum
- DC power:
 - 18–100 VDC
 - 4 watts typical, 7 watts maximum

The Model 2400S DeviceNet transmitter is powered from the DeviceNet network per the DeviceNet specification. There is no need to connect separate power-supply wiring for the Model 2400S DeviceNet transmitter. Skip to Chapter 4.

Transmitter Orientation and Power Supply

2.5.1 DC power requirements for Model 2400S Analog and PROFIBUS-DP transmitters

If you are using DC power with a Model 2400S Analog or PROFIBUS-DP transmitter, the following requirements apply:

- At startup, the transmitter power source must provide a minimum of 1 A of short-term current per transmitter.
- Length and conductor diameter of the power cable must be sized to provide 18 VDC minimum at the power terminals, at a load current of 0.5 A. (This assumes a single transmitter per cable. Connecting multiple transmitters to a single cable should generally be avoided.) To size the cable, refer to Table 2-1 and use the following formula as a guideline:

$$\text{MinimumSupplyVoltage} = 18\text{V} + (\text{CableResistance} \times \text{CableLength} \times 0.5\text{A})$$

Table 2-1 Typical power cable resistances at 68 °F (20 °C)

Gauge	Resistance ⁽¹⁾
14 AWG	0.0050 Ω/foot
16 AWG	0.0080 Ω/foot
18 AWG	0.0128 Ω/foot
20 AWG	0.0204 Ω/foot
2,5 mm ²	0.0136 Ω/meter
1,5 mm ²	0.0228 Ω/meter
1 mm ²	0.0340 Ω/meter
0,75 mm ²	0.0460 Ω/meter
0,5 mm ²	0.0680 Ω/meter

(1) These values include the resistance of both high and low conductors in a cable.

Example

The transmitter is mounted 350 feet from a DC power supply. If you want to use 16 AWG cable, calculate the required voltage at the DC power supply as follows:

$$\text{MinimumSupplyVoltage} = 18\text{V} + (\text{CableResistance} \times \text{CableLength} \times 0.5\text{A})$$

$$\text{MinimumSupplyVoltage} = 18\text{V} + (0.0080 \text{ Ohms/ft} \times 350 \text{ ft} \times 0.5\text{A})$$

$$\text{MinimumSupplyVoltage} = 19.4\text{V}$$

2.6 Wiring the power supply

Note: This procedure is required only for Model 2400S Analog and PROFIBUS-DP transmitters.


To wire the power supply:

1. Remove the transmitter housing cover and user interface module as described in Section 2.4.
2. Unscrew the warning flap screw and raise the warning flap. Figure 2-3 shows the warning flap in the open position.
3. Connect the power supply wires to terminals 9 and 10, as shown in Figure 2-3.
4. Ground the power supply to the transmitter's internal grounding screw, shown in Figure 2-3.
5. Lower the warning flap and tighten the warning flap screw.

Transmitter Orientation and Power Supply

A user-supplied switch may be installed in the power supply line. For compliance with low-voltage directive 2006/95/EC (European installations), a switch in close proximity to the transmitter is required.

Figure 2-3 Wiring the transmitter power supply



Chapter 3

I/O Wiring – Model 2400S Analog Transmitters

3.1 Overview

This chapter describes how to wire I/O for Model 2400S Analog transmitters.

Note: To wire I/O for Model 2400S PROFIBUS-DP and DeviceNet transmitters, see Chapter 4.

It is the user's responsibility to verify that the specific installation meets the local and national safety requirements and electrical codes.

3.2 Moisture protection

When rotating or wiring the transmitter, guard against condensation or excessive moisture inside the transmitter housing. Be sure that the conduit openings are completely sealed after all installation and wiring procedures have been performed.



Improperly sealed housings can expose electronics to moisture, which can cause measurement error or flowmeter failure. Install the meter so that the conduit openings do not point upward, and install drip legs in conduit or cable. Inspect and grease all gaskets and O-rings. Fully close and tighten all housing covers and conduit openings.

3.3 I/O options

Table 3-1 lists the options for the transmitter's two I/O channels. Before wiring Channel B, ensure that you know how it will be configured. For information on configuring Channel B for function and power, see the manual entitled *Micro Motion® Model 2400S Transmitters with Analog Outputs: Configuration and Use Manual*.

Table 3-1 Terminal configuration options

Channel	Terminals	Function	Power	Comm
A	1 & 2	mA	Internal ⁽¹⁾ or external	HART/Bell 202
B	3 & 4	Frequency ⁽¹⁾	Internal ⁽¹⁾ or external	None
		Discrete output	Internal or external	None
		Discrete input	Internal or external	None

(1) Factory default.

3.4 Wiring the outputs



Hazardous voltage can cause severe injury or death. Shut off power to the transmitter before wiring the transmitter outputs.



A transmitter that has been improperly wired or installed in a hazardous area could cause an explosion. Make sure the transmitter is wired to meet or exceed local code requirements. Install the transmitter in an environment that complies with the classification tag on the transmitter.

To wire the outputs:

1. Remove the transmitter housing cover and user interface module. See Section 2.4 for instructions.
2. Wire the outputs according to the appropriate wiring diagram:
 - For mA output wiring diagrams, see Section 3.4.1.
 - For frequency output wiring diagrams, see Section 3.4.2.
 - For discrete output wiring diagrams, see Section 3.4.3.
 - For a discrete input wiring diagram, see Section 3.4.4.
3. Replace the user interface module and transmitter housing cover.

Note: It is not necessary to open the power compartment to wire the outputs. Do not open the power compartment unless you are also wiring the power supply.

3.4.1 mA output wiring

The wiring diagrams in this section are examples of proper wiring for the Model 2400S mA output. The following options are shown:

- Internal power:
 - Basic mA output wiring – Figure 3-1
 - HART/analog single-loop wiring – Figure 3-2
- External power:
 - Basic mA output wiring – Figure 3-3
 - HART/analog single-loop wiring – Figure 3-4
- HART multidrop wiring, internal or external power – Figure 3-6

Note: If you plan to configure the transmitter to poll an external temperature or pressure device, you must wire the mA output to support HART communications. You may use either HART/analog single-loop wiring or HART multidrop wiring.

I/O Wiring – Model 2400S Analog Transmitters

Figure 3-1 Basic mA output wiring – Internal power






Figure 3-2 HART/analog single-loop wiring – Internal power




I/O Wiring – Model 2400S Analog Transmitters

Figure 3-3 Basic mA output wiring – External power



Excessive current will damage the transmitter. Do not exceed 30 VDC input. Terminal current must be less than 500 mA.

Figure 3-4 HART/analog single-loop wiring – External power



Note: See Figure 3-5 for voltage and resistance values.

I/O Wiring – Model 2400S Analog Transmitters

Figure 3-5 Required external voltage versus mA load resistance

If communicating with HART, a minimum of 250 Ohms is required.





Figure 3-6 HART multidrop wiring – Internal or external power



Note: For optimum HART communication, make sure the output loop is single-point-grounded to an instrument-grade ground.

3.4.2 Frequency output wiring

Frequency output wiring depends on whether you will use internal or external power. The following diagrams are examples of proper wiring for these configurations:

- Internal power – Figure 3-7
- External power – Figure 3-8

Figure 3-7 Frequency output wiring – Internal power





Figure 3-8 Frequency output wiring – External power



Excessive current will damage the transmitter. Do not exceed 30 VDC input. Terminal current must be less than 500 mA.

I/O Wiring – Model 2400S Analog Transmitters

3.4.3 Discrete output wiring

Discrete output wiring depends on whether you will use internal or external power. The following diagrams are examples of proper wiring for these configurations:

- Internal power – Figure 3-9
- External power – Figure 3-10

Figure 3-9 Discrete output wiring – Internal power





Figure 3-10 Discrete output wiring – External power



Excessive current will damage the transmitter. Do not exceed 30 VDC input. Terminal current must be less than 500 mA.

I/O Wiring – Model 2400S Analog Transmitters

Figure 3-11 Output voltage vs. load resistance – Internal power





Figure 3-12 Recommended pull-up resistor versus supply voltage – External power



Note: When using a discrete output to drive a relay, choose external pull-up to limit current to less than 500 mA.

I/O Wiring – Model 2400S Analog Transmitters

3.4.4 Discrete input wiring

Discrete input wiring depends on whether you will use internal or external power. The following diagrams are examples of proper wiring for these configurations:

- Internal power – Figure 3-13
- External power – Figure 3-14

If external power is configured, power may be supplied by a PLC or other device, or by direct DC input. See Table 3-2 for input voltage ranges.

Table 3-2 Input voltage ranges for external power

VDC	Range
3–30	High level
0–0.8	Low level
0.8–3	Undefined

Figure 3-13 Discrete input wiring – Internal power





Figure 3-14 Discrete input wiring – External power



Chapter 4

I/O Wiring – Model 2400S PROFIBUS-DP and DeviceNet Transmitters

4.1 Overview

This chapter describes how to wire I/O for Model 2400S PROFIBUS-DP and DeviceNet transmitters.

Note: To wire I/O for Model 2400S Analog transmitters, see Chapter 3.

It is the user's responsibility to verify that the specific installation meets the local and national safety requirements and electrical codes.

4.2 Moisture protection

When rotating or wiring the transmitter, guard against condensation or excessive moisture inside the transmitter housing. Be sure that the conduit openings are completely sealed after all installation and wiring procedures have been performed.



Improperly sealed housings can expose electronics to moisture, which can cause measurement error or flowmeter failure. Install the meter so that the conduit openings do not point upward, and install drip legs in conduit or cable. Inspect and grease all gaskets and O-rings. Fully close and tighten all housing covers and conduit openings.

4.3 I/O wiring for Model 2400S PROFIBUS-DP transmitters

To connect the I/O wiring for a 2400S PROFIBUS-DP transmitter:

1. Remove the user interface cover and user interface module. See Section 2.4 for instructions.
2. Wire the transmitter to the PROFIBUS-DP segment according to the diagram in Figure 4-1. Follow all local safety regulations.
3. Replace the user interface module and user interface cover.

Note: It is not necessary to open the power compartment to wire the outputs. Do not open the power compartment unless you are also wiring the power supply.

Note: The PROFIBUS cable shield is required to be grounded at both ends. At the 2400S, ground the cable shield in an appropriate cable gland. If an optional PROFIBUS-DP Eurofast M12 connector is used, the cable shield is grounded via the threads of the connector.




Hazardous voltage can cause severe injury or death. Keep the power supply compartment closed while wiring the transmitter outputs, or shut off power to the transmitter.



A transmitter that has been improperly wired or installed in a hazardous area could cause an explosion. Make sure the transmitter is wired to meet or exceed local code requirements. Install the transmitter in an environment that complies with the classification tag on the transmitter.

Figure 4-1 Model 2400S PROFIBUS-DP I/O wiring


Note: The Model 2400S PROFIBUS-DP transmitter does not have terminals for termination wiring. An external terminator is not required. The transmitter has an internal terminator. There is a switch on the user interface for enabling internal termination. See Section 4.3.1.



4.3.1 Enabling internal termination

Model 2400S PROFIBUS-DP transmitters have a switch on the user interface module to enable internal termination impedance. Refer to Figure 4-2.

Figure 4-2 Model 2400S PROFIBUS-DP internal termination impedance switch



I/O Wiring – Model 2400S PROFIBUS-DP and DeviceNet Transmitters

4.4 I/O wiring for Model 2400S DeviceNet transmitters


Connect the transmitter to the DeviceNet segment according to the diagram in Figure 4-3. The transmitter is shipped with a DeviceNet male sealed Micro Connector (Eurofast) that has been preinstalled and wired according to the DeviceNet specification.

Follow all local safety regulations.



A transmitter that has been improperly wired or installed in a hazardous area could cause an explosion. Make sure the transmitter is wired to meet or exceed local code requirements. Install the transmitter in an environment that complies with the classification tag on the transmitter.

Figure 4-3 Model 2400S DeviceNet I/O wiring



Attach a 5-pin female
Eurofast connector here



Appendix A

Dimensions and Specifications

A.1 Dimensions

Figure A-1 shows the dimensions of the Model 2400S transmitter. For sensor dimensions, see the sensor data sheet.

Figure A-1 Transmitter housing dimensions – Painted aluminum housing





Dimensions and Specifications

Figure A-2 Transmitter housing dimensions – Stainless steel housing

Dimensions in *inches*
(mm)


Note: Cover screws
must be torqued to a
minimum of 16 in-lbs
(1.8 N-m)



Dimensions and Specifications

A.2 Physical specifications

Housing	Polyurethane-painted aluminum Optional: 304L stainless steel with surface finish of 32 RA
Weight	Transmitter is mounted integrally with sensor. For weight of flowmeter, see product data sheet for sensor.
Mounting and cabling	Model 2400S transmitters are mounted integrally with sensor. The transmitter can be rotated on the sensor up to 360° in 45° increments. Cable entry holes are available with 1/2-NPT and M20 options (refer to the 2400S Product Data Sheet for ordering codes).



A.3 Power supply – Models 2400S Analog and PROFIBUS-DP

Self-switching AC/DC input, automatically recognizes supply voltage.
Complies with low voltage directive 2006/95/EC per EN 61010-1 (IEC 61010-1) with amendment 2.
Installation (Overvoltage) Category II, Pollution Degree 2.

AC	<ul style="list-style-type: none"> • 85–265 VAC • 50/60 Hz • 4 watts typical, 7 watts maximum
DC	<ul style="list-style-type: none"> • 18–100 VDC • 4 watts typical, 7 watts maximum
Fuse	IEC 127-1.25 fuse, slow blow

Dimensions and Specifications

A.4 Electrical connections


Model 2400S Analog	
Input and output connections	Two pairs of wiring terminals for transmitter inputs/outputs. Screw terminals accept solid or stranded conductors, 26 to 14 AWG (0,14 to 2,5 mm ²).
Power connections	One pair of wiring terminals accepts AC or DC power. One internal ground lug for power supply ground wiring. Screw terminals accept solid or stranded conductors, 26 to 14 AWG (0,14 to 2,5 mm ²).
Digital comm maintenance connections	Two clips for temporary connection to the service port. Two clips for temporary connection to HART/Bell 202 terminals.
Model 2400S PROFIBUS-DP	
PROFIBUS-DP segment	One pair of wiring terminals for connection to PROFIBUS-DP segment. Connection type: <ul style="list-style-type: none">• Screw terminals accept solid or stranded conductors, 26 to 14 AWG (0,14 to 2,5 mm²).• Five-pin PROFIBUS-DP M12 (Eurofast) female connector (optional).
Power connections	One pair of wiring terminals accepts AC or DC power. One internal ground lug for power supply ground wiring. Screw terminals accept solid or stranded conductors, 26 to 14 AWG (0,14 to 2,5 mm ²).
Digital comm maintenance connections	Two clips for temporary connection to the service port.
Model 2400S DeviceNet	
DeviceNet segment	One pre-installed male 5-pin Eurofast connector for I/O and power supply wiring
Digital comm maintenance connections	Two clips for temporary connection to the service port.

Dimensions and Specifications


A.5 User interface

Model 2400S Analog

With display




Without display




Model 2400S PROFIBUS-DP

With display




Without display




Model 2400S DeviceNet

With display



Without display



Dimensions and Specifications

Interface functions

All models with or without display

- Suitable for hazardous area installation.
- User interface module can rotate 360° on the transmitter in 90° increments.
- Three-color status LED on user interface module indicates flowmeter condition at a glance, using a solid green, yellow, or red light. Zero in progress is indicated by a flashing yellow light.
- Two clips for service port connections (requires removing transmitter housing cover).

Model 2400S Analog with or without display

- Two clips for HART/Bell 202 connections (requires removing transmitter housing cover).
- HART security switch (requires removing transmitter housing cover).

Model 2400S DeviceNet, with or without display

- Three rotary switches for selecting network address and baud rate (network address and baud rate are also software selectable).
- Module and network LEDs to indicate DeviceNet status.

Model 2400S PROFIBUS-DP, with or without display

- Three rotary switches for selecting network address (network address is also software selectable).
- DIP switch for enabling internal termination resistor.
- Address and network LEDs that indicate PROFIBUS-DP status.

All models with display

- Depending on purchase option, transmitter housing cover has glass or plastic lens.
- User interface module includes LCD panel. LCD line 1 displays process variable; line 2 displays engineering unit of measure.
- Display update rate is user-configurable: 1 to 10 seconds at 1-second increments.
- Display backlighting may be adjusted or turned off.
- Operator access to transmitter menus is provided via optical switches that are operated through the lens. LED indicators show when a “button” has been pressed.
- Infrared port allows access to service port from IrDA device (e.g., PDA running Pocket ProLink) without removing transmitter housing cover.

All models without display

- Transmitter housing cover is all metal (no lens).
- Access to user interface requires removing transmitter housing cover.
- Zero button allows flowmeter zero from field (requires removing transmitter housing cover).
- No IrDA.

Dimensions and Specifications

A.6 Input/output signals

Model 2400S Analog

Channel A	<p>One active or passive 4–20 mA output</p> <ul style="list-style-type: none"> • Not intrinsically safe • Isolated to ± 50 VDC from all other outputs and earth ground • Maximum load limit: 820 ohms • Can report mass flow, volume flow, density, temperature, or drive gain • Output is linear with process from 3.8 to 20.5 mA, per NAMUR NE43 (June 1994)
Channel B (configurable)	<p>One active or passive frequency/pulse output</p> <ul style="list-style-type: none"> • Not intrinsically safe • Can report mass flow or volume flow, which can be used to indicate flow rate or total • Scalable to 10,000 Hz • Power: <ul style="list-style-type: none"> - Internal (active): +24 VDC $\pm 3\%$ with a 2.2 kohm internal pull-up resistor - External (passive): +30 VDC maximum, +24 VDC typical • Output is linear with flow rate to 12,500 Hz
	<p>One active or passive discrete output</p> <ul style="list-style-type: none"> • Not intrinsically safe • Can report five discrete events, flow switch, forward/reverse flow, calibration in progress, or fault • Power: <ul style="list-style-type: none"> - Internal (active): +24 VDC $\pm 3\%$ with a 2.2 kohm internal pull-up resistor - External (passive): +30 VDC maximum, +24 VDC typical • Maximum sink capability: 500 mA
	<p>One active or passive discrete input</p> <ul style="list-style-type: none"> • Not intrinsically safe • Power: <ul style="list-style-type: none"> - Internal (active): +24 VDC, 10 mA maximum source current - External (passive): +3 to 30 VDC maximum • Can reset all totals, reset mass total, reset volume total, start/stop totalizers, or start sensor zero
Model 2400S PROFIBUS-DP	Digital 2-way PROFIBUS-DP signal. Certified by PNO.
Model 2400S DeviceNet	Digital 2-way DeviceNet signal. Certified by ODVA.

Dimensions and Specifications

A.7 Digital communications

All versions

Service port	One service port for temporary connections (requires removing transmitter housing cover) Uses RS-485 Modbus signal, 38.4 kBaud, one stop bit, no parity Address: 111 (not configurable)
Wireless	If transmitter has display, service port can be accessed with IrDA device (for example, a PDA running Pocket ProLink) without removing transmitter housing cover.

Model 2400S Analog

HART/Bell 202	HART signal is superimposed on the primary milliamp output, and is available for host system interface: <ul style="list-style-type: none">• Frequency: 1.2 and 2.2 kHz• Amplitude: to 1.0 mA• 1200 baud, one stop bit, odd parity• Address: 0 (default), configurable• Requires 250 to 600 Ω resistance
---------------	---

Model 2400S PROFIBUS-DP

PROFIBUS-DP	Digital 2-way communication protocol <ul style="list-style-type: none">• Automatically recognizes network baud rate• Address selectable by 3 rotary switches, or software selectable
-------------	---

Model 2400S DeviceNet

DeviceNet	Digital 2-way communication protocol <ul style="list-style-type: none">• Address and baud rate selectable by 3 rotary switches (2 to select address, 1 to select baud rate), or software selectable
-----------	---

A.8 Host interface

Model 2400S Analog	ProLink® II v2.5 or later from Micro Motion supports full device configuration. HART DD file supports all functionality.
--------------------	---

Model 2400S PROFIBUS-DP	ProLink II v2.5 or later from Micro Motion supports full device configuration. <ul style="list-style-type: none">• GSD file conforming to the PROFIBUS-DP specification:<ul style="list-style-type: none">- Provides Profibus Class 1 Master functions- Enables reading and controlling all process data• DD file conforming to Profibus EDDL specification<ul style="list-style-type: none">- Provides Profibus Class 2 Master functions- Enables device configuration- Supports Siemens Simatic PDM
-------------------------	---

Model 2400S DeviceNet	ProLink II v2.5 or later from Micro Motion supports full device configuration. <ul style="list-style-type: none">• EDS file conforming to the DeviceNet specification:<ul style="list-style-type: none">- Enables device configuration
-----------------------	--

Dimensions and Specifications

A.9 Environmental limits

Ambient temperature limits	Operating and storage: -40 to +140 °F (-40 to +60 °C) Below -4 °F (-20 °C), LCD responsiveness decreases and LCD may become difficult to read. Above 131 °F (55 °C), some darkening of the LCD panel might occur. ATEX requires limiting ambient temperature to below 131 °F (55 °C).
Humidity limits	5 to 95% relative humidity, non-condensing at 140 °F (60 °C)
Vibration limits	Meets IEC68.2.6, endurance sweep, 5 to 2000 Hz, 50 sweep cycles at 1.0 g

A.10 Environmental effects

All models

EMI effects	Complies with electromagnetic compatibility directive 2004/108/EC per EN 61326 industrial Conforms to NAMUR NE21 Version: 10.02.2004
-------------	---

Model 2400S Analog only

Ambient temperature effect	On mA output: ±0.005% of span per °C
----------------------------	--------------------------------------

A.11 Hazardous area classifications

All models

CSA ⁽¹⁾ C-US		Class I Division 2 Groups A, B, C, D Class II Division 2 Groups F and G
ATEX ⁽²⁾	Analog or PROFIBUS-DP	 II 3G EEx n A C II T5 II 3D IP66/IP67 T70°C
	DeviceNet	 II 3G Ex nA II T5 II 3D IP66/IP67 T70°C

(1) CSA is a Canadian approvals agency that provides approvals accepted both in the U.S.A. and in Canada.

(2) ATEX is a European directive.

Appendix B

Return Policy

Micro Motion procedures must be followed when returning equipment. These procedures ensure legal compliance with government transportation agencies and help provide a safe working environment for Micro Motion employees. Failure to follow Micro Motion procedures will result in your equipment being refused delivery.

Information on return procedures and forms is available on our web support system at www.micromotion.com, or by phoning the Micro Motion Customer Service department.

B.1 New and unused equipment

Only equipment that has not been removed from the original shipping package will be considered new and unused. New and unused equipment requires a completed Return Materials Authorization form.

B.2 Used equipment

All equipment that is not classified as new and unused is considered used. This equipment must be completely decontaminated and cleaned before being returned.

Used equipment must be accompanied by a completed Return Materials Authorization form and a Decontamination Statement for all process fluids that have been in contact with the equipment. If a Decontamination Statement cannot be completed (e.g., for food-grade process fluids), you must include a statement certifying decontamination and documenting all foreign substances that have come in contact with the equipment.

Index

C

Channels
configuration options 11, 21, 23

D

DeviceNet 21, 23

Dimensions 25

Discrete input wiring 19

Discrete output wiring 17
external power 17
internal power 17

Documentation 2

F

Flowmeter

components 1
documentation 2

Frequency output wiring 16

external power 16
internal power 16

I

I/O

analog wiring 11
configuration options 11, 21, 23
DeviceNet wiring 21, 23
PROFIBUS-DP wiring 21

Impedance switch 22

Installation

I/O wiring 11, 21, 23
moisture protection 5
overview 2
power supply requirements 7
rotating transmitter on sensor 5
rotating user interface module on transmitter 6
transmitter dimensions 25

M

mA output wiring 12

external power 14

HART multidrop 15

HART single-loop

external power 14
internal power 13

internal power 13

Moisture protection 5, 11, 21

P

Power supply
requirements 7
wiring 8

PROFIBUS-DP 21
impedance switch 22

R

Return policy 35

S

Safety messages 1

Sensor 1

Specifications 25

T

Transmitter 1
dimensions 25
documentation 2
I/O options 1, 11, 21, 23
I/O wiring 11, 21
installation overview 2
orientation 5
rotating on sensor 5
rotating user interface module 6
specifications 25

U

User interface module
rotating 6

W

Wiring 11, 21
analog 11
DeviceNet 23
discrete input 19
discrete output 17
external power 17
internal power 17
frequency output 16
external power 16
internal power 16
I/O options 1, 11, 23
mA output 12
external power 14
HART multidrop 15

Index

HART single-loop, external power 14
HART single-loop, internal power 13
internal power 13
moisture protection 11, 21
power supply wiring 8
PROFIBUS-DP 21

©2008, Micro Motion, Inc. All rights reserved. P/N 20003402, Rev. D



For the latest Micro Motion product specifications, view the
PRODUCTS section of our web site at www.micromotion.com

Micro Motion Inc. USA

Worldwide Headquarters

7070 Winchester Circle
Boulder, Colorado 80301

T +1 303-527-5200
+1 800-522-6277

F +1 303-530-8459

Micro Motion Europe

Emerson Process Management

Neonstraat 1

6718 WX Ede

The Netherlands

T +31 (0) 318 495 555
F +31 (0) 318 495 556

Micro Motion Asia

Emerson Process Management

1 Pandan Crescent

Singapore 128461

Republic of Singapore

T +65 6777-8211
F +65 6770-8003

Micro Motion United Kingdom

Emerson Process Management Limited

Horsfield Way

Bredbury Industrial Estate

Stockport SK6 2SU U.K.

T +44 0870 240 1978
F +44 0800 966 181

Micro Motion Japan

Emerson Process Management

1-2-5, Higashi Shinagawa

Shinagawa-ku

Tokyo 140-0002 Japan

T +81 3 5769-6803
F +81 3 5769-6844

Micro Motion®

recycled paper

EMERSON™
Process Management