



Freestyle 1050

Combined Cordless Telephone & Digital Answering Machine



User Guide

This equipment is not designed for making emergency telephone calls when the power fails. Alternative arrangements should be made for access to emergency services.


**Please open this page for an 'at a glance'
guide to your Freestyle 1050.**




**Please open this page for an 'at a glance'
guide to your Freestyle 1050.**



At a glance





1471

To set the 1471 call return feature on or off.
See page 18

Volume

Adjusts the loudspeaker volume.
See page 14

Quickdial reference label

Lists the names of up to 10 numbers stored in the quickdial memory.
See page 10

Page

Lets you page the handset. (Useful in finding a misplaced handset.)
See page 11

Skip

Switches message alert On/Off. Lets you skip forward and backwards through your messages. Sets Answer delay.
See page 14, 16, 17

Answer On/Off/Stop

Switches the answering machine on and off, and stops playback of messages when in Answer Machine mode.
See page 13

Battery charging contacts

Base unit aerial

Extend fully for best reception.
See page 7

OGM

Used when recording and playing back your own outgoing message.
See page 13

VIP

Automatically alerts you to your most important callers.
See page 19

Delete

Deletes recorded messages and memos.
See page 13, 16

LEDs

CHARGING – comes on when the handset battery is being charged.

IN USE – comes on when the line is in use.


BATT LOW – comes on when the answering machine back-up battery needs replacing.

Microphone

For recording your OGM and memo messages.

Play/Memo/Pause

Used when playing back or pausing messages and when recording memos.
See pages 15, 20



In this guide

<i>At a glance</i>	<i>1</i>
<i>Introduction</i>	<i>4</i>
<i>Setting up</i>	<i>5</i>
<i>Using your Freestyle 1050 telephone</i>	<i>8</i>
<i>Making and receiving calls</i>	<i>8</i>
<i>Using the memory to store and dial numbers</i>	<i>9</i>
<i>Using your Freestyle 1050 answering machine</i>	<i>12</i>
<i>Outgoing messages</i>	<i>12</i>
<i>Message display</i>	<i>12</i>
<i>Incoming messages</i>	<i>14</i>
<i>Answer delay</i>	<i>17</i>
<i>Call screening</i>	<i>17</i>
<i>Using the 1471 feature</i>	<i>18</i>
<i>Using the VIP feature</i>	<i>19</i>
<i>Memos</i>	<i>20</i>
<i>Operating your answering machine from the cordless handset</i>	<i>21</i>
<i>Remote access</i>	<i>23</i>
<i>Help</i>	<i>27</i>
<i>Technical information</i>	<i>30</i>
<i>Maintenance</i>	<i>32</i>
<i>Wall mounting</i>	<i>34</i>
<i>Index</i>	<i>36</i>

Introduction

Your Freestyle 1050 is designed for ease of use and made to the high standards set by BT

Thank you for making the right choice. You can expect your Freestyle 1050 to provide many years of quality service. Please read the instructions carefully before use and keep this user guide for future reference.

For your records

Date of purchase:
Place of purchase:
Serial number: (on the underside of the base unit)
Purchase price:

For warranty purposes, proof of purchase is required, so please keep your receipt.

Emergency calls

The emergency services can be contacted in the UK by dialling **999** or **112**.

As the Freestyle 1050 is a mains-powered cordless telephone, in certain situations you may not be able to make an emergency call:

- If there is severe radio interference.
- If the handset batteries fail.
- If there is a power cut.

If your Freestyle 1050 is connected to a PBX (switchboard), you may have to dial an access number before **999** to contact the emergency services.

Unpacking your Freestyle 1050



Check that your Freestyle 1050 is complete. When you unpack you should have:

- Freestyle 1050 handset including rechargeable battery



- Freestyle 1050 telephone answering machine

- Mains power lead with attached 13 amp adaptor plug



- Wall-mounting bracket, two screws and wall plugs for wall mounting


Customer Helpline

*If you have problems with your phone, call the Freestyle 1050 Helpline Service on **0845 758 5589***

Setting up


Follow these steps to get your Freestyle 1050 ready for use

1 Handset aerial



Your Freestyle 1050 uses a compact aerial which does not pull out.


2 Check your telephone socket



If you do not have a modern-style telephone socket, call **Freefone 0800 800 150** and ask for a BT engineer to come and fit the correct socket.

This is a chargeable service.

3 Insert a new PP3 9V alkaline back-up battery in the base unit




The back-up battery is available separately and ensures your Freestyle 1050 retains messages, settings and stored phone numbers if there is a mains power failure. If no battery is installed, the **BATT LOW** light comes on when the mains power is switched on.

In the event of a power failure the back-up battery will last for up to 6 hours.

4 Plug the mains adaptor cord into the back of the base unit

To prevent the cable being pulled out by accident, route it through the channel on the underside of the base.



Electrical storm warning

During periods of electrical storm, you are advised to disconnect your apparatus because damage may occur.

If a fault occurs during the 12-month warranty period and it is due to accidental or wilful damage (including lightning and electrical damage), BT will not replace or repair free of charge.

5 Plug the 3 pin adaptor into the mains power socket and switch on

Your Freestyle 1050 begins the set up procedure.

- the message counter flashes '≡'.
- the message counter then flashes ☐.
- the pre-set outgoing message is ready to use.

Mains power adaptor

The Freestyle 1050 must only be used with the adaptor supplied.

Using any other adaptor will invalidate the approval given to this apparatus.

6 Charge the handset battery for at least 12 hours

When you first use your Freestyle 1050, the rechargeable batteries in the handset need charging for 12 hours.

Place the handset on the base unit face down, ensuring the contacts are touching.

The **CHARGING** light on the base unit comes ON.

After the handset has been charged for 12 hours, your phone is ready for use.

As a rule, placing the handset on the base unit overnight will keep the batteries fully charged for all normal use.

The **CHARGING** light remains on until the handset is removed from the base unit.

When fully charged and in good condition, the handset battery will provide up to 6 hours continuous talk time or 72 hours standby.

*If the handset battery is running low, the **BATTERY LOW** light will flash every 10-15 seconds.*


If you are making a call and the handset battery is running low, the phone will beep every 10-15 seconds.

Place the handset on the base unit to recharge.


Battery Care

Batteries cannot be overcharged. However, leaving the handset on the base unit all the time can deteriorate rechargeable batteries. To get the longest possible life from your batteries, take the handset off the base for a few hours each day.

7 Plug your Freestyle 1050 into the phone socket



8 Fully extend the telescopic aerial on the base unit



For the best reception

Try to avoid putting the telescopic aerial near other electrical appliances, fluorescent lights and large metallic objects such as cookers, radiators and garage doors as these may cause interference and reduce the quality of your calls.

9 To plan the location of the base unit

Your Freestyle 1050 works by sending and receiving radio signals between the base unit and the handset.

The strength of the signal depends on where you site the base unit and how the aerial is deployed.

The higher the base unit is located, the better. An upstairs room is ideal. The following points should be considered:

- It should be within easy reach of a mains socket and a telephone socket. A new-style telephone socket is needed for this product. If you do not have one, call us on **Freefone 0800 800 150**.
- Try to avoid locations near metallic obstructions or electrical appliances, such as TV sets, fridges, computers, fluorescent lights, radiators, metal pipes and metal window frames.
- The Freestyle 1050 can be wall mounted by using the bracket and screws supplied; see page 34.

Your Freestyle 1050 is now ready for use

Using your Freestyle 1050 telephone

Making and receiving calls

The handset range is up to 200 metres from the base unit in ideal conditions. If you start to go out of range while using the phone, you will hear warning beeps. If you do not come back in range, your call will be cut off.

To make a call

Press buttons in order shown

Lift the handset off the base



Press the **TALK** button. The handset **IN USE** light comes on. The base unit light flashes. Listen for dial tone.

Dial the number.

To end a call



Press the **TALK** button.

Or



Replace the handset on the base.

To receive a call

When the phone rings:



If your handset is on the base unit, simply pick it up to answer the call.

Or



If your handset is off the base, press the **TALK** button to answer the call.

To redial the last number

You can redial a number of up to 32 digits long.



Press the **TALK** button. You hear the dialling tone.



Press the **REDIAL** button. The last number you called is redialled.

To ensure the best sound quality

Your Freestyle 1050 automatically scans available radio channels between the handset and base for the best quality signal. However, if you hear noise or interference during your call:



Press the **CHANNEL** button. Your Freestyle 1050 will select a new channel for you.

If you go out of range

Your Freestyle 1050 has a range of 200 metres under ideal conditions.

However, if you go out of range during a call, you will hear a series of beeps. Move closer to the base to re-establish the signal.

Using the Secrecy button

You can prevent your caller from hearing you while you talk to someone else close by.



Press the **SECRECY** button. A beep is heard and the **IN USE** light flashes. Your caller cannot hear you until you press the **SECRECY** button again.

Using the memory to store and dial numbers

Your Freestyle 1050 handset can store up to ten separate phone numbers, each up to 16 digits long. You can then dial each number by pressing just two buttons.

To store a number in the memory

Press buttons in order shown



Press the **QUICKDIAL** button. You hear a beep and the **IN USE** light begins to flash.



Press one of the **0-9** buttons to set the location code under which your phone number will be stored.

DIAL

Dial the number you want to store.



Press the **QUICKDIAL** button. You hear a confirmation beep. The number is stored.



Repeat these steps for any other numbers you want to store, using a different **0-9** location code for each one.

Storing a number in the memory automatically overwrites any previous number stored under the same location code.

Stored numbers can include those for switchboard and network services that use the **★** and **#** buttons as well as the **PAUSE** and **RECALL** functions.

To dial a stored number



Press the **TALK** button.



Press the **QUICKDIAL** button



Press the **0-9** location code under which the number you want is stored.
The number is dialed automatically.

Did you know?

*You can mix manual and memory dialling as required. For example, you can dial the area code **0181 380** from the memory and then complete the number manually.*

NOTE

Keep a note of your stored numbers on the Quickdial reference label on the base unit.

To store a number of more than 16 digits



Press the **QUICKDIAL** button.



Press one of the **0-9** buttons to set the location code under which your phone number will be stored.

DIAL

Dial the first 16 digits.



Press the **QUICKDIAL** button. You hear a confirmation beep. The number is stored.



Press the **QUICKDIAL** button again.



Press a different **0-9** button to select a second location code under which to store the remaining digits.

DIAL

Dial the remaining digits.



Press the **QUICKDIAL** button. You hear a confirmation beep. The rest of the number is stored.

To dial a stored number of more than 16 digits



Press the **TALK** button.



Press the **QUICKDIAL** button, then the first **0-9** location code number. The number begins dialling automatically.



When the first part of the number has been dialled, press the **QUICKDIAL** button again, then the second **0-9** location code number. The rest of the number is dialled.



To page the handset

If you misplace the handset, you can use **PAGE** to find it again.



Press the **PAGE** button on the base. The handset will beep. The **IN USE** light on the base flashes.



Stop the handset beeping either by pressing the **PAGE** button again
or



the **TALK** button on the handset.

To insert a pause

With some switchboards, after dialling the access code you may have to wait for a moment while the switchboard picks up an outside line. If so, press the **PAUSE** button to insert a 2.5 second pause before keying in the telephone number.



To use the recall button



This button signals Timed Break Recall only. If you are connected to a PBX (Private Branch Exchange), contact your PBX supplier for further information.

Using the Freestyle 1050 answering machine

Outgoing messages

Your Freestyle 1050 can digitally record up to 14 minutes of messages, with each incoming message lasting a maximum of 2 minutes.

The outgoing message is the message a caller hears when your Freestyle 1050 answers a call.

The Freestyle 1050 has a pre-recorded outgoing message which announces...

“Hello, your call cannot be taken at the moment, so please leave your message after the tone.”

You can record your own outgoing message to replace the pre-recorded message.

If you record your own message, the pre-recorded message is automatically removed and stored in the memory, in case you wish to reinstate it; see how to delete your outgoing message on page 13.

Any outgoing message you record can be up to 2 minutes long, but you should keep it short to allow more time for recording of incoming calls.

NOTE

To record your own outgoing message, speak clearly, 15 to 20cm from the built-in microphone.

Message display

Display	Definition
(Blank)	Power off.
≡	Power up or reset.
–	Power on – answer off mode.
0-30	Answer-on mode, 0-30 messages.
P (flashing)	Message paused.
r (flashing)	Message recording (memo, outgoing message or incoming message).
Å (flashing)	Remote access in progress.
F (flashing)	Memory full.
t or 2 to 9	Setting or reading answer delay.
d (flashing)	1471 function in progress.
E (flashing)	Error.
8-0	Counting down.

To record your outgoing message

Press buttons in order shown

OGM



Press and hold down the **OGM** button. Your Freestyle 1050 will beep and r flashes on the message counter.

OGM



Keep holding down the **OGM** button and say your message into the microphone.

OGM



When you have finished speaking, release the **OGM** button.

Your Freestyle 1050 will beep, play back your message, then beep to confirm the recording. It will then return to 'Answer On' mode.

To re-record your outgoing message, repeat this procedure.

To check your outgoing message

OGM



Press the **OGM** button.

Your Freestyle 1050 will beep, play back your message, then beep to confirm the recording. It will then return to 'Answer On' mode.

"Beep. Your message. Beep"

To delete your outgoing message

You can delete your outgoing message and return to your Freestyle 1050's pre-recorded outgoing message.

OGM



Press the **OGM** button.

"Your message"

Your outgoing message is played back to you.

Delete



While the message is playing, press the **DELETE** button.

Your Freestyle 1050 will beep and play its pre-recorded outgoing message.

"Hello, your call cannot be taken at the moment, so please leave your message after the tone."

Your own message has now been replaced by the Freestyle 1050's original pre-recorded message.

To switch the answering machine on/off

Answer on/off



Press the **ANSWER ON/OFF** button. Your Freestyle 1050 will announce *"Answer off"*.

Display shows a single dash.

Answer on/off



Press the **ANSWER ON/OFF** button again. The machine will announce *"Answer On"*.

To adjust the loudspeaker volume

Press buttons in order shown

Your Freestyle 1050 has a volume range of **0-8** (**0** = Off, **8** = Loud). The pre-set level is **3**.



Press **VOL +** to increase the volume.



Press **VOL -** to decrease the volume.

As you press, a beep sounds at the level you are selecting. When the volume is at its highest or lowest, you will hear two beeps.

Message alert

When new messages have been received, your Freestyle 1050 will beep every 10 seconds. The volume of the beep is at the volume you have set for the loudspeaker.

To switch the message alert on or off

When the answering machine is in its idle state:



Press and hold the **SKIP <** button. The machine announces, "*Message alert off/on*" as appropriate.



Press the **SKIP <** button again to change the setting.

Incoming messages

Your Freestyle 1050 will automatically record an incoming message when it is connected to your phone socket and is set to 'Answer On'.

While a message is being recorded, the display flashes **r**. It will stop recording if the caller stops speaking for longer than 6 seconds.

Two minutes is the maximum time allowed for each incoming message. If the maximum message length is reached – or if the memory becomes full – your Freestyle 1050 will give 4 beeps and hang up.

NOTE

If a call comes in while you are playing back a message or memo, the playback continues until completed, or you take the call.

Using the 1471 feature with your answering machine

When using your answering machine, if the 1471 feature is switched on, your Freestyle 1050 will automatically record the time of each call and the caller's number (if available).

When the message is played back, you will then hear these details at the end of their message.

If the caller hangs up before recording their message, your Freestyle 1050 will still record the caller's number and time of their call after announcing "*you have no message*". The message counter will also move up by one. Memos do not have the time of recording automatically added.

To play back a message



Press the **PLAY/MEMO** button. Your Freestyle 1050 announces "*You have X messages*".

The message will then be played back followed by the 1471 details (if the service is switched on) e.g. "*Telephone number XXX called today at 2.13pm*".

If you have two or more messages, they are played back in the order in which they were received.

When all your messages have been played back, your Freestyle 1050 announces "*End of messages*".

The display counts down from 8 to 0.

*Press the **STOP/ANSWER ON/OFF** button at any time during playback to stop messages playing.*

To pause a message



While listening to the message, press the **PLAY/MEMO**. Your Freestyle 1050 will beep every 10 seconds during pause.

Display shows F.



Press the **PLAY/MEMO** button again to resume playback.

If playback is not resumed within 60 seconds, the machine automatically resets to 'Answer On' mode

To skip forward or backward through messages

Press buttons in order shown

When playing back messages, you can skip forward to the next message or backward to the start of the current or previous message.

While the message is being played back.



Press the **SKIP >** button to start playing the next message. If you press the skip button while playback is paused, play will continue with the next message. You will see the counter change with each press.

If you skip beyond the last message, your Freestyle announces *"End of messages"*.



Press the **SKIP <** button once to replay the current message.



Press the **SKIP <** button twice to go to the start of the previous message.

To delete individual messages



Press the **PLAY/MEMO** button to play your messages.



When the message you wish to delete is playing, press the **DELETE** button. Your Freestyle 1050 announces *"Message deleted"*.

Skip through your messages to make any further deletions.

NOTE

*To cancel deletions and retain your messages, press the **STOP/ANSWER ON/OFF** button during the 8 to 0 countdown at the end of your messages.*

To delete all messages

Following playback of messages, your Freestyle 1050 will count down from 8 to 0 .

During this time you can delete all stored messages.

Press the **DELETE** button while the display is counting down from 8 to 0 .



Your Freestyle 1050 will announce... *"All messages deleted"*.

It will then continue its countdown to 0 , and return to 'Answer On' mode.

NOTE

*If you accidentally delete all messages you can still save them by pressing the **STOP/ANSWER ON/OFF** button before countdown reaches 0 .*

Answer delay

Answer delay sets the number of times your Freestyle 1050 will ring before answering a call.

NOTE

If you set your 1050 Answer Delay to Time Saver this means that when you call in from another phone (remote access), if any messages have been recorded your Freestyle 1050 will answer after only 2 rings. If there are no messages, it will answer after 6 rings, thereby allowing you the option of hanging up before your Freestyle 1050 answers. In using Time Saver, you can avoid the cost of a call.

To set the answer delay



Press and hold the **SKIP >** button. The current setting is displayed on the message counter and is set to 6 rings



Keep holding the **SKIP >** button. Your Freestyle 1050 will announce the answer delay options...
"Time Saver, 2, 3, 4, 5, 6, 7, 8, 9."



When you hear the setting you want, release the **SKIP >** button. Your Freestyle 1050 will then announce the new answer delay setting and return to 'Answer On' mode. *"Answer delay, 4 rings"*.

PLEASE NOTE

If you set the answer delay to a specific number of rings, it will actually ring one less than the number you set. So, if you set it to ring 5 times, it will actually ring 4 times. This is because your Freestyle requires one ring to activate the radio link between the base station and the handset ringer.

To check the answer delay setting



Press the **SKIP >** button. Your Freestyle 1050 will announce the current setting. *"Answer delay, 4 rings"*.

Call screening

You can let your Freestyle 1050 answer an incoming call, allowing you to identify the caller and decide whether to take the call. (The VIP feature must be set to OFF).

To use call screening

Make sure that the volume is set to an audible level. (See page 14).

Allow the incoming call to be answered by your Freestyle 1050 as normal. You will hear the caller begin to leave a message.

At the base unit



If the handset is resting on the base unit and you decide to take the call, lift the handset and speak to the caller.

Recording will stop automatically.

NOTE

*If, when you lift the telephone handset your Freestyle 1050 does not stop recording, either replace the handset and lift again, or press the **TALK** button to speak to your caller.*

To screen a call vial the handset

When your Freestyle 1050 starts to record an incoming message, the handset gives 3 beeps and the **IN USE** light flashes.



Press the **SECRECY/SCREEN** button. You can hear the caller on the handset.

Or



To interrupt recording and talk to your caller, press the **TALK** button.

Using the 1471 feature

After each incoming message your Freestyle 1050 is set to dial the free 1471 service and record the announcement that gives you the telephone number of your caller whether they leave a message or not. On playing back messages you will be given the caller's number and time of the call.

NOTE

This service will not work with switchboards and may not work with some Cable Networks.

Please ask your Telecommunication supplier for further details.

To switch the 1471 feature on and off

Press buttons in order shown

When you first switch on your Freestyle 1050, Call Return is automatically set to 'on'.

The 1471 feature can be switched on and off.



Press the **1471** button to switch it off. The freestyle 1050 announces "1471 off".



Press the **1471** button again to switch it back on. The Freestyle 1050 announces "1471 on".

NOTE

The free 1471 service announces the day and time that the call was left. Your Freestyle 1050 will automatically record this announcement immediately after receiving a call. Consequently, the day of the call will be recorded as 'today'. Therefore, it is recommended that you check your messages on a daily basis. The free 1471 announcement also asks if you wish to return the call. In fact, you are not able to do this.

Using the VIP feature

Your Freestyle 1050 has a VIP feature which sets your answering machine to answer calls silently but allows designated callers to alert you with a beep that they are trying to contact you. The VIP feature will only operate with the answering machine in 'Answer On' mode.

While the VIP feature is switched on, you will not be disturbed by any other callers and your answering machine will take messages silently.

To switch the VIP feature on and off

VIP is pre-set to off.



Press and release the **VIP** button to turn it on.



By pressing the **VIP** button, the Freestyle 1050 announces "*VIP on, thirty*".



Press **VIP** button again to switch off.

To check VIP code and setting



Press the **VIP** button.

Your Freestyle 1050 will announce if the setting is on or off and the code number.

To allow VIP callers to signal their call

Press buttons in order shown

Give your special callers the VIP code. Your pre-set code is 30. Tell them to key in the code when they hear your outgoing message. The VIP alert beeps last for 30 seconds.



If a caller wishes to cancel the alert, they press the **#** button on their phone. Your Freestyle 1050 will give a long beep at the end of the outgoing message and the caller can leave their message after the beep.

To change the VIP code



Press and hold down the **VIP** button. The machine announces the current VIP code e.g. "*Thirty*". Continue to hold down the VIP button and press the **SKIP >** button to move forward through the numbers or press **SKIP <** to move backward.



When the number you want is announced, release the **SKIP** and **VIP** buttons. The machine announces e.g. "*VIP on/off Twenty five set*".

NOTE

The code numbers available run from 00 to 39. They are announced by your Freestyle 1050.

To cancel any procedure



Pressing the **STOP/ANSWER ON/OFF** button will cancel any procedure currently in progress and your Freestyle 1050 will return to 'Answer On' mode.

When the memory is full

When 14 minutes recording time have been used up. Or, a maximum of 30 messages have been recorded, your Freestyle 1050 will not record any more messages.

Memos

A personal memo can be recorded on your Freestyle 1050 and left as a message for another user. Memos can be of any length, up to the maximum recording capacity (14 minutes), but you should keep them short to allow time for recording incoming messages.

To record a memo



Press and hold the **PLAY/MEMO** button. Your Freestyle 1050 will beep and the display shows r. Speak clearly into the built-in microphone.



When you have completed your memo, release the **PLAY/MEMO** button. Your Freestyle 1050 will beep again.

Your memo is now stored and can be played back later. Memos are stored in the same way as incoming messages.

NOTE

To play back, delete or skip forward or backward through memos, follow the instructions for playing back messages (page 16).

NOTE

If the answer machine is set to 'off', recording a valid memo will switch the answer machine on.

Operating your answering machine from the cordless handset

You can use your Freestyle 1050 cordless handset to listen to your messages, delete, skip forward or backward and record a memo or new outgoing message. You can also use it to screen an incoming call.



To start playback of messages



Press the **SECURITY/SCREEN** button on the handset. Your answering machine will announce either “*You have no messages*” and you have 8 seconds to give it an instruction, or “*You have X messages*” and begins playback.

Use the handset buttons to operate the machine as follows:



to stop playback



to pause and resume playback



repeat message (or press twice to play the previous message)



delete the message that is playing



to skip forward to the next message (or press twice to skip forward two messages).

To replay all messages

At the end of your messages, you will hear “*End of messages*”.



Within 8 seconds press **2** on your telephone keypad. All messages are replayed.

To change your outgoing message



Press the **7** button twice within 8 seconds of hearing either “End of messages”

or

“You have no messages”.

Your Freestyle 1050 gives a long beep after the second press of the **7** button to tell you it is starting to record.



When you have finished recording your new message, press and hold the **0** button for 1 second.

Your Freestyle 1050 will beep and play your new outgoing message to confirm recording.

To check your outgoing message



Press the **9** button while your Freestyle 1050 is waiting for an instruction.

Your outgoing message is played.

At the end you have 8 seconds in which to give your machine another instruction.

To go back to the pre-set outgoing message

Press buttons in order shown



Press the **9** button while your Freestyle 1050 is waiting for an instruction.

Your outgoing message is played.



While the message is playing, press the **5** button. Callers will now hear your Freestyle 1050 pre-recorded message “Hello, your call cannot be taken at the moment, so please leave your message after the tone.”

To screen a call via the handset

When your Freestyle 1050 starts to record an incoming message, the handset gives 3 beeps and the **IN USE** light flashes.



Press the **SECREC/SCREEN** button. You can hear the caller on the handset.

Or



To interrupt recording and talk to your caller, press the **TALK** button.

Remote access

Control your answering machine from another phone using a TouchTone™ keypad

You can turn your Freestyle 1050 answering machine on and off and listen to your messages from any TouchTone™ telephone. To protect your privacy, messages can only be accessed by entering a 2-digit security code.

The code is pre-set and cannot be changed. The code can be found on the underside of the base unit.

To check for messages

Press buttons in order shown

Dial your phone number and wait.



When you hear your outgoing message, press the ★ button on your phone. You will hear a *'Beep'*.

CODE Key in the first digit of your security code. You will hear the number you keyed in and a *'Beep'*.

CODE Key in the second digit of your security code. You will hear the number you keyed in then a long *'Beep'*.

Once you have entered your security code.

If you have no messages you will hear *"You have no messages."*

You now have 8 seconds to enter any other instructions before your Freestyle 1050 hangs up.

If you have messages you will hear *"You have X messages."*

Your Freestyle 1050 will then play your messages.

NOTE

If you hear 4 short 'beeps', it means that you have entered the wrong security code and you are invited to try again.

If you take longer than 8 seconds to enter a ★ or number, your Freestyle 1050 will hang up.

Controlling your message

You can now play back, delete or skip backward and forward through your messages using the telephone keypad, as follows:

To replay the message you are listening to:

- 4 While the message is playing, press **4** on your telephone keypad. The message will replay from the beginning.

To replay all messages

At the end of your messages, you will hear "End of messages".

- 2 Within 8 seconds press **2** on your telephone keypad. All messages are replayed.

To move forward to the next message

- 6 While a message is playing, press **6** on your telephone keypad. Your Freestyle 1050 will play the next message.
- 6 You can move forward 2 messages by pressing the **6** button twice and so on.

To delete the message you are listening to

- 5 During playback, press the **5** button on your telephone keypad. Your Freestyle 1050 will announce "Message deleted".

To delete all messages

You can delete all messages immediately after listening to them.

- 5 Press the **5** button within 8 seconds of hearing "End of messages."

All messages will be deleted. Your Freestyle 1050 will announce "All messages deleted."

NOTE

If you accidentally delete a message or messages, simply hang up within 8 seconds of hearing the message "All messages deleted."

All messages marked for deletion will be restored.

To pause a message

Press buttons in order shown

2

While the message is playing, press the **2** button.

2

Press **2** again to resume playback.

If you pause for longer than 60 seconds, the line will be disconnected.

To cancel message playback or pause

0

While listening or pausing, press the **0** button. Your Freestyle 1050 gives 2 beeps and you have 8 seconds to give it another instruction.

To turn your Freestyle 1050 on

If you have gone out without switching on your Freestyle 1050, you can turn it on from another phone.

Ring your answering machine as normal.

Let your telephone ring 20 times. Your Freestyle 1050 will then answer.

Hang up the phone. Your Freestyle 1050 is switched on and will answer calls.

NOTE

If the memory is full, you will have to delete some messages before your Freestyle 1050 will switch to 'Answer On' mode.

*After you hear the 'Memory Full' announcement, you have 8 seconds to enter **2** (to listen to your messages), or **5** to delete all messages).*

To turn your Freestyle 1050 off

Dial your number and enter your security code.

8

Press the **8** button within 8 seconds of hearing either "End of messages" or "You have no messages".

Your Freestyle 1050 will announce "Answer off".

8

If you press the **8** button again within 8 seconds, you will turn your Freestyle 1050 on again and hear the announcement "Answer On".

To change your outgoing message

7

Press the **7** button twice within 8 seconds of hearing either *“End of messages”*.

or

“You have no messages”.

Your Freestyle 1050 gives a long beep after the second press of the **7** button to tell you it is starting to record.

Now record your new OGM.

0

When you have finished recording your new message, press and hold the **0** button for at least 1 second.

Your Freestyle 1050 will beep and play your new outgoing message to confirm recording.

To go back to the pre-set outgoing message

9

Press the **9** button while your Freestyle 1050 is waiting for an instruction.

Your outgoing message is played.

5

While the message is playing, press the **5** button. Callers will now hear your Freestyle 1050 pre-recorded message *“Hello, your call cannot be taken at the moment, so please leave your message after the tone.”*

To check your outgoing message

9

Press the **9** button while your Freestyle 1050 is waiting for an instruction.

Your outgoing message is played. At the end you have 8 seconds in which to give your machine another instruction.

Help

If you have any problems using your Freestyle 1050, this section will give you the most common, easy-to-follow solutions.

<i>Telephone problems</i>	<i>Possible cause</i>	<i>Solution</i>
<ul style="list-style-type: none">• No dialling tone.	Telephone not connected to telephone line.	Plug the telephone into the telephone line.
<ul style="list-style-type: none">• Telephone will not dial out.	Mains disconnected.	Make sure the mains supply is connected.
<ul style="list-style-type: none">• Telephone cannot receive calls.	Power cut. Handset battery pack is discharged.	Wait until the power is restored. Place the handset on the base unit and recharge it for 12 hours, ensuring the charging light is on.
<ul style="list-style-type: none">• You have dialling tone but the telephone will not dial out.	You may be trying to use tone dialling on a pulse dialling exchange. You are connected to a PBX and are not dialling the access code.	Check with your network provider. Your Freestyle 1050 only provides tone dialling. Use the PBX access code.
<ul style="list-style-type: none">• Handset does not ring.• No lights on handset.	Handset battery pack is discharged.	Place the handset on the base unit and recharge it for 12 hours.
<ul style="list-style-type: none">• Handset does not ring, but lights show on base.	Check the REN (see page 31). If you connect too many telephones or devices to your line, they may not all operate correctly. If your telephone is connected to an extension socket, it may have been connected incorrectly. Check handset battery is not flat.	If the REN exceeds 4, disconnect one or more telephones or devices. Check with your telephone engineer that the extension socket has been installed correctly. Recharge handset battery.

*Telephone problems**Possible cause**Solution*

<ul style="list-style-type: none">• Callers are faint.• Interference.• Buzzing.• Whooshing. • Echoing. • Tinniness.	<p>The base unit telescopic aerial is not extended as high as possible.</p> <p>You are moving out of range.</p> <p>Radio channel interference.</p> <p>Radio channel interference.</p> <p>The base unit or the handset are too close to electrical equipment or metal obstructions.</p>	<p>Extend the base unit telescopic aerial as far as possible.</p> <p>Move closer to the base unit.</p> <p>Press the CHANNEL button on the handset, to select a clearer channel.</p> <p>Press the CHANNEL button on the handset, to select a clearer channel.</p> <p>Relocate the base unit or move around with the handset until reception improves.</p>
<ul style="list-style-type: none">• No Quickdial store.	<p>You may be trying to store the number with the talk light on.</p>	<p>Ensure that the TALK light is off before storing the number.</p>
<ul style="list-style-type: none">• BATTERY LOW light on the handset is flashing.	<p>The handset battery needs recharging.</p>	<p>Replace the handset on the base unit, ensuring that the base unit is plugged in and that the CHARGING light is on.</p>
<ul style="list-style-type: none">• No CHARGING light on the base unit.	<p>Dirty contacts on base unit or handset.</p>	<p>Clean the contacts with a dry cloth. Heavy soiling can be removed with a pencil eraser.</p>

<i>Answering Machine problems</i>	<i>Possible cause</i>	<i>Solution</i>
<ul style="list-style-type: none"> • General problems. 	<p>None of the answering machine functions will operate while the telephone is in use.</p>	<p>Ensure that the telephone is not in use before operating the answering machine.</p>
<ul style="list-style-type: none"> • Will not record incoming messages. 	<p>The answering machine is switched off.</p> <p>The answering machine is full.</p>	<p>Switch the answering machine on manually or by remote control.</p> <p>Delete some or all of your messages manually or by remote control, to make room for new messages.</p>
<ul style="list-style-type: none"> • Distorted outgoing message. • Faint outgoing message. • Noisy outgoing message. 	<p>The answering machine has a very sensitive microphone. This picks up any background noise. If you record your outgoing message too quietly or from too far away the sensitivity of the microphone increases to compensate and will pick up more background noise.</p>	<p>Record your outgoing message at a reasonable volume 20cm away from the microphone in a quiet environment.</p>
<ul style="list-style-type: none"> • No call screening from the base unit. • Cannot hear messages when played. 	<p>The volume is set too low.</p> <p>VIP setting is ON.</p> <p>The volume is set too low.</p>	<p>Increase the volume to a suitable level using the volume control.</p> <p>Switch VIP OFF.</p> <p>Increase the volume to a suitable level using the volume control.</p>
<ul style="list-style-type: none"> • Back-up battery fails frequently. 	<p>Frequent power failures will drain the back-up battery.</p> <p>Unplugging the base unit from the power supply drains the back-up battery.</p> <p>Switching the mains supply off will drain the back-up battery.</p>	<p>Leave the base unit plugged in, or remove the back-up battery before unplugging.</p> <p>Remove the back-up battery before switching the mains supply off.</p>

Technical information

Approval for use

Your Freestyle 1050 is tested and approved for connection to public networks, provided it is used in accordance with the guidelines in this user guide.

You may connect it:

- To direct exchange lines.
- To extensions with new plug and socket arrangements provided with these direct exchange lines.
- To compatible switchboards.

You may NOT connect it:

- To shared service (party) lines.
- As an extension to a payphone.

This phone is designed for UK use only. Using it abroad may violate local radio laws.

The base unit is intended for use when powered from the 12V AC mains adaptor supplied, which conforms to EN60950. Any other usage will invalidate the approval given to this apparatus if, as a result, it ceases to comply with EN60950.

Environment

Your Freestyle 1050 should be kept free of dust, moisture, high temperature and vibration, and should not be exposed to direct sunlight. Do not stand it on carpets or other surfaces which generate fibres, or place it in locations which prevent the free flow of air over its surfaces.

WARNING

The apparatus is only designed to be operated in a normal office or domestic environment where the relative humidity does not exceed 60%. It should not be used in bathrooms or near water.

How many phones can you have?

All items of telephone equipment have a Ringer Equivalence Number (REN), which is used to calculate the number of items which may be connected to any one telephone line. Your Freestyle 1050 has a REN of 1. A total REN of 4 is allowed. If the total REN of 4 is exceeded, the telephones may not ring. With different telephone types there is no guarantee of ringing, even when the REN is less than 4.

Connecting to a switchboard

Your Freestyle 1050 may be connected to compatible switchboards. If in doubt, your switchboard supplier or maintainer should be able to offer help. Advice on connection to BT switching systems can be obtained by dialling BT on **152**.

If you do not have a compatible switchboard, it cannot be guaranteed that your Freestyle 1050 will operate correctly under all possible conditions of connection.

Call security

Your Freestyle 1050 has its own digital security code that prevents other cordless phone owners from using your phone line. This ensures that you are charged only for calls using your phone. However, all approved cordless phones use radio signals to communicate between the base unit and cordless handset units. It is therefore possible that your conversations could be overheard by other people, on their cordless phones, or on radios that use the same radio frequencies.

As this problem applies equally to all similar cordless phones currently available in the UK, call privacy cannot be guaranteed. However, the security coding prevents unauthorised use of your line.

In the unlikely event of your Freestyle 1050 picking up conversations from other cordless phones being used nearby, try changing channels using the **CHANNEL** button on the handset.

Transmission frequencies

This cordless telephone has been designed to operate on radio frequencies which have been assigned to the exclusive use of cordless telephones. As the use of cordless telephones becomes more widespread, the quality of service obtained from this apparatus may lessen.

Transmission frequencies of available channels:

<i>Channels</i>	<i>Base Unit Tx Freq./MHz</i>	<i>Handset Tx Freq./MHz</i>
1	31.0375	39.9375
2	31.0625	39.9625
3	31.0875	39.9875
4	31.1125	40.0125
5	31.1375	40.0375
6	31.1625	40.0625
7	31.1875	40.0875
8	31.2125	40.1125

Safety advice

Don't use your Freestyle 1050 in the open air during thunderstorms. Unplug it from the telephone line and the mains socket when there are storms in your area.

Don't use your Freestyle 1050 outdoors in the rain, or handle it with wet hands.

Don't install the base unit near a sink, bath or shower. Electrical appliances can cause serious injury if used when you are wet or standing in water.

Don't install the base unit where the various leads can be tripped over or walked on. This may cause injury, or damage to the leads and your Freestyle 1050.

In the event of a power failure

In the event of a mains power failure you will not be able to make or receive calls from your Freestyle 1050. Alternative arrangements should be made for access to emergency services.


Maintenance

Installing a handset battery pack and recharging

Replacing the handset on the base unit to recharge overnight should keep the Freestyle 1050 operative for normal use. In time, the handset battery pack will no longer hold a sufficient charge and should be replaced.

To change the handset battery pack

The handset battery compartment is located at the back of the handset at the lower end.



- Firmly hold the handset in both hands with the back towards you and the bottom end away from you.
- Push the depression in the battery compartment cover, inward and away from you with both thumbs, to remove it.
- Undo the plastic belt securing the battery pack.
- Remove the old battery pack by unplugging the small white plug that connects it to the handset.
- Insert the small white plug of the new battery pack. (If you look at the shape of the plug and socket, you will see that it can only be inserted one way).
- Place the battery pack in the recess, secure it with the plastic belt and refit the compartment cover.
- Replace the handset on the base unit and charge for a full 12 hours.
- The battery pack must be recycled or disposed of properly.
- Do not burn or puncture as it could release toxic material which may cause injury.

Spare parts for your Freestyle 1050 are available from your BT shop or supplier.

Care of rechargeable battery pack

- When you first install the Freestyle 1050, or replace the battery pack, the handset must be fully charged for 12 hours before use.
- To maintain optimum charge and battery condition, the handset should be allowed to fully discharge about every four months.
- Dispose of Ni-Cad battery packs safely. Do not puncture or burn them. They contain toxic materials which could cause injury.

General cleaning

Clean the cabinet of the handset and the base with a soft cloth slightly dampened with a mild solution of water and detergent. Charging contacts should be cleaned with a dry cloth or for heavy soiling a pencil eraser can be used.

- Do not clean with a wet cloth.
- Do not clean with abrasive materials or solvents as these may damage the unit.
- Do not spray aerosol cleaners onto the base or handset.

Extended periods of non-use

It is recommended that you:

- Disconnect the base unit from both mains supply and telephone line.
- Remove the back-up battery from the base unit and battery pack from the handset.
- When reconnecting, check that the charging light on the base unit is on. Recharge the handset battery for 12 hours.

Guarantee

If you own your Freestyle 1050 under BT's guarantee

BT guarantees the product for one year provided that:

The goods have only been used for their intended purpose and have not been subjected to misuse, or been wilfully or accidentally damaged.

The goods have not been tampered with or repaired by anyone other than BT, its staff or agents. If a fault does occur in this product, and you bought the unit yourself, provided that you return it to the place of purchase and produce your receipt, it will either be repaired or replaced free of charge. The terms and conditions of this guarantee do not affect your statutory rights.

If you own your Freestyle 1050 outside the guarantee period

If your Freestyle 1050 needs repair after the guarantee period has ended, it must be repaired so as to remain compliant with the approval requirements for connection to the telephone network. We recommend that you call BT on **Freefone 0800 800 150** or visit your nearest BT shop and you will be informed of our recommended repair agents.

Wall Mounting

Your Freestyle 1050 can be wall-mounted by using the bracket provided.

You can use the bracket as a template to mark where the screws should go into the wall.


Please refer to page 35, wall mounting template.

Before you wall-mount your Freestyle 1050, check that:

- the wall can support the weight of the base unit and handset;
- the position you choose leaves enough space so that the base unit (which is larger than the bracket) is clear of any obstruction on the wall, such as a shelf or cupboard. Room should be left so that the handset can be placed on charge without touching any obstructions;
- the position leaves enough space for the aerial to be extended when wall-mounted.

For the best operating conditions, try to place the base unit away from large metal objects and other electrical appliances.


- 1 Drill 2 holes for the screws and insert the wall-plugs provided (if required).



- 2 Drive the screws into the wall, leaving about 4mm free on which to mount the bracket and base unit.
- 3 Make sure that the power supply and the telephone cables are connected to the base unit, then fit the cables into the channels on the bottom of the base unit.
- 4 Clip the bracket onto the base unit as shown on the next page.

- 5  Attach the bracket and base unit by hooking them over the screws protruding from the wall.

Wall Mounting template



Index

Adaptor	6	Ending a call	8
Aerial		Guarantee	33
base unit	7	Help	27
handset	5	Helpline	4
Answer delay	17	Incoming messages	14
checking	17	Location	7
setting	17	Maintenance	32
Answering machine on/off	13	Making a call	8
Answering machine -		Memory numbers	
operating from the handset	21	dialling	10
Battery		storing	9, 10
care of handset battery	7, 33	Memory full	20
changing handset battery	32	Memos	20
charging handset battery	6	playback	15
installation of base unit battery	5	recording	20
recommended base unit battery	5	Message alert on/off	14
Calls		Message display	12
ending	8	Messages – incoming	14
making	8	delete all messages	16
receiving	8	delete individual messages	16
Call screening	17	pause	15
at the base	17	playback	15, 21
at the handset	18, 22	replay all messages	21
Cancel any procedure	20	skip backwards/forwards	16
Channel	9	Messages – outgoing	12
Charging handset battery	6	change your message	22
Cleaning	33	check your message	13, 22
Dialling a memory number	10	deleting	13
Display - answer machine	12	pre-set message	22
Display messages	12	recording	13
Emergency calls	4	On/off – answering machine	13

Outgoing messages	12	on/off	19
Paging	11	signalling the code	19
Pause	11	Volume	
Power adaptor/cord	6	loudspeaker	14
Power failure	31	Wall-mounting	34
Power socket	6	Wall mounting template	35
Quickdial reference label	10	1471 feature	15, 18
Range	9		
Recall	11		
Redialling last number	8		
REN (Ringer Equivalence Number)	30		
Receiving a call	8		
Remote access	23		
cancel playback/pause	25		
change your outgoing message	26		
check for messages	23		
check your outgoing message	26		
delete all messages	24		
delete individual messages	24		
pause a message	25		
pre-set message	26		
replay all messages	24		
skip forward	24		
switching on/off remotely	25		
Remote access from the handset	21		
Safety advice	31		
Secrecy	9		
Security	31		
Sound quality	9		
Stop any procedure	20		
Storing a memory number	9, 10		
Switchboards	30		
Technical information	30		
Telephone socket	5, 7		
Transmission frequencies	31		
VIP feature	19		
checking	19		
changing	19		



*Offices in Europe, North America,
Japan and Asia Pacific.*

The telecommunications services described in this publication are subject to availability and may be modified from time to time. Services and equipment are provided subject to British Telecommunications plc's respective standard conditions of contract. Nothing in this publication forms any part of any contract.

© British Telecommunications plc 1999.
Registered Office: 81 Newgate Street, London EC1A 7AJ.
Registered in England No. 1800000.
Designed by: The Art & Design Partnership Limited.
Printed in China by: Team Concepts
Freestyle 1050 Issue 1 (5/99) 5.

Printed on paper which meets international environmental standards



CE compliant to 89/336/EEC
(EMC Directive) & 73/23/EEC
(Low Voltage Directive)

APPROVED for connection to
telecommunication systems specified
in the instructions for use subject to
the conditions set out in them

