




# User Guide

BT LYRIC 1100  
BT LYRIC 1100 TWIN



# Welcome...

to your BT Lyric 1100 Digital  
Cordless Telephone

- 
- Easy, menu-based operation.
  - Digital quality call clarity.
  - The 40 name and number phonebook makes it simple to store and dial your most frequently used numbers.
  - Use Caller Display and the calls list to see who is calling before you pick up the phone and keep track of incoming calls.
  - Redial any of the last 5 numbers dialed from the redial list.
  - Use up to 5 handsets with your BT Lyric 1100 base station without the need for additional wiring, giving you a complete phone system on a single line.
  - The BT Lyric 1100 is a Digitally Enhanced Cordless Telecommunications (DECT) product and GAP compatible.

This User Guide provides you with all the information you need to get the most from your phone.

Before you make your first call you will need to set up your phone. Follow the simple instructions in ‘Getting Started’, on the next few pages.

■ **Need help?**

If you have any problems setting up or using your BT Lyric 1100 please contact the Helpline on **0870 605 8047**.

Alternatively, you may find the answer in ‘Help’ at the back of this guide.

**Got everything?**

- BT Lyric 1100 handset
- BT Lyric 1100 base
- 2 x NiMH AAA rechargeable batteries
- Mains power adaptor
- Telephone line cord
- Belt clip
- Headset

If you have purchased the BT Lyric 1100 Twin you will also have:

- BT Lyric 1100 additional handset
- BT Lyric 1100 charger
- 2 x AAA NiMH rechargeable batteries
- Mains power adapter
- Belt clip
- Headset

# In this guide

## Getting started

Location	.6
Setting up	.6
Attach the belt clip (optional)	.8

## Getting to know your phone

Handset buttons	.9
Handset display icons	.10
Navigating the menus	.11
Menu map	.13
Base	.14

## Using the phone

Switch handset on/off	.15
Make an external call	.15
Preparatory dialling	.15
End a call	.15
Receiving calls	.15
Earpiece volume	.16
Loudspeaker volume	.16
Handsfree	.16
Secrecy	.17
Redial a number from the redial list	.17
Paging	.18
Direct call	.18

## Phonebook

Add a new phonebook entry	.20
Dial from the phonebook	.20
Edit an entry	.21
Delete entries	.21
Insert a 'pause' in a stored number	.22

## Caller Display & the calls list

Caller Display	.23
Calls list	.23
View the calls list	.24
Dial a number in the list	.24
Copy a number to the phonebook	.24
Delete from list	.25
Call Waiting	.25
Speak to a second caller	.25

## Handset settings

Handset ringer volume	.27
Handset ringer melody	.27
Keypad lock	.28
Keypad beeps	.28
Auto-answer	.29
Name a handset	.29
Handset language	.30

## Base settings

Set date and time .....	31
Base ringer volume .....	31
Base ringer melody .....	32
Base PIN .....	32
Reset to original settings .....	33

## Additional handsets & bases

Register handset to base .....	36
Deregister handsets .....	36
Register handset to a different make of base .....	37
Base identity number .....	38
Select base .....	38
Set ring priority .....	38
Switch ring priority on/off .....	39
Making internal calls .....	40
Transferring calls .....	40
3-way conversation .....	41
Room monitor .....	41

## Switchboard use

Switchboard compatibility .....	43
Switchboard external line access code .....	43
Recall .....	44
Dialling mode .....	45

## Help .....46

## General information

Safety .....	49
General .....	49
Cleaning .....	50
Environmental .....	50
Technical information .....	51
How many telephones can you have? .....	51
Guarantee .....	52
Returning your phone .....	53
R&TTE .....	54
Declaration of Conformance .....	54

# Getting started

## WARNING

Do not place your BT Lyric 1100 in the bathroom or other humid areas.

## Handset range

The handset reception range from the base is up to 300m outdoors and up to 50m indoors.

## Signal strength

The  $\Upsilon$  symbol on your handset indicates when you are in range. When you are out of range a beep will sound every minute.

## IMPORTANT

Do not connect the telephone line until the handset is fully charged.

The base station must be plugged into the mains power socket at all times.

## Which socket?



Power socket



Telephone line socket

## Location


You need to place your BT Lyric 1100 close enough to a mains power and telephone socket so that the cables will reach.

Make sure it is at least 1 metre away from other electrical appliances to avoid interference.


Your BT Lyric 1100 works by sending radio signals between the handset and base. The strength of the signal depends on where you site the base. Putting it as high as possible ensures the best signal.

## Setting up

1. Plug the power adaptor and telephone cables into the underside of the base.



2. Plug the power adaptor into the mains wall socket and switch the power on. The green **Power** light on the base comes on.
3. Install the 2 x NiMH AAA batteries supplied. Then slide the battery compartment cover into place.



4. Charge the handset for at least 16 hours by placing the handset on the base. The red **Charging** light comes on. The handset is pre-registered to the base as BT Lyric. This is shown in the display.
5. After 16 hours charging, plug the telephone line cord into the wall socket.

**Your BT Lyric 1100 is ready for use.**

#### **Talk/Standby time**

Under ideal conditions, the handset batteries should give about 14 hours talk time or 350 hours standby on a single charge. (The base must still remain plugged in to the mains and switched on at all times.)

Please note that new NiMH batteries do not reach full capacity until they have been in normal use for several days.

#### **Battery low warning**



When the handset battery symbol is empty and flashing, and there is a warning beep every 10 seconds, you will need to recharge the handset before using it.

See 'Battery performance' on the following page.

## 8 Getting started


### Battery performance

To keep your batteries in the best condition, leave the handset off the base for a few hours at a time (after the initial 16 hour charge). Running the batteries right down at least once a week will help them last as long as possible.

After charging your handset for the first time, subsequent charging time is about 6–8 hours a day. Batteries and handset may become warm during charging. This is normal.

The charge capacity of rechargeable batteries will reduce with time as they wear out, giving the handset less talk/standby time. Eventually they will need to be replaced. New batteries are available from the BT Lyric 1100 Helpline on 0870 605 8047.


### Attach the belt clip (optional)






# Getting to know your phone


## Handset buttons





## 10 Getting to know your phone


### Handset display icons



 **Battery fully charged**

 **Battery low**  
When the battery icon is empty and flashing you will need to recharge the handset battery by returning it to the base.

 **New calls indicator**  
Shows the number of new entries in the Calls List, see page 24

 **Signal strength**  
Permanently displayed when handset is registered to base.

Flashes when handset is not registered to any base.

 **Internal call**





 **External call**

 **Keypad locked**




 **Displayed when in handsfree mode**

### Navigating the menus...









Your BT Lyric 1100 handset uses a menu system which is easy to use. In most cases each menu leads to a list of options. Have a look at the menu map on the following page.

When the handset is switched on and in standby, press **Menu**  to open the main menu and use the  and  **scroll** buttons to highlight the menu you want. Press **Menu**  again to open the list of options.

### ...and selecting menu options

Once the menu list you want is open, use the  and  to scroll through the options and the  button to select the option you want.

For example, to change the handset ringer volume:

1. Press **Menu**  to open the main menu then  to display Handset Menu. Press **Menu** , then  to display Ring Volume.
2. Press **Menu** , then  or  to select volume 1-5 or Off. Then press **Menu**  to confirm.




Press the **Menu** button to access menus and select options.


Use the scroll buttons to navigate through menus and options.

## 12 Section

---

### **Exit menu**

If you want to exit a menu or the phonebook, press *and hold*  to return to the standby screen.

To return to the previous screen press *and release* .

## Menu map



### Phonebook

#### Ed. Phonebook

Add Entry  
Edit Entry  
Delete Entry

### Keypad lock

### Direct Call

### Monitor Mode

### Handset Menu

Warning  
Tones  
Ring Volume  
Ear Volume  
Int. Melody  
Ext. Melody  
Auto Answer  
Handset  
Name  
Language

### Setup


Date/Time  
Base Volume  
Base Melody  
Base ID  
Select Base  
Remove HS  
PIN Code  
Ring Priority  
Dialling  
Mode  
Recall  
PABX Setup  
Default

### Registration

## 14 Getting to know your phone

---

### Base



Page

#### Page

Lets you page the handsets, *page 18*

Used when registering additional handsets, *page 36*

#### Charging light

ON = handset charging

#### Power/In use

ON = standby



Flashes = during handset registration

Flashes = during a call


Flashes = When the phone rings

# Using the phone



## Switch handset on/off

1. Press *and hold*  to switch off. Press *and release*  again to switch on.


## Make an external call

1. Press , listen for the dial tone then dial the number.

## Preparatory dialling

1. Enter the number first. If you make a mistake press  to delete. Press  to dial.


## End a call

1. Press  or place the handset back on the base.

## Receiving calls

When the phone rings, the display shows **External Call** and the EXT symbol flashes.

If you have subscribed to your network's Caller Display service, the caller's number (and name if stored in the phonebook) is displayed. See page 23 for more information.

1. Press  to answer the call or, if the handset is on the base, simply lift it and speak.

## Dialling numbers quickly

Numbers can also be dialled direct from the phonebook (page 20), the calls list (page 24), or the redial list (page 17).

## Call timer

Your handset automatically times the duration of every external call. The time is shown during the call and for a few seconds after the call has ended.

## Auto-answer




If you would rather press **Talk** to receive a call when the the handset is on the base, you need to switch Auto-answer off, see page 29.

## 16 Using the phone







### **Earpiece volume**

You can adjust the earpiece/loudspeaker volume. There are 5 levels to choose from.

*During a call:*

1. Use the  and  buttons to select volume 1-5. Press  to confirm.

*In standby:*

1. Press  to open the main menu then  to scroll to Handset Menu. Press  then  to scroll down to Ear Volume.
2. Press , then scroll to the required volume level. Then press .

### **Loudspeaker volume**





To adjust loudspeaker volume follow the steps as per earpiece volume above.

### **Handsfree**

Handsfree lets you talk to your caller without holding the handset. It also enables other people in the room listen to both sides of your conversation.





You can switch to handsfree before or during a call.

1. Press . Display shows the  icon.
2. To switch handsfree off, press  again.
3. To end the call press .





### Security

During a call, you can talk to someone nearby without your caller hearing you.

1. During the call press . Display shows **Security On**. Your caller cannot hear you.
2. Press  again to return to your caller.

### Redial a number from the redial list


You can redial up to 5 of the last numbers called. If the number is stored in the phonebook, the name will also be displayed (see '*Phonebook*', page 20).

1. Press , then use the  and  buttons to scroll through the list. The most recently dialed number is shown first.
2. Press  to redial the number.

## 18 Using the phone


### Paging

You can alert handset users that they are wanted or locate a missing handset. (Paging calls cannot be answered by a handset.)






1. Press  on the base. The handset(s) ring. Display shows **Paging**.
2. To stop a handset ringing press any button on the keypad.

### Direct Call




You can enter a telephone number into the handset which can be used as an emergency quick dial – for example by a babysitter.

When direct call is switched on, press any button on the handset (except ) and the direct call telephone number will be dialled automatically.




### Set a direct call number

1. Press , then scroll down to **Direct Call**. Press  again and scroll down to **Number**. Press .
2. Enter the telephone number you want. Press .
3. Press *and hold*  to return to standby.

### Switch direct call on

1. Press , then scroll down to **Direct Call**.
2. Press  and scroll down to **On**. Press  to confirm.  
The display will show **Direct Call** until you switch direct call off.

### Switch direct call off

1. Press . Your handset displays **Direct Call**. Press  and scroll up to **OFF**.
2. Press  to switch direct call off.

# Phonebook

## Entering names

Use the keypad letters to enter names, e.g. to store TOM:

Press **8** *once* to enter T.

Press **6** *three times* to enter O.



Press **6** *once* to enter M.

## Writing tips

Press **1** *once* to insert a space  
*twice* to insert number 1  
*three times* for underscore  
*four times* for a hyphen

Available characters are displayed at the top of the screen.

## Inserting numbers/characters









Use  button to move left and  button to move right to insert characters or numbers.

## Deleting numbers/characters





If you make a mistake, press  to delete the last character or digit.



You can store up to 40 entries in the phonebook. Each entry contains a name and phone number. Names can be up to 8 characters long and numbers up to 20 digits.

## Add a new phonebook entry











1. Press  then  to scroll to Ed. Phonebook. Press . Display shows **Add Entry**.
2. Press  to display **Name**. Use the keypad to enter a name.
3. Press . Display shows **Number**. Enter the phone number and press . Display shows **Stored**. It's best to enter the full number, including the area code (see 'Caller Display' on page 23).
4. Either press  to enter another entry or press *and hold*  to return to standby.

## Dial from the phonebook








1. Press  to enter the phonebook.
2. Either, use  and  to scroll to the entry you want and press  to dial.

Or, search alphabetically by pressing the relevant key, e.g. to find TOM, press  and scroll through entries under T, then press  to dial.



### Edit an entry

1. Press , scroll down to Ed. Phonebook and press .
2. Press  to scroll to Edit Entry and press .  
Then scroll to the entry you want to edit and press .  
The name is displayed.
3. Press  to delete characters and enter the new name.  
Press  to confirm. The number is displayed.
4. Press  to delete digits and enter the new number.  
Press  to confirm.
5. Press *and hold*  to return to standby.

### Delete entries

1. Press , scroll down to Ed. Phonebook and press .
2. Press  to scroll to Delete Entry and press .
3. Scroll to the entry you want to delete and press .  
Delete? is displayed.
4. Press  to confirm.
5. Press *and hold*  to return to standby.

### Inserting numbers/characters

Use  button to move left and  button to move right to insert characters or numbers.

## 22 Phonebook

### Pause

You may also need to insert a pause when storing international dialling codes, charge card numbers and with other tele-banking facilities.

For more information on use with a switchboard, see page 43.

### Insert a 'pause' in a stored number

Some internal switchboards may require you to enter an access code (e.g. 9) to get an outside line. So that the switchboard has time to pick up an outside line before the rest of the number is dialled, you may need to add a pause in the dialling sequence. For example:

9	P	0870 605 8047
Switchboard code for an outside line	Pause inserted in dialling sequence	Rest of number

1. When storing a number, at the point you want to insert a pause, press *and hold*  until P is displayed.

You can enter as many pauses as required.

# Caller Display & the calls list

## Caller Display

If you subscribe to a Caller Display service you can see who is calling you on your handset display.

If the caller's number matches an entry stored in the phonebook, the name will be displayed as well.

Caller Display information contains the full telephone number, including the area code. So when storing numbers in the phonebook remember to include the area code, otherwise the caller's number will not match.

## Calls list

Whether you answer a call or not, the caller's number and the date and time of the call are stored in the calls list. The calls list stores the details of your last 20 callers.

You can display, scroll through and dial numbers on the list and copy them into the phonebook.

If a call is received when the calls list is full, the oldest entry will be deleted automatically.

### IMPORTANT

To use Caller Display and Call Waiting you must first subscribe to the service from your network provider. A quarterly fee is payable.

For more information on BT's Calling Features, call BT on Freefone 0800 800 150.

### Caller information not available

Occasionally the telephone number of the caller is not available and cannot therefore be displayed.

In this case your BT Lyric 1100 provides you with some explanatory information.

#### UNAVAILABLE

The number is unavailable.

#### WITHHELD

The caller has withheld their number.

#### RINGBACK

Ringback call.

#### OPERATOR

The call has been made via the operator.

#### PAYPHONE


The caller is ringing from a payphone.

#### INTERNAT

International call.

## 24 Caller Display and the calls list

### New calls indicator






New calls are entries in the calls list that have not yet been viewed.



For example, if someone calls while you are out that call will be added to the calls list as a 'new call'.

The **new calls indicator** shows how many new calls you have.







### View the calls list

1. Press  to open the calls list. Then use the  and  buttons to scroll through the list.
2. If the name and number of the caller has been stored in the phonebook these will be displayed.

### Dial a number in the list

1. Press  to open the calls list then scroll to the entry you want.
2. Press  to dial the number.






### Copy a number to the phonebook

1. Press  to open the calls list, scroll to the entry you want and press . Display shows Add Entry and Delete.
2. Press  or  to select Add Entry then press .
3. Enter the name and press  to confirm.

Once copied to the phonebook the entry will be deleted from the calls list.



### Delete from list



1. Press  to open the calls list, scroll to the entry you want and press . Display shows Add Entry and Delete?.
2. Press  or  to select Add Entry or Delete? then press .

## Call Waiting

Providing you have subscribed to your network's provider's Call Waiting service, you will hear a soft beep every 5 seconds if an incoming call arrives while you are already on the phone. This beep is not audible to the person you are speaking to. The second caller's number (and name if stored in the phonebook) will appear on the handset display.

Instead of the engaged tone, the second caller will hear an announcement asking them to hold the line.

### Speak to a second caller



1. Press  to answer the second call and put you current caller on hold. Press  again to return to your first caller and to switch between both callers.

## 26 Caller Display and the calls list

---








The second caller is only charged from the second you answer, not while they are waiting to be connected.

*Or*

2. If you want to end the current call and pick up the waiting call, press . The handset will ring. Press  again to connect to the waiting caller.

# Handset settings

## Handset ringer volume








1. Press  then  to scroll to Handset Menu. Then press .
2. Scroll down to Ring Vol and press . The current setting is played.
3. Use the  and  buttons to select Volume 1-5 or Volume Off. A sample ring is played. Press  to confirm.


While the phone is ringing you can adjust the ring volume by pressing

 or .


## Handset ringer melody

You can set separate melodies for internal and external calls and there are 5 melodies to choose from.

1. Press  then  to scroll to Handset Menu. Then press .
2. Scroll down to Int. Melody or Ext. Melody and press . The current melody is played.
3. Use the  and  buttons to hear different melodies. Press  to select the new melody.

You can now either select a different Internal or External call melody or press and hold  to return to standby.






## 28 Handset settings

When the keypad lock is on, the  icon will be displayed.

### Keypad lock

Locking the keypad prevents numbers from being accidentally dialled while carrying the handset around.

#### Switch keypad lock on











1. Press  then  to scroll to **Keypad lock**. Then press .
2. Press  to select **On** then  to confirm.

#### Switch keypad lock off


1. Press  then  to select **Off**. Press  to confirm.

### Keypad beeps








You can have the keypad and warning beeps switched on or off.

1. Press  then  to scroll to **Handset Menu**. Then press . Display shows **Warning Tones**. Press .
2. Use the  and  buttons to select the tones you want switch on or off: **Key Press**, **Low Battery** or **Out of Range**. Then press .
3. Press  or  to select **On** or **Off**. Press  to confirm.

## Auto-answer








When the handset is on the base, you can answer a call just by picking it up. When auto-answer is switched off, you will always have to press  to answer a call. The default setting is **On**.

### Switch auto-answer on/off

1. Press  then  to scroll to Handset Menu. Then press .
2. Scroll down to Auto Answer. Press  then  or  to select On or Off. Press  to confirm.



## Name a handset

The handset name is pre-set to BT LYRIC. If you add additional handsets, you can give each handset a different name, for example Kitchen or Office.

1. Press  then  to scroll to Handset Menu. Then press .
2. Scroll down to Handset Name and press .
3. Press  to delete the current name. Enter the name you want. (If you make a mistake, press  to delete the last character.) Press  to confirm.

Each handset name can have a maximum of 8 characters.

### Inserting numbers/characters








Use  button to move left and  button to move right to insert characters or numbers.

### Additional handsets

See page 35 for more information on adding additional handsets.







## Handset language

You can change the language used on the handset display. Handset languages are English, French, German, Dutch, or Portuguese.

1. Press  then  to scroll to Handset Menu. Then press .
2. Scroll down to Language and press .
3. Use the  and  buttons to scroll through the languages English, Français, Deutsch, Dutch or Português. Press  to confirm.










# Base settings

## Set date and time

1. Press  then  to scroll to **Setup**, then press .
2. Press  to select **Date/Time Settings**. Display shows the date.
3. Enter the day and month, e.g. 17 June = 17 Jun.  
Press . Display shows the time.
4. Enter the time using the 24 hour clock, e.g. 4.30pm = 16.30. Press  to confirm.

## Base ringer volume

Choose from 5 levels (1–5) or you can turn the ringer off.

1. Press  then  to scroll to **Setup**. Then press .
2. Press  to scroll to **Base Volume** and press .  
The current volume setting is played and displayed.
3. Use the  and  buttons to select **Volume 1-5** or **Volume Off**. Press  to confirm.
4. Press *and hold*  to return to standby.

If you subscribe to your network's Caller Display service, the date and time are set automatically when your BT Lyric 1100 receives its first call.

When new handsets are registered to the base, they will also receive the current date or time.

If the mains power to the base is cut, the date and time are saved on the handset.










## 32 Base settings

### IMPORTANT

If you change the base PIN, make sure you keep a record of the new number on page 54.









### Base ringer melody

Choose from 5 base ringer melodies.

1. Press  then  to scroll to **Setup**. Then press .
2. Press  to scroll to **Base Melody** and press .
3. Use the  and  buttons to hear different melodies. Press  to select the new melody.
4. Press *and hold*  to return to standby.

### Base PIN (Personal Identification Number)






You need your base PIN when registering handsets and for other optional settings. The default PIN is **0000**, so you may wish to change this to a more unique number.

1. Press  then  to scroll to **Setup**. Then press .
2. Scroll down to **PIN Code** and press .
3. Enter the current 4-digit PIN (default **0000**) then press  to confirm.
4. Enter the new 4-digit PIN, press  and enter the new PIN again. Press  to confirm.
5. Press *and hold*  to return to standby.



### Reset to original settings

You can reset your BT Lyric 1100 to its original/default settings.

1. Press  then  to scroll to **Setup**. Then press .
2. Scroll down to **Default** and press .
3. Enter the current 4-digit PIN (default **0000**) then press  to confirm. The handset display flashes **BASE 1** and then **LYRIC 1**. Your BT Lyric 1100 is now reset.

A list of the default settings is shown on the following page.

#### WARNING

Resetting your phone to its original settings will delete any entries in the Phonebook, Redial and Calls list.


## 34 Section

**Default settings are:**

Earpiece volume .....	<b>3</b>
Handset & base ringer volume .....	<b>3</b>
Internal and External handset & base melody .....	<b>1</b>
Base PIN code .....	<b>0000</b>
Handset name .....	<b>BT LYRIC</b>
Handset language .....	<b>English</b>
Button beeps .....	<b>On</b>
Battery low indicator beeps .....	<b>On</b>
Out of range warning beeps .....	<b>On</b>
Auto answer .....	<b>On</b>
Dialling mode .....	<b>Tone</b>
Pause after picking up line/ dial out .....	<b>3 seconds</b>
Phonebook .....	<b>Empty</b>
Redial list .....	<b>Empty</b>
Calls list .....	<b>Empty</b>

# Additional handsets & bases

Up to 5 handsets can be registered and operated from any one BT Lyric 1100 base. Each handset can be registered on up to 4 bases. This gives you the flexibility to build your own phone system without the need for any additional wiring or sockets.



## Features available with additional handsets:

- Transfer an external call from one handset to another.
- Make an internal call between handsets.
- Conduct a 3-way conversation between an external caller and another internal handset.
- Make an internal call between two handsets while a third is making an external call.
- Set a ring priority so that one handset rings before all the others.

## 36 Additional handsets & bases

### Please note

Your handset is supplied pre-registered as BT Lyric 1 to its base (Base 1).

Each additional handset you buy must be registered with the base.

Remember to charge the batteries of new handsets for at least 16 hours before first use.

If the display shows Not Sub, and (SIGNAL) is flashing, your handset is not yet registered with the base.







### Naming additional handsets

Once you have registered additional handsets you may wish to give them a different name, see page 29.

Please note you cannot de-register the handset you are using.








### Register handset to base


Make sure the handset is close to the base.

1. **At the base:** Press *and hold*  until you hear two beeps (after about 10 seconds). Release .
2. **At the handset:** Press , then scroll to **Registration**. Press . Display shows **Base 1-4**. Ticks indicate other bases the handset is registered to (if any).
3. Enter 1-4 for the base you want to register to followed by your 4-digit PIN (default 0000). Press .
4. Display shows **Base search 1, 2, 3, 4**. The  icon flashes until the handset locates the base.

If the handset does not find the base, it will try to go back to the previous menu. If this happens, try registering again using a different base number.







### De-register handsets

1. Press  then scroll down to **Setup** and press .
2. Scroll down to **Remove HS** and press .
3. Enter your 4-digit PIN (default 0000). Press .
4. Use the  and  buttons to select the handset (1-5) you want to de-register. Press .

5. Press  again to confirm.

Once de-registered, the handset display shows `Not Sub.`

### Register handset to a different make of base

1. **At the base:** Set the base in registration mode, see the base's user guide.
2. **At the handset:** Press , then scroll to `Registration`. Press . Display shows `Base 1-4`. Ticks indicate other bases the handset is registered to (if any).
3. Enter `1-4` for the base you want to register to. Press .
4. Enter your 4-digit PIN (default 0000). Press .
5. Display shows `Base search 1; 2; 3 4`. The  icon flashes until the handset locates the base. When the base is located press  to confirm.

If the handset does not find the base, it will try to go back to the previous menu. If this happens, try registering again using a different base number.





#### Base compatibility

The other manufacturer's base must be GAP compatible.

Check with the literature that came with the other base to see if this is this case.







### Base identity number

Follow these instructions to check the individual code number of the base.

1. Press  then scroll down to **Setup** and press .
2. Scroll down to **Base ID**. Press  to display the number.
3. Press *and hold*  to return to standby.

### Select base












If a handset is registered to more than one base, you can select which one it will use. (For more information on registering your handset to another base, see page 36.)

1. Press  then scroll down to **Setup** and press .
2. Scroll down to **Select Base** and press .
3. Use the  and  buttons to select the base (1–4) and press  to confirm.

### Set ring priority








This allows you to make the base of one of the handsets ring before the others when you receive an external call.

You can select which base or handset will ring and how many rings it can make before the others start to ring.

1. Press  then  to scroll to **Setup**. Then press .
2. Scroll down to **Ring Priority** and press .
3. Scroll down to **Def. Priority** and press .
4. Use the  and  buttons to select the base or handset you want, then press .
5. Now use the  and  buttons to select the number of rings 1–9, then press  to confirm.

### Switch ring priority on/off

Once ring priority has been set, you can switch it on or off to provide normal ringing.



1. Press  then  to scroll to **Setup**. Then press .
2. Scroll down to **Ring Priority** and press .
3. Press  to select **On** or **Off** and press  to confirm.
4. Press *and hold*  to return to standby.

The Int icon will be displayed during an internal call.

## Use of additional handsets



### Making internal calls


If you have more than one handset registered to the base, you can make internal calls between handsets.

1. Press *and hold*  until Internal Call is displayed and enter the handset number (1–5) you want to call.
2. Press  to end the call.

### Transferring calls

You can transfer an external call to another handset registered to the base.



1. **During an external call:** Press *and hold*  until Internal Call is displayed.
2. Enter the number of the handset you want to transfer the call to. The caller is put on hold. When the other handset answers you can talk to them then press  to transfer the call.


If the handset does not answer, press *and hold*  to speak to your caller again.




### 3-way conversation

You can talk to one external caller and another internal caller at the same time on your handset.

1. **During an external call:** Press *and hold*  to put your caller on hold.
2. Enter the handset number you want.
3. When the handset answers, press *and hold*  for about 3 seconds. You can now start your 3-way conversation.





If the handset does not answer, press *and hold*  to speak to your caller again.

4. Press  to end the call.

## Room monitor


If you have at least two handsets registered to your BT Lyric 1100 base you can leave one handset in a room and monitor the sounds in the room by making an internal call to another handset. This could be used, for example, in a child's bedroom.

### Switch room monitor on



1. Press , scroll down to Monitor Mode then press .
2. Use the  and  buttons to select Off or On.

## 42 Additional handsets & bases

---

3. Press  to confirm. The display shows Monitor Mode until you switch it off.

### **To use room monitor**

1. Enter the handset number of the handset you have left in the room to be monitored. Press *and hold* .
2. To exit monitor mode, press .

# Switchboard use

## Switchboard compatibility

This product is intended for use within the UK for connection to public telephone network and compatible switchboards, which support tone dialling and timed break recall. If in doubt please consult your network service provider.

## Switchboard external line access code













Some internal switchboards may require you to enter an access code (e.g. 9) to get an outside line. So that the switchboard has time to pick up an outside line, you may also need to add a pause after the access code.

### **To insert an access code followed by a pause**

If you use your phone with two separate switchboards you can set up two separate access codes. Then you can simply select which switchboard you are using your phone with.

This feature can also automatically insert a pause between the access code and the phone number stored in the Phonebook.


## 44 Switchboard use

1. Press  then  to scroll to **Setup**. Then press .
2. Scroll down to **PABX Setup** and press .
3. Scroll down to **PABX 1** and press . **PIN Code?** is displayed.
4. Enter the PIN (default 0000) and press , **PABX Setup** is displayed. Enter the switchboard access code and press .
5. Scroll down to **Pause Setup** and press . Use the  and  buttons to select the length of pause – 3 or 5 seconds. Press  to confirm.
6. Press *and hold*  to return to standby.

For more information on BT's Calling Features, call BT on Freephone 0800 800 150.

Alternatively, if you are not with BT, contact your service provider for more information.









## Recall

The  button is used when connected to certain switchboards and for some BT Calling Features or those services available via your network provider.

## Dialling mode

Your BT Lyric 1100 is pre-set to tone dialling. If required you can switch it to pulse dialling.


### To set dialling mode

1. Press  then  to scroll to Setup. Then press .
2. Scroll down to Dialling Mode and press .
3. Press  or  to select either Tone or Pulse, then press  to confirm.
4. Press *and hold*  to return to standby.

# Help

Many common problems are caused by the telephone and power cables being incorrectly connected, not connected at all, or the power being turned off.

Please check that your BT Lyric 1100 has been correctly set up, *see page 6*, before ringing the BT Lyric 1100 Helpline.

<b>Problems</b>	<b>Possible cause</b>
<b>No display</b>	The batteries may be dead. Recharge or replace the batteries.  Is the handset switched off? To switch the handset on, <i>see page 15</i> .
<b>No dial tone</b>	Check that the telephone line cord is plugged into the phone socket.  Check that the base is connected to the mains power and switched on.
<b>You cannot link up with the base</b>	Check that the base is connected to the mains power and switched on.  Is the display showing a flashing  icon? You may be out of range. Move the handset closer to the base.  Are the batteries low or flat? If so, charge the batteries or replace them if necessary.

<b>Problems</b>	<b>Possible cause</b>
	Your handset could be registered to another base. If using more than one base, check that you are connected to the correct base, <i>see page 38</i> .
<b>No ring on the handset</b>	Check that the ringer volume is switched on, <i>see page 27</i> . Check that the base is plugged into the phone socket and that it is also connected to the mains power and switched on.
<b>Buzzing noise on my radio, TV, computer or hearing aid</b>	Sometimes, your BT Lyric 1100 and other DECT GAP compatible handsets can interfere with other electrical equipment if it is placed too close. Move it at least one metre away from such appliances.
<b>The base is not charging the handset</b>	Check that the base is plugged into the mains socket and switched on.  Check that you are using the correct power adaptor plug (item code 872260).  Check that the handset is sitting correctly in the base.  Check that the handset batteries have been correctly installed.

## 48 Help

<b>Problems</b>	<b>Possible cause</b>
<b>Cannot adjust an option in the base</b>	Someone else might be making changes using another handset. Try again when the other handset user has finished.

### BT Lyric 1100 Helpline 0870 605 8047

Call the dedicated BT Lyric 1100 Helpline:

- if you are having difficulties using your BT Lyric 1100;
- if you need replacement batteries or mains power lead.

Lines open 9am – 5.30pm,  
Monday to Friday.  
9.30am – 2.30pm Saturday.

### BT accessories and replacement items

For a full range of accessories and replacement items for BT products please call 0870 240 5522, or visit:





# General information

## **IMPORTANT**

This equipment is not designed for making emergency telephone calls when the power fails. Alternative arrangements should be made for access to emergency services.

## Safety

### **General**

- Only use the power supply included with the product. Using an unauthorised power supply will invalidate your guarantee and may damage the telephone. The item code for the mains power supply is 872260. If you have purchased the BT Lyric 1100 Twin, the item code for the charger mains power supply is 003313.
- Only use approved AAA NiMH rechargeable batteries.
- Do not open the handset or base. This could expose you to high voltages or other risks. Contact the BT Lyric 1100 Helpline on 0870 605 8047 for all repairs.
- Radio signals transmitted between the handset and base may cause interference to hearing aids.
- It is recommended that advice from a qualified medical expert be sought before using this product in the vicinity of emergency/intensive care medical equipment.
- It is recommended that if you have a pacemaker fitted you check with a medical expert before using this product.
- Your product may interfere with other electrical equipment, e.g. TV and radio sets, clock/alarms and computers if placed too close. It is recommended that you place your product at least one metre away from such appliances to minimise any risk of interference.

## 50 General information

---

- Never dispose of batteries in a fire. There is a serious risk of explosion and/or the release of highly toxic chemicals.

### **Cleaning**

Simply clean the handset and base with a damp (not wet) cloth, or an anti-static wipe. Never use household polish as this will damage the product. Never use a dry cloth as this may cause a static shock.

### **Environmental**

- Do not expose to direct sunlight.
- The product may heat up when the battery pack is being recharged. This is normal. However, we recommend that you do not place the product on antique/veneered wood to avoid damage.
- Do not stand your product on carpets or other surfaces which generate fibres, or place it in locations preventing the free flow of air over its surfaces.
- Do not submerge any part of your product in water and do not use it in damp conditions, such as bathrooms.
- Do not expose your product to fire, explosive or other hazardous conditions.
- There is a slight chance that your phone could be damaged by an electrical storm. We recommend that you unplug the power and telephone line cord for the duration of the storm.

## Technical information

### **How many telephones can you have?**

All items of telephone equipment have a Ringer Equivalence Number (REN), which is used to calculate the number of items which may be connected to any other telephone line. Your BT Lyric 1100 has a REN of 1. A total REN of 4 is allowed. If the total REN of 4 is exceeded, the telephone may not ring.

With different telephone types there is no guarantee of ringing, even when the REN is less than 4.

- Only use approved the supplied mains power adaptor, item code: 876220.  
If you have purchased the BT Lyric 1100 Twin, the item code for the charger mains power supply is 003313.
- Only use approved AAA NiMH rechargeable batteries.

## Guarantee

Your BT Lyric 1100 digital cordless telephone is guaranteed for a period of 12 months from the date of purchase.

Subject to the terms listed below, the guarantee will provide for the repair of, or at BT's or its agent's discretion the option to replace the BT Lyric 1100, or any component thereof, (other than batteries), which is identified as faulty or below standard, or as a result of inferior workmanship of materials. Products over 28 days old from the date of purchase may be replaced with a refurbished or repaired product.

### **The conditions of this guarantee are:**

- The guarantee shall only apply to defects that occur within the 12 month guarantee period.
- Proof of purchase is required.
- The equipment is returned to BT or its agent as instructed.
- This guarantee does not cover any faults or defects caused by accidents, misuse, fair wear and tear, neglect, tampering with the equipment, or any attempt at adjustment or repair other than through approved agents.
- This guarantee does not affect your statutory rights.

---

### **Within the 12 month guarantee period:**

If you experience difficulty using the product, prior to returning it, please read the 'Help' section beginning on page 46, or contact the BT Lyric 1100 Helpline on 0870 605 8047, 9.00am–5.30pm, Monday to Friday, 9.30am–2.30pm Saturday.

In the unlikely event of a defect occurring, please follow the Helpline's instructions for replacement or repair.

### **Outside of the 12 month guarantee period:**

If your product needs repair after the guarantee period has ended, the repair must meet the approval requirements for connection to the telephone network. We recommend that you contact BT's approved repair agent, TecLogic on 01672 564444 or a local qualified repairer.

### **Returning your phone**

If the Helpline is unable to remedy your problem they will ask you to return the product. Where possible, pack the product in its original packaging. Please remember to include all parts, including the line cords, power supply units and the original batteries. (Please note that we cannot take responsibility for goods damaged in transit.) Please obtain and keep proof of posting from the Post Office.

## 54 General information

---

### For your records

Date of purchase:

Place of purchase:

Serial number:

For guarantee purposes proof of purchase is required so please keep your receipt.

Enter your base PIN here:

[ / / / ]

(see page 32 for more information)

## R&TTE

This product is intended for use within the UK for connection to the public telephone network and compatible switchboards.

This equipment complies with the essential requirements for the Radio Equipment and Telecommunications Terminal Equipment Directive 1999/5/EC.

## Declaration of Conformance

Hereby, Suncorp Technologies, declares that this BT Lyric 1100 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

The Declaration of Conformance for the BT Lyric 1100 is published on the website: <http://www.suncorptech.com/bt>

Visit us at [www.bt.com](http://www.bt.com)



### Offices worldwide

The telecommunications services described in this publication are subject to availability and may be modified from time to time. Services and equipment are provided subject to British Telecommunications plc's respective standard conditions of contract. Nothing in this publication forms any part of any contract.

© British Telecommunications plc 2003.  
Registered Office: 81 Newgate Street, London EC1A 7AJ.  
Registered in England No. 1800000.  
BT Lyric 1100 (09/03) 4  
Designed and produced by The Art & Design Partnership Ltd.  
Printed in China

