



Oricom DECT Digital Cordless Telephone with Answering System



USER GUIDE

M800 Series

Keep this user guide for future reference. Always retain your proof of purchase in case of warranty service and register your product on line at: AUSTRALIA: www.oricom.com.au

TABLE OF CONTENTS

SAFETY INFORMATION	1
GETTING STARTED	3
PHONE FUNCTION KEYS	5
BATTERY CHARGING	9
SCREEN DISPLAY ICON	10
MENU TREE	11
TELEPHONE OPERATION	13
HANDSET AND BASE OPTIONS	17
PHONEBOOK	20
CALLER ID	22
CLOCK AND ALARM	23
DO NOT DISTURB	25
BLOCK LIST	26
ADVANCED SETTINGS	27
ANSWERING SYSTEM	29
TROUBNLESHOOTING GUIDE	34
WARRANTY	36
CUSTOMER SUPPORT	38

IMPORTANT

- Avoid exposure of this telephone to moisture or liquid.
- To prevent electric shock, do not open the handset or base cabinet.
- Avoid metallic contact (e.g. metal clips, keys) between the battery contacts and charging conductors.
- There is a slight chance that the telephone could be damaged by an electrical storm. It is recommended that users unplug the phone from the mains supply and telephone socket during a storm.
- Do not use the handset in an explosive hazard area such as where there is gas leaking.
- Follow the local regulations regarding the disposal of your packing materials, exhausted batteries and used phone. Wherever possible, recycle those materials.
- This phone should not be used near intensive care medical equipment. Persons with pacemakers should consult their Doctor or cardiologist before using this phone.
- Clean with a dry, soft, lint-free cloth. Never use cleaning agents, particularly aggressive solvents.
- Because the phone works by sending radio signals between base station and handset, wearers of hearing aids may experience interference in the form of a humming noise.
- Your phone can interfere with electrical equipment such as answering machines, TV and radio sets, clock radios and computers if placed too close. It is recommended that you position the base unit at least one metre from such appliances.
- This telephone complies with applicable safety requirements for exposure to radio waves (EMR). The mean power of this telephone does not exceed 20mW limit at which point testing is required.
- Privacy of communications may not be ensured when using this telephone.
- The earpiece of the handset may attract small metal objects such as staples and pins. Care should be taken when placing the handset near these items.
- This telephone is not designed for making emergency telephone calls when the mains power fails. Always have a corded phone available to be able to make and receive calls to emergency services if the mains power fails.

2

SAFETY INFORMATION

- Do not use your telephone during an electrical storm thunderstorm as it is possible to get an electric shock. Refer to information contained in White pages directory.
- This phone is designed for connection to a PSTN telephone line or an analogue extension port of a PBX system. If you connect this device to a digital extension of a PBX, damage may result to the PBX.

Tip!

It is good practice to put the cordless handset on the charging cradle when it is not in use to ensure that the handset is always fully charged.



WARNING

DO NOT USE STANDARD/ALKALINE BATTERIES IN THIS PRODUCT, AS THERE IS A RISK OF EXPLOSION AND/OR INJURY. ONLY USE THE Ni-MH RECHARGEABLE BATTERIES SPECIFIED IN THIS USER GUIDE. CONTACT ORICOM FOR REPLACEMENT BATTERIES.

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

Never use non-rechargeable batteries. Use recommended type supplied with this product.

- Never use alkaline or lithium batteries.
- Do not dispose of the batteries in a fire, as they can explode.
- Do not open or mutilate the battery. Released electrolyte is corrosive and can cause damage to the eyes or skin. It can be toxic if swallowed.
- Avoid contact with metal objects when handling the battery. These objects could short out the batteries or cause the conductor to overheat resulting in burns.
- Do not attempt to recharge the battery cell by heating it. Sudden release of battery electrolyte can cause burns or irritation to the eyes or skin.

Parts Checklist

Depending on the model you have purchased this pack should contain the following items:

If any of these items are missing, please contact Oricom directly.

	Single	Twin
Base unit	1	1
Cordless handsets	1	2
Charging cradle	0	1
Power adaptors	1	2
Line cord	1	1
User guide	1	1
Handset Rechargeable Ni-MH 1.2V 400mAh Batteries	2	4

If you have a Broadband line

If you connect your telephone to a line with a broadband connection, you must connect an in line filter (not supplied) between the telephone socket and your phone base to ensure that your broadband and m800 will work properly.

If you do not install the filter you will experience interference on the cordless phone and your Broadband may suffer dropouts. Please refer to the user guide of the in line filter for installation.

In a home with broadband, every telephone, fax or answering system must have a in-line filter connected, not just the one at the telephone point that your modem is connected to.

Additional in-line filters can be purchased from electronic stores.

Telephone base and charger installation

1. Plug the smaller end of the power adaptor into the power jack at the bottom of the telephone base.
2. Plug one end of the telephone line into the jack at the bottom of the telephone base.
3. Plug the other end of the telephone line into a telephone wall jack.
4. Plug the larger end of the power adaptor into an electrical outlet not controlled by a wall switch.

CAUTION

Use only the power adaptor that came with this unit. (Telephone base: 6Vdc/500mA, charger: 6Vdc/150mA). Using other power adaptors may damage the unit. Contact your local distributor if you need to order replacement for the power adaptors.

Purchasing additional handsets

You may expand your cordless system by adding more handsets (M8050). These can be purchased separately from the retailer where you purchased the product, or directly from Oricom (Australia) www.oricom.com.au.

The M800 can accommodate a total of 5 cordless handsets.

Battery installation

For optimum battery performance, charge the battery for 14 hours before first use.

1. Remove the battery compartment cover.
2. Insert the AAA rechargeable batteries in the battery compartment, matching the +/- polarity markings.
3. Align the cover against the battery compartment and slide it upwards until it clicks into place.

4. Charge the handset by placing it in the telephone base or charger. The light on the handset is on when charging.

CAUTION

To reduce the risk of fire or personal injury, use only the Oricom approved model (400mAh 1.2V Ni-MH) which is compatible with this unit.


WARNING

- Observe the proper polarity, or direction, of any battery. Reverse insertion of the battery cell can result in leakage or explosion.
- Remove the batteries if you do not plan to use the product for several months at a time.
- Follow the local regulations regarding the disposal of your packing materials, exhausted batteries and used phone. Wherever possible, recycle those materials.

PHONE FUNCTIONS KEYS









5

Telephone base layout (TAM Version)



6


PHONE FUNCTIONS KEYS

	PAGE	- Press to page all system handsets.
	Answer on/off	- Press to turn the answering system on or off.
DND	DND	- Press to turn DND mode on or off.
	Volume down	- Press to decrease the telephone base ringer volume when in standby mode. - Press to decrease the volume during playback or call screening.
	Volume up	- Press to increase the telephone base ringer volume when in standby mode. - Press to increase the volume during message playback or call screening.
Message window	Message window	- Displays the number of messages. - Displays the message number during playback.
	Delete	- Press to delete the message during playback, or press and hold to delete all old messages.
	Repeat	- Press to repeat a message or press twice to play the previous message.
	Play/Stop	- Press to play messages or stop playback.
	Skip	- Press to skip to the next message.

PHONE FUNCTIONS KEYS












7

Handset layout




8

PHONE FUNCTIONS KEYS

	CID/Volume up	<ul style="list-style-type: none"> - Press to review the call log when the telephone is not in use. - While in menu, press to scroll up. - During a call, press to increase the incoming volume.
	OFF/Cancel	<ul style="list-style-type: none"> - During a call, press to hang up. - During programming, press to cancel and exit without making changes.
	(flash)	<ul style="list-style-type: none"> - During a call, press to answer an incoming call if you receive a call waiting alert (if you have subscribed to the call waiting feature from your service provider). - Press to access message playback when in idle mode (for TAM version only)
	Menu/OK/Mute	<ul style="list-style-type: none"> - Press to show menu. - Press to select an item, or to save an entry or setting. - Press to mute a call, press again to resume conversation.
	Delete/INT	<ul style="list-style-type: none"> - Press to delete the last number or letter entered. - Press to initiate an intercom call or transfer a call.
	Phonebook	<ul style="list-style-type: none"> - Press to review the phonebook when the telephone is not in use.
	Talk/Speaker	<ul style="list-style-type: none"> - Press to make or answer a call. - Press to switch to speakerphone during a call or message playback. - During a call, press to switch between speakerphone and normal handset use.
	keylock	<ul style="list-style-type: none"> - Long Press to lock/ unlock the keypad when in idle mode
	-Volume down	<ul style="list-style-type: none"> - While in menu, press to scroll down. - During a call, press to decrease the incoming volume.
	Redial	<ul style="list-style-type: none"> - Press to review redial list.
	#/Pause/Ring off	<ul style="list-style-type: none"> - Press and hold to turn the ringer off. - Press and hold to add a dialling pause when dialling or entering numbers into phonebook.

Battery charging









The following table summarizes the battery charge indicators and what actions need to be taken.

Battery indicators	Battery status	Action
Battery icon is scrolling. 	Battery is charging.	Keep the handset in the telephone base or charger when not in use.
Battery icon is on steady.	Battery is completely charged.	The handset is ready for use. It will take approximately 2 hours for the battery icon to indicate a full charge even if the handset is only removed from the telephone base or charger for a short time and replaced. This is a normal operation and does not indicate a battery issue.
Battery icon is empty and the screen shows LOW BATTERY .	Battery is low.	Place the handset in the telephone base or charger to charge without interruption (at least 30 minutes) before use.
The screen is blank.	Battery has no power while the handset is out of the telephone base or charger.	Place the handset in the telephone base or charger for at least 14 hours without interruption. See troubleshooting for help if the screen remains blank after charging.

10 SCREEN DISPLAY ICON

Screen display icon

The following table summarizes the battery display indicators.

Item	Meaning
	<ul style="list-style-type: none">• Displays when the telephone base is within reception range.• Flashes when the telephone base is out of range.
	<ul style="list-style-type: none">• Scrolls to indicate battery charging when handset is in the telephone base or charger.• Flashes and empty when battery level is low.
	<ul style="list-style-type: none">• Speakerphone is in use.
	<ul style="list-style-type: none">• Displays when there is a new voice mail message. (Available only if you have subscribed to voice mail service from your telephone service provider)
	<ul style="list-style-type: none">• Displays when the alarm is set.
	<ul style="list-style-type: none">• Energy saving mode is activated.
	<ul style="list-style-type: none">• Displays when the ringer is turned off.
	<ul style="list-style-type: none">• Displays when answering system is on.• Flashes when there are new messages.

MENU TREE 11

Menu tree

Main Menu	Sub-menu 1	Sub-menu 2
PLAY MESSAGES (only for TAM version)		
ANS SYSTEM (only for TAM version)	ANSWER MODE	ANSWER & REC
		ANSWER ONLY
		OFF
	ANNOUNCEMENT	
	DEL. ALL OLD	
	RECORD MEMO	
	SETTINGS	RING DELAY
		REMOTE ACCESS
		REMOTE CODE
		HS SCREENING
		VOICE LANG.
PHONEBOOK	ADD NEW	
		EDIT CONTACT
		DELETE ENTRY
		DELETE ALL
BLOCK LIST	ADD NEW	
		EDIT CONTACT
		DELETE ENTRY
		DELETE ALL
PROGRAM DND	OFF ONE TIME DAILY	

12 MENU TREE

CLOCK & ALARM	SET DATE/TIME	
	SET FORMAT	TIME FORMAT
		DATE FORMAT
	ALARM	
	ALARM TONE	
SETTINGS	HANDSET NAME	
	LANGUAGE	
	EQUALIZER	
	ENERGY SAVE	
	AUTO HANG-UP	
	ANTO ANSWER	
HANDSET TONES	RING VOLUME	
	EXT.RING TONE	
	INT.RING TONE	
	KEY BEEP	
BASE TONES	BASE MELODY	
	BASE VOLUME	
ADV SETTING	CALL BARRING	
	PIN	
	REGISTER	
	DEREGISTER	
	RESET	
	RECALL TIME	
	FIRST RING	

TELEPHONE OPERATION 13

Telephone operation

Make a call

1. Press [📞].
2. Dial the phone number after you hear the dial tone.

Redial a call

1. Dial the phone number using the keypad.
If you make an error while dialling, you can press [C] to erase the last digit entered.
2. Press [📞].

Answer a call

Press [📞] to answer an incoming call.

When there is an incoming call, the screen and keypad backlight will be on.

Note:

The screen shows the elapsed time as you talk (in hours, minutes and seconds).

End a call

Press [📞] or place the handset in the telephone base or charger to end a call.

Speakerphone

Anytime during a call, press [📞] to switch between speakerphone and normal handset use. When the speakerphone is active, the handset screen shows [📞].

Note:

Using the speakerphone will drain the battery faster than the normal handset use.

Volume control

You can adjust the volume of the handset or speakerphone anytime during a call.

On the handset, press [🔊] to increase or [🔇] to decrease the volume.

Note:

Only the listening volume can be adjusted.

Make a call using the redial memory

The last 10 telephone numbers previously dialled are stored in the redial list (up to 24 digits each).

1. Press [📞].
2. [🔍]/[🔽]: select the desired phone number -> [📞] to dial.

14 TELEPHONE OPERATION

Save a number from the redial list to the phonebook

1. .
2. /[]: select the desired phone number -> .
3. /[]: SAVE NUMBER -> .
4. Enter the name by using the keypad and then press .
5. Edit the number by using the keypad if necessary, and then press .

Delete number from the redial list

1. .
2. /[]: select the desired phone number -> .
3. /[]: DELETE -> -> CONFIRM? -> to delete the selected number.

-OR-

/[]: DELETE ALL -> -> CONFIRM? -> to delete all numbers.

Mute

The mute function allows you to turn off the microphone while on a call. You can hear the other party but the other party cannot hear you.

1. Press during a call.
2. Press again to resume conversation.

Note:

The screen shows MUTE ON when mute feature is activated.

Handset page

You can locate a misplaced handset by paging it.

1. Press on the telephone base. All registered handsets beep for one minute.
2. Press on the telephone base or press on any handset to stop paging.



Intercom (only applicable for models with multiple handsets)

The system allows an intercom call between two handsets registered to the same telephone base.



To initiate an intercom call

1. Press .
- If your telephone system has only two handsets registered, the intercom call will be automatically directed to the other system handset.
- If your telephone system has more than two handsets registered, enter the handset number you want to call by using the keypad 1-5.

TELEPHONE OPERATION 15





2. Press  to answer the intercom call on the other handset.
3. To end the intercom call, press .

Notes:

- 1) The intercom call can be cancelled before it is answered by pressing  or  on the originating handset.
- 2) If the handset being called does not answer within one minute, the paging will be cancelled.


To answer an incoming call during intercom

You will hear an alert tone when you receive an incoming call during intercom.

- Press  to answer the incoming call and end the intercom.
- Press  to answer the incoming call and put the intercom on hold. Press and hold  to switch between intercom and the incoming call.
- Press and hold  to conference with both the incoming call and the intercom.


To initiate an intercom during a call

You can intercom with another system handset during a call, or invite another system handset to join.


1. Press  during a call.




- If your telephone system has only two handsets registered, the intercom call will be automatically directed to the other system handset.
- If your telephone system has more than two handsets registered, you will need to enter the handset number you want to intercom to by using the keypad 1–5.

The call is placed on hold while the intercom is established with the other handset.

2. Press  to answer the intercom on the other handset.

Note:

The intercom call can be cancelled before it is answered by pressing  on the originating handset.




3. You can choose from one of the following options for this intercom call.
 - Press and hold  to connect both handsets to the call.
 - Press  on the originating handset to alternate between the intercom and the call.
 - Press  on either handset to terminate the intercom on that handset. The call will continue on the other handset.

16 TELEPHONE OPERATION

Push to talk (PTT) (only applicable for models with multiple handsets)

You can directly broadcast messages to the speakerphone of any registered handset in the system.

To initiate a PTT

1. Press the PTT button on the right side of the handset.
 - If your telephone system has only two handsets registered, the broadcast will be automatically directed to the other system handset.
 - If your telephone system has more than two handset. Press / to select the handset you want to broadcast the message, or select ALL to broadcast to all handsets and then press .
2. PRESS AND HOLD (PTT) TO TALK shows on the screen when the connection is set between the initiating handset and the destination handset.
3. Press and hold the (PTT) button on either handset to start the broadcast.

Note:

Connection set between handsets lasts for 30 minutes after it is established, or 30 minutes after the last broadcast. You will need to perform the above operation again if you want to initiate a PTT to another system handset or after the 30-minute time out.

HANDSET AND BASE OPTIONS 17


Handset options

Ring volume

You can set the handset ringer volume from level 1 to level 5 or turn the ringer off.

1. [MENU] [OK].
2. [F1]/[▼]: HANDSET TONES -> [MENU] [OK].
3. [F1]/[▼]: RING VOLUME -> [MENU] [OK].
5. [F1]/[▼]: select the desired level -> [MENU] [OK].

Note:

Press and hold the [M] key to switch the ringer between on and off when the handset is in standby mode. The  icon displays on the screen when ringer off feature is activated

EXT. Ring Tone

You can select from 10 ring tones.

1. [MENU] [OK].
2. [F1]/[▼]: HANDSET TONES -> [MENU] [OK].
3. [F1]/[▼]: EXT.RING TONE -> [MENU] [OK].
4. [F1]/[▼]: select the desired melody -> [MENU] [OK].

INT. Ring Tone

You can select from 10 ring tones.

1. [MENU] [OK].
2. [F1]/[▼]: HANDSET TONES -> [MENU] [OK].
3. [F1]/[▼]: INT.RING TONE -> [MENU] [OK].
4. [F1]/[▼]: select the desired melody -> [MENU] [OK].

Key tone

The handset can be programmed to emit a tone with each key press. To change the key tone setting:

1. [MENU] [OK].
2. [F1]/[▼]: HANDSET TONES -> [MENU] [OK].
3. [F1]/[▼]: KEY BEEP -> [MENU] [OK].
4. [F1]/[▼]: select ON or OFF -> [MENU] [OK].


Handset Name

To change the handset name:

1. [MENU] [OK].
2. [F1]/[▼]: SETTINGS -> [MENU] [OK].
3. [F1]/[▼]: HANDSET NAME -> [MENU] [OK].
4. Edit the name by using the keypad and then press [MENU] [OK].

18 HANDSET AND BASE OPTIONS









Note:

If you make an error while dialling, you can press  to erase the last digit entered.

Display language











You can select ENGLISH, DEUTSCH, FRANCAIS, ITALIANO, ESPAÑOL, TÜRKÇE, POLSKI or PORTUGUÊS as the display language. The default setting is ENGLISH.

To change the display language:

1. .
2. /[]: SETTINGS -> .
3. /[]: LANGUAGE -> .
4. /[]: select the desired setting -> .











Equalizer

This feature allows you to change the balance of the audio of the handset to best suit your hearing.


1. .
2. /[]: SETTINGS -> .
3. /[]: EQUALIZER -> .
4. /[]: select from NATURAL, BASS or TREBLE.
5. .

Energy save

This feature enables the handset to operate in energy saving mode. With this feature turned on, the handset will automatically turn the handset backlight off.











1. .
2. /[]: SETTINGS -> .
3. /[]: ENERGY SAVE -> .
4. /[]: select ON or OFF -> .

Note:

When ENERGY SAVE is turned on, the  icon shows on the handset screen.

Auto Hang-Up

This feature allows you to release the line automatically when you put the handset back on the charge-cradle.

1. .
2. /[]: SETTINGS -> .
3. /[]: AUTO HANG-UP -> .
4. /[]: select ON or OFF -> .

HANDSET AND BASE OPTIONS 19

Auto Answer

This feature allows you to answer the call automatically when you pick up the handset from the charge-cradle.

1. [MENU
OK].
2. [▲]/[▼]: SETTINGS -> [MENU
OK].
3. [▲]/[▼]: AUTO ANSWER -> [MENU
OK].
4. [▲]/[▼]: select ON or OFF -> [MENU
OK].

Call Waiting

If you have subscribed to Call Waiting service, the earpiece will emit a beep tone to inform you that there is a second incoming call. The number or name of the second caller will also be displayed on your phone if you have subscribed to Caller Id. Please contact your network provider for more information on this service.

Base options

Base ringer melody

You can select from 5 ringer tones.

1. [MENU
OK].
2. [▲]/[▼]: BASE TONES -> [MENU
OK].
3. [▲] -> BASE MELODY.
4. [▲]/[▼]: select the desired melody -> [MENU
OK].

Base ringer volume

You can set the telephone base ringer volume from level 1 to level 5 or turn the ringer off.

1. [MENU
OK].
2. [▲]/[▼]: BASE TONES -> [MENU
OK].
3. [▲]/[▼]: BASE VOLUME -> [MENU
OK].
4. [▲]/[▼]: select the desired setting (LEVEL 1 to 5 or OFF) -> [MENU
OK].

20 PHONEBOOK

Phonebook

Add a phonebook record

1. [MENU
OK].
2. [A/P]/[▼]: PHONEBOOK -> [MENU
OK].
3. [MENU
OK] -> ADD NEW.
4. Enter the name (max. 14 character). Press the key to the corresponding character to display the correct letter.
5. [MENU
OK].
6. Enter the number (max. 20 digits). If you need a pause between digits, press and hold the [≡] until a P appears in the display. This will insert a 3-second pause in the dialling sequence.
7. Press [MENU
OK].

Notes:

1. The phonebook is shared by all handsets. Changes made to the phonebook on any one handset apply to all.
2. The directory can store up to 100 entries with up to 20 digits for each telephone number and 14 characters for each name.

To view/call a phonebook record

Records are stored alphabetically in the phone book. To search the phonebook:

1. [C].

Note:

You can also access the phonebook by pressing [MENU
OK] and selecting PHONEBOOK.

2. [A/P]/[▼].
3. [CALL] to call the displayed entry.

Edit a phonebook entry

1. [C].
2. [A/P]/[▼]: locate a desired entry -> [MENU
OK].
3. [A/P]/[▼]: EDIT CONTACT -> [MENU
OK].
4. Edit the name by using the [ENT] key to erase and backspace, then enter new characters using the keypad keys and press [MENU
OK].
5. Edit the number by using the [ENT] key to erase and backspace, then enter new numbers using the keypad keys and press [MENU
OK].

Delete a phonebook entry

1. [RECALL].
2. [▲]/[▼]: locate the desired entry -> [MENU/OK].
3. [▲]/[▼]: DELETE ENTRY.
4. [MENU/OK] to confirm to delete the selected entry.

Delete all phonebook entries

1. [RECALL].
2. [▲]/[▼]: select any entry -> [MENU/OK].
2. [▲]/[▼]: DELETE ALL.
3. [MENU/OK] to confirm to delete all entries.

22 CALLER ID






Caller ID

Using Caller ID service









IMPORTANT: To use the Caller ID capabilities of this telephone system, you must subscribe to the Caller ID service from your network service provider. Check with your telephone service provider for details. Your telephone stores Caller ID memory for the 40 most recent calls. Each entry holds up to 20 digits for the telephone number and 14 characters for the name.

Review/call from the call log











As calls are received and stored, the display is updated to let you know new calls have been received. To scroll through the Caller ID records:

1.  .
2.  to view from the most recent calls, or  to view the oldest calls.
3. When the desired record is displayed, press  to call.

Save a number to the phonebook

1.  .
2.  : locate the desired record -> .
3. : COPY TO PHBK.
4. Enter the name by using the keypad keys if necessary -> .
5. Edit the number by using the keypad keys if necessary -> .

Delete Caller ID record

1.  .
2.  : locate the desired record -> [].
3.  : DELETE to delete the selected record
-> 
-OR-
 : DELETE ALL to delete all records -> 

CLOCK AND ALARM 23

Clock and alarm

Date and time

You can set the date and time of the telephone system as follows.

1. [MENU/OK].
2. [A/P]/[▼]: CLOCK & ALARM -> [MENU/OK].
3. [A/P] again: SET DATE/TIME.
4. Enter the current month, day and year.
5. [MENU/OK].
6. Enter the current hour and minute. [A/P]/[▼]
select AM or PM -> [MENU/OK].

Time format

The display format of time can either be selected as 12 hour or 24 hour. The default setting is 12 hour. To change your setting:

1. [MENU/OK].
2. [A/P]/[▼]: CLOCK & ALARM -> [MENU/OK].
3. [A/P]/[▼]: SET FORMAT -> [MENU/OK].
4. [A/P] again -> TIME FORMAT.
5. [A/P]/[▼]: select the desired setting (12 HOUR or 24 HOUR) -> [MENU/OK].

Date format

The display format of date can either be selected as Month/Day or Day/Month. The default setting is Day/ Month. To change your setting:

1. [MENU/OK].
2. [A/P]/[▼]: CLOCK & ALARM -> [MENU/OK].
3. [A/P]/[▼]: SET FORMAT -> [MENU/OK].
4. [A/P]/[▼]: DATE FORMAT -> [MENU/OK].
5. [A/P]/[▼]: select the desired setting
(MM/DD or DD/MM) -> [MENU/OK].

Alarm

The alarm can be programmed to sound once or daily for one minute. The alarm setting is independent to each handset.

1. [MENU/OK].
2. [A/P]/[▼]: CLOCK & ALARM -> [MENU/OK].
3. [A/P]/[▼]: ALARM -> [MENU/OK].
4. [A/P]/[▼]: select the desired alarm option -> [MENU/OK].
OFF: Turn alarm off (settings completed).
ONCE: The alarm sounds once at the set time.
DAILY: The alarm sounds daily at the set time.
5. Enter the desired hour and minute -> [A/P]/[▼]
select AM or PM.
6. [MENU/OK].

24 CLOCK AND ALARM

Alarm tone

You can select from 3 alarm melodies.

1. [MENU
OK ⏻].
2. [⏻]/[▼]: CLOCK & ALARM -> [MENU
OK ⏻].
3. [⏻]/[▼]: ALARM TONE -> [MENU
OK ⏻].
4. [⏻]/[▼]: select the desired alarm tone -> [MENU
OK ⏻].

DO NOT DISTURB 25

Do not disturb

When **DO NOT DISTURB (DND)** mode is activated, all incoming calls will be silent. This feature only silences the ringer, the incoming number, if you have subscribed to the Caller ID service from your telephone service provider, will be recorded in the Caller ID history as normal.








Global DND

When global DND is activated, all system handsets and the telephone base will be silent when there is an incoming call. Press the DND button on the telephone base to turn this feature on or off.

Handset DND

You can program individual handset to silence during predetermined time frames. This setting is independent to each handset and only silences the ringer of the handset programmed.







To program the **DND** time for individual handset

1. .
2. /[]: PROGRAM DND -> .
3. /[]: select the desired option -> .

ONE TIME: The telephone silences once during the set time.

DAILY: The telephone silences daily during the set time.

OFF: Turn DND off (settings completed).

4. Enter the desired start time. []/[]: select AM or PM -> .
5. Enter the desired stop time. []/[]: select AM or PM -> .

Notes:

When global DND is turned on, individual handset will continue to be in DND mode even after the set DND time on the handset ends.

26 BLOCK LIST

Block list

You can program telephone numbers into the block list so that the telephone silences when a call is received from one of the blocked numbers. The handset shows BLOCK LIST when the programmed numbers call and will not record the number in the Caller ID history.

To add a new entry

1. [MENU] [OK].
2. [▲] / [▼]: BLOCK LIST -> [MENU] [OK].
3. [MENU] [OK] again -> ADD NEW.
4. Enter the desired number -> [MENU] [OK].

To view the list

1. [MENU] [OK].
2. [▲] / [▼]: BLOCK LIST -> [MENU] [OK].
3. [▲] / [▼] to browse through the block list.

To edit an entry

1. [MENU] [OK].
2. [▲] / [▼]: BLOCK LIST -> [MENU] [OK].
3. [▲] / [▼]: select the desired entry -> [MENU] [OK].
4. [▲] / [▼]: EDIT CONTACT -> [MENU] [OK].

5. Edit the number by using the [8H] key to erase and backspace, then enter new numbers by using the keypad keys and press [MENU] [OK].

To delete an entry

1. [MENU] [OK].
2. [▲] / [▼]: BLOCK LIST -> [MENU] [OK].
3. [▲] / [▼]: select the desired entry -> [MENU] [OK].
4. [▲] / [▼]: DELETE ENTRY -> [MENU] [OK] to confirm.

To delete all entries

1. [MENU] [OK].
2. [▲] / [▼]: BLOCK LIST -> [MENU] [OK].
3. [▲] / [▼]: select any entry -> [MENU] [OK].
4. [▲] / [▼]: DELETE ALL -> [MENU] [OK] to confirm.

ADVANCED SETTINGS 27

Advanced settings

Call Barring

This feature allows you to bar outgoing calls.

1. [MENU] [OK].
2. [▲]/[▼]: ADV SETTING -> [MENU] [OK].
3. [▲]/[▼]: CALL BARRING -> [MENU] [OK].
4. Enter the PIN (default: 0000) -> [MENU] [OK].
5. [▲]/[▼]: MODE -> [MENU] [OK].
6. [▲]/[▼]: select [ON] or [OFF] -> [MENU] [OK].
7. [▲]/[▼]: NUMBER -> [MENU] [OK].
8. [▲]/[▼]: select [NUMBER 1], [NUMBER 2] or [NUMBER 3] -> [MENU] [OK].
9. ENTER NUMBER -> [MENU] [OK].

Notes:

"CALL BARRING" will be displayed on the handset screen when it is set as ON.

PIN

The default PIN is 0000. To change the PIN:

1. [MENU] [OK].
2. [▲]/[▼]: ADV SETTING -> [MENU] [OK].

3. [▲]/[▼]: PIN -> [MENU] [OK].
4. Enter the old code (default: 0000) -> [MENU] [OK].
5. Enter the new code -> [MENU] [OK].
6. CONFIRM CODE: enter the new code again -> [MENU] [OK]. "STORED" will be displayed on HS screen when it is changed successfully.

Registering a handset

The telephone system can support up to a total of 5 cordless handsets. Handsets that were included with your main base are pre-registered.

To add or re-register a handset:

1. Press and hold [O] on the base for 5 seconds until a beep sounds.
2. Press [MENU] when handset displays REGISTER YOUR HANDSET.
3. Enter the PIN (default: 0000) -> [MENU] [OK].

A beep sounds on the handset when the registration is successful and displays "REGISTERED" on HS screen.

Notes:

An error tone will sound if the registration is not successful.

28 ADVANCED SETTINGS

Deregistering a handset

1. [MENU OK].
2. [F]/[▼]: ADV SETTING -> [MENU OK].
3. [F]/[▼]: DEREGISTER -> [MENU OK].
4. Enter the PIN (default: 0000) -> [MENU OK].
5. [F]/[▼]: select the desired handset -> [MENU OK].

Reset

This feature allows you to restore all system settings, except the answering system messages and phonebook, to default settings. This feature could be useful, for example, if you have forgotten the security code to access the answering system remotely.

1. [MENU OK].
2. [F]/[▼]: ADV SETTING -> [MENU OK].
3. [F]/[▼]: RESET -> [MENU OK].
4. HS displays [CONFIRM?] --> [MENU OK].

Note:

All settings under the **ANS SYSTEM, BLOCK LIST, PROGRAM DND, CLOCK & ALARM, SETTINGS, HANDSET TONES, BASE TONES and ADV SETTING** menus in the handset will be restored to default settings, the redial list and call log will also be cleared.

Recall time

This setting allows you to choose between SHORT or LONG to accommodate the setting of your telephone service provider for using customer calling service, such as call waiting.

To change the recall time:

1. [MENU OK].
2. [F]/[▼]: ADV SETTING -> [MENU OK].
3. [F]/[▼]: RECALL TIME -> [MENU OK].
4. [F]/[▼]: Select the desired setting -> [MENU OK].

First Ring

This menu is to enable/ disable the unit start ringing from the 1st ring during the incoming call.

1. [MENU OK].
2. [F]/[▼]: ADV SETTING -> [MENU OK].
3. [F]/[▼]: FIRST RING -> [MENU OK].
4. [F]/[▼]: select [ON] or [OFF] -> [MENU OK].

ANSWERING SYSTEM 29

Answering system

Turning the answering system on or off

Using the telephone base:

Press [Ⓢ] on the telephone base to turn the answering system on or off. The [Ⓢ] button will light when the answering system is on.

Using a handset

1. [MENU [OK]].
2. [⬆]/[▼]: ANS SYSTEM -> [MENU [OK]].
3. [MENU [OK]]: ANSWER MODE.
4. [⬆]/[▼]: [ANSWER & REC.], [ANSWER ONLY] or OFF -> [MENU [OK]].

Answering system and voice mail

Your telephone has a built-in answering system and voicemail indicator (if you subscribe to voicemail offered by your telephone service provider). They are independent features and each alerts you to new messages differently.

To listen to your voicemail, follow the instructions provided by your voicemail service provider.


Message capacity

The answering system can record up to 59 messages. Each message can be up to 3 minutes in length, and the total recording time is 20 minutes. When the message capacity is full, the answering system only plays the outgoing announcement but will not record any message.

Telephone base volume

Use the [Ⓢ] button to adjust the playback volume at the telephone base to a comfortable level (a beep tone will sound when the volume reaches the maximum or minimum level.)

New message indicator

When there are new messages on the answering system, the number of new messages flashes on the message window on the telephone base, the  icon flashes and NEW MESSAGE displays on the handset screen.

Outgoing Announcement (OGA)

When the answering system answers a call, the pre-recorded outgoing announcement is played to the caller unless you have recorded your own outgoing announcement.

30 ANSWERING SYSTEM

Record an outgoing announcement (OGA)

To record your OGA:

1. [MENU] [OK].
2. [▲] / [▼]: ANS SYSTEM -> [MENU] [OK].
3. [▲] / [▼]: ANNOUNCEMENT -> [MENU] [OK].
4. [▲] / [▼]: ANSWER & REC. -> [MENU] [OK].
5. [▲] / [▼]: RECORD OGA-> [MENU] [OK].
6. After a beep sounds, speak into the handset as you would normally during a call while recording your OGA (2 minutes maximum).
7. [MENU] [OK] when finished. The system will then play back the recorded message.

Delete your recorded OGA

If you want to use the pre-recorded outgoing announcement, simply delete your recorded OGA.

1. [MENU] [OK].
2. [▲] / [▼]: ANS SYSTEM -> [MENU] [OK].
3. [▲] / [▼]: ANNOUNCEMENT -> [MENU] [OK].
4. [▲] / [▼]: ANSWER & REC. -> [MENU] [OK].
5. [▲] / [▼]: DELETE -> [MENU] [OK].

Play the current outgoing announcement

The following steps allow you to listen to the current outgoing announcement. The answering system plays the pre-recorded outgoing message if you have not recorded your own.

To listen to the current outgoing announcement:

1. [MENU] [OK].
2. [▲] / [▼]: ANS SYSTEM -> [MENU] [OK].
3. [▲] / [▼]: ANNOUNCEMENT -> [MENU] [OK].
4. [▲] / [▼]: ANSWER & REC. -> [MENU] [OK].
5. [MENU] [OK]: PLAY OGA. The system announces the current outgoing announcement you are using.

Number of rings before the system answers

You can select the number of rings before the answering system answers a call.

1. [MENU] [OK].
2. [▲] / [▼]: ANS SYSTEM -> [MENU] [OK].
3. [▲] / [▼]: SETTINGS -> [MENU] [OK].
4. [MENU] [OK]: RING DELAY.
5. [▲] / [▼]: select the desired setting -> [MENU] [OK].

ANSWERING SYSTEM 31

Note:

If you select TOLL SAVER, the system answers after the second ring if there are new messages, or after the fourth ring if there is no new message. This allows you to check your system to see if there are new messages before incurring toll charges.

Security code for remote access

Your answering system allows you to program a 4-digit security code to get access to the system through any touch-tone telephone. The default security code is 0000.

To view the current remote code:

1. [MENU] [OK].
2. [▲]/[▼]: ANS SYSTEM -> [MENU].
3. [▲]/[▼]: SETTINGS -> [MENU].
4. [▲]/[▼]: REMOTE CODE -> [MENU].
5. [MENU]: VIEW CODE. The screen displays the current remote code.

To change the remote code:

1. [MENU].
2. [▲]/[▼]: ANS SYSTEM -> [MENU].
3. [▲]/[▼]: SETTINGS -> [MENU].

4. [▲]/[▼]: REMOTE CODE -> [MENU].
5. [▲]/[▼]: CHANGE CODE -> [MENU].
6. Use the dial key pad to enter a new 4-digit security code -> [MENU].
7. Enter the code again -> [MENU].

Call screening

When the answering system answers a call, you can listen at the telephone base while the caller leaves a message.

At the telephone base:

The message automatically plays on the telephone base. Use the [VOLUME] button to adjust speaker volume.


From a cordless handset:

1. [MENU]. The caller's voice will be heard while the answering system is recording the message.
2. To intercept during handset screening, press [CALL] button on the handset. The answering system will automatically stop recording when you do so.






Message playback using the telephone base

1. Press [RECALL] on the telephone base to listen to the messages, the number of messages will be displayed on the base screen.

32 ANSWERING SYSTEM



2. The system announces the number of messages and date and time when the message was recorded.
3. Press  again to stop the playback.

Options during playback

Key	Operation
	Press to adjust the listening volume.
	Press to playback or stop messages.
	Press to repeat a message. Press twice to play the previous message.
	Press to skip to the next message.
	Press during playback to delete the current message. Press and hold in idle mode to delete all old messages.

Message playback using the handset

To listen to messages on a handset:


1. Press  twice. Your messages will automatically be played back through the handset speakerphone. Press  to listen to your messages privately through the handset.

2. The following message options are available during playback:

REPEAT: Press 1 to repeat the currently playing message.

STOP: Press 2 to pause the message currently playing, press 2 again to resume playing.

SKIP: Press 3 to listen to the next message.








DEL: Press  to delete the currently playing message.

Delete all messages

Using the telephone base

Press and hold the  key. A confirmation tone sounds to confirm.

Using a handset

1. .
2. /: ANS SYSTEM -> .
3. /: DEL.. ALL OLD.
4.  to confirm

ANSWERING SYSTEM 33

Message window

The table below summarizes the messages displayed on the telephone base display.

-	When the answering system is turned off.
00 (ON steadily)	There are no messages in the answering system.
1-59 (flashing)	Total number of new messages.
1-59 (On steadily)	Total number of old messages.
F (flashing)	Memory is full.
CL (flashing)	Time is not set and there are old messages.
LA (flashing)	The telephone is being accessed remotely.
LA/1-59 (alternating)	The telephone is being accessed remotely and the alternating number indicates the total number of messages.
L0-L5 (On steadily)	Telephone base volume level when adjusting.

Access the answering system remotely

1. Dial your phone number from any touch-tone telephone.
2. Once your answering system takes your call

and you hear your outgoing announcement, press the [#] key.

3. Enter your security code using the numeric keypad on the touch-tone telephone. The system will start playing messages after you hear a confirmation tone.

Notes:

1. If your answering system is off, you will not hear your outgoing announcement. The system will answer your call after 10 rings.
2. If you have entered an incorrect security code, the system will ask you to enter the code again.
3. If you have forgotten the security code, you will need to reset the system. The security code will be restored to its default setting as 0000 after system reset.

Remote access commands

Touch-tone	Remote command
1	Replay the current or previous message.
2	Play/stop messages.
3	Skip to the next message.
4	Turn the answering system on or off.
0	Delete the current message.

34 TROUBLESHOOTING GUIDE

Troubleshooting guide

If your telephone system is not operating properly, first try this general reset procedures:

1. Unplug all power a dapters from the power outlets.
2. Disconnect the telephone line cord from the base or modular jack.
3. Remove the battery compartment covers and unplug all handset battery packs.
4. After a few minutes, re-install all handset battery packs, making sure that the connectors are snug and the wires are not pinched before replacing all battery compartment covers.
5. Plug the power adaptors for the base and any chargers back into their power outlets. Be sure not to use outlets that are controlled by wall switches or timers.
6. Place all handsets in the telephone base or chargers to charge without interruption for at least 30 minutes before use.
7. Plug the line cord into the telephone base or modular jack and verify operation.

General Performance

Problem	Cause/solution
Cannot hear a dial tone.	<ul style="list-style-type: none">• Increase the volume on the handset.• Disconnect the telephone line cord from the base unit and connect it to a known working telephone. If the known working telephone operates properly, contact our customer support center for warranty information.
Handset does not ring.	<ul style="list-style-type: none">• The ringer may be off. Increase the ringer volume.• Make sure your handset is charged.
You experience audible static, noise, or fading in and out.	<ul style="list-style-type: none">• The handset may be near the end of range limit. Move the handset closer to the base unit.• If you are using a line with DSL service, make sure you have properly installed the DSL filters supplied by your service provider.• Try to relocate the base unit and use the handset away from sources of electrical interference.

TROUBLESHOOTING GUIDE 35

Caller ID

Problem	Cause/solution
Caller ID information is not displayed.	<ul style="list-style-type: none">You must subscribe to Caller ID service from your service provider/telephone company.Make sure the base unit is plugged directly into a telephone modular jack. If you are using a line with ADSL service, make sure you have properly installed the ADSL filters supplied by your service provider.
While on a call, new caller ID information is not displayed.	<ul style="list-style-type: none">You must subscribe to Caller ID with Call Waiting service from your service provider/telephone company.

Answering system

Problem	Cause/solution
The unit does not record new messages.	<ul style="list-style-type: none">Make sure the answering system is on.The message memory may be full. Some messages will need to be deleted.
Cannot access the answering system locally through a system handset.	<ul style="list-style-type: none">The system may be in use by another party.The system is busy recording a message.
Cannot operate the answering system remotely.	<ul style="list-style-type: none">You must use a touch-tone telephone for remote access.Make sure you follow the remote access procedures in this user's guide.

36 WARRANTY

Warranty information (Australia)

Oricom makes no other warranties or conditions, express or implied, including as to acceptable quality and fitness for a particular purpose, except as stated in this Warranty. Any implied warranties that may be imposed by law are limited in duration to the Warranty Period. Oricom warrants that the product is free from defects in materials or workmanship during the Warranty Period. This Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia.

This warranty in no way affects your statutory warranty rights under the Competition and Consumer Act 2010 or any other similar legislation.

The Warranty Period will be 1 year from the date of purchase of the product evidenced by your dated sales receipt. You are required to provide proof of purchase as a condition of receiving warranty services. You are entitled to a replacement product or repair of the product according to the terms and conditions of this document if your product is found to be faulty within the Warranty Period. This Warranty extends to the original purchaser only and is not transferable. Batteries or Battery Packs (if supplied) with this product are covered under this warranty for a period of 90 days.

Products distributed by Oricom are manufactured using new materials or new and used materials

equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Warranty Period of the Oricom branded product in which they are installed, whichever is longer. During the Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof.

All component parts removed under this Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance. Oricom does not warrant that the operation of the product will be uninterrupted or error free.

Oricom is not responsible for damage that occurs as a result of your failure to follow the instructions that came with the product. These terms and conditions together with any specific terms and conditions contained in the user guide to the product purchased constitute the complete and exclusive agreement between you and Oricom regarding the product. No change to the conditions of this

Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom. Oricom will not be in breach of a warranty expressly set out in this User Guide or under the Competition and Consumer Act 2010 and excludes any liability for damages or any other remedy arising under any other legislation or the common law if the damage occurs as a result of:

1. failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;
2. negligence on your part or misuse by you of the product;
3. an uncontrollable external cause which results in the product not functioning including but not limited to power failure, lightning or over voltage; and
4. modification to the product or services carried out on the production by anyone other than Oricom or Oricom's authorised service provider.

Oricom will not be liable for any damages caused by the product or the failure of the product to perform, including any lost profits or savings or special, incidental or consequential damages. Oricom is not liable for any claim made by a third party or made by you on behalf of a third party. This limitation of liability applies whether damages are sought, or a claim made, under this Warranty or as a tort claim (including negligence and strict product liability), a contract claim or any other claim. However, this limitation of liability will not apply to claims for

personal injury. Nothing in this Warranty excludes, restricts or modifies any condition, warranty, right or remedy which pursuant to the Competition and Consumer Act 2010 applies to this Warranty and which may not be so excluded, restricted or modified. For warranties that cannot be excluded, restricted or modified, Oricom limits the remedies available to those specified in the relevant legislation.

Customer Support

Customer Support

If you have any problems setting up or using this product you will find use-full tips and information in the Troubleshooting section of this user guide as well as "Frequently Asked Questions" on our website www.oricom.com.au. If you have further questions about using the product after reviewing the resources above or would like to purchase replacement parts or accessories please call our Customer Support Team. Our dedicated local support team are more likely to be able to help you than the retailer where you made your purchase.

Please retain your purchase receipt and attach to the back page of this user guide as you will need to produce this if warranty service is required. Take a few moments to register your product online: www.oricom.com.au



Australia

Oricom International Pty Ltd

Locked Bag 658

South Windsor, NSW 2756

Australia

Email: support@oricom.com.au

Phone: 1300 889 785

(Monday to Friday 8am to 6pm AEST)

Web: www.oricom.com.au

Fax: (02) 4574 8898

