

TOPCOM® BUTLER OUTDOOR 2000



USER GUIDE

1.1

CE

Important

To use 'Caller ID' (display caller), this service has to be activated on your phone line. Normally you need a separate subscription from your telephone company to activate this function. If you don't have the Caller ID function on your phone line, the incoming telephone numbers will NOT be shown on the display of your telephone.

This product is in compliance with the essential requirements and other relevant provisions of the R&TTE directive 1999/5/EC.
The Declaration of conformity can be found on :

<http://www.topcom.net/support/cedclarations.php>

To be connected to the public analogue telephone network.

The features described in this manual are published with reservation to modifications.

1 Description of telephone (see folding page)

- 1.1 Handset and base Butler Outdoor 2000
- 1.2 Display

2 Telephone installation

- 2.1 Connections
- 2.2 Rechargeable batteries

3 Using the telephone

- 3.1 Setting menu language
- 3.2 Handset ON/OFF
- 3.3 Receiving a call
- 3.4 Making an external call
- 3.5 Making an internal call
- 3.6 Internal call transfer
- 3.7 Conference Call
- 3.8 Handsfree mode
- 3.9 Display of call duration
- 3.10 Microphone mute
- 3.11 Pause Key
- 3.12 Caller Identification
- 3.13 Redial memory
- 3.14 Calling from the phonebook
- 3.15 Using the alphanumerical keypad
- 3.16 Using the menu
- 3.17 LED Light

4 Personalisation

- 4.1 adjusting the ring volume
- 4.2 Choosing the ring melody
- 4.3 Speaker volume during call
- 4.4 Activation / Deactivation of beeps
- 4.5 Handset name
- 4.6 Changing the PIN code
- 4.7 Setting the dialling mode
- 4.8 Flash time duration
- 4.9 Automatic answer
- 4.10 Reset
- 4.11 Keypad lock
- 4.12 Setting the time
- 4.13 Setting the date
- 4.14 Setting the alarm

5 Advanced functions

- 5.1 Phonebook
- 5.2 Searching a handset from the base

- 5
- 5
- 5

- 6

- 6

- 6

- 7

- 7

- 7

- 7

- 7

- 7

- 7

- 8

- 8

- 8

- 8

- 8

- 8

- 8

- 8

- 9

- 10

- 10

- 11

- 11

- 11

- 11

- 12

- 12

- 13

- 13

- 13

- 14

- 14

- 14

- 15


- 15

- 16

- 16

- 16

- 17



6	Managing multiple handsets	18
6.1	Setting up an additional handset	18
6.2	Removing a handset	19
6.3	Setting up a handset on another base	19
6.4	Selecting a base	19
7	SMS	20
7.1	How to write an SMS	20
7.2	Sending an SMS	20
7.3	Read and view the list of received messages (Inbox)	20
7.4	Multiple users	21
7.5	SMS Settings	22
7.6	Memory full	23
8	Troubleshooting	23
9	Technical characteristics	24
10	Topcom warranty	24
10.1	Warranty period	24
10.2	Warranty handling	24
10.3	Warranty exclusions	24

Safety Instructions


- Only use the charger plug supplied. Do not use other chargers, as this may damage the battery cells.
- Only insert rechargeable batteries of the same type. Never use ordinary, non-rechargeable batteries. Insert rechargeable batteries so they connect to the right poles (indicated in the battery compartment of the handset).
- Do not touch the charger and plug contacts with sharp or metal objects.
- The operation of some medical devices may be affected.
- The handset may cause an unpleasant buzzing sound in hearing aids.
- Do not place the basic unit in a damp room or at a distance of less than 1.5 m away from a water source. Keep water away from the handset.
- Do not use the telephone in environments where there is a risk of explosions.
- Dispose of the batteries and maintain the telephone in an environment-friendly manner.
- As this telephone cannot be used in case of a power cut, you should use a mains-independent telephone for emergency calls, e.g. a mobile phone.

Disposal of the device (environment)

At the end of the product lifecycle, you should not throw this product into the normal household garbage but bring the product to a collection point for the recycling of electrical and electronic equipments. The symbol on the product, user guide and/or box indicate this.

Some of the product materials can be re-used if you bring them to a recycling point. By re-using some parts or raw materials from used products you make an important contribution to the protection of the environment.

Please contact your local authorities in case you need more information on the collection points in your area.













Cleaning

Clean the telephone with a slightly damp cloth or with an anti-static cloth. Never use cleaning agents or abrasive solvents.


The CE symbol indicates that the unit complies with the essential requirements of the R&TTE directive.

1 Description of telephone (see folding page)

1.1 Handset and base Butler Outdoor 2000














1. Earpiece
2. Display
3. Handsfree key 
4. Menu/OK 
5. Up key/Redial/Pause key 
6. Phonebook 
7. Down key/Call log key 
8. Internal call INT
9. Microphone
10. Flash key/Power ON/OFF R/
11. Line key 
12. Mute/Delete key/Escape key 
13. LED Light (High intensity LED's)
14. Torch key 
15. Paging key 
16. Power indicator/Incoming call LED
17. Charge indicator

1.2 Display



Each operation has an associated icon

Icon:

- | | |
|---|---|
|  | Meaning:
You are online |
| EXT | You are in external communication |
| INT | You are in internal communication |
|  | New numbers in call list |
|  | Indicate answered call |
|  | Indicate unanswered call |
|  | You are opening your address book. |
|  | You are in the menu. |
|  | rechargeable battery level indicator |
| | 1 segment: weak, 2 segments: medium, 3 segments: full. |
|  | The antenna indicates the quality of reception. |
|  | The antenna flashes when the handset is not registered on the base. |
|  | Handset keypad locked |
|  | Indicates that the displayed number is longer than the screen (12 digits) |
|  | Alarm set and ON |
|  | SMS message received |

1.2.1 Standby display

In standby mode, the display shows the time and the handset name and number:


12:05

B2000 1

2 Telephone installation

2.1 Connections

Back view of base/charger Butler Outdoor 2000



2.2 Rechargeable batteries



Before you use your Butler Outdoor 2000 for the first time, you must first make sure that the batteries are charged for 6-8 hours. The telephone will not work optimally if not properly charged.

To change or insert a rechargeable battery (see folding page):

1. Unscrew the battery door and belt-clip
2. Remove the belt-clip
3. Lift the battery door
4. Insert the batteries **respecting the (+ and -) polarity**
5. Replace the battery cover.



The maximum standby time of the batteries is approx. 100 hours and the maximum talk time is 10 hours! In the course of time the batteries will start to drain faster. The batteries must be replaced. 2 rechargeable batteries, type AAA NiMH!

3 Using the telephone

3.1 Setting menu language

1. Enter the menu by pressing \leftrightarrow /OK
2. Select HANDESET using the up \blacktriangle and down \blacktriangledown keys
3. Press OK
4. Select LANGUAGE using the up \blacktriangle and down \blacktriangledown keys
5. Press OK
6. Select the language of choice by means of the up \blacktriangle and down \blacktriangledown keys.
7. Press OK to validate

3.2 Handset ON/OFF

- Turn ON handset: Press the \downarrow key on the handset. The handset will search the base.
- Turn OFF handset: Press \downarrow for 3 sec. The display will go OFF.

3.3 Receiving a call

When the handset rings, press \curvearrowright to answer. You are then connected to your correspondent. If the hand-set is on the base when the telephone rings, you just need to pick up the handset to answer the call (if the option autoanswer is activated: See 4.9. Automatic answer).

3.4 Making an external call

3.4.1 Normal:

1. Press \curvearrowright
2. Enter telephone number

3.4.2 Block dialling:

1. Dial your correspondents number
 2. Press \curvearrowright
- To correct a number use the c/B key to delete an entered digit

3.5 Making an internal call

1. Press INT
2. Enter the number of the internal handset (1 to 5)

3.6 Internal call transfer

When you want to transfer an external call to another handset:

1. During a conversation, press INT
 2. Select the number of the internal handset, the external caller is put on hold.
 3. When the other handset picks up, press **↵** to hang up and transfer the call.
- If the internal correspondent does not pick-up, press INT again to reconnect to the external caller on line.

3.7 Conference Call

Only possible when more than one handset are registered to the base!!

You can converse simultaneously with an internal correspondent and an external correspondent.

When you are on line with an external correspondent:

1. Press INT
2. Enter the number of the internal handset that you want to call
3. When the internal correspondent picks- up, press and hold #
4. If the internal correspondent does not answer, press INT again to reconnect to the external correspondent on-line.

3.8 Handsfree mode

You can speak with your correspondent without picking up the handset. To activate or deactivate the handsfree mode, press the **☐** key during a call. To adjust the volume, See 4.3 "Speaker volume during call" on page 12.

3.9 Display of call duration

The call duration is displayed after 15 seconds, in minutes - seconds.
At the end of each call, the total call duration is displayed for 5 seconds.

3.10 Microphone mute

It is possible to mute the microphone during a conversation.

Press **C/Ⓢ** during the conversation, the microphone is then deactivated, you can talk freely without being heard by the calling party.

"MUTE" is displayed. Press **C/Ⓢ** again to return to normal mode.

3.11 Pause Key

When dialling a number you can add a pause between two digits by pressing the redial **Ⓢ** key.

3.12 Caller Identification

Caller identification is only available if you have subscribed to this service with your telephone operator.







When you receive an external call, the callers number will appear on the display as the telephone rings.

If the network sends it, or if the name of the caller is in the address book, the caller is identified by his or her name.
The caller identity is replaced by the call duration after 15 seconds in communication. It is still possible to display the caller's identity after this time by pressing OK-key repeatedly for the name and number.

3.12.1 List of calls

Your telephone keeps a list in memory of the last 40 calls received. This function is only available if you are subscribed to the caller ID information. The correspondents that have called are identified by their telephone number or name in the same way as in caller identification.




The presence of new / unanswered calls is indicated by the flashing -icon on the display. To consult the list of calls:

1. Press . If there are no calls in the list 'EMPTY' will appear.
2. Scroll through the calls using the up  or down  arrows. The callers names will be shown if the name is send by the network or is stored in the phonebook. When  is shown, this call is been answered. When  is shown, the call is unanswered. If you are at the end of the list you will hear a beep tone.
3. If you press OK, the telephone number will be shown. Note: if the telephone number is longer then 12 digits, press OK again to see the complete number.
4. Press OK again to see the time and date when the call is received
5. Pressing OK again will give you the option to add this entry in the phonebook if it's not already stored:
 - Press OK when 'ADD' is shown on the display. Enter or modify the name and press OK. Enter or modify the telephonenumber and press OK. Select the melody (1-10) which will be heard when this number is calling by means of the up/down keys and press OK. The entry will be stored in the phonebook.
6. To call back a correspondent, simply press the key  when their telephone number or name are displayed.

If a caller is in the phonebook, they are identified by their name in the list of calls.

3.12.2 Delete an entry or all entries in the call list

You can delete each entry separately or all entries at ones:

- When scrolling through the calls, press:
 - the mute key  short to delete this entry only. DELETE appears on the screen.
 - the mute key  long (2 sec.) to delete all entries: DELETE ALL appears on the screen.
- Press OK to delete current/all entry(y)(ies), or  to cancel the delete operation.

3.13 Redial memory

Your telephone keeps a list of the 10 last calls (of 32 digits) you have made in memory. The correspondents called are identified by their telephone number or by their name if they appear in the phonebook.

To consult the redial list:

1. Press **○**
2. Scroll through the calls with the up **▲** and down **▼** arrows.
3. To call by the selected correspondent, simply press **↵** when their telephone number or name is displayed.



When name is displayed, you can toggle between name and number by pressing the OK key!

3.14 Calling from the phonebook

To call a correspondent whose name you have saved in the phonebook:

1. Press **□** to enter the phonebook
2. Press the first letter of the name. The first name that starts with this letter or the nearest letter in the alphabet will be displayed.
3. Go through the list of names with the up **▲** and down **▼** keys. The list scrolls in an alphabetical order.
4. Press **↵** to dial the number of the correspondent whose name is displayed.

To see the number before dialling, carry out steps 1 to 3 from before and press OK.

3.15 Using the alphanumerical keypad

With your telephone you can also enter alphanumerical characters. This is useful for entering a name into the phonebook, giving a name to a hand-set, ...

To select a letter, press the corresponding key as many times as is necessary. For example to select an 'A', press '2' once, to select a 'B', press '2' twice and so on. To select 'A' and then B consecutively, select 'A', wait until the cursor moves on to the next character, then press '2' twice.

To select a space, press '0'.

To switch between small letters and capitals, press the '#'-key.

The keypad characters are as follows:

1	.	,	-	?	!	\	Ø	:	;	1
2	A	B	C	2	Ä	A	Æ			
3	D	E	F	3	É	Δ	Φ			
4	G	H	I	4	Γ					
5	J	K	L	5	Λ					
6	M	N	O	6	Ñ	ö	Ø		Ω	
7	P	Q	R	7	Π	π	ψ		Σ	
8	T	U	V	8	Ü	Θ				
9	W	X	Y	Z	9				€	£
0	␣	∅	~	&	%	¤			¥	\$
*	*	=	+	\	<	>	#		()

3.16 Using the menu

A wide range of telephone functions are accessible through a user friendly menu.

1. To enter the menu, press ⇨/OK
2. Scroll through the selections using the up ▲ and down ▼ keys, the selections scroll in a loop (you return to the first after the last).
3. To validate a selection, press OK
4. To return to the previous menu, press ⌂/C

3.17 LED Light

Press and hold the LED light key to turn on the built-in LED light.

4 Personalisation



Every programming is confirmed at the end by a double or single long beep. A double beep confirms the validation of your choice. A long beep signifies that the modification has not been taken into account.

4.1 adjusting the ring volume

4.1.1 Handset ring volume External/internal calls

The handset ring volume for internal or external calls can be set separately:

1. Enter the menu by pressing ⇨/OK
2. Select HANDSET using the up ▲ and down ▼ keys
3. Press OK
4. Select INT RING VOL or EXT RING VOL using the up ▲ and down ▼ keys
5. Press OK
6. Select the desired volume (OFF or 1 to 5)
7. Press OK to confirm or C/⌂ to return to the previous menu.

4.1.2 Base ring

1. Enter the menu by pressing ⇨/OK
2. Select SETUP using the up ▲ and down ▼ keys
3. Press OK
4. Select BASE VOLUME using the up ▲ and down ▼ keys
5. Press OK
6. Select the desired volume (OFF or 1 to 5)
7. Press OK to confirm or C/⌂ to return to the previous menu.

4.2 Choosing the ring melody

The base and each handset can ring with a different melody.

The handsets can ring with a different melody according to whether the call is internal or external.

4.2.1 Base melody

1. Enter the menu by pressing ⇐/OK
2. Select SETUP using the up ▲ and down ▼ keys
3. Press OK
4. Select BASE MELODY using the up ▲ and down ▼ keys
5. Press OK
6. Select the melody of your choice (1 to 5) using the up ▲ and down ▼ keys
7. Press OK to confirm or c/Ⓟ to return to the previous menu.

4.2.2 Handset melody, external call

1. Enter the menu by pressing ⇐/OK
2. Select HANDSET using the up ▲ and down ▼ keys
3. Press OK
4. Select EXT MELODY using the up ▲ and down ▼ keys
5. Press OK
6. Select the melody of your choice (1 to 10) using the up ▲ and down ▼ keys
7. Press OK to confirm or c/Ⓟ to return to the previous menu.

4.2.3 Handset melody, internal call

1. Enter the menu by pressing ⇐/OK
2. Select HANDSET using the up ▲ and down ▼ keys
3. Press OK
4. Select INT MELODY using the up ▲ and down ▼ keys
5. Press OK
6. Select the melody of your choice (1 to 10) using the up ▲ and down ▼ keys
7. Press OK to confirm or c/Ⓟ to return to the previous menu.

4.3 Speaker volume during call

During conversation, press the up ▲ or down ▼ key to change the volume accordingly.



The handsfree volume is also adjusted together with the receiver in the handset as above described.

4.4 Activation / Deactivation of beeps

The handsets can emit beep tone when a key is pressed, when the batteries are low or when the handset is out of range.

4.4.1 Key pressed beep tone on/off

1. Enter the menu by pressing ⇐/OK
2. Select HANDSET using the up ▲ and down ▼ keys
3. Press OK
4. Select BEEP using the up ▲ and down ▼ keys
5. Press OK

6. Select KEYSTONE using the up ▲ and down ▼ keys
7. Press OK
8. Select ON to activate, OFF to deactivate
9. Press OK to confirm.

4.4.2 Low battery

Proceed as before, but select at point 6 "LOW BATTERY" instead of "KEYSTONE".


4.4.3 Handset out of range

Proceed as before, but select at point 6 "OUT RANGE" instead of "KEYSTONE".

4.5 Handset name

This function allows you to personalise each handset.

1. Enter the menu by pressing ⇄/OK
2. Select HANDSET using the up ▲ and down ▼ keys
3. Press OK
4. Select HANDSET NAME using the up ▲ and down ▼ keys
5. Press OK
6. Enter the name
7. Press OK to validate

While entering the name, press 'c' to delete a character and press and hold  to exit the menu without taking any modifications into account.

4.6 Changing the PIN code

Certain functions are only available to users who know the PIN code. By default this is PIN code = 0000.

To change the PIN code:

1. Enter the menu by pressing ⇄/OK
2. Select SETUP using the up ▲ and down ▼ keys
3. Press OK
4. Select PIN CODE using the up ▲ and down ▼ keys
5. Press OK
6. Enter the old 4 figure PIN code.
7. Press OK
8. Enter the new 4 figure PIN code
9. Press OK
10. Enter the new PIN code a second time
11. Press OK to validate

4.7 Setting the dialling mode

There are two types of dialling mode:

- DTMF/Tone dialling (the most common)
- Pulse dialling (for older installations)

To change the dialling mode:

1. Enter the menu by pressing ⇐/OK
2. Select setup using the up ▲ and down ▼ keys
3. Press OK
4. Select DIAL MODE using the up ▲ and down ▼ keys
5. Press OK
6. Select the dialling mode using the up ▲ and down ▼ keys
7. Press OK to validate

4.8 Flash time duration

1. Enter the menu by pressing ⇐/OK
2. Select SETUP using the up ▲ and down ▼ keys
3. Press OK
4. Select RECALL using the up ▲ and down ▼ keys
5. Choose RECALL 1 for short flash time (100ms) or RECALL 2 for long flash time (250ms)

4.9 Automatic answer

When there is an incoming call and the handset is on the base, the phone automatically takes the line when lifted. This is the default setting, but can be set OFF:

1. Enter the menu by pressing ⇐/OK
2. Select HANDSET using the up ▲ and down ▼ keys
3. Press OK
4. Select AUTO ANSWER using the up ▲ and down ▼ keys
5. Select ON (for automatic answer) or OFF
6. Press OK

4.10 Reset

It is possible to return the phone to the original default configuration. This is the configuration which was installed when you first received the telephone.

To return to default settings:

1. Enter the menu by pressing ⇐/OK
2. Select SETUP using the up ▲ and down ▼ keys
3. Press OK
4. Select DEFAULT using the up ▲ and down ▼ keys
5. Press OK
6. Enter the 4 digit PIN code (default =0000). Press OK.
7. Press again OK to validate


DEFAULT PARAMETERS ARE:

Low battery beeps	ON	Ear volume	3
Out of range warning beeps	OFF	Phonebook	Empty
Key click	ON	Call log list	Empty
Auto answer	ON	Redial list	Empty
Internal melody	1	Pin code	0000
Internal volume	3	Dial mode	DTMF
External melody	3	Keypad lock	OFF
External volume	3		








Returning to default settings will delete all entries in the phonebook and call log. The PIN code will also be reset to 0000.

4.11 Keypad lock

The keypad can be locked so that no settings can be changed or no telephone number can be dialed. The -icon will appear on the screen when keypad is locked.

4.11.1 Locking the keypad by Menu

1. Enter the menu by pressing /OK
2. Select HANDSET using the up  and down  keys
3. Press OK
4. Select KEY LOCK? using the up  and down  keys
5. Press OK to lock the keypad






4.11.2 Locking the keypad by the *-key (quick lock)

Press and hold the *-key for 3 seconds. The keypad will be locked.

4.11.3 Unlock the keypad

1. Press any key
2. PRESS * will appear on the screen
3. Press the * key within 3 seconds to unlock the keypad

4.12 Setting the time

1. Enter the menu by pressing /OK
2. Select DATE & TIME using the up  and down  keys
3. Press OK
4. Select TIME SET using the up  and down  keys
5. Press OK
6. Enter the time (24h format).
7. Press OK to validate

4.13 Setting the date

1. Enter the menu by pressing \leftrightarrow /OK
2. Select DATE & TIME using the up \blacktriangle and down \blacktriangledown keys
3. Press OK
4. Select SET DATE using the up \blacktriangle and down \blacktriangledown keys
5. Press OK
6. Enter the date dd-MM (dd=day, MM=month).
7. Press OK to validate

4.14 Setting the alarm

1. Enter the menu by pressing \leftrightarrow /OK
2. Select DATE & TIME using the up \blacktriangle and down \blacktriangledown keys
3. Press OK
4. Select SET ALARM using the up \blacktriangle and down \blacktriangledown keys
5. Press OK
6. Select ON to turn On the alarm and press OK. Enter the time (24h format) when the alarm must be activate.

Or

7. Select OFF to turn off the alarm and press OK to confirm.



When the alarm goes off you can press any handset key to turn it off.

5 Advanced functions

5.1 Phonebook

The Phonebook allows you to memorise 50 telephone numbers and names. You can enter names of up to 12 characters length and numbers of up to 20 digits length.

To call a correspondent whose number is stored in the phonebook, refer to the section 3.14. To enter alphanumerical characters, refer to the section 3.15.

5.1.1 Add an entry into the phonebook

1. Enter the menu by pressing \leftrightarrow /OK
2. Select PHONE BOOK using the up \blacktriangle and down \blacktriangledown keys
3. Press OK
4. Select ADD ENTRY using the up \blacktriangle and down \blacktriangledown keys
5. Press OK
6. Enter the name
7. Press OK to validate.
8. Enter the telephone number
9. Press OK to validate
10. Select the desired melody (1-10) by means of the up/down key
11. Press OK to Validate

5.1.2 *Modify a name or number*

To modify a number in the phonebook:

1. Enter the menu by pressing ⇐/OK
2. Select PHONE BOOK using the up ▲ and down ▼ keys
3. Press OK
4. Select MODIFY ENTRY using the up ▲ and down ▼ keys
5. Press OK
6. Move through the list of names with the up ▲ and down ▼ keys. The list scrolls in alphabetical order.
7. Press OK when you find the name to modify
8. Use the 'c/Ⓢ' key to go back and enter the new name
9. Press OK to validate
10. Enter the new telephone number
11. Press OK to validate



Warning! If you enter the Phonebook first with the ☐ key and modify a telephone number with the c/Ⓢ key, the modification will be taken into account only for this call and will not be stored in the phonebook!

5.1.3 *Deleting an entry*

To delete an entry:

1. Enter the menu by pressing ⇐/OK
2. Select PHONE BOOK using the up ▲ and down ▼ keys
3. Press OK
4. Select DELETE ENTRY using the up ▲ and down ▼ keys
5. Press OK
6. Move through the list of names using the up ▲ and down ▼ keys the list scrolls in alphabetical order.
7. Press OK when you find the name you wish to delete
8. CONFIRM appears, press OK to confirm or c/Ⓢ to stop.

5.2 **Searching a handset from the base**

When the paging button Ⓢ on the base is pressed all the handsets will ring. This ringing will help you locate a lost handset. By simply pressing one of the handset keys the ringing stops.

6 Managing multiple handsets

6.1 Setting up an additional handset



You only need to register a 2nd handset in case your 2nd handset does not link with the base anymore or when you have bought a new one!!!

You can register new handsets on the base if these handsets support the DECT GAP protocol.

The base can support a maximum of 5 handsets. If you already have 5 handsets, and you wish to add another one or change one handset, you must first delete a handset, then associate the new handset.

To register any handset, the base must be put into a special registration mode:

1. Press and hold the paging key \Rightarrow of the base for 6 seconds.
2. The base will then emit a beep tone. The base is now ready to register a new handset. You have 90 seconds after pressing the button to register a new handset.

After putting the base into registration mode, start the procedure on the new handset:

6.1.1 if your additional handset is a Butler Outdoor 2000

3. Enter the menu by pressing \Rightarrow /OK
4. Select REGISTER using the up \blacktriangle and down \blacktriangledown keys
5. Press OK
6. Select REG BASE using the up \blacktriangle and down \blacktriangledown keys
7. Enter a base number (from 1 to 4). The flashing numbers are already in use.
8. Enter the Base PIN code (0000 by default)
9. Press OK. The handset will start searching for the DECT base
10. If the handset has located the base, it will display the base identification number, validate the base registration by pressing OK or stop by pressing \square .
11. If the handset does not locate the base, it will return to the standby mode after a few seconds.
12. Try again by changing the base number and check that you are not in an environment where there is interference. Move closer to the base.

6.1.2 if your handset is another model

After starting the registration procedure on the base, refer to the handset manual to find out how to register the handset. The handset must be GAP compatible.

The icon \Rightarrow and the text "NOT REG" flashes on the display when the handset is not associated with the base.

When a handset is associated with a base, it is attributed a handset number by the base. It is this number that is displayed on the handset after the name and must be used for internal calls.



DECT GAP Profile only guarantees that basic calling-functions will work correctly between different brands/types. There's a possibility that certain services (like CLIP) will not work correctly.

6.2 Removing a handset

You can remove a handset with a base to allow another handset to be registered

1. Enter the menu by pressing ↵/OK
2. Select SETUP using the up ▲ and down ▼ keys
3. Press OK
4. Select DEL HANDSET using the up ▲ and down ▼ keys
5. Press OK
6. Enter the 4 digit base PIN code
7. Press OK
8. Select the handset to be removed
9. Press OK to validate

6.3 Setting up a handset on another base

If you want to use a Butler Outdoor 2000 handset with a base of another model. The base must be GAP compatible.

1. To put the base in registration mode, refer to the base user manual.
2. Carry out operations 3 to 10 from the paragraph 6.1.

6.4 Selecting a base

The handsets can be registered up to 4 bases simultaneously.
To select a base:

1. Enter the menu by pressing ↵/OK
2. Select REGISTER using the up ▲ and down ▼ keys
3. Press OK
4. Select SELECT BASE using the up ▲ and down ▼ keys
5. Press OK
6. Select a base or select AUTO using the up ▲ and down ▼ keys
7. Press OK

When selecting the base, the current selected base is indicated by a blinking base number. If you select 'Auto' the handset will automatically search for another base when you are out of range!

7 SMS

You can send and receive SMS with your Butler telephone. This section tells you how to use the SMS feature. You can store a total of 15 SMS messages sent and received, each with up to 160 characters.



Before sending and receiving SMS text messages you need to set the telephone number of your Network's SMS Centre for outgoing and incoming messages (See 7.5.3)

7.1 How to write an SMS


The method is the same as entering a name in the phonebook (See 3.15).

To enter a space press '0' and to change from capital to small character press '#'.

7.2 Sending an SMS

- Enter the menu by pressing \rightarrow / OK
- Select '**SMS**' using the up \blacktriangle and down \blacktriangledown keys and press OK
- Select '**Write**' using the up \blacktriangle and down \blacktriangledown keys and press OK
- Start writing the message and press OK
- Enter the telephone number



Instead of entering a number with the numerical keypad, you can select a number out of the phonebook by pressing the phonebook key .

- Press \blacktriangle or \blacktriangledown until the desired name is displayed.
- Press OK twice to send the SMS message

- Press OK to send the message
- The SMS will be sent out automatically.

7.3 Read and view the list of received messages (Inbox)

Your Butler display indicates the number of new messages you have received. is shown on the screen. The LED on the base is blinking.

A beep indicates you have just received a new message (can be turned ON or OFF: See 7.5.1).

When the number of new messages is indicated on the display.

- Press the OK-key. The telephone number of the most recent message is listed first.

When the number of new messages is not displayed.

- Enter the menu by pressing \rightarrow / OK
- Select '**SMS**' using the up \blacktriangle and down \blacktriangledown keys and press OK
- Select '**Inbox**' using the up \blacktriangle and down \blacktriangledown keys and press OK. The telephone number of the most recent message is listed first.

Once you have entered the INBOX:

- Press ▲ or ▼ to scroll through all messages. Messages with ** before the telephone number are unread messages.
- To read the message, press OK.
- Press ▲ or ▼ to scroll through the whole message.
- Press OK when the whole message is read.
- Press ▲ or ▼ to scroll to select one of the next options:
 - **Reply** : Edit the message using the alphanumeric keypad and sent it.
 - **Forward** : Forward the stored message to another user. Follow the same instructions as for sending an SMS message (See 7.2).
 - **Delete ?** : Delete the message. Press OK again to confirm.
- Press *c/Ⓡ* to return to the 'Inbox' menu.

7.4 Multiple users

With your Butler telephone you can register up to 5 handsets on one base. Each handset has it's own handset number (1-5) which is also the terminal number to send Personal messages. All handset have standard terminal number '0' as well. In order to receive personal SMS messages, you must give your correspondents the user Terminal Number that they need to add to your standard telephone number (See below). For example, when you have a 2nd handset (Handset 2) this handset will have terminal number = 2. If no terminal number is add to you telephone number or '0', all handset will receive these messages.

You can change the terminal number to another one but only from 6-9 (See 7.5.6).

7.4.1 Receiving personal user SMS



You correspondents will need to add your Terminal Number to your telephone number when they want to send personal SMS.
E.g. If your personal Terminal Number is "1" and your telephone number is 123456789, your correspondents should send their SMS messages to:1234567891! This is the number you need to remember and give to your correspondents.

7.4.2 Reading personal user SMS

When a new message comes in, your Butler emits a beep. The screen shows  and the number of new messages.

- Press the OK key.

In the SMS list, private messages are flagged with the key-icon  on top of de screen.
Or

- Enter the menu by pressing *↵/ok*
- Select 'SMS' using the up ▲ and down ▼ keys and press OK
- Select 'Personal SMS' using the up ▲ and down ▼ keys and press OK. The telephone number of the most recent message is listed first.

7.5 SMS Settings

7.5.1 Set SMS alert tone ON/OFF

Your handset can play a melody to announce a new text message.

- Enter the menu by pressing ↵/OK
- Select '**SMS**' using the up ▲ and down ▼ keys and press OK
- Select '**SMS Settings**' using the up ▲ and down ▼ keys and press OK.
- Press ▲ or ▼ until '**Msg Alert**' is displayed and press OK
- Press ▲ or ▼ to select '**ON**' or '**Off**' the desired melody and press OK to confirm and go back to previous menu
- Press ▲ or ▼ to select '**On**' or '**Off**' and press OK

7.5.2 SMS Service center numbers

To send and receive SMS text messages you need the telephone number of your Network's SMS Centre. These numbers have been pre-loaded into the Butler. You can also find these numbers on the addendum sheet mentioned per country and per operator. If you accidentally delete the SEND or RECEIVE SMS Service Centre numbers you will need to re-enter them in order for your SMS Service to work.

The Butler can store 2 SEND SMS Service center numbers and 2 RECEIVING SMS Service center numbers.

7.5.3 To set the SMS sending Centres numbers

- Enter the menu by pressing ↵/OK
- Select '**SMS**' using the up ▲ and down ▼ keys and press OK
- Select '**SMS Settings**' using the up ▲ and down ▼ keys and press OK.
- Press ▲ or ▼ until '**Send Center**' is displayed and press OK
- Select '**Send 1**' or '**Send 2**' and press OK
- Enter the telephone number of the SMS server

7.5.4 To set the SMS Receiving centres numbers

- Enter the menu by pressing ↵/OK
- Select '**SMS**' using the up ▲ and down ▼ keys and press OK
- Select '**SMS Settings**' using the up ▲ and down ▼ keys and press OK.
- Press ▲ or ▼ until '**Rcv Center**' is displayed and press OK
- Select '**Receive 1**' or '**Receive 2**' and press OK
- Enter the telephone number of the SMS server

7.5.5 Select the SMS center to send SMS

Because you can set 2 SMS sending centres, you have to select one of both before sending you messages:

- Enter the menu by pressing ↵/OK
- Select '**SMS**' using the up ▲ and down ▼ keys and press OK
- Select '**SMS Settings**' using the up ▲ and down ▼ keys and press OK.
- Press ▲ or ▼ until '**Send Service**' is displayed and press OK
- Select '**Send 1**' or '**Send 2**' and press OK

7.5.6 Setting the terminal number

Each handset has terminal number '0' and terminal number = handset number (1-5). You can change the terminal number to another number (6-9) if needed:


- Select '**SMS**' using the up ▲ and down ▼ keys and press OK
- Select '**SMS Settings**' using the up ▲ and down ▼ keys and press OK.
- Press ▲ or ▼ until '**Terminal no**' is displayed and press OK
- Delete the old terminal number and enter the new one (0, 6-9).
- Press OK to confirm

7.6 Memory full

When the memory is full, you get the screen message "Memory Full". You can no longer send or receive SMSs. To continue to receive SMSs, you can delete some or all of the messages. To delete all the messages stored in the "**Inbox**" or "**Personal SMS**":

- Enter the menu by pressing →/OK
- Select '**SMS**' using the up ▲ and down ▼ keys and press OK
- Select '**SMS Settings**' using the up ▲ and down ▼ keys and press OK.
- Select '**Delete All**' and press OK
- Select '**Inbox**' or '**Personal SMS**' and press OK. '**Confirm ?**' appears.
- Press OK to confirm or c/Ⓢ to go back

8 Troubleshooting

Symptom	Possible cause	Solution
No display	Batteries uncharged	Check the position of the batteries Recharge the batteries
No tone	Handset turned OFF Telephone cord badly connected	Turn ON the handset Check the telephone cord connection
The icon  flashes	The line is occupied by another handset Handset out of range	Wait until the other handset hangs up Bring the handset closer to the base
	The base has no power supply	Check the mains connection to the base
	The handset is not registered on the base	Register the handset on the base
Base or handset do not ring	The ringing volume is zero or low	Adjust the ringing volume
Tone is good, but there is no communication	The dialling mode is wrong	Adjust the dialling mode (pulse/ tone)
Not possible to transfer a call on PABX	The FLASH time is too short	Set the unit to Long Flash time
Telephone does not react to pressing the keys	Manipulation error	Remove the batteries and put them back in place

9 Technical characteristics

Standard:	DECT (Digital Enhanced Cordless Telecommunications) GAP (Generic Access Profile)
Frequency range:	1880 MHz to 1900 MHz
Number of channels:	120 duplex channels
Modulation:	GFSK
Speech coding:	32 kbit/s
Emission power:	10 mW (average power per channel) max 950m in open space /150m max. inhouse
Range:	230 V / 50 Hz / 7,5V DC 300mA
Base power supply:	2 rechargeable batteries AAA, NiMH 550mAh
Handset Batteries:	100 hours in standby
Handset autonomy:	10 hours
Talk time:	6-8 hours
Charging time:	+5 °C to +45 °C
Normal conditions of use:	Pulse / Tone
Dialling mode:	100 or 250 ms
Flash time:	
Splash water proof	
& resistance to dust:	IP54

10 Topcom warranty

10.1 Warranty period

The Topcom units have a 24-month warranty period. The warranty period starts on the day the new unit is purchased. The warranty on batteries is limited to 6 months after purchase. Consumables or defects causing a negligible effect on operation or value of the equipment are not covered.

The warranty has to be proven by presentation of the original purchase receipt, on which the date of purchase and the unit-model are indicated.

10.2 Warranty handling

A faulty unit needs to be returned to a Topcom service centre including a valid purchase note. If the unit develops a fault during the warranty period, Topcom or its officially appointed service centre will repair any defects caused by material or manufacturing faults free of charge.

Topcom will at its discretion fulfill its warranty obligations by either repairing or exchanging the faulty units or parts of the faulty units. In case of replacement, colour and model can be different from the original purchased unit. The initial purchase date shall determine the start of the warranty period. The warranty period is not extended if the unit is exchanged or repaired by Topcom or its appointed service centres.

10.3 Warranty exclusions

Damage or defects caused by incorrect treatment or operation and damage resulting from use of non-original parts or accessories not recommended by Topcom are not covered by the warranty. Topcom cordless phones are designed to work with rechargeable batteries only. The damage caused by the use of non-rechargeable batteries is not covered under warranty. The warranty does not cover damage caused by outside factors, such as lightning, water and fire, nor any damage caused during transportation. No warranty can be claimed if the serial number on the units has been changed, removed or rendered illegible. Any warranty claims will be invalid if the unit has been repaired, altered or modified by the buyer or by unqualified, non-officially appointed Topcom service centres.

TOPCOM[®]

visit our website
www.topcom.net

MB300002