

DIGITAL 900MHz
CORDLESS PHONE
With Integrated Telephone
Answering Device
MODEL VTECH 900i



VTECH COMMUNICATIONS LTD.

Distributed in the U.S.A. by VTECH Communications, 8770 SW Nimbus Avenue /
Beaverton, Oregon, 97008
Distributed in Canada by VTECH Electronics Canada Ltd., 200-7671 Alderbridge Way,
Richmond, B.C.
Copyright 1996 for VTECH COMMUNICATIONS LTD.

91-4010-13-00
ISSUE 0



VTECH COMMUNICATIONS LTD.

900i
INSTRUCTION **manual**

TABLE OF CONTENTS

INTRODUCTION.....	2	INTEGRATED TELEPHONE ANSWERING	18
Parts Check List.....	3	DEVICE (ITAD) OPERATION.....	18
IMPORTANT SAFETY INSTRUCTIONS...	4	LCD DISPLAY.....	18
HANDSET BATTERIES.....	6	LCD Display Icons.....	18
Charging the Handset Batteries.....	6	LCD Display Digits.....	19
Replacing The Handset Batteries...	7	BASE KEYPAD FUNCTIONS.....	19
GETTING STARTED.....	8	Main Function Keys.....	19
Setting Up Your <i>VTech 900i</i>	8	Message Playback Keys.....	22
WALL MOUNTING.....	10	INITIAL SET-UP.....	23
QUICK REFERENCE GUIDE.....	11	Ring Type Programmi.....	23
INITIAL POWER-UP.....	11	Security Code Programming.....	23
<i>VTech 900i</i> Cordless Telephone...11		Time and Day Setup.....	24
<i>VTech 900i</i> Integrated Telephone		Mailbox Programming.....	24
Answering Device (ITAD).....	12	Selecting the Announcement.....	25
CORDLESS PHONE OPERATION...13		Recording the Announcement.....	25
Making Calls.....	13	Leaving a Message.....	26
Disconnecting.....	13	Recording a Memo.....	26
To Put A Call On Hold.....	13	Listening to Messages.....	27
The Mute Feature.....	13	REMOTE OPERATION OF ITAD.....29	
Changing Channels.....	14	ACTIVATING REMOTE OPERATION..29	
Temporary Tone.....	14	To activate remote operation from your	29
Programming the Ringer Type.....	14	cordless handset.....	29
Turning Off The Ringer.....	15	To activate remote operation from a	29
Checking the Ringer.....	15	different telephone line.....	29
Memory Dialing.....	15	VOICE PROMPTS.....	30
To Store a Number into Memory..15		Listening to Messages.....	31
To Dial a Number From Memory..16		Changing the Announcement.....	31
To Change or Replace a Stored Number.16		Recording a Memo.....	31
Storing Pauses in Memory.....	16	REMOTE COMMANDS.....	32
Using Redial.....	16	MAINTENANCE.....	35
Storing a Redial Number in Memory Dial.17		OUT OF RANGE INDICATION.....	36
The Page Feature.....	17	IN CASE OF DIFFICULTY.....	37
Tone Definitions.....	17	WARRANTY STATEMENT.....	39
		FCC AND IC REGULATIONS.....	40
		TECHNICAL SPECIFICATIONS.....	43

INTRODUCTION

Congratulations! You have purchased one of the most sophisticated cordless telephones on the market! The **VTech 900i** has been designed to offer a new standard in cordless telephone technology.

Unlike most other cordless phones, the **VTech 900i** digitizes your voice to give the minimum amount of noise. In most conditions you will not be able to tell you are using a cordless phone. Gone are the annoyances of static, interference and having to listen to other people's conversations on your cordless phone.

The **VTech 900i** scrambles your voice before it transmits it. This allows you the security of knowing that no one can tune in and eavesdrop on your conversations. The phone will also alert you when you are "Out of Range" even when you're not using the phone! In this way you will not miss an incoming call just because you were not close enough to the base unit.

Cordless Telephone Features:

- 10 Number Speed Dial Memory
- 10 Channels of Operation
- Automatic Channel Selection
- 65,000 security code combinations Page
- HOLD, REDIAL, MUTE and FLASH features
- Programmable Ringer Types
- Digital Volume Adjust
- Temporary Tone Dialing

The **VTech 900i** base unit includes an Integrated Telephone Answering Device (ITAD). It uses digital memory to record messages, eliminating the need for cassette tapes.

You can access your messages from the base unit, the handset or from a remote location.

ITAD Features:


- 30 or 15 minutes standard record time option
- Base LCD display for ease and clarity of operation.
- Time and day stamp for incoming messages.
- Digital message counter indicates number of messages received.
- Auto disconnect stops ITAD from answering call when an extension is picked up.
- Skip messages, scan forwards or backwards through your messages instantly.
- Selective message delete allows you to keep important messages.
- Message length control; stops recording after 5 seconds of silence in recorded message.
- Memory backup to protect against power failure.
- Ring pick-up selection; unit can be set to pick-up and record messages after 2 rings, 4 rings or play announcement only with no message recorded.
- Toll saver for remote operation.
- Memo record capability.
- Programmable security code for remote operation.
- Volume control with 4 levels for the ITAD speaker.
- 4 individual mailboxes for personalized message storage and retrieval.

This manual is designed to familiarize you with the **VTech 900i**. To get the most use out of your **VTech 900i**, we strongly recommend you read the manual before using your phone.

INTRODUCTION

Parts Check List:

1. Handset
2. Base unit and AC adapter
3. Telephone line cord
4. Molded Battery pack
5. Wall mounting screws and caps
6. Wall mounting bracket



IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on the product.
3. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
4. Do not use this product near water (for example, near a bath tub, kitchen sink, or swimming pool).
5. Do not place this product on an unstable cart, stand, or table. The product may fall, causing serious damage to the product.
6. Slots and openings in the cabinet and the back or bottom are provided for ventilation. To protect it from overheating, these openings must not be blocked by placing the product on the bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heat register. This product should not be placed in a built-in installation where proper ventilation is not provided.
7. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your dealer or local power company.
8. Do not allow anything to rest on the power cord. Do not locate this product where the cord will be abused by persons walking on it.
9. Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short out parts that could result in a risk of fire or electric shock. Never spill liquid of any kind on the product.
10. To reduce the risk of electric shock, do not disassemble this product, but take it to a qualified serviceman when some service or repair work is required. Opening or removing cabinet parts other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassembling can cause electric shock when the appliance is subsequently used. In addition, attempting to service the unit yourself may void your warranty.
11. Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock.

IMPORTANT SAFETY INSTRUCTIONS

12. Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- A. When the power supply cord or plug is damaged or frayed.
- B. If liquid has been spilled into the product.
- C. If the product has been exposed to rain or water.
- D. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions because improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
- E. If the product has been dropped and the cabinet has been damaged.
- F. If the product exhibits a distinct change in performance.

13. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.

14. Do not use the telephone to report a gas leak in the vicinity of the leak.

SAVE THESE INSTRUCTIONS

HANDSET BATTERIES

Charging the Handset Batteries

The handset of your **VTech 900i** cordless telephone is powered by rechargeable batteries. They charge automatically whenever the handset is in the base. You should charge the batteries for **24 hours** when you first receive your phone. You'll know the batteries need charging when:

- The phone beeps when you press the **PHONE** key.
- The **LOW BAT / MUTE LED** is flashing.
- The handset seems completely dead and does not beep when you press the keys.

To Charge The Batteries

Place the handset in the base unit. The **CHARGE** indicator will light to show the handset is seated properly and the batteries are charging. The **CHARGE** indicator will flash if the handset battery is not charged enough for the handset to operate. Once the battery reaches the minimum level needed to operate, the **CHARGE** indicator will illuminate steadily and the battery will continue to charge up to its full potential.

It is recommended that the battery be charged for **24 hours**. You can use your telephone before that with diminished capacity, but it is best to let them charge fully. To maximize the charge capacity of the NiCad battery pack, recharge the battery for several cycles. Once you have properly conditioned the rechargeable battery, the maximum battery life should be **6 hours** of continuous talk time or **5 days** of standby.

IT IS IMPOSSIBLE TO OVER-CHARGE THE BATTERIES

If the Batteries Don't Recharge

The battery pack can be recharged many times, but if you get a low-battery signal even after **24 hours** of charging, the battery pack should be replaced.

Optional Accessory Battery and Charger

Your 900i uses a molded battery pack which may need to be replaced at some point in the future. VTech offers an accessory battery, as well as a battery and charger (model# TBC-900) which is compatible with your 900i. Please contact your local VTech dealer, or call VTech directly.

To purchase replacement battery packs and other accessories:

In the US call:

**VTech Communications at
1-800-624-5688**


In Canada call:

**VTech Electronics at
1-800-267-7377**


HANDSET BATTERIES

Replacing The Handset Batteries

1. Remove the old molded battery pack by pressing on the battery release button and slide the battery downward.



2. Discard the old battery pack. Don't put the old battery pack in a trash compactor or a fire - it could burst.
3. Slide the new molded battery pack on its track, until it is firmly in place.
4. The new molded battery pack must be charged before using your telephone. Place the handset in the cradle of the base unit to allow it to charge for 24 hours.



CAUTION:

To Reduce the Risk of Fire or Injury to Persons, Read and Follow the Instructions


1. Use only VTech battery, part number: 80-4016-00-00.
2. Do not open or mutilate the battery. Released electrolyte is corrosive and may cause damage to the eyes or skin. It may be toxic if swallowed.
3. Exercise care in handling batteries in order not to short the battery with conducting materials such as rings, bracelets, and keys. The battery or conductor may overheat and cause burns.
4. Do not dispose of the battery in a fire. The cell may explode.

IMPORTANT: Do not dispose of this battery into household garbage. For information on recycling or proper disposal, consult your local solid waste collection or disposal organization.


GETTING STARTED

Setting Up Your VTech 900i

1. Choose an area near an electrical outlet and a telephone wall jack.



2. Install optional 9V back-up battery in compartment located on underside of 900i base unit. This battery retains memory in the event of a power outage. VTech recommends the use of an alkaline battery.




3. Connect the telephone line cord. Insert one end of the telephone line cord into the jack at the rear of the base unit. Plug the other end into a telephone wall jack. Make sure the plugs snap securely into place.


4. Plug the AC power adapter into an electrical outlet. The ON/OFF LED will flash during initialization for about 20 seconds. After initialization of the iTAD, the LCD clock display will flash until it is set.

NOTE: Connect power to the base unit before placing the handset in the cradle.

4. Set the TONE/PULSE switch on the base unit. If you have touch tone service on your phone line, set the switch to TONE. If you have rotary service, set the switch to PULSE.



5. Fill in the telephone number card on the base unit.




GETTING STARTED

6. CHARGE THE HANDSET BATTERIES BEFORE USE.

The batteries recharge automatically whenever the handset is in the base unit cradle. The batteries must be charged for **24 hours** before using your phone for the first time. The **CHARGE** LED will flash until the handset is placed in the base cradle and the batteries are charged.

7. CHECK FOR A DIAL TONE.

After the batteries are charged, pick up the handset and press the **PHONE** key. The **PHONE** indicator should light up, and you should hear a dial tone. If not, see **IN CASE OF DIFFICULTY**.



CAUTION:

1. Never install telephone wiring during a lightning storm.
2. Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
3. Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
4. Use caution when installing or modifying telephone lines.

Wall Installation Using Mounting Screws Provided

Tools You Will Need:

A hammer, a nail, a pencil or ball-point pen, a Phillips head (+) screwdriver, and the Wall Mounting Template included in the back of this booklet.

1. Choose a spot near an electrical outlet and a telephone jack.

Your phone requires a modular telephone jack and a standard electrical outlet (120v AC). The power cord is six feet long; make sure there is an electrical outlet within reach of the base. The outlet should not be controlled by a wall switch. If the switch is ever turned off, the phone will not operate.

2. Choose and mark the mounting position.

The mounting screws should screw into a wooden stud within the wall - they will not hold securely in wallboard alone. Locate a wall stud in the area where you want to install your telephone. Use the Wall Mounting Template and a pencil to mark the screw positions on the wall over the stud. Put the template aside.

3. Install the mounting sleeves and screws.

Start the screw holes by lightly tapping a nail into the marks you made on the wall. Remove the nail from the wall. Now slip the mounting

sleeves onto the screws as shown, with the smaller end of the sleeve toward the screw head. Insert the screws into the holes you started. Tighten the screws until the large end of the mounting sleeve is flat against the wall.

4. Position the wall mount adapter on the base.

Line up the tabs on the wall mount adapter with the holes on the bottom of the base. Snap the wall mount adapter firmly in place.

5. Mount the base on the wall.

Position the base so the mounting studs will fit into the holes on the bottom of the base. Position the power cord to extend down the wall the phone is to be mounted on. Slide the base down on the mounting studs until it locks into place.

6. Connect the telephone cord.

The telephone line cord has a snap-in plug at each end. Insert one of the plugs into the jack on the bottom of the base. Insert the other end of the plug into the wall jack.

7. Plug the AC adapter on the power cord into an electrical outlet.

8. Set the dial mode switch on the base unit.

If you have touch tone service on your phone line, set the switch to TONE. If you have rotary service, set the switch to PULSE.

Here's a brief guide to the features and functions of your **VTech 900i** cordless telephone and Integrated Telephone Answering Device (ITAD):

INITIAL POWER-UP

- Connect telephone line cord to base unit and telephone jack.
- Plug AC adapter into a standard electrical outlet. The **ON/OFF** LED will flash during initialization and the LCD clock display will flash on completion (approx. 20 seconds).
- Set Dial Mode switch to **PULSE** or **TONE**.
- The **CHARGE** LED will flash until handset is placed in base and the batteries are charged (charge batteries **24 hours** before first use).

VTech 900i Cordless Telephone

MAKING CALLS

- Press **PHONE** key on the handset. When the **PHONE** indicator lights and you hear a dial tone, dial the number.

ANSWERING CALLS

- If the handset is in the base unit cradle, just pick up the handset.
- If the handset is away from the base unit, press any key other than **OFF** on the handset.

HANGING UP

- Press the **OFF** key on the handset, or place the handset in the base cradle.

MEMORY DIALING

Numbers can be stored in memory using the handset unit.

To store a number in memory:

- Press **PRG**.
- Enter the memory location (0..9).

- Enter the phone number you wish to store (up to 16 digits).
- Press **MEM**. The phone number is now stored.

To dial a number from memory using the handset unit:

- Press **PHONE**.
- Press **MEM** and the number key you assigned (0..9).

USING REDIAL

- Press **PHONE**, then **REDIAL** to automatically redial the last number you dialed.

HOLD

- When using the handset press **HOLD** to put a call on hold.
- To return to the call, press **PHONE**.

CHANGING CHANNELS

- If you experience noise or interference during a conversation, press **CHAN** to switch to a clear channel.

FLASH

- You can use your **VTech 900i** cordless telephone with services such as Call Waiting and Call Forwarding. Instead of pressing the switch-hook, press **FLASH** on the handset.

PAGE

- From the base unit, press **PAGE** to signal the person at the handset.

MUTE

- When using the handset, press **MUTE** to temporarily turn off the microphone. To return to two-way operation, press **MUTE** again.

QUICK REFERENCE GUIDE

VOLUME CONTROLS

- The handset has digital volume controls.
- The volume controls for the handset are located on the side of the unit. Press the Δ (up) or ∇ (down) keys to increase or decrease the volume.

VTech 900i Integrated Telephone Answering Device (ITAD)

SETTING THE RING TYPE

- Press and hold **SETUP** until you hear a beep.
- Use **REPEAT** and **SKIP** keys to select ring type (2, 4 or toll saver).
- Press **STOP** to exit.

SETTING THE SECURITY CODE

- Press and hold **SETUP** until you hear a beep.
- Press **SETUP** again briefly.
- Use **REPEAT** and **SKIP** keys to select security code (0-99).
- Press **STOP**.

SETTING THE CLOCK

- Press and hold **SETUP** until you hear a beep.
- Press **SETUP** briefly 2 times.
- Use **REPEAT** and **SKIP** keys to select the correct day.
- Each press of **SETUP** allows you to skip to the next step, in the order: day, hour, minute.
- Press **STOP** once clock is set.

SETTING THE MAILBOXES

- Press and hold **SETUP** until you hear a beep.
- Press **SETUP** 5 times until the MAILBOX icon is illuminated.
- Use **REPEAT** and **SKIP** keys until you've reached the desired mailbox selection.
- Press **STOP**.

RECORDING THE ANNOUNCEMENT

- Press **ANNC** until you've reached the desired Announcement (1 or 2).
- Press and hold **ANNC** until you hear a beep.
- Record your Announcement.
- Press **ANNC** or **STOP**.


LISTENING TO MESSAGES

- Press **MAILBOX** key until the desired mailbox appears on the display.
- Press **PLAY**.
- **REPEAT** and **SKIP** keys can be used to scan forwards or backwards through messages.
- Press **STOP** to exit.

CORDLESS PHONE OPERATION

Making Calls

Pick up the handset and press **PHONE**. When you hear a dial tone, dial the number. The indicator for **IN USE** (on the base unit) and **PHONE** (on the handset) will light.



If you make a mistake when dialing, press **OFF** to hang up, then press **PHONE** to get the dial tone again.


You must always press **PHONE** before you can dial a call on the handset.

Disconnecting

To end a call, either place the handset back in the base, or press **OFF** on the handset.

To Put A Call On Hold

While using the handset, you can put a call on hold by pressing **HOLD**. The **PHONE** indicator on the handset will blink to show that a call is on hold.



To return to the call, press **PHONE**.

If a call is on **HOLD** using the **VTech 900i** and you pick up another phone on the same line, the **VTech 900i** will take itself off **HOLD** and turn **OFF**. Therefore, you do not have to go back to turn the phone **OFF** if you go to another extension. It is done automatically.

The Mute Feature

When you press **MUTE** while using the handset, you can hear the caller's voice, but they can't hear you. Use this feature to speak to someone in the room without your caller hearing. While the call is muted, the **MUTE/LO BATT** Indicator will be lit. To go back to the two-way conversation, press **MUTE** again.



CORDLESS PHONE OPERATION

Changing Channels


In the unlikely event you notice interference when using your handset, press **CHAN** to switch to a clear channel. Using this key to change channels is only available when you are on a call. When the call is on **HOLD** or if you are in **STANDBY** mode, the **CHAN** key is inactive.



Temporary Tone

If you have rotary (dial-pulse) telephone service, (**TONE/PULSE** switch is set to **PULSE**), this feature allows you to enter special codes and tones to operate answering machines, use electronic banking services, calling cards, or other special services.

First, dial the call normally. Then activate the Temporary Tone feature by pressing **TONE** (the * key). You can then press the numbers or symbols you need, and your phone will send the proper signals.



To end the call, press **OFF** or place the handset back in the base. The phone will automatically go back to rotary (dial-pulse) service.

If you have touch-tone service, (**TONE/PULSE** switch set to **TONE**), just enter the codes normally. This feature is only for rotary service telephone lines.

Programming the Ringer Type


The handset ringer is capable of four different types of ringing tones. The following sections detail how to change the different tones and to turn off the ringer on the handset.

To program, the handset must be **OFF**.

To select a different ringer type do the following:

- Press **PRG**
- Press the # key.
- Press a key 1..4 to select a ringer type.
- Press **OFF** to exit.


CORDLESS PHONE OPERATION



Turning Off The Ringer

To turn off the ringer on the handset, do the following:

- Press **PRG**
- Press the # key
- Press 5 to turn off the ringer
- Press **OFF** to exit
- To turn ringer on again, see **Programming the Ringer Type**.




Checking the Ringer

To check the ringer which is currently programmed, do the following:

- Press **PRG**
- Press the # key
- Press 0
- Press **OFF** to exit

The phone will ring once to show the ringer selected.



Memory Dialing

The **VTech 900i** can store up to 10 different phone numbers that you can dial just by pressing **MEM** and one of the number keys.

To Store a Number into Memory

The handset must be **OFF**.

1. Press **PRG**
2. Press the number of the memory location you wish to store the number in (0..9).
3. Using the dial pad, dial the number you want to store. The number can be up to 16 digits long.
4. Press **MEM**. That assigns the phone number to the key you selected.




CORDLESS PHONE OPERATION

If you hear a long buzzing tone, press **OFF**, then **PRG**, and store the number again. Follow the steps for each number you want to store. Assign each phone number to a different key (0..9).

To Dial a Number From Memory

1. Press **PHONE** to get the dial tone.
2. Press **MEM** and the number key (0..9).



For example, to dial the number you assigned to key '8', you would press **PHONE**, **MEM**, **8**.

To Change or Replace a Stored Number


To change or replace a stored number simply enter the new number and store it in the memory location you wish to change.

Storing Pauses in Memory

To insert a pause in a phone number, press **HOLD** at the appropriate point when storing the number. This inserts a 1.5 second pause. For longer pauses, press **HOLD** two or more times. Each press makes the pause 1.5 seconds longer and is treated as a stored digit.


If your phone is connected to a PBX you can store the PBX access number and a pause before the phone number. For example, to store **9-PAUSE-555-1234** in memory location **8**, do the following:

1. Press **PRG**
2. Press **8**
3. Press **9**
4. Press **HOLD**
5. Dial **555-1234**
6. Press **MEM**



Using Redial


To **REDIAL** the last number you dialed out, press **PHONE** then press **REDIAL**. The phone will automatically dial out the number.



CORDLESS PHONE OPERATION


Storing a Redial Number in Memory Dial

To store the last number you dialed as a regular Speed Dial number, press **PRG**, a number key (0..9), **REDIAL**, **MEM**.



The Page Feature

From the base unit, press **PAGE** to signal the person at the handset. To end the page at the base, press **PAGE** again. To end the page at the handset, press **OFF**.



This feature is also useful if you have misplaced the handset. To locate the handset press **PAGE** at the base. This starts a paging tone at the handset. When it is located, cancel the paging tone by pressing **OFF** on the handset.

Tone Definitions

A long warbling tone signals an incoming call. This tone is programmable. See **Programming The Ringer Type**.


A long series of beeps signals a page.

A short buzz when you press **PHONE** signals the batteries need charging.

A short beep signals that you are either out of range, or that a call is on **HOLD**.

A long buzzing tone signifies an invalid key operation.

LCD DISPLAY



LCD Display Icons



MAILBOX

- The **MAILBOX** icon and the *Mailbox Number* icons remain on steadily if the ITAD is set-up for 1 or more mailboxes. Otherwise they remain off for zero mailboxes. See **Mailbox programming**.
- The *Mailbox Number* icons flash (in conjunction with **MESG'S** icon) to indicate new messages designated for specific mailboxes. New messages for the *Generic* mailbox do not cause the **MAILBOX** icons to flash.

MESG'S

- **MESG'S** (the Messages icon) flashes to indicate new messages and/or memos.
- **MESG'S** will always flash if a new message/memo is present, independent of the current mailbox selection.
- **MESG'S** remains on steadily if there are messages in memory, but no new messages.

REC

- **REC** (the Record icon) flashes when either of the two outgoing announcements (Announcement 1 or 2), or a memo is being recorded.

MEMO

- The **MEMO** icon remains on steadily during memo playback.
- **MEMO** also remains on steadily during recording of a memo.

ANNC

- The Announcement icon, **ANNC**, illuminates steadily in conjunction with one of the *Announcement Number* icons (**1, 2** or **OGM**) to indicate which outgoing announcement has been selected.
- **ANNC** and the corresponding *Announcement Number* icon also illuminate steadily when the announcement is being recorded.


DAY

- The *Day* icons (**SUN-SAT**) indicates the current day by steadily illuminating the corresponding day icon when the ITAD is not in use. If the clock has not been set the **SUN** day icon will flash.
- The *Day* icon also indicates the day a message/memo was recorded by steadily illuminating the corresponding day icon for the duration of the message/memo playback.
- All of the *Day* icons flash when memory is full.


BATTERY

- The *Battery* icon will flash when the back-up battery is in need of replacement.
- This will only function when power is applied to the unit; it will not function when the back-up battery is in use.

LCD Display Digits




CLOCK/TIME STAMP DISPLAY



- The four digits on the left of the display, including the colon and the am/pm icons, display current time of day when the ITAD is not in use.
- If the clock has not been set it will remain flashing until it is properly set (See **Time and Day Setup**).
- During message/memo playback, the clock will steadily display the time stamp for that message/memo.
- During the recording of either memos or outgoing announcements, the clock will display the elapsed time in minutes:seconds.



MESSAGE COUNTER



- The two digits on the right hand side of the display form the message counter. They display the total number of messages (old and new) in the current mailbox selection (the default selection is All Mailboxes).

- In the Volume Setting mode, the message counter will display an 'L' in the first digit, followed by a 1, 2, 3, or 4 in the second digit corresponding to the current volume level setting.

BASE KEYPAD FUNCTIONS




Main Function Keys

ON/OFF

- This key is used to turn **ON** and **OFF** the ITAD. While in the **OFF** state, the cordless phone will still operate normally.
- When the ITAD is **ON**, the power LED beside the **ON/OFF** key is illuminated.


- Regardless of whether the ITAD is on or off, the message counter, and current time/day are still displayed.
- When **OFF**, the ITAD can be reactivated remotely by 10 successive rings on an incoming call.
- The ITAD is activated whenever the cordless handset is used to access the 900i by pressing **PHONE**, *, # (see **Activating Remote Operation**).

MAILBOX




- The ITAD stores the messages into different mailboxes for retrieval by the corresponding mailbox user. For example, mailbox 1 is for John, mailbox 2 is for Jane, etc.
- Use the **MAILBOX** key to select the current mailbox, either for message/memo playback or for memo recording.
- **MAILBOX** and *Mailbox Number* icons on the LCD indicate the current mailbox selection. Each press of the **MAILBOX** key selects the next mailbox option in the following order: All>Generic>1>2>3>4>All>...
- If no keys are pressed for 5 seconds, the ITAD will return to standard operation mode, and the default selection is All Mailboxes.

MEMO



- The **MEMO** key is used to record memos at the base unit into the current mailbox selection.
- Press and hold the key for 2 seconds to begin recording.
- Stop recording by either: pressing the **MEMO** key again, pressing the **STOP** key or automatically after 5 seconds of silence.


ANNC



- The Announcement key, **ANNC**, is used to select and record the outgoing announcement or outgoing message.
- Press **ANNC** briefly to select the next announcement option in the following order: Announcement 1, Announcement 2, OutGoing Message (see **Selecting the Announcement**).


- Press and hold **ANNC** for 2 seconds to begin announcement recording (see **Recording the Announcement**).

MEMORY



- The **MEMORY** key is used to check the amount of memory still available for new messages/memos.
- After pressing the **MEMORY** key, a voice message will inform you of the number of available minutes remaining in memory.
- To make more available Memory, delete old messages and/or record shorter outgoing message(s).


SETUP



- The **SETUP** key is used to access the set-up menu by pressing and holding it for more than 2 seconds (until a beep is heard).

- To see the different set-up options, keep pressing **SETUP** key briefly (1 press per option).
- To terminate Set-up mode, either press **STOP** or it is done automatically by not pressing any keys for a 5 second period.

VOLUME



- The **VOLUME** key is used to select the volume level of the base unit speaker.
- 4 volume levels are available.
- The volume level setting is displayed on the LCD *Message Counter* for 2 seconds after this key is pressed (L1, L2, L3, or L4 - L1 is the lowest volume level; L4 is the highest).
- Each press of the **VOLUME** key selects the next volume level.
- Note that the first press of this key doesn't change the volume level but just displays the current volume.
- The volume level always decreases towards the lowest level before increasing.
- You can adjust the volume key during message playback and call screening. Call screening is when you wait for the caller to start leaving a message before you decide if you will take the call.
- The volume key is not active while in set-up mode.

Message Playback Keys




ERASE

- PRESS ONCE TO ERASE CURRENT PLAYING MESSAGE
- PRESS and HOLD TO ERASE ALL REVIEWED MESSAGES

ERASE

- The **ERASE** key is used to delete old messages (previously reviewed) from the ITAD.
- Pressing **ERASE** during message playback deletes that message.
- If this key is pressed and held for more than 2 seconds, all **old** (previously reviewed) messages in the current mailbox selection will be deleted (This feature works only when the answering machine is idle; it does not work during message playback).
- To prevent accidental deletion of new messages, you are not able to delete a message unless it has been listened to first!



ERASE

- TO REPLAY CURRENT PLAYING MESSAGE :
PRESS **REPEAT**
- TO REPEAT PREVIOUS MESSAGE
PRESS **REPEAT REPEAT**

REPEAT

- The **REPEAT** key is used to return to the beginning of a message during message playback.
- If this key is pressed prior to a message, the previous message will begin.
- The previous message will also begin if this key is pressed twice quickly during message playback.




STOP

- TO STOP MESSAGE PLAYBACK
- TO STOP MEMO RECORDING
- TO STOP ANNC. RECORDING
- TO EXIT SET-UP MODE

PRESS **STOP**

STOP

- The **STOP** key is used to exit the current mode of operation and return to the ITAD *Standard operation* mode.
- Use **STOP** to stop message playback, stop memo or announcement recording, or exit the set-up mode.



PLAY

- TO PLAYBACK ALL MESSAGES
PRESS **PLAY** ONCE
- TO PLAYBACK ANNC. MESSAGES
PRESS **PLAY** and HOLD 2 SEC.

PLAY

- The **PLAY** key is used to begin playback of all messages/memos (new and old) in the current mailbox selection (the default mailbox selection is *All*).
- This key is also used to play the current announcement message by pressing and holding it for more than 2 seconds.



SKIP

- TO PLAY NEXT MESSAGE :

PRESS **SKIP**

SKIP

- The **SKIP** key advances to the beginning of the next message during message playback.

INITIAL SET-UP

Press the **SETUP** key for more than 2 seconds to enter the set-up mode or until it beeps once. Here you can set the ring type, security code, time/day and mailbox programming as follows.

Ring Type Programming


The ITAD has 3 ring type settings:

- 2 rings** The incoming call is answered after 2 rings.
- 4 rings** The incoming call is answered after 4 rings.
- Toll Saver** The incoming call is answered after 2 rings only

if there are new messages/memos present in memory; otherwise, answers call after 4 rings. Thus, if Toll Saver is active and your ITAD rings 3 times when you call, you can hang-up to avoid any long distance charges.

To change ring type setting:

1. Press and hold the **SETUP** key for 2 seconds. The ITAD will beep and the LCD will display "rt" (ring type) and the current ring type setting.
2. Use the **REPEAT** and **SKIP** keys to scroll to the desired ring type. Forward selection is in the following order **2 rings, 4 rings, Toll saver**.
3. Press the **SETUP** key to exit ring type programming mode, and advance to security code programming, or press the **STOP** key to exit the set-up mode, and return to standard operation mode.




Security Code Programming

The security code programmed into the ITAD is used to gain access to the functions from remote locations.

The security code default setting is 99.

To change security code:

1. Press and hold **SETUP** until it beeps.
2. Press **SETUP** briefly. The LCD will display "SC" (Security Code) and the current security code setting.
3. Use **REPEAT** and **SKIP** to scroll to desired code, between 00 and 99.
4. Press **SETUP** to exit security code programming mode, and advance to time/day programming, or press **STOP** to exit.




Note: When accessing the ITAD remotely, the security code is preceded by the * key.

Time and Day Setup

The Time and Day default is set to **SUN 12:00 pm**. This will flash to indicate clock has not been set.

To change the time display on the LCD:




1. Press and hold **SETUP** for 2 seconds or until it beeps.
2. Press **SETUP** 2 times until clock is displayed and the **DAY** icon is flashing.
3. Use **REPEAT** and **SKIP** keys to select correct day.
4. Press **SETUP** to advance to hour programming. Use **REPEAT** and **SKIP** keys to select correct hour and am/pm.
5. Press **SETUP** to advance to minute programming. Use **REPEAT** and **SKIP** keys again.
6. Press **SETUP** to exit time/day programming mode, and advance to mailbox programming, or press **STOP** to exit.

Mailbox programming

The ITAD has the ability to be programmed for up to 4 individual mailboxes. In addition, there is also a *Generic* mailbox for general messages storage. On initial power-up, only the *Generic* mailbox is enabled.

To change the number of mailboxes:

1. Press and hold **SETUP** for 2 seconds or until it beeps.
2. Press **SETUP** 5 times until **MAILBOX** icon is illuminated.
3. Use **REPEAT** and **SKIP** keys to scroll through selections (the *Mailbox Number* icons indicate which mailboxes are enabled).
4. Press **SETUP** to exit mailbox programming mode, and return to ring type programming, or press **STOP** to exit.



Selecting the Announcement

The **ANNC** key is used to select the current outgoing announcement. There are 3 choices of Announcements as follows: **1, 2 & OGM**.

Announcement 1

You can record your own personal announcement and the caller is able to leave a message.

If you do not record your own announcement, the factory default announcement:

Please record message after the tone.

will be used (see **Recording the Announcement**).

Announcement 2

You can record your own announcement but the caller is not able to leave a message.

If you do not record your own announcement, the factory default announcement:

No one can answer the phone at the moment, please call again.

will be used (see **Recording the Announcement**).

After you record your own announcement, you can return to the default announcement by record an OGM less than 1 second.

OGM (OutGoing Message)

You are not able to record an announcement, it is programmed into ITAD memory. The caller is not able to leave a message.

Programmed **OGM** Announcement:

No one can answer the phone at the moment, please call again.


Note: The ITAD will default to OGM Announcement if the current selection is Announcement 1 and the memory is full.

Recording the Announcement

1. Press **ANNC** key until the desired announcement icon is displayed on the screen (1 or 2).

2. Press and hold **ANNC** key for 2 seconds until a beep is heard. The clock will display **0:00** and will start incrementing for the length of the announcement.

3. Speak into the microphone on the base. Announcement can be no more than 2 minutes in length. More than 5 seconds of silence will automatically stop recording.
4. Press **ANNC** key or **STOP** to stop the recording.
5. To review a recorded announcement, press and hold the **PLAY** key for 2 or more seconds.



Example Announcements:

Example for Announcement 1 with zero mailboxes (acts as standard answering machine):

Hello. You've reached 555-1234, I can't come to the phone right now. Please leave a message after the beep. Thank you

Example for Announcement 1 (with all mailboxes on):

Hi! We can't come to the phone right now. If you have a message for John press 1, if you have a message for Jane press 2, if you have a message for Jack press 3, if you have a message for Jill press 4. If you have a message for

any one of us press 0 or just stay on the line and record after the beep. Thank you.

Example for Announcement 2:
Hi. You've reached Jack and Jill. We will be back after 1 pm. Please call us back then. Thank you.

Leaving a Message

The ITAD will answer the call (according to the current ring selection), play the current announcement followed by a beep tone to signify the start of recording.

- Messages can be a maximum of 5 minutes in length; anything longer will be cut-off. The ITAD will automatically stop recording if there is more than 5 seconds of silence.

- To select a specific destination mailbox for the message, press the number corresponding to the desired mailbox. For the Generic mailbox press 0 or just wait for the beep.

NOTE: Mailboxes must be enabled before they can be used (see **Mailbox Programming**).


Recording a Memo

To record a memo at the base unit:

1. Press **MAILBOX** key to select the mailbox where you want to record the memo. If current mailbox setting is *All*, the memo will be stored in the *Generic Mailbox*.
2. Press and hold the **MEMO** key for 2 seconds until a beep is heard. The **MEMO**, **MAILBOX** and corresponding *Mailbox Number* icons will illuminate, the **REC** icon

will flash, and the clock display will start incrementing from 0:00.

3. Speak into the base microphone to record the memo.
4. Press the **MEMO** key again or press the **STOP** key to stop the recording.



Listening to Messages

When new messages and/or memos are in the ITAD, **MESG'S** (messages icon) will flash. If the messages or memos have been sent to a specific mailbox, the corresponding *Mailbox number* icon will also flash.


To playback messages:

- Press **MAILBOX** to reach the mailbox from which messages will be played. The message counter will indicate the total number of messages (new and old) present in the current mailbox selection. A voice prompt will indicate the number of **new** messages present in the current mailbox selection.

- Press **PLAY** (for less than 2 seconds) to begin playback of messages and/or memos in current mailbox selection. The clock will display the time and day that the current message was recorded.


- **REPEAT** and **SKIP** keys can be used to scan forward and backwards through messages during playback.

- Press **STOP** at any time during message playback to exit.



To delete messages:

- Press **ERASE** button at any time during message or corresponding time and day stamp to delete current message.
- When all messages have been heard, all messages within that mailbox can be deleted by pressing the **ERASE** key for more than 2 seconds. **New** messages that still exist in that mailbox will be saved, only the old messages will be deleted.



Message/memo playback begins with a voice prompt indicating the **total** number of messages present in the current mailbox selection. It then proceeds to play the messages; the most recently recorded messages are heard first. New messages are preceded with the voice prompt "**New message**" and memos are preceded with the voice prompt "**Memo**" (new memos are preceded by "**New memo**").

The time and day stamp is announced after each message is played.

After all messages and memos have been played, the final voice prompt will be "**End of messages**".

NOTE: If the phone rings while you are playing messages at the ITAD base, you can stop message playback by pressing STOP at the base.

Remote operation allows you control the functions of the **VTech 900i** when you are away from the base unit. Therefore remote operation can be accessed from the handset of your **900i** cordless phone or at a phone connected to a different telephone line. The ITAD **cannot** be accessed from another telephone on the same line as your **VTech 900i**.

You can access many of the ITAD functions from a remote location such as listening to messages, changing recorded announcement, and recording a memo.


To access the ITAD from a remote location you must use a phone with Touch Tone Service. Remote operation can **only** be accessed from a touch tone phone. If the remote phone is set to pulse dialing, switch it to tone. If tone dialing is not available you will not be able to access the ITAD.

ACTIVATING REMOTE OPERATION

To activate remote operation from your cordless handset

1. Pick up handset and press **PHONE** to get a line, you will hear a dial tone.
2. If your phone is set on pulse dial, press the * key to enter touch tone dialing mode. Otherwise omit this step.
3. Press the * key followed by the # key within 10 seconds. This enables you to release the connection to the phone line and allows you to communicate directly with the ITAD. If a mistake is made press the **PHONE** key again and re-enter the * followed by #.

4. You did it! You are now in remote operation mode. Now you will hear a series of voice prompts. You will use the number keys to control any of the available ITAD functions.




Note: Whenever you access the ITAD from the **900i** handset by pressing **PHONE**, *, #, the ITAD will be automatically turned **ON**.

To activate remote operation from a different telephone line

1. Dial the telephone number of your **VTech 900i** and wait for the ITAD to answer. If the ITAD is OFF when you call, simply let the ITAD ring 10 times, and it will automatically turn itself on and answer your call.
2. Once the ITAD answers, it will begin playing the currently selected announcement (as with any incoming call).
3. Enter the * key followed by the 2 digit security code during the announcement.

REMOTE OPERATION OF ITAD

- Once the security code is received, you are in remote operation mode. You will hear a series of voice prompts and you can control the ITAD functions with the numbered keypad.



NOTE: If you want to hang up the phone while you are in the middle of playing messages, you must press 4 to STOP message playback. If you do not press this key the ITAD will continue to play message(s) and tie up your phone line after you have hung up!

If no command is entered for approximately 20 seconds (the ITAD will repeat the voice prompts at the current level twice during this time) the ITAD will automatically terminate remote access mode from a different telephone line.

VOICE PROMPTS

Upon entering the remote access mode you will be greeted with a series of voice prompts. The first voice prompt will be either "**X new messages**", or "**No new messages**", indicating the **total** number of new messages present in *All* mailboxes.

In addition, the voice prompt "**Memory Full**" will be added if the ITAD has no more space for new messages, and the voice prompt "**Low Battery**" will be added if the back-up battery in the ITAD is low on charge.

There are 3 different levels of voice prompts.

The 1st or top level voice prompts are:
"Press 1 to play messages"
"Press 6 to select mailbox"
"Press * for other functions"

If the * key is pressed, the 2nd level of voice prompts are:

"Press 7 to play announcement"
"Press 8 to select announcement"
"Press 9 to record announcement"
"Press 0 to record memo"
"Press # to turn answering machine off"
"Press * for other functions"

If the * key is pressed at level 2, the 3rd level of voice prompts are:

"During message playback"
"Press 2 to repeat message"
"Press 3 to skip message"
"Press 4 to stop playback"
"Press 5 to delete message"
"Press * for other functions"

If the * key is pressed at this level, voice prompting returns to level 1 (top level).


Note that this 3 level menu structure **does not** restrict you to operating the ITAD functions in the above order. For example, pressing 7 will play the current announcement at **any time**.

REMOTE OPERATION OF ITAD

The more you use the ITAD in remote operation, the more familiar you will become with the various functions on the numbered keypad. Soon you may be able to access all functions with little or no help from the voice prompts!


Listening to Messages

- Press 6 to enter mailbox selection.
- Press 1-4 for the corresponding mailbox or 0 for *Generic* mailbox. You could also press 5 for *All* mailboxes or skip steps 1 & 2 (as *All* mailboxes is the default).
- Press 1 to play messages from the chosen mailbox.
- Use the keys 2 (repeat) & 3 (skip) to scan forwards and backwards through messages.
- Press 5 at any time during or immediately following a message to delete.




Changing the Announcement

- Press 7 to check the current announcement.
- Press 8 until the desired Announcement is reached (1, 2 or OGM).
- If Announcement 1 or 2 is chosen, press 9 to record. If **OGM** is chosen skip steps 3-5.
- Record Announcement after the beep.
- Press 4 to stop recording.




Recording a Memo

- Press 6 for mailbox selection.
- Choose mailbox 1-4, 0 for *Generic* mailbox, or 5 for *All* mailboxes. You can also skip steps 1 & 2 if you choose *All* mailboxes - the memo will be stored in the *Generic* mailbox (this is the default).
- Press 0 to record a memo to the currently selected mailbox.
- Record memo after the tone.
- Press 4 to stop recording.



REMOTE COMMANDS

You can access almost all of the ITAD functions in remote mode. By pressing keys on the numbered keypad you can access these functions. Below is a diagram of the numbered keypad with the related commands labeled. A description of each key follows.



1 MESSAGE PLAYBACK

- Press **1** to playback all the messages and memos in the currently selected mailbox.

- If you want to listen to messages from a particular mailbox, press **6** for *Select Mailbox*. Otherwise you will hear messages from *All Mailboxes* (this is the default in remote operation).
- Before message playback, you will hear either:
 - "Message playback mailbox X", where X is 1-4,
 - "Message playback generic mailbox", or
 - "Message playback all mailboxes", depending on the current mailbox selection. If the ITAD is set up for zero mailboxes, the voice prompt will simply say: "Message playback".
- If the current mailbox selection is *All Mailboxes*, there will be **NO** further voice prompts indicating which mailbox a message came from.
- A voice prompt indicating the **total** number of messages (new and old) that are present in the current mailbox selection is heard next.
- Message playback begins with new messages with the most recent messages heard first. Each message is preceded by "New message" or "New memo".
- Message playback continues in the same fashion with old messages. Memos are preceded with "Memo".
- The time and day stamp is announced after each message. You can bypass the time/day information and skip to the next message by pressing **3**, the *Skip* key.
- A tone is played after the time and day stamp to separate the messages.
- After all messages and memos have been played, you will hear the final voice prompt "End of messages".

2 REPEAT

- Press **2** while listening to message to repeat the current message.
- To repeat the previous message, press **2** while listening to message introduction or press **2** twice quickly during message playback.
- This key has no function if ITAD is not in *Playback* mode.

3 SKIP

- While listening to messages (*Playback* mode), press **3** to terminate the present message and skip to the next message.
- **SKIP** can also be used to bypass voice prompts (e.g. before recording a memo).

4 STOP

- While in *Playback* mode, press **4** to stop playback of the message.
- If no other keys are pressed within 20 seconds, remote operation mode will be terminated, and the base unit will hang-up the line (This only occurs if you are in remote access mode on a different telephone line).
- During memo or announcement recording, press **4** to stop the recording.

5 DELETE

- Press **5** at any time during, or immediately following message (during time/day stamp); this will delete the message.
- The voice prompt, "Press 5 to confirm deletion", gives you one more chance to decide.
- Press **5** again to delete.
- You will hear "Message deleted".

6 SELECT MAILBOX

- Press **6** to select the current mailbox. *All Mailboxes* is the default setting.
- You will hear the voice prompt "Enter mailbox number". If you have set the ITAD for zero mailboxes, this key will have no function. The voice prompt in this case will be "No mailboxes".
- Valid mailbox numbers are **1-4** for mailboxes 1-4 (only mailbox numbers which were defined in the set-up will be accepted), **0** for *Generic* mailbox, and **5** for *All* mailboxes.
- After a valid mailbox number is entered, you will hear either "Mailbox X", where X is 1-4, "Generic mailbox", or "All mailboxes", depending on the selection made.
- After the voice message indicates the current mailbox selection, an additional voice prompt of either "X new messages", or "No new messages" will occur, indicating the total number of new messages present in the new mailbox selection.

7 PLAY ANNOUNCEMENT

- Press **7** to play back the current announcement, this will be preceded by a voice prompt of either "Announcement 1", "Announcement 2", or "Outgoing message", depending on the current announcement selection.

8 SELECT ANNOUNCEMENT

- Press **8** to toggle between available announcements.
- After each press, you hear "Announcement 1", "Announcement 2", or "Outgoing message".
- The first time the key is pressed, the voice prompt will indicate the current selection.

9 RECORD ANNOUNCEMENT

- Press **9** to record a new announcement.
- You will hear "Record announcement X after tone, press 4 to end recording", where X is either 1 or 2, depending on the current announcement selection.
- If your current selection is *Outgoing Message*, you will hear "Cannot record outgoing message".
- Press **4** to complete announcement recording.

0 RECORD MEMO

- Press **0** to record a new memo to the currently selected mailbox. If the current mailbox selection is *All Mailboxes*, then the message is recorded into the *Generic* mailbox.
- You will hear either "Record memo for mailbox X after tone, press 4 to end recording", where X is 1-4, or "Record memo for generic mailbox after tone, press 4 to end recording".
- If you have set the ITAD for zero mailboxes, you will hear "Record memo after tone, press 4 to end recording".
- Press **4** to STOP recording
- You can press **3** (skip) to bypass the voice prompt, and you'll hear the beep to start recording.

OFF

- Press **#** to switch the ITAD off.
- You will hear "Answering machine off".
- Now the ITAD will only be reactivated to answer an incoming call if the caller lets it ring 10 times.

TAKING CARE OF YOUR TELEPHONE.

Your *VTech 900i* cordless telephone contains sophisticated electronic parts so it must be treated with care.

Avoid rough treatment

Place the handset down gently. Save the original packing materials to protect your telephone if you ever need to ship it.

Avoid water

Your telephone can be damaged if it gets wet. Do not use the handset outdoors in the rain, or handle it with wet hands. Do not install your base unit near a sink, bathtub or shower.

Remember that electrical appliances can cause serious injury if used when you are wet or standing in water. If your base unit should fall into water, **DO NOT RETRIEVE IT UNTIL YOU UNPLUG THE POWER CORD AND TELEPHONE LINE CORDS FROM THE WALL.** Then pull the unit out by the unplugged cords.

Electrical storms

Electrical storms can sometimes cause power surges harmful to electronic equipment.

For your own safety, use caution when using electric appliances during storms.

Cleaning your telephone

Your telephone has a durable plastic casing that should retain its luster for many years. Clean it only with a soft cloth slightly dampened with water or a mild soap. Do not use excess water or cleaning solvents of any kind.

OUT OF RANGE INDICATION

NOISE OR INTERFERENCE

Your **VTech 900i** cordless telephone has auto-channel scan circuitry which will detect excess noise and change the channel of the phone to reduce it. This is done automatically.

Since the **VTech 900i** is a fully digital phone it does not suffer from noise associated with regular cordless phones. At times you may experience occasional "drop outs" especially at the extreme edges of the phone's range. Simply move closer to the base unit and this will disappear.

AUTOMATIC SECURITY CODING

Every time you place the handset in the base, your **VTech 900i** phone randomly picks one of 65,000 possible security codes. This allows your handset and base to recognize each other, and minimizes the possibility of another cordless phone using your telephone line.

OUT OF RANGE INDICATION

If the handset is moved to a point where the base and handset can no longer communicate, the handset will make a quick series of beeps to signal "Out of Range." It will continue to make the beeps at 10-30 second intervals.

OUT OF RANGE WHEN PHONE IS ON

If you are presently engaged in a phone conversation move closer to the base. If the base unit does not communicate with the handset within 30 seconds of losing contact it will automatically hang up.

OUT OF RANGE WHEN PHONE IS OFF

If the phone is **OFF**, the handset and base still monitor each other to make sure that they can communicate. If the handset is moved out of range, the handset will make a series of beeps at 10-30 second intervals. This tells you that the handset may not ring for incoming calls.

If you wish to stop the "Out of Range" tones, simply press and hold any number key on the handset until the handset beeps an acknowledgment. The handset will not work until the handset is brought closer to the base. The base unit will continue to function during this time.

When the base unit is unplugged from the power supply, the handset will begin to give the "Out of Range" warning beeps. This will continue until the base is powered again and the handset is placed into the base cradle for re-initialization. If you wish to turn off the "Out of Range" beeping, simply press any key on the handset and hold until the handset beeps an acknowledgment.

IN CASE OF DIFFICULTY

If you have difficulty operating your phone, the suggestions below should solve the problem. If you still have difficulty after trying these suggestions, In the US call:

VTECH Communications
at 1-800-624-5688.

In Canada call:

VTECH Electronics
at 1-800-267-7377

THE PHONE DOESN'T WORK AT ALL.

- Make sure the power cord is plugged in.
- Make sure the telephone line cord is plugged firmly into the base unit and the telephone wall jack.
- Make sure the batteries are properly charged. If the **MUTE/LOW BAT** indicator is on, the battery needs charging. If the **IN USE** and **PHONE** indicators do **not** light when you press **PHONE**, you must charge the batteries.
- If you recently installed a new battery pack, make sure it is installed correctly.

Follow the procedure:

1. Remove battery from handset.
2. Disconnect power supply from base unit.
3. Wait a few minutes.
4. Re-connect power supply to base unit.
5. Replace battery in handset.
6. Place the handset in the charge cradle. Wait 60 seconds.

Pick up the handset and press **PHONE**.

NO DIAL TONE.

- First check all the suggestions above.
- If you still don't hear a dial tone, disconnect the base unit from the telephone jack and connect a different phone. If there is no dial tone on that phone either, the problem is in your wiring or local service. Call your local telephone company.

YOU GET NOISE, STATIC, OR A WEAK SIGNAL EVEN WHEN YOU'RE NEAR THE BASE UNIT.

- Place the handset in the base momentarily to re-set the security code. Then press **PHONE** to get a line.

Household appliances plugged into the same circuit as the base unit can sometimes cause interference. Try moving the appliance or the base unit to another outlet.

YOU GET NOISE, STATIC, OR A WEAK SIGNAL WHEN YOU'RE AWAY FROM THE BASE UNIT.

- You may be out of range. Either move close to the base, or relocate the base unit.
- The layout of your home may be limiting the range. Try moving the base unit to the second or third floor.

IN CASE OF DIFFICULTY

THE HANDSET DOES NOT RING WHEN YOU RECEIVE A CALL.

- Make sure you have the handset ringer activated.
- Make sure the telephone line cord is plugged firmly into the base unit and the telephone jack. Make sure the power cord is plugged in.
- You may be too far from the base unit.
- You may have too many extension phones on your telephone line to allow all of them to ring. Try unplugging some of the other phones.

YOUR CALLER FADES IN AND OUT.

You may be nearly out of range. Move closer, or relocate the base.

YOU HEAR OTHER CALLS WHILE USING YOUR PHONE.

- Replace the handset in the base cradle, wait a few moments and try again.
- Disconnect your base unit from the telephone jack, and plug in a regular telephone. If you still hear other calls, the problem is probably in your wiring or local service. Call your local telephone company.

YOU HEAR NOISE IN THE HANDSET, AND NONE OF THE KEYS OR BUTTONS WORK.

- Make sure the power cord is plugged in.
- Your base unit and handset may not be operating on the same channel or security code. Place the handset in the cradle for a few moments to reload the security code and reset the channel.

COMMON CURE FOR ELECTRONIC EQUIPMENT

Electronics, like people, can sometimes get confused. If the unit does not seem to be responding normally, then try putting the handset in the cradle to re-initialize the unit. If it still does not seem to respond after doing this a few times, do the following (in the order listed):

1. Disconnect the power to the base.
2. Disconnect the handset battery.
3. Wait a few minutes.
4. Connect power to the base.
5. Connect the handset battery.
6. Put the handset in the base to reinitialize.

WARRANTY STATEMENT

WHAT DOES OUR WARRANTY COVER?

- Any defect in material or workmanship.

FOR HOW LONG AFTER THE ORIGINAL PURCHASE?

- One Year.

WHAT WILL VTECH DO?

- At our option, repair or replace your unit.

HOW DO I SEND MY UNIT, IN OR OUT OF WARRANTY?

- In the US, call VTECH Communications customer service for Return Authorization at:
1-800-624-5688

IF YOU PURCHASED YOUR TELEPHONE IN CANADA

Please call: **1-800-267-7377**

- Properly pack your unit. Include any cables & accessories which were originally provided with the product. We recommend using the original carton and packing materials.
- Include in the package a copy of the sales receipt or other evidence of date of original purchase (if the unit was purchased within the last twelve months).
- Print your name and address, along with a description of the defect, and include this in the package.

- Include payment for any service or repair not covered by warranty, as determined by VTECH Communications or VTECH Electronics Canada Ltd.

- In the US, ship the unit via UPS Insured, or equivalent to:

VTECH COMMUNICATIONS
8770 SW Nimbus Avenue
Beaverton, Oregon 97008

Ship to: **VTECH ELECTRONICS**
200-7671 Alderbridge Way
Richmond, BC V6X 1Z9

**VTECH ASSUMES NO
RESPONSIBILITY FOR UNITS
RETURNED
WITHOUT PRIOR RETURN
AUTHORIZATION.**

WHAT DOES OUR WARRANTY NOT COVER?

- Batteries
- Damage from misuse, neglect, or acts of nature (lightning, floods, power surges, etc.)
- Products which may have been modified or incorporated into other products
- Products purchased outside the USA
- Products serviced by the owner or a service facility not expressly authorized by VTECH Communications
- Products purchased more than 12 months from current date

This equipment complies with Parts 15 and 68 of the Federal Communications Commission (FCC) rules for the United States. It also complies with regulations RSS-210 and CS-03 of Industry Canada (IC).

A label is located on the underside of the base unit containing either the FCC registration number and Ringer Equivalence Number (REN) or the IC registration number and Load Number (LN). You must, upon request, provide this information to your local telephone company.

This equipment is compatible with inductively coupled hearing aids.

Should you experience trouble with this telephone equipment, please contact:

In the United States:
VTECH COMMUNICATIONS
1-800-624-5688
In Canada:
VTECH ELECTRONICS
1-800-267-7377

for repair/warranty information. The telephone company may ask you to disconnect this equipment from the line network until the problem has been corrected.

Your **VTech 900i** is designed to operate at the maximum power allowed by the FCC and IC. This means your handset and base unit can communicate only over a certain distance - which will depend on the location of the base unit and handset, weather, and the construction and layout of your home or office.

If you move the handset out of range during a phone conversation, you will hear an 'Out of Range' tone to tell you to move closer to the base. If you do not move within range within 30 seconds the call is automatically disconnected.

If you move out of range when the handset is in standby mode, it will give an 'Out of Range' tone to tell you that the handset will not be able to receive or place calls. You may terminate the 'Out of Range' tone by pressing any number key on the handset.

FCC Part 15

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The equipment has been tested and found to comply with part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet or on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Part 68

The FCC requires that you connect your cordless telephone to the nationwide telephone network through a modular telephone jack (USOC RJ11C or RJ11W).

Your telephone company may discontinue your service if your equipment causes harm to the telephone network. They will notify you in advance of disconnection, if possible. During notification, you will be informed of your right to file a complaint with the FCC.

Occasionally, your telephone company may make changes in its facilities, equipment, operation, or procedures that could affect the operation of your equipment. If so, you will be given advance notice of the change to give you an opportunity to maintain uninterrupted service.

The base unit contains no user serviceable parts. The handset contains a user replaceable battery pack.

If it is determined that your telephone equipment is malfunctioning, the FCC requires that it not be used and that it be unplugged from the modular jack until the problem has been corrected. Repairs to this telephone equipment can only be made by the manufacturer or its authorized agents or by others who may be authorized by the FCC. For repair procedures, follow the instructions outlined under the VTECH Limited Warranty.

This equipment may not be used on coin service lines provided by the phone company or on party lines.

The REN is useful in determining the number of devices you may connect to your telephone line and still enable the devices to ring when you receive a call. The general rule is that the REN value should not exceed 5.0A total; however, contact your local telephone company for the specific number in your area.

IC (Industry Canada)

This telephone is registered for use in Canada.

Notice: The Industry Canada label identifies certified equipment. This certification means that the equipment meets certain telecommunications network, protective, operational and safety requirements. Industry Canada does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connections. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

The Load Number (LN) assigned to this device denotes the percentage of the total load to be connected to a telephone loop which is used by the device to prevent overloading. The termination on a loop may consist of any combination of devices subject only to the requirement that the total of the load numbers of all the devices does not exceed 100.

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

FREQUENCY CONTROL

Crystal Controlled Dual PLL Synthesizer

TRANSMIT FREQUENCY

Handset : 925.05 MHz to 927.75 MHz
(All ten channels within this range)

Base : 902.3 MHz to 905.0 MHz
(All ten channels within this range)

RECEIVE FREQUENCY

Handset : 902.3 MHz to 905.0 MHz
(All ten channels within this range)

Base : 925.05 MHz to 927.75 MHz
(All ten channels within this range)

NOMINAL EFFECTIVE RANGE

Maximum power allowed by FCC and IC. Actual operating range may vary according to environmental conditions at the time of use.

The range quoted for this phone is based on open field measurements under ideal conditions.

WEIGHT

Handset : 345 grams (with battery)
Base : 1075 grams (with AC adapter)

SIZE

Handset : 20.0cm x 6.2cm x 4.3cm
(L x W x T) maximum
(antenna excluded)
Base : 22.0cm x 19.5cm x 6.1cm
(L x W x T) maximum
(antenna excluded)


POWER REQUIREMENTS

Handset : Self-contained nickel-cadmium rechargeable battery supply, 6.0V nominal, 600mAh capacity.

Power Adapter: 12VDC @ 500mA


SPECIFICATIONS ARE TYPICAL AND MAY CHANGE WITHOUT NOTICE.

Vtech 900i Cordless Telephone



Wall Mounting Template

Use this template when wall mounting your base unit. To mark the positions of the mounting screws, hold this template against the wall, and press a pencil or pen point through the center of each crossmark.



NOTE:

Select a spot where you can screw into a wooden stud within the wall. The mounting screws will not hold securely in plaster or wallboard alone.