



MOTOROLA
intelligence everywhere™



MA3160 Series User Guide

2.4 GHz Cordless Telephone with
Answering Machine

For a copy of a large-print version of this guide, or for product-related questions, please visit us online:

www.motorola.com/cordless

or contact us at:

1-800-353-2729 U.S.A.

1-800-461-4575 Canada

1-888-390-6456 TTY (Text Telephone)

Motorola reserves the right to revise this publication and to make changes in content from time to time without obligation on the part of Motorola to provide notification of such revision or change. Motorola provides this guide without warranty of any kind, either implied or expressed, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Motorola may make improvements or changes in the product(s) described in this manual at any time.

MOTOROLA, and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners.

Copyright © 2005 Motorola, Inc.

All rights reserved. No part of this publication may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation or adaptation) without written permission from Motorola, Inc.

Welcome

Welcome

Congratulations on your purchase of a Motorola MA3160 Series Cordless Telephone. Take a moment to ensure that your purchase includes each of the items pictured below.




Important: Product registration is an important step toward enjoying your new Motorola product. Registering helps us facilitate warranty service, and permits us to contact you should your Motorola product require an update or other service. Registration is not required for warranty coverage. To register your product online, visit:


<https://broadbandregistration.motorola.com>

Please retain your original dated sales receipt for your records. You must show proof of purchase, and return the defective product to Motorola, a working unit is sent after the defective product is received. Registration is not required for warranty coverage.


Handset Features Overview



Base Unit Overview



Stand Alone Charger Overview



UNCONTROLLED
DOCUMENT

Table of Contents

Welcome	i
Important Safety Instructions	vii
FCC Information	x
Getting Started	1
Battery Safety Instructions	1
Charging the Battery	2
Handset Display Overview	6
Installation	7
Setting Up	8
Personalizing Your Handset	8
Selecting Ring Tones	8
Selecting Language Preference	9
Setting Touch Tone or Pulse Dialing	9
Setting Date and Time	10
Using the Handset	11
Making a Call	11
Answering/Ending a Call	11
Locating a Misplaced Handset	12
Using the Channel Key	12
Adjusting the Volume During a Call	12
Muting a Call	12
Forwarding a Call	13
Common Display Messages	14
Storing Numbers in Memory	15
Assigning Speed Dial Numbers	15
Dialing Speed Dial Numbers	17
Editing Speed Dial Numbers	17
Reassigning Speed Dial Numbers	17

Erasing Speed Dial Numbers	18
Entering Numbers into Phonebooks	18
Editing or Erasing a Programmed Number	20
Using Caller ID	20
Storing a Caller ID Entry in the Phonebook	21
Dialing a Caller ID Listing	21
Reviewing Caller ID Lists	21
Deleting a Specific Caller ID Listing	22
Deleting All Caller ID Listings	22
Using the Answering Machine	23
Setting Up the Answering Machine	24
Setting the Date and Time	24
Setting Up Your Outgoing Message (OGM)	24
Mailboxes and Announcements	24
Announcement Options	24
Recording Outgoing Message (OGM)	25
Reviewing an OGM	25
Deleting an OGM	25
Common Answering Machine Display Messages ...	26
Setting the Answering Machine Features	28
Accessing the Answering Machine Remotely	29
Motorola Limited Warranty	30

Important Safety Instructions

Follow these safety precautions when using your cordless phone to reduce the risk of fire, electric shock and injury to persons or property:

To reduce the risk of fire and shock:

1. Keep all slits and openings of the phone unblocked. Do not set the phone on a heating register or over a radiator. Ensure that proper ventilation is provided at the installation site.
2. Do not use while wet or while standing in water.
3. Do not use this product near water (for example, near a bath tub, kitchen sink, or swimming pool).
4. Do not allow anything to rest on the power cord. Place the power cord so that it will not be walked on.
5. Never insert objects of any kind into the product slits as that may result in fire or shock.
6. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
7. Do not disassemble this product. If service or repair work is required, contact the Motorola address found in the back of this user guide.
8. Do not overload wall outlets and extension cords.
9. Avoid using during an electrical storm. Use a surge protector to protect the equipment.
10. Do not use this cordless phone to report a gas leak, especially if you are in the vicinity of the gas line.

Caution: To reduce the risk of fire, use only No. 26 AWG or larger UL listed or CSA Certified Telecommunication Line Cord.

Unplug this cordless phone immediately from an outlet if:

- The power cord or plug is damaged or frayed.
- Liquid has been spilled into the product.
- The product has been exposed to rain or water. Do not retrieve the handset or base until after you have unplugged the power and phone from the wall. Then retrieve the unit by the unplugged cords.
- The product has been dropped or the cabinet has been damaged.
- The product exhibits a distinct change in performance.

Installation Guidelines

1. Read and understand all instructions and save them for future reference.
2. Follow all warnings and instructions marked on the product.
3. Do not install this product near a bath tub, sink, or shower.
4. Operate this phone using only the power source that is indicated on the marking label. If you are unsure of the power supply to your home, consult your dealer or local power company.
5. Do not place this product on an unstable cart, stand, or table. This product may fall, causing serious damage to the product.
6. Adjust only those controls that are covered by the operating instructions. Improper adjustment of other controls may result in damage and will often require extensive work to restore the product to normal operation.
7. Clean this product with a soft, damp cloth. Do not use chemicals or cleaning agents.

8. Use only the power supply that came with this unit. Using other power supplies may damage the unit.
9. Because cordless phones operate on electricity, you should have at least one phone in your home that isn't cordless, in case the power in your home goes out.
10. To avoid interference to nearby appliances, do not place the base of the cordless phone on or near a TV, microwave oven, refrigerator, or VCR.

Caution: To maintain compliance with the FCC's RF exposure guidelines, place the base unit at least 20 cm from nearby persons.

UNCONTROLLED
DOCUMENT

FCC Information

This equipment complies with Parts 15 and 68 of the FCC rules and the requirements adopted by the Administrative Council for Terminal Attachments (ACTA).

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

Notification of Local Telephone Company

On the bottom of this equipment is a label that contains, among other information, a product identifier in the form US:AAAEQ##TXXXX. You must, upon request, provide this information to your telephone company.

The digits represented by ## in the product identifier indicate the Ringer Equivalency Number (REN) for this equipment. The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, contact your local telephone company.

Note: This equipment may not be used on coin service provided by the telephone company.

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this cordless phone does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

Notice must be given to the telephone company upon permanent disconnection of your telephone from your line. The FCC requires that you connect your cordless telephone to the nationwide telephone network through a modular telephone jack (USOC RJ11C/RJ11W or RJ14C/RJ14W).

Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required.

Where prior notice is not practical and the circumstances warrant such action, the telephone company may temporarily disconnect service immediately. In case of such temporary discontinuance, the telephone company must:

- Promptly notify you of such temporary discontinuance
- Afford you the opportunity to correct the situation

- Inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

Interference Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference with one or more of the following measures:

- Reorient or relocate the receiving antenna (that is, the antenna for the radio or television that is "receiving" the interference).
- Reorient or relocate and increase the separation between the telecommunications equipment and the receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How to Identify and Resolve Radio/TV Interference Problems."

The FCC requires this product to be serviced only by Motorola or its authorized service agents.

CAUTION / WARNING: Changes or modifications not expressly approved by Motorola could void not only the user's authority to operate the equipment, but also the limited warranty.

Hearing Aid Compatibility

This telephone system meets the FCC standards for hearing aid compatibility.

Getting Started

Before you can use your new Motorola telephone to make or receive calls, you must charge the batteries.

Battery Safety Instructions


- Do not burn, disassemble, mutilate, or puncture the battery. The battery contains toxic materials that could be released, resulting in injury.
- **Caution:** There is a risk of explosion if you replace the battery with an incorrect battery type. Use only the battery that came with your phone or an authorized replacement recommended by the manufacturer.
- Keep batteries out of the reach of children.
- Remove batteries if storing over 30 days.
- Do not dispose of batteries in fire, which could result in explosion.
- The rechargeable batteries that power this product must be disposed of properly and may need to be recycled. Refer to your battery's label for battery type. Contact your local recycling center for proper disposal methods.




Charging the Battery

Your MA3160 series telephone comes with a Base Unit with Answering Machine and a Stand Alone Charger. Use the Charger to charge one of your two Handsets. See "Installation" on page 7 for step-by-step instructions on installing the Base Unit.

- 1 Press the indentation on the battery door and slide downwards to remove.




- 2 Insert the battery connector into the receptacle, then insert the battery (top edge first) into the battery compartment.




(**Note:** For the initial charge, please charge the battery for at least 15 hours.)

UNCONTROLLED
DOCUMENT


- 3 Replace the battery door.




- 4 Attach the Belt Clip. (optional)



- 5 Plug the power cord into the bottom of the Charger and into an electrical outlet.



- 6 Place the handset in the Charger.




- 7 Charge the battery for at least 15 hours before using for the first time. The glowing LED light indicates that the handset is charging.

Handset Display Overview

Use the at-a-glance image below to familiarize yourself with the MA3160 series handset's display. See "Personalizing Your Handset" on page 8 for step-by-step instructions on setting preferences.

Main Display Screen




Note: Caller ID information is supplied only if you subscribe to the service with your local telephone company.

Installation

Note: Install the Base Unit away from electronic equipment, such as computers, televisions, or microwave ovens. Avoid excessive heat, cold, dust, or moisture.

- 1 Select a location convenient to both an electrical outlet and a telephone jack.
- 2 Insert the telephone and power cords into the bottom of the Base Unit.
- 3 Place your second handset in the base unit to charge. **Do not plug the telephone cord into the wall jack until the Handset is fully charged (15 hours).**
- 4 Plug the telephone cord into the telephone wall jack.
- 5 Plug the power cord into the electrical outlet.



Setting Up

After your handsets are fully charged, you are ready to set your personal preferences.

Personalizing Your Handset

Personalize each handset by selecting distinguishing ring tones or you can extend the time between charges by turning off the ringer.

Selecting Ring Tones

With your handset off, select from the four different ring tones available. If you subscribe to Caller ID service, please see “Using Caller ID” starting on page 20 to set distinctive ring tones for programmed callers.

- 1 Press **PROGRAM**.
- 2 Scroll to **RINGER**.
- 3 Press **sel/transfer**. The current setting blinks and a sample of the ring plays.
- 4 Scroll through the list of ring tones to hear samples of each.
- 5 Press **sel/transfer** to choose your desired ring tone.

Selecting Language Preference

- 1 Press **PROGRAM**.
- 2 Scroll to **LANGUAGE**.
- 3 Scroll to your desired language (**ENGLISH**, **FRENCH**, **SPANISH**).
- 4 Press **sel/transfer**.

Setting Touch Tone or Pulse Dialing

Your telephone is preset for touch tone dialing. If your telephone dial service is pulse (rotary) only, you must change the settings.

- 1 Press **PROGRAM**.
- 2 Scroll to **DIAL MODE**.
- 3 Press **sel/transfer**. The current setting blinks.
- 4 Scroll to **PULSE** or **TONE**.
- 5 Press **sel/transfer** to save selection.

Note: You can temporarily change to tone dialing during a call by pressing ***tone** (asterisk/star key). All keys pressed afterward will send touch tone signals. Your telephone automatically returns to pulse dial after the call is disconnected.

Setting Date and Time

If you subscribe to Caller ID service through your telephone company, the date and time will set automatically with the first incoming call.


If you do not have Caller ID service, set the date and time manually for both handsets.

- 1 Press **PROGRAM** on the handset.
- 2 Scroll to **DATE/TIME**.
- 3 Press **sel/transfer**.
- 4 Scroll to the correct month.
- 5 Press **sel/transfer** to save selection.



Repeat the steps to select the correct day, hour, minute, and AM or PM settings.

Using the Handset


Making a Call

Press . When you hear the dial tone, dial the number.

OR

Enter the phone number, then press . You can see the phone number on the display before it is dialed. Use the **cid**  button to make corrections.

Answering/Ending a Call

You can answer an incoming call by pressing  or any number key (0-9) on the handset.

You can end a call by pressing  or any number key (0-9) on the handset.

OR

Place the handset on the Base Unit or Charger to end call.


Note: If you use DSL, please use the filtering devices provided by your DSL service company to prevent interference. If interference does occur, please contact your DSL service provider.

Locating a Misplaced Handset

Press **PAGE** on the Base Unit. The handsets beep.
(The page continues for approximately two minutes if unanswered or canceled.)

Press **PAGE** again to stop paging the handsets.

OR

Press  on any handset.


OR

Place the handset on the Base Unit or Charger to stop paging.

Using the Channel Key

For clearer reception, press the **CHANNEL** button to switch channels during a call.

Adjusting the Volume During a Call



Muting a Call

Press the **MUTE** button. Press the **MUTE** button again to unmute the call.

Forwarding a Call

Transfer a call at any time to the second handset by following the steps below.

- 1 Press **sol/transfer**. The display reads **TRANSFERRING CALL**. The second handset display reads **CALL TRANSFERRING**.
- 2 Press **sol/transfer** on the second handset to complete the transfer.

Note: If the second handset is not found or picked up within 30 seconds, there is an audible tone, and the call returns to the first handset.

The first handset rings for 30 seconds, and terminates the call automatically if it is not picked up.

Common Display Messages

** RINGING **	Incoming call.
CONNECTING...	Waiting for a dial tone.
PHONE ON	Handset is in use.
SCANNING...	Handset is changing to another of the 30 channels available.
** PAGING **	Base unit is paging the Hands.
BATTERY LOW	Battery needs to be recharged.


Storing Numbers in Memory

You can enter numbers directly into the phonebook, or add them from the Caller ID list.

Each handset has its own phonebook which holds up to 50 names and numbers. Nine of the 50 locations are dedicated for Speed Dial numbers.

Assigning Speed Dial Numbers

Number keys 1 through 9 are the memory locations for speed dial.

Note: Press  at any time to exit. If the memory location is full, the screen displays **MEMORY FULL**. You must delete a number before adding a new one.


- 1 Press **PROGRAM**.
- 2 Scroll to **SPEED DIAL**.
- 3 Press **sel/transfer**. The display reads **ENTER 1-9**.
- 4 Press the number key (1-9) you wish to assign to the telephone number. The display reads **ENTER NAME**.
- 5 Enter the name (up to 15 characters).

The chart below shows how many times to press each button on the handset to enter letters and special characters. Use the scroll keys to backspace to make corrections.

Button	Number of Presses				
	1	2	3	4	5
1	1				
2	A	B	C	2	
3	D	E	F	3	
4	G	H	I	4	
5	J	K	L	5	
6	M	N	O	6	
7	P	Q	R	S	7
8	T	U	V	8	
9	W	X	Y	Z	9

- 6 Press **Program** or **sel/transfer** to save the name. The display reads **Enter Number**.
- 7 Enter up to 24 digits for the telephone number. You can add a pause to the number by pressing **Redial**.
- 8 Press **Program** or **sel/transfer** to save the number. The display reads **Distinct Ring?**
- 9 Press **cid** or **dir** to select **Y** (Yes) or **N** (No). If you select **Y**, a distinctive ring tone sounds each time the programmed number calls, and a **D** is displayed with the Speed Dial entry. You must have Caller ID to use this feature.
- 10 Press **sel/transfer** to save the entry.

Dialing Speed Dial Numbers

- 1 Press and hold the location number (1-9).
- 2 Press  to dial the number.

Editing Speed Dial Numbers

- 1 Press and hold the memory location number (1-9) you wish to edit.
- 2 Press **sel/transfer** when the entry is displayed.
- 3 Scroll to **Edit**.
- 4 Press the **cid**▼ and ▲**dir** buttons to make edits to the name.
- 5 Press **sel/transfer**.
- 6 Press **cid**▼ to make edits to the number.
- 7 Press **sel/transfer**.

Reassigning Speed Dial Numbers

- 1 Press and hold the memory location number you wish to reassign.
- 2 Press **sel/transfer** when the entry is displayed.
- 3 Scroll to **Speed**.
- 4 Press **sel/transfer**.
- 5 Press new location number at prompt, **Enter 1-9**. A beep confirms the change.

Erasing Speed Dial Numbers



- 1 Press and hold the memory location number (1-9) you wish to delete.
- 2 Press **sel/transfer** when the entry is displayed.
- 3 Scroll to **ERASE**. The display reads **ERASE NO YES**.
- 4 Select **YES** to erase the entry.
- 5 Press **sel/transfer**.

Entering Numbers into Phonebooks

- 1 Press **PROGRAM**.
- 2 Scroll to **DIRECTORY**.
- 3 Press **sel/transfer**. The display reads **ENTER NAME**.
- 4 Enter the name (up to 15 characters).

Use the table below to enter letters and special characters. Use the scroll keys to backspace to make corrections.

Button	Number of Presses				
	1	2	3	4	5
1	1				
2	A	B	C	2	
3	D	E	F	3	
4	G	H	I	4	
5	J	K	L	5	
6	M	N	O	6	
7	P	Q	R	S	7
8	T	U	V	8	
9	W	X	Y	Z	9


- 5 Press **PROGRAM** or **sel/transfer** to save the entry. The display reads **ENTER NUMBER**.
- 6 Enter the phone number (up to 24 digits), or press **REDIAL** to enter the last number dialed. (Add a pause by pressing **REDIAL**.)
- 7 Press **PROGRAM** or **sel/transfer** to save entry. The display reads **DISTINCT RING?**
- 8 Press **cid**  or **dir**  to select **Y** (Yes) or **N** (No). If you select **Y**, a distinctive ring tone sounds each time the programmed number calls, and a D is displayed with the Speed Dial entry. You must have Caller ID to use this feature.
- 9 Press **sel/transfer** to save the entry.

Editing or Erasing a Programmed Number

- 1 Press **▲dir**.
- 2 Scroll to the desired entry using the **CIDv/▲dir** keys.
- 3 Press **sel/transfer**.
- 4 Scroll to **EDIT**, or **ERASE**.
- 5 Press **sel/transfer** to select option.
- 6 Select **EDIT** to make corrections, or scroll to **ERASE** and press **YES**.
- 7 Press **sel/transfer** to save changes.


Using Caller ID

Your Caller ID locations hold up to 90 calls. The most recent call is stored last on the list. When the location is full, the oldest call is deleted to add room for new calls.





Note: If you subscribe to caller ID service, but **INCOMING CALL** or **No Data** is displayed for all of your incoming calls, contact your telephone company.



Storing a Caller ID Entry in the Phonebook

- 1 Press **cid** .
- 2 Scroll to the desired entry.
- 3 Press **#** if you wish to change the dialing format (7, 10, or 11 digits) for the entry.
- 4 Scroll to **PROGRAM**.
- 5 Press **sel/transfer** three times.
- 6 Select **Y** or **N** for a distinctive ring. A “**D**” is displayed next to the entry.
- 7 Press **sel/transfer** to save the entry.

Dialing a Caller ID Listing

- 1 Press **cid** .
- 2 Scroll to the desired entry.
- 3 Press  **flash**.
- 4 Press **#** if you wish to change dialing sequence (7, 10, and 11-digits) for the entry.
- 5 Scroll to **DIAL**.

Reviewing Caller ID Lists

- 1 Press **cid** .
- 2 Scroll through the list of incoming calls.
- 3 Press  **cancel** to exit list.

Deleting a Specific Caller ID Listing

- 1 Press **cld**▼.
- 2 Scroll to the entry you want to delete.
- 3 Press **sel/transfer**. The display reads **ERASE ALL NO YES** and the phone number.
- 4 Scroll to **YES** to erase the entry.
- 5 Press **sel/transfer**. A long beep confirms the deletion.


Deleting All Caller ID Listings

- 1 Press and hold **DELETE**. The screen displays **ERASE ALL NO YES**.
- 2 Scroll to **YES**.
- 3 Press **sel/transfer**.

Using the Answering Machine

Your new answering machine has audio prompts that guide you through setting up and accessing the different features.

The answering machine has three mailboxes that can be assigned to different users, and stores up to 15 minutes of messages and/or memos.



Setting Up the Answering Machine

If you subscribe to Caller ID service with your telephone company, the date and time automatically sets with the first incoming call. (You must set the year manually.) If you do not subscribe to the service, set the time for the answering machine and handsets manually.

Setting the Date and Time

- 1 Press **TIME**. The system announces the current setting.
- 2 Press **TIME**.
- 3 Press **CHANGE** until you hear the correct setting.
- 4 Press **TIME** to save the change.
- 5 Repeat the steps to set the current day, hour, minute, and year.

Note: To advance the minutes or years by increments of 10, press and hold **CHANGE**. You can select up to the year 2039.

Setting Up Your Outgoing Message (OGM)

Mailboxes and Announcements

Your new answering system has three voice mailboxes that you can assign to different people. Callers with touch tone dialing can select from the boxes by pressing 1, 2, or 3. If a caller does not specify a mailbox, the message is automatically recorded in mailbox 1.

Announcement Options

You can record your own Outgoing Message (OGM) or use the prerecorded OGM. A second OGM option allows you to give an announcement without accepting

messages: "Thank you for calling, please try again later." You can record a personal announcement or use the prerecorded message.

Recording Outgoing Message (OGM)

- 1 Press **MENU** until you hear the prompt, "**CHANGE ANNOUNCEMENT.**"
- 2 Press **MEMO**. The system prompts, "**NOW RECORDING**" followed by a beep.
- 3 Facing the Base Unit, record your message. You have up to 90 seconds.
- 4 Press any mailbox button to stop recording. Your message plays back automatically.

If you assign different boxes, remember to include that information in your OGM. "Sorry we missed your call. To leave a message for Tucker, press 1; for Ben, press 2; for Denise, press 3."

Reviewing an OGM

- 1 Press **MENU** until you hear the prompt, "**CHANGE ANNOUNCEMENT.**"
- 2 Press any mailbox button. The current OGM plays.

Deleting an OGM

Press **DEL** during the playback. The system uses the prerecorded announcement until you record a new one.

Common Answering Machine Display Messages

0	No messages in any mailbox
1 – 99	Total number of messages in all mailboxes, or current message number during message playback
0 – 99 ↔ F	Memory is full, or total number of messages is 99.
Counting 1 to 99	Duration of memo recording
99 Flashing	Length of recording is more than 99 seconds.
1 – 8, steady for one second	Indicates volume level selected when VOL – or Vol + is pressed
40 – 99	Current Remote Access Code while setting
A	Announce Only mode
ON or OFF	Displays when system is turned on or off.
CL ↔ Normal Display	Clock must be set.
—	System is answering a call or is in remote operation.
—, Flashing	System is in programming mode or initializing.

Notes: Your system stores up to 99 messages (approximately 15 minutes of recorded messages, memos, and announcements) until you delete them.

- Incoming messages cannot exceed four minutes.
- Mailboxes with new messages flash and glow.
- Mailboxes with both old and new messages will play the new messages first. Press the mailbox number again to hear all messages.
- Prior to playing a message, the system announces the day and time it was received. The LED displays the message's number in the queue.

UNCONTROLLED
DOCUMENT

Setting the Answering Machine Features

- 1 Press **MENU** until the desired feature is announced.
- 2 Press **CHANGE** until the desired setting is announced.
- 3 Press **TIME** to save selection.
- 4 Press **MENU** to move to the next feature, or a mailbox button to exit.

AUDIO FEATURE PROMPTS	FEATURE DESCRIPTIONS
Change Remote Access Code	Allows remote access to system. Select any two-digit code from 40 to 99. Default code is 50. Press and hold CHANGE to advance by increments of 10.
Change Message Alert	Base Unit beeps every 10 seconds to announce new messages. Default setting is off.
Change Announce Only	Plays announcement, but does not take messages. Default setting is on.
Change Base Ringer	Turn ringer for Base Unit on or off. Default setting is on.
Change Number of Rings (2, 4, 6, Toll Saver)	Select number of rings allowed before system answers call. In Toll Saver mode, system answers after two rings when there is a new message, four when there are no messages. Default setting is four rings.

Accessing the Answering Machine Remotely

You can listen to your messages from anywhere using a touch tone telephone.

- 1 Enter your two digit remote access code during the OGM. The machine announces the number of messages.
- 2 Press the required key(s) to access the available commands.
 - Press # 1 to Play Mailbox 1
 - Press # 2 to Play Mailbox 2
 - Press # 3 to Play Mailbox 3
 - Press # 5 to Stop
 - Press # 4 to Repeat a message
 - Press # 4 # 4 to Repeat previous message
 - Press # 6 to Skip a message
 - Press # 7 to Review Announcement / OGM
 - Press * 7 to Record Announcement / OGM
 - Press * 8 and mailbox number to Record a voice memo
 - Press # 9 to Delete a message
 - Press # 0 to turn Machine on or off
 - Press * 0 to Exit
 - Press * 5 for Help list of commands

Note: If no key is pressed within 10 seconds of entering your remote access code, the voice menu announces available options. After the voice menu announcements, if no key is pressed within 20 seconds, the call automatically ends.

Motorola Limited Warranty

Motorola Limited Warranty

for Consumer Products, Accessories, and Software
Purchased in the United States or Canada

What Does this Warranty Cover?

Subject to the exclusions contained below, Motorola, Inc. warrants its cordless telephones ("Products"), Motorola-branded or certified accessories sold for use with these Products ("Accessories"), and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty:

Products and Accessories as defined above, unless otherwise provided for below. Length of coverage: one (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.

- **Decorative Accessories and Cases.** Decorative covers, bezels, PhoneWrap® covers and cases. Length of coverage: limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.
- **Products and Accessories that are Repaired or Replaced.** Length of coverage: The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer.
- **Software.** Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk). Length of coverage: ninety (90) days from the date of purchase.

Exclusions

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) Acts of God or nature, or other acts which are not the fault of Motorola, are excluded from coverage.

Use of Non-Motorola Products and Accessories.

Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered, or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products, Accessories or Software is excluded from coverage.

Software Embodied in Physical Media. No warranty is made that the software will meet your requirements or will work in combination with any hardware or software

applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

Software NOT Embodied in Physical Media. Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided "as is" and without warranty.

Who is Covered

This warranty extends to the first end-user purchaser, only.

What will Motorola Do?

Motorola, at its option, will at no charge repair, or replace any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

How to Get Warranty Service or Other Information

In the USA, call:

1-800-353-2729

TTY 1-888-390-6456

In Canada, call:

1-800-461-4575

TTY 1-888-390-6456

For accessories and software, please call the telephone number designated above for the product with which they are used. You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable), (e) your telephone number; and most importantly, your return mailing address on the outside of the returned unit.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, OR REPLACEMENT AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted.

UNCONTROLLED
DOCUMENT

UNCONTROLLED
DOCUMENT

Visit our website at:

www.motorola.com/cordless



MOTOROLA

519928-001

03/05

MGBI