


VFD-PU06 Digital Keypad Instruction Sheet

① Description of the Digital keypad VFD-PU06



② Explanation of Display Message

Display Message	Descriptions
F 6000	The AC motor drive Master Frequency Command.
H 5000	The Actual Operation Frequency present at terminals U, V, and W.
u 18000	The custom unit (u)
A 50	The output current present at terminals U, V, and W.
rEAd0	Press ▲ to change the mode to READ. Press PROG/DATA for about 2 sec or until it's flashing, read the parameters of AC drive to the digital keypad PU06. It can read 4 groups of parameters to PU06. (read 0 - read 3)
SAvE -	Press ▲ to change the mode to SAVE. Press PROG/DATA for about 2 sec or until it's flashing, then write the parameters from the digital keypad PU06 to AC drive. If it has saved, it will show the type of AC motor drive.
06-00	The specified parameter setting.
10	The actual value stored in the specified parameter.

Display Message	Descriptions
EF.	External Fault
-End-	"End" displays for approximately 1 second if the entered input data have been accepted. After a parameter value has been set, the new value is automatically stored in memory. To modify an entry, use the ▲ or ▼ keys.
-Err-	"Err" displays if the input is invalid.
CE-10	Communication Error. Please check the AC motor drive user manual (Chapter 5, Group 9 Communication Parameter) for more details.

③ Operation Flow Chart

