
Lavavajillas Dishwasher Máquina de lavar loiça



Model ESF 4120

- Manual de instrucciones
- GB Instruction book
- Instruções de utilização

Electrolux

Contents

Important safety information	17
Hints and tips	17
Description of the appliance	18
The control panel	18
Before use Setting the water softener Filling with salt Rinse aid Use of detergent	19 19 20 20 21
Using your appliance Loading your appliance Adjusting the height of the upper basket Use of detergent	22 22 22 35
Washing programmes	23
Operating sequence	24
Maintenance and cleaning Internal cleaning Cleaning the filters External cleaning	25 25 25 25
Something not working Service and spare parts Protection against flooding	26 27 27
Hints for test centres	27
Installation instructions Water supply connections Water outlet hose connection Electrical connection Fitting under a counter Levelling	28 28 28 28 29 29

Technical specifications

Dimensions	Width Height with worktop Height without worktop Max depth Max depth with open door	45 cm 85 cm 82 cm 63 cm 115.9 cm
Electrical connection Motor rating during wash Power of heating element Overall power	Voltage	230 V - 60 Hz 200 W 2100 W 2300 W
Water supply pressure	Minimum Maximum	50 kPa (0.5 bar) 800 kPa (8 bar)
Capacity		9 place settings



- This appliance complies with the following E.E.C. Directives:
 73/23 of 19.2.73 (Low Voltage Directive) and subsequent modifications;
 89/336 of 3.5.89 (Electromagnetic Compatibility Directive) and subsequent modifications.

Important safety information

It is most important that this instruction book should be retained with the appliance for future reference. Should the appliance be sold or transferred to another owner, or should you move house and leave the appliance, always ensure that the book is left with the appliance in order that the new owner can get to know the functioning of the appliance and the relevant safety information.

This information has been provided in the interest of your safety. You MUST read it carefully before installing or using the appliance.

Installation

- This appliance is heavy. Care should be taken when moving it.
- It is dangerous to alter the specifications or attempt to modify this product in any way.
- Care must be taken to ensure that the appliance does not stand on the electrical supply cable.
- Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.
- Any plumbing work required to install this appliance should be carried out by a qualified plumber or competent person.

Child Safety

- This appliance is designed to be operated by adults.
 Children should not be allowed to tamper with the controls or play with the product.
- Keep all packaging well away from children.
- Keep all detergents in a safe place out of children's reach.

During Use

- Items that are contaminated by petrol, paint, steel or iron debris, corrosive, acidic or alkaline chemicals must not be washed in this dishwasher.
- Under no circumstances should you open the door whilst the appliance is in operation. Always turn off the appliance before opening the door.
- Only use detergent specifically designed for use in dishwashers.
- Long bladed knives stored in an upright position are a potential hazard.

- Long and/or sharp items of cutlery such as carving knives must be positioned horizontally in the upper basket.
- When finishing loading or unloading close the door, as an open door can be a hazard.
- Do not sit or stand on the open door.
- Isolate the appliance from the power supply and turn off the water supply after use.
- Care should be taken when cleaning the bottom door seal and hinge area as any exposed metal edges may cut if care is not taken.
- This product should be serviced by an authorised Service engineer, and only genuine spare parts should be used.
- Under no circumstances should you attempt to repair the machine yourself. Repairs carried out by inexperienced persons may cause injury or serious malfunctioning. Contact your local Service Force Centre. Always insist on genuine spare parts.

Conservation

brass tend to stain.

In the interest of the environment:

- Materials marked with the symbol △ are recyclable.
- Check with your local Council or Environmental Health Office to see if there are facilities in your area for re-cycling this appliance.
- When the appliance is to be scrapped, cut off the power supply cable and make the door closing device unusable to prevent young children from being trapped inside.
- Help to keep your country tidy use authorised disposal sites for your old appliance.

Hints and tips

To save energy

Place dishes in the machine immediately after every meal and wait until the dishwasher is full before washing.

Do not prewash dishes under running water.

For best washing results

Before loading, remove all scraps of food and soak very heavily soiled pots and pans.

Arrange saucepans, cups and glasses etc. upside-down. Tilt items with convex or concave surfaces so that the water drains off easily.

Avoid contact between the dishes as far as possible.

Items not suitable for dishwashers

The following items should not be washed in the dishwasher (unless they are sold as dishwasher proof):

- Cutlery with wooden or horn handles or glued parts
- bronze cutlery
- saucepans with wooden handles
- aluminium ware
- crystal ware
- leaded glass
- plastic items
- antique or fine decorated china

Certain types of decoration can discolour when washed in a dishwasher.

Crystal-ware and plastic objects, if not guaranteed dishwasher proof should be washed by hand.


Certain types of glass can also become opaque after being washed several times in a dishwasher.

A chemical reaction can occur between silver cutlery and stainless steel cutlery. As a precaution, do not wash together. Iron and cast iron objects can rust and stain other items. Aluminium tends to go black, copper, pewter and


If in doubt check with manufacturer of the item. When buying new dishes, ensure that they are dishwasher proof.

Description of the appliance

- 1. Levelling spacers
- 2. Upper basket stop
- 3. Upper spray arm
- 4. Salt container
- 5. Detergent dispenser
- 6. Control panel
- 7. Rinse aid dispenser
- 8. Filters
- 9. Lower spray arm
- 10. Upper basket
- 11. Worktop



The control panel



1. Programme selection push buttons

2. Delay start push button

This option allows the start of the programme to be delayed by 3, 6 or 9 hours.

3. Indicator lights

Phase indicator lights

- washing phase illuminates when the washing phase is running
- drying phase illuminates when the drying phase is running
- end of programme illuminates when the washing programme has ended

Salt and rinse aid indicator lights

- salt refilling indicator light illuminates when the salt has run out and the salt container requires refilling.
- rinse aid refilling indicator light illuminates when the rinse aid has run out and the rinse aid container requires refilling.
- 4. Door handle
- 5. On/Off indicator light
- 6. On/Off push button

Before use

Before using your dishwasher for the first time:

- Ensure that the electrical and water connections comply with the installation instructions
- 2. Remove all packaging from inside the appliance
- 3. Set the water softener
- Pour 1 litre of water inside the salt container and then fill with salt
- 5. Fill the rinse aid dispenser.

Setting the water softener

The dishwasher is equipped with a water softener designed to remove minerals and salts from the water supply, which would have a detrimental or adverse effect on the operation of the appliance.

The higher the content of these salts, the harder your water is. Water hardness is measured in equivalent scales, German degrees, French degrees and PPM (parts per Million).

The softener should be adjusted according to the hardness of the water in your area. Your local Water Authority can advise you on the hardness of the water in your area.

	1			
Level	German degrees (°dH)	French degrees (°TH)	PPM (Parts per Million)	Use of salt
1	< 4	< 8	< 80	NO
2	4 - 18	8 - 30	81 - 300	YES
3	19 - 29	31 - 50	301 - 500	YES
4	30 - 40	51 - 70	501 - 700	YES
5	41 - 50	71 - 90	701 - 900	YES

The dishwasher is factory set at level 3.

If this level is not suitable for your area the softener should be adjusted.


If your water is level 1 it is already soft and therefore there is no need to use salt.

With the setting of the water softener at level 1 the salt indicator light on the control panel will always remain off. Use salt from level 2 upwards.


To select a different level be sure that the dishwasher is off and then proceed as follows:

- Press Intensive 70° 80' and Normal 65° programme push buttons simultaneously.
- While keeping the programme push buttons Intensive 70° 80' and Normal 65° pressed switch on the dishwasher by pressing the On/Off push button.

The On/Off indicator light comes on. At the same time, the indicator lights of the **Intensive 70° 80'** and **Normal 65°** push buttons start flashing.



3. Press the Intensive 70° 80' push button, the indicator light of the Normal 65° push button turns off, while the indicator light of the Intensive 70° 80' push button remains fixed for about 5 seconds and then starts to flash indicating the current level



The current level is indicated by the number of flashes made by the **Intensive 70° 80'** indicator light, that alternates 5 seconds off with a number of flashes, this continues for about 60 seconds.

Example:

1 flash = level 1 2 flashes = level 2 3 flashes = level 3

4 flashes = level 4 5 flashes = level 5

4. To change the level, press the Intensive 70° 80' programme push button. Each time the push button is pressed the level changes.

Example:

If the current level is 3, by pressing the **Intensive 70° 80'** programme push button once, level 4 is selected. If the current level is 5, by pressing the **Intensive 70° 80'** programme push button once, level 1 is selected.

The **Intensive 70° 80'** indicator light remains off for about 5 seconds after which it starts flashing indicating the new level selected.

5. To memorise the new level, switch off the dishwasher by pressing the **On/Off** push button.

Filling with salt

Only use salt specifically designed for use in dishwashers.

All other types of salt not specifically designed for use in a dishwasher, especially table salt, will damage the water softener.

Only fill with salt just before starting one of the complete washing programmes.

This will prevent any grains of salt or salty water, which may have been spilled, remaining on the bottom of the machine for any period of time, which may cause corrosion.

To fill:

- 1. To fill with salt, unscrew the cap of the salt container.
- Pour 1 litre of water inside the container (this is necessary only before filling with salt for the first time).
- Using the funnel provided, pour in the salt until the container is full.
 Do not worry if water over flows from the unit when filling with salt, this is quite normal.
- SROG
- Replace the cap making sure that there is no trace of salt on the screw thread or on the gasket.
- 5. Screw on the cap tightly.

The salt container will require topping up periodically.

You are reminded of this by the salt indicator light on the control panel which comes on when the salt has finished.

The salt indicator light on the control panel can remain illuminated for 2-6 hours after the salt has been replenished, assuming the dishwasher remains switched on. If you are using salts that take longer to dissolve then this can take longer. The function of the machine is not affected.


From level 2 upwards, if salt refilling is necessary, the salt indicator light will illuminate only in setting mode and at the end of the washing programme. During the run of the programme it will remain off.


Rinse aid

Rinse aid is automatically added during the last rinse, ensuring thorough rinsing, and spot and streak free drying. The dispenser, which is positioned inside the door, holds about 110 ml of rinse aid, which is sufficient for 16 - 40 dishwashing programmes, depending upon the dosage setting.

Filling with rinse aid

- 1. Open the container by turning the lid (A) anticlockwise.
- Add the rinse aid until the container is completely full. The indicator (B) will be completely dark.
- **3.** Top up the rinse aid when the rinse aid indicator light on the control panel illuminates.





If rinse aid refilling is necessary, the rinse aid indicator light will illuminate only in setting mode and at the end of the washing programme.

During the run of the programme it will remain off.

Ensure that the lid is closed after every refill.

Do not put liquid detergent in the rinse aid compartment. Clean up any rinse aid spilt during filling with an absorbent cloth to avoid excess foaming during the next wash.


It is possible to deactivate the rinse aid indicator light (see the following instructions), By default the rinse aid indicator light is active.

To deactivate the rinse aid indicator light be sure that the dishwasher is off and then proceed as follows:

- Press Intensive 70° 80' and Normal 65° programme push buttons simultaneously.
- While keeping the programme push buttons Intensive 70° 80' and Normal 65° pressed switch on the dishwasher by pressing the On/Off push button.


The On/Off indicator light comes on.

At the same time, the indicator lights of the **Intensive 70° 80'** and **Normal 65°** push buttons start flashing.



3. Press the Normal 65° push button, the correspondent indicator light keeps flashing while the indicator light of the Intensive 70° 80' push button turns off.

At the same time the indicator light "end of programme" starts to flash.



- **4.** Press the **Normal 65°** push button again, the **"end of programme"** indicator light turns off, this means that the rinse aid indicator light has been deactivated.
- **5.** To memorise the operation, switch off the dishwasher by pressing the On/Off push button.


To reactivate the rinse aid indicator light follow the same process until the "end of programme" indicator light starts to flash

Adjusting the dose

According to the finish and drying results obtained, adjust the dose of rinse aid by means of the 6 position selector (C) (position 1 minimum dosage, position 6 maximum dosage).

Increase the dose if there are drops of water or lime spots on the dishes after washing.

Reduce it if there are sticky whitish streaks on the dishes.



Use of detergent


Only use detergents specifically designed for use in dishwashers.


If using powder detergents proceed as follows:

- 1. Open the dispenser lid by pulling the catch (D).
- Add the detergent according to the instructions given in the Washing programmes chart.As all detergents are not the same, you should also consult

the instructions on the packet.

- 3. Always close the lid.
- 4. If the programme has a prewash add a little amount of detergent over the lid of the dispenser. Follow the recommended quantity of detergent given in the Washing programmes chart.





If using detergent in tablets proceed as follows:

- For all programmes; place 1 tablet inside the detergent dispenser.
- 2. Always close the lid.
- **3.** For all programmes with prewash; place a portion of a further tablet on the lid of the detergent dispenser.

Insufficient quantities of detergent will produce poor washing results, whereas an excessive amount of detergent will not improve washing results and is also wasteful.

Using no more than the correct amount also contributes to reducing pollution.

Compact detergents with enzymes

In these compact powders the environmentally unfriendly components have been replaced by natural enzymes and other more biodegradable substances.

The enzymes deploy their full dirt dissolving power at a temperature as low as 50°C.

By choosing the BIO programmes you can therefore achieve the same cleaning results that would otherwise be achievable only with 65°C programmes and conventional detergents.

Using your appliance

Loading your appliance

Before placing dishes in the machine, remove any scraps of food, to avoid clogging the filters and consequently reducing the performance.


Do not load very small items which can fall through the baskets.


Open the door and slide out the baskets to load the dishes.

The lower basket

The lower basket is designed to take saucepans, lids, plates, salad bowls, cutlery etc.

Serving dishes and large lids should be arranged around the edge of the basket, ensuring that the upper spray arm can turn freely.







The two rear rows of prongs on the lower basket can be easily lowered to allow you to load pots, pans and bowls.

To lower the prongs:

- Slightly pull them upward and let them drop down (see picture).
- To bring them back to the standing position, just pull them up again.





The cutlery basket

Long bladed knives stored in an upright position are a potential hazard.

Long and/or sharp items of cutlery such as carving knives must be positioned horizontally in the upper basket. Take care when loading or unloading sharp items such as

knives.Cutlery should be placed in the removable cutlery basket with


the handles facing downwards.

If the handles protrude from the bottom of the basket, obstructing the lower spray arm, load the cutlery with the handles facing upwards.

Mix spoons with other cutlery to prevent them from sticking together.

Silver cutlery tends to go black if mixed with steel cutlery. Place it in the cutlery basket separate from the others.

Arrange spoons, dessert spoon, knives and other small items of cutlery in the racks on both sides of the cutlery basket.



The upper basket


The upper basket is designed for plates (dessert plates, saucers, dinner plates of up to 24 cm in diameter), salad bowls, cups and glasses.

Arrange items so that water can reach all surfaces.

Glasses with long stems can be placed upside down in the cup racks.

The cup rack on the left folds upwards to increase your loading flexibility.

Light items (plastic bowls etc.) should be loaded in the upper basket and arranged so they do not move.




Before closing the door, ensure that the spray arms can rotate freely.

Adjusting the height of the upper basket

If washing very large plates (over 27 cm and up to 31 cm in diameter) you can load them in the lower basket after moving the upper basket to the higher position.

To move to the higher position proceed as follows:

- Move the front runnner stops (A) of the upper basket outwards and slide the basket out.
- 2. Refit the basket in the higher position and replace the stops (A) in their original position.



When the top basket is in the higher position it will only take plates up to 20 cm in diameter and you will not be able to use

the cup racks.

After loading your machine always close the door, as an open door can be a hazard.

Washing programmes

Programme	Type of load and	•	Recommended quantity of detergent		Cycle description
degree of soil	degree of soil		wash	prewash	
* Intensive 70° 80'	Heavy soil. Crockery, cutlery, pots and pans	On/Off + O 70° 80'	15 g	10 g	Hot prewash Main wash up to 70°C 1 cold rinse 1 hot rinse Active dry
Normal 65°	Normal soil. Crockery and cutlery	On/Off + <u>\$</u> 65°	15 g	10 g	Warm prewash Main wash up to 65°C 1 cold rinse 1 hot rinse Active dry
** Quick 65°	Fresh soil. Crockery and cutlery	On/Off + \$\frac{2}{5}\$ 65°	20 g	/	Main wash up to 65°C 1 hot rinse
*** BIO 50°	Normal soil. Crockery and cutlery	On/Off +	20 g	5 g	Cold prewash Main wash up to 50°C 1 cold rinse 1 hot rinse Active dry

- * Ideal for washing a complete load of **9 place settings with normal soil**. Characterised by a duration of about 80 minutes and a washing temperature of 70°C.
 - The time value is approximate and depends on the pressure and the temperature of the water and also by the variations of the power supply.
- ** Ideal for washing crockery and cutlery of breakfast and dinner (**fresh soil**). Characterised by a duration of about 30 minutes and a washing temperature of 65°C.
 - The time value is approximate and depends on the pressure and the temperature of the water and also by the variations of the power supply.
 - This is the perfect daily programme, made to meet the needs of a family of **4 persons** who only wish to load breakfast and dinner crockery and cutlery.
- *** Testing programme for EN 50242 (see "Hints for Test Centres). This programme, developed for the use of detergents with enzymes, allows to achieve, with reduced consumptions of energy the same cleaning results that would otherwise be obtained only with the 65°C programmes and conventional detergents. To compensate the lower temperature, the duration of the programme has been prolonged.

The products

In order to obtain a good wash, it is necessary to use detergents specially designed for dishwashers.

To ensure that your dishwasher functions perfectly, Zanussi recommends using Calgonit System, a unique and complete product, tested by millions of householders.

Calgonit System includes Calgonit detergent, rinse aid, salt, machine detergent and Citro-Fresh.

It is able to fulfil the main requirements for clearing both the crockery and the machine itself.



Operating sequence

1. Check the filters

Ensure they are clean and properly positioned (see "Maintenance and cleaning").

2. Press the On/Off push button

The On/Off indicator light will come on.

3. Check that there is rinse aid and salt

The corresponding indicator lights will illuminate if refilling is necessary.

4. Load the dishes

Remove any scraps of food.

Pull the lower basket out and arrange the saucepans, plates and cutlery in it.

Pull the upper basket out and arrange the plates, saucers, glasses and cups etc. in it.

Slide the baskets back into the machine.

5. Ensure that the spray arms can rotate freely.

Measure out detergent

Add the required amount of detergent into the dispenser according to the recommended quantity given in the Washing programmes chart.

Close the detergent dispenser lid.

7. Close the dishwasher door

8a. Setting and starting the programme without delay start

Press the push button corresponding to the wanted programme: the indicator light corresponding to the programme illuminates and the phase indicator lights foreseen for that programme start flashing.

The start of the programme will occur after about 6 seconds from the last pressure of a programme push button, in this time it is possible to change programme simply pressing the push button of another programme. Once the programme has started the phase indicator lights will turn off except for the phase under way.

It is possible to interrupt the programme:

- · opening the door
- pressing the On/Off (in this case all the indicator lights turn off)

Close the door again o press the On/Off, the programme will start from the point in which it was interrupted.

8b. Setting and starting the programme with delay start

The setting of the delay start occurs before selecting the programme.

Press the delay start push button and selected the desired time (3, 6 or 9 hours) until the indicator light corresponding to the chosen hours flashes.

Press the push button corresponding to the required programme: the indicator light corresponding to the programme illuminates and the phase indicator lights for that programme start flashing.

The start of the countdown will occur after about 6 seconds from the last pressure of a programme push button.

The countdown will decrease with step of 3 hours and you are informed of this by the indicator lights of the hours

During the countdown the only indicator lights illuminated are the programme light and the light of the number of hours to the start of the programme.

Once the delayed time has elapsed the programme will start automatically.

It is possible to stop a countdown in progress or before it starts, simply pressing the delay start push button until the indicator lights of the hours are off.

9. To cancel a programme in progress

A programme in progress can be cancelled at any time. Press for about 3 seconds the push button of the running programme until all indicator lights are off. Only the On/Off indicator light will remain on once the programme has been cancelled.

It is now possible to select a new washing programme.

10. At the end of the washing programme

The dishwasher will automatically stop and the phase indicator light **end of programme** will come on.

The indicator light of the programme just ended will remain on.

The dishwasher has finished the programme only when the phase indicator light **end of programme** is illuminated.

If you do not wait for the end of the programme it will not be possible to start a new programme if first you do not cancel the previous. (For the formalities how to cancel a programme see point 9).

If during the drying phase (drying indicator light illuminated) the dishwasher door is opened or the On/Off push button is pressed, the running programme is automatically cancelled.

In this case the machine returns to setting mode and it is possible to select a new washing programme without cancelling the previous.

Switch off the dishwasher by pressing the On/Off push button and open the door.

Wait a few minutes before removing the dishes; in this way they will be cooler.

Empty the lower basket first and then the upper one; this will avoid water dripping from the upper basket onto the dishes in the lower one.

Important!

In general it is not advisable to open the door while the machine is working; if the door is opened however, a safety device ensures that the machine stops. Care must be taken if the door is opened during the hot phase or immediately after a programme has finished, as steam may escape.

When the washing programme has finished, it is recommended that the dishwasher is unplugged and the water tap turned off.

Maintenance and cleaning


Internal cleaning


Ensure that the seals around the door, the detergent and rinse aid dispensers are cleaned regularly with a damp cloth. We recommend every 3 months to run a 65°C wash programme without dishes using detergent.

Cleaning the filters


The filters in the base of the washing compartment are to large extent self-cleaning. Nevertheless the filters should be checked and cleaned from time to time. Dirty filters will degrade the washing result.

- 1. Open the door, remove the lower basket.
- The dishwasher filter system comprises a coarse/fine filter, microfilter and a flat filter. Unlock the filter system using a handle on the microfilter, and remove.
- 3. Turn the handle about 1/4 a turn anticlockwise and remove.
- **4.** Take hold of the coarse/fine filter (1/2) by the handle with the hole and remove from the microfilter (3).
- 5. Clean all filters thoroughly under running water.





Remove the flat filter (4) from the base of the washing compartment and clean both faces thoroughly.



- Put the flat filter back in the base of the washing compartment.
- **8.** Place the coarse/fine filter in the microfilter and press together.
- Put the filter combination in place and lock by turning the handle clockwise to the stop. During this process ensure that the flat filter does not protrude above the base of the washing compartment.

The dishwasher must not be used without filters. Incorrect repositioning and fitting of the filters will produce poor washing results.

Cleaning the filters is vital to ensure correct operation of the machine.

External cleaning

Clean the external surfaces of the machine and control panel with a damp soft cloth. If necessary use only neutral detergents. Never use abrasive products, scouring pads or solvent (acetone, trichloroethylene etc....).

Prolonged periods of non-operation

If you are not using the machine for any period of time you are advised to:

- 1. Unplug the appliance and then turn off the water.
- 2. Fill the rinse aid dispenser.
- 3. Leave the door ajar to prevent the formation of any unpleasant smells.
- 4. Leave the inside of the machine clean.

Frost precautions

Avoid placing the machine in a location where the temperature is below 0°C. If this is unavoidable, empty the machine, close the appliance door, disconnect the water inlet pipe and empty it.

Moving the machine

If you have to move the machine (moving house etc....):

- 1. Unplug it.
- 2. Turn the water tap off.
- 3. Remove the water inlet and discharge hoses.
- **4.** Pull the machine out together with the hoses.

Avoid over tilting the machine during transportation.

Something not working

Certain problems are due to lack of simple maintenance or oversights, which can be solved easily without calling out an engineer. The dishwasher is fitted with a number of alarm systems which can help you to quickly determine the cause of any problems. The dishwasher will not start or stops during operation. All push buttons are inoperative except for the On/Off push button. The indicator light of the programme under and one or more of the phase indicator lights (washing, drying, end of programme) are flashing.

Press the On/Off push button to switch off the dishwasher and carry out the following suggested corrective actions listed below.

Symptom	Fault code	Solution
The machine will not start		 The door has not been properly closed. The plug is not properly inserted in the power socket. There is a power failure.
The machine does not fill with water	washing phase indicator light flashing	 Ensure the water tap is open. Ensure the mains water supply has not been cut off. The inlet hose may be squashed or bent. Reposition the hose. The inlet hose may be blocked. Switch off the water supply and clean the filter.
The dishwasher will not drain	drying phase indicator light flashes	 The drain hose may be squashed or bent. Reposition the hose. The sink may be blocked. Clear any blockages. The drain hose extension is not correct. Follow the instructions for connecting to the waste. There is no vent in the end of the drain hose.
Protection against flooding is active	washing and drying phase indicator lights are flashing	Close the water tap and contact the Service Force Centre.
General	One or more phase indicator lights are flashing	Switch off the dishwasher. Switch it back on and start the programme. If the alarm reappears, call the local Service Force Centre.
The machine is noisy		 Dishes are rattling against each other, refer to "Loading your machine". The spray arms are knocking against the dishes. Refer to "Loading your machine".
The door is difficult to close		The dishwasher is not level, or not properly built-in.
Visible lime deposits or white film on the dishes		 Check that there is salt and that the salt cap is tight. Check that the right level of the water softener is set.
The dishes are not quite dry		The rinse aid has run out or too little is being used.
The dishes are not clean (poor wash)		 The baskets are too full. The dishes have not been arranged properly. The spray arms do not rotate The spray arms are clogged. The filters are clogged. The filters are not in the correct position. Not enough detergent has been used or it is unsuitable. The detergent is old or has gone hard. The salt container cap is not properly closed. The washing programme selected is too gentle.

Once the checks have been carried out switch on the dishwasher and start a washing programme, if the fault code reappears contact your local Service Force Centre.

If after all these checks, the problem persists, contact your local Service Force Centre, quoting the model and serial number.

This information can be found on the rating plate located on the right hand side of the dishwasher door (see picture).



Protection against flooding

In order to prevent water floods, the machine has been provided with a device in the bottom of the machine.

The device will operate if there are any water leaks in the machine, however it will only operate if the machine is on.

In case of malfunction, the **washing** and **drying** phase indicator lights start **flashing**.

To repair the dishwasher, turn off the water tap and call the Service Force Centre.

Service and spare parts

This product should be serviced by an authorised Service engineer, and only genuine spare parts should be used. Under no circumstances should you attempt to repair the machine yourself.


Repairs carried out by inexperienced persons may cause injury or serious malfunctioning. Contact your local Service Force Centre.

Always insist on genuine spare parts.

Hints for test centres

Before starting any test it is necessary to fill completely with salt the salt container and with rinse aid the rinse aid dispenser.


Test standard	EN 50242
Reference programme:	BIO 50°
Load:	9 standard place settings
Rinse aid selector:	position 4
Detergent dosage :	20 g in the dispenser 5 g on the dispenser lid



Arrangement upper basket



Arrangement cutlery basket



Arrangement lower basket

Installation instructions

Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.

Any plumbing work required to install this appliance should be carried out by a qualified plumber or competent person.

Remove all packaging before positioning the machine. If possible, position the machine next to a water tap and a drain.

Water supply connections

This dishwasher may be fed with either hot (max. 60°) or cold water. Nevertheless we advise you a cold water supply. A hot water supply is not always efficient with very soiled crockery as it shortens the washing programmes a lot. The water pressure must be within the limits given in the technical specifications.

Your local Water Authority will advise you on the average mains pressure in your area.

The dishwasher features fill and drain hoses which can be turned either to the left or the right to suit the installation. The locknut must be correctly fitted to avoid water leaks.


Do not use, for connection, old hoses which have been used in another appliance.

Avoid bends or kinks in the hose which could prevent or slow down the water supply.

If the machine is connected to new pipes or pipes which have not been used for a long time, you should run the water for a few minutes before connecting the inlet hose. This will prevent deposits of sand or rust clogging the inlet hose filter.

For making the connection itself, the coupling nut fitted to the machine's supply hose is designed to screw onto either a 3/4 inch gas thread spout, or to a purpose made quick-coupling tap such as the Press-block.


Be sure to incorporate the filter (A) supplied with the machine onto the joint.



Water outlet hose connection

The end of the drain hose can be connected in the following ways:

- 1. To the sink outlet spigot, securing it if necessary with a clip.
- 2. Hooked over the edge of the sink using the special curved plastic guide provided.
- **3.** To a stand pipe provided with vent-hole, minimum internal diameter 4 cm.




The waste connection must be at a height of between 30 cm (minimum) and 100 cm (maximum) from the bottom of the dishwasher.

The drain hose can face either to the right or left of the dishwasher

Ensure the hose is not bent or squashed as this could prevent or slow down the discharge of water.

If you use a drain hose extension it must be no longer than 2 metres and its internal diameter must be no smaller than the diameter of the hose provided.

Likewise the internal diameter of the couplings used for connections to the waste outlet must be no smaller than the diameter of the hose provided.



The sink plug must not be in place when the machine is draining as this could cause the water to siphon back into the machine.

Attention!

Our appliances are supplied with a security device to protect against the return of dirty water back into the machine.

If the spigot of your sink has a "no return valve" incorporated this can prevent the correct draining of your dishwasher.

We advise you therefore to remove it.

Electrical connection

Before plugging the appliance into the wall socket, make sure that:

- **1.** The mains voltage corresponds to the voltage given in the "Technical specifications".
- 2. The meter, fuses, mains power supply and wall socket can all take the maximum load required.

Make sure that the socket and plug are compatible without having to use any type of adaptor. If necessary, have the domestic wiring system socket replaced.


Safety standards require the appliance to be earthed.

The manufacture accepts no liability for failure to observe the above safety precautions.

Fitting under a counter

(kitchen worktop or sink)

By removing the machine's worktop, you can install it under a close fitting sink unit or a pre-existing top, providing the dimensions of the recess correspond to those shown in the picture.



Proceed as follows:

 Remove the machine's worktop by unscrewing the two front retaining screws, pull from the front and slide out the rear slots, lifting the worktop.

Insert the machine after adjusting height and levelling with the adjustable feet. When inserting the machine, ensure that the water inlet and drain hoses are not kinked or squashed.

Levelling

Good levelling is essential for correct closure and sealing of the door.

When the appliance is correctly levelled, the door will not catch on the levelling spacers on either side of the cabinet.

If the door does not close correctly, loosen or tighten the adjustable feet until the machine is perfectly level.

The Electrolux Group. The world's No.1 choice.

The Electrolux Group is the world's largest producer of powered appliances for kitchen, cleaning and outdoor use. More than 55 million Electrolux Group products (such as refrigerators, cookers, vacuum cleaners, chain saws and lawn mowers) are sold each year to a value of approx. 14 billion USD in more than 150 countries around the world.



152976 94/1 **1** 01/02