

VBP620

**PORTABLE 6.2" LCD MONITOR AND DVD PLAYER
IN A BAG**



Notice:

This Product incorporates copyright protection technology that is protected by method claims of certain U.S. Patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

An LCD panel and/or video monitor may be installed in a motor vehicle and visible to the driver if the LCD panel or video monitor is used for vehicle information, system control, rear or side observation or navigation. If the LCD panel or video monitor is used for television reception, video or DVD play, the LCD panel or video monitor must be installed so that these features will only function when the vehicle is in park! or when the vehicle's parking brake is applied.

An LCD panel or video monitor used for television reception, video or DVD play that operates when the vehicle is in gear or when the parking brake is not applied must be installed to the rear of the driver's seat where it will not be visible, directly or indirectly, to the operator of the motor vehicle.

A. Introduction

Thank you for selecting the VBP620 portable DVD player in a bag. The main features include a 6.2" Screen (16:9 Aspect Ratio) Liquid Crystal Display (LCD) monitor and a DVD player. The unit applies the latest state of the art electronics and is designed for use in hotels, offices home or vehicle. The unit is constructed to provide years of reliable, trouble-free service, and is compact so that you can take it with you anywhere and is designed for quick and easy installation. Please read the entire instruction manual supplied with this product prior to operation. The documentation will assist you in installing the system properly to obtain the best equipment performance. All manuals should be stored for later use.

B. Cautions and Warnings

1. Placement

To prevent fire or electric shock, do not expose this appliance to rain or moisture. Do not place the set on an unstable cart, stand, tripod, bracket or table to prevent it from falling. Keep the unit away from strong magnets, heat sources, direct sunlight, excessive dust. If the unit is brought directly from a cold to a warm location, moisture may condense inside the unit. When you move it from a cold to a warm location, wait for about one hour before operating the unit, or remove the disc and leave the unit turned on until the moisture evaporates.

2. Installation

Ensure that the VBP620 is installed in accordance with the instructions and illustrations provided in this manual.

3. Object and Liquid

Do not push objects of any kind into the unit through openings; do not spill or spray liquid of any kind on or in the system (this may result in a fire or electric shock). Do not place anything heavy on the unit. To ensure proper ventilation and proper operation, never cover or block the slots and openings with a cloth or other material.

4. Disassembly

Do not attempt to disassemble the cabinet. There is a risk of electric shock and/or exposure to Laser Radiation. Contact qualified service personnel if your system is in need of repair.

5. Cleaning Unit

When cleaning, make sure the system is unplugged from the power source. Do not use liquid cleaners or aerosol cleaners. Use a cloth lightly dampened with water for cleaning the exterior of the system only.

6. Disc

Do not use irregularly shaped discs such as heart or star-shaped discs as they may cause the unit to malfunction. Do not stick paper, tape or glue on the disc. Do not expose the disc to direct sunlight or heat sources such as hot air ducts. Do not touch the surface of disc. Handle the disc by its edge. Clean the disc by wiping the disc from the center out with a cleaning cloth. Remove the disc from the unit and store it in its case after playing. Some playback operations of discs may be intentionally fixed by software producers. Since this unit plays discs according to the disc contents the software producers designed, some playback features may not be available. Also refer to the instructions supplied with the discs.

C. Contents

1. 1 x 6.2" LCD Monitor & DVD Player Combination
2. 1 x AC to DC Adapter
3. 1 x Remote Control w/Battery (CR2025)
4. 1 x Instruction Manual
5. 1 x Power Adapter w/Built-In FM Modulator
6. 1 x Mounting Bag w/Straps
7. 1 x Carrying bag
8. 1 x Rechargeable Battery Pack (Part Number RB05)
9. 1 x Audio/Video Input Cable
10. 1 x Audio/ Video Output Cable

OPTIONAL:

Wireless IR headphones (Part Number IRHSCS)

D. Powering and installation

1. Powering the system indoors (Refer to Figure 1)

Plug one end of the AC to DC adapter into the DC 9V jack on the right side of the main unit, then plug the other end into the 120V AC power receptacle.

2. Powering the system in a car

Plug one end of the DC Power adapter into the DC 9V jack on the unit, then plug the other end into the cigarette lighter socket.




Figure 1

3. Powering the system with rechargeable Battery

Please refer to **K. * Rechargeable Battery Installation and Use** (Page 34 and 36).

E. Installation Prior to installation

Make sure that the unit is placed into the mounting bag with the clear plastic covering around DVD door, Load a disc into the DVD compartment and then fasten the Velcro strap across the top portion of the unit. If you are installing the bag onto the seatback you will need to attach the supplied Seat Standoff to the back of the mounting bag with the Velcro bands to obtain the proper viewing angle as shown in Figure.2

1. Installing the System onto the seat back in a car
(Refer to Figure 2)




Figure 2

- 1). Take one of the supplied straps from the carrier bag. Connect the latch to one of the upper metal rings on the mounting bag. Connect the S! hook to the other upper metal ring and place the loop over the headrest. Adjust the strap until the bag is firmly secured.
- 2). Take another strap from the carrier bag, and connect the latch to the lower metal ring on the left side of the bag. Attach the S! hook to the same ring after looping the strap around the seat rail. Repeat this process for the right side. In some vehicles, it may be necessary to attach the S! connector to the rail directly, as it may not be long enough to reach back to the ring.
- 3). Adjust the straps tightly so that the bag is secured.

2. Installing the system between the driver/passenger seat
(Refer to Figure 3)




Figure 3

- 1). Take one strap and connect the latch to the upper metal ring on the left side of the bag. Attach the S! hook to the same ring after looping the strap around the headrest of the driver's seat. Repeat this process for the right side (Passenger Seat).
- 2). Take another strap and connect the latch to lower metal ring on the left side of the bag. Attach the S! hook to the same ring after looping the strap around the driver's seat rail. Repeat this process for the right side. In some vehicles, it may be necessary to attach the S! connector directly to the rail, as it may not be long enough to reach back to the ring.
- 3). Adjust the straps tightly so that the bag is secured.

F. Controls, Indicators, and Connectors

1. Unit View (Refer to Figure 4)




Figure 4

- | | |
|--------------------------|-------------------------------|
| 1) Screen Mode Button | 12) Brightness control |
| 2) Pause Button | 13) Volume control |
| 3) Play Button | 14) Headphone Jack 1 |
| 4) Open Button | 15) Headphone Jack 2 |
| 5) Previous Button | 16) IR On/Off Switch |
| 6) Stop Button | 17) DC 9V Input Jack |
| 7) Next Button | 18) DVD Video Output Jack |
| 8) IR Transmitter | 19) DVD L+R Audio Output Jack |
| 9) Remote Control Sensor | 20) Video Input Jack |
| 10) Power LED | 21) Audio L+R Input Jack |
| 11) Power On/Off Switch | |

2. Remote Control View (Refer to Figure 5)

- 1) DISPLAY Button
- 2) ANGLE Button
- 3) SUBTITLE Button
- 4) AUDIO Button
- 5) ZOOM Button
- 6) UP/DOWN/LEFT/RIGHT/
ENTER Button
- 7) RETURN Button
- 8) A-B Button
- 9) FORWARD Button
- 10) REVERSE Button
- 11) SLOW Button
- 12) STOP Button
- 13) NUMERIC KEYPAD
- 14) SETUP Button
- 15) MENU Button
- 16) REPEAT Button
- 17) PREVIOUS Button
- 18) NEXT Button
- 19) PLAY Button
- 20) PAUSE Button





Figure 5

G. Loading and Playing a Disc

- a. After connecting power to the unit, slide the POWER ON/OFF on the right side to ON, the DVD player's POWER indicator lights.
- b. Open the disc tray by pressing OPEN at the lower right of the disc tray, and place a disc into the tray with the disc's label facing up.
- c. Press at the right side of the door until it clicks shut. The unit will load the disc and start playing.
- d. Rotate BRIGHT and VOLUME to adjust the LCD's brightness and the DVD player's volume.
- e. To stop playing a disc, press STOP.
- f. To turn off the DVD player, slide POWER ON/OFF to OFF. The DVD player's POWER indicator turns off.
- g. To remove the disc, open the disc tray, just use your finger to access the right inner corner of the disc tray and lift up the disc and remove it from the disc tray. Please refer to Figure 6.



Remove disc from here.

Figure 6

H. SETUP

Press #SETUP" to display the Main screen of the SETUP Menu on the screen. Press #SETUP" again to exit the SETUP Menu and the unit will resume its last playback mode.

1) Press #SETUP", the General Setup Page! will display on screen.




General SETUP Menu Screen

a).Select #TV Type" using UP/DOWN, and then press the RIGHT button to enter the submenu. Choose TV Type using UP/DOWN and then press ENTER to confirm the setting. Press the LEFT button to return.



TV Type Screen Display


b).Select #TV Display" using the UP/DOWN button, and then press RIGHT to enter the submenu. Select the TV display mode on the screen using UP/DOWN, and press ENTER to confirm the setting. Press LEFT to return.



TV Display Screen Display

- * Normal/PS: When the player is connected to a normal TV, and a wide picture is shown on the full screen.
- * Normal/LB: When the player is connected to a normal TV, and a wide picture is shown on the screen with a black strip at both the top and bottom of the screen.
- * Wide: When the player is connected to a wide screen TV, a wide picture is shown on the full screen.

c). Select "Angle Mark" using the UP/DOWN button, and then press the RIGHT button to enter the submenu. Choose Angle Mark on or off using the UP/DOWN button and then press ENTER to confirm the setting. Press the LEFT button to return.




Angle Mark Screen Display

- * On: The screen will show the angle mark icon. (*If an angle option is available).
- * Off: The screen will not display the Angle Mark icon.

NOTE: Not all discs contain above features.

- d).Select "#Screen Saver" using the UP/DOWN button, and then press the RIGHT button to enter the submenu. Choose Screen Saver on or off using the UP/DOWN button and then press ENTER to confirm the setting. Press the LEFT button to return.



Screen Saver Display

*On: Enables screen saver

*Off: Disables screen saver (off)

***NOTE:** The DVD player will enter the Screen Saver mode after approximately five minutes if the same image remains on the screen.

- e).Select "#Last Memory" by using the UP/DOWN button, and then press the RIGHT button to enter the submenu. Choose Last Memory on or off using the UP/DOWN button and then press ENTER to confirm the setting. Press the LEFT button to return.



Last Memory Screen Display

*On: The unit will return to the last position on the disc.

*Off: The unit will not return to the last position on the disc.

NOTE: For last position memory to function, the power to the unit must remain on and the disc door must remain closed.

- 2) Select Video Quality Setup! by using the LEFT/RIGHT button, press ENTER to enter the video quality setup page.




Main Setup Menu Video Quality

- a).Select "Brightness" by using the UP/DOWN button ,then press ENTER you can change the brightness by pressing the LEFT or RIGHT button. To exit Brightness setting, press ENTER again to return the main Menu.



Brightness Screen Display


- b).Select "Contrast" by using the UP/DOWN button,then press ENTER you can adjust the Contrast by pressing the LEFT or RIGHT button.



Contrast Screen Display

- To exit Contrast setting, press ENTER again to return to the main Menu.


- c).Select #Hue" by using the UP/DOWN button, then press ENTER you can adjust the Hue by pressing the LEFT or RIGHT button.



Hue (Tint) Screen Display

To exit Hue setting, press ENTER again to return the main Menu.


- d).Select #Saturation" by using the UP/DOWN button, then press ENTER you can adjust the Saturation by pressing the LEFT or RIGHT button.



Saturation (Color)Screen Display

To exit Saturation setting, press ENTER again to return to the main Menu.

- 3).Select Password! using the LEFT or RIGHT buttons,press ENTER to enter the password setup page,then press the RIGHT button to enter the submenu.




Password Change Menu

Press ENTER to enter the "Password Change Page". Input the Old Password or the Default Password, the New Password, and the Confirmed New Password. Press ENTER to confirm the change.



Password Change Menu



Password Verify Input Screen Display


NOTE: The Default Password is **3308**. This password is always effective even after you have selected your own password and changed it. To avoid the possibility of others using the default password to set the parental level and change the password, you can record this default password in another area and delete it from this manual. Some discs can be limited depending on the age of users while some discs cannot.

- 4).With no disc inside the player, select Preference! using the LEFT or RIGHT button, then press ENTER to enter the preference page.
- a. Select #Audio" using the UP/DOWN button, then press RIGHT to enter the submenu. Select the audio language you desire using the UP or DOWN button, then press ENTER to confirm the setting. Press LEFT to return.



Preference Audio Language

- b. Select #Subtitle" the using UP/DOWN button, then press RIGHT to enter the submenu. Select the desired subtitle language or Subtitle Off using the UP or DOWN button, then press ENTER to confirm the setting. Press LEFT to return.



Preference Subtitle Language


- c. Select #Disc Menu" using the UP/DOWN button, then press RIGHT to enter the submenu. Select the Disc Menu Language you desire using the UP or DOWN buttons , then press ENTER to confirm the setting. Press LEFT to return.



Preference Disc Menu Language

Note: Language and subtitle selection is only available for discs that are recorded in the above listed languages. If the selected, language is not available, the player will play and display on the screen the original recorded language contained in the disc.

- d. Select #Parental" using the UP/DOWN button, then press RIGHT to enter the submenu.




Parental Preference Screen Display

Select the parental level you desire using the UP or DOWN button for discs with lock-out function or multiple rating levels. These are listed from the lowest level (1 Kid Safe) to the highest level (Adult). Enter a 4 digit password, then press ENTER to confirm the parental level setting.

NOTE: The level of 8 Adult is the factory default.

- e. Select "#Default" using the UP/DOWN button, then press RIGHT to enter the submenu. Press ENTER to make the setting return to the factory-set mode.



Loading Factory Setting

NOTE: The parental setting is not affected by the default reset function.

I. Playing DVD

1. Basic Operation

POWER	Turn the unit on/off
OPEN	Remove/load the disc
PLAY	Start Play/Execute item or setting
SLOW	Play at 1/2, 1/4, 1/8 or 1/16 times speed
PAUSE	Still Picture
STOP	(1 time) Stop at the present playing point / (2 times) Stop playing
NEXT	Go to the next chapter, track or scene during playback
PREVIOUS	Go back to the previous chapter, track or scene during playback
FORWARD	Scan forward at 2, 4, 8, 16 or 32 times speed
REVERSE	Scan backward at 2, 4, 8, 16 or 32 times speed
LEFT/RIGHT/UP/DOWN	Used for Menu Navigation
ENTER	Execute item or confirm setting
NUMBERS	Select item, setting or password
RETURN	Return
MENU	Display the main menu of the disc
REPEAT	Repeat playing title, chapter, or track
A-B	Repeat a specific portion from point A to point B of the disc
DISPLAY	Display information (title, chapter, track, time, etc.).
ANGLE	Change the viewing angles on the scene
SUBTITLE	Select the subtitle language and turn it on/off
AUDIO	Select the audio language
ZOOM	Enlarge an image to 2, 3, or 4 times the original size.
SETUP	Display the setup menu to select and set items, and exit the setup menu.


2. MENU

A DVD is divided into sections called titles and chapters. When you play a DVD, a root menu of the disc will appear on the screen of your TV or Monitor. The contents of the menu vary from disc to disc. Press MENU during playback to display the menu. Some DVDs only allow you to select disc playback options using the DVD root menu.

3. DISPLAY


1. PLAYING TIME AND REMAINING TIME

- a. During playback press the #DISPLAY" button to display the current title number (1), the total number of Titles (2), the current chapter number (3), the total Number of Chapters (4), and the playing elapsed Time for the title (5). The heading will disappear automatically after 3 seconds if the #DISPLAY"button is not pressed.




Title, Chapter Number, and Time Screen Display

- b. Press #DISPLAY" again to display the remaining time of the title. The heading will disappear automatically in 3 seconds.




Title Remaining Time Screen Display

- c. Press #DISPLAY" a 3rd time to display the Elapsed Time for the chapter. The heading will disappear automatically in 3 seconds.



Chapter Elapsed Time Screen Display

- d. Press #DISPLAY" a 4th time to display the Remaining Time for the chapter. The heading will disappear automatically in 3 seconds.



Chapter Remaining Time Screen Display

- e. Press #DISPLAY" a 5th time to exit, #Display Off" will be displayed and will disappear automatically in 3 seconds.

2. ANGLE

During playback of a disc, press #ANGLE" to display the available angles if discs containing multi-angles*, with the current angle number (1) and the total number of angles (2) displaying. Press #ANGLE" to select another angle, then press again to exit and return to the normal viewing angle. The angle display will disappear automatically if the #ANGLE" button is not pressed again within 3 seconds.


***NOTE:** Not all discs contain this feature.



Angle Screen Display

3. *SUBTITLE*

During disc playback press #SUBTITLE" to select the subtitle language you desire*, with the current Subtitle Language Number (1) and the total number of subtitle languages (2) displayed. If there are multiple languages press #SUBTITLE" again to select another subtitle language. To turn subtitles off, press the #SUBTITLE" button until #Subtitle Off" is displayed. The Subtitle display will disappear automatically if the #SUBTITLE" button is not pressed again within 3 seconds.




Subtitle Screen Display

* Some DVDs only allow access to this function through the DVD menu.

4. AUDIO

During playback press #AUDIO" to select the audio language you desire*, with the current audio channel number (1) and the total number of audio channels (2) displayed. Press #AUDIO" again to select another audio language. The audio display will disappear automatically if the #AUDIO" button is not pressed within for 3 seconds.



Audio Language Screen Display

* Some DVDs only allow access to this function through the DVD menu.

5. ZOOM

During playback press #ZOOM" to enlarge the picture by 2x, 3x or 4X with the current zoom multiple.(1)Press ZOOM! one time, the picture will be enlarged 2X.(2)Press ZOOM! a 2nd time, the picture will be enlarged 3X.(3)Press ZOOM! a 3rd time, the picture will be enlarged 4X.(4)Press ZOOM! a 4th time, the picture will return to normal size.



ZOOM Screen Display


6. *A-B REPEAT*

- a. During playback press first time #A-B" to set the Starting Point A.




A-B Repeat Starting Point Screen Display

- b. Press #A-B" second time to set the Ending Point B and the player will repeatedly play the part between Point A and Point B.



A-B Repeat Ending Point Screen Display


- c. Press A-B a third time to cancel A-B repeat and resume playback.



A-B Repeat Cancelled Screen Display

7. *REPEAT*

- a. During playback press #REPEAT" once to repeatedly play the current chapter.



Chapter Repeat Screen Display

- b. During playback press #REPEAT" again to repeatedly play the current title.




Title Repeat Screen Display

- c. During playback press #REPEAT" a 3rd time to repeat all Chapters and Titles.



All Repeat Screen Display

- d. Press REPEAT! a 4th time, to resume normal play.



Repeat Off Screen Display

4. PLAYING AUDIO CDS

When playing an audio CD press the DISPLAY button on the remote to view time information. The options below show you what information is available using this function.

- a. The current track and playing time of that track will be displayed on the screen.



Single Elapsed Screen Display

- b. Press #DISPLAY" one time and #Single Remain" appears along with the current track playing and the amount of time left.



Single Remain Screen Display

- c. Press #DISPLAY" a 2nd time and #Total Elapsed" appears along with the current track playing and the total time that the CD has been playing.



Total Elapsed Screen Display

- d. Press #DISPLAY" a 3rd time and #Total Remain" appears along with the current track playing and the amount of time remaining on the CD.



Total Remain Screen Display

- e. Press #DISPLAY" a 4th time and #Display Off" will appear momentarily then disappear. The CD time Information will not be displayed.

USING THE REPEAT FEATURE

The default mode for the Repeat feature is OFF. Pressing REPEAT consecutively changes the repeat options:

\$Track- repeats the track that is playing.

\$All- repeats the disc that is playing.

\$Off

As you toggle through the options, the repeat option changes. The selected repeat option loops repeatedly until you turn it off.

5. PLAYING MP3 DISCS

MP3 is a format for storing digital audio. An audio CD-quality song is compressed into the MP3 format with very little loss of audio quality while taking up much less disc space. CD-R /RW discs that have been encoded in MP3 format are compatible with this system.

Playback modes:


Folder (normal playback)

Single

Repeat One (repeat playback of a song)

Repeat Folder (repeat playback of a specific folder)

Insert a MP3 CD, the DVD player will initialize the disc and the directory (folder) will be shown on the TV screen.



MP3 Menu Screen Display

When a MP3 disc is inserted into the unit, the menu screen appears automatically. You can use the menu screen to change folders and songs. The system plays the songs in the order they were burned onto the disc.

1. Press the ▲ or ▼ button to choose a folder from the folder list on the left side of the screen.
2. Press ENTER to select the highlighted folder. The songs available under the folder will be listed.
3. Use ▲ or ▼ button to choose a song from the list. Press ENTER to select and begin playback of the highlighted song.

Use the ►►(NEXT) button to move to the next song. Press the ◀◀(PREVIOUS) button to move to the beginning of the previous song.

Using The Repeat Feature

The default mode for the Repeat feature is OFF. Pressing REPEAT consecutively changes the repeat options:

- \$ Single
- \$ Repeat One
- \$ Repeat Folder
- \$ Folder

Pressing REPEAT a 4th time will resume normal playback. As you toggle through the options, the repeat option changes. The selected repeat option loops repeatedly until you turn it off.

NOTE

- ! icon in front of a file name indicates that this is a folder, not a MP3 file.
- MP3! icon in front of a file name indicates that this is a MP3 file.
- If the MP3! disc only contains one folder the songs in the folder will be listed.

6. Playing JPEG file

- 1) Load the JPEG Disc into tray.
- 2) Select JPEG file by pressing UP/DOWN! button.
- 3) You can open the JPEG file by pressing Play! or ENTER!.
- 4) Pressing the LEFT Key will rotate the picture 90 degrees counterclockwise. Pressing the RIGHT Key will rotate the picture clockwise.
- 5) When browsing the photos, you can reverse the photo horizontally by pressing UP! key, or you can reverse the photos vertically by pressing DOWN! key.
- 6) When you browse the JPEG file, press display!, there will be different refresh mode below.
 - a. Press display! first time, WIPE TOP! will display on the screen, the picture will refresh from top to bottom.
 - b. Press display! 2nd time, WIPE BOTTOM! will display on the screen, the picture will refresh from bottom to top.
 - c. Press display! 3rd time, WIPE LEFT! will display on the screen, the picture will refresh from left side to right side.
 - d. Press display! 4th time, WIPE RIGHT! will display on the screen, the picture will refresh from right side to left side.
 - e. Press display! 5th time, DIAGONAL WIPE LEFT TOP! will display on the screen, the picture will refresh from left top to right bottom.
 - f. Press display! 6th time, DIAGONAL WIPE RIGHT TOP! will display on the screen, the picture will refresh from right top to left bottom.
 - g. Press display! 7th time, DIAGONAL WIPE LEFT BOTTOM! will display on the screen, the picture will refresh from left bottom to right top.
 - h. Press display! 8th time, DIAGONAL WIPE RIGHT BOTTOM! will display on the screen, the picture will refresh from right bottom to left top.

- i. Press display! 9th time, EXTEND FROM CENTER H! will display on the screen, the picture will refresh from horizontal center to both sides.
 - j. Press display! 10th time, EXTEND FROM CENTER V! will display on the screen, the picture will refresh from vertical center to both sides.
 - k. Press display! 11th time, COMPRESS TO CENTER H! will display on the screen, the picture will refresh from top and bottom to center.
 - l. Press display! 12th time, COMPRESS TO CENTER V! will display on the screen, the picture will refresh from right and left to center.
 - m. Press display! 13th time, WINDOW H! will display on the screen, the picture will refresh from four window's top side to bottom side.
 - n. Press display! 14th time, WINDOW V! will display on the screen, the picture will refresh from four window's left side to right side.
 - o. Press display! 15th time, WIPE FROM EDGE TO CENTER! will display on the screen, the picture will refresh from 4 edges to center.
- 7) When previewing the file, pressing ANGLE, SUBTITLE, AUDIO, NUMBER, AB, RETURN, REW/FF, SLOW! a hand icon will appear on the display meaning that these options are not available.
- 8) Press Stop! to browse the JPEG file, SLIDE SHOW! MENU! will display on the screen.
- 9) When browsing the picture, press Stop! and thumbnail size picture will be displayed. You can select the picture you desire by using the UP/DOWN/LEFT/RIGHT/ENTER key.
- 10) Press Play! or OK!, to preview the left top picture.
- 11) You can return the root Menu by pressing MENU! key.

7. Connecting to a TV or another monitor (Refer to Figure 7)

You can also connect the DVD player to a TV to enjoy high quality stereo sound and picture on another monitor.

1. Connect one end of the audio/video cable's black (1/8" stereo plug) plug into the unit's DVD AUDIO OUT jack, and connect the other end to the AUDIO INPUT jacks on your TV or Monitor (white = left channel, red = right channel).
2. Connect the audio/video cable's yellow plug into the DVD VIDEO OUT jack on the back of the unit, and the other yellow plug to the VIDEO INPUT jack on your TV or Monitor.




Figure 7

J. Specifications

Compatible DISC: DVD/CD/MP3/JPEG

Signal system: NTSC/PAL

Panel size: 6.2 inch

Frequency response: 20 Hz to 20 kHz

Video output: 1 Vp-p/75 Ohm, unbalanced

Audio output: 1.4Vrms/10kOhm

Audio S/N: Better than 60 dB

Dynamic range : Better than 85 dB

Laser: Semiconductor Laser, Wave Length: 650 nm/795 nm

Power source: DC 9V

Power consumption: 12 W

Operating temperature: 5~35°C

Weight : 0.75 kg

Dimensions (W x D x H): 200 x 150 x 50.5mm

Battery Type: Ni-Mh

K. Rechargeable Battery Installation and Use

The player utilizes a set of long-life Ni-Mh batteries for a portable power supply. Ni-MH batteries feature high storage capacity and low level of degradation. This means the Ni-MH batteries do not have Memory Effect! and thus can be recharged safely regardless of whether the battery is fully or only partially discharged. Please fully charge the battery prior to first use.

NOTE: When the DVD player is used with the battery as a power source, ensure that the battery has been charged for at least eight hours prior to connecting it to the DVD player for the first time.

If you plan not to use the battery for an extended period of time (one week or longer), we recommend that you first fully charge the battery and store it away properly. For longer periods of storage, please recharge the battery at least once every two months to maintain the battery in optimum condition. Under no circumstances short the battery terminals, store the battery in a metal container, or leave the battery in a humid or damp environment. Ideally, store the battery in an airtight container with desiccant or other dehumidifying agent. Each full recharge takes approximately five-hours and one full charge can provide power to the player for approximately 3 hours.

During recharge, the red indicator will stay on. Once fully recharged, the red light will turn off. At this point you may remove the wall plug and stop charging.

Precautions related to Battery Recharge:

1. Once the battery is fully discharged, immediately recharge (regardless of whether you plan to use battery or not) in order to maximize battery life.
2. To charge the battery, please connect the power jack directly into the DVD player and leave the POWER switch in the "Off" position.

Using and Maintaining your Rechargeable Batteries

1. Please make sure you always use **only** the **AC adapter** included with the player to recharge your batteries.
2. Recharge efficiency will degrade when environmental temperatures drop below 50°F (10°C) or exceed 95°F (35°C).
3. Please remove battery from the player and store it properly if the player is not to be used for long time. During this period, please recharge the battery at least once two months to avoid irreparable damage to the battery.

Installing the Battery Pack:

1. First, make sure the player is in Stop! mode and that the AC power supply has been disconnected.
2. Close the player cover.
3. Align the battery pack with the player module's front edge.
4. Push the battery towards the back of the player until it locks into position. The lock position is indicated by a click. The unit will fit snugly to the player.




Figure 8. Installing the DVD Player Battery

Removing the Battery Pack:

1. First, make sure the player is in Stop! mode and the AC power supply has been disconnected.
2. Press the release button on the rear of battery.
3. Slide the battery towards the front of the unit.




Figure 9. Removing the DVD Player Battery

L. Using Wired and wireless headphones

1. *Wired headphones*

Optional wired headphones may be used with the unit. Simply plug in the headset to either Headphone Jack 1 or Headphone jack 2 on the right side of the monitor.

NOTE: Plugging headset into Headphone Jack 1 disables external speakers.

2. *Wireless headphones*


The VBP620 includes a built in infrared transmitter* for use with wireless headphones(PN IRHSCS). Turning the Wireless Headphone switch ON will activate the internal IR transmitter and the volume can then be adjusted separately with the controls on the wireless headphones. Any number of wireless headphones can be used, but all must be within direct line of sight from the transmitter. See the documentation accompanying your wireless headphones for more detailed information.

NOTE: If the wireless headphones are not being used the IR Switch should be set to the off position to conserve battery life.

M. Wiring Diagram

(Power Adapter With Built-in Wireless FM Modulator)

FCC ID:RR8401



This power adapter has a built-in wireless FM Modulator. The FM modulator is designed to transmit the audio from your DVD player to your vehicle radio.

The channel select switch is used to select the modulator frequency (88.1MHz, 88.3MHz, 88.5MHz and 88.7MHz). The vehicle radio must be tuned to the same frequency that is selected on the wireless FM modulator.

Installation:

- 1) Plug the Power Adapter into the 12 VDC outlet in the vehicle.
- 2) Connect the 3.5mm audio jack to the audio output jack on the rear of the DVD player.
- 3) Connect the DC jack to the 9 VDC input on the side of the DVD player.
- 4) Tune the vehicle radio to the same frequency that is selected on the modulator.

NOTE: For best performance, use a radio frequency that is not in use in your local area.



90 DAY LIMITED WARRANTY

Applies to Audiovox Video Products

AUDIOVOX ELECTRONICS CORP. (the Company) warrants to the original retail purchaser of this product that should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 90 days from the date of original purchase, such defect(s) will be repaired or replaced with reconditioned product (at the Company's option) without charge for parts and repair labor.

To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s), transportation prepaid, to the Company at the address shown below.

This Warranty does not extend to the elimination of externally generated static or noise, to correction of antenna problems, to costs incurred for installation, removal or reinstallation of the product, or to damage to tapes, discs, speakers, accessories, or electrical systems.

This Warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s). THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN A PERIOD OF 30 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

U.S.A. : AUDIOVOX ELECTRONICS CORPORATION, 150 MARCUS BLVD.
HAUPPAUGE, NEW YORK 11788 • 1-800-645-4994

CANADA : CALL 1-800-645-4994 FOR LOCATION OF WARRANTY STATION SERVING YOUR AREA

128-5556C



For Customer Service
Visit Our Website At
www.audiovox.com
Product Information, Photos,
FAQ's Owner's Manuals