



# myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for EMERSON EWR10D4. You'll find the answers to all your questions on the EMERSON EWR10D4 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual EMERSON EWR10D4  
User guide EMERSON EWR10D4  
Operating instructions EMERSON EWR10D4  
Instructions for use EMERSON EWR10D4  
Instruction manual EMERSON EWR10D4



**Emerson**  
EMERSON AND THE G-CLEF LOGO ARE REGISTERED TRADEMARKS OF EMERSON RADIO CORP., 100 SPRINGWOOD AVE., NEW JERSEY, U.S.A.

## Owner's Manual

### DVD Recorder

# EWR10D4

INSTRUCCIONES EN ESPAÑOL INCLUIDAS.

**Supplied Accessory**

- Remote control (NB001UD) with two AA batteries
- RF cable (WFZ0901TM002 or WFZ0901CAB01)
- Audio/Video cables (WFZ0102TM015 or WFZ0102LTE01)
- Owner's Manual (0VMND4178)
- Quick Use Guide (0VMND4181)

Please read before using this equipment. If you need additional operating assistance after reading this owner's manual or to order replacement accessories, please call **TOLL FREE : 1-800-605-8457** or visit our web site at <http://www.funai-corp.com>

Before you use this unit, you need to complete connections. Refer to "Connections" on pages 13-15.

To record a program easily, refer to "Easy DVD recording" on pages 16-17 after connections are completed. (You CANNOT record on any copyright protected DVD disc with this DVD recorder.)

Before you start | Connections | Getting started | Recording | Playing discs | Editing | Copying/Editing | Others | Español



[Your user manual](#)  
[EMERSON EWR10D4](#)

**Manual abstract:**

*A NOTE ABOUT RECYCLING This product's packaging materials are recyclable and can be reused. Please dispose of any materials in accordance with your local recycling regulations. Batteries should never be thrown away or incinerated but disposed of in accordance with your local regulations concerning chemical wastes. Make your contribution to the environment!!! · Used up batteries do not belong in the dust bin. · You can dispose of them at a collection point for used up batteries or special waste. Contact your council for details. For Customer Use: Read carefully the information located at the back of this unit and enter below the Serial No. Retain this information for future reference. Model No. \_\_\_\_\_ Serial No.*

*\_\_\_\_\_ 2 Before you start Before you start Precautions (cont'd) Important Safeguards 1. Read Instructions - All the safety and operating instructions should be read before the appliance is operated. 2. Retain Instructions- The safety and operating instructions should be retained for future reference. 3.*

*Heed Warnings - All warnings on the appliance and in the operating instructions should be adhered to. 4. Follow Instructions - All operating and use instructions should be followed. 5. Cleaning - Unplug this product from the wall outlet before cleaning.*

*Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning. EXCEPTION: A product that is meant for uninterrupted service and, that for some specific reason, such as the possibility of the loss of an authorization code for a CATV converter, is not intended to be unplugged by the user for cleaning or any other purpose, may exclude the reference to unplugging the appliance in the cleaning description otherwise required in item 5. 6. Attachments*

*- Do not use attachments not recommended by the product manufacturer as they may cause hazards. 7. Water and Moisture- Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, and the like. 8. Accessories - Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the appliance.*

*Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the appliance should follow the manufacturer's instructions and should use a mounting accessory recommended by the manufacturer. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn. 9. Ventilation - Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to. 10. Power Sources - This product should be operated only from the type of power source indicated on the marking label.*

*If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions. 11. Grounding or Polarization - This product is equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way.*

*This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug. 12.*



[Your user manual](#)  
[EMERSON EWR10D4](#)