

**TOSHIBA**



# COMBINATION FLAT COLOR TELEVISION AND VIDEO CASSETTE RECORDER / DVD VIDEO PLAYER

**MW20F51**  
**MW24F51**  
**MW27F51**

*OWNER'S MANUAL*

**VHS** **Hi-Fi**




Illustration of MW27F51

©2005 Toshiba Corporation  
This device does not tape-record copy protected DVD video discs.

Introduction **2**

Connections **14**

Basic setup **19**

TV operation **24**

Playback  
(VCR) **34**

Recording  
(VCR) **39**

Other functions  
(VCR) **43**


Basic playback  
(DVD) **45**

Advanced  
playback  
(DVD) **48**

Function setup  
(DVD) **57**

Others **63**

# SAFETY PRECAUTIONS



The lightning flash with arrowhead symbol, within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

**WARNING:** TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

**WARNING:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**CAUTION:** Changes or modifications not expressly approved by the party responsible for compliance with the FCC (Federal Communications Commission) Rules could void the user's authority to operate this equipment.

**COPYRIGHT:** It is permissible to record television programs, films, video tapes and other material only in the event that third party copyrights and other rights are not violated.

**CAUTION:**  
THIS DIGITAL VIDEO PLAYER EMPLOYS A LASER SYSTEM.


TO ENSURE PROPER USE OF THIS PRODUCT, PLEASE READ THIS OWNER'S MANUAL CAREFULLY AND RETAIN FOR FUTURE REFERENCE. SHOULD THE UNIT REQUIRE MAINTENANCE, CONTACT AN AUTHORIZED SERVICE LOCATION.

USE OF CONTROLS, ADJUSTMENTS OR THE PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

TO PREVENT DIRECT EXPOSURE TO LASER BEAM, DO NOT TRY TO OPEN THE ENCLOSURE. VISIBLE LASER RADIATION MAY BE PRESENT WHEN THE ENCLOSURE IS OPENED. DO NOT STARE INTO BEAM.

## Location of the required Marking

The rating sheet and the safety caution are on the rear of the unit.



CERTIFICATION: COMPLIES WITH  
FDA RADIATION PERFORMANCE  
STANDARDS, 21 CFR SUBCHAPTER J.

# IMPORTANT SAFEGUARDS

## 1. READ INSTRUCTIONS

All the safety and operating instructions should be read before the unit is operated.

## 2. RETAIN INSTRUCTIONS

The safety and operating instructions should be retained for future reference.

## 3. HEED WARNINGS

All warnings on the unit and in the operating instructions should be adhered to.

## 4. FOLLOW INSTRUCTIONS

All operating and use instructions should be followed.

## 5. CLEANING

Unplug this unit from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners.

Use a damp cloth for cleaning the exterior cabinet only.

## 6. ATTACHMENTS

The manufacturer of this unit does not make any recommendations for attachments, as they may cause hazards.

## 7. WATER AND MOISTURE

Do not use this unit near water. For example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool.

## 8. ACCESSORIES

Do not place this unit on an unstable cart, stand, tripod, bracket, or table.

The unit may fall, causing serious injury, and serious damage to the unit.

- 8A.** An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.

## 9. VENTILATION

Slots and openings in the cabinet back or bottom are provided for ventilation, and to ensure reliable operation of the unit, and to protect it from overheating.

These openings must not be blocked or covered. The openings should never be blocked by placing the unit on a bed, sofa, rug, or other similar surface. This unit should never be placed near or over a radiator or heat source. This unit should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

## 10. POWER SOURCE

This unit should be operated only from the type of power source indicated on the rating plate. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For units intended to operate from battery power, or other sources, refer to the respective pages on this Owner's Manual for their operating instructions.

## 11. GROUNDING OR POLARIZATION

This unit is equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Instead of the polarized alternating-current line plug, your unit may be equipped with a 3-wire grounding-type plug (a plug having a third (grounding) pin). This plug will only fit into a grounding-type power outlet. This too, is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet.

Do not defeat the safety purpose of the grounding-type plug.

## 12. POWER-CORD PROTECTION

Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

PORTABLE CART WARNING  
(symbol provided by RETAC)



S3126A

# IMPORTANT SAFEGUARDS

## 13. LIGHTNING

To protect your unit from a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the unit due to lightning and power line surges.

## 14. POWER LINES

An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall onto or against such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits, as contact with them might be fatal.

## 15. OVERLOADING

Do not overload wall outlets and extension cords, as this can result in a risk of fire or electric shock.

## 16. OBJECT AND LIQUID ENTRY

Do not push objects through any openings in this unit, as they may touch dangerous voltage points or short out parts that could result in fire or electric shock. Never spill or spray any type of liquid into the unit.

## 17. OUTDOOR ANTENNA GROUNDING

If an outside antenna or cable system is connected to the unit, be sure the antenna or cable system is grounded to provide some protection against voltage surges and built-up static charges. Section 810 of the National Electrical Code (NEC), ANSI/NFPA 70, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

## 18. SERVICING

Do not attempt to service this unit yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

For example:

- a. When the power-supply cord or plug is damaged.
- b. If liquid has been spilled, or objects have fallen into the unit.
- c. If the unit has been exposed to rain or water.
- d. If the unit does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions, as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the unit to its normal operation.
- e. If the unit has been dropped or the cabinet has been damaged.
- f. When the unit exhibits a distinct change in performance, this indicates a need for service.

## 19. REPLACEMENT PARTS

When replacement parts are required, be sure the service technician uses replacement parts specified by the manufacturer or those that have the same characteristics as the original part.

Unauthorized substitutions may result in fire, electric shock or other hazards.

## 20. SAFETY CHECK

Upon completion of any service or repairs to this unit, ask the service technician to perform safety checks to determine that the unit is in proper operating condition.

## 21. HEAT

The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

## 22. DISC TRAY

Keep your fingers well clear of the disc tray as it is closing. It may cause serious personal injury.

## 23. CONNECTING

When you connect the product to other equipment, turn off the power and unplug all of the equipment from the wall outlet. Failure to do so may cause an electric shock and serious personal injury. Read the owner's manual of the other equipment carefully and follow the instructions when making any connections.

## 24. SOUND VOLUME

Reduce the volume to the minimum level before you turn on the product. Otherwise, sudden high volume sound may cause hearing or speaker damage.

## 25. SOUND DISTORTION

Do not allow the product output distorted sound for a longtime. It may cause speaker overheating and fire.

## 26. HEADPHONES

When you use the headphones, keep the volume at a moderate level. If you use the headphones continuously with high volume sound, it may cause hearing damage.



## IMPORTANT SAFEGUARDS/Power source

### 27. LASER BEAM

Do not look into the opening of the disc tray or ventilation opening of the product to see the source of the laser beam. It may cause sight damage.


### 28. DISC

Do not use a cracked, deformed, or repaired disc. These discs are easily broken and may cause serious personal injury and product malfunction.

### 29. NOTE TO CABLE TV SYSTEM INSTALLER

This reminder is provided to call the Cable TV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.


EXAMPLE OF ANTENNA GROUNDING AS PER THE  
NATIONAL ELECTRICAL CODE



## IMPORTANT RECYCLING INFORMATION

This product uses both Cathode Ray Tube (CRT) and other components that contain lead. In your community there might be regulations that require you to dispose these materials properly under environmental considerations. Please contact your local authorities, or the Electronic Industries Alliance (<http://www.eiae.org>) for disposal or recycling information.

## Power source



### TO USE AC POWER SOURCE

Use the AC polarized line cord provided for operation on AC. Insert the AC cord plug into a standard 120V 60Hz polarized AC outlet.

#### Notes:

- Never connect the AC line cord plug to other than the specified voltage (120V 60Hz). Use the attached power cord only.
- If the polarized AC cord does not fit into a non-polarized AC outlet, do not attempt to file or cut the blade. It is the user's responsibility to have an electrician replace the obsolete outlet.
- If you cause a static discharge when touching the unit and the unit fails to function, simply unplug the unit from the AC outlet and plug it back in. The unit should return to normal operation.
- If the AC cord plug is plugged in for the first time, wait for approx. 5 seconds before pressing the POWER button.

## Precautions

### Notes on handling

- When shipping the unit, the original shipping carton and packing materials come in handy. For maximum protection, repack the unit as it was originally packed at the factory.
- Do not use volatile liquids, such as insect spray, near the unit. Do not leave rubber or plastic products in contact with the unit for a long time. They will leave marks on the finish.
- The top and rear panels of the unit may become warm after a long period of use. This is not a malfunction.
- When the unit is not in use, be sure to remove the disc and the video cassette turn off the power.
- If you do not use the unit for a long period, the unit may not function properly in the future. Turn on and use the unit occasionally.

### Notes on locating

- Place the unit on a level surface. Do not use it on a shaky or unstable surface such as a wobbling table or inclined stand. The loaded disc or the video tape may come off the proper position and cause damage to the unit.
- When you place this unit near a TV, radio, or VCR, the playback picture may become poor and the sound may be distorted. In this case, place the unit away from the TV, radio or VCR.

### Notes on cleaning


Use a soft, dry cloth for cleaning.

- For stubborn dirt, Do not use any type of solvent, such as thinner and benzene, as they may damage the surface of the unit.
- If you use a chemical saturated cloth to clean the unit, follow that product's instructions.

### Notes on moisture condensation


**Moisture condensation damages the unit. Please read the following carefully.**

Moisture condensation occurs, for example, when you pour a cold drink into a glass on a warm day. Drops of water form on the outside of the glass. In the same way, moisture may condense on the head drum or the optical pick-up lens inside this unit, one of the most crucial internal parts of the unit.




■ **Moisture condensation occurs during the following cases.**

- When you bring the unit directly from a cold place to a warm place.
- When you use the unit in a room where you just turned on the heater, or a place where the cold wind from the air conditioner directly hits the unit.
- In summer, when you use the unit in a hot and humid place just after you move the unit from an air conditioned room.
- When you use the unit in a humid place.



■ **Do not use the unit when moisture condensation may occur.**

If you use the unit in such a situation, it may damage discs and internal parts. Remove the disc or the video tape, connect the power cord of the unit to the wall outlet, turn on the unit, and leave it for two or three hours. After two or three hours, the unit will have warmed up and evaporated any moisture. Keep the unit connected to the wall outlet and moisture condensation will seldom occur.





# Contents

## Introduction

|                                  |    |
|----------------------------------|----|
| SEFETY PRECAUTIONS .....         | 2  |
| IMPORTANT SAFEGUARDS .....       | 3  |
| Precautions .....                | 6  |
| Contents .....                   | 7  |
| Notes and Information .....      | 8  |
| Identification of controls ..... | 11 |

## Connections

|                                        |    |
|----------------------------------------|----|
| Antenna connections .....              | 14 |
| Cable TV connections .....             | 15 |
| Connecting to optional equipment ..... | 16 |

## Basic setup

|                               |    |
|-------------------------------|----|
| Starting setup .....          | 19 |
| Clock setting .....           | 20 |
| Setting the language .....    | 23 |
| TV/VCR operation status ..... | 23 |

## TV operation

|                                             |    |
|---------------------------------------------|----|
| TV operation .....                          | 24 |
| Closed captions .....                       | 26 |
| To memorize channels .....                  | 27 |
| Setting the V-Chip .....                    | 28 |
| To set the on timer .....                   | 30 |
| To set the off timer .....                  | 31 |
| Picture control adjustment .....            | 32 |
| Adjusting the picture preference .....      | 32 |
| Sound control adjustment .....              | 33 |
| Stereo and Second Audio Program (SAP) ..... | 33 |

## Playback (VCR)

|                                             |    |
|---------------------------------------------|----|
| Loading and unloading a cassette tape ..... | 34 |
| Cassette tape playback .....                | 35 |
| Special playback .....                      | 36 |
| Convenient function .....                   | 37 |

## Recording (VCR)

|                                       |    |
|---------------------------------------|----|
| Recording a TV program .....          | 39 |
| One-touch Timer Recording (OTR) ..... | 40 |
| Timer recording .....                 | 41 |

## Other functions (VCR)

|                                |    |
|--------------------------------|----|
| Duplicating a video tape ..... | 43 |
| Recording a DVD/CD disc .....  | 44 |

## Basic playback (DVD)

|                      |    |
|----------------------|----|
| Playing a disc ..... | 45 |
|----------------------|----|

## Advanced playback (DVD)

|                                    |    |
|------------------------------------|----|
| Zooming .....                      | 48 |
| Locating desired scene .....       | 48 |
| Repeat playback .....              | 49 |
| A-B Repeat playback .....          | 49 |
| Program playback .....             | 50 |
| Random playback .....              | 50 |
| Changing angles .....              | 51 |
| Title selection .....              | 51 |
| DVD menu .....                     | 51 |
| Changing soundtrack language ..... | 52 |
| Subtitles .....                    | 52 |
| Disc status .....                  | 53 |
| To turn off the PBC .....          | 53 |
| MP3/WMA/JPEG operation .....       | 54 |

## Function setup (DVD)

|                                                       |    |
|-------------------------------------------------------|----|
| Customizing the function settings .....               | 57 |
| Temporary disabling of rating level by DVD disc ..... | 62 |


## Others

|                              |    |
|------------------------------|----|
| Language code list .....     | 63 |
| Reception disturbances ..... | 64 |
| Troubleshooting .....        | 65 |
| Specifications .....         | 67 |
| Limited warranty .....       | 68 |

## Notes and Information

### On handling discs

- Do not touch the playback side of the disc.




- Do not attach paper or tape to discs.



### On cleaning discs

- Fingerprints and dust on the disc cause picture and sound deterioration. Wipe the disc from the center outwards with a soft cloth. Always keep the disc clean.



- Do not use any type of solvent such as thinner, benzene, commercially available cleaners or antistatic spray for vinyl LPs. It may damage the disc.


### On storing discs

- Do not store discs in a place subject to direct sunlight or near heat sources.
- Do not store discs in places subject to moisture and dust such as a bathroom or near a humidifier.
- Store discs vertically in a case. Stacking or placing objects on discs outside of their case may cause warping.


### Structure of disc contents

Normally, DVD video discs are divided into titles, and the titles are sub-divided into chapters. Video CDs and Audio CDs are divided into tracks.

#### DVD video disc



#### Video CD/Audio CD



Each title, chapter or track is assigned a number, which is called "title number", "chapter number" or "track number" respectively.

There may be discs that do not have these numbers.

### Notes on copyright

The unauthorized recording, use, distribution, or revision of copyrighted materials including, without limitation, television programs, videotapes, and DVDs, is prohibited under the Copyright Laws of the United States and other countries, and may subject you to civil and criminal liability.

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.



## About this owner's manual

This owner's manual explains the basic instructions of this unit. Some DVD video discs are produced in a manner that allows specific or limited operation during playback. As such, the unit may not respond to all operating commands. This is not a defect in the unit. Refer to instruction notes of discs.

“” may appear on the TV screen during operation. A “” means that the operation is not permitted by the unit or the disc.

For example, sometimes it is unable to stop the playback of copyright message of the disc when the STOP () button is pressed. Alternatively, the “” may also indicate that the feature is not available for the disc.

## Notes on region numbers

The region number of this unit is 1. If region numbers, which stand for their playable area, are printed on your DVD video disc and you do not find  or , disc playback will not be allowed by the player. (In this case, the unit will display a message on-screen.)

## On Video CDs

This DVD supports Video CDs equipped with the PBC (Version 2.0) function. (PBC is the abbreviation of Playback Control.) You can enjoy two playback variations depending on types of discs.

- **Video CD not equipped with PBC function (Version 1.1)**

Sound and movie can be played on this DVD in the same way as an audio CD.

- **Video CD equipped with PBC function (Version 2.0)**

In addition to operation of a Video CD not equipped with the PBC function, you can enjoy playback of interactive software with search function by using the menu displayed on the TV screen (Menu Playback). Some of the functions described in this owner's manual may not work with some discs.

## Playable discs

This unit can play the following discs.

|                 | Disc Mark                                                                            | Contents                        | Disc Size        | Maximum playback time                   |
|-----------------|--------------------------------------------------------------------------------------|---------------------------------|------------------|-----------------------------------------|
| DVD video discs |    | Audio + Video (moving pictures) | 12 cm            | Approx. 4 hours (single sided disc)     |
|                 |                                                                                      |                                 |                  | Approx. 8 hours (double sided disc)     |
|                 |                                                                                      |                                 | 8 cm             | Approx. 80 minutes (single sided disc)  |
|                 |                                                                                      |                                 |                  | Approx. 160 minutes (double sided disc) |
| Video CDs       |   | Audio + Video (moving pictures) | 12 cm            | Approx. 74 minutes                      |
|                 |                                                                                      |                                 | 8 cm             | Approx. 20 minutes                      |
| Audio CDs       |  | Audio                           | 12 cm            | Approx. 74 minutes                      |
|                 |                                                                                      |                                 | 8 cm (CD single) | Approx. 20 minutes                      |

The following discs are also available.

- DVD-R/RW discs of DVD video format
  - CD-R/CD-RW discs of CD-DA or Video CD
  - Kodak picture CD and FUJICOLOR CD format
- Some of these discs may be incompatible.

- You cannot play discs other than those listed above.
- You cannot play discs of DVD-RAM, DVD-ROM, Photo CD, etc., or non standardized discs even if they may be labeled as above.
- Some CD-R/RWs cannot be played back depending on the recording conditions.
- This unit uses the NTSC color system, and cannot play DVD video discs recorded in any other color system (PAL, SECAM, etc.).

Because of problems and errors that can occur during the creation of DVD software and/or the manufacture of DVD discs, Toshiba cannot guarantee that this player will play every feature of every DVD bearing the DVD logo. As one of the creators of DVD technology, Toshiba DVD players are manufactured using the highest standards of quality, and as a result, such incompatibilities are rare. If you happen to experience any difficulty playing a DVD on a Toshiba DVD player, please feel free to call our Contact listed in “How to Obtain Warranty Service” (see page 69).

## Notes and Information (Continued)

### Playable Media cards

This unit can play the following cards.

|                                         | Card Mark                                                                         | Contents                      | Playable card capacity |
|-----------------------------------------|-----------------------------------------------------------------------------------|-------------------------------|------------------------|
| <b>SD (Secure Digital™) memory card</b> |  | MP3/<br>WMA/<br>JPEG<br>files | 32 MB – 1 GB           |
| <b>MMC (MultiMediaCard™)</b>            | <b>MMC</b>                                                                        |                               | 8 MB – 1 GB            |
| <b>xD-Picture card</b>                  |  |                               | 16 MB – 512 MB         |
| <b>Memory Stick™</b>                    |  |                               | 16 MB – 128 MB         |
| <b>Memory Stick™ (Pro)</b>              | <b>MEMORY STICK</b>                                                               |                               | 128 MB – 2 GB          |

- Do not insert any cards other than those listed above as this may cause a malfunction of the unit or cards.
- Some Media cards may not be played back due to its capacity and/or manufacturer, etc.
- This unit cannot play the xD-Picture card Type M.

### Notes on Media cards

- Ensure that you insert the Media card correctly into the media card slot.
- Never remove the Media card or turn off the unit while using the Media card. Doing so may result in loss of data or damage to the Media card or the unit. SUCH DAMAGE IS NOT COVERED BY YOUR TOSHIBA WARRANTY.
- It is recommended that you back up your Media card data. Toshiba is not liable for any damage caused by the use of any Media card with this unit. Toshiba will not compensate for any lost data or recording(s) caused by the use of such cards.
- Media card is a precision electrical instrument. Do not bend, drop or apply strong force to it.
- Do not use or store the Media card in an environment of high static electricity or electrical interference.
- Avoid using or storing in areas of high temperature and humidity.
- Prevent contact of the metallic area on the Media card with dust, dirt, or other foreign particles. Do not touch the metallic area of the Media card with your hands or otherwise handle it with anything other than a soft, dry, lint-free, antistatic cloth.
- Use index labels made exclusively for your specific brand of Media card. Do not use commercially sold labels, which can cause a malfunction when the card is inserted or ejected.
- When ejecting the Media card after extended use it may feel warm to the touch. This is normal. The Media card is not malfunctioning.
- For instructions on using your Media card, refer to the owner's manual for your Media card.

SD is a trademark of SD Card Association.

MMC and MultiMediaCard are trademarks of Infineon Technologies AG and licensed to MMCA (MultiMediaCard Association).

xD-Picture card™ is a trademark of Fuji Photo Film Co., Ltd.

Memory Stick is a trademark of Sony Corporation.




## Identification of controls

See the page in  for details.

This owner's manual uses the illustrations of MW27F51. MW24F51 and MW20F51 has some differences in appearance from the illustrations. Example: Model MW27F51 has a door on the front panel.


### Front panel

Illustration of MW27F51



Model MW27F51 has a door on the front panel. Please open it to access the \*PHONES jack and the \*AUDIO (L/R)/VIDEO IN (LINE IN 2) jacks.


### Rear panel



## Identification of controls (Continued)

### Remote control

The instructions in this manual describe the function on the remote control. See the page in  for details.




#### \*DVD MENU button


Use the DVD MENU button to display the menu included on many DVD video discs. To operate a menu, follow the instructions in "DVD menu." [51]

## Inserting batteries


- 1** Open the battery compartment cover in the direction of the arrow.



- 2** Install two “R03/AAA” batteries (supplied), paying attention to the polarity diagram in the battery compartment.



- 3** Replace the compartment cover.



### Caution:

- Never throw batteries into a fire.

### Notes:

- Be sure to use AAA size batteries.
- Dispose of batteries in a designated disposal area.
- Attention should be drawn to the environmental aspects of battery disposal.
- Do not mix different battery types or combine used batteries with new ones.
- If the remote control does not operate correctly, or if the operating range becomes reduced, replace both batteries with new ones.
- If the batteries are dead or if you will not be using the remote control for a long time, remove the batteries to prevent battery acid from leaking into the battery compartment.


## Remote control basics

- Press **POWER** to turn the unit on or off.
- Select your desired operating mode (TV/VCR or DVD) using **TV/VCR** or **DVD**.
- Tap **CH**  $\wedge$  or  $\vee$  to move through the channels one channel at a time.
- The **Direction** buttons ( $\blacktriangle$ / $\blacktriangledown$ / $\blacktriangleleft$ / $\blacktriangleright$ ) are also used to navigate on-screen menu system.
- You can directly access specific channels using **Direct channel selection** buttons.

### Operation:

- Aim the remote control at the remote sensor and press control buttons to operate.
- Operate the remote control within 30° angle on either side of the remote sensor, up to a distance of approx. 5 meters.


Illustration of MW27F51



## Antenna connections

If you are using an indoor or outdoor antenna, follow the instructions below that correspond to your antenna system.  
If you are using a cable TV service (CABLE), see page 15 for Cable TV connections.


### Combination VHF/UHF antenna (Single 75 ohm cable or 300 ohm twin-lead wire)



Connect the 75 ohm cable from the combination VHF/UHF antenna to the antenna jack.


If your combination VHF/UHF antenna has a 300 ohm twin-lead wire, the use of the 300-75 ohm matching transformer may be necessary.

### Combination VHF/UHF antenna (Separate VHF and UHF 300 ohm twin-lead wires)



Connect the UHF 300 ohm twin-lead wire to the combiner (not supplied). Connect the VHF 300 ohm twin-lead wire to the 300-75 ohm matching transformer. Attach the transformer to the combiner, then attach the combiner to the antenna jack.

### Separate VHF/UHF antennas (75 ohm VHF cable and 300 ohm UHF twin-lead wires)




Connect the VHF 75 ohm cable and UHF 300 ohm twin-lead wire to the combiner (not supplied). Attach the combiner to the antenna jack.



## Cable TV connections

This unit has an extended tuning range and can tune most cable channels without using a Cable TV converter box. Some cable companies offer “premium pay channels” in which the signal is scrambled. Descrambling these signals for normal viewing requires the use of a descrambler device which is generally provided by the cable company.


### For subscribers to basic cable TV service



For basic cable service not requiring a converter/descrambler box, connect the Cable TV 75 ohm coaxial cable directly to the Antenna jack on the back of the unit.


### For subscribers to scrambled cable TV service

If you subscribe to a cable TV service which requires the use of a converter/descrambler box, connect the incoming 75 ohm coaxial cable to the converter/descrambler box. Using another 75 ohm coaxial cable, connect the output jack of the converter/descrambler box to the antenna jack on the unit. Follow the connections shown below. Set the unit to the output channel of the converter/descrambler box (usually channel 3 or 4) and use the converter/descrambler box to select channels.




### For subscribers to unscrambled basic cable TV service with scrambled premium channels

If you subscribe to a cable TV service in which basic channels are unscrambled and premium channels require the use of a converter/descrambler box, you may wish to use a signal splitter and an A/B Switch box (available from the cable company or an electronics supply store). Follow the connections shown below. With the switch in the “B” position, you can directly tune any unscrambled channels on your unit. With the switch in the “A” position, tune your unit to the output of the converter/descrambler box (usually channel 3 or 4) and use the converter/descrambler box to tune scrambled channels.




## Connecting to optional equipment

Before connecting the unit to other equipment, be sure to turn off the power and unplug all of the equipment from the wall outlet before making any connections. You can enjoy the TV game, camcorder or high quality dynamic sounds of DVD video discs or audio CDs by connecting the unit to optional audio equipment.



### Using the audio/video inputs

Press **INPUT** repeatedly to select the desired mode. "LINE1", "LINE2" or TV channel will display on the screen for 4 seconds.




**Note:** In the DVD mode this key will not operate.

### Connecting a camcorder or a TV game

To playback from the camcorder or playing a TV Game, connect the camcorder to the unit as shown.


➡ Signal flow



Model MW27F51 has a door on the front panel. Please open it to access the PHONES jack and the AUDIO (L/R)/VIDEO IN (LINE IN 2) jacks.

### Connecting to an audio system

Connect the unit to your audio system.





You can enjoy high quality dynamic sounds by connecting the unit to optional audio equipment.


• This section uses the following reference mark.

|                   |                    |
|-------------------|--------------------|
| ■ : Front speaker | □ : Center speaker |
| ■ : Rear speaker  | ⇒ : Signal flow    |
| □ : Sub woofer    |                    |

## Connecting to an amplifier equipped with a Dolby Digital decoder

### Dolby Digital

Dolby Digital is the surround sound technology used in theaters showing the latest movies, and is now available to reproduce this realistic effect in the home. You can enjoy motion picture and live concert DVD video discs with this dynamic realistic sound by connecting the unit to a 6 channel amplifier equipped with a Dolby Digital decoder or Dolby Digital processor. If you have a Dolby Surround Pro Logic decoder, you will obtain the full benefit of Pro Logic from the same DVD movies that provide full 5.1-channel Dolby Digital soundtracks, as well as from titles with the Dolby Surround mark.




## Connecting to an amplifier equipped with Dolby Surround Pro Logic

### Dolby Surround Pro Logic

You can enjoy the dynamic realistic sound of Dolby Surround Pro Logic by connecting an amplifier and speaker system (right and left front speakers, a center speaker, and one or two rear speakers).


- With an amplifier equipped with Dolby Digital  
Connect the equipment the same way as described in "Connecting to an amplifier equipped with a Dolby Digital decoder." Refer to that amplifier's owner's manual and set the amplifier so you can enjoy Dolby Surround Pro Logic sound.
- With an amplifier not equipped with Dolby Digital  
Connect the equipment as follows.
  - This connection is only suitable for Video CDs and Audio CDs.



## Connecting to an amplifier equipped with a DTS decoder

### Digital Theater Systems (DTS)

DTS is a high quality surround technology used in theaters and now available for home use, on DVD video discs or audio CDs. If you have a DTS decoder or processor, you can obtain the full benefit of 5.1 channel DTS encoded sound tracks on DVD video discs or audio CDs.




## Connecting to optional equipment (Continued)

### Connecting to an amplifier equipped with a MPEG audio decoder

#### MPEG2 sound


You can enjoy motion picture and live concert DVD video discs with dynamic realistic sound by connecting an amplifier equipped with an MPEG2 audio decoder or MPEG2 audio processor.



### Connecting to an amplifier equipped with a digital audio input

#### 2 channel digital stereo

You can enjoy the dynamic sound of 2 channel digital stereo by connecting an amplifier equipped with a digital audio input and speaker system (right and left front speakers).




#### Notes:

- DO NOT connect the COAXIAL DIGITAL AUDIO OUT jack of the unit to the AC-3 RF input of a Dolby Digital Receiver. This input on your A/V Receiver is reserved for Laserdisc use only and is incompatible with the COAXIAL DIGITAL AUDIO OUT jack of the unit.
- Connect the COAXIAL DIGITAL AUDIO OUT jack of the unit to the "COAXIAL" input of a Receiver or Processor.
- Refer to the owner's manual of the connected equipment as well.
- When you connect the unit to other equipment, be sure to turn off the power and unplug all of the equipment from the wall outlet before making any connections.
- The output sound of the unit has a wide dynamic range. Be sure to adjust the receiver's volume to a moderate listening level. Otherwise, the speakers may be damaged by a sudden high volume sound.
- Turn off the amplifier before you connect or disconnect the unit's power cord. If you leave the amplifier power on, the speakers may be damaged.

## Starting setup


The STARTING SETUP function makes installing your unit easily. It leads you the Language selection, TV/CABLE selection and auto channel memory automatically.

**IMPORTANT:** Make sure that the antenna or cable TV system connection is made!




### Starting setup

- 1 Press **POWER**.  
The starting setup function begins and the Language setup menu appears on the screen. Press **▲** or **▼** to select your desired language, then press **ENTER**.



- 2 Press **▲** or **▼** to select “TV” or “CABLE”, then press **ENTER**.



- 3 Press **▲** or **▼** to select “START”, then press **ENTER**.  
If you select “CANCEL” and press **ENTER**, the STARTING SETUP stops and changes to the TV screen.



- 4 Now the “AUTO CH MEMORY” and “AUTO CLOCK” starts.

After the starting setup is completed, the TV channel appears on the screen.



#### Notes:

- The starting setup function will work only when you press **POWER** for the first time.
- In “AUTO CLOCK” setting, it may take more than 10 minutes to read the EDS signal for one channel, which has only “Time of day” or “Local time zone”.

## Clock setting

The auto clock function will automatically set the built-in clock (Month, Day, Year and Time) when the unit is connected to an antenna or cable system and it is turned off. As the unit searches for a receivable station in your area and it receives a broadcast signal for auto clock, the auto clock needs several minutes to set itself.

### Auto clock setting

#### Preparation:

- Connect the antenna or cable system.
- If you use a cable box, turn it on.
- Plug the AC power cord to the AC outlet.

#### 1 Make sure the unit is turned off.

- If you press **POWER**, the Auto Clock set is not effective.


#### 2 Wait at least three minutes and press **POWER**.



- Depending on the reception condition, it may take approx. thirty minutes.
- The POWER indicator will light.



#### 3 Press **TV/VCR** to select TV/VCR mode. Then press **DISPLAY** to check the clock on the screen.



#### 4 If the clock is not set, check the antenna condition. The Auto clock may not function properly if the reception condition is not good.

### Auto clock adjustment

The Auto clock adjustment will be performed at 12:00 PM everyday if you turn off the unit.

- If you use a cable box and you want Auto Clock adjustment to be performed, the cable box must be left on.
- The Auto Clock adjustment is not effective when there is a difference of more than 5 minutes exists between the built-in clock time and the actual time.


### To set auto clock to OFF

When shipped from factory the AUTO CLOCK is set to "ON". But if you do not want auto clock set (Adjustment):


#### 1 Press **MENU**, then press **◀** or **▶** to select option.



#### 2 Press **▲** or **▼** to select "AUTO CLOCK".



#### 3 Press **◀** or **▶** to select "OFF".




#### 4 Press **MENU** repeatedly until the menu screen is cleared.



- When the AUTO CLOCK is set to "OFF", the Auto Clock adjustment does not function.
- Set the clock manually [22].

#### Notes:

- If the unit does not operate properly, or No key operation (by the unit and/or the remote control): Static electricity, etc., may affect the player's operation. Disconnect the AC power cord once, then connect it again.
- The TV section has its own menu and also DVD section has its own menu [57].
- If no buttons are pressed for more than 60 seconds, the TV/VCR menu screen will return to normal TV operation automatically.



## To set standard time

In the rare event that you live within broadcast range of two stations in two different time zones, the unit may recognize the wrong station for the auto clock set.

To correct the situation:

- 1** Press MENU, then press ◀ or ▶ to select option.
 

CLOCK SET  
 ON/OFF TIMER  
 AUTO CLOCK  
 STANDARD TIME  
 DAYLIGHT  
 SAVING TIME

▶ ON  
 ▶  
 ▶  
 ▶  
 ▶

▲/▼/◀/▶/MENU
- 2** Press ▲ or ▼ to select “STANDARD TIME”, then press ▶.
 

CLOCK SET  
 ON/OFF TIMER  
 AUTO CLOCK  
 STANDARD TIME  
 DAYLIGHT  
 SAVING TIME

▶ ON  
 ▶  
 ▶  
 ▶  
 ▶

▲/▼/◀/▶/MENU
- 3** Press ▲/▼/◀/▶ to select your time zone, then press ENTER.
 

ATLANTIC : GMT-4hours  
 EASTERN : GMT-5hours  
 CENTRAL : GMT-6hours  
 MOUNTAIN : GMT-7hours  
 PACIFIC : GMT-8hours  
 ALASKA : GMT-9hours  
 HAWAII : GMT-10hours  
 AUTO : AUTO SET  
 (GMT: Greenwich Mean Time)
- 4** Press MENU repeatedly until the menu screen is cleared.

### Note:

To be able to select the standard time, the clock must first be set by “AUTO CLOCK” once.

## To set daylight saving time

You can set the daylight saving time automatically or manually.

- 1** Press MENU, then press ◀ or ▶ to select option.
 

CLOCK SET  
 ON/OFF TIMER  
 AUTO CLOCK  
 STANDARD TIME  
 DAYLIGHT  
 SAVING TIME

▶ ON  
 ▶  
 ▶  
 ▶  
 ▶

▲/▼/◀/▶/MENU
- 2** Press ▲ or ▼ to select “DAYLIGHT SAVING TIME”, then press ▶.
 

CLOCK SET  
 ON/OFF TIMER  
 AUTO CLOCK  
 STANDARD TIME  
 DAYLIGHT  
 SAVING TIME

▶ ON  
 ▶  
 ▶  
 ▶  
 ▶

▲/▼/◀/▶/MENU
- 3** Press ▲ or ▼ to select one of the options, then press ENTER.
 

DAYLIGHT SAVING TIME  
  
 ON  
 OFF  
 AUTO

▶  
 ▶  
 ▶

▲/▼/ENTER/MENU

**ON:** for manual setting (forward one hour)

**OFF:** for manual setting (back one hour)


**AUTO:** for automatic setting (read EDS in the signal)

When you want to set the daylight saving time manually, on the first Sunday in April you set to “ON”, and on the last Sunday in October you set to “OFF”.
- 4** Press MENU repeatedly until the menu screen is cleared.

### Notes:

- When shipped from factory, the DAYLIGHT SAVING TIME is set to “AUTO” position.
- When the clock is not set, daylight saving time setting is not available.
- When there is no daylight saving time in your area, always select “OFF” position in step 3.

## Clock setting (Continued)



### Manual clock setting


You must set the date and time manually for timer recordings, ON/OFF timer and daylight saving time if the auto clock process did not set them correctly.

**EXAMPLE:** Setting the clock to "8:30 AM", 26th. (SAT) March, 2005.


**1** Press MENU, then press ◀ or ▶ to select



**2** Press ▲ or ▼ to select "CLOCK SET", then press ▶.



**3** Press ◀ or ▶ to set the month, then press ▼.



**4** Set the day, year and time as in step 3, then press ENTER.



**5** After setting the clock, date and time starts functioning automatically.

8:30 AM SAT

#### ■ To make corrections any time during the process


Press ▲ or ▼ repeatedly until the item you want to change blinks, then set the item again.

#### Notes:

- After a power failure or disconnection of the power, the timer settings will be lost. In this case, reset the present time.
- When you set the minute, you can change in 10-minutes step by holding down ◀ or ▶.



## Setting the language/ TV/VCR operation status




### Setting the language

This unit can display the on screen language in English, Spanish or French.


- 1 Press **MENU**, then press **◀** or **▶** to select option.



- 2 Press **▲** or **▼** to select "LANGUAGE/IDIOMA/LANGUE", then press **▶**.



- 3 Press **▲** or **▼** to select the desired language: English (ENGLISH), Spanish (ESPAÑOL) or French (FRANCAIS), then press **ENTER**.




- 4 Press **MENU** repeatedly until the menu screen is cleared.




### TV/VCR operation status

Press **DISPLAY** to display the information on the screen. To cancel the display, press **DISPLAY** again.

#### While watching TV



#### While operating a tape



Basic setup


# TV operation

## TV operation

- 1 To turn on the unit, press POWER.**  
The Power indicator will light.
- Every time you turn on the TV, the unit starts from TV/VCR mode. When you use TV/VCR after DVD operation, press **TV/VCR**.



- 2 Adjust the volume level by pressing VOL + or -.**  
The volume level will be indicated on the screen by green bars. As the volume level increases, so do the number of bars. If the volume decreases, the number of green bars also decreases.




- 3 Set the TV/CABLE selection to the appropriate position [27].**

TV - VHF/UHF channels  
CABLE - Cable TV channels

- 4 Press Direct channel selection buttons (0-9) to select the channel.**

### TV mode direct channel selection

When the TV/CABLE selection is in the TV position, all channels can be instantly selected by using two buttons. (for example, to select channel 2, press "0", then "2". If you press only "2", channel selection will be delayed for a few seconds.) For channels 10 and above, press the 2 digits in order.



### CABLE mode direct channel selection

When the TV/CABLE selection is in the CABLE position, channels can be selected as follows:  
TO SELECT CABLE TV CHANNELS:

- 1-9: Press "0" twice, then 1-9 as needed.  
Example, to select channel 2, press "002".  
10-12: Press "0", then the remaining 2 digits.  
Example, to select channel 12, press "012".  
13-99: Press the 2 digits in order. Example, to select channel 36, press "36".  
100-125: Press the 3 digits in order. Example, to select channel 120, press "120".


### NOTE FOR CHANNELS 1-12:

If only 1 or 2 buttons are pressed, the corresponding channel will be selected in 2 seconds.

| TV    | Cable TV    |
|-------|-------------|
| VHF   | VHF         |
| 2-13  | 2-13        |
| UHF   | STD/HRC/IRC |
| 14-69 | 14-36       |
|       | (A) (W)     |
|       | 37-59       |
|       | (AA) (WW)   |
|       | 60-85       |
|       | (AAA) (ZZZ) |
|       | 86-94       |
|       | (86) (94)   |
|       | 95-99       |
|       | (A-5) (A-1) |
|       | 100-125     |
|       | (100) (125) |
|       | 01          |
|       | (5A)        |



### Notes:

- If a channel with no broadcast is selected, the sound will automatically be muted.
- If a station being viewed stops broadcasting, the TV will automatically shut itself off after 15 minutes.




### ■ CHANNEL UP/DOWN

Press and release **CH**  $\wedge$  or  $\vee$ . The channel automatically stops at the next channel set into memory. For proper operation, before selecting channels, they should be set into the memory. See page 27 "To memorize channels".




### ■ CHANNEL RETURN

This button allows you to go back to the last channel selected by pressing **CH RTN**. Press **CH RTN** again to return to the last channel you were watching.




### ■ MUTE

Press **MUTE** to switch off the sound. The unit's sound will be silenced and "MUTE" will briefly appear on the screen. The sound can be switched back on by pressing this button again or one of **VOL +/-**.



### ■ SLEEP


To set the unit to turn off after a preset amount of time, press **SLEEP** on the remote control. The clock will count down 10 minutes for each press of **SLEEP** (120, 110, ...10, 0). After the sleep time is programmed, the display will appear briefly every ten minutes to remind you that the sleep timer is operating. To confirm the sleep timer setting, press **SLEEP** and the remaining time will be displayed for a few seconds. To cancel the sleep timer, press **SLEEP** repeatedly until the display turns to 0.



### ■ HEADPHONES

Insert a stereo headphones (not supplied) with a 1/8" mini plug into the PHONES jack on the front panel. If you connect headphones, the sound from TV speakers is muted.

\* Model MW27F51 has a door on the front panel. Please open it to access the PHONES jack and the AUDIO (L/R)/VIDEO IN (LINE IN 2) jacks.



TV operation

## Closed captions

### WHAT IS CLOSED CAPTIONING?

This television has the capability to decode and display closed captioned television programs. Closed captioning will display text on the screen for hearing impaired viewers or it will translate and display text in another language.



CLOSED CAPTION

## Closed captions

**Captions:** This closed caption mode will display text on the screen in English or another language (depending on the setting of the closed captions CH 1/2).


Generally, closed captions in English are transmitted on captions channel 1 and closed captions in other languages are transmitted on captions channel 2.

**Text:** The text closed caption mode will usually fill the screen with a programming schedule or other information. After selecting a closed caption mode, it will stay in effect until it is changed, even if the channel is changed. If the captions signal is lost due to a commercial or a break in the signal, the captions will reappear when the signal is received again. If the channels are changed, the captions will be delayed approximately 10 seconds. The captions will appear in places on the screen where they will least interfere with the picture, usually on the bottom of the screen. News programs will usually show three-line closed captions which scroll onto the screen. Most other shows provide two or three lined captions placed near the character who is speaking so the viewer can follow the dialogue. Words in italics or underlined describe titles, words in foreign languages or words requiring emphasis. Words that are sung usually appear enclosed by musical notes.

For television programs broadcasting with closed captions, look in your TV guide for the closed captions symbol (CC).

### TO VIEW CLOSED CAPTIONS

Press **CLOSED CAPTION** to switch between normal TV and the two closed caption modes (captions and full screen text). Closed captioning will display text on the screen for hearing impaired viewers.




### Notes:

- When selecting closed captions, the captioning will be delayed approximately 10 seconds.
- If no caption signal is received, no captions will appear, but the television will remain in the caption mode.
- Misspellings or unusual characters may occasionally appear during closed captioning. This is normal with closed captioning, especially with live programs. This is because during live programs, captions are also entered live. These transmissions do not allow time for editing.
- When captions are being displayed, on-screen displays, such as volume and mute may not be seen or may interfere with closed captions.
- Some cable systems and copy protection systems may interfere with the closed captioned signal.
- If using an indoor antenna or if TV reception is very poor, the closed caption decoder may not appear or may appear with strange characters or misspelled words. In this case, adjust the antenna for better reception or use an outdoor antenna.


## To memorize channels

This unit is equipped with a channel memory feature which allows channels to skip up or down to the next channel set into memory, skipping over unwanted channels. Before selecting channels, they must be programmed into the unit's memory. In addition to normal VHF and UHF channels, this unit can receive up to 113 cable TV channels. To use this unit with an antenna, set the TV/CABLE selection to the TV position. When shipped from the factory, this selection is in the CABLE position.




### TV/CABLE selection

- 1 Press MENU in the TV mode, then press ◀ or ▶ to select option.




- 2 Press ▲ or ▼ to select "TV/CABLE".



- 3 Press ◀ or ▶ to select "TV" or "CABLE".

TV - VHF/UHF channels  
CABLE - Cable TV channels



- 4 Press MENU repeatedly until the menu screen is cleared.



### Cable TV chart

The chart below is typical of many cable system channel allocations.

| Number on this TV | Corresponding Cable TV channel | 14  | 15  | 16  | 17  | 18  | 19  | 20  | 21  | 22  |
|-------------------|--------------------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 23                | 24                             | 25  | 26  | 27  | 28  | 29  | 30  | 31  | 32  | 33  |
| J                 | K                              | L   | M   | N   | O   | P   | Q   | R   | S   | T   |
| 41                | 42                             | 43  | 44  | 45  | 46  | 47  | 48  | 49  | 50  | 51  |
| EE                | FF                             | GG  | HH  | II  | JJ  | KK  | LL  | MM  | NN  | OO  |
| 59                | 60                             | 61  | 62  | 63  | 64  | 65  | 66  | 67  | 68  | 69  |
| WW                | AA                             | BB  | CC  | DD  | EE  | FF  | GG  | HH  | II  | JJ  |
| 77                | 78                             | 79  | 80  | 81  | 82  | 83  | 84  | 85  | 86  | 87  |
| RRR               | SSS                            | TTT | UUU | VVV | WWW | XXX | YYY | ZZZ | 88  | 89  |
| 95                | 96                             | 97  | 98  | 99  | 100 | 101 | 102 | 103 | 104 | 105 |
| A-5               | A-4                            | A-3 | A-2 | A-1 | 100 | 101 | 102 | 103 | 104 | 105 |
| 113               | 114                            | 115 | 116 | 117 | 118 | 119 | 120 | 121 | 122 | 123 |
| 113               | 114                            | 115 | 116 | 117 | 118 | 119 | 120 | 121 | 122 | 123 |

### Automatic memory tuning

- Press ▲ or ▼ to select the "AUTO CH MEMORY", then press ▶.

The TV will begin memorizing all the channels available in your area.




### To ADD/DELETE channels


- 1 Press ▲ or ▼ to select "ADD/DELETE", then press ▶.



- 2 Select the desired channel to be added or deleted using Direct channel selection buttons (0-9) or ▲/▼.



- 3 Press ◀ or ▶ to select "ADD" or "DELETE", whichever function you want to perform.



### Note:

You can not select option if you set the channel to "LINE1" or "LINE2".

TV operation

## Setting the V-Chip


An age limitation can be set to forbid children to watch programs according to “TV RATING” and “MOVIE RATING” level set. To use the V-Chip function, you must register a password.

### Notes:


- If you forget the password, you cannot set the V-Chip.
- To avoid forgetting the password, write it down and keep in the safe place.

### To register password

- 1** Press MENU, then press ◀ or ▶ to select option.





- 2** Press ▲ or ▼ to select “PASSWORD”.



- 3** Enter the password (4 digits) using Number buttons (0–9), then press ENTER.


- If you put a wrong number, press CANCEL.




“\*” appears instead of the number.



- 4** Enter the same password again using Number buttons (0–9) for safety, then press ENTER.




Now the password was registered and V-Chip setting menu will appear on the display.





### To change password



- 1** In the V-CHIP menu, press ▲ or ▼ to select “CHANGE PASSWORD”, then press ▶.



- 2** Enter the new password using Number buttons (0–9), then press ENTER.




- 3** Enter the same password again using Number buttons (0–9) for safety, then press ENTER.




- 4** Press MENU repeatedly until the menu screen is cleared.






## To set the V-Chip

- 1** In the V-CHIP menu, press ▲ or ▼ to select “V-CHIP SET”, then press ►.



- 2** Press ▲ or ▼ to select “TV RATING”, then press ◀ or ▶ to display the desired setting. After setting, press ENTER.


**OFF** : TV RATING is not set  
**TV-Y** : All children  
**TV-Y7** : 7 years old and above  
**TV-G** : General audience  
**TV-PG** : Parental guidance  
**TV-14** : 14 years old and above  
**TV-MA** : 17 years old and above




When you select TV-Y7, TV-PG, TV-14 or TV-MA, press **DISPLAY** to show the contained rating. Press ▲/▼/◀/▶ to select the desired item you want.



- 3** Press ▲ or ▼ to select “MOVIE RATING”.




- 4** Press ◀ or ▶ to select desired rating. After setting, press ENTER.




**OFF** : MOVIE RATING is not set  
**G** : All ages  
**PG** : Parental guidance  
**PG-13** : Parental guidance less than 13 years old  
**R** : Under 17 years old  
**NC-17** : 17 years old and above  
**X** : Adult only

- 5** Press ▲ or ▼ to select “V-CHIP”.



- 6** Press ◀ or ▶ to display “ON”. Now your settings were set into the memory.



- 7** Press MENU repeatedly until the menu screen is cleared.



### To use after the TV is protected

When the program applied to the V-Chip setting is received, enter the password, then press **ENTER**. Protection can be canceled.


#### Note:

The V-Chip function is activated only on programs that have the rating signal.

TV operation

## To set the on timer

This feature allows you to have the unit automatically turn on at a predetermined time. If you program the ON TIMER once, the unit will turn on the programmed day (daily/weekly) at the same time to the same channel.




### To set the on timer

**EXAMPLE:** Turning on the TV to channel 12 at 7:00 AM, MONDAY-FRIDAY.


- 1** Press **MENU**. Press **◀** or **▶** to select **⌚** option.  
You can also select ON/OFF TIMER by pressing **PROGRAM** twice.




- 2** Press **▲** or **▼** to select **"ON/OFF TIMER"**, then press **▶**.




- 3** Press **▲** or **▼** to select **"ON TIMER"**, then press **▶**.



- 4** Press **◀** or **▶** to set the desired hour, then press **▼**.




- 5** Set the desired minute, channel and daily or weekly timer date as in step 4.



- 6** Press **◀** or **▶** to select **"SET"**, then press **ENTER**.

Now the ON TIMER is set.



- 7** Press **MENU** repeatedly until the menu screen is cleared.




#### Notes:

- The unit will automatically turn off approximately 1 hour later after the ON TIMER turns on if no OFF TIMER has been set. To continue watching the TV, press any button to cancel the one hour automatic shut off.
- To cancel the ON TIMER, follow above steps 1~5, then press **◀** or **▶** to select **"CANCEL"**. Press **MENU** repeatedly until the menu screen is cleared.
- After setting the ON TIMER, **"▶ OFF TIMER"** will be highlighted. If you wish to set the OFF TIMER, press **▶** then follow the steps 4~6 on page 31.
- If you want to correct the digits while setting, press **▲** or **▼** until the item you want to correct, then press **◀** or **▶** to correct the desired setting.



## To set the off timer


This feature allows you to have the unit turn off automatically at a predetermined time. If you program the OFF TIMER once, the unit will automatically turn off at the same time everyday.




### To set the off timer

**EXAMPLE:** Turning off the TV at 11:30 PM.


- 1** Press **MENU**. Press **◀** or **▶** to select option. You can also select ON/OFF TIMER by pressing **PROGRAM** twice.




- 2** Press **▲** or **▼** to select "ON/OFF TIMER", then press **▶**.




- 3** Press **▲** or **▼** to select "OFF TIMER", then press **▶**.




- 4** Press **◀** or **▶** to set the desired hour, then press **▼**.



- 5** Press **◀** or **▶** to set the desired minute, then press **▼**.



- 6** Press **◀** or **▶** to select "SET". Now the OFF TIMER is set.



- 7** Press **MENU** repeatedly until the menu screen is cleared.



#### Notes:


- To cancel the OFF TIMER function:**  
To cancel OFF TIMER, follow above steps 1~5, press **◀** or **▶** to select "CANCEL". Press **MENU** repeatedly until the menu screen is cleared.
- To confirm the ON/OFF TIMER:**  
Press **PROGRAM** twice to indicate the programs on the screen.

TV operation

## Picture control adjustment/ Adjusting the picture preference


Picture controls are factory preset but you can adjust them individually as follows:

And also you can select four picture modes—Standard, Sports, Movie, and Memory—as described in the following table:




### Picture control adjustment


- 1** Press MENU, then press ◀ or ▶ to select option.



- 2** Press ▲ or ▼ to select “PICTURE”, then press ▶.



- 3** Press ▲ or ▼ to select the item you want to adjust, then press ◀ or ▶ to adjust the setting.



#### Selection

#### ◀ Pressing ▶

|                   |         |          |
|-------------------|---------|----------|
| <b>BRIGHTNESS</b> | darker  | lighter  |
| <b>CONTRAST</b>   | lower   | higher   |
| <b>COLOR</b>      | paler   | deeper   |
| <b>TINT</b>       | reddish | greenish |
| <b>SHARPNESS</b>  | softer  | sharper  |

#### Note:

The CONTRAST default setting is set to maximum (+32) at the factory.


- 4** After your desired setting press MENU repeatedly until the menu screen is cleared.



■ To return all adjustments to the factory preset levels  
Press **CANCEL** while making picture adjustments.

### Adjusting the picture preference

- 1** Press MENU, then press ◀ or ▶ to select option.



- 2** Press ▲ or ▼ to select “PICTURE PREFERENCE”, then press ▶.



- 3** Press ▲ or ▼ to select the desired picture mode, then press ENTER.



#### Mode Picture quality


|                 |                                                                                  |
|-----------------|----------------------------------------------------------------------------------|
| <b>STANDARD</b> | Standard picture quality (factory-set)                                           |
| <b>SPORTS</b>   | Bright and dynamic picture (factory-set)                                         |
| <b>MOVIE</b>    | Movie-like picture (factory-set)                                                 |
| <b>MEMORY</b>   | Your personal preferences (set by you; see “Picture control adjustment” as left) |

- 4** After your desired setting press MENU repeatedly until the menu screen is cleared.




## Sound control adjustment/ Stereo and Second Audio Program (SAP)

Sound controls are factory preset but you can adjust them individually as follows:  
The unit is equipped with a feature known as multi-channel TV sound or MTS.  
MTS broadcasts greatly enhance TV viewing by bringing you programs with high fidelity stereo sound.  
MTS also provides an extra channel called the Second Audio Program or SAP which broadcasters can use to transmit a second language for bilingual transmission or for other purposes.




### Sound control adjustment

- 1** Press MENU, then press ◀ or ▶ to select option.



- 2** Press ▲ or ▼ to select "AUDIO", then press ▶.



- 3** Press ▲ or ▼ to select the item you want to adjust, then press ◀ or ▶ to adjust the setting.



- BASS:** Press ◀ or ▶ to adjust the bass sound.  
**TREBLE:** Press ◀ or ▶ to adjust the treble sound.  
**BALANCE:** Press ◀ or ▶ to obtain an equal sound level from both speakers.  
**SURROUND:** Press ◀ or ▶ to select "ON" or "OFF".  
ON: The dynamic presence and sound created offers a thoroughly enjoyable listening experience.  
OFF: Normal sound.  
**STABLE SOUND:** Press ◀ or ▶ to select "ON" or "OFF".  
ON: The Stable Sound feature limits the highest volume level to prevent extreme changes in volume when the signal source is changed.  
OFF: Normal sound.  
**SAP:** Press ◀ or ▶ to select "ON" or "OFF".  
ON: SAP is available.  
OFF: SAP is not available.

- 4** After your desired setting press MENU repeatedly until the menu screen is cleared.




- To return BASS/TREBLE/BALANCE control adjustments to the factory preset levels

Press CANCEL while making sound adjustments.

### Listening to stereo sound

When the TV is turned on or a channel selection is made, make certain the "STEREO" appears on the screen. This means that Stereo broadcasting is available. You can enjoy stereo sound from the left and right speakers.

- When mono broadcasting is received, no indication is displayed.
- If the broadcast signal is not strong enough or clear stereo sound is not available, press **AUDIO SELECT** to change to mono sound. The noise should be eliminated. Press it again to return to the stereo sound.




### Listening to SAP (Second Audio Program)

When the TV is turned on or a channel selection is made, make certain the SAP appears on the screen. This means that the Second Audio Program broadcasting is available.



### To select desired sound

Press **AUDIO SELECT** to select the desired sound.



| Broadcast  | SAP setting | Audio display |
|------------|-------------|---------------|
| MONO       | OFF         | MONO          |
|            | ON          | MONO          |
| STEREO     | OFF         | STEREO ↔ MONO |
|            | ON          | STEREO ↔ MONO |
| MONO+SAP   | OFF         | MONO          |
|            | ON          | SAP           |
| STEREO+SAP | OFF         | STEREO ↔ MONO |
|            | ON          | SAP           |

TV operation

## Loading and unloading a cassette tape


Use only video cassette tapes marked **VHS**.

### Loading


Push the center of the tape until it is automatically inserted.



Insert the cassette tape with its labeled side facing up and the erase prevention tab positioned at your left. An inverted cassette tape cannot be inserted.



Erase prevention tab



#### Automatic power ON

When you insert a cassette tape the unit power will turn ON automatically.

#### Automatic playback


When loading a cassette tape without an erase prevention tab, playback will start automatically.

### Unloading


- 1 Press **STOP/EJECT** on the front panel or **EJECT** on the remote control.



or



- 2 Remove the cassette tape.



#### Automatic tape eject

This unit will automatically rewind the tape when the tape has ended. And when the tape is rewinded to its beginning, the cassette tape will be ejected automatically.


#### Notes:

- Always eject the tape when not in use.
- The cassette tape can be ejected even if the POWER is "OFF".

### To prevent accidental erasure


#### To prevent accidental erasure

Remove the erase prevention tab with a screwdriver.



#### To record again

Cover the hole with a piece of adhesive tape.





### Tape speed and maximum recording time

| Tape Speed            | Video cassette tape |         |             |         |             |
|-----------------------|---------------------|---------|-------------|---------|-------------|
|                       | T-160               | T-120   | T-90        | T-60    | T-30        |
| SP (Standard Play)    | 2-2/3 hours         | 2 hours | 1-1/2 hours | 1 hour  | 30 minutes  |
| SLP (Super Long Play) | 8 hours             | 6 hours | 4-1/2 hours | 3 hours | 1-1/2 hours |



## Cassette tape playback

To play a prerecorded tape.



### Playback

#### 1 Load a prerecorded tape:


(When loading a cassette tape without the erase prevention tab, playback will start automatically).



#### 2 To start playback:

Press **PLAY** on the front panel or on the remote.  
Playback will start. "▶" will appear on the screen for about 4 seconds.

PLAY



#### To stop playback:

Press **STOP/EJECT** once on the front panel or press **STOP** on the remote.  
The tape will stop but remain fully loaded and ready to play.  
"■" will appear on the screen for about 4 seconds.

STOP/EJECT



### Rewind or forward the tape

Stop the playback or recording with **STOP**.

#### To rewind the tape:

Press **REW** on the front panel or press **REV** on the remote.



#### To forward the tape:

Press **FF** on the front panel or press **FF** on the remote.



To stop the tape-winding, press **STOP**. To switch to playback directly (without **STOP**), press **PLAY**.

#### ■ Forward/Reverse picture search mode


When the tape is being winded, you can switch to picture search mode (see next page). To do this, press **REV** or **FF** again and hold it down. The unit will resume the tape winding as soon as the button is released.

Playback (VCR)

#### Notes:

- If you play a prerecorded tape after the DVD playback, you must set the unit to TV/VCR mode using the TV/VCR button.
- This unit selects the playback tape speed SP or SLP automatically.
- When you select the TV/VCR mode during DVD playback, DVD playback will change to the still mode, and after 5 minutes it will change to the resuming playback mode automatically.

## Special playback



### Picture search

#### Reverse picture search function

Press **REV** once or twice during the playback.

#### Forward picture search function

Press **FF** once or twice during the playback.

To return to playback, press **PLAY**.

#### SPEED SEARCH TIMES

| TAPE SPEED            | PICTURE SEARCH SPEED |             |
|-----------------------|----------------------|-------------|
|                       | PRESS ONCE           | PRESS TWICE |
| SP (Standard Play)    | 3 X                  | 5 X         |
| SLP (Super Long Play) | 9 X                  | 15 X        |

### Still picture

Press **PAUSE/STILL** during playback.

To resume normal playback, press **PLAY** or **PAUSE/STILL**.

If the still picture jitters excessively, press **TRK + / -** to stabilize the still picture.

### Slow motion

During playback press **SLOW**.

To return to playback, press **PLAY** or **SLOW**.

#### ■ Slow tracking and vertical lock adjustment

If noise bars appear in the picture during slow motion, press the **TRK + / -** to reduce the noise bars.

### Frame by frame picture

Press **PAUSE/STILL** during playback.

Press **SLOW** one by one: The picture advances frame by frame.

To return to playback, press **PLAY** or **PAUSE/STILL**.

### CM skip

Press **CM SKIP** during playback. The unit will search forward through approximately 30 seconds of the tape (e.g. unwanted commercial time) for each press of **CM SKIP** (maximum six presses) and then resume normal playback.

For example : 1 press: 30 seconds of tape



2 press: 60 seconds of tape

3 press: 90 seconds of tape

### Digital tracking controls

When a tape is played, the Digital Auto Tracking system automatically adjusts the tracking to obtain the best possible picture. If noise bars appear during playback, adjust the tracking manually as follows:


- Press **TRK + / -** to obtain the best possible picture. "MANUAL TRACK" will appear for 4 seconds on the screen. To resume automatic tracking, press **D.TRACKING**. "DIGITAL TRACK" will appear for 4 seconds on the screen.



#### Notes:

- "SP" is more appropriate as less noise appeared during search and still playback for tape recorded in SP.
- The audio output is muted during PICTURE SEARCH, STILL, FRAME ADVANCE and SLOW MOTION.
- During picture search mode there will be noise bars which are caused by the system.
- The Special Playback will automatically change to playback after approx. 5 minutes to protect the video tape against excessive wear.


## Convenient function




### Repeat playback

The entire video tape will be played until its end. The tape will automatically rewind to the beginning and the playback will be repeated.

#### 1 Press MENU, then press ◀ or ▶ to select option.



#### 2 Press ▲ or ▼ to select "AUTO REPEAT".



#### 3 Press ◀ or ▶ to select "ON" or "OFF".

If "ON" is selected, the playback will be repeated endlessly.



#### 4 Press MENU repeatedly until the menu screen is cleared.

If you press **DISPLAY**, "23" will appear on the screen .

#### 5 To start the playback, press **PLAY**.

The playback will be repeated endlessly.

#### ■ To cancel repeat mode:

In step 3 above, press ◀ or ▶ to select "OFF" position. Press **MENU** repeatedly until the menu screen is cleared. The repeat function is canceled automatically when the unit is switched off.

### Using the real time tape counter

The on-screen real time tape counter shows the tape running time in hours, minutes and seconds. You can easily determine how long the tape has been running or how much time is left on the tape.

#### 1 Press **DISPLAY**.



#### 2 Press **COUNTER RESET** to set the counter to "00:00:00".



#### 3 Begin Playback or Recording to start the tape, the counter will display the elapsed time.




#### 4 When you wish to make the counter disappear, press **DISPLAY** once again.



Playback (VCR)


## Convenient function (Continued)




### Zero return function

The zero return function provides a convenient method of rapidly returning to the starting point of recording or playback. The starting point can be indexed for any location on the tape by pressing COUNTER RESET and ZERO RETURN.

#### 1 Press DISPLAY.




#### 2 Before playback or recording, press COUNTER RESET to set the counter to "00:00:00".




#### 3 Begin playback or recording.



#### 4 Press STOP.



#### 5 Press ZERO RETURN. The tape will rewind and automatically stop at the "00:00:00" position.



### Video head cleaning

#### Video head clogging

The video heads are the means by which the unit reads the picture from the tape during playback. In the unlikely event that the heads become dirty enough to be clogged, no picture will be played back. This can easily be determined if, during playback of a known good tape, there is good sound, but no picture (picture is extremely snowy). If this is the case, have the unit checked by qualified service personnel.



Good Picture



Snowy Picture

#### Video head cleaning


Video head cleaning is needed when the playback picture becomes unclear. This signifies that the heads are getting dirty and can occur when playing poor quality or damaged tapes. If the heads require cleaning, use an equivalent high quality chemical non-abrasive (wet) head cleaning tape or have them cleaned professionally. If playing a head cleaning tape in the unit once does not improve the picture, play it several times before requesting service.

#### Notes:

- DO NOT ATTEMPT TO CLEAN THE VIDEO HEADS OR SERVICE THE UNIT BY REMOVING THE REAR COVER.
- Video heads may eventually wear out and should be replaced when they fail to produce clear pictures.
- To help prevent video head clogging, use only good quality VHS tapes. Discard worn out tapes.

## Recording a TV program

Recording and viewing the same TV program.



### Recording a TV program

- 1** Load a cassette tape with the erase prevention tab intact.



The unit will automatically turn on.

- 2** Press **SPEED** to select the desired tape speed SP or SLP.

The tape counter and SP or SLP will appear on the screen for about 4 seconds.





00:00:00 SP

- 3** Select "TV" or "CABLE" to the appropriate position **[27]**.

TV - VHF/UHF channels  
CABLE - Cable TV channels

- 4** Press Direct channel selection (0-9) or CH ^/v to select the channel to be recorded.



CH 110

- 5** Press **REC**.

"●" will appear on the screen for about 4 seconds and the REC/OTR indicator on the front panel will light.



CH 110

#### Notes:

- If power is switched off during recording, the TV and the DVD sections go off and the VCR continues to record. Press the STOP button to halt the recording and turn off the VCR.
- The unit channel cannot be changed during recording.
- If you record the TV program after the DVD playback, you must set the unit to TV/VCR mode using the TV/VCR button.

### To stop recording

Press **STOP** to stop recording.

"■" will appear on screen for about 4 seconds.



### To stop recording temporarily

Press **PAUSE/STILL** to avoid recording unwanted material.

"||" will appear on the screen and the REC/OTR indicator will blink on and off. Press **PAUSE/STILL** or **REC** to continue the recording.



CH 110

#### Note:

The pause function will be released after 5 minutes to prevent damage to the tape or the unit. The unit will change to the STOP mode.

#### ■ Auto Rewind feature

This VCR will automatically rewind the tape when the tape has ended (except during OTR and timer recording). It will also eject the tape.


#### Note:

If the erase prevention tab is removed, the tape will eject when REC button is pressed for recording.

Recording (VCR)

## One-touch Timer Recording (OTR)

The One-touch timer recording feature provides a simple and convenient way to make a timed recording.



### One-touch timer recording (OTR)

**Example:** One-touch timer recording for 30 minutes.


- 1** Load a cassette tape with the erase prevention tab intact.



The unit will automatically turn on.

- 2** Press **SPEED** to select the desired tape speed SP or SLP.



The tape counter and SP or SLP will appear on the screen for about 4 seconds.



- 3** Set "TV" or "CABLE" option to the appropriate position **[27]**.


TV - VHF/UHF channels  
CABLE - Cable TV channels

- 4** Press Direct channel selection (0-9) or CH ^/v to select the channel to be recorded.




- 5** Press **REC** to begin recording. Press the button again to stop recording after 30 minutes. Each additional press of **REC** will increase recording time as shown below, up to a maximum of 6 hours. "OTR" will appear on the screen.

| Press   | Recording time | Press    | Recording time |
|---------|----------------|----------|----------------|
| once    | NORMAL REC     | 6 times  | 3:00           |
| twice   | 0:30           | 7 times  | 4:00           |
| 3 times | 1:00           | 8 times  | 5:00           |
| 4 times | 1:30           | 9 times  | 6:00           |
| 5 times | 2:00           | 10 times | NORMAL REC     |



### To cancel OTR

Press **STOP**.




"■" will appear on screen for about 4 seconds.

#### Notes:

- If you wish to watch the DVD playback during the recording or the OTR, press **DVD** to change to DVD mode and perform the DVD playback **[45]**.
- The channel cannot be changed during recording.

## Timer recording

Timer recording can be programmed on-screen with the remote control. The built-in timer allows automatic unattended recording of up to 8 programs within 1 month.



### Timer recording


#### Preparation:

- Press **TV/VCR** to select the TV/VCR mode.
- Load a cassette tape with the erase prevention tab intact.
- Check the time and date are correct [22].


#### Example:

Program a timer recording for 23rd day, channel 125 (Cable TV), 7:00 - 9:30 PM (Tape speed : SLP).


#### 1 Press MENU, then press ◀ or ▶ to select option.



#### 2 Press ▲ or ▼ to select "TIMER REC SET", then press ▶.




#### 3 Press ▲ or ▼ to select one of the program line, then press ENTER.



#### 4 Press ◀ or ▶ to select the date, then press ▼.



#### 5 Set the start time, end time, channel and tape speed as in step 4. Then press ENTER.




#### Notes:

- Press ▲ to move cursor backward for correction.
- To record from external source set the channel to "L1" or "L2".

#### 6 To set the timer for another program, repeat steps 3 to 5 to set another program.

#### 7 Press TIMER REC. The TIMER REC indicator will light. The Timer is programmed, when the programmed time is reached, the recording is automatically started.




#### Notes:

- The VCR section cannot be used while the TIMER REC indicator is lit. If you want to use the VCR operation, press **TIMER REC** to deactivate the timer.
- When the clock is not set, you cannot select "TIMER REC". In this case, set the clock (see pages 20~22).
- After a power failure or disconnection of the power plug, all programmed recording setting and time display will be lost upon resumption of power. In this case, reset the clock (see pages 20~22) and reprogram any timer recordings.
- If you want to correct the digits while setting, press ▲ or ▼ until the item you want to correct, then press ◀ or ▶ to correct the desired setting.
- If programming is performed without a tape in the unit, or with a tape without an erase prevention tab, the Timer Recording is not possible. If a tape without an erase prevention tab is in the unit, the tape will be ejected.

Recording (VCR)

## Timer recording (Continued)



### To set daily/weekly timer

**Weekly (e.g. WKL-TUE: each Tuesday) or daily (e.g. MON-SAT: Monday to Saturday) Timer recording**

Follow the procedure of timer recording on the previous page. At picture 4 press ◀ or ▶ repeatedly until the desired setting appears. Then press **ENTER**.

When you press ◀ repeatedly, the indicator at DATE will change as follows, in this case the day is Friday.

The current day (Friday) → SUN-SAT (Sunday to Saturday)

↑  
One month later  
minus one day  
↑

WKL-WED  
(Weekly Wednesday)

↓  
MON-SAT (Monday to Saturday)

↓  
MON-FRI (Monday to Friday)

↓  
WKL-THU (Weekly Thursday)



### To confirm the settings

Press **PROGRAM** once. The TV screen displays the timer program list. Press **PROGRAM** again. The TV screen displays the ON/OFF timer setting.



Press **PROGRAM** 3 times. The menu screen is cleared.

(once)

|       |         |         |         |
|-------|---------|---------|---------|
| 23 TH | 7:00 PM | 9:30 PM | 125 SLP |
| ---   | ---     | ---     | ---     |
| ---   | ---     | ---     | ---     |
| ---   | ---     | ---     | ---     |
| ---   | ---     | ---     | ---     |
| ---   | ---     | ---     | ---     |
| ---   | ---     | ---     | ---     |
| ---   | ---     | ---     | ---     |
| ---   | ---     | ---     | ---     |
| ---   | ---     | ---     | ---     |

▲/▼/ENTER/CANCEL/MENU

(twice)

|           |        |
|-----------|--------|
| ON TIMER  |        |
| 12:00 AM  |        |
| CH 001    |        |
| SUN-SAT   | CANCEL |
| OFF TIMER |        |
| 12:00 AM  | CANCEL |

▲/▼/▶/MENU

### To cancel a program

Press **PROGRAM** once. The TV screen displays the timer program list.

Press ▲ or ▼ to select the unnecessary program, and press **CANCEL** to cancel the program.



|       |          |          |         |
|-------|----------|----------|---------|
| 23 TH | 7:00 PM  | 9:30 PM  | 125 SLP |
| 24 WE | 8:00 PM  | 9:00 PM  | 120 SLP |
| 26 SA | 10:00 AM | 10:30 AM | 120 SLP |
| 26 SA | 7:00 PM  | 9:00 PM  | 007 SP  |
| 27 SU | 8:30 PM  | 9:00 PM  | 018 SP  |
| 28 MO | 6:00 PM  | 6:30 PM  | 001 SP  |
| 29 TU | 11:00 PM | 11:20 PM | 110 SP  |
| 31 WE | 7:30 PM  | 9:00 PM  | 125 SLP |

▲/▼/ENTER/CANCEL/MENU




|       |          |          |         |
|-------|----------|----------|---------|
| 23 TH | 7:00 PM  | 9:30 PM  | 125 SLP |
| 24 WE | 8:00 PM  | 9:00 PM  | 120 SLP |
| 26 SA | 10:00 AM | 10:30 AM | 120 SLP |
| ---   | ---      | ---      | ---     |
| ---   | ---      | ---      | ---     |
| 27 SU | 8:30 PM  | 9:00 PM  | 018 SP  |
| 28 MO | 6:00 PM  | 6:30 PM  | 001 SP  |
| 29 TU | 11:00 PM | 11:20 PM | 110 SP  |
| 31 WE | 7:30 PM  | 9:00 PM  | 125 SLP |

▲/▼/ENTER/MENU

### If the programs overlap another

Do not overlap timer programs as portions of the conflicting programs will be lost. The first recording time has priority over the next recording time as shown in the diagram below.




#### Notes:

- The daily/weekly recording can be made continuously until the recording is canceled or the tape reaches the end.
- During timer recording the automatic rewinding mechanism does not function.
- You can correct or cancel the programmed setting in program confirm mode.

## Duplicating a video tape

If you connect the unit to another VCR or Camcorder, you can duplicate a previously recorded tape. Make all connections before turning on the power.



### Duplicating a video tape

#### Preparation:

- Press **TV/VCR** to select the TV/VCR mode.
- Load a cassette tape with the erase prevention tab intact.
- Load a previously recorded tape into the playback VCR or Camcorder.


#### 1 Press **SPEED** to select the desired tape speed **SP** or **SLP**.



It is recommended that you set the Speed to the SP mode on the recording VCR for best results.

#### 2 Press **INPUT** once or twice to select **AUDIO/VIDEO** input position.

"LINE1" or "LINE2" will appear on the screen.



LINE1: on the rear panel  
LINE2: on the front panel

#### 3 Press **REC**.



#### 4 Press **PLAY** on the playback VCR or camcorder.

#### 5 Press **STOP** after duplicating a video tape.




#### Note:

Unauthorized recording of copyrighted television programs, films, video cassettes and other materials may infringe the rights of copyright owners and be contrary to copyright laws.


#### Connection with second video recorder

- Select "LINE1" on step 2.



#### Connection with Camcorder


- Select "LINE2" on step 2.



For duplicating a previously recorded tape from a camcorder, follow the camcorder manufacturer's instructions. A typical camcorder dubbing hookup is shown above.

## Recording a DVD/CD disc

You can record disc material in DVD, Audio CD, etc. onto a video tape with this unit.



### Duplicating a DVD or CD disc

#### Preparation:

- Press **TV/VCR** to select the TV/VCR mode.
- Load a cassette tape with the erase prevention tab intact.
- Load a DVD/CD disc.

#### 1 Press **SPEED** to select the desired tape speed **SP** or **SLP**.



#### 2 Press **DVD** to select the DVD mode.



#### 3 Press **PLAY** to start playback.



#### 4 Press **REC** to start recording.



The unit will change to the VCR mode automatically and the playback picture or sound will be duplicated on the video cassette tape.

#### 5 Press **STOP** if you finish recording.



If you wish to stop a DVD/CD disc, press **DVD** to change the DVD mode, then press **STOP**.

#### Notes:

- You may not record the beginning of the disc, so start to playback the disc, then start to record.
- You cannot record the disc with copy guard function. "DISC IS COPY PROTECTED" will show up on the TV screen for approx. 4 seconds.

## Playing a disc

This section shows you the basics on how to play a disc.

### CAUTION

Keep your fingers well clear of the disc tray as it is closing. Neglecting to do so may cause serious personal injury.




Illustration of MW27F51



## Basic playback

### Preparations:

- Insert the AC cord plug into a standard 120V 60Hz polarized AC outlet. If the AC cord plug is plugged in for the first time, you need to set "Starting setup" [19].
- When connecting to other equipment, turn power off.

### 1 Press POWER on the unit or on the remote control to turn on the unit.

The Power indicator will light.


- Every time you press **POWER**, the TV/VCR/DVD starts from TV mode.
- When using an amplifier, switch on the amplifier.

POWER



### 2 Press DVD to select DVD mode.

The DVD startup screen will appear on the screen. "Reading Disc" display will change to "No Disc". (If DVD disc has already loaded, playback will start automatically.)




### 3 Press OPEN/CLOSE.

The disc tray opens.

OPEN/CLOSE



### 4 Place the disc on the disc tray.



With the playback side down

- There are two different disc sizes. Place the disc in the correct guide on the disc tray. If the disc is out of the guide, it may damage the disc and cause the unit to malfunction.
- Do not place a disc which is unplayable on the disc tray.

### 5 Press OPEN/CLOSE or PLAY.

OPEN/CLOSE



OR

PLAY



The disc tray closes automatically. On the TV-screen, "▲" changes to "Reading Disc" and then playback commences.



- A menu screen will appear on the TV screen, if the disc has a menu feature. Press ▲/▼ or ◀/▶ to select title, then press **ENTER**. Title is selected and play commences.

### 6 Press STOP to end playback.



#### ■ Resuming facility

- The unit records the stopped point, depending on the disc. "■" appears on the screen. Press **PLAY** to resume playback (from the scene point).
- If you press **STOP** again or unload the disc ("■" appears on the screen.), the unit will clear the stopped point.

#### ■ To start playback in the stop mode

Press **PLAY**.



#### Note:

#### If the unit does not operate properly:

Static electricity, etc., may affect the player's operation. Disconnect the AC power cord once, then connect it again.

## Playing a disc (Continued)

### Basic playback

#### ■ To pause playback (still mode)

Press **PAUSE** during playback.



To resume normal playback, press **PLAY**.

- The sound is muted during still mode.

#### ■ To stop playback

Press **STOP**.




#### ■ To remove the disc

Press **OPEN/CLOSE**.



Remove the disc after the disc tray opens completely.



Be sure to press **OPEN/CLOSE** to close the disc tray after you remove the disc.

#### Notes:

- If a non-compatible disc is loaded, "Incorrect Disc", "Region Code Error" or "Parental Error" will appear on the TV screen according to the type of loaded disc. In this case, check your disc again (see pages 9 and 61).
- Some discs may take a minute or so to start playback.
- When you set a single-faced disc label downwards (ie. the wrong way up) and press **OPEN/CLOSE** or **PLAY** on the unit, "Reading Disc" will appear on the display for a few minutes and then "Incorrect Disc" will continue to be displayed.
- Some discs may not work the resuming facility.
- Resuming cannot function when you play a PBC-featured Video CD while the PBC is on. To turn off the PBC, see page 53.
- Some playback operations of DVDs may be intentionally fixed by software producers. Since this unit plays DVDs according to the disc contents the software producers designed, some playback features may not be available. Also refer to the instructions supplied with the DVDs.
- Do not move the unit during playback. Doing so may damage the disc.
- Use **OPEN/CLOSE** to open and close the disc tray. Do not push the disc tray while it is moving. Doing so may cause the unit to malfunction.
- Do not push up on the disc tray or put any objects other than discs on the disc tray. Doing so may cause the unit to malfunction.
- In many instances, a menu screen will appear after playback of a movie is completed. Prolonged display of an on-screen menu may damage your television set, permanently etching that image onto its screen. To avoid this, be sure to press **POWER** on your remote control once the movie is completed.
- There may be a slight delay between you pressing the button and the function activating.
- If the Media card is inserted during the playback, playback will stop and change to the CARD mode automatically. If you wish to change to the DVD mode, press **DVD/CARD**.

#### ■ To obtain a higher quality picture

Occasionally, some picture noise not usually visible during a normal broadcast may appear on the TV screen while playing a DVD video disc because the high resolution pictures on these discs include a lot of information. While the amount of noise depends on the TV you use with this unit, you should generally reduce the sharpness adjustment on your TV when viewing DVD video discs.

#### ■ About


The     icons on the heading bar show the playable discs for the function described under that heading.

 : You can use this function with DVD video discs.

 : You can use this function with Video CDs.

 : You can use this function with Audio CDs and CD-R/RW CDs.

 : You can use this function with Media cards.



## Playing in fast reverse or fast forward directions

Press **REV** or **FF** during playback.



**REV:** Fast reverse playback  
**FF:** Fast forward playback

Each time you press **REV** or **FF**, the playback speed changes.

### ■ To resume normal playback

Press **PLAY**.



#### Notes:

- The TV/DVD mutes sound and subtitles during reverse and forward scan of DVD/VCD video discs. However, the TV/DVD plays sound during fast forward or fast reverse play of audio CDs.
- The playback speed may differ depending on the disc.



## Playing frame by frame

Press **PAUSE** during still playback.



Each time you press **PAUSE**, the picture advances one frame.

### ■ To resume normal playback

Press **PLAY**.



#### Note:

The sound is muted during frame by frame playback.



## Playing in slow-motion

Press **SLOW** during playback.



Each time you press the button, the slow-motion speed changes.

### ■ To resume normal playback

Press **PLAY**.



#### Note:

The sound is muted during slow-motion playback.



## Locating a chapter or track

Press **SKIP** **◀** or **▶** repeatedly to display the chapter or track number you want.

Playback starts from the selected chapter or track.



To locate succeeding chapters or tracks.



Playback starts from the beginning of the current chapter or track.  
When you press twice in quick successions, playback starts from the beginning of the preceding chapter or track.

#### Note:


Press and hold **SKIP** on the unit during playback to play forward or in reverse. Afterwards, each time you press and hold **SKIP**, the playback speed will change.

#### Notes:

- A prohibition symbol “” may appear at the upper left of the screen. This symbol means either the feature you tried is not available on the disc, or the TV/VCR/DVD cannot access the feature at this time. This does not indicate a problem with the TV/VCR/DVD.
- The unit is capable of holding a still video image or On screen display image on your television screen indefinitely. If you leave the still video image or On screen display image displayed on your TV for an extended period of time, you risk permanent damage to your television screen. Projection televisions are very susceptible.

Basic playback (DVD)

## Zooming/Locating desired scene



### DVD VCD CD Zooming

This unit will allow you to zoom in on the frame image. You can then make selections by switching the position of the frame.

#### 1 Press ZOOM during playback.



The center part of the image will be zoomed in. Each press of **ZOOM** will change the ZOOM Q1 (x 1.3), Q2 (x 1.5) and Q3 (x 2.0).

Q1

#### 2 Press ▲/▼/◀/▶ to view a different part of the frame.



You may move the frame from the center position to UP, DOWN, LEFT or RIGHT direction.

#### 3 In the zoom mode press ZOOM repeatedly to return to a 1:1 view (Q Off).



#### Notes:

- You can select the Pause, Slow or Search playback in the zoom mode.
- Some discs may not respond to zoom feature.

### DVD VCD CD Locating desired scene

Use the title, chapter and time recorded on the DVD disc to locate the desired point to play back. In the case of VCD/CD disc, time and track are used to locate the desired point to play back.

To check the title, chapter and time, press **DISPLAY**.

#### 1 Press JUMP during playback or stop mode.



|                          |          |        |     |
|--------------------------|----------|--------|-----|
| Time                     | : ---:-- | ---:-- | --- |
| Title                    | : ---    | -/6    |     |
| Chapter                  | : ---    | -/-    |     |
| ▲▼/Enter/0-9/Cancel/Jump |          |        |     |


- "Time" only works in playback or resume stop mode.

#### 2 Press ▲ or ▼ to select the "Time", "Title" or "Chapter".



|                          |          |        |     |
|--------------------------|----------|--------|-----|
| Time                     | : ---:-- | ---:-- | --- |
| Title                    | : ---    | -/6    |     |
| Chapter                  | : ---    | -/-    |     |
| ▲▼/Enter/0-9/Cancel/Jump |          |        |     |

#### 3 Press Number buttons (0-9) to change the number.



|                          |          |        |     |
|--------------------------|----------|--------|-----|
| Time                     | : ---:-- | ---:-- | --- |
| Title                    | : ---    | -/6    |     |
| Chapter                  | : 12-    | -/-    |     |
| ▲▼/Enter/0-9/Cancel/Jump |          |        |     |

- If you input a wrong number, press **CANCEL**.
- Refer to the package supplied with the disc to check the numbers.

#### 4 Press ENTER. Playback starts.




- When you change the title, playback starts from Chapter 1 of the selected title.
- Some discs may not work in the above operation.

#### Note:

In case of the Video-CD playback with PBC, the JUMP does not work. To turn off PBC, see page 53.

## Repeat playback/A-B Repeat playback



### Repeat playback

#### 1 Press **PLAY MODE** during playback or stop mode.



#### 2 [DVD] Press **</>** to select "Chapter" or "Title".



The unit automatically starts repeat playback after finishing the current title or chapter.




[Audio CD, Video CD]

Press **▼** to select "Repeat".

Press **</>** to select "Track" or "All".



The unit automatically starts repeat playback after finishing the current track.



- If you set the repeat mode during stop mode, press **PLAY** to start Repeat playback.

#### 3 Press **PLAY MODE** again to make the screen disappear.

#### ■ To resume normal playback

Select Repeat : "Off" in step 2.

#### Notes:

- Some discs may not work with the repeat operation.
- In case of Video CD with PBC, repeat functions are prohibited during playback.


### A-B Repeat playback

A-B repeat playback allows you to repeat material between two selected points.

#### 1 Press **REPEAT A-B** during playback.




The start point is selected.



#### 2 Press **REPEAT A-B** again.



The end point is selected. Playback starts at the point that you selected. Playback stops at the end point, returns to Point A automatically, then starts again.



#### ■ To resume normal playback

Press **REPEAT A-B** again.



" Off" appears on the screen.


#### Notes:

- In A-B Repeat mode, subtitles near the A or B locations may not be displayed.
- You cannot set the A-B Repeat for the scenes that include multiple angles.
- A-B Repeat playback does not work when Repeat playback is activated.
- You may not be able to set A-B Repeat, during certain scenes of the DVD.
- A-B Repeat does not work with an interactive DVD.
- A-B Repeat is prohibited when PBC is on.

Advanced playback (DVD)

## Program playback/Random playback

You can arrange the playback order of tracks or files on the disc. And also the unit selects tracks or files at random and playback them. These feature works for Audio CD and Video CD.



### VCD CD Program playback

#### 1 Press PLAY MODE in the stop mode.



Play Mode : Off  
Repeat : Off  
◀▶/▶/Play Mode

#### 2 Press ▲ or ▼ to select Play Mode, then press ◀▶ to select "Program".




Play Mode : Program  
Repeat : Off  
1 --- 4 --- 7 --- 10 ---  
2 --- 5 --- 8 --- 11 ---  
3 --- 6 --- 9 --- 12 ---  
[Clear] [Program Playback]  
◀▶/▶/Enter/0-9/Cancel/Play Mode

#### 3 Press ▲/▼ or ◀▶ to select the programming position. Use Number buttons (0-9) to input the Track or file numbers.



- To program others, repeat step 3.
- If you input a wrong number, press CANCEL.



Play Mode : Program  
Repeat : Off  
1 9-- 4 --- 7 --- 10 ---  
2 3-- 5 --- 8 --- 11 ---  
3 11- 6 --- 9 --- 12 ---  
[Clear] [Program Playback]  
◀▶/▶/Enter/0-9/Cancel/Play Mode

#### 4 Press ▲/▼/◀▶ to select "Program Playback" and press ENTER.

The programs you selected will start to playback in the order.

- In case of JPEG file, press SKIP >>> to continue the program playback.
- To resume normal playback, select Play Mode: "Off" in step 2.



Play Mode : Program  
Repeat : Off  
1 9-- 4 --- 7 --- 10 ---  
2 3-- 5 --- 8 --- 11 ---  
3 11- 6 --- 9 --- 12 ---  
[Clear] [Program Playback]  
◀▶/▶/Enter/0-9/Cancel/Play Mode

#### ■ To change the program

- In the program mode, press ▲/▼/◀▶ to select the track number.
- Press **Number buttons (0-9)** to select the track number to be replaced.

#### ■ To clear the program one by one

In the program mode, press ▲/▼/◀▶ to select the track number. Then press **CANCEL**.

#### ■ To clear all the programs

In the program mode, press ▲/▼/◀▶ to select "Clear". Then press **ENTER**.

#### Notes:

- In playing back the Video CD with PBC, you cannot set Program playback.
- The program is cancelled when you open the disc tray or turn the power off.

### VCD CD Random playback

#### 1 Press PLAY MODE during playback or stop mode.



#### 2 Press ▲/▼ to select Play Mode, then press ◀▶ to select "Random".



Play Mode : Random  
Repeat : Off  
◀▶/▶/Play Mode

#### 3 Press PLAY.



The Random Playback will start.


- If you set "Random" during playback mode, Random playback will begin after the track that is currently being played has ended.
- To resume normal playback, select Play Mode: "Off" in step 2.

#### Note:

In playing back the Video CD with PBC, you can not set Random playback.



## Changing angles/Title selection/DVD menu




### Changing angles

When playing back a disc recorded with multi-angle facility, you can change the angle that you are viewing the scene from.

#### 1 Press ANGLE during playback.



The current angle will appear.



#### 2 Press ANGLE repeatedly until the desired angle is selected.



#### Note:

Depending on the DVD, you may not be able to change the angles even if multi-angles are recorded on the DVD.

### Title selection

Two or more titles are recorded on some discs. If the title menu is recorded on the disc, you can select the desired title.

#### 1 Press TOP MENU during playback.



Title menu appears on the screen.

#### 2 Press ▲/▼/◀/▶ to select the desired title.



#### 3 Press ENTER or PLAY.



The playback of the selected title will start.

#### Note:

Depending on the DVD, you may not be able to select the title. Depending on the DVD, a "title menu" may simply be called a "menu" or "title" in the instructions supplied with the disc.

### DVD menu

Some DVDs allow you to select the disc contents using the menu.

When you play back these DVDs, you can select the subtitle language and sound-track language, etc. using the menu.

#### 1 Press DVD MENU during playback.



The DVD menu appears on the screen.

- Press **DVD MENU** again to resume playback at the scene when you pressed **DVD MENU**.

#### 2 Press ▲/▼/◀/▶ to select the desired item.



#### 3 Press ENTER.




The menu continues to another screen. Repeat steps 2 and 3 to set the item completely.

#### Note:

Depending on the DVD, you may not be able to resume playback from the scene point when you pressed **DVD MENU**.

## Changing soundtrack language/ Subtitles



### Changing soundtrack language

You can select the language when you play a multilingual disc.

#### 1 Press AUDIO SELECT during playback.



The current soundtrack language will appear.

2/8 Fra Dolby Digital

#### 2 Press AUDIO SELECT repeatedly until the desired language is selected.




1/8 Eng Dolby Digital

- The on screen display will disappear after a few seconds.

#### ■ In case of Video CD playback

Audio type changes as follows each time you press **AUDIO SELECT**.



#### Notes:

- If the desired language is not heard after pressing the button several times, the language is not recorded on the disc.
- Changing soundtrack language is cancelled when you open the disc tray. The initial default language or available language will be heard if the disc is played back again.
- If you select DTS in playing DTS-encoded disc, no sound will be heard from the TV/VCR/DVD's speakers.



### Subtitles

When playing back a disc recorded with subtitles, you can select the subtitle language or turn the subtitle off.

#### 1 Press SUBTITLE repeatedly during playback until your desired language appears.



1/8 Eng

#### 2 To turn off the subtitle, press SUBTITLE until "Off" appears.




Off

- The on screen display will disappear after a few seconds.

#### Notes:

- Depending on the DVD, you may not be able to change subtitles, or to turn subtitles on or off.
- While playing a DVD, the subtitle may change when you open or close the disc tray.
- In some cases, a selected subtitle language may not be changed immediately.

## Disc status/To turn off the PBC




### Disc status

With each press of **DISPLAY**, the status of the disc will appear on the screen and change as follows.




#### DVD




To make status display disappear, press **DISPLAY** again.

#### Video CD



To make status display disappear, press **DISPLAY** again.


#### Audio CD



When you playback the CD disc, the status display will appear on the screen and continue displaying.

### To turn off the PBC

- 1** Press **PLAY MODE** in the stop mode.
- 2** Press **▲/▼** to select Play Mode, then press **◀/▶** to select "Off".  


- 3** Press **PLAY MODE** again to make the screen disappear.

#### ■ To turn on the PBC

Select Play Mode : "PBC" in step 2.

#### Note:

You can also turn off the PBC by pressing number button **1** and **ENTER** in the stop mode.

Advanced playback (DVD)

## MP3/WMA/JPEG operation

This player can play back the MP3/WMA/JPEG-data which has been recorded on CD-R, CD-RW or Media card.

### Note:

This unit requires discs/recordings to meet certain technical standards in order to achieve optimal playback quality. Prerecorded DVDs are automatically set to these standards. There are many different types of recordable disc formats (including CD-R containing MP3/WMA files). Given the fact that technology in this area is still maturing, Toshiba cannot guarantee that all genre of recordable discs will produce optimal playback quality. The technical criteria set out in this owner's manual are meant as a guide only.

Please be advised that you must obtain permission from the applicable copyright owners to download copyrighted content, including music files, in any format, including the MP3 and WMA formats, prior to the downloading thereof. TOSHIBA has no right to grant and does not grant permission to download any copyrighted content.

## MP3/WMA/JPEG file information

### Limitations on MP3/WMA/JPEG file playback

- MP3/WMA/JPEG file is the disc/card that is standardized by ISO9660, its file name must include 3-digits extension letters, "mp3", "wma", "jpg".
- MP3/WMA/JPEG file must be correspond to the ISO standardized files.
- This unit can read 600 files per disc/card. If one directory has more than 600 files, it reads up to 600 files, the remaining files will be omitted.
- The unit is able to recognize up to a maximum of 50 directories per disc/card.
- MP3/WMA/JPEG files cannot be used for the purpose of recording.
- If the disc/card has both audio tracks and MP3/WMA/JPEG files, only audio tracks are played.
- It may take more than one minute for this unit to read MP3/WMA/JPEG files depending on its structure.
- Music recorded by "Joliet Recording Specification" can be played back, the file name is displayed (within 16 letters) on the screen. Long file names will be condensed.
- The music files recorded by "Hierarchical File System" (HFS) cannot be played.

### Limitations on display

- The maximum number for display is 16 letters.  
Available letters for display are the following:  
capital or small alphabets of A through Z, numbers of 0 through 9, and \_ (under score).
- Other letters than those above are replaced in hyphen.

### Notes on MP3/WMA/JPEG files

To play back MP3/WMA/JPEG file in the recorded order,

1. Use MP3/WMA/JPEG software that records data alphabetically or numerically.
2. Name each file including two-digit or three-digit number (ex. "01" "02" or "001" "002").
3. Refrain from making too many sub-folders.

### CAUTION:

- Some MP3/WMA/JPEG CDs/Cards cannot be played back depending on the recording conditions.
- The CD/cards that has no music data or non MP3/WMA/JPEG files cannot be played back.

### Standard, sampling frequency, and the bit rate:

#### MP3 file

MPEG-1 Audio

32kHz, 44.1kHz, 48kHz

32kbps ~ 320kbps (constant bit rate or variable bit rate)

The recommend recording setting for a high-quality sound is 44.1kHz of sampling frequency and 128kbps of constant bit rate.

#### WMA file

WMA version 7, and 8

32kHz, 48kbps

44.1kHz, 48kbps ~ 192kbps

48kHz, 128kbps ~ 192kbps


The file recorded by mono, 48kHz, 48 kbps is not available to this unit.

Microsoft, Windows Media, and Windows Logo are trademarks or registered trademarks of Microsoft Corporation in both the United States and other countries.

### CAUTION

Do not insert any foreign objects into the Media card slot as this can result in a risk of fire or electric shock.

Place a CD-R/RW on which MP3, WMA or JPEG files have been recorded onto the disc tray or insert a Media card on which MP3, WMA or JPEG files have been recorded into the media card slot on the front panel.




## MP3/WMA playback


- 1 Place a CD-R/RW on which MP3 or WMA files have been recorded onto the disc tray, or insert a Media card on which MP3 or WMA files have been recorded into the media card slot on the front panel.

**Note:** When the media card is inserted, the unit is changed to the CARD mode automatically.


- 2 Press DVD/CARD to select the DVD (CD) mode or the CARD mode.  
A file menu screen will appear on the screen.  
Press ◀/▶ or ENTER to select folder.



- 3 Press ▲/▼/◀/▶ or Number buttons (0-9) to select the desired file.



- In case the folder includes more than 15 files, press ◀ or ▶ to display next file list.



- When **PLAY** has been pressed after displaying the file menu, or when the disc tray has been closed using **PLAY**, playback begins automatically starting from the first file. In this case, if the first file is an MP3/WMA file, only MP3/WMA files are played back in order. If the first file is a JPEG file, the first JPEG file is played back.

- 4 Press **ENTER**.  
The selected file starts playing back.



- 5 Press **STOP** to end playback.



- The unit records the stopped point. “■” appears on the screen. Press **PLAY** to resume playback (from the scene point).
- If you press **STOP** again, unload the disc or change the DVD mode and CARD mode, the unit will clear the stopped point.


### To eject the Media card

Confirm the Media card is not in use now. Pull the card out slowly and straight.

#### Note:

Do not remove the card while it is in use. If removed while in use, information on the card may be lost.

### About file menu



#### Media type

CD: CD-R/RW  
SD: SD (Secure Digital™) memory card  
MMC: MMC (MultiMediaCard™)  
xD: xD-Picture Card  
MS: Memory Stick™(Pro)

#### File type

MP3 : MP3-file  
WMA : WMA-file  
JPEG : JPEG-file

#### Notes:

- The picture menu is displayed when the FUJICOLOR CD or the Kodak Picture CD are played. To display the file menu, press **TOP MENU**.
- In the case of a CD containing a mixture of MP3, WMA and JPEG files, the files are played back by selecting them from the file menu.
- MP3 or WMA file on the Kodak Picture CD is not recognized on this unit.


#### Notes:

- During MP3/WMA/JPEG-Playback, you cannot use SEARCH, A-B Repeat functions.
- You can use Repeat (Track or All), Random functions and Program playback for MP3/WMA/JPEG Playback [49] [50].

## MP3/WMA/JPEG operation (Continued)

### CAUTION

Do not insert any foreign objects into the Media card slot as this can result in a risk of fire or electric shock.



### CD CARD JPEG playback


- 1 Place a CD-R/RW on which JPEG files have been recorded onto the disc tray, or insert a Media card on which JPEG files have been recorded into the media card slot on the front panel.

**Note:** When the media card is inserted, the unit is changed to the CARD mode automatically.

- 2 Press DVD/CARD to select the DVD (CD) mode or the CARD mode. A file menu screen will appear on the screen. Press  $\triangle/\nabla$  to select folder.



- 3 Press  $\triangle/\nabla/\triangleleft/\triangleright$  or Number buttons (0-9) to select the desired file. To display a picture menu, press DVD MENU. (To return to a file menu, press TOP MENU.) Press  $\triangle/\nabla$  or  $\triangleleft/\triangleright$  to select the desired file.



- To display next list, press **SKIP**  $\triangleleft/\triangleright$ .
- When **PLAY** has been pressed after displaying the file menu, or when the disc tray has been closed after pressing **PLAY**, playback begins automatically starting from the first file. In this case, if the first file is a JPEG file, the first JPEG file is played back. If the first file is an MP3/WMA file, only MP3/WMA files are played back in order.

- 4 Press ENTER. The selected picture appears on the screen.



#### Rotating an image

You can rotate an image by 90 degrees by pressing **ANGLE** during playback of the image.

" $\triangleleft/\triangleright$ ", " $\triangleleft/\triangleright$ ", " $\triangleleft/\triangleright$ " or " $\triangleleft/\triangleright$ " appears briefly on the screen.

- 5 Press **STOP** to end playback.

The file menu appears on the screen. If you want to watch the other file, repeat steps 3 ~ 4.



### CD CARD JPEG slide show

The slide show enables you to view pictures (files) one after another automatically.

#### Preparation:

Set "JPEG Interval" setting to "5 Seconds", "10 Seconds" or "15 Seconds"  $\boxed{60}$ .

- 1 Select your desired starting file for the slide show in the step 4 as left.

- 2 Press ENTER to start slide show from the selected file.



- If you press **PAUSE** during the slide show, the slide show stops temporary. "II" appears briefly on the picture. If the picture appears upside down or sideways, press **ANGLE** repeatedly until it's right side up. " $\triangleleft/\triangleright$ ", " $\triangleleft/\triangleright$ ", " $\triangleleft/\triangleright$ " or " $\triangleleft/\triangleright$ " appears briefly on the screen. Press **PLAY** or **SKIP**  $\triangleleft/\triangleright$  again to resume the slide show.
- When the slide show playback finished the file list appears.
- To stop the slide show, press **STOP**. The file list appears.

#### To eject the Media card


Confirm the Media card is not in use now. Pull the card out slowly and straight.

#### Note:

Do not remove the card while it is in use. If removed while in use, information on the card may be lost.

## Customizing the function settings

You can change the default settings to customize performance to your preference.




### Setting procedure

#### 1 Press SETUP during stop mode.



The following on-screen display appears.



#### 5 To make SETUP screen disappear, press SETUP or RETURN.



#### 2 Press ◀ or ▶ to select the desired section, then press ▼ or ENTER.



#### 3 Press ▲ or ▼ to select the desired option.



#### 4 Change the selection using ◀ or ▶, by referring to the corresponding pages 59~61.




- Repeat steps 3 and 4 to change other settings.
- To select another operation, go back to step 2 by pressing ▲ repeatedly.

## Customizing the function settings (Continued)

### Setting details

| Section                                                                             | Option                     | Details                                                                                                       | Page |
|-------------------------------------------------------------------------------------|----------------------------|---------------------------------------------------------------------------------------------------------------|------|
|    | <b>Menu Subtitle Audio</b> | To select the language of "Menu", "Subtitle" and "Audio" if more than one language are available on the disc. | 59   |
|                                                                                     | <b>TV Screen</b>           | To select a picture size according to the aspect ratio of your TV.                                            | 59   |
|                                                                                     | <b>Display</b>             | To turn on or de-activate the operational status display on the screen.                                       | 59   |
|                                                                                     | <b>Picture Mode</b>        | To select a preferred picture mode from "Video", "Film" or "Auto".                                            | 60   |
|                                                                                     | <b>JPEG Interval</b>       | To select a preferred setting for the slide show playback.                                                    | 60   |
|  | <b>DRC</b>                 | To select On or Off for DRC (Dynamic Range Control).                                                          | 60   |
|  | <b>Password</b>            | Input 4-digit password to set the parental level.                                                             | 61   |
|                                                                                     | <b>Parental</b>            | To select a preferred parental level for the parental setting.                                                |      |
|                                                                                     | <b>Select Files</b>        | To select a preferred file type for playing back a CD containing a mixture of file types.                     |      |



#### ■ Menu, Subtitle, Audio

You can select the language of “Menu”, “Subtitle” and “Audio” if more than one languages are recorded onto the disc.

##### **English, Francais, Espanol:**

The selected language will be heard or seen.

##### **Other:**

Other language can be selected (see the “Language code list” on page 63).

##### **Original: (Audio)**


The unit will select the first-priority language of each disc.

##### **Off: (Subtitle)**

Subtitles do not appear.

##### **Notes:**

- If the selected language is not recorded on the disc, the first-priority language is selected.
- If you want to change the OSD language, you can perform it by TV MENU (see page 23).



#### ■ TV Screen

You have the following screen sizes to choose from:

##### **4:3 Letter box:**

Select this mode when connecting to a conventional TV. When playing back a wide screen-DVD disc, it displays the wide picture with black bands at the top and bottom of screen.

##### **4:3 Pan scan:**

It displays the wide picture on the whole screen with left and right edges automatically cut off.

Press **OPEN/CLOSE** to view in the selected screen size.

##### **Note:**

If the DVD disc is not formatted in the pan & scan style, it displays 4:3 style.

#### ■ Display

On screen display can be switched on or off when you press the buttons.

**On:** On screen displays appear when you press the buttons (factory setting).

**Off:** On screen displays do not appear when you press any buttons.



## Customizing the function settings (Continued)

### Setting details

#### Picture Mode

There are two types of source content in pictures recorded in DVD video discs: film content (pictures recorded from films at 24 frames per second) and video content (video signals recorded at 30 frames per second). Make this selection according to the type of content being viewed.

**Auto:** Select this position normally.  
The DVD player automatically detects source content, film or video, of playback source, and converts that signal in the progressive output format in an appropriate method.

**Film:** The DVD player converts film content pictures in the progressive output format appropriately. Suitable for playback of film content pictures. The progressive output feature will be most effective under this selection.

**Video:** The DVD player filters video signal, and converts it in the progressive output format appropriately.  
Suitable for playback of video content pictures.

**Note:**  
Depending on the disc, pictures may be cut off or doubled. In this case, select "Video".

#### JPEG Interval


You can continuously play back all JPEG files automatically.  
After the setting below, start playing the disc on which JPEG files have been recorded.

**Off:**  
Plays back one file at a time.

**5 Seconds:**  
Plays back images in the form of a slide show at 5 second intervals.

**10 Seconds:**  
Plays back images in the form of a slide show at 10 second intervals.

**15 Seconds:**  
Plays back images in the form of a slide show in 15 second intervals.




#### DRC

DRC (Dynamic Range Control) enables you to control the dynamic range so as to achieve a suitable sound for your equipment.

- On:** Loud sound such as explosion or similar is toned down slightly when played back. This makes it suitable for when it is connected to a stereo.
- Off:** It plays back at the recording level on the disc.

#### Notes:

- This function works only during playback of Dolby Digital recorded discs.
- The level of Dynamic Range Reduction may differ depending on DVD video disc.



### ■ Parental control setting

Some discs are specified not suitable for children. Such discs can be limited not to play back with the unit.

- 1) Press ▲ or ▼ to select "Parental", then press ◀ or ▶ until the level you require appears.
  - Level Off: The parental control setting does not function.
  - Level 8: All DVD software can be played back.
  - Level 1: DVD software for adults cannot be played back.

Select from the level 1 to level 8. The limitation will be more severe as the level number is lower.

- 2) Press ▲ or ▼ to select "Password". Press **Number buttons (0-9)** to input a 4-digit password. Be sure to remember this number!
  - If you input a wrong number, press **CANCEL**.
- 3) Press **ENTER** to store the password.

Note: Now the rating is locked and the setting can not be changed unless you enter the correct password.
- 4) Press **OPEN/CLOSE** to activate Parental control setting. (See "Temporary disabling of rating level by DVD disc" on page 62.)

#### Notes:

- Depending on the discs, the unit cannot limit playback.
- Some discs may not be encoded with specific rating level information though its disc jacket says "adult." For those discs, the age restriction will not work.

### ■ To change the parental level

- 1) Press ▲ or ▼ to select "Password".
- 2) Press **Number buttons (0-9)** to enter the password you have stored.
- 3) Press **ENTER**.
  - The rating is now unlocked.
- 4) Press ▲ or ▼ to select "Parental", then press ◀ or ▶ to change the parental level.
- 5) Press ▲ or ▼ to select "Password", then press **Number buttons (0-9)** to enter the password.

Note: You can change the password if you want.
- 6) Press **ENTER**.

Now the parental level is changed and locked.

#### If you forget the password...

1. Press **OPEN/CLOSE** to open the disc tray.
2. Remove the disc.
3. Press **OPEN/CLOSE** again to close the disc tray.

"No Disc" appears on the screen.
4. While holding **STOP** down on the front panel, press **7** on the remote control. "PASSWORD CLEAR" appears on the screen.
5. Enter a new password again.

### ■ Select Files

When playing back a CD or Media card containing a mixture of MP3, WMA and JPEG files, only MP3/WMA or JPEG files can be displayed on the file menu.

#### All:

Displays all files.

#### Music Only:

Displays only MP3/WMA files.

#### Pictures Only:

Displays only JPEG files.

#### Note:


If each setup (pages 59-62) has been completed, the unit can always be worked under the same conditions (especially with DVD discs).

Each setup will be retained in the memory even if you turn the power off.


## Temporary disabling of rating level by DVD disc

Depending on the DVD disc, the disc may try to temporarily cancel the rating level that you have set.


It is up to you to decide whether to cancel the rating level or not.



- 1** Load a DVD disc and press **PLAY** or **OPEN/CLOSE** on the unit [45].



- 2** If the DVD disc has been designed to temporarily cancel the Rating level, the screen which follows the "Reading Disc" screen will change, depending on which disc is played. If you select "YES" with the **ENTER** key, "Your disc exceeds the parental control level#" screen will then appear.



Your disc exceeds the parental control level#.

Parental Control Level

Cancel Picture


▲▼/Enter/Return

- 3** If you wish to cancel the set rating level temporarily, select "Parental Control Level" with **▲** or **▼**, then press **ENTER**. If the 4-digit password at step 2 on page 61 has been set, the password entering screen will appear as shown in step 4. Alternatively, if the password has not been set, playback will commence. If you don't know (or have forgotten) the password, select "Cancel Picture".

The setting screen will disappear. Press **OPEN/CLOSE** to remove the disc.



- 4** Enter the password with Number buttons (0-9). Then press **ENTER**.



To exit from the entry, press **RETURN**.

Please enter the 4 - digit password

\*\*\*\*

Enter/0 - 9/Cancel/Return

- 5** Playback will commence if the entered password was correct.

### Note:

This temporary cancellation of rating level will be kept until the disc is ejected.

When the disc is ejected, the original rating level will be set again automatically.

## Language code list

Enter the appropriate code number for the initial settings “Menu”, “Subtitle” and/or “Audio” [59].

| Language Name   | Code | Language Name    | Code | Language Name  | Code | Language Name | Code |
|-----------------|------|------------------|------|----------------|------|---------------|------|
| Abkhazian       | 1112 | Fiji             | 1620 | Lingala        | 2224 | Singhalese    | 2919 |
| Afar            | 1111 | Finnish          | 1619 | Lithuanian     | 2230 | Slovak        | 2921 |
| Afrikaans       | 1116 | French           | 1628 | Macedonian     | 2321 | Slovenian     | 2922 |
| Albanian        | 2927 | Frisian          | 1635 | Malagasy       | 2317 | Somali        | 2925 |
| Amharic         | 1123 | Galician         | 1722 | Malay          | 2329 | Spanish       | 1529 |
| Arabic          | 1128 | Georgian         | 2111 | Malayalam      | 2322 | Sundanese     | 2931 |
| Armenian        | 1835 | German           | 1415 | Maltese        | 2330 | Swahili       | 2933 |
| Assamese        | 1129 | Greek            | 1522 | Maori          | 2319 | Swedish       | 2932 |
| Aymara          | 1135 | Greenlandic      | 2122 | Marathi        | 2328 | Tagalog       | 3022 |
| Azerbaijani     | 1136 | Guarani          | 1724 | Moldavian      | 2325 | Tajik         | 3017 |
| Bashkir         | 1211 | Gujarati         | 1731 | Mongolian      | 2324 | Tamil         | 3011 |
| Basque          | 1531 | Hausa            | 1811 | Nauru          | 2411 | Tatar         | 3030 |
| Bengali; Bangla | 1224 | Hebrew           | 1933 | Nepali         | 2415 | Telugu        | 3015 |
| Bhutani         | 1436 | Hindi            | 1819 | Norwegian      | 2425 | Thai          | 3018 |
| Bihari          | 1218 | Hungarian        | 1831 | Oriya          | 2528 | Tibetan       | 1225 |
| Breton          | 1228 | Icelandic        | 1929 | Panjabi        | 2611 | Tigrinya      | 3019 |
| Bulgarian       | 1217 | Indonesian       | 1924 | Pashto, Pushto | 2629 | Tonga         | 3025 |
| Burmese         | 2335 | Interlingua      | 1911 | Persian        | 1611 | Turkish       | 3028 |
| Byelorussian    | 1215 | Irish            | 1711 | Polish         | 2622 | Turkmen       | 3021 |
| Cambodian       | 2123 | Italian          | 1930 | Portuguese     | 2630 | Twi           | 3033 |
| Catalan         | 1311 | Japanese         | 2011 | Quechua        | 2731 | Ukrainian     | 3121 |
| Chinese         | 3618 | Javanese         | 2033 | Rhaeto-Romance | 2823 | Urdu          | 3128 |
| Corsican        | 1325 | Kannada          | 2124 | Romanian       | 2825 | Uzbek         | 3136 |
| Croatian        | 1828 | Kashmiri         | 2129 | Russian        | 2831 | Vietnamese    | 3219 |
| Czech           | 1329 | Kazakh           | 2121 | Samoan         | 2923 | Volapük       | 3225 |
| Danish          | 1411 | Kirghiz          | 2135 | Sanskrit       | 2911 | Welsh         | 1335 |
| Dutch           | 2422 | Korean           | 2125 | Scots Gaelic   | 1714 | Wolof         | 3325 |
| English         | 1524 | Kurdish          | 2131 | Serbian        | 2928 | Xhosa         | 3418 |
| Esperanto       | 1525 | Laothian         | 2225 | Serbo-Croatian | 2918 | Yiddish       | 2019 |
| Estonian        | 1530 | Latin            | 2211 | Shona          | 2924 | Yoruba        | 3525 |
| Faroese         | 1625 | Latvian, Lettish | 2232 | Sindhi         | 2914 | Zulu          | 3631 |



Others

## **Reception disturbances**

Most types of television interference can be remedied by adjusting the height and position of the VHF/UHF antenna. Outdoor antennas are recommended for best results. The most common types of television interference are shown below. If one of these symptoms appear when the unit is connected to a Cable TV system, the disturbance may be caused by the local Cable TV company broadcast.

### **IGNITION**

Black spots or horizontal streaks may appear, the picture may flutter or drift. Usually caused by interference from automobile ignition systems, neon lamps or AC powered tools and appliances such as drills or hair dryers.



### **GHOSTS**

Ghosts are caused by the television signal following two paths. One is the direct path and the other is reflected by tall buildings, hills or other large objects. Changing the direction or position of the antenna may improve the reception.




### **SNOW**

If the unit is located far from the TV station, in a fringe reception area where the signal is weak, small dots may appear in the picture. If the signal is extremely weak, the installation of a larger external antenna may be necessary.



### **RADIO FREQUENCY INTERFERENCE (RFI)**

Caused by two-way radios, this type of interference produces moving ripples or diagonal streaks in the picture. Some cases may cause a loss of contrast in the picture. Changing the direction and position of the antenna or installing an RFI filter may improve the picture.



### **PICTURE SIZE VARIATION**

A slight picture size variation is normal when you adjust the CONTRAST or BRIGHTNESS settings.



## **CARE AND MAINTENANCE**

To prevent fire or shock hazard, disconnect the unit from the power source before cleaning.

The finish on the cabinet may be cleaned with mild soap and a soft, damp cloth and cared for as other furniture.

Use caution when cleaning or wiping the plastic parts.

# Troubleshooting

Check the following guide for the possible cause of a problem before contacting service.

| SYMPTOMS                                             | CAUSE                                                                      | POSSIBLE SOLUTIONS                                                       | PAGE   |
|------------------------------------------------------|----------------------------------------------------------------------------|--------------------------------------------------------------------------|--------|
| <b>POWER</b>                                         |                                                                            |                                                                          |        |
| No power.                                            | The AC power cord is not connected.                                        | Connect the AC power cord to the AC outlet.                              | 5      |
| Although the power is on, the unit does not operate. | Cassette or disc is not inserted.                                          | Insert a video cassette or disc.                                         | 34, 45 |
|                                                      | The TIMER REC button is depressed.                                         | Press the TIMER REC button.                                              | 41     |
| <b>TV BROADCAST RECEPTION</b>                        |                                                                            |                                                                          |        |
| Poor or no picture.                                  | TV station experiencing problems.                                          | Try another channel.                                                     | 24     |
|                                                      | Picture control is not adjusted.                                           | Check picture control adjustments.                                       | 32     |
|                                                      | Possible local interference.                                               | Check for source of reception disturbance.                               | 64     |
|                                                      | Antenna (CABLE) connector is not connected or possible local interference. | Check CABLE connection or VHF/UHF antenna, reposition or rotate antenna. | 14, 15 |
| Poor or no color.                                    | TV station experiencing problems.                                          | Try another channel.                                                     | 24     |
|                                                      | Picture control is not adjusted.                                           | Check picture control adjustments.                                       | 32     |
|                                                      | Possible local interference.                                               | Check for source of reception disturbance.                               | 64     |
|                                                      | Antenna (CABLE) connector is not connected or possible local interference. | Check CABLE connection or VHF/UHF antenna, reposition or rotate antenna. | 14, 15 |
| Picture wobbles or drifts.                           | TV station experiencing problems.                                          | Try another channel.                                                     | 24     |
|                                                      | Antenna (CABLE) connector is not connected or possible local interference. | Check CABLE connection or VHF/UHF antenna, reposition or rotate antenna. | 14, 15 |
|                                                      | Cable TV channel is scrambled.                                             | Try another channel.                                                     | 24     |
| No CATV reception.                                   | CABLE connector is not connected.                                          | Check all CABLE connections.                                             | 15     |
|                                                      | TV/CABLE selection is set to the TV position.                              | Set the selection to the CABLE position.                                 | 27     |
|                                                      | Cable TV service interrupted.                                              | Contact your Cable TV company.                                           | —      |
| No reception above channel 13.                       | TV/CABLE selection is not set to the appropriate position.                 | Make sure selection is in the appropriate position.                      | 27     |
|                                                      | UHF antenna is not connected.                                              | Check UHF antenna.                                                       | 15     |
| Poor or no sound.                                    | TV station experiencing problems.                                          | Try another channel.                                                     | 24     |
|                                                      | Antenna (CABLE) connector is not connected or possible local interference. | Check CABLE connection or VHF/UHF antenna, reposition or rotate antenna. | 14, 15 |
|                                                      | Possible local interference.                                               | Check for source of reception disturbance.                               | 64     |
|                                                      | The MUTE button is depressed.                                              | Check the MUTE button has not been pressed.                              | 25     |
| TV shuts off.                                        | TV station stopped broadcasting.                                           | Tune new channel.                                                        | 24     |
|                                                      | Sleep timer is set.                                                        | Set Sleep Timer to "0".                                                  | 25     |
| Closed caption is not activated.                     | TV station experiencing problems or program tuned is not closed captions.  | Try another channel.                                                     | 24     |
|                                                      | TV signal is weak.                                                         | Check CABLE connection of VHF/UHF antenna, reposition or rotate antenna. | 14, 15 |
|                                                      | The CLOSED CAPTION button is not depressed.                                | Press the CLOSED CAPTION button to turn on the closed caption.           | 26     |

Others

## Troubleshooting(Continued)

| SYMPTOMS                                                                                                   | CAUSE                                                                            | POSSIBLE SOLUTIONS                                                                     | PAGE   |
|------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|--------|
| <b>VCR</b>                                                                                                 |                                                                                  |                                                                                        |        |
| TV recording does not work.                                                                                | The video cassette's erase prevention tab is broken off.                         | Place a piece of adhesive tape over the hole.                                          | 34     |
| Timer recording does not work.                                                                             | The time is not set correctly.                                                   | Reset the present time.                                                                | 21, 22 |
|                                                                                                            | The recording start/end time is not set correctly.                               | Reset the start/end time.                                                              | 41     |
|                                                                                                            | The TIMER REC button have not been pressed (the TIMER REC indicator is not lit). | Press the TIMER REC button (the TIMER REC indicator is lit).                           | 41     |
| Noise bars appear on the screen.                                                                           | Tape is old or worn.                                                             | Replace the tape.                                                                      | –      |
|                                                                                                            | Tracking adjustment is beyond range of automatic tracking circuit.               | Adjust tracking manually using the TRK +/- buttons on the remote control.              | 36     |
|                                                                                                            | Video heads are dirty.                                                           | Clean the video heads.                                                                 | 38     |
| <b>DVD</b>                                                                                                 |                                                                                  |                                                                                        |        |
| The playback picture has occasional distortion.                                                            | The disc is dirty.                                                               | Eject the disc and clean it.                                                           | 8      |
|                                                                                                            | It is in fast forward or fast reverse playback.                                  | Some times a small amount of picture distortion may appear. This is not a malfunction. | –      |
| The unit does not start playback.                                                                          | No disc is inserted.                                                             | Insert a disc.                                                                         | 45     |
|                                                                                                            | An unplayable disc is inserted.                                                  | Insert a playable disc (Check the disc type and color system).                         | 9      |
|                                                                                                            | The disc is placed upside down.                                                  | Place the disc with the playback side down.                                            | 45     |
|                                                                                                            | The disc is not placed within the guide.                                         | Place the disc correctly inside the guide on the disc tray.                            | 45     |
|                                                                                                            | The disc is dirty.                                                               | Clean the disc.                                                                        | 8      |
|                                                                                                            | The parental lock function is set.                                               | Cancel the parental lock function or change the parental lock level.                   | 61, 62 |
| Playback does not follow the course of the disc's program.                                                 | It is in the mode of repeat playback, memory playback, etc.                      | These operations may prevent a proper progress of the contents.                        | –      |
|  appears on the screen. | The function is prohibited with the unit or the disc.                            | –                                                                                      | 9      |
| <b>REMOTE CONTROL</b>                                                                                      |                                                                                  |                                                                                        |        |
| Remote control does not operate.                                                                           | The remote control is not aimed at the sensor.                                   | Aim the remote control at the remote sensor.                                           | 13     |
|                                                                                                            | Distance is too far or too much light in the room.                               | Operate within 5 m or reduce the light of the room.                                    | 13     |
|                                                                                                            | There is an obstacle in the path of the beam.                                    | Clear the path of the beam.                                                            | 13     |
|                                                                                                            | The batteries are weak.                                                          | Replace the batteries.                                                                 | 13     |
|                                                                                                            | The batteries are not inserted correctly.                                        | Insert correctly.                                                                      | 13     |

# Specifications

|                                       | MW20F51                                                                     | MW24F51                   | MW27F51                   |
|---------------------------------------|-----------------------------------------------------------------------------|---------------------------|---------------------------|
| General                               |                                                                             |                           |                           |
| Power supply                          | AC 120 V 60 Hz                                                              |                           |                           |
| Power consumption                     |                                                                             |                           |                           |
| Operation:                            | 110 W                                                                       | 135 W                     | 145 W                     |
| Stand by:                             | 4 W                                                                         |                           |                           |
| Picture tube                          | 20 in. (508 mm) diagonal*                                                   | 24 in. (600 mm) diagonal* | 27 in. (677 mm) diagonal* |
| Speaker                               | 1-13/16 x 3-7/8 inches (46 x 99 mm), 8 Ω x 2                                |                           |                           |
| Audio output power                    | 1.5 W + 1.5 W                                                               |                           | 2.5 W + 2.5 W             |
| Weight                                | 59.5 lbs (27 kg)                                                            | 79.4 lbs (36 kg)          | 97.0 lbs (44 kg)          |
| Dimensions                            |                                                                             |                           |                           |
| Width:                                | 22-9/16 inches (573 mm)                                                     | 25-13/16 inches (655 mm)  | 29-1/8 inches (740 mm)    |
| Height:                               | 20-3/8 inches (517 mm)                                                      | 22-13/16 inches (580 mm)  | 25-3/8 inches (645 mm)    |
| Depth:                                | 18-15/16 inches (481 mm)                                                    | 18-5/8 inches (472.5 mm)  | 19-7/16 inches (493 mm)   |
| Tuner                                 | 181 channel freq. synthesized<br>VHF 2-13<br>UHF 14-69<br>CATV 125 Channels |                           |                           |
| Antenna input                         | UHF/VHF: 75 Ω coaxial                                                       |                           |                           |
| Color system                          | NTSC                                                                        |                           |                           |
| Video head                            | 4 Rotary heads                                                              |                           |                           |
| Audio track                           | Hi-Fi sound - 2 Tracks / MONO sound - 1 Track                               |                           |                           |
| Hi-Fi frequency response              | 20 Hz to 20,000 Hz                                                          |                           |                           |
| Hi-Fi dynamic range                   | More than 90 dB                                                             |                           |                           |
| F.FWD/REW<br>time at 25°C (77°F)      | Approx. 1 minute and 48 seconds (with T-120 cassette tape)                  |                           |                           |
| Applicable disc                       | DVD (12 cm, 8 cm), CD (12 cm, 8 cm)                                         |                           |                           |
| Frequency range                       | DVD: 4 Hz-22 kHz, CD: 4 Hz-20 kHz                                           |                           |                           |
| Operating conditions                  | Temperature: 5°C-40°C (41°F-104°F), Operating status: Horizontal            |                           |                           |
| Input/Output                          |                                                                             |                           |                           |
| Video input                           | 1.0 V (p-p), 75 Ω, negative sync., pin jack x 2                             |                           |                           |
| Video output                          | 1.0 V (p-p), 75 Ω, negative sync., pin jack x 1                             |                           |                           |
| Audio input                           | -8 dBm, 50 kΩ, negative sync., pin jack (L/R) x 2                           |                           |                           |
| Audio output                          | -8 dBm, 1 kΩ, negative sync., pin jack (L/R) x 1                            |                           |                           |
| Audio output<br>(DIGITAL COAXIAL)     | 0.5 V (p-p), 75 Ω, pin jack x 1                                             |                           |                           |
| Supplied accessories                  |                                                                             |                           |                           |
| Remote control (WC-SB1) ..... 1       |                                                                             |                           |                           |
| Batteries (R03/AAA) ..... 2           |                                                                             |                           |                           |
| 300-75 Ω matching transformer ..... 1 |                                                                             |                           |                           |

\* Screen size is approximate.

- This model complies with the above specifications.
- Designs and specifications are subject to change without notice.
- This model may not be compatible with features and/or specifications that may be added in the future.

Others



## **Limited warranty**

Toshiba America Consumer Products, L.L.C. ("TACP") makes the following limited warranties. These limited warranties extend to the original consumer purchaser or any person receiving this set as a gift from the original consumer purchaser and to no other purchaser or transferee.

### **Limited Ninety (90) Day Warranty**

TACP warrants this product and its parts against defects in materials or workmanship for a period of ninety (90) days after the date of original retail purchase. During this period, TACP will repair a defective product or part, without charge to you. You must deliver the entire set to an Authorized TACP Service Station. You pay for all transportation and insurance charges for the set to and from the Service Station.

### **Limited One (1) Year Warranty**

TACP further warrants the parts in this product against defects in materials or workmanship for a period of one year after the date of original retail purchase. During this period TACP will replace a defective part without charge to you, except that if a defective part is replaced after ninety (90) days from the date of original retail purchase you pay labor charges involved in the replacement. You must also deliver the entire product to a TACP Authorized Service Station. You are responsible for all transportation for the set to and from the Service Station.

### **Limited Two (2) Year Warranty of Picture Tube**

TACP further warrants the picture tube in this product against defects in materials or workmanship for a period of two (2) years after the date of original retail purchase. During this period, TACP will replace a defective picture tube without charge to you except that if a defective picture tube is replaced after ninety (90) days from the date of the original retail purchase, you pay labor charges involved in the replacement. You are responsible for all charges involved in the replacement. You are responsible for all transportation and insurance charges for the set to and from the Service Station.

### **Rental Units**

The warranty for rental units begins with the first rental or thirty (30) days from the date of shipment to the rental firm, whichever comes first.

### **Commercial Units**

Products sold and used for commercial use have a limited ninety (90) day warranty for all parts, labor and picture tube.

### **Owner's Manual and Demographic Card**

You should read this owner's manual thoroughly before operating this product. You should complete and mail the enclosed Demographic card within ten days after you, or the person who has given you this product as a gift, purchased this product. This is one way to enable TACP to provide you with better customer service and improved products. Failure to return the Demographic card will not affect your rights under this warranty.

### **Your Responsibility**

The above warranties are subject to the following conditions:

- ( 1 ) You must retain your bill of sale or provide other proof of purchase.
- ( 2 ) All warranty servicing of this product must be made by an Authorized TACP Service Station.
- ( 3 ) These warranties are effective only if the product is purchased and operated in the U.S.A. or Puerto Rico.
- ( 4 ) Labor service charges for set installation, set up, adjustment of customer controls and installation or repair of antenna systems are not covered by this warranty. Reception problems caused by inadequate antenna systems are your responsibility.
- ( 5 ) Warranties extend only to defects in materials or workmanship as limited above and do not extend to any product or parts which have been lost or discarded by you or to damage to products or parts caused by misuse, accident, damage caused by Acts of God, such as lightning or fluctuations in electric power, improper installation, improper maintenance or use in violation of instructions furnished by us; or to units which have been altered or modified without authorization of TACP.

## Limited warranty (continued)

### How to Obtain Warranty Service

If after following all of the operating instructions in this manual and checking the section "Troubleshooting" and you still find that service is needed;

- ( 1 ) Call the TACP toll free number 1-800-631-3811 after you find a defective product or part to find the nearest Toshiba Authorized Service Station.
- ( 2 ) Please present your bill of sale or other proof to the Authorized Service Station.  
"TACP Authorized Service Station personnel will come to your home when warranty service is required. Depending on the type of repair required, the service will either be performed in your home or the set will be taken to the TACP Authorized Service Station for repair and returned to your home at no cost to you".

**In the Continental United States contact:**



All warranties implied by state law, including the implied warranties of merchantability and fitness for a particular purpose, are expressly limited to the duration of the limited warranties set forth above. With the exception of any warranties implied by state law as hereby limited, the foregoing warranty is exclusive and in lieu of all other warranties, guarantees, agreements and similar obligations of manufacturer or seller with respect to the repair or replacement of any parts. In no event shall TACP be liable for consequential or incidental damages.

No person, agent, distributor, dealer or company is authorized to change, modify or extend the terms of these warranties in any manner whatsoever. The time within which action must be commenced to enforce any obligation of TACP arising under this warranty or under any statute, or law of the United States or any state thereof, is here by limited to 90 days from the date you discover or should have discovered, the defect. This limitation does not apply to implied warranties arising under state law.

This warranty gives you specific legal rights and you may also have other rights which may vary from state to state. Some states do not allow limitation on how long an implied warranty lasts, when an action may be brought, or the exclusion or limitation of incidental or consequential damages, so the above provisions may not apply to you.

Others

This image shows a full page of white paper with horizontal dotted lines. The lines are evenly spaced and run across the width of the page, providing a guide for handwriting or typing. There are no margins, text, or other markings on the page.



## Others



# TOSHIBA

**TOSHIBA AMERICA CONSUMER PRODUCTS, L.L.C.**



J5T80101B SH 05/04

Printed in Thailand