

Franklin®

BOOKMAN®

ELECTRONIC BOOK CARD

**Crosswords
Puzzle Solver**

USER'S GUIDE

CWQ-2056

Retain for Future Reference

License Agreement

READ THIS LICENSE AGREEMENT BEFORE USING ANY BOOKMAN BOOK CARD.

YOUR USE OF THE BOOKMAN BOOK CARD DEEMS THAT YOU ACCEPT THE TERMS OF THIS LICENSE. IF YOU DO NOT AGREE WITH THESE TERMS, YOU MAY RETURN THIS PACKAGE WITH PURCHASE RECEIPT TO THE DEALER FROM WHICH YOU PURCHASED THE BOOKMAN BOOK CARD AND YOUR PURCHASE PRICE WILL BE REFUNDED. BOOKMAN BOOK CARD means the software product and documentation found in this package and FRANKLIN means Franklin Electronic Publishers, Inc.

LIMITED USE LICENSE

All rights in the BOOKMAN BOOK CARD remain the property of FRANKLIN. Through your purchase, FRANKLIN grants you a personal and nonexclusive license to use the BOOKMAN BOOK CARD on a single FRANKLIN BOOKMAN at a time. You may not make any copies of the BOOKMAN BOOK CARD or of the data stored therein, whether in electronic or printed format. Such copying would be in violation of applicable copyright laws. Further, you may not modify, adapt, disassemble, decompile, translate, create derivative works of, or in any way reverse engineer the BOOKMAN BOOK CARD. You may not export or reexport, directly or indirectly, the BOOKMAN BOOK CARD without compliance with appropriate governmental regulations. The BOOKMAN BOOK CARD contains Franklin's confidential and propriety information which you agree to take adequate steps to protect from unauthorized disclosure or use. This license is effective until terminated. This license terminates immediately without notice from FRANKLIN if you fail to comply with any provision of this license.

Contents

Welcome to the world of BOOKMAN!
BOOKMAN is a powerful, portable electronic reference with a built-in book and a slot in the back for more books such as this one.

Now there's a fun way to make crossword puzzles less puzzling. With your new *Crosswords Puzzle Solver*

you can find possible crossword answers when you know only a few letters. Plus you can find other similarly spelled words, find phrases for a word, and use Topics for more specific searches. Also you can play the Crossword Quiz game to practise your puzzle-solving skills.

Key Guide	3
Installing a Book Card	4
Selecting a Book	4
Using the Colour Keys	5
Viewing a Demonstration	5
Changing the Settings	6
Finding Words	6
Finding Words by Topic	7
Finding More Words	8
Finding Phrases	8
Correcting Misspellings	9
Playing the Quiz Game	9
Your Notes	10
Limited Warranty	11
Book Card Care	11
Resetting Your BOOKMAN	12
Copyrights and Patents	12
Limited Warranty (U.S. Only)	14
Index	15

Key Guide

Colour Keys

MORE **(red)** Expands your search to find similarly spelled words and crossword patterns.

PHRASE **(green)** Displays phrases for a word or crossword pattern.

TOPICS **(yellow)** Displays the Topics menu or Topics for the current word.

QUIZ **(blue)** Starts the Crossword Quiz game.

Other Keys

BACK Takes you back to the previous screen or erases a letter or number.

CARD Exits the book you are reading.

CLEAR Clears to the *Enter a word or pattern*: screen.

ENTER Enters a word or selects a menu item.

HELP Displays help messages.

MENU Displays the main menus.

ON/OFF Turns your BOOKMAN on or off.

SPACE Types a space or pages down.

? * Types a question mark (?) to stand for an unknown letter or shows a full menu item.

Direction Keys



Move in indicated direction.

Pages up or down.

Key Combinations*

☆ + **Q** - **P** Types numbers.

CAP + **↓** Goes to the bottom of a list.

CAP + **↑** Goes to the top of a list.

* Hold one key while pressing the other key.

► Understanding the Colour Keys


The colour keys (red, green, yellow, and blue) perform the functions listed above only for the BOOKMAN book card described in this User's Guide.

Other books have their own colour key functions, which are labelled on their book cards and listed in their User's Guides. For more information, read "Using the Colour Keys."

Installing a Book Card

Warning: Never install or remove a book card while your BOOKMAN is turned on. If you do, information that you entered in its built-in book and in an installed book may be erased.

1. Turn your BOOKMAN off.
2. Turn your BOOKMAN over.
3. Align the tabs on the book card with the notches in the slot.



4. Press the book card down until it snaps into place.

► Removing a Book Card

Warning: When you remove a book card to install another, information that you have entered in the removed book card will be erased.

Selecting a Book

Once you have installed a book card in your BOOKMAN, you can select which book you want to use.

1. Turn your BOOKMAN on.
2. Press **CARD**.



These are sample books.

3. Press **⇨** or **⇩** to highlight the book you want to use.



4. Press **ENTER** to select it.


► About Screen Illustrations

Some screen illustrations in this User's Guide may differ from what you see on the actual screen. This does not mean that your BOOKMAN is malfunctioning.

Using the Colour Keys

The red, green, yellow and blue keys on your BOOKMAN change functions according to which book is selected.

When the built-in book is selected, the colour keys function as labelled on the BOOKMAN keyboard. When a book card is selected, the colour keys function as labelled on that card.




► Resuming Where You Left Off

You can turn off your BOOKMAN at any screen. When you turn your BOOKMAN on again, the screen that you last viewed appears.

Viewing a Demonstration

Before you begin, you may want to view a brief demonstration describing the features of this book. Simply install the book card and then follow these steps.

1. Press **MENU**, if necessary.
2. Use **→** or **←** to highlight the **Setup** menu.
3. Press **↓** to highlight **View Demo**.



4. Press **ENTER** to start the demonstration.
5. To stop the demonstration at any time, press **CLEAR**.

► Help is Always at Hand

You can view a help message at virtually any screen by pressing **HELP**. Use the Direction Keys to read it. To exit help, press **BACK**.

To see a tutorial and key guide describing the functions of this book, select *Tutorial* from the Setup menu.

Changing the Settings

Using the Setup menu, you can adjust the type size, the shutoff time and screen contrast. *Set Shutoff* sets how long the BOOKMAN unit stays on if you forget to turn it off. *Set Contrast* makes the screen lighter or darker.

1. Press **MENU**.
2. Use **⇨** or **⇧** to highlight the Setup menu.
3. Highlight *Set Type Size*, *Set Shutoff* or *Set Contrast*.



4. Press **ENTER**.
5. Press **↑** or **↓** to change the setting.
If you select *Set Contrast*, press **↑** or **↓** repeatedly to make the screen lighter or darker.
To exit without changing settings, press **BACK**.
6. Press **ENTER** to select the new setting.

Finding Words

Crosswords Puzzle Solver helps you find answers to crossword puzzles by finding missing letters. Type a ? in place of each unknown letter and let *Crosswords Puzzle Solver* find all possible matches from its word list.

1. Type a word with ?'s. For example, **CH??E**.

Enter a word or pattern:

CH??E

To erase a letter, press **BACK**.
You can type capitals only.

2. Press **ENTER** to search.

CH??E
CHAFE
CHAPE

3. Press **↓** or **↑** to scroll down the list of matching words.

CH??E
CHAFE
CHAPE

4. Press **CLEAR** when finished.

Finding Words

► Finding Topics for a Word

Some words belong to one or more Topics. If the word “TOPICS” appears at the top right of the screen when a word is highlighted, press **TOPICS** (the yellow key) to view the Topics with which that word is associated.

You can also find the Topics for a word by typing it at the *Enter a word or pattern*: screen and pressing **TOPICS** (yellow). Note: If you misspell a word, type a word that is not recognized, or type a word that does not have any Topics, the entire Topics menu will be shown.

To learn more about Topics, read “Finding Words by Topic.”

► Follow the Arrows

The flashing arrows that you see on the right of the screen show which arrow keys you can press to scroll through menus or text.

Finding Words by Topic

You can even narrow your search by Topic. There are 196 Topics from which to choose. They include everything from *Academics* to *Zoology*. Note: There are no Topics starting with the letters K, Q, X, or Y.

1. Press **TOPICS** (the yellow key).




2. Start typing the desired Topic until it is highlighted. For example, *Bible*.

Or use the Direction Keys to scroll to the desired Topic.

3. Press **ENTER**.

4. Type your crossword guess with ?'s and press **ENTER**. For example, *M????S*.




5. Use ↓ or ↑ to scroll through the list.

6. Press **CLEAR** when finished.

Finding More Words

If the word you are looking for is not found in your search, you can press **MORE** (the red key) to find more possibilities. When you press **MORE** (red), *Crosswords Puzzle Solver* substitutes a letter for one that you have typed. Try this example.

1. **Type a word. For example, type DOT.**
2. **Press **MORE** (red).**



Note: You can also press **MORE** (red) from any word list.


The lowercase letter is the new letter.

3. **Press **↓** repeatedly to view more matches.**
These are all variations, with one letter changed, of the original word *DOT*.
4. **To view the Topics for a word, press **TOPICS** (yellow).**
A word has one or more Topics if the word “TOPICS” appears at the top right of the screen.
5. **Press **CLEAR** when finished.**


Finding Phrases

Crosswords Puzzle Solver can also find phrases that include a key word.

1. **Type a word in a phrase. For example type CAT.**
2. **Press **PHRASE** (the green key).**



Note: You can also press **PHRASE** (green) from any word list.

3. **Press **↓** repeatedly to view the phrases.**
- 
4. **To view a Topic for a phrase, press **TOPICS** (yellow).**
A word has one or more Topics if the word “TOPICS” appears at the top right of the screen.
 5. **Press **CLEAR** when finished.**

Correcting Misspellings

If you are not sure whether a word is spelled correctly, do not worry. The *Crosswords Puzzle Solver* will automatically give you a list of spelling corrections.

1. Type a misspelled word. For example, type **GIRAPHE**.

Enter a word or pattern:

GIRAPHE

To erase a letter, press **BACK**.

2. Press **ENTER**.

CORRECTION LIST

GIRAFEE
GIRAFH
GRAPH

3. Use **↓** or **↑** to highlight a correction if needed.
4. Do one of the following:

To...	Press...
view Topics for the word	TOPICS
view similarly spelled words	MORE
view phrases for the word	PHRASE
5. Press **CLEAR** when finished.

Playing the Quiz Game

Crosswords Puzzle Solver has a fun, challenging Crossword Quiz game which you can play to practise your crossword-puzzle solving skills.

To play, you must guess the letters of a mystery word. Your score appears after each round and clears to zero when you exit the game.

1. Press **QUIZ** (the blue key).

SELECT SKILL LEVEL

Beginner
Intermediate

2. Use **↓** or **↑** to highlight a skill level, if needed.

The skill level changes the number of letters that you must guess for each mystery word. (*Beginner* has two unknown letters and *Wizard* has six unknown letters.) A check tick notes the current setting.

3. Press **ENTER** to select the skill level.

Topic: High scoring words

ADJECTIVES

The Topic of the mystery word appears above the mystery word.

4. Type letters in place of the ?'s.

If you type a letter that is not in the word, you see *No, try again*. If you guess a letter correctly, continue to type letters until *You win!* appears.

5. To reveal the mystery flashing letter hold and press

.

If you reveal a letter, you will automatically lose the current round.

6. To reveal the word and end the round, press .

7. Press to play another round.

8. Press when finished.

Limited Warranty

This product, excluding batteries, is guaranteed by Franklin for a period of one year from the date of purchase. It will be repaired or replaced (at Franklin's discretion) free of charge for any defect due to faulty workmanship or materials.

Products returned under warranty should be sent to the original vendor with proof of purchase and description of fault. Charges will be made for all repairs unless valid proof of purchase is provided.

This warranty explicitly excludes defects due to misuse, accidental damage, or wear and tear. This guarantee does not affect the consumer's statutory rights.

This unit may change operating modes due to Electro-static Discharge. Normal operation of this unit can be re-established by pressing the reset key, **ON/OFF**, or by removing/replacing the batteries.


Book Card Care

- **Do not touch the metal contacts on your book cards.**

Caution: Touching these electrical contacts with statically charged objects, including your fingers, could erase information entered in a book card or built-in book.



- **Do not put excessive weight on your book cards.**



- **Do not expose your book cards to heat, cold, or liquids.**



Resetting Your BOOKMAN

If the BOOKMAN keyboard fails to respond, or if its screen performs erratically, first press **(CLEAR)** and then press **(ON/OFF)** twice. If nothing happens, follow the steps below to reset it.

Warning: Pressing the reset button with more than very light pressure may permanently disable your BOOKMAN. In addition, resetting your BOOKMAN unit erases settings and information entered into its built-in book, and in an installed book.

1. Hold **(CLEAR) and press **(ON/OFF)**.**

If nothing happens, try Step 2.

2. Use a paper clip to gently press BOOKMAN's reset button.

To learn where the reset button is located on your BOOKMAN, read its User's Guide.

▶ Troubleshooting BOOKMAN

- Make sure your book card, if any, is installed correctly.
- Check that your book card's metal contacts are dirt-and dust-free.

Copyrights and Patents

Model: CWQ-2056

Crosswords Puzzle Solver

- size: 5.9 x 4.2 x 0.2 cm
- weight: 0.4 oz.

Contacts

For registration and sales call 1-800-665-5450 (U.S. only) or visit us at www.franklin.com.

Please have your product number (**CWQ-2056**) and date of purchase handy when you call to register. For customer service call 609-239-4333. For technical support call 609-386-8997.

© 1996-1999 Franklin Electronic Publishers, Inc., Burlington, NJ 08016-4907 USA. All rights reserved.

© 1994 Chambers Harrap Ltd. All rights reserved

U.S. Patents: 4,490,811; 4,830,618;
4,891,775; 5,113,340; 5,203,705; 5,218,536;
5,396,606; 5,249,965

German Pats. M 9409743.7;
M 9409744.5

Euro Patents 0 136 379

ISBN 1-56712-345-7

Franklin Electronic Publishers (Europe) Ltd
11&12 Windmill Business Village
Brooklands Close
Sunbury-on-Thames
Middlesex TW16 7DY
United Kingdom

This product, excluding batteries, is guaranteed by Franklin for a period of one year from the date of purchase. It will be repaired or replaced with an equivalent product (at Franklin's option) free of charge for any defect due to faulty workmanship or materials.

Products purchased outside the United States that are returned under warranty should be returned to the original vendor with proof of purchase and description of fault. Charges will be made for all repairs unless valid proof of purchase is provided.

This warranty explicitly excludes defects due to misuse, accidental damage, or wear and tear. This guarantee does not affect the consumer's statutory rights.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This unit was tested with shielded cables on the peripheral devices. Shielded cables must be used with the unit to insure compliance.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Limited Warranty (U.S. only)

LIMITED WARRANTY, DISCLAIMER OF WARRANTIES AND LIMITED REMEDY

(A) LIMITED WARRANTY. FRANKLIN WARRANTS TO THE ORIGINAL END USER THAT FOR A PERIOD OF ONE (1) YEAR FROM THE ORIGINAL DATE OF PURCHASE AS EVIDENCED BY A COPY OF YOUR RECEIPT, YOUR FRANKLIN PRODUCT SHALL BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP. THIS LIMITED WARRANTY DOES NOT INCLUDE DAMAGE DUE TO ACTS OF GOD, ACCIDENT, MISUSE, ABUSE, NEGLIGENCE, MODIFICATION, UNSUITABLE ENVIRONMENT OR IMPROPER MAINTENANCE. THE SOLE OBLIGATION AND LIABILITY OF FRANKLIN, AND YOUR EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY, WILL BE REPAIR OR REPLACEMENT WITH THE SAME OR AN EQUIVALENT PRODUCT OF THE DEFECTIVE PORTION OF THE PRODUCT. AT THE SOLE OPTION OF FRANKLIN IF IT DETERMINES THAT THE PRODUCT WAS DEFECTIVE AND THE DEFECTS AROSE WITHIN THE DURATION OF THE LIMITED WARRANTY, THIS REMEDY IS YOUR EXCLUSIVE REMEDY FOR BREACH OF THIS WARRANTY. THIS WARRANTY GIVES YOU CERTAIN RIGHTS; YOU MAY ALSO HAVE OTHER LEGISLATED RIGHTS THAT MAY VARY FROM JURISDICTION TO JURISDICTION.

(B) DISCLAIMER OF WARRANTIES AND LIMITATION OF LIABILITY. EXCEPT FOR THE LIMITED WARRANTIES EXPRESSLY RECITED ABOVE, THIS FRANKLIN IS PROVIDED ON AN "AS IS" BASIS, WITHOUT ANY OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR THOSE ARISING BY LAW, STATUTE, USAGE OF TRADE, OR COURSE OF DEALING. THIS WARRANTY APPLIES ONLY TO PRODUCTS MANUFACTURED BY FRANKLIN AND DOES NOT INCLUDE BATTERIES, CORROSION OF BATTERY CONTACTS OR ANY OTHER DAMAGE CAUSED BY BATTERIES. NEITHER FRANKLIN NOR OUR DEALERS OR SUPPLIERS SHALL HAVE ANY LIABILITY TO YOU OR ANY OTHER PERSON OR ENTITY FOR ANY INDIRECT, INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING, BUT NOT LIMITED TO, LOSS OF REVENUE OR PROFIT, LOST OR DAMAGED DATA OR OTHER COMMERCIAL OR ECONOMIC LOSS, EVEN IF WE HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR THEY ARE OTHERWISE FORESEEABLE. WE ARE ALSO NOT RESPONSIBLE FOR CLAIMS BY A THIRD PARTY. OUR MAXIMUM AGGREGATE LIABILITY TO YOU, AND THAT OF OUR DEALERS AND SUPPLIERS, SHALL NOT EXCEED THE AMOUNT PAID BY YOU FOR THE FRANKLIN PRODUCT AS EVIDENCED BY YOUR PURCHASE RECEIPT. YOU ACKNOWLEDGE THAT THIS IS A REASONABLE ALLOCATION OF RISK. SOME STATES/COUNTRIES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. IF THE LAWS OF THE RELEVANT JURISDICTION DO NOT PERMIT FULL WAIVER OF IMPLIED WARRANTIES, THEN THE DURATION OF IMPLIED WARRANTIES AND CONDITIONS ARE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY GRANTED HEREIN.

(C) WARRANTY SERVICE: UPON DISCOVERING A DEFECT, YOU MUST CALL FRANKLIN'S CUSTOMER SERVICE DESK, 1-800-266-5626, TO REQUEST A RETURN MERCHANDISE AUTHORIZATION ("RMA") NUMBER, BEFORE RETURNING THE PRODUCT (TRANSPORTATION CHARGES PREPAID) TO:

FRANKLIN ELECTRONIC PUBLISHERS, INC.
ATTN: SERVICE DEPARTMENT
ONE FRANKLIN PLAZA
BURLINGTON, NJ 08016-4907

IF YOU RETURN A FRANKLIN PRODUCT, PLEASE INCLUDE A NOTE WITH THE RMA, YOUR NAME, ADDRESS, TELEPHONE NUMBER, A BRIEF DESCRIPTION OF THE DEFECT AND A COPY OF YOUR SALES RECEIPT AS PROOF OF YOUR ORIGINAL DATE OF PURCHASE. YOU MUST ALSO WRITE THE RMA PROMINENTLY ON THE PACKAGE IF YOU RETURN THE PRODUCT. OTHERWISE THERE MAY BE A LENGTHY DELAY IN THE PROCESSING OF YOUR RETURN. WE STRONGLY RECOMMEND USING A TRACKABLE FORM OF DELIVERY TO FRANKLIN FOR YOUR RETURN.

Index

About screen illustrations 4

Book card

- care 11
- installing 4
- removing 4

BOOKMAN

- resetting 12
- troubleshooting 12
- turning on 4

Changing, settings 6

Colour keys

- understanding 3
- using 5

Contrast, Changing 6

Correcting misspellings 9

Crossword Quiz Game 9

Demonstration, viewing 5

Finding

- phrases 8
- Topics for a word 7

Function keys 3

Games

- selecting a skill level 9
- playing games 9

Help is always at hand 5

Help, using 5

Missing letters, finding 6

Misspellings, correcting 9

MORE (the red key), using 8

Number keys 3

Phrases, finding 8

Playing Quiz (the blue key) 9

Quiz game, playing the 9

Resuming where you left off 5

Screen illustrations 4

Set Contrast 6

Set Shutoff 6

Settings, Changing 6

Shutoff time, setting 6

Topic, finding words by 7

Topics, finding 7

Tutorial 5

Understanding the colour keys 3

Using MORE (the red key) 8

Using PHRASES (the green key) 8

Using TOPICS (the yellow key) 7

Viewing

- demo 5
- tutorial 5

FRB-28071-00
P/N 7201146

Franklin®

Electronic Publishers

www.franklin.com