



# **JVC**

**ENGLISH** 

InteriArt

LT-23C88SJ

WIDE LCD PANEL TV

**JVC** 





### **Contents**

For your safety1
Important Instruction 3
Important Information 4
Remote Control Buttons 5
Control Panel Buttons 6
Where to install9
Preparation 10
Before Switching on your TV 10
Switching the TV ON/OFF11
Operating the TV 12
Operating the TV 13
Menu System14
Other Features 20
PC Mode 23
Teletext25
Peripheral Equipment Connections 26
Peripheral Equipment Connections 28
Antenna Connections 29
Peripheral Equipment Connections 29
PC Input Typical Display Modes 30
Tips 31
Charifications 22

# For your safety


This equipment has been designed and manufactured to meet international safety standards but, like any electrical equipment, care must be taken if you are to obtain the best results and safety is to be assured. So, please read the points below for your own safety. They are of a general nature, intended to help you with all your electronic consumer products and some points may not apply to the goods you have just purchased.

# Some "DOs" and "DON'Ts" for you Air Circulation...

Leave at least 10cm clearance around the television to allow adequate ventilation. This will prevent the TV from overheating and consequential possible damage to the TV. Dusty places should also be avoided.

### Heat Damage...

Damage may occur if you leave the TV in direct sunlight or near a heater. Avoid places subject to extremely high temperatures or humidity, or locations where the temperature is likely to fall below 5°C (41°F).



### Mains Supply...

The mains supply required for this equipment is 100-240 V AC, 50 Hz. Never connect to a DC supply or any other power source. DO ensure that the TV is not standing on the mains lead. DO NOT cut off the mains plug from this equipment, this incorporates a special Radio Interference Filter, the removal of which will impair its performance.

### **Hot / Moderate Climate Conditions**

This device is suitable for working in hot and moderate climate conditions.

IF IN DOUBT PLEASE CONSULT A COMPETENT ELECTRICIAN.
Do...

**DO** read the operating instructions before you attempt to use the equipment.

**DO** ensure that all electrical connections (including the mains plug, extension leads and inter-connections between pieces of equipment) are properly made and in accordance with the manufacturers' instructions.

Switch off and withdraw the mains plug before making or changing connections.

**DO** consult your dealer if you are ever in doubt about the installation, operation or safety of your equipment.

**DO** be careful with glass panels or doors on equipment.

### DO NOT...

**DON'T** remove any fixed cover as this may expose dangerous voltages.

**DON'T** obstruct the ventilation openings of the equipment with items such as newspapers, table-cloths.

curtains etc. Overheating will cause damage and shorten the life of the equipment.

**DON'T** allow electrical equipment to be exposed to dripping or splashing or objects filled with liquids, such as vases, to be placed on the equipment.

**DON'T** place hot objects or naked flame sources, such as lighted candles or nightlights on, or close to the equipment. High temperatures can melt plastic and lead to fires.

**DON'T** use makeshift stands and NEVER fix legs with wood screws. To ensure complete safety, always fit the manufacturer's approved stand or legs with the fixings provided according to the instructions.

**DON'T** listen to headphones at high volume, as such use can permanently damage your hearing.

**DON'T** leave equipment switched on when it is unattended, unless it is specifically stated that it is designed for unattended operation or has a standby mode. Switch the equipment off and make sure your family know how to do this. Special arrangements may need to be made for infirm or handicapped people.

**DON'T** continue to operate the equipment if you are in any doubt about it working normally, or it is damaged in any way – switch off, withdraw the mains plug and consult your dealer.

**DON'T** put the empty batteries into garbage instead of recycle bin to reduce harmfull effects to the environment.

ABOVE ALL – NEVER let anyone, especially children, push anything into holes, slots or any other openings in the case – this could result in a fatal electric shock.

NEVER guess or take chances with electrical equipment of any kind – it is better to be safe than sorry.

To fully disconnect the TV, switch off the mains socket and remove the Power plug. Safety Precautions for Power adapter

- · Be careful! May become hot.
- · For indoor and dry location use only.
- Risk of electric shock.
- · Shock hazard, do not open.
- Keep all power adapters away from any other heat source.
- Always use power adapter(s) well-ventilated area.
- \*\* Cold cathode fluoresant lamp in LCD PANEL contains a small amount of mercury, please follow local ordinates or regulations for disposal.


"The LCD panel is very high technology product with about a million thin film transistors, giving you fine picture details. Occasionally, a few non-active pixels may appear on the screen as a fixed point of blue, green or red. Please note that this does not affect the performance of your product." Please note that certain light guns used with games consoles may not work on this product.

## **Warning:**

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

#### WARNING

- Fingers may be trapped under the TV causing injuries. Hold the TV at the bottom in the middle, and do not allow it to tilt up or down.
- The TV may fall causing injuries. Hold the bottom of the stand with your hand and tilt the TV up and down.
- Do not allow children to hang from the TV, place their elbows on the TV or lean against the TV. Doing so may cause the TV to fall over and lead to injuries.



### **CAUTION:**

 To avoid electric shock or damage to the unit, first firmly insert the small end of the power cord into the AC Adapter unit it is no longer wobbly, and then plug the larger end of power cord into an AC outlet.

# Important Instruction

For your own safety read following instruction carefully before attempting to connect this unit to the mains supply.

# MAINS (AC) OPERATION

The wires in this mains lead are coloured in accordance with the following code :

### **BLUE-NEUTRAL**

### **BROWN-LIVE**


As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

No connection is to be made to the earth terminal of the plug.

If a 13 Amp (BS 1363) Plug is used a 5 Amp Fuse must be fitted, or if any other type of Plug is used a 5 Amp Fuse must be fitted, either in the Plug of Adaptor, or on the Distribution Board.



### CAUTION

TO PREVENT ELECTRIC SHOCK DISCONNECT FROM THE MAINS BEFORE REMOVING COVER. NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

### SAFETY PRECAUTION

THIS EQUIPMENT MUST BE DISCONNECTED FROM THE MAINS WHEN NOT IN USE. DO NOT ALLOW THIS UNIT TO BE EXPOSED TO RAIN OR MOISTURE.

# **Important Information**

## Please take note

### **EXCLUSION CLAUSE**

JVC shall under no circumstances be liable for loss and/or damage to the product caused by:

- fire:
- · earthquake;
- · accidental damage;
- · intentional misuse of the product;
- use of the product in improper conditions:
- loss and/or damage caused to the product whilst in the possession of a third party;
- any damage or loss caused as a result of the owner's failure and/or neglect to follow the instructions set out in the owner's manual:
- any loss or damage caused directly as a result of misuse or malfunction of the product when used simultaneously with associated equipment;

Furthermore, under no circumstances shall JVC be liable for any consequential loss and/ or damage including but not limited to the following, loss of profit, interruption of business, the loss of recorded data whether caused during normal operation or misuse of the product.

# WARNING! NEVER LEAVE A STATIONARY IMAGE ON THE SCREEN

If stationary images generated by TELETEXT, CHANNEL IDENTIFICATION LOGOS, COMPUTER DISPLAYS, VIDEO GAMES, ON SCREEN MENUS, etc. are left on the TV screen for any length of time, they could become permanently ingrained.

If you use your television to display completely still images, or moving pictures which have a permanent still image superimposed e.g. broadcast network logos, it is always advisable to reduce BOTH the brightness and contrast settings.

# Care and disposal

### Cleaning the screen and cabinet...


Turn off the power, clean the screen and cabinet with a soft, dry cloth. We recommend that you do not use any proprietary polishes or solvents on the screen or cabinet as this may cause damage.

### Disposal...


When the set reaches the end of its useful life please dispose of it in accordance with Local Government Regulations or at a recycling centre.

# **Remote Control Buttons**

- 1) **b**/I = (Stand By) button
- (2) TV / VCR / DVD Switch
- (3) Number buttons
- (4) **AV** button (TV, EXT-1, EXT-2, EXT-2 S, EXT-3, EXT-4, EXT-4 S or PC)
- (5) BLUE / PICTURE Mode button
- 6 YELLOW / Sleep Timer button
- (7) **MENU** button
- 8 ▲ = Cursor Up button
- 9 OK button
- 10 = Cursor Right button
- (11) BACK button
- 12 = Volume + / buttons
- 13 Teletext / VCR / DVD Control buttons
- (14) PC Control Buttons
- (15)  $P \land / \lor$  buttons
- (16) ▼ = Cursor Down button
- 17 = Teletext Button
- 18 ◀= Cursor Left button
- (19) W I/II = Stereo / Bilingual button
- 20 GREEN / Hyper Sound On/Off button
- 21 RED / ZOOM Mode button
- 23 🕱 = Mute button



# **Control Panel Buttons**



With certain combinations of connectors and leads the back cover may not be easily fitted. If the cover is left off, this in no way infringes safety requirements.

### Using the stand

### This TV comes with a Table Top Stand already attached.

This stand can be used to adjust the direction of the TV screen 5° up, 10° down, and 20° to the left or right.

### Tilt the TV up and down:

While holding the bottom of the stand with one hand, use your other hand to hold the middle of the top of the TV and slowly tilt the TV up and down.

 As a safety measure, the stand is constructed so that it requires a certain amount of force to tilt the TV.




### Rotate the TV to the left and right:

While holding the bottom of the stand with one hand, use your other hand to hold the odge of the panel and slowly adjust the direction of the TV screen.



### Cable holder

A cable holder which is used to keep the connection cables tidy is attached to the back of the stand.




### Remove the terminal Cover

There are connection terminals behind the covers of the rear of the TV. Remove the cover before connecting an antenna, DVD or VCR.

Remove the covers by removing the hooks. When replacing the covers, place the side or bottom of the covers against the TV and insert the hooks.

- Leave the covers off if they do not fit properly. DO NOT force to replace the covers. Doing so may cause damages of the connection cables and the covers.
- · Leave these covers off when mounting the TV on a wall.



- 100 mm mount based on VESA regulation is equipped.
- The handle and the stand can be left by loosing the screws with a screwdriver when mounting the TV on a wall.
- Spread a soft cloth on a flat table and then place the TV on the cloth with the screen facing downwards when you leave the handle and the stand.


### Where to install

Locate the TV away from direct sunlight and strong lights, soft, indirect lighting is recommended for comfortable viewing. Place on a sturdy platform, the mounting surface should be flat and steady, it should then be secured to the wall with a sturdy tie using the hook on the back of the TV, this will prevent it from falling over. Use curtains or blinds to prevent direct sunlight falling on the screen.

A floor and table top stand are available for this television, or and angled bracket which enables the TV to be wall-mounted.

The LCD display panels are manufactured using an extremely high level of precision technology, however sometimes some parts of the screen may be missing picture elements or have luminous spots. This is not a sign of a malfunction.


Make sure the TV is located in a position where it cannot be pushed or hit by objects, as pressure will break or damage the screen.



# **Preparation**

Install Display on solid horizontal surface such as a table or desk

For ventilation, leave a space of at least 10 cm free all around the set. To prevent any fault and unsafe situations, please do not place any objects on top of the set.



### **Features**

- It is a remote controlled colour television and PC monitor.
- 100 programmes from VHF, UHF bands or cable channels can be preset.
- It can tune cable channels.
- Controlling the TV is very easy by its menu driven system.
- It has 2 pieces of Euroconnector socket for external devices (such as video, video games, audio set, etc.)
- To use as a PC monitor, 15 Pin Mini D-Sub connector for computer.
- Optional stereo sound systems (German or German+Nicam) are available.
- Multilanguage OSD.
- Teletext (Fastext, 7 pages).
- It is possible to connect headphone.
- A.P.S. (Automatic programming system)
- All programmes can be named.
- Forward or backward automatic tuning.
- Sleep timer.
- Child lock
- Auto, Full, Regular, Panoramic, 14:9 Zoom,16:9 Zoom,16:9 Zoom Subtitle modes.

- Automatic sound mute when no transmission.
- When no valid signal is detected, after 5 minutes the TV switches itself automatically to stand-by mode.
- NTSC Playback.
- Universal power supply range is a standard feature on this model.
- TV Picture in PC (if PC input available).
- PLL (Channel Search)
- PC input (Support Up to 1360 x 768)


### **Panel Features**

- High resolution, 23"-inch TFT LCD display.
- High contrast ratio (800:1 Typical)
- Brightness: 500 cd/m<sup>2</sup>
- High-speed response time < 25 msec.
- Wide viewing angle (typical) 170° (horizontal) and 170" (vertical).
- 8-bit colour depth, display 16.7 M colours.

# Before Switching on your TV

### Power connection

Only use the adaptor supplied with this product.




IMPORTANT: The TV set is designed to operate on 24 V DC. For this, an adaptor is used which gives 24 V DC voltage. Connect this adaptor to a system that supplies 100 -240V AC, 50 Hz.

 After unpacking, allow the TV set to reach the ambient room temperature before you connect the set to the mains.

# Connections to the RF input socket

 Connect the aerial or cable TV plug to the RF input socket located at the back of the TV and connect the cable plug coming out from the TV out socket located at the devices (VCR, DVB etc.) to this socket as well.




### How to connect other devices

**IMPORTANT:** Switch off the TV before connecting any external device.

Sockets for external connections are at the back of the TV. For connection of other devices via Euroconnector refer to the manuals of the related devices.

# Inserting batteries in the remote control handset

- Remove the battery cover located on the back of the handset by gently pulling upwards from the indicated part.
- Insert two AA/R6 dry cell or equivalent type of batteries inside.
- Replace the battery cover.



**NOTE:** Remove the batteries from remote control handset when it is not to be used for a long period. Otherwise it can be damaged due to any leakage of battery.

Old batteries must be disposed in a designated area. If performance of the remote control reduces, replace the batteries with the correct type. Do not combine a used, old battery or a new one or mixed battery types. Remove dead batteries immediately to prevent acid from leaking into the battery compartment.

# Switching the TV ON/OFF

### To switch the TV on

Your TV will switch on in two steps:

- 1- Connect the power supply cord to the system. Then the TV switches itself to standby mode and the power lamp becomes red located on the front of the TV.
- **2-** To switch on the TV from stand-by mode either:

Press the "O" button on the remote control or on the right side of the TV

or.

press a digit button on the remote control so that a programme number is selected,

or

Press "**P/Ch**" button on the right side of the TV or press "**P** $\checkmark$ " or "**P** $\checkmark$ " buttons on the remote control, so that last switched off programme is selected.

By either ways the TV will switch on and the power lamp will become green.

### To switch the TV off

• Press the "🖒" button on the remote control or on the right side of the TV, so the TV will switch to stand-by mode and the power lamp will become red.

**NOTE:** To switch the TV off completely remove the mains plug from the socket.

# Operating the TV

You can operate your TV both using the remote control handset and onset buttons.

# First A.P.S. (Automatic Programming System)

APS, searches and sorts all channels and stores them automatically on your TV, according to the transmission of programme systems in your area.



To cancel APS before starting, press BLUE button.

First of all choose the "Language" which the menus of the TV will appear. As soon as you change the language, the menu items will be displayed in the selected language. By pressing the "▲" or "▼" button, come to the "Country" item and select the country. This will effect the sort process in APS. Press red button to start A.P.S.

After APS is finalized, a programme list will appear on the screen. In the programme list you will see the programme numbers and names assigned to the programmes.

If you press the BLUE button at any time while the A.P.S. is running, the A.P.S. will be ended.

If you do not accept the locations and / or the programme names of programmes, you can change them in Program menu. For details see **Program Menu** on page 19.

If you do not have a T-V Link compatible VCR, press BLUE button to exit the menu.

If you have aT-V Link compatible VCR connected to the EXT-2 terminal, press "①" button to display T-V Link menu. Then follow the operating procedure "Downloading data to VCR" in the following T-V Link section.

### T-V Link

When a T-V Link compatible VCR connected to the EXT-2 terminal on the TV, it is easier to set up the VCR and to view videos. T-V Link uses the following features:

### To use T-V Link functions

A "T-V Link compatible VCR" means a JVC video cassette recorder with the T-V Link logo, or with one of the following logos. For details see your VCR instruction manual.

"Q-LINK" (A trademark of Panasonic Corporation)

"Data Logic" (A trademark of Metz Corporation)

"Easy Link" (A trademark of Phillips Corporation)


"Megalogic" (A trademark of Grundig Corporation)

"SMARTLINK" (A trademark of Sony Corporation)

### Downloading data to VCR:

menu is displayed.

The VCR will automatically download the registered data on the TV channels from the TV. This means you do not need to set up the programme channels on your VCR manually. The "T-V Link" menu will be displayed when you press the "fi" button while Program



Press "▶" or "OK" button to start downloading data to VCR. "TRANSFER" is displayed in the menu



If you do not want to continue press the BLUE button to exit the menu.

If "FEATURE NOT AVAILABLE" is displayed,

download was not performed correctly. Before trying to download again, check that:

- The VCR power is turned on.
- The VCR is T-V Link compatible.
- The VCR is connected to the EXT-2.
- The scart cable is fully wired.

### **Direct REC:**

You can easily record to VCR the images that you are watching on the TV. For details, read the manual for your VCR. Use your VCR controls you can not carry out Direct REC using your TV control.

When the VCR is not ready (For example when there is no tape inserted), "NO RECORDING" is displayed. In the following situations, the VCR will stop recording if the Tv is turned off, if the TV channel or input is changed, or if the menu is displayed on the TV:

- When recording images from an external device connected to TV (For example camcorder).
- When recording a TV channel after it has been unscrambled on a decoder.
- When recording a TV channel by using the TV's output because the VCR's own tuner can not properly receive that channel.

### TV autopower on/VCR image view:

When the VCR starts playing, the TV automatically turns on and images from EXT-2 appear on the screen.

This function does not happen if your TV's main power is turned off. Set your TV's main power to on (StandBy Mode).

# Operating the TV

You can operate your TV both using the remote control handset and onset buttons.

Volume setting and programme selection can be made by using the buttons at the control panel on the right side of the TV.

### **Volume Setting**

Press " - " button to decrease volume or " + " button to increase volume, so a volume level scale (slider) will be displayed at the middle of the bottom on the screen.

### **Programme Selection**

Press "P\sqrt{"" button to select the next programme or "P\sqrt{"" button to select the previous programme.

### **Entering Main Menu**

Press "MENU" button to enter Main menu. In the Main menu select submenu using "P√" or "P^" button and enter the submenu using " -" or " -" +" button. To learn the usage of the menus, refer to the Menu System sections.

# **Operating with Remote Control**


The remote control handset of your TV is designed to control all the functions of the model you selected. The functions will be described in accordance with the menu system of your TV.

Functions of the menu system are described in following sections.

### **Volume Setting**

Press " +" button to increase volume.

Press " -" button to decrease volume. A volume level scale (slider) will be displayed in the middle at the bottom of the screen.



# Programme Selection (Previous or next programme)

- Press "P\scrip" button to select the previous programme.
- Press "P\" button to select the next programme.

### **Programme Selection (direct access):**

Press digit buttons on the remote control handset to select programmes between 0 and 9. TV will switch to the selected programme. To select programmes between 10 - 99, press the digit buttons consecutively which programme you want to select (eg. for programme 27, first press 2 and then 7). When it is late to press second digit button only the first digit programme will be displayed. The limit of the delay time is 3 seconds

.Example: PR6  $\rightarrow$  press 6, PR12  $\rightarrow$  press 1and 2 . PR123  $\rightarrow$  press 1.2 and 3.

Press directly the programme number to reselect single digit programmes.

Hint: The channel list numbers are assigned by the broadcasters. Because not all channels are broadcast free-to-air and stored by the receiver, the channel list numbers do not run continuously. The fifteenth channel in the list, for example, may not be channel number 15 but channel number 17.

# Menu System

Your TV has been designed with a menu system to provide an easy manipulation of a multifunction system. The TV is controlled by choosing the commands, which are displayed on the screen.

### MAIN MENU

Press the "**MENU**" button. The main menu will be displayed in the middle of the screen.



To select a sub-menu use "▲" or "▼" button, and press "◀" or "▶" button or directly press "OK" button.

In EXT-1, EXT-2 and EXT-4 modes, main menu appears the same as in TV mode but without Program sub-menu.

In EXT-3 mode, Main Menu appears as follows:



Menu does not disappear automatically if it is left on the screen.

Press "MENU" button again to remove menu.


### Picture Menu

Press "MENU" button, now you are in main menu. In the Main menu, select "Picture" using "▲" or "▼" button, then enter the Picture menu pressing "◄" / "▶" or "OK" button.

### **Setting Mode**


- As you enter the picture menu, Mode will be the first item.
- By pressing "◀" or "▶" button you may choose one of these options:

### Soft, Standard and Bright.




### **Setting Contrast**

- Using "▲" or "▼" button select Contrast.
- Press "▶" button to increase contrast level.
- Press "◀" button to decrease contrast level.



### **Setting Bright-1**


- Using "▲" or "▼" button select Bright-1.
- Press ">" button to increase brightness.
- Press "◀" button to decrease brightness.



### **Setting Sharpness**


Using "▲" or "▼" button select Sharpness.

- Press ">" button to increase sharpness level.
- Press "◀" button to decrease sharpness level.



### **Setting Colour**


- Using "▲" or "▼" button select Colour.
- Press ">" button to increase colour level.
- Press "◀" button to decrease colour level.



### **Setting Bright-2**

Using" ▲ " or " ▼" button select Bright-2.

- Press ">" button to increase the back light.
- Press "◀" button to decrease the back light.



### **Setting Colour Temp.**

- Using " ▲ " or " ▼ " button select Colour Temp.
- Press "◀" or "▶" button to select "Warm", "Cool" or "Normal".

### **Setting Noise Reduction**

- Using "▲" or "▼" button select Noise Reduction
- Press "◀" or "▶" button to select Noise Reduction level "Off" or "Minimum" or "Medium" or "Maximum

#### Note 1:

At low signal level, the changings on the Noise Reduction function are not effective when there is menu on the screen. If the menu is removed, the effect of this function is seen. At normal broadcasting, Noise Reduction changings are effective at once.

#### Note 2:

At moving pictures, while Noise Reduction is at maximum level, some picture distortions may occur. If Noise Reduction is set to medium or minimum, the picture will improve.

### **Setting Hue**

During Playback NTSC system, this will appear in AV mode only when NTSC video source is applied. Otherwise, HUE option is invisible in Picture menu in TV mode:

- Using "▲" or "▼" button select Hue.
- Press ">" button to increase hue level.
- Press "◀" button to decrease hue level.

Center value is indicated with one arrow.

### Reset

Press BLUE button to reset the picture modes to factory default settings.

## To Store the Settings

In the Picture Menu, all settings are stored automatically.

### Sound Menu

### To change sound settings

As you enter the main menu, sound will be the second item. In the main menu, select **Sound** using "▲" or "▼" button, then enter the sound menu pressing "◄" / "▶" or "OK" button.


### **Setting Volume:**

As you enter the sound menu, Volume will be the first selected option.

Press ">" button to increase volume.

Press "◀" button to decrease volume.

Or you can directly change the volume settings using " +" (to increase) or "- •" (to decrease) button.



### **Setting Bass Level**

- Using "▲" or "▼" button select Bass Level.
- Press ">" button to increase bass level.
- Press "◀" button to decrease bass level.

### **Setting Treble Level**

- Using "▲" or "▼" button select Treble
- Press ">" button to increase treble level.
- Press "◀" button to decrease treble level

### **Setting Balance**

It allows adjusting the distribution between the left and right speakers.

- Using "▲" or "▼" button select Balance.
- Press "▶" button to change balance rightward.
- Press "◀" button to change balance leftward.

### Hyper Sound

- Using " ▲ " or " ▼ " button select Hyper Sound
- Pressing "◀" or "▶" button will turn on or off this feature.

Pseudo/spatial effect can be turned on or off via the Hyper Sound item in the Sound menu or by remote control. In Mono transmission the left and right channels will be added at left channel and dummy stereo effect will introduced to end-user.

In stereo transmission it yields a phase difference between left and right channels. Hyper Sound selection will be displayed on the

screen when the TV Status button is pressed or programme is changed.

### **To Change Audio Out Settings**

Audio Out is a sub-menu of Sound menu.

Use this settings to adjust volume for audio out terminal which is located at the right side of the TV.

- Using "▲" or "▼" button select Audio Out.
- Press "◀" or "▶" button or directly press
   "OK" button on Audio Out, to enter the Audio
   Out menu.



### **Audio Out Volume**

- As you enter the Audio Out sound menu, Volume will be the only option.
- Press ">" button to increase volume.
- Press "◀" button to decrease volume.

### **Selecting Sound Mode**

- Using "▲" or "▼" button select Sound Mode
- Press "◀" or "▶" button to change Sound Mode.

You can choose **Mono**, **Stereo** or **Dual** (I-II) mode, only if the selected channel supports that Sound mode.

You can also change sound mode directly pressing "I-II" button on your remote control.


In case of bilingual broadcast (Dual Sound), you can select original or dubbed language using mode option. So when somebody listens to the original language from the loudspeakers, somebody else can listen to the dubbed language from headphone.

### To Store The Settings

In the Sound Menu, all settings are stored automatically.

### **Feature Menu**

Press "MENU" button, now you are in mainmenu. In the main menu, select Feature using "▲" or "▼" button. Then enter the Feature menu pressing "◄" / "▶" or "OK" button.



### **Sleep Timer**

The Sleep Timer is used to turn the TV off after a defined period of time after selecting this item. The timer can be programmed between Off and 120 minutes in steps of 10 minutes. (Off, 010, 020, 030, 040, ..., 120)

If sleep timer is activated, at the end of the selected the time, the TV goes automatically to stand-by mode.

#### Child Lock

You can use this feature to prevent children turning on/off TV or changing programmes or adjustments etc. without remote control.

- Using "▲" or "▼" button select Child Lock.
- Press "◀" / "▶" button to select Child Lock
   On or Off.

The Child Lock feature can be set On or Off by

"
"
" button. When **Off** is selected, there will be no difference in the operation of your TV. When **On** is selected, the TV can only be controlled by the remote control handset. In

this case the control panel buttons except "O" button on the right side of the TV will not work.

### **Selecting Menu Language**

- Using "▲" or "▼" button select Language.
- Press "◀" or "▶" button to select menu language.

### **EXT-2 Output**

From EXT-2 Output; **TV**, **EXT-1** or **EXT-4** can be given. These modes can be chosen by pressing "◀" or "▶" button on "**EXT-2 Output**".

Feature			
Sleep Timer	Off		
Child Lock	Off		
Language	English		
EXT-2 Output	TV		
Blue Back	Off		

### Blue Back (During No Signal)

The Blue Back Feature can be set by "▲" or "▼" button to either On or Off.

### **To Store Settings**

In Feature menu all settings are stored automatically.

### **Install Menu**

Press "MENU" button, now you are in main menu. In the main menu, select "Install" using ▲ " or "▼" button. Then enter the Install menu pressing "◄" / "▶" or "OK" button.

	Install
Programme	P 02
Band	С
Channel	02
Colour System	Auto
Sound System	1
Fine Tuning	<b>(</b>
Search	048.25
Decoder(EXT-2)	Off
VCR	Off
Store	

In EXT mode, Install menu appears like this:

Install			
Colour System	Auto		
VCR	Off		

You can change only Colour system and VCR.

### **Selecting Programme**

- Using "▲" or "▼" button select Programme.
- To select programme number, you can use
  "◀" / "▶" button or Digit Buttons

### **Selecting Band**

Band, can be chosen either,

• "C" or "S" by "◀" or "▶" button.

### **Selecting Channel**

**Channel** can be changed by "◀" or "▶" button or by Digit Buttons.

### **Selecting Colour System**

Using "◀" or "▶" button on Colour System, you can change the colour system to PAL, SECAM or Auto.

**Note:** In EXT mode, you can choose NTSC 3.58 and NTSC 4.43 as well.

### **Selecting Sound System**

Using "◀" or "▶" button on **Sound System**, you can change the standard to **BG**, **DK**, **I**, **L**, **Lp**.

### **Selecting Fine Tuning**

You can use the Fine Tuning process for fine adjustment (after coarse adjustment), if you are not happy about the image on the screen.

Use "◀" or "▶" button on **Fine Tuning** item, until getting the best image on the screen.

### **Selecting Search**

To start the search process, press "▶" button for forward search or "◄" button for backward search. If a signal is found or reaches to end of the band after searching, press "◄" or "▶" buttons to continue search process. To stop the search process when you want, press "◄" or "▶" buttons at any time.

### Decoder (EXT-2)

You can use this mode to connect any decoder to your TV.

• Press the"◀" or "▶" buttons to set it "On" or "Off".

When you select Decoder(EXT-2) "On", EXT-2 output will be chosen as TV mode only and any scrambled channels will be unscrambled through decoder connected your TV via EXT-2 output.

# Setting VCR ( Video Cassette Recorder ) Mode

 This item can be seen in TV, EXT-1, EXT-2, EXT-3 and EXT-4 modes.

- If you want to watch a VCR source from one of these modes, then it will be better to set VCR mode "On". For this, while the cursor is on this item press the "■" buttons to set it "On".
- If you want to watch a DVD, then you must set this item "Off"; because DVD is not a source like a VCR and to see the picture better, you must set the VCR mode "Off".


### **To Store Settings**

- Press "◀" / "▶" or "OK" button on Store option to store Install menu settings.
- After stored, T-V Link menu will appear. If you do not need to do T-V Link, press BLUE button to exit the menu.

## **Program Menu**

Press "MENU" button, now you are in main menu. In the main menu, select "Program" using "▲" or "▼" button. Then enter the Programme menu, press "◄" / "▶" or "OK" button.

**Note:** There is no Program menu in any EXT modes.



Program Menu is used to delete a channel, to change the programme number of a channel, to give a channel name to a channel, and to start the A.P.S (Autostore) function.

# To choose a channel in the PROGRAM menu

Press "▲" / "▼" / "■" button. The programme number that you choose is highlighted in the Program.

#### Caution:

Using "Delete" or "Insert" function rewrite the current channel list in the Program menu. Therefore, the programme numbers of some of channels will change.

# When you complete the settings of Program menu:

If you have a T-V Link compatible VCR, press

" the data to VCR" button to display the T-V Link menu. then follow the operating procedure "Downloading the data to VCR"



If you do not have a T-V Link compatible VCR, press BLUE button to exit the menu.

### To give a channel name (Name):

- 1. Choose the channel you want to give a channel name.
- Press the RED button to enter the Namemode.
- 3. Press "◀" or "▶" button to choose the position,and press "▲" or "▼" button to choose each character of channel name.
- 4. Press the RED button to store the channel name.
- To cancel the Name mode, press the BLUE button.

### To delete a channel (Delete):

- 1. Choose the channel you want to delete.
- 2. Press the YELLOW button to enter the Delete mode.
- 3. Press the YELLOW button to delete it.
- To cancel the Delete mode, press the BLUE button.

# To change the programme number of a channel (Insert)

- 1. Choose the channel you want to change the programme number.
- 2. Press the GREEN button to enter the Insert mode.
- 3. Press "▲" / "▼" / "◀" / "▶" button to choose new programme number.

4. Press the GREEN button to insert the channel to the chosen programme number.

### Autostore:

To enter Autostore menu, press the BLUE button. To learn the features of this function see "Autostore" below.

Autostore, searches and stores all channels automatically on your TV, according to the transmission of programme systems in your area.



First of all choose the "**Country**" by using "◀" or "▶" button.

After Autostore is finalized, a programme list will appear on the screen. In the program list you will see the programme numbers and names assigned to the programmes.


If you do not accept the locations and/or the programme names of programmes, you can change them in Programme menu.

### Source Menu

You can switch your TV to EXT modes by pressing directly to "AV" button or by selecting in source menu from the main menu.

While in EXT mode, you can also switch your TV to TV or other EXT modes by selecting in source menu from the main menu.

In main menu, firstly use "▲" or "▼" button then use "◀" / "▶" or "OK" button to enter Source menu. In source menu, move the cursor by "▲" or "▼" button and then press "OK" button or "◀" / "▶" buttons when the cursor is on the required item. The selected mode comes automatically on the screen.



### **Other Features**

### TV Status

**Programme Number**, **Programme Name** (or **EXT**), (they are displayed on the upper left of the screen). The **sound indicator** is displayed with them too. They are displayed after programme change during 3 seconds.

### **Sound Indicator**

The alternatives of the indicator are Mono, Stereo, Dual I and Dual II. This indicator is displayed under the programme number indicator on the screen. "I-II" button is used to select Mono or Stereo. or Dual I or Dual II.

### Mono

In Mono broadcast or in forced-mono (for stereo broadcast).

Stereo

In Stereo broadcast.

Dual I

If dual broadcast detected. Dual I is selected in default and also can be selected after Dual II by Remote Control.


Dual II

If Dual II selected by Remote Control.

# **Hyper Sound**

By selecting Hyper Sound in sound menu or by pressing the " button on your remote control, Pseudo/Spatial effect can be turned on or off. In Mono transmission the left and right channels will be added at left channel and dummy stereo effect will introduced to end-user.

In stereo transmission it yields a phase difference between left and right channels. Hyper Sound selection will be displayed on the screen when the TV Status button is pressed or programme is changed.



### **Picture Mode**

Picture mode OSD is displayed when BLUE button is pressed. Picture mode can be changed to standard, soft, and bright.

# Sleep Timer

Sleep Timer mode OSD is displayed when YELLOW button is pressed.

The Sleep Timer is used to turn the TV off after a defined period of time after selecting this item. The timer can be programmed between Off and 120 minutes in steps of 10 minutes. (Off, 010, 020, 030, 040, ..., 120)

If sleep timer is activated, at the end of the selected the time, the TV goes automatically to stand-by mode.

### **Mute Indicator**

It is placed in the upper middle of the screen when enabled, and it stays there until it is disabled.



To cancel mute, there are two alternatives; the first one is by pressing the "X" button, this volume is set to the preceding value, and the second one is increasing the volume level. By decreasing the volume level in mute state, mute will not be ignored, only the volume level will decrease.

# No-Signal Detection (TV mode)

If no valid signal detected, it takes 5 minutes to switch to the Stand-By mode unless any signal detected or any Remote Control command is accessed.

After a Remote Control command (if No-Signal Timer is active) the timer stops and if no signal detected again the timer is initialized to 5 minutes and starts 3 seconds later again to count down.

It is not valid in EXT modes.

# No-Signal and Out Of Range Detection (PC mode)

In PC Mode, as no menu is displayed, in case that there is no PC input to the TV, it is displayed an OSD message:

# No input signal detected

then the power lamp turns to amber and PC will be in PC standby mode. Press "AV" button, digit buttons or "P\script" / "P\script" buttonsto exit standby mode.

In PC Mode, as no menu is displayed, in case that there is no PC input to the TV, but the resolution and the vertical frequency is not supported by the concept, it is displayed an OSD message:

# Signal out of range

### Volume Bar

It is displayed in the lower middle of the screen. When a volume command is received (pressing " +" or " -" by Remote Control or Control panel at the top of the TV) and no menu is active, it stays on the screen for 3 seconds, after the last volume command or until another command is received in between.



### **EXT Modes**

By pressing the "AV" button you can switch your TV to EXT modes (except being in Teletext). Pressing this button will consecutively switch the TV in one of the optional EXT modes: EXT-1, EXT-2, EXT-2 S, EXT-3, EXT-4, EXT-4 S and PC.

In order to quit the EXT mode press any digit buttons or "P\sqrt" or "P\sqrt""

### **Zoom Modes**

Zoom mode can be changed by pressing Red button. You can change the screen size according to the picture aspect ratio. Select the optimum one from the following **ZOOM** modes.

#### AUTO:

When a WSS (Wide Screen Signalling) signal, which shows the aspect ratio of the picture, is included in the broadcast signal or the signal from an external device, the TV automatically changes the ZOOM mode to 16:9 ZOOM mode PANORAMIC or FULL mode according to the WSS signal.

When the AUTO mode does not function correctly due to poor WSS signal quality or when you want to change the ZOOM mode, change to another ZOOM mode manually.

### Using the different screen formats

Press the Red button to select the different modes: AUTO, FULL, REGULAR, PANORAMIC, 14:9 ZOOM, 16:9 ZOOM, 16:9 ZOOM SUBTITLE modes.

**Note:** You can only choose REGULAR and FULL in PC mode

### **FULL:**


This uniformly stretches the left and right sides of a normal picture (4:3 aspect ratio) to fill the wide TV screen.



• For 16:9 aspect ratio pictures that have been squeezed into a normal picture (4:3 aspect ratio), use the **FULL** mode to restore the picture to its original shape.


### **REGULAR:**

Use to view a normal picture (4:3 aspect ratio) as this is its original shape.



### PANORAMIC:

This stretches the left and right sides of a normal picture (4:3 aspect ratio) to fill the screen, without making the picture appear unnatural.



The top and bottom of the picture are slightly cut off.


### 14:9 ZOOM:

This zooms up the wide picture (14:9 aspect ratio) to the upper and lower limits of the screen.




### 16:9 ZOOM:

This zooms up the wide picture (16:9 aspect ratio) to the full screen.



### 16:9 ZOOM SUBTITLE:

This zooms up the wide picture (16:9 aspect ratio) with subtitles to the full screen.




### **PC Mode**

### Installation

- Power off both Computer and Display before making any connections.
- Set your PC's resolution correctly before connecting to the TV. See the table in page 30 for supported modes.
- Use a D-SUB cable to connect the TV's PC input to the computer's RGB output terminal.
   If you want to listen to the sound from the computer, use an audio cable to connect the PC AUDIO IN to the computer's sound output terminal.


15 Pin Mini D-Sub Connector



• Tighten the screws of the Display cable until the connectors are fastened securely (finger-tighten only).


### Main Menu in PC mode:

Enter the main menu by pressing the "**MENU**" button on the remote control.



### **PC Picture Position Menu:**

In the Main menu, select "PC Picture Position" using "▲" or "▼" button, then enter the menu pressing "◀" / "▶" or "OK" buttons..



### **Auto Position**

If you shift the picture horizontally or vertically to an unwanted position, use this item to put the picture into correct place automatically.

- Select Auto position item by using "▲" or "▼" buttons.
- Press "OK" button.
- Press "MENU" button or "BACK" button to store the value.

**Warning:** Auto position adjustment recommended to be done with the full screen image for the proper adjustment.

### **Horizontal Position**

This item shifts the image horizontally to right hand side or left hand side of the screen.

- Select Hori. Position item by using "▲" or
   "▼" button.
- Use "◀" or "▶" button to adjust the value.
- Press "MENU" button or "BACK" button to store the value.

### **Vertical Position**

This item shifts the image vertically towards the top or bottom of the screen.

- Select Ver. Position item by using "▲" or "▼" button.
- Use "◀" or "▶" button to adjust the value.
- Press "MENU" button or "BACK" button to store the value.

### **Dot Clock**

Dot Clock adjustments correct interference that appear as vertical banding in dot intensive presentations like spreadsheets or paragraphs or text in smaller fonts.

• Use "◀" or "▶" button to adjust the value.

### **Clock Phase**

Depending on the resolution and scan frequency that you input to the TV Set, you may see a muddy or noisy picture on the screen. In such a case you can use this item to get a clear picture by trial and error method.


Use "◀" or "▶" button to adjust the value.

### PC Picture Menu

In the Main menu, select "**PC Picture**" using "▲" or "▼" button, then enter the PC Picture menu pressing "◀" / "▶" or "**OK**" buttons.

**Contrast**, **Bright-1** and **Colour Temp**. adjustments in this menu are identical to adjustments defined in TV picture menu.

R, G, and B adjust the TV image colour in PC mode. You can change the TV colour to your desired colour: R (Red), G (Green), B (Blue)



### Sound Menu


In the main menu select "**Sound**" using "▲" or "▼" button then enter the Sound menu pressing "◀" / "▶" or "OK" buttons.

The items in this menu are described at **Sound menu** starting page 16.

### **PIP Picture**

In the Main menu, select "PIP Picture" using "▲" or "▼" button, then enter the PIP Picture menu pressing "◀" / "▶" or "OK" buttons.

This menu is displayed when PIP is displayed on the screen and otherwise "PIP No Signal" message will be displayed at the bottom of menu.




PIP picture is displayed on the screen with "OK" button. By pressing "OK" button, PIP window is selected. PIP position is changed by "Dutton. There are four different PIP positions. PIP size is changed by "Dutton. Two different PIP size are available.

Programme in the PIP window is increased / decreased by "**P** ✓ / **P** ∕ ", digit buttons or AV button. All EXT modes (Except EXT-3) are also available in PIP window. PIP window is removed from the screen by " button.

The items in this menu are described at **Picture menu** starting page 14.

### Source Menu

In the Main menu, select "Source" using "▲" or "▼" button, then enter the Source menu pressing "◀" / "▶" or "OK" buttons.



Select the available sources of TV, EXT-1, EXT-2, EXT-2 S, EXT-3, EXT-4, EXT-4 S or PC using "▲" or "▼" button and by pressing "◄"

### Sound in PC mode

- Connect the PC's Audio output to the TV's PC
   Audio In socket with an audio cable.
- On your remote control, using " " button to select sound source from TV, EXT-1, EXT-2, EXT-3, EXT-4 and PC options.
- When PIP is displayed on the screen, " )" allows you to switch sound between PC and selected PIP source.

### **Teletext**

Teletext is an information system that displays text on your TV screen. Using the Teletext information system you can view a page of information on a subject that is available in the list of contents (index).

On screen display is not available in text mode. Contrast, brightness or colour control is not available, but volume control is available in text mode.

# To operate Teletext

- Select a TV station on which Teletext is being transmitted.
- Press (TELETEXT) " button. Usually the list of contents (index) is displayed on the screen.



## To select a page of Teletext

 Press the appropriate digit buttons for the required Teletext page number.

The selected page number is displayed at the top left corner of the screen. The Teletext page counter searches until the selected page number is located, so that the desired page is displayed on the screen.

- Press "**P**\sqrt{" button to move the Teletext screen forward one page at a time.
- Press "P\screen" button to move the Teletext screen backward one page at a time.

# To Select Index Page

• To select the page number of the index (generally page 100), press "[]" button.

# Searching for a teletext page while watching TV

 In the Teletext mode pressing "X" button will switch the screen to the TV mode. In the TV mode enter a page number using digit buttons. As you enter last digit of page number, "\(\existsim\)" sign will replace the page number and flash until the entered page number is found. Then the page number will replace "
"" sign again. Now you can display this teletext page pressing "(X)" button.

# To Select Double Height Text

### To Reveal "concealed" Information

- Pressing "?" button once will reveal answers on a quiz or games page.
- Pressing "?" button again will conceal the revealed answers.

## To Stop Automatic Page Change

The teletext page you have selected may contain more information than what is on the screen; the rest of the information will be displayed after a period of time.

- Press "\( \bigce \)" button to stop the automatic page change.
- Press "\( \bigzeq \)" button again to allow the next page to be displayed.

# To Select a Subcode Page

Subcode pages are subsections of long Teletext pages that can only be displayed on the screen one section at a time.

- · Select the required Teletext page.
- Press "(心)" button.
- Select the required subcode page number by pressing four digit buttons (e.g. 0001).
- If the selected subcode page is not displayed in a short time, press "X" button. TV programme will be displayed on the screen.
- Teletext page number will be displayed on the upper left corner of the screen when the selected page is found.

• Press "X" button to display the selected Teletext page.

### To exit Teletext

 Press "
 button. The screen will switch to TV mode.

## **Fastext and Toptext**

Your TV supports the 7 page Teletext system. When the page number of any of the 7 pages in memory is entered, the system will not search for the requested page; instead it will display the page automatically.

- Press "**P**\sqrt{" button to move the Teletext screen forward one page at a time.
- Press "P\screen" button to move the Teletext screen backward one page at a time.

### For Fastext and Toptext

The subject-heading for the information may have a particular colour.

 Press an appropriate RED, GREEN, YELLOW or BLUE button in order to reach the relevant page quickly.

### For TOPTEXT

If Toptext transmission is present, colour coded buttons will appear in status row.

If Toptext transmission is not present, status row will not appear.

In Toptext mode the "**P**\sqrt{" or "**P**\sqrt{"}" commands will request the next or previous page respectively. If Toptext transmission is not available, in case of operation of these commands, wraparound occurs. For example page 100 appears to be one greater than page 199.

# Peripheral Equipment Connections

There is a wide range of audio and video equipment that can be connected to your TV.

Connection diagrams at the and of this section show you where the different equipment should be connected at the back side of the TV

### Via the Euroconnector

Your TV set has 2 Euroconnector sockets. If you want to connect peripherals (e.g. video, decoder, etc.) which have Euroconnectors, to your TV, use **SCART** input.

If an external device is connected via Euroconnector sockets TV is switched to AV mode automatically. In this case if both sockets are connected SCART has the precedence.

## T-V Link compatible VCR

Be sure to connect the T-V Link compatible VCR to the **EXT.2** terminal. If not, the T-V Link function will not work properly.

 When connecting a T-V Link compatible VCR to the EXT.2 terminal, be sure to connect the decoder to the VCR. If not, the T-V Link function may not work properly. And then set the Decoder(EXT-2) function for the channel to ON to unscramble a scrambled channel.

### RGB mode

If an equipment can output the **RGB** signals, connect it to the **EXT-1** or **EXT-2** terminal.

### **EXT-2 S Mode**

If the equipment connected to your TV set supports S-Video (Y/C) output from Euroconnector, you can have a better picture quality by selecting **EXT-2 S** mode and connecting your equipment to the **EXT.2 (EXT-2 S)** terminal of TV. See your equipment's booklet to check if your equipment has such feature.

# Via the RCA jacks

If you have an equipment (such as a Camcorder) which has the RCA jacks, connect it to the **EXT-4** terminal with the video and audio cables.

If you have a device which outputs component

signal, connect it to the EXT-3 terminal with a component video cable.

## Via the ANT (aerial) socket

If your equipment does not have an Euroconnector or RCA jacks, connect it to the TV with an aerial cable. For details, see the manual provided with the equipment.

• To store the test signal that comes from the equipment, see "Install Menu" on page 18 and store it to the program number 0. You can watch images from that equipment to select the program number which you stored the test signal.

### Decoder

Cable TV offers you a wide choice of programmes. Most of them are free, others are to be paid for by the viewer. This means that you will need to subscribe to the broadcasting organisation whose programmes you wish to receive. This organisation will supply you a corresponding decoder unit to allow the programmes to be unscrambled.

For further information ask your dealer. See also the booklet supplied with your decoder.

# Connect a decoder with an aerial socket to the TV

Connect the aerial cable

# Connect a decoder without an aerial socket to the TV

 Connect the decoder to your TV with a eurocable (RCA Jack Cable) to EXTERNAL (RCA Jack). When your decoder has a Euroconnector / RCA Jack you can obtain better picture quality if you connect a eurocable (RCA Jack Cable) to EXTERNAL (RCA Jack).

# TV and Video Recoder (VCR)

- Connect the Video Recorder to the ANT (antenna input) socket of the TV with the aerial cable.
- Connect the Video Recorder to the EXT-1 or EXT-2 terminal with the SCART cable, or connect it to the EXT-4 terminal with the audio and video cables.

# **NTSC Playback**

Connect a NTSC video recorder to a terminal. Then press "**AV**" button to select the corresponding AV mode.

**INTSC 3.58/4.43** system is detected automatically in AV mode.

### Camera and Camcorder

### To connect to the EXT-4 terminal

Connect your camera or camcorder at the back side of your TV.

 Connect your equipment to the TV via VIDEO (yellow), AUDIO R (red) and AUDIO L (white) inputs. You should connect the jacks to the input in the same colour.

# Connect the decoder to the video recorder

Some video recorders have a special euroconnector for decoder

- Connect a eurocable to the euroconnector of your decoder and to the special euroconnector of your video recorder. See also the handbook of your video recorder.
- To connect your video recorder to the TV, see TV and Video Recorder section.

If you want to connect more equipment to your TV, consult your dealer.

# **Connecting Headphones**

Use the stereo headphone socket on the right side of your TV, to connect headphones.

# Connecting the PC

Connect PC monitor with 15-pin PC cable to the 15-pin connector on the rear of the computer. For detail installation procedure see **Installation** in PC mode.


# To connect to S-Video input


Connect your camera or camcorder at the back side of your TV.

 Connect your equipment to the TV via S-Video input at the back side by using S-Video cables.

# **Peripheral Equipment Connections** S-€ Ð $\mathbf{H}$ P AUDIO OUT PR SUB WOOFEF PC IN (D-SUB) DC IN EXT-2 (\$-€)) EXT-1 (→) EXT-3 7 PC.Þ Pr R--- ♪---L 0 ((()) A **DC 24 V** Υ **PC INPUT** Pb **© EXT-3** -Component Audio In R **D** EXT-2 Component Audio In L E EXT-1 (F) **ANTENNA** S-Video In **(G**) PC AUDIO IN Video In Audio R $\oplus$ EXT-4 Audio L (I)**AUDIO OUT TERMINAL** Audio R Audio L Subwoofer Out

ENGLISH -28-





# **PC Input Typical Display Modes**

The display has a maximum resolution of  $1360 \times 768$ , vertical sync. frequency range of 50-75 Hz and a horizontal sync. frequency range of 30-69 KHz.

The following table is an illustration of some of the typical video display modes.

Mode	Resolution		Frequency		Sync. Polarity	
Wode	Horizontal	Vertical	Hor. (kHz)	Ver. (Hz)	Hor.	Ver.
1	640	400	31.5	60	1	+
2	640	400	31.5	70	1	-
3	640	480	31.5	60	-	-
4	640	480	37.9	72	-	-
5	640	480	37.5	75	-	-
6	720	400	31.5	70	-	+
7	800	600	35.2	56	+	+
8	800	600	37.9	60	+	+
9	800	600	48.1	72	+	+
10	800	600	46.9	75	+	+
11	1024	768	48.4	60	ı	-
12	1024	768	56.5	70	-	-
13	1024	768	60.0	75	+	+
14	1280	720	44.6	60	-	+
15	1360	768	47.7	60	+	+

The native resolution of the TFT-LCD Panel is  $1360 \times 768$ . Therefore using Mode 15 is advised to get the best PC input display quality.

# **Tips**

### Care of the Screen

Clean the screen with a slightly damp, soft cloth. Do not use abrasive solvents as they may damage the TV screen coating layer

# Colors of image on screen are abnormal

Have you selected the correct TV system? Is your TV set or house aerial located too close to the loudspeakers, non-earthed audio equipment or neon lights, etc.?

Mountains or high buildings can cause double pictures or ghost images. Sometimes you can improve the picture quality by changing the direction of the aerial.

Is the picture or Teletext unrecognisable? Check if you have entered the correct frequency.

The picture quality may degrade when two peripherals are connected to the TV at the same time. In such a case, disconnect one of the peripherals.

# No Image on Display Screen

Is the aerial connected properly? Are the plugs connected tightly to the aerial socket? Is the aerial cable damaged? Are suitable plugs used to connect the aerial? If you are in doubt, consult your dealer.

**No Image** means that your TV is not receiving any transmission. Have you pressed the correct buttons on the remote control? Try once more.

### **PC Picture**

If no PC picture appears, check that the D-SUB cable is connected properly. Check that your PC's resolution set correctly. See page 30 for supported modes.

### Sound

You can not hear any sound. Did you perhaps interrupt the sound, pressing "X" button? Are external speakers connected to the TV?

Sound is coming from only one of the speakers. Is the balance set to one direction extreme? See **Sound** menu.

### **Remote Control**

If your TV no longer responds to the remote control, perhaps the batteries are exhausted. Replace the batteries.

Have you selected the wrong menu? Press "MENU" button to return to normal screen or press "BACK" button to return to the previous menu.

### No solution

Switch your TV set off and on. If this does not work, switch off, remove the mains plug and call the service personnel; never attempt to repair it yourself.

### For users in the UK:

If you have any problems setting up your new TV, please call the **JVC** Helpline on 0870330 5000

### For users in the Republic of Ireland:

If you have any problems setting up your new TV, please call the **JVC** Helpline on 1890 - 582500

Specifications				
ltem Model	LT-23C88SJ			
Broadcasting Systems	PAL SECAM BG, DK, I, L, Lp			
Channels and	VHF (VL) 46,25 MHz - 168,25 MHz			
Frequencies	VHF (VH) 175,25 MHz - 463,25 MHz			
	UHF 471,25 MHz - 863,25 MHz			
	Cable TV (S1-S20/ S21-S41)			
Input Signal	Video: Analog 0,7 Vp-p 75 ohm positive			
	Sync: TTL Level positive or negative, Seperate sync.			
Horizontal Timing	30 - 69 KHz			
Vertical Timing	50 - 75 Khz			
Dot Rate	78,75 MHz max.			
Panel Size	23,01" (583,1 mm) (measured diagonally)			
Visible Picture Size	508,5 mm horizontal x 286,1 mm vertical			
Display Resolution	1360 x 768 max. (WXGA)			
Number of Preset Channels	100			
Channel Indicator	On Screen Display (OSD)			
RF Aerial Output	75 Ohm (unbalanced)			
Power Requirements	Adaptor: 100-240 V AC, 50 Hz / TV: 24 V DC			
Power Consumption (W)	108 W (max) / STAND-BY <3W			
Sound Systems	German , Nicam Stereo			
Audio Output	2 x 5 W <sub>RMS</sub> (%10 THD)			
EXT-1 Terminal	Euroconnector (21-pin, SCART 1) (bottom of the cabinet)			
	Video Input, Audio L/R Inputs and RGB inputs are available.			
	• TV broadcast outputs (Video and Audio L/R) are available.			
EXT-2 Terminal	Euroconnector (21-pin, SCART 2) (bottom of the cabinet)			
	Video Input, S-VIDEO (Y/C) input, Audio L/R and RGB inputs are available. Video and Audio L/R outputs are available.			
	T-V Link functions are available.			
EXT-3 Terminal	RCA connectors x 5 (bottom of the cabinet)			
	Component video (Pr, Pb, Y) inputs and Audio L-R inputs are available			
EXT-4 Terminal	RCA connectors x 3 (side of the cabinet)			
	S-VIDEO connector x 1 (side of the cabinet)			
	Video input, S-VIDEO (Y/C) input and Audio L/R inputs are available.			
AUDIO OUT Terminal	RCA connectors x 3			
	Audio L/R output are available.			
	Subwoofer out is available.			
PC IN terminal	Analog RGB D-SUB 15 x 1			
	• PC signal is available (refer to page 28 for details of the signals which can be input)			
PC AUDIO IN terminal	Stereo mini-jack (3.5 mm diameter)			
Dimensions (W x H x D)	614 mm x 482 mm x 240 mm			
·	614 mm x 438 mm x 79 mm (TV only)			
Weight	7,4 kg (with stand) / 6,4 kg (TV only)			
Accessories	Remote control unit x 1 (RM-C1860) - AA/R6 dry cell battery x 2			
	AC adapter x 1			
	Power cord x 1			
Headphone jack	Stereo mini-jack (3.5 mm diameter)			
1 3				