

DLP Cinema® Projector

NEC

NC800C

User's Manual





NEC Viewtechnology, Ltd.

Important Information

WARNING

TO PREVENT FIRE OR SHOCK HAZARDS, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE. ALSO DO NOT USE THIS UNIT'S POLARIZED PLUG WITH AN EXTENSION CORD RECEPTACLE OR OTHER OUTLETS, UNLESS THE PRONGS CAN BE FULLY INSERTED. REFRAIN FROM OPENING THE CABINET AS THERE ARE HIGH-VOLTAGE COMPONENTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



DOC compliance Notice

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Precautions: Please read this manual carefully before using your **NC800C** and keep the manual handy for future reference.

WARNING

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

CAUTION

- In order to reduce any interference with radio and television reception use a signal cable with ferrite core attached. Use of signal cables without a ferrite core attached may cause interference with radio and television reception.
- This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the installation manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Important Safeguards

These safety instructions are to ensure the long life of your projector and to prevent fire and shock. Please read them carefully and heed all warnings.

Installation

1. Place the projector on a flat, level surface in a dry area away from dust and moisture. Tilting the front of the projector up or down from level could reduce lamp life. Do not put the projector on its side when the lamp is on. Doing so may cause damage to the projector.
2. Do not place the projector in direct sunlight, near heaters or heat radiating appliances.
3. Exposure to direct sunlight, smoke or steam could harm internal components.
4. Handle your projector carefully. Dropping or jarring your projector could damage internal components.
5. To carry the projector, a minimum of four persons are required. Do not hold the lens part and the anamorphic lens part with your hand. Otherwise the projector may tumble or drop, causing personal injury.
6. Do not place heavy objects on top of the projector.
7. If you wish to have the projector installed on the ceiling:
 - a Do not attempt to install the projector yourself.
 - b The projector must be installed by qualified technicians in order to ensure proper operation and reduce the risk of bodily injury.
 - c In addition, the ceiling must be strong enough to support the projector and the installation must be in accordance with any local building codes.
 - d Please consult your dealer for more information.
 - e Do not attempt to stack projectors on the ceiling.

Power Supply

1. The projector is so designed that it operates with the power supply voltage described below.
 - 1.2kW (Max. 12A) AC100-120V 50/60Hz
 - 1.7kW (Max. 8.5A) AC200-240V 50/60HzEnsure that your power supply fits this requirement before attempting to use your projector.
2. Consult your dealer for installing the power cord to the projector. **DO NOT** install the power cord by yourself. Doing so may cause a fire or electric shock.
3. Handle the power cord carefully and avoid excessive bending. Do not place any heavy objects on the power cord. A damaged cord can cause electric shock or fire.
4. If the projector will not be used for an extended period of time, shut down AC power.
5. Placing the power cord and the signal cable closely to each other can cause beat noise. If this happens, keep the two separated so that beat noise is not generated. Beat noise is corruption of the picture often seen as a rolling band moving through the image.
6. Do not touch the projector during a thunder storm. Doing so can cause electrical shock or fire.

Cleaning

1. Unplug the projector before cleaning.
2. Clean the cabinet periodically with a damp cloth. If heavily soiled, use a mild detergent. Never use strong detergents or solvents such as alcohol or thinner.
3. Use a blower or lens paper to clean the lens, and be careful not to scratch or mar the lens.

Fire and Shock Precautions

1. Ensure that there is sufficient ventilation and that vents are unobstructed to prevent potentially dangerous concentrations of ozone and the build-up of heat inside your projector. Allow at least 8 inches (20cm) of space between your projector and a wall. Allow at least 20 inches (50cm) of space between the ventilation outlet and object.
2. Prevent foreign objects such as paper clips and bits of paper from falling into your projector. Do not attempt to retrieve any objects that might fall into your projector. Do not insert any metal objects such as a wire or screwdriver into your projector. If something should fall into your projector, disconnect it immediately and have the object removed by a qualified service person.
3. Do not place any liquids on top of your projector. Refer servicing to qualified service personnel if liquid has been spilled.
4. Keep any items such as magnifying glass out of the light path of the projector. The light being projected from the lens is extensive, therefore any kind of abnormal objects that can redirect light coming out of the lens, can cause unpredictable outcome such as fire or injury to the eyes.
5. Do not cover the lens with the supplied lens cap or equivalent while the projector is on. Doing so can lead to melting of the cap and possibly burning your hands due to the heat emitted from the light output.
6. When using a LAN cable:
For safety, do not connect to the connector for peripheral device wiring that might have excessive Voltage.

CAUTION: High Pressure Lamp May Explode if Improperly Handled. Refer Servicing to Qualified Service Personnel.

Lamp Caution: Please read before operation

Due to the lamp being sealed in a pressurized environment, there is a small risk of explosion, if not operated correctly. There is minimal risk involved, if the unit is in proper working order, but if damaged or operated beyond the recommended hours, the risk of explosion increases. Please note that there is a warning system built in, that displays following message when you reach a preset operating time "Over Time Bulb". When you see this message please contact your dealer for a replacement. If the lamp does explode, smoke will be discharged from the vents located on the back of the unit. Do not stand in front of the vents during the operation. This smoke is comprised of glass in particulate form and Xenon gas, and will not cause harm if kept out of your eyes. If your eyes have been exposed to this gas, please flush your eyes out with water immediately and seek immediate medical attention. Do not rub your eyes! This could cause serious injury.

WARNING:

Do not look into the lens while the projector is on. Serious damage to your eyes could result.

CAUTION

Never unplug the projection head power plug from the outlet or disconnect the breaker under the following conditions. Doing so can damage the projector.

- While projecting images
- While cooling after the projector has been turned off. (The POWER indicator blinks in orange while the fan is rotating, and the LCD screen is displaying "cooling...". The cooling fan continues to work for 3 minutes.)

Remote Control Precautions

- Handle the remote control carefully.
- If the remote control gets wet, wipe it dry immediately.
- Avoid excessive heat and humidity.
- Do not heat, take apart, or throw batteries into fire.
- If you will not be using the remote control for a long time, remove the batteries.
- Ensure that you have the batteries' polarity (+/-) aligned correctly.
- Do not use new and old batteries together, or use different types of batteries together.
- Dispose of used batteries according to your local regulations.

Disposing of your used product



EU-wide legislation as implemented in each Member State requires that used electrical and electronic products carrying the mark (left) must be disposed of separately from normal household waste.

This includes projectors and their electrical accessories or lamps. When you dispose of such products, please follow the guidance of your local authority and/or ask the shop where you purchased the product.

After collecting the used products, they are reused and recycled in a proper way. This effort will help us reduce the wastes as well as the negative impact to the human health and the environment at the minimum level.

The mark on the electrical and electronic products only applies to the current European Union Member States.

For questions relating to unclear points or repairs

Contact your dealer or the following support branches for questions relating to unclear points, malfunctions and repairs of the product.

In Europe

NEC Europe, Ltd. / European Technical Centre
Address: Unit G, Stafford Park 12, Telford TF3 3BJ, U.K.
Telephone: +44 1952 237000
Fax Line: +44 1952 237006

In North America

NEC Corporation of America
Digital Cinema Division
Address: 4111 West Alameda Avenue Suite 412 Burbank, CA 91505
Telephone: 818 557 2500
*If the above line is busy, please dial as below;
Telephone: 866 632 6431


Important Information



Précaution: lire attentivement ce manuel avant d'utiliser le **NC800C** et le conserver à portée de main pour future référence.

AVERTISSEMENT

POUR EVITER UN INCENDIE OU UN RISQUE D'ELECTROCUTION NE PAS EXPOSER CET ENSEMBLE A LA PLUIE OU A L'HUMIDITE; DE MEME, NE PAS BRANCHER LA PRISE POLAIRE AVEC UNE RALLONGE A MOINS QUE LES BROCHES DE LA PREMIERE NE S'Y INSERENT PLEINEMENT.

EVITER D'OUVRIRE LE COFFRET CAR IL Y A, A L'INTERIEUR DES COMPOSANTS SOUMIS A UNE HAUTE-TENSION; POUR LES REPARATIONS, S'ADRESSER A UN PERSONNEL QUALIFIE.



| | |
|--|--|
| ATTENTION | |
| POUR EVITER LES RISQUES D'ELECTROCUTION, NE PAS OUVRIR LE COUVERCLE. AUCUN DES ELEMENTS INTERNES NE DOIT ETRE REPARÉ PAR L'UTILISATEUR. NE CONFIER L'ENTRETIEN QU'A UN PERSONNEL QUALIFIE. | |
|  | L'éclair fléché dans un triangle équilatéral est destiné à avertir l'utilisateur de la présence, dans l'appareil, d'une zone non-isolée soumise à une haute-tension dont l'intensité est suffisante pour constituer un risque d'électrocution. |
|  | Le point d'exclamation dans un triangle équilatéral est destiné à attirer l'attention de l'utilisateur sur la présence d'informations de fonctionnement et d'entretien importantes dans la brochure accompagnant l'appareil. |

DOC avis de conformité

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le Matériel D'interférence du Canada.

Recommandations importantes

Ces instructions de sécurité ont pour but d'assurer une longue vie à votre projecteur et d'éviter un incendie ou une décharge électrique. Prière de les lire attentivement et de tenir compte de tous les avertissements.

Installation

1. Placer le projecteur sur une surface plane et de niveau, et dans un endroit sec et à l'abri des poussières et de l'humidité.
2. Ne pas exposer le projecteur aux rayons directs du soleil, ni le placer près d'un chauffage ou de dispositifs de radiation de chaleur.

3. L'exposition aux rayons directs du soleil, à la fumée ou à la vapeur pourrait endommager des composants internes.
4. Manipuler le projecteur avec précaution. La chute du projecteur ou lui donner des chocs pourrait endommager des composants internes.
5. Le transport du projecteur doit être effectué par quatre personnes au minimum.
Ne pas saisir le projecteur par son objectif ni par les des anamorphoseurs. Le cas échéant, le projecteur risque de se renverser ou de tomber et d'être à l'origine d'un accident corporel.
6. Ne pas poser d'objets lourds sur le dessus du projecteur.
7. Si vous voulez installer le projecteur au plafond:
 - a. N'essayez pas d'installer le projecteur vous-même.
 - b. Le projecteur doit être installé par un technicien qualifié pour garantir une installation réussie et réduire le risque d'éventuelles blessures corporelles.
 - c. De plus le plafond doit être suffisamment solide pour supporter le projecteur et l'installation doit être conforme aux réglementations locales de construction.
 - d. Veuillez consulter votre revendeur pour de plus amples informations.
 - e. Ne pas superposer les projecteurs accrochés au plafond.

Alimentation

1. Le projecteur est conçu pour fonctionner sous la tension d'alimentation ci-dessous.
 - 1.2kW (Max. 12A) CA100-120V 50/60Hz
 - 1.7kW (Max. 8.5A) CA200-240V 50/60HzS'assurer que la tension du secteur soit conforme à ces caractéristiques avant d'utiliser le projecteur.
2. Pour l'installation du cordon d'alimentation électrique sur le projecteur, voir le concessionnaire. NE PAS installer le cordon d'alimentation électrique soi-même. Il y a risque d'incendie ou d'électrocution.
3. Manipuler le cordon d'alimentation avec précaution et éviter des flexions excessives. Ne placez pas d'objets lourds sur le cordon d'alimentation. Un cordon endommagé peut occasionner une décharge électrique ou un incendie.
4. Si le projecteur n'est pas utilisé pendant une longue période, coupez l'alimentation CA.
5. Placer le cordon d'alimentation et le câble de signal tout près l'un de l'autre peut occasionner un bruit de battement. Si cela se produit, les maintenir séparés jusqu'à ce que le bruit de battement disparaisse.
6. Ne pas toucher le projecteur pendant un orage. Cela pourrait causer un choc électrique ou un incendie.

Nettoyage

1. Débrancher le projecteur avant de le nettoyer.
2. Nettoyer régulièrement le boîtier extérieur avec un chiffon humide. S'il est très sale, utiliser un détergent doux. Ne jamais utiliser de détergent forts ou de solvants tels que de l'alcool ou du diluant.
3. Utiliser un souffleur ou du papier pour objectif pour nettoyer l'objectif, et veiller à ne pas rayer ou endommager l'objectif.

Précautions contre l'incendie ou la décharge

1. S'assurer qu'il y ait une ventilation suffisante et que les ouvertures ne soient pas obstruées afin d'éviter des concentrations potentiellement dangereuses d'ozone et l'accumulation de chaleur à l'intérieur du projecteur. Laisser au moins 20 cm d'espace entre le projecteur et un mur. Veuillez laisser un espace libre d'au moins 50 cm (20 pouces) entre les orifices de ventilation
2. Empêcher tous corps étrangers tels que des attaches trombones ou des morceaux de papier de tomber à l'intérieur du projecteur. Ne pas essayer de récupérer des objets qui seraient tombés dans le projecteur. Ne pas introduire d'objets métalliques tels que fil ou un tournevis dans le projecteur. En cas de chute d'objet dans le projecteur, le débrancher immédiatement et faire enlever l'objet par un technicien agréé.
3. Ne pas poser de liquides sur le dessus du projecteur. Confier la réparation à du personnel technique qualifié si du liquide a été renversé.
4. Maintenez tout ce qui s'apparente à une loupe en dehors du faisceau lumineux du projecteur. La lumière projetée par l'objectif est très puissante, de sorte que tout objet en opposition pourrait dévier le faisceau provenant de l'objectif, ce qui pourrait avoir des conséquences imprévues telles qu'un incendie ou une lésion oculaire.
5. Ne bouchez pas l'objectif avec son couvercle fourni lorsque le projecteur est allumé. Faire cela pourrait faire fondre le couvercle et peut-être brûler vos mains à cause de la chaleur émise par le faisceau lumineux.

ATTENTION: La lampe à haute pression peut exploser si elle est manipulée incorrectement. Confier l'entretien à du personnel d'entretien qualifié.

Précautions avec la lampe : lire avant l'utilisation

La lampe a été scellée dans un environnement sous pression, et il y a donc un petit risque d'explosion, si elle n'est pas utilisée correctement. Le risque est minime si l'appareil est en bon ordre de marche, mais s'il est endommagé ou utilisé au-delà du nombre d'heures recommandées, le risque d'explosion augmente alors. Il est à noter l'existence d'un système d'avertissement intégré, lequel affiche le message "Over Time Bulb" lorsqu'un temps de fonctionnement pré-réglé est atteint. Si la lampe explose, de la fumée peut être produite par les fentes d'aération situées sur l'arrière de l'appareil. Ne vous tenez pas devant les événements pendant l'opération. Cette fumée est composée de verre sous forme de particules et de gaz de Xenon, et n'est pas nuisible si elle est maintenue à distance des yeux. Si les yeux sont exposés à ce gaz, les rincer immédiatement à l'eau courante et consulter tout de suite un médecin. Ne pas se frotter les yeux ! Cela pourrait provoquer une grave blessure.

AVERTISSEMENT:

Ne pas regarder dans l'objectif lorsque le projecteur est allumé. De sérieux dommages aux yeux pourraient en résulter.

ATTENTION

Ne jamais débrancher la prise d'alimentation à tête de projection ni débrancher le disjoncteur dans les conditions suivantes. Cela pourrait endommager le projecteur.

- Lors de la projection d'images
- Pendant le refroidissement après que le projecteur ait été éteinte. (Le voyant POWER clignote en orange lorsque le ventilateur fonctionne, et l'écran ACL affiche « cooling... ». le ventilateur du refroidissement continué à tourner pendant 3 minutes.)

Précautions se rapportant à la télécommande

- Manipuler la télécommande avec précaution.
- Si la télécommande est mouillée, l'essuyer immédiatement.
- Eviter toute chaleur excessive et l'humidité.
- Ne pas chauffer, démonter ou jeter les piles au feu.
- Si la télécommande n'est pas utilisée pendant une longue période, retirer les piles.
- S'assurer de respecter la polarité (+/-) des piles.
- Ne pas utiliser des piles neuves et des piles usagées en même temps et ne pas utiliser des piles de différents types ensemble.
- Mettre les piles usagées au rebut d'après la réglementation locales.

Mise au rebut du produit usagé



La législation européenne, appliquée dans tous les Etats membres, exige que les produits électriques et électroniques portant la marque (à gauche) doivent être mis au rebut séparément des autres ordures ménagères. Ceci inclus les projecteurs et leurs accessoires électriques ou lampes. Lorsque vous mettez au rebut ces produits, veuillez suivre les recommandations des autorités locales et/ou demandez conseil au magasin qui vous a vendu le produit.

Une fois ces produits mis au rebut, ils sont recyclés et de manière appropriée. Cet effort nous aidera à réduire les déchets et à maintenir au niveau minimum leurs conséquences négatives sur la santé humaine et sur l'environnement.

La marque figurant sur les produits électriques et électroniques ne s'applique qu'aux Etats membres actuels de l'Union Européenne.

Si vous avez des questions concernant des points peu clairs ou des réparations

Contactez votre distributeur ou les branches d'assistance suivantes si vous avez des questions concernant des points à éclaircir, des défauts et des réparations du produit.

En Europe

NEC Europe, Ltd. / European Technical Centre
Adresse : Unit G, Stafford Park 12, Telford TF3 3BJ, U.K.
Téléphone : +44 1952 237000
Fax : +44 1952 237006

En Amérique du Nord

NEC Corporation of America
Division Cinéma Numérique
Adresse : 4111 West Alameda Avenue Suite 412 Burbank, CA 91505
Téléphone : 818 557 2500
*Si la ligne ci-dessus est occupée, essayer le numéro suivant ;
Téléphone : 866 632 6431



Important Information

Maschinenlärminformations-Verordnung – 3. GPSGV,

Der höchste Schalldruckpegel beträgt 70 dB(A) oder weniger gemäß EN ISO 7779.

WARNUNG

ZUR VERMEIDUNG VON FEUER UND ELEKTRISCHEN SCHLÄGEN DARF DAS GERÄT WEDER REGEN NOCH FEUCHTIGKEIT AUSGESETZT WERDEN. DER POLARISIERTE STECKER DIESES GERÄTES DARF NUR DANN IN EIN VERLÄNGERUNGSKABEL ODER IN EINE STECKDOSE EINGESTECKT WERDEN, WENN DIE STECKKONTAKTE VOLLSTÄNDIG EINGESTECKT WERDEN KÖNNEN. UNTERLASSEN SIE, DAS GERÄT ZU ÖFFNEN, DA DADURCH IM GERÄT FREILIEGENDE HOCHSPANNUNGSFÜHRENDE TEILE BERÜHRT WERDEN KÖNNEN. LASSEN SIE DEN KUNDENDIENST NUR VON HIERFÜR QUALIFIZIERTEN PERSONEN DURCHFÜHREN.



Vorsichtsmaßnahmen: Lesen Sie sich dieses Handbuch bitte sorgfältig durch, bevor Sie den **NC800C** benutzen, und bewahren Sie das Bedienungshandbuch in greifbarer Nähe als spätere Referenz auf.

Wichtige Sicherheitshinweise

Diese Sicherheitshinweise sollen eine lange Lebensdauer Ihres Projektors sicherstellen und vor Feuer und elektrischen Schlägen schützen. Lesen Sie diese Hinweise sorgfältig durch und beachten Sie alle Warnungen.

Installation

1. Stellen Sie den Projektor auf eine flache, waagerechte Fläche in einer trockenen Umgebung; frei von Staub und Feuchtigkeit.

2. Stellen Sie den Projektor weder in direktes Sonnenlicht noch in die Nähe einer Heizung oder sonstiger Hitze abstrahlender Einrichtungen.
3. Wenn das Gerät direktem Sonnenlicht, Rauch oder Dampf ausgesetzt wird, können interne Komponenten beschädigt werden.
4. Behandeln Sie Ihren Projektor vorsichtig. Fallenlassen oder starkes Schütteln kann interne Komponenten beschädigen.
5. Zum Tragen des Projektors werden mindestens vier Personen benötigt. Den Projektor nicht am Linsenbereich oder den anamorphotischen Linsenwelle tragen. Beschädigungs- und Verletzungsgefahr.
6. Legen Sie keine schweren Gegenstände auf den Projektor.
7. Wenn der Projektor an der Decke installiert werden soll:
 - a Versuchen Sie nicht, den Projektor selbst zu installieren.
 - b Der Projektor muss von qualifizierten Technikern installiert werden, um einen ordnungsgemäßen Betrieb sicherzustellen und die Verletzungsgefahr zu reduzieren.
 - c Die Decke muss für das Gewicht des Projektors ausreichende Festigkeit aufweisen, und die Installation muss entsprechend den örtlichen Bauvorschriften ausgeführt werden.
 - d Weitere Informationen erhalten Sie von Ihrem Fachhändler.
 - e Versuchen Sie nicht, mehrere Projektoren an der Decke übereinander zu stapeln.

Spannungsversorgung

1. Der Projektor wurde so konzipiert, dass er mit der unten aufgeführten Netzspannung läuft.
 - 1.2kW (Max. 12A) 100-120V Wechselstrom, 50/60Hz
 - 1.7kW (Max. 8.5A) 200-240V Wechselstrom, 50/60Hz

Stellen Sie sicher, dass die vorhandene Spannungsversorgung diesen Vorgaben entspricht, bevor Sie versuchen, Ihren Projektor zu betreiben.

2. Zum Installieren des Netzkabels am Projektor wenden Sie sich bitte an Ihren Fachhändler. UNTER KEINEN UMSTÄNDEN versuchen, das Netzkabel selbst zu installieren. Brand- und Schlaggefahr.
3. Behandeln Sie das Netzkabel vorsichtig und vermeiden Sie Knicke. Legen Sie keine schweren Gegenstände das Netzkabel. Ein beschädigtes Netzkabel kann elektrische Schläge oder einen Brand verursachen.
4. Wenn der Projektor über eine längere Zeit nicht genutzt wird, schalten Sie die Stromversorgung ab.
5. Wenn Sie das Netzkabel und das Signalkabel in unmittelbarer Nähe zueinander platzieren, kann Überlagerungsrauschen auftreten. Vergrößern Sie in einem derartigen Fall den Abstand zwischen diesen beiden Kabeln.
6. Berühren Sie den Projektor auf keinen Fall während eines Gewitters. Wenn Sie dies nicht beachten, kann dies zu einem elektrischen Schlag oder einem Feuer führen.

Reinigung

1. Trennen Sie den Projektor vor der Reinigung von der Netzsteckdose ab.
2. Reinigen Sie das Gehäuse regelmäßig mit einem feuchten Tuch. Bei starker Verschmutzung verwenden Sie ein mildes Reinigungsmittel. Reinigen Sie das Gerät niemals mit starken Reinigungs- oder Lösungsmitteln wie z.B. Alkohol oder Verdüner.
3. Reinigen Sie die Linse mit einer Blaseinrichtung oder einem Linsentuch. Beachten Sie dabei, dass die Linsenoberfläche weder zerkratzt noch auf andere Weise beschädigt wird.

Vorsichtsmaßnahmen zur Vermeidung von Bränden und elektrischen Schlägen

1. Sorgen Sie für ausreichende Belüftung und stellen Sie außerdem sicher, dass die Lüftungsschlitze frei bleiben, damit sich innerhalb des Projektors kein Hitzestau bilden kann. Lassen Sie mindestens 20 cm Abstand zwischen Ihrem Projektor und der Wand. Der Abstand zwischen den Belüftung und anderen Gegenständen sollte mindestens 50cm betragen.
2. Vermeiden Sie, dass Fremdgegenstände wie Büroklammern und Papierschnipsel in den Projektor fallen. Versuchen Sie nicht, in den Projektor gefallene Gegenstände selbst zu entfernen. Stecken Sie keine Metallgegenstände wie einen Draht oder Schraubendreher in Ihren Projektor. Wenn etwas in den Projektor gefallen ist, müssen Sie sofort den Netzstecker ziehen und den Gegenstand von qualifiziertem Servicepersonal entfernen lassen.
3. Stellen Sie keine mit Flüssigkeit gefüllten Gefäße auf Ihren Projektor. Überlassen Sie die Reparatur ausschließlich qualifiziertem Servicepersonal, wenn Flüssigkeit verschüttet worden ist.
4. Lichtkegel des Projektors fern. Da das von der Linse projizierte Licht umfassend ist, können alle abnormalen Gegenstände, die in der Lage sind, das aus der Linse austretende Licht umzulenken, unvorhersehbare Ereignisse wie z.B. einen Brand oder Augenverletzungen verursachen.
5. Bedecken Sie die Linse nicht mit der mitgelieferten Linsenkappe o.ä. während der Projektor eingeschaltet ist. Dies kann ein Schmelzen der Kappe verursachen. Darüber hinaus würden Sie sich aufgrund der vom Lichtausgang abgestrahlten Hitze wahrscheinlich die Hände verbrennen.

VORSICHT: Bei unsachgemäßer Handhabung kann die Hochdrucklampe explodieren. Überlassen Sie die Reparatur ausschließlich qualifiziertem Servicepersonal.

Vorsichtsmaßnahmen bezüglich der Lampe: Bitte vor dem Betrieb durchlesen

Aufgrund der unter Druck luftdicht verschlossenen Lampe besteht bei falscher Handhabung eine geringe Explosionsgefahr. Wenn sich das Gerät in einwandfreiem Zustand befindet, ist dieses Risiko minimal; die Explosionsgefahr erhöht sich jedoch im Falle einer Beschädigung oder bei einer Benutzung über die empfohlenen Betriebsstunden hinaus. Beachten Sie bitte, dass im Gerät ein Warnsystem integriert ist, das bei Erreichen der voreingestellten Betriebsdauer die nachfolgende Meldung anzeigt: "Over Time Bulb". Im Falle einer Lampenexplosion tritt aus den Lüftungsschlitzen der Rückseite des Gerätes Rauch aus. Stehen Sie nicht vor den Entlüftungsöffnungen während des Betriebes. Dieser Rauch besteht aus einer ganz besonderen Form von Glas und aus Xenon-Gas. Solange dieser Rauch nicht in die Augen gelangt, bestehen keinerlei gesundheitliche Risiken.

Wenn Ihre Augen dem Gas ausgesetzt worden sind, spülen Sie die Augen bitte sofort mit Wasser aus und konsultieren Sie einen Arzt. Reiben Sie die Augen nicht!

Dies könnte ernsthafte Verletzungen zur Folge haben.

WARNUNG:

Schauen Sie nicht in die Linse, wenn der Projektor eingeschaltet ist. Dies könnte schwere Augenverletzungen zur Folge haben.

VORSICHT

Ziehen Sie den Projektor-Hauptnetzstecker nicht vom Ausgang ab, und trennen Sie den Unterbrecher, unter den folgenden Bedingungen nicht ab. Anderenfalls kann der Projektor beschädigt werden.

- Während der Projektierung von Bildern
- Während des Abkühlens, nach dem Projektor ausgeschaltet worden ist. (Die POWER-Anzeige blinkt orange, während das Gebläse in Betrieb ist, und auf der LCD-Anzeige wird "cooling..." angezeigt. Das abkühlende fan fährt fort, für 3 Minuten zu arbeiten.)

Vorsichtsmaßnahmen zur Fernbedienung

- Behandeln Sie die Fernbedienung mit Sorgfalt.
- Wischen Sie die Fernbedienung sofort trocken, wenn sie einmal nass geworden sein sollte.
- Vermeiden Sie übermäßige Hitze und Feuchtigkeit.
- Erhitzen Sie die Batterien nicht, nehmen Sie sie nicht auseinander und werfen Sie sie nicht ins Feuer.
- Nehmen Sie die Batterien heraus, wenn Sie beabsichtigen, die Fernbedienung über einen längeren Zeitraum hinweg nicht zu benutzen.
- Stellen Sie sicher, dass die Batteriepole (+/-) richtig ausgerichtet sind.
- Verwenden Sie niemals verschiedene Batterietypen oder neue und alte Batterien zusammen.
- Entsorgen Sie leere Batterien entsprechend den an Ihrem Wohnort geltenden Bestimmungen

Entsorgung Ihres benutzten Gerätes



Die EU-weite Gesetzgebung, wie sie in jedem einzelnen Mitgliedstaat gilt, bestimmt, dass benutzte elektrische und elektronische Geräte mit dieser Markierung (links) getrennt vom normalen Haushaltsabfall entsorgt werden müssen.

Dies schließt Projektoren und deren elektrisches Zubehör oder ihre Lampen mit ein. Folgen Sie beim Entsorgen eines solchen Gerätes bitte den Anweisungen Ihrer örtliche Behörde und/oder konsultieren Sie den Händler, bei dem Sie das Gerät erworben haben.

Nach der Sammlung benutzter Geräte werden diese erneut verwendet und entsprechend den Umweltbestimmungen recycelt. Das trägt dazu bei, die Abfallmenge zu reduzieren sowie die negativen Auswirkungen auf die menschliche Gesundheit und die Umwelt möglichst gering zu halten.

Die Markierung auf elektrischen und elektronischen Geräten gilt nur für die gegenwärtigen Mitgliedsstaaten der Europäischen Union.

Bei Fragen, die sich aus unklaren Punkten oder Reparaturarbeiten ergeben

Bei Fragen, die sich aus unklaren Punkten, Fehlfunktionen oder Reparaturarbeiten am Produkt ergeben, wenden Sie sich an Ihren Händler oder an eine der folgenden Niederlassungen.

In Europa

NEC Europe, Ltd. / European Technical Centre
Adresse: Unit G, Stafford Park 12, Telford TF3 3BJ, U.K.
Telefon: +44 1952 237000
Fax-Nummer: +44 1952 237006

In Nordamerika

NEC Corporation of America
Digital-Cinema-Abteilung
Adresse: 4111 West Alameda Avenue Suite 412 Burbank, CA 91505
Telefon: 818 557 2500

*Falls die oben aufgeführte Leitung besetzt sein sollte, wählen Sie bitte die folgende Nummer;
Telefon: 866 632 6431

(MEMO)

Table of Contents

| | |
|---|-----------|
| Table of Contents | 1 |
| 1.What's in the Box? and the Names of the Projector Parts..... | 2 |
| 1-1. Features | 2 |
| 1-2. What's in the Box? | 4 |
| 1-3. Names of the Projector Parts | 5 |
| 1-4. Names on the Remote Control | 11 |
| 2.Installation and Connection | 14 |
| 2-1. Steps for setting up and connecting | 14 |
| 2-2. Connecting the image input terminals | 15 |
| 2-3. Connecting the various control terminal | 16 |
| 2-4. Connecting the power cord | 17 |
| 3.Projection of Images (Basic Operation) | 18 |
| 3-1. Steps of projecting images | 18 |
| 3-2. Turning your projector on | 19 |
| 3-3. Selecting the title of input signal | 21 |
| 3-4. Adjusting the position and the size of projected screen | 22 |
| 3-5. Turning your projector off | 24 |
| 4.Using Menus | 25 |
| 4-1. Basic operation with adjustment menus | 25 |
| 4-2. Table of adjustment menus | 29 |
| 4-3. Title Select | 30 |
| 4-4. Configuration | 31 |
| 4-5. Title Setup | 31 |
| 4-6. Information | 32 |
| 5.Maintenance of Your Projector | 34 |
| 5-1. Cleaning the Cabinet | 34 |
| 5-2. Cleaning the Lens | 34 |
| 6.Appendix | 35 |
| 6-1. Troubleshooting | 35 |
| 6-2. Indicator display list..... | 37 |
| 6-3. Error code list | 38 |
| 6-4. Operation using an HTTP browser | 40 |
| 6-5. Outline Drawing | 42 |
| 6-6. Specifications | 43 |
| 6-7. Pin Assignment and Functions of Terminal | 46 |
| 6-8. Related products list | 51 |

1.

What's in the Box? and the Names of the Projector Parts

1-1. Features

- **Compact projector for dedicated use with DLP Cinema®**

We have made the projector and the lamp console into one unit and achieved a quite compact projector exclusively used for DLP Cinema®.

- **Various setups possible thanks to a variety of optional lens units and the facility for inverted installation**

The DLP Cinema® projector is provided with a lens memory function for storing lens zoom positions and shift positions to set screens sizes for each input signal. It is also provided with a lamp power memory function for storing the brightness of the images on the screen for each input signal.

Even if you are projecting multiple images that have different settings for image sizes and brightness, you can project them with the conditions pre-registered for each signal, simply by selecting the corresponding signal.

- **Equipped with easy to use functions**

- (1) Lens memory function that can be operated with one touch, and lamp power memory function

The DLP Cinema® projector is provided with a lens memory function for storing lens zoom positions and shift positions to set screens sizes for each input signal. It is also provided with a lamp power memory function for storing the brightness of the images on the screen for each input signal.

Even if you are projecting multiple images that have different settings for image sizes and brightness, you can project them with the conditions pre-registered for each signal, simply by selecting the corresponding signal.

- (2) Equipped with a lamp output control function

You can set to any brightness setting, from low brightness to high brightness. This function makes it possible to minimize the fluctuation (*) in brightness as brightness of the lamp decreases as a result of long-term lamp usage.

* The time for maintaining fluctuations in brightness depends on the setting value for brightness.

- (3) Registered signal selection buttons

The projector has been equipped with new 8 signal selection buttons that make it easy to select registered signals. Up to 8 signals can be selected.

1. What's in the Box? and the Names of the Projector Parts

- **Up-to-date functions of DLP Cinema® available**

This projector supports CineLink™, CineCanvas™, CinePalette™ and CineBlack™ which are the new functions for security, subtitles, etc., developed by Texas Instruments Incorporated.

(1) CineLink™: Security management

This function supports encryption of the local link between server and projector, adds a “watermark” to enable the tracing of pirated films (illegal copying), and provides other functions.

(2) CineCanvas™: Image management

This function enables insertion of subtitles and captions, correction of distortion, changing of resolution, etc.

(3) CinePalette™: Color management

This function allows extension of color range, correction of color, etc.














(4) CineBlack™: Contrast management

This function realizes a color tone scale from pitch black to pure white.

- DLP, DLP Cinema and their respective logos are trademarks or registered trademarks of Texas Instruments.
- CineLink, CineCanvas, CinePalette, and CineBlack are trademarks of Texas Instruments.

1-2. What's in the Box?

Check the content of the accessories.

| | | |
|--|---|--|
| <input type="checkbox"/> NC800C projector | <input type="checkbox"/> Lens holder (NC-PH01) | |
|  |  | |
| <input type="checkbox"/> Remote control (RD-371E) | <input type="checkbox"/> Small iris x 1 | |
|  |  | |
| <input type="checkbox"/> UM-3 AA size battery (for the remote control) x 2 | <input type="checkbox"/> Wire stopper x 1 | |
|  |  | |
| <input type="checkbox"/> Remote cable (4 m) x 1 | <input type="checkbox"/> Sheet of title labels (for 20 labels) x 2 | |
|  |  | |
| <input type="checkbox"/> Remote cable (16 m) x 1 | <input type="checkbox"/> User's Manual (This document) | |
|  |  | |
| <input type="checkbox"/> Power cord (grounded) | | |
| Connect this projector to the power outlet. | | |
| Three types of power cords are supplied with this projector: for Japan, for the U.S. and for European countries. | | |
| • Power cord for Europe (AC230V) | • Power cord for North America (AC120V) | • Power cord for Japan (AC100V) |
|  |  |  |


TIP

- In the event that you did not receive all of the accessories outlined above, or some are damaged, contact your dealer/distributor.

Differs slightly from the drawings in this manual, but there is no problem in actual use.

1-3. Names of the Projector Parts

1-3-1. Front of the projector



1. Air inlet

Air is taken in here to provide cooling of the projector.

2. Control panel

On the control panel, power to your projector is turned on or off, signals are selected, and various adjustments are made of projected screen. (See page 9)

3. Connection terminals

Various image signal cables are to be connected here. (See page 7)

4. Feet (in four positions on the bottom)

In the ordinary installation, you can adjust the projector inclination at 4 positions.

5. Carrying handles

Hold the carrying handles when carrying your projector.


There are a total of two carrying handles, a set of bottom ones on the front and the back of your projector.

6. Lens (optional)

Images are projected from the lens. Please contact your dealer/distributor to install or replace the lens.

NOTE Do not cover the air inlet and outlet during operation. Inadequate air intake may lead to a rise in inside temperature, thus causing a fire or serious projector failure.

1-3-2. Rear of the projector



1. Air inlet

Air is taken in here to provide cooling of the projector.

2. Air outlet

The heat of the lamp is vented here.

3. Power cord

Connect the power cord to an AC outlet.

4. Function ground

The function ground is used when you wish to establish a common ground potential between the projector and the image-sending device or other equipment.

This is not a power supply ground terminal.

5. Main power switch

Connect the power cord to an AC outlet and set the main power switch to ON, then your projector will enter a standby state.


6. Lamp cover

The lamp house is accommodated. Mount and remove the lamps from here. For lamp mounting and removal, consult with your dealer.

NOTE

- Do not cover the air inlet and outlet during operation. Inadequate air intake may lead to a rise in inside temperature, thus causing a fire or serious projector failure.
- Do not touch the air outlet when your projector is operating. Otherwise, the high temperature may cause burns.

1-3-3. Connection terminals



1. Remote control input terminal (REMOTE IN) (Stereo mini)

Connect the remote control of the projector, using the supplied remote control cable.

Memo

- The projector's remote control can be used by connecting with the remote control cable. (See page 13)
-

2. PC control signal switch (CINEMA/SYSTEM)

Use this to set data on the projector.

3. PC control terminal (RS-232C) (D-Sub 9P)

This is used when the service personnel sets the data for the projector or operates the projector from PC via RS-232C. Use a commercially available RS-232C straight cable to connect the projector to the PC.

4. PC card slot

- Set a wireless LAN card, and you can control the projector from a PC, using a wireless LAN Please inquire your dealer/distributor about a wireless LAN card that can be used.
- Use this slot when doing maintenance on your projector.

5. USB port (USB) (type A)

Use this port when doing maintenance on your projector.

6. HDSDI A input terminal (SDI-A) (BNC)

Connect a Video Server or Video source to this terminal. Use a 75Ω coaxial cable.

7. HDSDI B input terminal (SDI-B) (BNC)

Connect a Video Server or Video source to this terminal. Use a 75Ω coaxial cable.

8. DVI-D A input terminal (DVI-A) (DVI-D 24P)

Connect the DVI-D output terminal of a PC to this terminal. Use a commercially available DVI-D signal cable (Single Link).

1. What's in the Box? and the Names of the Projector Parts

9. DVI-D B input terminal (DVI-B) (DVI-D 24P)

Connect the DVI-D output terminal of a PC to this terminal. Use a commercially available DVI-D signal cable (Single Link).

10. External control terminal (GP I/O) (D-Sub 37P)

Use this terminal when controlling your projector from an external switcher. (See page 48)


11. Ethernet port (LAN-A, LAN-B) (RJ-45)

Use this port when controlling your projector in LAN connection from a PC. Use a commercially available LAN cable (10Base-T/100Base-T) to connect the projector to the PC.

12. Ethernet port for the touch panel (TOUCH PANEL) (RJ-45)

This terminal is for future extensions.

1-3-4. Control panel



1. Remote control light reception unit

This receives signals from the remote control.

2. BACKLIGHT switch

Operate this switch to turn on/off the back light of the LCD screen and operation panel.

3. MMS STATUS indicator

This indicates the link status of the optional multi-media switcher (MMS).

| | |
|-----------------|--|
| Off | When not using multi-media switcher. |
| Orange lighting | When linked to multi-media switcher. |
| Orange blinking | Preparing link with multimedia switcher. |
| Red blinking | When a link error occurs. |

4. LCD screen

The liquid crystal display screen shows menus and setting values for the operation of your projector.

5. POWER button

Press this button to turn on or off (standby) the power to your projector. Press this for more than three seconds.

When turning on the power to the projector, first set the main power switch to the main unit to ON, thereby setting the projector in a standby state. (See page 19)

6. POWER indicator

| | |
|-----------------|---|
| Green lighting | When power is on. |
| Green blinking | When the douser is closed. |
| Orange lighting | When the power is off (in standby state). |
| Orange blinking | When the cooling fan(s) is running immediately after power-off. |

7. STATUS indicator

| | |
|--------------|--|
| Off | When the projector is operating normally. |
| Red blinking | When an error has occurred. An error code is displayed on the LCD screen. |

8. CTL (MACRO) button

Press the CTL (MACRO) button together with MACRO SELECT 1 to 8 buttons.

MACRO SELECT<1> to <8> button does not work individually.

1. What's in the Box? and the Names of the Projector Parts

9. 1 to 8 buttons

Press the 1 to 8 buttons while depressing the CTL (MACRO) button to select titles (input signals) assigned to each button. To this projector, 100 titles at most can be registered (input signal registration). Among the registered titles, any 8 titles can be assigned to the buttons <1> to <8>.

The indicator to the left of the buttons show the assigned/selected status of titles.

Request your dealer/distributor for details on registering and changing titles.

| | |
|-----------------|---|
| Green lighting | When any title is assigned to the button. |
| Orange lighting | When title is selected. |
| Off | When any title is not assigned to the button. |

10. CTL (LAMP) button

Press the CTL (LAMP) button together with the LAMP +/- buttons.

<LAMP +/-> button does not work individually.

11. LAMP +/- buttons

Press the LAMP +/- buttons while depressing the CTL (LAMP) button to adjust the output (brightness) of the lamp. (See page 23)

12. MENU button

Press this button, and menus for various settings and adjustments will be displayed. (See page 26)

13. [MENU CTL] UP/DOWN/LEFT/RIGHT buttons

Press the [MENU CTL] UP/DOWN/LEFT/RIGHT buttons when the menu is displayed to select menu items.

14. CANCEL button

Press the CANCEL button to return to previous menu item.

15. ENTER button

Press the ENTER button, and the displayed menu item is actioned.

16. FOCUS +/- buttons

Press the FOCUS +/- buttons while depressing the CTL (LENS) button to adjust the focus of the projected image. (See page 23)

17. ZOOM +/- buttons

Press these buttons while depressing the CTL (LENS) button, for fine adjustment of the size of projected image. (See page 23)

18. [LENS CTL] UP/DOWN/LEFT/RIGHT buttons

Press the [LENS CTL] UP/DOWN/LEFT/RIGHT buttons while depressing the CTL (LENS) button to move (lens shift) the position of the projected image up, down, left and right. (See page 22)

19. CTL (LENS) button


Press the CTL (LENS) button together with the FOCUS +/- button, the ZOOM +/- button, the [LENS CTL] UP/DOWN/LEFT/RIGHT button and the DOUSER button.

The FOCUS +/-, ZOOM +/- [LENS CTL] UP/DOWN/LEFT/RIGHT and DOUSER buttons do not function when pressed alone.

20. DOUSER button

Press the DOUSER button while depressing the CTL (LENS) button to open and close the douser.

1-4. Names on the Remote Control



1. POWER ON button

Operate this button to turn on the power to your projector.

Press it three seconds or longer.

When turning on the power to your projector, first set the main power switch to the main unit to ON, which puts your projector on standby. (See page 19)

2. POWER OFF button

Operate this button to turn off (standby) the power to your projector. Press it three seconds or longer.

3. Numeric buttons (1 to 0 buttons)

Use these buttons to enter alphanumeric characters. (See page 28)

4. TEST button

- Press this button, and a test pattern will be displayed.

Check the test pattern on the LCD screen by pressing the SELECT ◀/▶ button, then press ENTER to set your selection.

To cancel the test pattern display, reselect the signal to project.

5. KEYSTONE / R button

Press the KEYSTONE(R) button while depressing the CTL button, then the red (R signal) of the test pattern will be turned off temporarily. Press this button again while depressing the CTL button, and the red (R signal) will be projected again.

6. AMPLITUDE / G button

Press the AMPLITUDE (G) button while depressing the CTL button, then the green (G signal) of the test pattern will be turned off temporarily.

Press this button again while depressing the CTL button, and the green (G signal) will be projected again.

7. ENTRYLIST / B button

Press the ENTRYLIST (B) button while depressing the CTL button, then the blue (B signal) of the test pattern will be turned off temporarily.

Press this button again while depressing the CTL button, and the blue (B signal) will be projected again.

8. POSI / LENS button

Press the POSI/LENS button while depressing the CTL button, to adjust the position of projected screen (Lens Shift Mode). (See page 22)

9. PICT / SHUT button

- Press this button to turn off image projection temporarily. Press it again, and the image will be projected again.
- Press the PICT / SHUT button while depressing the CTL button, then the douser will operate to shut off the light for projection. The POWER indicator blinks in green while the douser is operating. Press this button again while depressing the CTL button to cancel the operation of the douser.

NOTE When GPIO Control is set to "Enable", it is not possible to turn the power on/off and the douser function.

10. MENU button

Operate this button, and menus for various settings and adjustments will be displayed on the LCD screen. (See page 26)

1. What's in the Box? and the Names of the Projector Parts

11. SELECT \blacktriangledown \blacktriangleleft \blacktriangleright buttons

- Press the SELECT \blacktriangleleft / \blacktriangleright button when the menu is displayed, and a menu item can be selected.
- Press the SELECT \blacktriangledown button when the menu is displayed, and a submenu will be displayed.
- Press the SELECT \blacktriangle button when the menu is displayed, and a menu one level above will be displayed.
- During character entry, press the SELECT \blacktriangleleft button while depressing the CTL button, then one character will be deleted.

12. ENTER button

Press the ENTER button, and the displayed menu item is actioned.

13. CANCEL button

Press the CANCEL button to return to the previous menu item.

14. FOCUS +/- buttons

Press the FOCUS +/- button while depressing the CTL button, to make lens focus adjustment. (See page 23)

15. ZOOM +/- buttons

Press the ZOOM +/- button while depressing the CTL button, to make lens zoom adjustment. (See page 23)

16. CTL button

The CTL button is a shift function used to access alternative functions on other buttons.

17. Back light switch

When this is set to [ON], the characters on the remote controller will light up.

- When using the remote control with infrared ray signals
If the remote control device is not operated for 30 seconds after turning "ON" the back light switch, the back light switch will automatically extinguish itself. Thereafter, it will light again when the remote control buttons are operated.
- When using the remote control connected to the remote control cable
The back light will constantly light when the power to the projector is turned on and when the projector is in standby status.

NOTE

- The following buttons cannot be used with this projector:
WHITE BAL., ADJUST PICTURE, IMAGE, INFO., PIXEL., MUTE SOUND, MUTE OSD, HELP, AUTO, UNDO

Inserting the batteries

[1] Remove the battery case cover on the backside of the remote control.

[2] Insert the UM-3 size AA batteries into the case. Be careful of the direction poles on the batteries.


[3] Restore the cover.

NOTE

- When replacing the batteries, always purchase two of the same type of UM-3 size AA batteries.

Effective range of the remote control

To operate the remote control using infrared rays, and not using the remote control cable, point the remote control transmission unit toward the remote control reception unit on the projector. Signals from the remote control can generally be received within the range shown in the figure below.




(Note) The effective range depicted in the figure may differ slightly in actual use.

1. What's in the Box? and the Names of the Projector Parts

Using the remote control cable

Use the remote control cable when there are objects that interrupt or obstruct the space between the remote control reception unit on the projector and the remote control, or when you are using the remote control beyond its effective range. Note that the remote control cable is connected first to the remote control, then to the projector head.



Notes for use of the remote control

- Do not drop or handle the remote control in a careless manner.
- Do not allow the remote control to be splashed with water or any other liquid. If the remote control should get wet accidentally, wipe the liquid off immediately.
- Be sure to use the remote control in a place free from heat or dampness as far as is practicable.
- The remote cable is connected first to the remote control, then to the projector head. The leading end of the remote cable is the power supply unit, so be careful not to touch the other end of the remote cable to the projector head or other devices while only the remote cable is connected to the projector.

2.

Installation and Connection

2-1. Steps for setting up and connecting

Use the following steps for setting up your projector:

- **Step 1**

Setup the screen and projector. (Contact your dealer to carry out the setup.)

- **Step 2**

Connect cables to the image input terminals. (See page 15)

Connect cables to the various control terminals. (See page 16)


- **Step 3**

Connect the power cord. (See page 17)

2-2. Connecting the image input terminals

Your projector has four image input terminals, namely, the HDSDI A input terminal, the HDSDI B input terminal, the DVI-D A input terminal, and the DVI-D B input terminal.


- HDSDI A/B input terminal (SDI A/SDI B) Inputs serial digital images from a Video Server or Video source.
- DVI-D A/B input terminal (DVI A/DVI B) Inputs digital RGB signals from a PC.



2-3. Connecting the various control terminal

For control, your projector comes with such ports as the PC control terminal and the Ethernet port (RJ-45).

- PC control terminal (PC CONTROL) Use this terminal when controlling the projector in serial connection from a PC.
- Ethernet port (LAN 1/LAN 2) Use this port when controlling the projector in LAN connection from a PC.




2-4. Connecting the power cord

After making certain that the main power switch of your projector is OFF, connect the power cord to 100-120VAC or 200-240VAC three-prong outlet (grounded).

CAUTION



- Please contact your dealer/distributor to perform the wiring for connection of the power cord to your projector.
- Be sure to ground the equipment to ensure safety.
To avoid electric shocks, request a professional to carry out the grounding.
Be sure to perform earth connection before inserting the power plug into the wall outlet.



→ 100-120 VAC or 200-240 VAC
three-prong outlet

NOTE

- In the following instances, do not disconnect the power plug from the outlet. Otherwise, trouble may occur:
 - When the fan is running after the power is turned off.
 - When using a Flash Memory card or LAN card, the card may be damaged.

Using the Power Cord Stopper


The Power cord wire stopper is provided on the projector so that the cord cannot be accidentally unplugged from the AC IN.

1. Lift up the wire stopper.



2. Plug the power cord into the AC IN.

3. Lift down the wire stopper to hold the power cord.


Wire stopper



Power cord



For North America



For Europe

3.

Projection of Images (Basic Operation)

3-1. Steps of projecting images

- **Step 1**

Turn on the power to the projector. (See page 19)

- **Step 2**

Select the title of input signal. (See page 21)

- **Step 3**

Adjust the position and size of the projected screen. (See page 22)

- **Step 4**

Turn off the power to the projector. (See page 24)

3-2. Turning your projector on


Preparation: Supply AC power to the projector head.
Please contact your dealer/distributor to connect the power cord.

- NOTE**
- Turn off the main power switch to the projector head when supplying or cutting AC power to the projector. If power is supplied or cut while the main power switch is turned on, the projector will be damaged.
 - Be sure to turn your projector on or off in two steps of operation with the “main power switch” and the “POWER button” (“POWER ON/OFF button” on the remote control).
 - Turning power on (See this page)
 - [1] Turn the “main power switch” on the projector head to on.
Your projector is set in a standby state.
 - [2] Press the POWER button (POWER ON button on the remote control) three seconds or longer.
Your projector is turn on.
 - Turning power off (See page 24)
 - [1] Press the POWER button (POWER OFF button on the remote control) three seconds or longer.
Your projector is set in a standby state.
 - [2] When the fan has stopped running, set the “main power switch” on the projector head to OFF.
Your projector is turned off.

1 Remove the lens cap.

2 Turn the main power switch on the side of your projector head to on.

The POWER indicator lights up orange (standby state).




3. Projection of Images (Basic Operation)

3 Press the POWER button on the control panel of your projector three seconds or longer.

Your projector is turn on, and the screen glows light about 30 seconds later. The POWER indicator of the projector lights up green.

- When controlling with the remote control, press the POWER ON button three seconds or longer.



NOTE


- While your projector is on, be sure to have the lens cap removed from the lens. Otherwise, the lens cap may get deformed due to a heat buildup.
- In the following instances, the power to your projector cannot be turned on even if you press the POWER button.
 - When the inside temperature is abnormally high. The protective function prevents power from turning on. Wait some time (until the projector inside cools down) and then turn on the power.
 - When the STATUS indicator is blinking without the lamp lighting up after power-on. Your projector may be in trouble. Check the error display on the LCD screen and contact your dealer/distributor for instructions.
- Note that the image may sometimes flicker until the lamp has stabilized (5 to 10 minutes) after power-on. This is due to the characteristics of the lamp and is not trouble of your projector.

3-3. Selecting the title of input signal

This projector allows you to select pre-registered signals using the signal selection buttons on the control panel (up to 8 signals). Request your dealer/distributor for details on registering and changing titles. This section explains the steps for selecting registered signals.

- 1** Turn on the power to the image devices connected to the projector.
- 2** Press the MENU button.
- 3** Press the [MENU CTL] LEFT/RIGHT button to display "Title Select" on the LCD screen.


At each press of the [MENU CTL] LEFT/RIGHT buttons, the display will cycle as "Title Select" ↔ "Configuration" ↔ "Title Setup" ↔ "Information."



- 4** Press the [MENU CTL] DOWN button.

The title of the input signal is displayed.


- When you have made a wrong selection, press the [MENU CTL] UP button. A return will be made to the previous menu.



- 5** Press the [MENU CTL] LEFT/RIGHT buttons to display "Title of Signal to be Projected" on the LCD screen.
- 6** Press the ENTER button.

The title of the signal to be projected is selected.

- The (*) mark on the LCD indicates that this is the currently selected item.




3-4. Adjusting the position and the size of projected screen

3-4-1. Displaying the test pattern


- 1 Press the TEST button on the remote control. Alternatively, select the test pattern from the signal selection button.

If you register the test patterns to the signal selection buttons (<1> to <8> buttons), select the test pattern according to "3-3. Selecting the title of input signal (See page 21)".
The mode for selecting the test pattern is set.



- 2 Press the SELECT ◀▶ button.

The display of the test pattern name on the LCD switches.



- 3 Display on the LCD the name of the test pattern to be projected, then press the ENTER button.

The test pattern is displayed.

- To cancel the test pattern display, reselect the signal to be project.





3-4-2. Adjusting the position of the projected screen (Lens shift)

- 1 Press the [LENS CTL] UP/DOWN/LEFT/RIGHT buttons while depressing the CTL button, on the control panel of your projector as required.

The position of the projected screen will move upward, downward, left or right.



- When controlling with the remote control, press the POSI/LENS button while depressing the CTL (LENS) button.



3-4-3. Fine adjustment of the size of the projected screen (Zoom)

1 Press the ZOOM +/- buttons while depressing the CTL (LENS) button on the control panel of your projector as required.



- When controlling with the remote control, press the ZOOM +/- button while depressing the CTL (LENS) button.



3-4-4. Focusing the projected screen (Focus)



1 Press the FOCUS +/- buttons while depressing the CTL (LENS) button, on the control panel of your projector as required.

- When controlling with the remote control, press the FOCUS +/- button while depressing the CTL (LENS) button.



3-4-5. Adjusting the brightness of the projected screen (Lamp output)

1 Press the LAMP +/- buttons while depressing the CTL (LAMP) button, on the control panel of your projector as required.



3-5. Turning your projector off


- 1 Press the **POWER** button on the projector control panel for three seconds or longer.

The power to the projector is turned off. The **POWER** indicator will blink in orange (cooling state).

The fan will continue to rotate while cooling, and the amount of time remaining for cooling is displayed on the LCD screen. The cooling-off time is 3 minutes.


When cooling has ended, the **POWER** indicator lights in orange (Standby).

- When controlling with the remote control, press the **POWER OFF** button for three seconds or longer.



- 2 When the projector has entered the standby state, turn the main power switch on the projector head to off.

The projector **POWER** indicator will extinguish and the main power will turn off.



- 3 Turn off the AC power to the projector head.

NOTE

- In the following instances, do not turn off the main power switch or disconnect the AC power. Doing so can damage the projector.
 - While projecting images
 - While the fan is running after the power is turned off (The cooling-off time is 3 minutes)


4. Using Menus

4-1. Basic operation with adjustment menus





To adjust the projector, display the menu on the LCD screen of the projector control panel.

4-1-1. Screen display

The menu display screen is composed of a menu display field (the upper two lines) and a setting item display field (the bottom two lines).



The meanings of symbols in the menu display screen are outlined below.


| | |
|---|--|
|  | Indicates that there is a menu of a higher level. Press the [MENU CTL] UP button to return to a menu one level above. |
|  | Indicates that there is a selected item or menu at the same level. Press the [MENU CTL] LEFT/RIGHT button to display other selected items or menus. |
|  | Indicates that there is a menu of a lower level. Press the [MENU CTL] DOWN button to display the menu one level below. |
|  | Indicates that there are setting items of a lower level. Press the [MENU CTL] UP button to return to a menu one level above. Press the [MENU CTL] DOWN button to display the setting item one level below. |

4. Using Menus

When not displaying menus, the following screen is normally displayed.


When in standby

When the projector is in a standby state (the main power switch in on), the following is displayed.



When power is turned on

When the power is turned on, the following is displayed.



← Displays the hours of lamp bulb use.


← Displays the lamp output (%).

← Displays the selected title.

← Displays the selected port.

When the power is turned off

The amount of time remaining for cooling is displayed as shown below, when the power to the projector head is turned off.




4-1-2. Operating menus

Preparation: Turn your projector on. (See page 19)


- 1 Press the MENU button on the control panel of your projector .

The menu is displayed in the LCD screen.



- 2 Press the [MENU CTL] LEFT/RIGHT buttons to display "Information."

At each press of the [MENU CTL] LEFT/RIGHT buttons, the display y p l cycle as "Title Select" ↔ "Configuration" ↔ "Title Setup" ↔ "Information."




3 Press the [MENU CTL] DOWN button.


The submenu "Lamp" of "Information" is displayed.

The menu item can be selected by pressing the ENTER button instead of the SELECT DOWN button


To return to the previous state, press the [MENU CTL] UP button, or the CANCEL button.

**4** Press the [MENU CTL] LEFT/RIGHT button to select the submenu "Version."


At each press of the [MENU CTL] LEFT/RIGHT button, the display will cycle as "Lamp" ↔ "Macro Key" ↔ "Usage" ↔ "Error Code" ↔ "Version" ↔ "IP Address" ↔ "MMS Status."

**5** Press the [MENU CTL] DOWN button.

The submenu "BIOS" another rank lower than "System" is displayed.

**6** Press the [MENU CTL] LEFT/RIGHT button to select the submenu "Data."

At each press of the [MENU CTL] LEFT/RIGHT button, the display will cycle as "BIOS" ↔ "Firmware" ↔ "Data" ↔ "Serial No.," and each version information is displayed.

**7** Press the [MENU CTL] UP button several times.


At each press of the [MENU CTL] UP button, the display will return to a menu one level above.

4. Using Menus

4-1-3. How to enter alphanumeric characters

Alphanumeric characters are entered for items, such as the title of input signal.

With this projector, the characters are inputted by pressing numeric buttons on the remote control.



By pressing the numeric buttons, the characters can be inputted as shown in the table below.

- To delete a character during entry, press the SELECT ◀ button while depressing the CTL button.

[Example of Entry]

To enter "XGA" for example, use the following procedure:

- Press the 8 button three times.
V → W → X
- Press the SELECT ▶ button.
- Press the "3" button.
XG
- Press the SELECT ▶ button.
- Press the "1" button.
XGA

| Numeric button | Press directly | While depressing CTL button |
|----------------|----------------------|-----------------------------|
| 1 | A → B → C → 1 → ↑ | a → b → c → ! → ↑ |
| 2 | D → E → F → 2 → ↑ | d → e → f → î → ↑ |
| 3 | G → H → I → 3 → ↑ | g → h → i → # → ↑ |
| 4 | J → K → L → 4 → ↑ | j → k → l → \$ → ↑ |
| 5 | M → N → O → 5 → ↑ | m → n → o → % → ↑ |
| 6 | P → Q → R → 6 → ↑ | p → q → r → & → ↑ |
| 7 | S → T → U → 7 → ↑ | s → t → u → í → ↑ |
| 8 | V → W → X → 8 → ↑ | v → w → x → (→ ↑ |
| 9 | Y → Z → / → 9 → ↑ | y → z → ? →) → ↑ |
| 0 | * → . → . → 0 → ↑ | ; → : → + → _ → ↑ |

[NOTE]

- To input characters using the remote control, only numbers can be entered with [password] and the security [keyword].

4-2. Table of adjustment menus

Menus in parentheses are menus for our service personnel. Normally, these menus cannot be used.

| Main menu | Submenu | | Description | Reference page | |
|---------------|---------------------|--|--|---|----|
| Title Select | "Title Memory Name" | | Selects the title of the signal to be projected. | 30 | |
| | TEST Pattern | | Selects the test pattern to be projected. | 30 | |
| Configuration | Lamp Setup | Adjust | Adjusts lamp brightness. | 31 | |
| | | Feedback | Sets the lamp brightness constant mode that uses a brightness sensor. | 31 | |
| | (Setup) | Douser Mode | Selects whether to use the douser (screen mute) when switching signals. | - | |
| | | Ext. MMS Link | Sets whether to connect the multi-media switcher (MMS). | - | |
| | | Panel Key Lock | Locks the buttons on the projector's control panel so that they cannot be operated. | - | |
| | | GPIO Port | Selects the target of GPIO port control. | - | |
| | | FactoryDefault | Returns the settings to their default values (only macro keys and titles, or all settings). | - | |
| | (Installation) | Image Orient | Selects the projection method (desktop front / desktop rear / ceiling front / ceiling rear). | - | |
| | | Lens Center | Moves the lens shift position to the center. | - | |
| | | MMS Select | Selects the multi-media switcher (MMS) to connect. | - | |
| | | Baudrate | Sets the PC control connector (RS-232C) data transmission speed (bps). | - | |
| | | Date/Time | Sets the date and time on the projector. | - | |
| | | Bulb Alignment | Sets the lamp bulb alignment. | - | |
| | (Memory) | Lamp | Saves the current lamp setting. | - | |
| | | Lens | Saves the current lens setting. | - | |
| | (Title Setup) | Macro Key | Macro Key No.1-8 | Sets the titles to be assigned to the macro keys of 1 to 8. | 31 |
| | Information | Lamp | Output | Displays the lamp output setting. | 32 |
| Macro Key | | Macro Key No.1-8 | Displays the titles assigned to the macro keys of 1 to 8. | 32 | |
| Usage | | Displays the usage times of the projector, lamp bulb, lamp house and bulb warning. | 32 | | |
| Error Code | | Displays the currently occurring error. | 32 | | |
| Version | | Displays the version of the projector head. (BIOS, Firmware, Data, and Serial No.) | 33 | | |
| IP Address | | System | Displays the SYSTEM IP address. | 33 | |
| | | Cinema | Displays the CINEMA IP address. | 33 | |
| MMS Status | | Displays the link-status of the connected multi-media switcher (MMS). | 33 | | |


4-3. Title Select

4-3-1. Title select (Title Memory)

Selects the title of the signal to be projected.

You can register up to 100 titles. You can also assign registered titles to the Macro keys of 1 to 8 on the projector's control panel and call them up directly using those buttons.

Request your dealer/distributor for details on registering and changing titles.




← Displays the currently selected item with asterisk (*).

← Selects the title to be projected.

4-3-2. Test Pattern

Selects the test pattern to be projected.



← Displays the currently selected item with asterisk (*).

← Selects the test pattern to be projected.

OFF, Alignment, Cross Hatch, Convergence, Red, Green, Blue, White, Black, White 50% [IRE], H-Ramp, Logo

4-4. Configuration

Please request your dealer/distributor to perform the settings.

4-4-1. Lamp Setup

Adjust

Adjusts the lamp output (brightness). Control the output at 30 to 34 W increments.

```
LAMP SETUP
Adjust
 85 [%] (*)
128.0 [A]
```

← Displays the lamp output (%) with regard to the setting.

← Adjusts the lamp brightness.

Feedback

Sets the lamp brightness constant mode that uses a brightness sensor.

```
LAMP SETUP
Feedback
 (*)
Disable
```

← Displays the currently selected item with asterisk (*).

← Displays the setting.

| | |
|---------|---|
| Disable | Disables the lamp brightness constant mode. |
| Enable | Enables the lamp brightness constant mode. |

4-5. Title Setup

Sets the titles to be assigned to the macro keys.

Request your dealer/distributor to perform the settings.

4-6. Information


Displays the hours of lamp bulb use, the version information and error codes.

4-6-1. Lamp

Displays information relating to the lamp. (Such as lamp output and the utilization time of lamp bulb.)

Output


Displays the lamp brightness (output) setting.



← Displays the power consumption (W).

4-6-2. Macro Key

Displays the titles assigned to the macro keys of 1 to 8 on the projector's control panel.




← Selects the macro key number whose contents you want to display.

← Displays the registered names of the assigned titles.

4-6-3. Usage

Projector and lamp bulb utilization times and the remaining usable time for the lamp bulb are displayed.




← Selects the item to display.

← Displays the hours of use (H).

| | |
|----------------|--|
| Projector | Displays the hours of projector head use. |
| Bulb | Displays the utilization time of the currently used lamp bulb (Lamp utilization time). |
| Remaining Time | Displays the remaining usable time for the lamp bulb. |

4-6-4. Error Code

Displays the error code when an error occurs. See the "Error Code List" in the Appendix for details on error codes.




← Displays the code of the error currently occurring.

← Displays the name of the error currently occurring.

When multiple errors occur, you can display them by pressing the [MENU CTL] LEFT/RIGHT buttons.

4-6-5. Version

Displays the versions of the projector head.




← Selects the item to display.

← Displays the version information.

| | |
|------------|--|
| BIOS | Displays the BIOS version of the projector head. |
| Firmware | Displays the firmware version of the projector head. |
| Data | Displays the data version of the projector head. |
| Serial No. | Displays the serial number of the projector head. |

4-6-6. IP Address

Displays the IP address set in the projector head.




← Selects the item to display the IP address.

← Displays the IP address.

| | |
|--------|--|
| System | Displays the IP address set for the projector head (System). |
| Cinema | Displays the IP address set for the projector head (Cinema). |

4-6-7. MMS Status

Indicates the link-status of the multi-media switcher (MMS) connected to your projector.



← Displays the status information of MMS linked operations.

← Displays the IP address.

| | |
|----------|--|
| External | External multi-media switcher (MMS) is linked. |
| Not Use | There is no link established. |

5.

Maintenance of Your Projector

NOTE Please request your dealer to perform lamp replacement, filter replacement and cleaning of the projector inside.

5-1. Cleaning the Cabinet

Be sure to always check that the AC power supply of the projector head is disconnected before carrying out maintenance of your projector.

- Wipe with a dry, soft cloth without nap.
When the cabinet is excessively dirty, wipe with cloth well wrung after being dampened with a neutral detergent diluted with water and then finish up with a dry cloth.
When you use a chemical dust cloth, follow the instructions in the manual attached to it.
- Do not use a solvent, such as thinner or benzene. The coating may deteriorate or peel off.
- When removing dust on the ventilation opening, suck it off using an adapter with a brush on a vacuum cleaner. Never allow the cleaner without an adapter to come into direct contact or use a nozzle adapter in cleaning.
- Clean the ventilation opening at regular intervals. Dust, if allowed to accumulate there, may cause heating inside, which leads to functional trouble. The interval, which can vary with the location of your projector, is about 100 hours.
- Do not damage the cabinet by scratching it or allowing hard objects to hit it. This can scratch the projector.
- Consult your dealer/distributor about cleaning the inside of the projector.

NOTE Do not allow insecticide or other volatile liquid to splash on the cabinet, lens or screen. Also, do not allow any rubber or plastic object to remain in contact with the cabinet for a long time. The coating may deteriorate or peel off.

5-2. Cleaning the Lens

Clean the lens the same way as with camera lens (using a commercially available camera blower or cleaning paper for glasses). Take care not to damage the lens when cleaning.

6.

Appendix

6-1. Troubleshooting

Before asking for repair, please check your connection, settings and operation once again. If the trouble cannot be corrected, please contact your dealer/distributor for instructions or repair.

6-1-1. Problems and where to check


| Problem | Check these items |
|------------------------------------|---|
| The projector cannot be turned on. | Check to see if the power plug is properly connected to the outlet. |
| | Make certain that the main power switch is ON. |
| | Check to see whether the panel key lock function is activated. If so, the main unit's control buttons are locked and do not work, but the projector can be controlled using the remote control unit. |
| | Is the temperature inside the projector too high? When the inside temperature is too high, the protective function does not allow your projector to be turned on. Wait some time and then turn it on. |
| The image cannot be projected. | Check to see if the connected input has been selected. |
| | Check to see if a cable is properly connected to the input terminal. |
| | Check to see whether the douser is closed. |
| | Check to see if the settings are all adjusted properly. |
| The image is distorted. | Check to see if the projector is properly set up. |
| The image is blurred. | Make certain that the lens is properly focused. |
| | Check to see if the screen and a projector are installed at correct angles. |
| | The projection distance may be larger than the focusing range. |
| | See if the lens and other parts have condensation on them. If the projector is turned on in a warm place after storage in a cold place, the lens and other optical components inside may develop condensation. In such a case, please wait several minutes until the condensation disappears. |
| Video image is disturbed | Check whether the signal cable connected to the projector is disconnected. |

6. Appendix

| Problem | Check these items |
|---|--|
| The projector cannot be operated with the remote control. | Make sure the remote control transmission unit is facing the light reception unit on the projector. |
| | Check whether the batteries are still good. Replace with new batteries. |
| | Check whether there is any obstructing object between the remote control and the light reception unit on the projector. |
| | Check whether you are outside of the remote control's effective range (7m). |
| | Check whether the remote control cable has become disconnected, if you are using the remote control by connecting with the remote control cable. |
| The STATUS indicator blinks in red. | Your projector may have trouble. Please contact your dealer/distributor for instructions. |
| An error code is displayed. | See the "Error Code List" (page 38). |

6-2. Indicator display list

See the descriptions below when the blinking or lighting of the two indicators on the projector's control panel is observed.



6-2-1. POWER indicator

| Indicator condition | | Projector condition | Note |
|---------------------|--------|---|--------------------|
| Off | | The main power is off. | - |
| Blinking light | Green | The projector is getting ready to turn on. The douser is closed. | Wait for a moment. |
| | Orange | The projector is cooling down. | Wait for a moment. |
| Steady light | Green | The projector is turned on. | - |
| | Orange | The projector is in standby. | - |

6-2-2. STATUS indicator

| Indicator condition | | Projector condition | Note |
|---------------------|-----|-----------------------------|---|
| Off | | Normal. | - |
| Blinking light | Red | When an error has occurred. | An error message is displayed in the LCD screen. Check the content of the error. |

6-2-3. MMS STATUS indicator

| Indicator condition | | Projector condition | Note |
|---------------------|--------|---|---|
| Off | | Multi-media switcher (MMS) not in use. | - |
| Blinking light | Red | Link error | Link error. An error message is displayed in the LCD screen. Check the content of the error. |
| | Orange | Preparing link with Multi-media switcher (MMS). | Wait for a moment |
| Steady light | Orange | Multi-media switcher (MMS) is linked. | - |

6-3. Error code list

Please inquire your dealer/distributor about action to be taken for each error code.

Description is omitted for error codes 20 to 92.

| Error code | Error message | Description |
|------------|-------------------------|---|
| 1 | Lamp Cover Open | Lamp cover is open. |
| 2 | Over Temp Lamp | Temperature (lamp temperature) is abnormal. |
| 3 | Fan Stop | DC fan stop. |
| 4 | GPSU Fail | Power supply is abnormal. |
| 5 | Lamp Unlit | Lamp doesn't light up. |
| 8 | Over Temp. LPSU | Temperature (in lamp power supply) is abnormal. |
| 9 | Over Temp. In | Temperature (inside of projector) is abnormal. |
| 10 | DLP PGOOD Fail | Engine power is abnormal. |
| 11 | DLP Comm. Fail | Cinema engine communication error. |
| 12 | E2PROM R Fail | E2PROM data read error is detected. |
| 15 | E2PROM W Fail | E2PROM data write error is detected. |
| 16 | Fan Stop Lamp | Stop of lamp cooling fan. |
| 17 | Pump Stop | Stopped for pump error. |
| 18 | Over Temp. DMD | DMD temperature error alarm. |
| 19 | E2PROM D Fail | E2PROM data failure. |
| 20 | System Fail | - |
| 21 | Self Test Fail | - |
| 22 | ARM Fail | - |
| 23 | DSP Fail | - |
| 24 | Interface FPGA Fail | - |
| 25 | Processor FPGA Fail | - |
| 30 | IB Diag Not Performed | - |
| 31 | IB FPGA Code Invalid | - |
| 32 | IB FPGA INITZ Fail | - |
| 33 | IB FPGA No-Load Set | - |
| 34 | IB FPGA DONE Fail | - |
| 35 | IB FPGA Reg R/W Fail | - |
| 36 | IB Framestore Test Fail | - |
| 37 | IB ANC FIFO Test Fail | - |
| 38 | IB RTC Serial # Fail | - |
| 39 | IB UART0 Fail | - |
| 40 | IB UART1 Fail | - |
| 41 | IB IIC Fail | - |
| 42 | IB Ethernet Fail | - |
| 43 | IB Sync-Serial Fail | - |
| 44 | IB File System Fail | - |
| 45 | IB Formatter Fail | - |
| 46 | IB Flash Protect Fail | - |
| 47 | IB GPI Macro Fail | - |
| 48 | IB A/D Macro Fail | - |
| 60 | PB Diag Not Performed | - |
| 61 | PB FPGA Code Invalid | - |
| 62 | PB FPGA INITZ Fail | - |

| Error code | Error message | Description |
|------------|-------------------------------|---|
| 63 | PB McBSP XRDY Fail | - |
| 64 | PB FPGA Done Fail | - |
| 65 | PB FPGA Reg R/W Fail | - |
| 66 | PB Serial-ID Chip Fail | - |
| 67 | PB CLUT-SRAM Fail | - |
| 68 | PB OvFS-SDRAM Fail | - |
| 69 | PB Resizer FIR Fail | - |
| 70 | PB Resizer FIFO Fail | - |
| 71 | PB Other Fail | - |
| 90 | FB Red RDRAM Signature Fail | - |
| 91 | FB Green RDRAM Signature Fail | - |
| 92 | FB Blue RDRAM Signature Fail | - |
| 120 | DLP Ack Fail | Cinema block communication ACK error. |
| 123 | OverTime Bulb | Lamp bulb cumulative time is over. |
| 130 | MMS Comm. Fail | Multimedia switcher (MMS) link operation failure. |

6-4. Operation using an HTTP browser

6-4-1. Overview

The use of HTTP server functions will allow control of the projector from a web browser. Please be sure to use “ Microsoft Internet Explorer 4.x” or a higher version for the web browser.

This device uses “JavaScript” and “Cookies” and the browser should be set to accept these functions. The setting method will vary depending on the version of the browser. Please refer to the help files and the other information provided in your software.

NOTE The display's or button's response can be slowed down or operation may not be accepted depending on the settings of your network.
Should this happen, consult your network administrator.
The projector may not respond if its buttons are repeatedly pressed in rapid intervals. Should this happen, wait a moment and repeat. If you still cannot get any response, pull out and then reinsert the LAN card on the projector.
Access is gained to the HTTP server functions by and specifying
`http://<the projector's IP address>/index.html`
in the entry column of the URL.

6-4-2. Preparation before use

Make network connections and set up the projector and confirm that it is complete before engaging in browser operations. Operations with a browser that uses a proxy server may not be possible depending on the type of proxy server and the setting method. Although the type of proxy server will be a factor, it is possible that items that have actually been set will not be displayed depending on the effectiveness of the cache, and the contents set from a browser not be reflected in operation. It is recommended that a proxy server not be used unless it is unavoidable.

6-4-3. Handling of the address for operation via a browser

Regarding the actual address that is entered for the address or entered to the URL column when operation of the projector is via a browser, the host name can be used as it is with the host name corresponding to the IP address of the projector has been registered in the domain name server by a network administrator, or the host name corresponding to the IP address of the projector has been set in the “HOSTS” file of the computer being used.

(Example 1) When the host name of the projector has been set to “pj.nec.co.jp”

`http://pj.nec.co.jp/index.html` is specified for the address or the entry column of the URL to access HTTP server functions.

(Example 2) When the IP address of the projector is “192.168.10.10”


`http://192.168.10.10/index.html` is specified for the address or the entry column of the URL to access HTTP server functions.

6-4-4. Structure of the HTTP server



| | | |
|------------------|---------|--|
| Power | | Controls the power to your projector. <ul style="list-style-type: none"> • On: Turns the power on. • Off: Turns the power off. |
| Title List | | Displays titles set in the projector (such as input port, screen type, and title). Check, and the title will be changed. |
| Basic Control | | Displays the basic control items. |
| Lens | | Controls the lens operation. |
| | Shift | <ul style="list-style-type: none"> ▲ : Shifts the projected screen upward. ▼ : Shifts the projected screen downward. ◀ : Shifts the projected screen leftward. ▶ : Shifts the projected screen rightward. ■ : Stops the shifting. Shifting can also be stopped by clicking the same button one more time. |
| | Zoom | <ul style="list-style-type: none"> ▲ : Zooms up the lens. ▼ : Zooms down the lens. ■ : Stops the zooming. Zooming the can also be stopped by clicking the same button one more time. |
| | Focus | <ul style="list-style-type: none"> ▲ : Focuses up the lens. ▼ : Focuses down the lens. ■ : Stops the focusing. Focusing can also be stopped by clicking the same button one more time. |
| Mute | Picture | Click and the douser closes and the projected picture disappears. Click once again and the picture will be projected again. |
| Projector Status | | Displays the condition of the projector. <ul style="list-style-type: none"> • Port: Displays the input port of the selected title. • Lamp Usage: Displays the hours of lamp use. • Lamp Power: Displays lamp output (%). • Error Status: Displays the status of errors occurring within the projector. • Refresh: Updates the display of the following conditions. |

6-5. Outline Drawing



Units: mm (inch)

6-6. Specifications

| | | | |
|--------------------------|---|--------------------------------|----------------------------|
| Model No. | NC800C | | |
| Projection method | 3 chip DMD reflector method (DLP® method) | | |
| Panel resolution | 2048 x 1080 | | |
| Lamp type | 1.25 kW xenon lamp | | |
| Screen sizes | 8 m (Width) (Depends on setup conditions) | | |
| Contrast ratio | 200:1 or above | | |
| Lens adjustment function | Motorized lens shift (vertical/horizontal), motorized zoom, motorized focus, douser | | |
| Signal input terminal | RGB DIGITAL (2) DVI-D 24pin (TMDS specification) SDI (2) BNC (SMPTE 292M) | | |
| External Control | RS232C (1) D-sub 9 pin Remote control LAN port (RJ-45) x 2 USB port (type A) GPIO port (D-sub 37 pin) PC card slot (1) PCMCIA type II, card bus LAN port for the Touch Panel (Note) | | |
| Power supply voltage | AC100 to 120V 50/60Hz, AC200 to 240V 50/60Hz | | |
| Input current | 12A (100 - 120V), 8.5A (200 - 240V) | | |
| Power consumption | 1.2kW to 1.44kW (100 - 120V), 1.7kW (200 - 240V) | | |
| Cooling method | Cooling air system (includes dust filter) | | |
| Noise level | Less than 45dB (When set to minimum brightness mode) | | |
| Installation | Orientation: Desktop/front, Desktop/rear, Ceiling/front, Ceiling/rear | | |
| Dimensions | 670mm(W) x 826mm(D) x 423mm(H) (Does not include protruding portions Includes foot) | | |
| Net weight | 66 kg (Excluding lens) | | |
| Environment | Operating temperature: 5 to 35°C Operating humidity: 10 to 85% (non-condensing) Storage temperature: -10 to 50°C Storage humidity: 10 to 85% (non-condensing) | | |
| Regulations | | <Safety> | <EMC> |
| | USA | UL60950-1 | FCC Class A |
| | Canada | CSA60950-1 | ICES-003 Class A |
| | Europe | EN60950-1 | EN55022 Class A EN55024 |
| | Oceania | IEC60950-1 AS/NZS CISPR. 22 | Class A |
| | Japan | J60950 | VCCI Class A |
| | Asia | IEC60950-1 | CISPR. 22 |

(Note) This is the terminal for future expansions.

* Note that these specifications and design can change without prior notice.

6. Appendix

Caracteristiques techniques

| | | | |
|-----------------------------------|--|------------------|-----------------------------|
| Numéro du modèle | NC800C | | |
| Mode de projection | Réflecteur DMD 3 matrices (DLP® method) | | |
| Résolution du panneau | 2048 x 1080 | | |
| Type de lampe | Lampe xenon 1.25kW | | |
| Tailles d'écran | 8m (Largeur) (Dépend des conditions de configuration) | | |
| Rapport de contraste | Plus de 200 : 1 | | |
| Fonction de réglage de l'objectif | Commande du mouvement horizontal et vertical de l'objectif à moteur, Commande du zoom et de la mise au point à moteur, obturateur | | |
| Borne d'entrée des signaux | RGB NUMERIQUE (2) DVI-D 24fiches (Spécifications TMDS) SDI (2) BNC (SMPTE 292M Niveau C, 4:2:2) | | |
| Commande extérieure | D-sub 9 fiches RS232C (1) Télécommande Port Ethernet (2) (RJ-45) Port USB (Type A) Port GPIO (D-sub 37 broches) Slot de carte PC (1) PCMCIA type II, bus de carte Port Ethernet pour le Toucher Panneau (Remarque) | | |
| Alimentation électrique | CA100-120V 50/60 Hz, CA200-240V 50/60 Hz | | |
| Intensité d'entrée | 12A(100-120V), 8.5A(200-240V) | | |
| Puissance absorbée | 1.2kW to 1.44kW(100-120V), 1.7kW(200-240V) | | |
| Mode de refroidissement | Système de refroidissement par air (comprend un filtre anti-poussière) | | |
| Niveau de bruit | Moins de 45dB (Lorsque réglé en mode de luminosité minimum) | | |
| Installation | Bureau/Avant, Bureau/Arrière, Plafond/Avant, Plafond/Arrière | | |
| Dimensions | 670mm(l) x 826mm(p) x 423mm(h) (Ne comprend pas les parties saillantes Comprend le pied) | | |
| Poids net | 66kg (sans objectif) | | |
| Environnement | Température de service : 5° à 35°C, Humidité : 10-85% (sans condensation) Température de magasinage: -10° à 50°C Humidité : 10-85% (sans condensation) | | |
| Réglementations | <Sécurité> | <EMC> | |
| | USA | UL60950-1 | FCC Classe A |
| | Canada | CSA60950-1 | ICES-003 Classe A |
| | Europe | EN60950-1 | EN55022 Classe A EN55024 |
| | Océanie | IEC60950-1 | |
| | | AS/NZS CISPR. 22 | Classe A |
| | Japon | J60950 | VCCI Classe A |
| | Asie | IEC60950-1 | CISPR. 22 |

(Remarque) C'est la borne pour de futures expansions.

* Veuillez noter que l'apparence et les caractéristiques peuvent être modifiées sans avertissement préalable.

Technische Daten

| | | | |
|-------------------------|---|------------------|-----------------------------|
| Modellnummer | NC800C | | |
| Projektionsverfahren | 3 Chip DMD-Reflektorverfahren (DLP®-Verfahren) | | |
| Bildflächenauflösung | 2048 x 1080 | | |
| Lampentyp | 1.25kW Xenon-Lampe | | |
| Bildschirmgrößen | 8m (Breite) (Ist abhängig von den Einrichtungsbedingungen) | | |
| Kontrastverhältnis | Mehr als 200 : 1 | | |
| Linsenbewegung | Servo in Horizontal- und Vertikalrichtung, Motorzoom und -fokus, Douser | | |
| Signaleingangsanschluss | RGB DIGITAL (2) DVI-D 24-pol (TMDS-Spezifikation) SDI (2) BNC (SMPTE 292M Level C, 4:2:2) | | |
| Externe Steuerung | RS232C (1) D-sub 9-pol Fernbedienung Ethernet Port (2) (RJ-45) USB Port (Typ A) GPIO Port (D-Sub 37-pol.) PC-Kartensteckplatz (1) PCMCIA Typ II, Karten-Bus Ethernet Port für das Fingerspizentablett (Hinweis) | | |
| Spannungsversorgung | 100-120V Wechselstrom 50/60Hz, 200-240V Wechselstrom 50/60Hz | | |
| Eingangsstrom | 12A(100-120V), 8.5A(200-240V) | | |
| Leistungsaufnahme | 1.2kW to 1.44kW(100-120V), 1.7kW(200-240V) | | |
| Abkühlverfahren | Luftabkühlssystem (einschließlich Staubfilter) | | |
| Geräuschpegel | Weniger als 45dB (Wenn es auf minimale Belichtung eingestellt ist) | | |
| Installation | Ausrichtung: Desktop/Vorn, Desktop/Hinten, Decke/Vorn, Decke/Hinten | | |
| Abmessungen (B/T/H) | 670mm(B) x 826mm(T) x 423mm(H) (Ohne hervorstehende Teile, einschließlich Fuß) | | |
| Gewicht | 66kg (ohne Linse) | | |
| Umgebungsbedingungen | Betriebstemperatur: 5°C bis 35°C Feuchtigkeit: 10-85% ohne Kondensatbildung Lagerungstemperatur: -10°C bis 50°C Feuchtigkeit : 10-85% ohne Kondensatbildung | | |
| Verordnungen | <Sicherheit> | <EMC> | |
| | USA | UL60950-1 | FCC Klasse A |
| | Kanada | CSA60950-1 | ICES-003 Klasse A |
| | Europa | EN60950-1 | EN55022 Klasse A EN55024 |
| | Ozeanien | IEC60950-1 | |
| | | AS/NZS CISPR. 22 | Klasse A |
| | Japan | J60950-1 | VCCI Klasse A |
| | Asien | IEC60950-1 | CISPR. 22 |


(Hinweis) Dieses ist der Anschluß für zukünftige Expansionen.

* Beachten Sie, dass Änderungen der technischen Daten und des Designs jederzeit vorbehalten sind.

6-7. Pin Assignment and Functions of Terminal

6-7-1. PC CONTROL connector (D-Sub 9 pin)

This is an RS-232C interface for controlling the projector head from a PC. The projector operates as a DCE (Data Communication Equipment), so use a straight cable when connecting to a PC.




| Pin No. | RS-232C Signal Name | Functions as RS-232C | Projector Connector Operation |
|---------|---------------------|------------------------------|--|
| 1 | CD | Carrier detection | Not used (N.C.) |
| 2 | RXD | Reception data | Data transmission to an external device |
| 3 | TXD | Transmission data | Data reception from an external device |
| 4 | DTR | Data Terminal ready (Note 1) | Connection to 6 pins |
| 5 | GND | Signal GND | Signal GND |
| 6 | DSR | Data set ready (Note 1) | Connection to 4 pins |
| 7 | RTS | Transmission request | SYSTEM (Note 2): Hi-Z (Not used) CINEMA (Note 2): Hi-Z (Used) |
| 8 | CTS | Transmission available | SYSTEM (Note 2): Fixed at -6.5 V (Not used) CINEMA (Note 2): ± 10.5 V (Used: Depends on communication status) |
| 9 | RI | Ring indicator | Not used (N.C.) |

Note 1: Do not use DTR and DSR signals when communicating.

Note 2: Connector operations vary according to the PC control signal switch (CINEMA/SYSTEM). (When in SYSTEM, do not use RTS and CTS signals.)


Internal Configuration Diagram of RS-232C Communication System



6-7-2. Remote control input connector (REMOTE IN) (Stereo mini)

Connected with the projector's remote control the accessory remote cable.

When the remote cable is connected to this connector, the remote cable connector operates with the following functions.



The DC voltage supplied from the projector to the remote control is approximately +4.0 V.

NOTE The remote control cable is connected first to the remote control, then to the projector head. The leading end of the remote control cable is the power supply unit, so be careful not to touch the other end of the remote cable to the projector head or other devices while only the remote control cable is connected to the projector.


TIP Even if the remote cable power supply unit and GND unit (such as the projector head) should short, the protective function inside the projector will activate to prevent the shorted cable from damaging the projector.

6-7-3. LAN port (LAN-A, LAN-B) (RJ-45)

Use Ethernet 10Base-T/100Base-TX UTP (Unshielded Twist Pair cable) to connect with a video server or a PC.

A switching hub exists inside, so there are no functional differences of either the LAN-A or LAN-B ports.

Internal Configuration Diagram of LAN Port




6. Appendix

6-7-4. External control connector (GP I/O) (D-Sub 37 pin)

It is possible to control the projector with an external device and to control the external device from the projector using an external control connector (GP I/O: General Purpose I/O Ports). Each pin is electrically separated from the projector internal circuits by a photo-coupler. 8 port input and 8 port output are available.


Please contact your dealer/distributor regarding how to use and to operate them.



Pin view of female connector

| Pin No. | Signal Name | I/O | Pin No. | Signal Name | I/O |
|---------|-----------------|--------|---------|-----------------|--------|
| 1 | Ext_GPIN_1_P | Input | 20 | Ext_GPIN_1_N | Input |
| 2 | Ext_GPIN_2_P | Input | 21 | Ext_GPIN_2_N | Input |
| 3 | Ext_GPIN_3_P | Input | 22 | Ext_GPIN_3_N | Input |
| 4 | Ext_GPIN_4_P | Input | 23 | Ext_GPIN_4_N | Input |
| 5 | Ext_GPIN_5_P | Input | 24 | Ext_GPIN_5_N | Input |
| 6 | Ext_GPIN_6_P | Input | 25 | Ext_GPIN_6_N | Input |
| 7 | Ext_GPIN_7_P | Input | 26 | Ext_GPIN_7_N | Input |
| 8 | Ext_GPIN_8_P | Input | 27 | Ext_GPIN_8_N | Input |
| 9 | Ext_GPOUT_1_P | Output | 28 | Ext_GPOUT_1_N | Output |
| 10 | Ext_GPOUT_2_P | Output | 29 | Ext_GPOUT_2_N | Output |
| 11 | Ext_GPOUT_3_P | Output | 30 | Ext_GPOUT_3_N | Output |
| 12 | Ext_GPOUT_4_P | Output | 31 | Ext_GPOUT_4_N | Output |
| 13 | Ext_GPOUT_5_P | Output | 32 | Ext_GPOUT_5_N | Output |
| 14 | Ext_GPOUT_6_P | Output | 33 | Ext_GPOUT_6_N | Output |
| 15 | Ext_GPOUT_7_P | Output | 34 | Ext_GPOUT_7_N | Output |
| 16 | Ext_PROJ_GOOD_P | Output | 35 | Ext_PROJ_GOOD_N | Output |
| 17 | NC | - | 36 | NC | - |
| 18 | Reserve | - | 37 | Reserve | - |
| 19 | Reserve | - | - | - | - |

Input Connector




• Use with External Control Mode

You can use the GP I/O input port to turn the projector power on and off, to control video mute and to switch signals (switching the input connector and image adjusting data).

| Pin No. | Photo-coupler ON / OFF | | | Function |
|---------|------------------------|------|------|---|
| 1-20 | OFF | | | External control mode OFF |
| | ON | | | External control mode ON |
| 2-21 | OFF | | | Power off |
| | ON | | | Power on |
| 3-22 | OFF | | | Image mute off |
| | ON | | | Image mute on |
| 4-23 | 6-25 | 5-24 | 4-23 | The following functions are used, depending on the combination of the input connectors. |
| 5-24 | OFF | OFF | OFF | Selects title registered to MACRO 1. |
| 6-25 | OFF | OFF | ON | Selects title registered to MACRO 2. |
| | OFF | ON | OFF | Selects title registered to MACRO 3. |
| | OFF | ON | ON | Selects title registered to MACRO 4. |
| | ON | OFF | OFF | Selects title registered to MACRO 5. |
| | ON | OFF | ON | Selects title registered to MACRO 6. |
| | ON | ON | OFF | Selects title registered to MACRO 7. |
| 7-26 | - | - | - | Used internally. |
| 8-27 | - | - | - | Used internally. |

NOTE When in use in the External Control Mode, it is not possible to turn the power on and off from the remote control, operation panel or menus, to mute the video, or to switch titles.

Output Connector




6. Appendix

6-7-5. SDI-A, SDI-B (HD-SDI input connector) (BNC)

This is a signal input connector (SMPTE 292/HDSDI) for CINEMA.


The SMPTE 292/HD-SDI transfers HDTV signals with 1.5 GHz digital serial signals, so use a 75 Ω coaxial cable having a thickness and characteristics higher than 5C-FB, and use a BNC for the connector.



6-7-6. DVI-A, DVI-B (DVI digital Input connector) (DVI-D 24 pin)

This is a single link DVI input connector that is compliant with hot plug detect (HPD). Use a single link cable. Noise may be generated in the video if you use a dual link cable.

EDID is available even when the projector is switched off.



Pin view of female connector

| Pin No. | Signal Name | Pin No. | Signal Name |
|---------|--------------------|---------|--------------------|
| 1 | TMDS Data 2- | 13 | unused |
| 2 | TMDS Data 2+ | 14 | +5V Power |
| 3 | TMDS Data 2 Shield | 15 | Ground |
| 4 | Unused | 16 | Hot Plug Detect* |
| 5 | Unused | 17 | TMDS Data 0- |
| 6 | DDC Clock | 18 | TMDS Data 0+ |
| 7 | DDC Data | 19 | TMDS Data 0 Shield |
| 8 | Unused | 20 | unused |
| 9 | TMDS Data 1- | 21 | unused |
| 10 | TMDS Data 1+ | 22 | TMDS Clock Shield |
| 11 | TMDS Data 1 Shield | 23 | TMDS Clock+ |
| 12 | Unused | 24 | TMDS Clock- |

6-8. Related products list

| Product name | | Model name |
|--|----------------------------------|------------|
| Lens | Zoom Lens 1.45 to 1.8:1 | L2K-14ZM |
| | Zoom Lens 1.8 to 2.4:1 | L2K-18ZM |
| | Zoom Lens 2.2 to 3.0:1 | L2K-22ZM |
| | Zoom Lens 3.0 to 4.3:1 | L2K-30ZM |
| Anamorphic lens | Anamorphic lens 1.25 | AL 1.25 |
| Anamorphic lens manually operated turret | Anamorphic turret | AS 1.25 |
| Lamp house module (excluding lamp) | Lamp house module | IS8LH-E |
| Lamp | Lamp | IS8LP4-E |
| Wireless LAN card | Wireless LAN Card NWL-100 Series | (Note) |

(Note) Please contact your dealer/distributor for details on product and model names .

(MEMO)

