



SAMSUNG

PDP-TELEVISION (PLASMA DISPLAY PANEL)

Owner's Instructions

Before operating the unit,
please read this manual thoroughly,
and retain it for future reference.

ON-SCREEN MENUS
Picture In Picture (PIP)
Energy Saving

TELETEXT (Option)



SRS TruSurround XT



Digital Natural Image engine

Register your product at www.samsung.com/global/register
Record your Model and Serial number here for future reference.

▪ Model _____ ▪ Serial No. _____

User Instructions

◆ Screen Image retention

Do not display a still image (such as on a video game or when hooking up a PC to this PDP) on the plasma monitor panel for more than 2 hours as it can cause screen image retention. This image retention is also known as "screen burn". To avoid such image retention, reduce the degree of brightness and contrast of the screen when displaying a still image.

◆ Height

The PDP can normally operate only under 2000m in height. It might abnormally function at a place over 2000m in height so do not install and operate there.

◆ Heat on the top of the PDP TV

The top side of the product may be hot after long period of use as heat dissipates from the panel through the vent hole in the upper part of the product. This is normal and does not indicate any defect or operation failure of the product. However, children should be prevented from touching the upper part of the product.

◆ The product is making a 'cracking' noise.

A 'cracking' noise may occur when the product contracts or expands due to a change of surrounding environment such as temperature or humidity. This is normal and not a defect of the unit.

◆ Cell Defects

The PDP uses a panel consisting of 1,230,000(SD-level) to 3,150,000(HD-level) pixels which require sophisticated technology to produce. However, there may be few bright or dark pixels on the screen. These pixels will have no impact on the performance of the product.

◆ Avoid operating the TV at temperatures below 5°C(41°F)

◆ A still image displayed too long may cause permanent damage to the PDP Panel.



Watching the PDP TV in 4:3 format for a long period of time may leave traces of borders displayed on the left, right and centre of the screen caused by the difference of light emission on the screen. Playing a DVD or a game console may cause similar effect to the screen. Damages caused by the above effect are not covered by the Warranty.

◆ Afterimage on the Screen.

Displaying still images from Video games and PC for longer than a certain period of time may produce partial afterimages. To prevent this effect, reduce the 'brightness' and 'contrast' when displaying still images.

◆ Warranty

- Warranty does not cover any damage caused by image retention.
- Burn-in is not covered by the warranty.

◆ Installation

Be sure to contact an authorized service centre, when installing your set in a location with heavy dust, high or low temperatures, high humidity, chemical substance and where it operates continually such as the airport, the train station etc. Failure to do so may cause a serious damage to your set.

Contents

General Information

- ◆ User Instructions 2
- ◆ Checking Parts 4
- ◆ Using the Stand-Base 4
- ◆ Control Panel 5
- ◆ Connection Panel 6
- ◆ Viewing the Remote Control
(depending on the model) 8

Operation

- ◆ Switching Your Television On and Off 9
- ◆ Viewing the Menus 10
- ◆ Freezing the Current Picture 10
- ◆ Plug & Play Feature 10
- ◆ Viewing an External Signal Sources 12
- ◆ Editing Device Names 12

Channel Control

- ◆ Storing Channels Automatically 13
- ◆ Sorting the Stored Channels 13
- ◆ Storing Channels Manually 14
- ◆ Adding / Locking Channels 15
- ◆ Assigning Names to Channels 16
- ◆ Fine Tuning Channel Reception 16

Picture Control

- ◆ Changing the Picture Standard 17
- ◆ Customizing the Picture Settings 17
- ◆ Configuring Detailed Settings on the Picture .. 18
- ◆ Selecting the Picture Size 19
- ◆ Digital NR / Active Colour / DNle 20

Sound Control

- ◆ Sound Features 20
- ◆ Selecting the Sound Mode
(depending on the model) 22

Function Description

- ◆ Time Features 23
- ◆ Language / Blue Screen / Melody /
Light Effect / Energy Saving /
HDMI Black Level 24
- ◆ Using Game Mode 25
- ◆ Screen Burn Protection 26
- ◆ Wall- mount adjustment (Sold separately) ... 27
- ◆ Viewing the Picture in Picture (PIP) 28

PC Display

- ◆ Setting up Your PC Software
(Based on Windows XP) 29
- ◆ Input Mode (PC) 30
- ◆ Setting the PC 31
- ◆ Setting the Home Theatre PC 32

Appendix

- ◆ Teletext Feature (depending on the model) .. 33
- ◆ Wall Mount Kit Specifications (VESA) 35
- ◆ How to assemble the Stand-Base
(depending on the model) 36
- ◆ Troubleshooting 37
- ◆ Specifications 38

Symbols



Press




Important




Note


Checking Parts



Vendu séparément




- **Ferrite Core (Power Cord, Side-Video Cable, Headphones Cable, S-Video Cable)**
The ferrite core is used to shield the cable from interference. When connecting a cable, open the ferrite core and clip it around the cable.




Using the Stand-Base

-
- ◆ Two or more people should carry the PDP. Never lay the PDP on the floor because of possible damage to the screen. Always keep the PDP upright.
 - ◆ The PDP can rotate 20 degrees in right and left directions.



Control Panel

Front (or Side) Panel



➤ The product colour and shape may vary depending on the model.

1 SOURCE

Displays a menu of all of the available input sources (TV, AV1, AV2, S-Video, Component1, Component2, PC, HDMI1, and HDMI2).

2 MENU

Press to see the on-screen menu of your TV's features.

3 + VOL -

Press to increase or decrease the volume. In the on-screen menu, use the + VOL - buttons as you use the ◀ and ▶ buttons on the remote control.

4 ^ CH v

Press to change channels. In the on-screen menu, use the ^ CH v buttons as you use the ▲ and ▼ buttons on the remote control.

5 ENTER

Press to confirm a selection.

6 Power button

Press to turn the TV on and off.

Power Indicator

- Power Off: Blue
- Power On: Off


Remote Control Sensor

Aim the remote control towards this spot on the TV.

7 Speaker

Connection Panel

Side Panel



➤ The product colour and shape may vary depending on the model.

- ◆ Whenever you connect an audio or video system to your set, ensure that all elements are switched off.
- ◆ When connecting an external device, match the colour of the connection terminal to the cable.

1 AV IN 2 (S-VIDEO or VIDEO / AUDIO L/R)

Video (S-Video or Video) and audio inputs for external devices, such as a camcorder or VCR.


2 Headphones jack

You can connect a set of headphones if you wish to watch a television programme without disturbing the other people in the room.

➤ Prolonged use of headphones at a high volume may damage your hearing.

Continued...

Rear Panel



➤ The product colour and shape may vary depending on the model.

- ◆ Whenever you connect an audio or video system to your set, ensure that all elements are switched off.
- ◆ When connecting an external device, match the colour of the connection terminal to the cable.

- 1 ANT IN**
75Ω Coaxial connector for Aerial/Cable Network.
- 2 HDMI IN 1**
Connect to the HDMI jack of a device with HDMI output.
- 3 PC IN / AUDIO**
Connect to the video and audio output jack on your PC.
- 4 SERVICE**
Connector for service only.
- 5 COMPONENT IN 1, COMPONENT IN 2**
Video (Y/P_B/P_R) and audio (AUDIO L/R) inputs for Component.
- 6 AV IN 1 (VIDEO/AUDIO R/L)**
Connect RCA cable to an appropriate external A/V device such as VCR, DVD or Camcorder.
- 7 AUDIO OUT (AUDIO R/L)**
Connect RCA audio signals from the TV to an external source, such as Audio equipment.
- 8 HDMI IN 2**
- Connect to the HDMI jack of a device with HDMI output. These inputs can also be used as a DVI connection with separate analog audio inputs.

An optional HDMI/DVI cable will be necessary to make this connection. When using the optional HDMI/DVI adapter, the DVI analog audio inputs on your TV allow you to receive left and right audio from your DVI device. (Not compatible with PC)

- When connecting this product via HDMI or DVI to a Set Top Box, DVD Player or Games Console etc, make sure that it has been set to a compatible video output mode as shown in the table below. Failure to observe this may result in picture distortion, image breakup or no picture.
- Do not attempt to connect the HDMI/DVI connector to a PC or Laptop Graphics Card. (This will result in a blank screen being displayed)

DVI IN (HDMI 2) AUDIO L/R

DVI audio outputs for external devices.

9 POWER IN

Connect the supplied power cord.

Supported modes for HDMI/DVI and Component

	480i	480p	576i	576p	720p	1080i
HDMI/DVI 50Hz	X	X	X	O	O	O
HDMI/DVI 60Hz	X	O	X	X	O	O
Component	O	O	O	O	O	O

Viewing the Remote Control (depending on the model)

- ◆ This is a special remote control for the visually impaired persons, and has Braille points on the POWER, Volume and Channel buttons.
- ◆ The performance of the remote control may be affected by bright light.


- 1 POWER button (turns the TV on and off)
- 2 Number buttons for direct channel access
- 3 One/Two-digit channel selection
- 4 Channel control button (Refer to page 15)
- 5 Selects the TV mode directly
- 6 ⊕ :Volume increase
⊖ :Volume decrease
- 7 Displays the main on-screen menu
- 8 Temporary sound switch-off
- 9 Use to see information on the current broadcast
- 10 Returns to the previous menu
- 11 Sound effect selection (Refer to page 21)
- 12 Picture effect selection (Refer to page 17)
- 13 Adjusts screen brightness to save energy.
- 14 Sound mode selection
- 15 Picture-In-Picture Off/On
- 16 TruSurround XT mode button
- 17 Available source selection
- 18 Previous channel
- 19 Automatic Power-off
- 20 Selects the HDMI mode directly.
- 21 ⏪ :Next channel
⏩ :Previous channel
- 22 Exit the on-screen menu
- 23 Change confirmation

- 24 Move to the required menu option / Adjust an option value respectively
- 26 Picture freeze
- 27 Picture size selection
- 29 Sub picture (PIP) channel selection
- 30 Sub picture (PIP) source selection
- 31 Sub picture (PIP) location selection

Teletext Functions

(Refer to page 33)


- 5 Exit from the teletext display (depending on the model)
- 7 Teletext index
- 9 Teletext reveal
- 15 Teletext hold
- 17 Teletext mode selection (LIST/FLOF)
- 18 Teletext sub page
- 21 P ⏪ :Teletext next page
P ⏩ :Teletext previous page
- 22 Teletext cancel
- 25 Teletext display/mix both teletext information and the normal broadcast
- 28 Fastext topic selection
- 30 Teletext store
- 31 Teletext size



Continued...

Installing Batteries in the Remote Control

- 1 Lift the cover at the back of the remote control upward as shown in the figure.
 - 2 Install two AAA size batteries.
 - ◆ Make sure to match the “+” and “-” ends of the batteries with the diagram inside the compartment.
 - ◆ Do not mix battery types, i.e. alkaline and manganese.
 - 3 Close the cover as shown in the figure.
 - Remove the batteries and store them in a cool and dry place if you won't be using the remote control for a long time. The remote control can be used up to about 23 feet from the TV. (Assuming typical TV usage, the batteries last for about one year.)
- If the remote control doesn't work! Check the following:
1. Is the TV power on?
 2. Are the plus and minus ends of the batteries reversed?
 3. Are the batteries drained?
 4. Is there a power cut, or is the power cord unplugged?
 5. Is there a special fluorescent light or a neon sign nearby?





Switching Your Television On and Off

The main lead is attached to the rear of the television.

- 1 Plug the main lead into an appropriate socket.
 - The main voltage is indicated on the rear of the television and the frequency is 50 or 60Hz.
- 2 Press the  (Power) button (On/Off) on the front of the television or press the **POWER** button on the remote control to switch the television on. The programme that you were watching last is re-selected automatically. If you have not yet stored any channels, no clear picture appears. Refer to “Storing Channels Automatically” on page 13 or “Storing Channels Manually” on page 14.
 - If the television is initially powered on, several basic customer settings proceed automatically. Refer to “Plug & Play Feature” on pages 10~11.
- 3 To switch the television off, press the  (Power) button (On/Off) on the front of the television or press the **POWER** button on the remote control.
- 4 To switch the TV on, press the  (Power) button on the front of the TV or press the **POWER** button or number buttons on the remote control.

Viewing the Menu


- 1 Press the **MENU** button.
The main menu is displayed on the screen.
Its left side has five icons: **Picture**, **Sound**, **Channel**, **Setup**, and **Input**.
- 2 Press the **▲** or **▼** button to select one of the icons.
Press the **ENTER** button to access the icon's sub-menu.
- 3 Press the **▲** or **▼** button to move to items in the menu.
Press the **ENTER** button to enter items in the menu.
- 4 Press the **▲/▼/◀/▶** button to change the selected items.
Press the **RETURN** button to return to the previous menu.
- 5 Press the **EXIT** button to exit from the menu.



Freezing the Current Picture

You can freeze the picture when watching a television programme simply by pressing the "STILL" button. To return to normal viewing, press it again.

- To prevent screen burn-in, this function will automatically become inactive in 1 minutes.



Plug & Play Feature

When the television is initially powered on, several basic customer settings proceed automatically and subsequently. The following settings are available.

- 1 If the television is in standby mode, press the **POWER** button on the remote control. The message **Start Plug & Play** is displayed. Press the **ENTER** button. **Language** menu is displayed.
 - If any language is not selected on the **Language** menu, the **Language** menu will disappear about 30 seconds later.
- 2 Select the appropriate language by pressing the **▲** or **▼** button. Press the **ENTER** button to confirm your choice. The message **Select Home Mode when installing this TV at home.** is displayed.



Continued...

- Press the ◀ or ▶ button to select **Shop** or **Home**, then press the **ENTER** button. The message to check the connected status of the antenna is displayed.

- ◆ The default selection is Home.
- ◆ We recommend setting the TV to Home mode for the best picture in your home environment.
- ◆ **Shop** mode is only intended for use in retail environments.
- ◆ - Shop mode activation: When the Shop mode is not active, press the **MENU** button on the TV panel for 5 seconds to activate the Shop mode.
- Shop mode deactivation: While the Shop mode is active and the volume bar is displayed, press the **MENU** button on the TV panel for 5 seconds to deactivate the Shop mode.

- Make sure that the antenna is connected to the TV. Press the **ENTER** button. **Area** menu is displayed.

- Select your country or area by pressing the ▲ or ▼ button, then press the **ENTER** button. **Auto Store** menu is displayed.

- Press the **ENTER** button to start search the channels. The channel search will start and end automatically. After all the available channels are stored, **Clock Set** menu is displayed.

- To stop the search before it has finished, press the **ENTER** button with **Stop** selected.



- Press the ◀ or ▶ button to select **Month**, **Day**, **Year**, **Hour**, **Minute** or **am/pm**. Set these by pressing the ▲ or ▼ button. Set these by pressing the ▲ or ▼ button.

- You can set the **Month**, **Day**, **Year**, **Hour**, or **Minute** directly by pressing the numeric buttons on the remote control.

- Press the **ENTER** button to confirm your setting. The message **Enjoy your viewing** is displayed.

- Even if the **ENTER** button is not pressed, the message will automatically disappear after several seconds.

- **Plug & Play** feature is available in the **TV** mode only.



If you want to reset this feature ...

- Press the **MENU** button to display the menu.
- Press the ▲ or ▼ button to select **Setup**, then press the **ENTER** button.
- Press the **ENTER** button again to select **Plug & Play**. The message **Start Plug & Play** is displayed.



Viewing an External Signal Sources




You can switch between viewing signals from connected equipment, such as a VCR, DVD, Set-Top Box, and the TV source (broadcast or cable).

- 1 Press the **MENU** button to display the menu.
- 2 Press the **▲** or **▼** button to select **Input**, then press the **ENTER** button.
- 3 Press the **ENTER** button again to select **Source List**.
- 4 Press the **▲** or **▼** button to select the signal source, then press the **ENTER** button.

Available signal sources: **TV, AV1, AV2, S-Video, Component1, Component2, PC, HDMI1, HDMI2**

➤ Only the connected devices can be selected.

- You can select these options simply by pressing the **SOURCE** button on the remote control.
- To watch television programme again, press the **TV** button and select the channel number required.
- Press the **INFO** button on the remote control to see the current input source.



Editing Device Names


You can give a name to the external source.

- 1 Press the **MENU** button to display the menu.
- 2 Press the **▲** or **▼** button to select **Input**, then press the **ENTER** button.
- 3 Press the **▲** or **▼** button to select **Edit Name**, then press the **ENTER** button.
- 4 Press the **▲** or **▼** button to select the external source to be edited, then press the **ENTER** button.
- 5 Select the required device by pressing **▲** or **▼**, then press the **ENTER** button.

Available device names: **VCR, DVD, D-VHS, Cable STB, HD STB, Satellite STB, AV Receiver, DVD Receiver, Game, Camcorder, DVD Combo, DHR (DVD HDD Recorder), PC.**

- 6 Press the **EXIT** button to exit.

- When a PC with a resolution of 640 x 480@60Hz is connected to the HDMI IN 1 port, you should set the HDMI1 mode to PC in the **Source List** of **Input** mode. If the HDMI1 mode is not PC, it may work depending on the TV setting.



Storing Channels Automatically

You can scan for the frequency ranges available to you (availability depends on your country).

Automatically allocated programme numbers may not correspond to actual or desired programme numbers. However you can sort numbers manually and clear any channels you do not wish to watch.

- 1 Press the **MENU** button to display the menu.
- 2 Press the **▲** or **▼** button to select **Channel**, then press the **ENTER** button.
- 3 Press the **ENTER** button to select **Area**.
- 4 Select your country or area by pressing the **▲** or **▼** button, then press the **ENTER** button.
- 5 Press the **▲** or **▼** button to select **Auto Store**, then press the **ENTER** button.
- 6 Press the **ENTER** button again to start the search.
The search will end automatically.
➤ To stop the search before it has finished, press the **RETURN** or the **ENTER** button.




Sorting the Stored Channels

This operation allows you to change the programme numbers of the stored channels.

This operation may be necessary after using the auto store.

- 1 Press the **MENU** button to display the menu.
- 2 Press the **▲** or **▼** button to select **Channel**, then press the **ENTER** button.
- 3 Press the **▲** or **▼** button to select **Sort**, then press the **ENTER** button.
- 4 Select the channel that you wish to move by pressing the **▲** or **▼** button, then press the **ENTER** button.
- 5 Select the number of the programme to which the channel is to be moved by pressing the **▲** or **▼** button. Press the **ENTER** button. The channel is moved to its new position and all other channels are shifted accordingly.
- 6 Repeat steps 4 to 5 until you have moved all the channels to the required programme numbers.
- 7 Press the **EXIT** button to exit.




Storing Channels Manually

You can store television channels, including those received via cable networks.

When storing channels manually, you can choose:

- ◆ Whether or not to store each of the channels found.
 - ◆ The programme number of each stored channel which you wish to identify.
- 1 Press the **MENU** button to display the menu.
 - 2 Press the **▲** or **▼** button to select **Channel**, then press the **ENTER** button.
 - 3 Press the **▲** or **▼** button to select **Manual Store**, then press the **ENTER** button.
 - 4 Select the required option by pressing the **▲** or **▼** button, then press the **ENTER** button.
 - 5 When you are satisfied with your setting, press the **ENTER** button.
 - 6 Press the **EXIT** button to exit.
- ◆ **Programme** (Programme number to be assigned to a channel)
 - Press the **▲** or **▼** button until you find the correct number.
 - You can also select the channel number directly by pressing the numeric buttons (0~9) on the remote control.
 - ◆ **Colour System: Auto/PAL/SECAM/NTSC4.43/NTSC3.58**
 - Press the **▲** or **▼** button to select the required colour standard.
 - ◆ **Sound System: BG/DK/I/M**
 - Press the **▲** or **▼** button to select the required sound standard.
 - ◆ **Channel** (When you know the number of the channel to be stored)
 - Press the **▲** or **▼** button to select **C** (Air channel) or **S** (Cable channel).
 - Press the **▶** button, then press the **▲** or **▼** button to select the required number.
 - You can also select the channel number directly by pressing the numeric buttons (0~9) on the remote control.
 - If there is abnormal sound or no sound, re-select the sound standard required.
 - ◆ **Search** (When you do not know the channel numbers)
 - Press the **▲** or **▼** button to start the search.
 - The tuner scans the frequency range until the first channel or the channel that you selected is received on the screen.
 - ◆ **Store** (When you store the channel and associated programme number)
 - Set to **OK** by pressing the **ENTER** button.
- Channel mode**
- ◆ **P** (Programme mode): When completing tuning, the broadcasting stations in your area have been assigned to position numbers from P00 to P99. You can select a channel by entering the position number in this mode.
 - ◆ **C** (Air channel mode): You can select a channel by entering the assigned number to each air broadcasting station in this mode.
 - ◆ **S** (Cable channel mode): You can select a channel by entering the assigned number for each cable channel in this mode.



Adding / Locking Channels

Using the Channel Manager, you can conveniently lock or add channels.

- 1 Press the **MENU** button to display the menu.
- 2 Press the **▲** or **▼** button to select **Channel**, then press the **ENTER** button.
- 3 Press the **▲** or **▼** button to select **Channel Manager**, then press the **ENTER** button.

◆ Adding channels

Using the **Channel List**, you can add channels.


- 4 Press the **ENTER** button again to select **Channel List**.
- 5 Move to the (⊞) field by pressing the **▲/▼/◀/▶** buttons, select a channel to be added, and press the **ENTER** button to add the channel.
 - If you press the **ENTER** button again, the (✓) symbol next to the channel disappears and the channel is not added.

◆ Locking channels

This feature allows you to prevent unauthorized users, such as children, from watching unsuitable programmes by muting out video and audio.

- 6 Press the **▲** or **▼** button to select **Child Lock**, then press the **ENTER** button.
- 7 Select **On** by pressing the **▲** or **▼** buttons, then press the **ENTER** button.
- 8 Press the **▲** or **▼** button to select **Channel List**, then press the **ENTER** button.
- 9 Move to the (🔒) field by pressing the **▲/▼/◀/▶** buttons, select a channel to be locked, and press the **ENTER** button.
 - If you press the **ENTER** button again, the (✓) symbol next to the channel disappears and the channel lock is canceled.
 - A blue screen is displayed when **Child Lock** is activated.
- 10 Press the **EXIT** button to exit.

- You can select these options simply by pressing the **CH LIST** button on the remote control.



Assigning Names to Channels

Channel names will be assigned automatically when channel information is broadcast. These names can be changed, allowing you to assign new names.

- 1 Press the **MENU** button to display the menu.
- 2 Press the **▲** or **▼** button to select **Channel**, then press the **ENTER** button.
- 3 Press the **▲** or **▼** button to select **Name**, then press the **ENTER** button.
- 4 Press the **▲** or **▼** button to select the channel to be assigned to a new name, then press the **ENTER** button.
- 5 Press the **▲** or **▼** button to select a letter, a number, or a symbol (Results in this sequence: A~Z, 0~9, +, -, *, /, blank). Move on to the previous or next letter by pressing the **◀** or **▶** button, then press the **ENTER** button.
- 6 Repeat steps 4 to 5 for each channel to be assigned to a new name.
- 7 Press the **EXIT** button to exit.






Fine Tuning Channel Reception

If the reception is clear, you do not have to fine tune the channel, as this is done automatically during the search and store operation.

If the signal is weak or distorted, you may have to fine tune the channel manually.

- 1 Press the **MENU** button to display the menu.
- 2 Press the **▲** or **▼** button to select **Channel**, then press the **ENTER** button.
- 3 Press the **▲** or **▼** button to select **Fine Tune**, then press the **ENTER** button.
- 4 To obtain a sharp, and clear picture and good sound quality, press the **◀** or **▶** button until you reach the optimal setting. Press the **ENTER** button.
 - To reset the fine tuning to 0, select **Reset** by pressing the **▲** or **▼** button. Press the **ENTER** button.
- 5 Press the **EXIT** button to exit.
 - Press the **INFO** button. Fine Tune Store will change the colour of the Channel OSD (On Screen Display) from white to red and add the "*" mark.






Changing the Picture Standard

You can select the type of picture which best corresponds to your viewing requirements.

- 1 Press the **MENU** button to display the menu.
- 2 Press the **ENTER** button to select **Picture**.
- 3 Press the **ENTER** button again to select **Mode**.
- 4 Select the required mode by pressing the **▲** or **▼** button, then press the **ENTER** button.

Available modes: **Dynamic**, **Standard**, **Movie**

- The settings values may vary depending on the input source. (ex. RF, Video, Component, PC, or HDMI)
- 5 Press the **EXIT** button to exit.
 - **◆** Choose **Dynamic** for viewing the TV during the day or when there is bright light in the room.
 - ◆** Choose **Standard** for general TV watching mode.
 - ◆** Choose **Movie** when viewing the movie.
- You can select these options simply by pressing the **P.MODE** button on the remote control.



Customizing the Picture Settings

Your television has several setting options that allow you to control the picture quality.

- 1 Press the **MENU** button to display the menu.
- 2 Press the **ENTER** button to select **Picture**.
- 3 Press the **ENTER** button again to select **Mode**.
- 4 Select the required mode by pressing the **▲** or **▼** button, then press the **ENTER** button.

Available modes: **Dynamic**, **Standard**, **Movie**

- 5 Select the required option by pressing the **▲** or **▼** button, then press the **ENTER** button.
- 6 When you are satisfied with your setting, press the **ENTER** button.
- 7 Press the **EXIT** button to exit.

◆ Contrast – Brightness – Sharpness – Colour – Tint

➤ In TV, AV, S-Video modes of the PAL system, you cannot use the Tint function.

Contrast – Brightness – Colour Tone: PC Mode
Press the **◀** or **▶** button until you reach the optimal setting.



◆ Colour Tone: Cool2/Cool1/Normal/Warm1/Warm2

➤ When the picture mode is set to **Dynamic** or **Standard**, **Warm1** and **Warm2** cannot be selected.

◆ Reset: OK/Cancel

Select **OK**. You can return to the factory defaults picture settings.

➤ The reset function is set for each picture mode and colour tone.



Configuring Detailed Settings on the Picture

You can set detailed picture settings.

- 1 Press the **MENU** button to display the menu.
- 2 Press the **ENTER** button to select **Picture**.
- 3 Press the **▲** or **▼** button to select **Detailed Settings**, then press the **ENTER** button.
- 4 Select the required option by pressing the **▲** or **▼** button, then press the **ENTER** button.

Available options: **Black Adjust**, **Dynamic Contrast**, **Gamma**, **Colour Space**, **White Balance**, **My Colour Control**, **Edge Enhancement**.

- 5 When you are satisfied with your setting, press the **ENTER** button.
 - 6 Press the **EXIT** button to exit.
- When the picture mode is set to **Standard** or **Movie**, **Detailed Settings** can be selected.

- If DNLe is Off, the Detailed Settings cannot be selected when the Picture mode is in Standard mode.

◆ **Black Adjust: Off/Low/Medium/High**

You can directly select the black level on the screen to adjust the screen depth.

◆ **Dynamic Contrast: Off/Low/Medium/High**

You can adjust the screen contrast so that the optimal contrast is provided.

◆ **Gamma: -3 ~ +3**

You can adjust the middle brightness of pictures.

Press the **◀** or **▶** button until you reach the optimal setting.

◆ **Colour Space: Auto/Wide**

You can set the colour reproduction space for the input signal to **Auto** or **Wide**.

◆ **White Balance: R-Offset/G-Offset/B-Offset/R-Gain/G-Gain/B-Gain/Reset**

You can adjust the colour temperature for more natural picture colours.

- **R-Offset/G-Offset/B-Offset/R-Gain/G-Gain/B-Gain:**

Changing the adjustment value will refresh the adjusted screen.

Select the required option by pressing the **▲** or **▼** button, then press the **ENTER** button.

Press the **◀** or **▶** button until you reach the optimal setting.

- **Reset:** The previously adjusted white balance will be reset to the factory defaults.

◆ **My Colour Control: Pink/Green/Blue/White/Reset**

This setting can be adjusted to suit your personal preferences.

- **Pink/Green/Blue/White:** Changing the adjustment value will refresh the adjusted screen.

Select the required option by pressing the **▲** or **▼** button, then press the **ENTER** button.


Press the **◀** or **▶** button until you reach the optimal setting.

- When running the **My Colour Control** feature, the current picture is captured as a still image before being displayed on the screen.

- **Reset:** The previously adjusted colours will be reset to the factory defaults.

◆ **Edge Enhancement: Off/On**

You can emphasize object boundaries.



Selecting the Picture Size

You can select the picture size which best corresponds to your viewing requirements.



- 1 Press the **MENU** button to display the menu.
- 2 Press the **ENTER** button to select **Picture**.
- 3 Press the **▲** or **▼** button to select **Size**, then press the **ENTER** button.
- 4 Select the required option by pressing the **▲** or **▼** button, then press the **ENTER** button.

Available options: **16 : 9**, **Wide Zoom**, **Zoom**, **4:3**, **Just Scan**

- ◆ **16 : 9**: Sets the picture to 16:9 wide mode.
- ◆ **Wide Zoom**: Magnify the size of the picture more than 4:3. Move the screen up/down using the **▲** or **▼** button after selecting the  by pressing the **▶** or **ENTER** button.
 - Wide Zoom function is available only in TV, AV1, AV2, and S-Video mode.
- ◆ **Zoom**: Magnify the size of the picture vertically on screen.
- ◆ **4 : 3**: Sets the picture to 4 : 3 normal mode.
- ◆ **Just Scan**: Use this function to see the full image without any truncation when HDMI(720p, 1080i) signals are input.
 - With the HDMI Just Scan picture size, depending on the AV devices, the screen may be cut off or a specific appears on the screen.

- 5 Press the **EXIT** button to exit.

- You can change the picture size simply by pressing the **P.SIZE** button on the remote control.
- Depending on the input source, the picture size options may vary.
- The items available may differ depending on the selected mode.




Positioning and Sizing the screen using Zoom

- ◆ Resizing the screen using the **Zoom** enables the positioning and sizing of the screen to up/down direction using the **▲** or **▼** button as well as the screen size.
- ◆ Move the screen up/down using the **▲** or **▼** button after selecting the  by pressing the **◀** or **▶** button.
- ◆ Resize the screen vertically using the **▲** or **▼** button after selecting the  by pressing the **◀** or **▶** button.

Digital NR / Active Colour / DNle

- 1 Press the **MENU** button to display the menu.
- 2 Press the **ENTER** button to select **Picture**.
- 3 Select the required option by pressing the **▲** or **▼** button, then press the **ENTER** button.
Available options: **Digital NR**, **Active Colour**, **DNle**
- 4 When you are satisfied with your setting, press the **ENTER** button.
- 5 Press the **EXIT** button to exit.



◆ **Digital NR: Off/Low/Medium/High/Auto**

If the signal received by the television is weak, you can activate this feature to reduce any static and ghosting that may appear on the screen.

◆ **Active Colour: Off/On**

If you turn on this option, the colours of the sky and grass will be stronger and clearer for a more vivid on-screen picture.

- This function is not available in **PC** mode.
- This function is available in **Dynamic** mode.

◆ **DNle: Off/Demo/On**

This TV includes the DNle function so as to provide a high visual quality. If you set DNle to on, you can view the screen with the DNle feature activated. If you set the DNle to Demo, you can view the applied DNle and normal pictures on the screen, for demonstration purposes. Using this function, you can view the difference in the visual quality.


➤ **DNle™ (Digital Natural Image engine) DNle**

This feature brings you more detailed image with 3D noise reduction, detail enhancement, contrast enhancement and white enhancement. New image compensation Algorithm gives brighter, clearer, more detailed image to you. DNle™ technology will fit every signal into your eyes.


- This function is not available in **PC** mode.
- When the picture mode is set to **Movie**, **DNle** cannot be selected.

Sound Features

- 1 Press the **MENU** button to display the menu.
- 2 Press the **▲** or **▼** button to select **Sound**, then press the **ENTER** button.
- 3 Select the required option by pressing the **▲** or **▼** button, then press the **ENTER** button.
Available options: **Mode**, **Equalizer**, **SRS TS XT**, **Auto Volume**, **Internal Mute**, **Sound Select**, **Reset** (If Game Mode is On)
- 4 When you are satisfied with your setting, press the **ENTER** button.
- 5 Press the **EXIT** button to exit.



< If Game Mode is On >




Continued...

◆ **Mode: Standard/Music/Movie/Speech/Custom**

You can select the type of special sound effect to be used when watching a given broadcast.


- ◆ Choose **Standard** for the TV standard factory settings.
 - ◆ Choose **Music** when watching the music videos or concerts.
 - ◆ Choose **Movie** when watching movies.
 - ◆ Choose **Speech** when watching a show that is mostly dialog(i.e., news).
 - ◆ Choose **Custom** to recall your personalized settings.
- You can select these options simply by pressing the **S.MODE** button on the remote control.



◆ **Equalizer: Balance/100Hz/300Hz/1KHz/3KHz/10KHz**

The television has several settings which allow you to control the sound quality.


- ◆ **L/R Sound Balance Adjustment:**
To adjust the sound balance of the L/R speakers.
 - ◆ **Bandwidth Adjustment(100Hz, 300Hz, 1KHz, 3KHz, 10KHz) :** To adjust the level of different bandwidth frequencies.
- If you make any changes to these settings, the sound standard is automatically switched to **Custom**.



◆ **SRS TS XT: Off/On**

TruSurround XT is a patented SRS technology that solves the problem of playing 5.1 multichannel content over two speakers. TruSurround delivers a compelling, virtual surround sound experience through any two-speaker playback system, including internal television speakers. It is fully compatible with all multichannel formats.

- TruSurround XT, SRS and  Symbol are trademarks of SRS Labs, Inc. TruSurround XT technology is incorporated under license from SRS Labs, Inc.
- You can select these options simply by pressing the **SRS** button on the remote control.



◆ **Auto Volume: Off/On**

Each broadcasting station has its own signal conditions, and so it is not easy to adjust the volume every time the channel is changed. This feature lets you automatically adjust the volume of the desired channel by lowering the sound output when the modulation signal is high or by raising the sound output when the modulation signal is low.

◆ **Internal Mute: Off/On**

If you want to hear the sound through separate speakers, cancel the internal amplifier.

- The **VOL +**, **VOL -**, **S.MODE** and **MUTE** buttons do not operate when the Internal Mute is set to On.

◆ **Sound Select: Main/Sub**

When the PIP feature is activated, you can listen to the sound of the sub (PIP) picture.


- **Main:** Used to listen to the sound of the main picture.
- **Sub:** Used to listen to the sound of the sub picture.

◆ **Reset**

If **Game Mode** is On, the Reset Sound function is activated. Selecting the **Reset** function after setting the equalizer resets the equalizer setting to the factory defaults.

Selecting the Sound Mode (depending on the model)

The DUAL I-II button displays/controls the processing and output of the audio signal. When power is switched on, the mode is automatically preset to either “DUAL-I” or “Stereo”, depending on the current transmission.



	Type of broadcast	On-screen indication		
NICAM Stereo	Regular broadcast (Standard audio)	Mono (Normal use)		
	Regular + NICAM Mono	NICAM	↔	Mono (Normal)
	NICAM Stereo	NICAM Stereo	↔	Mono (Normal)
	NICAM DUAL-I/II	NICAM DUAL-1	→ NICAM DUAL-2 →	Mono (Normal)
A2 Stereo	Regular broadcast (Standard audio)	Mono (Normal use)		
	Bilingual or DUAL-I/II	DUAL-I	↔	DUAL-II
	Stereo	Stereo	↔	Mono (Forced mono)

- ◆ If the receiving conditions deteriorate, listening will be easier if the mode is set to **Mono**.
- ◆ If the stereo signal is weak and automatic switching occurs, switch to **Mono**.
- ◆ This function is activated in stereo sound signal. It is deactivated in mono sound signal.

Time Features

- 1 Press the **MENU** button to display the menu.
- 2 Press the **▲** or **▼** button to select **Setup**, then press the **ENTER** button.
- 3 Press the **▲** or **▼** button to select **Time**, then press the **ENTER** button.
- 4 Select the required option by pressing the **▲** or **▼** button, then press the **ENTER** button.
Available options: **Clock Set**, **Sleep Timer**, **Timer 1**, **Timer 2**, **Timer 3**
- 5 When you are satisfied with your setting, press the **ENTER** button.
- 6 Press the **EXIT** button to exit.

◆ Clock Set

You can set the television clock so that the current time is displayed when pressing the **INFO** button on the remote control. You must also set the time if you wish to use the automatic on or off timers.

- Press the **◀** or **▶** button to select **Month**, **Day**, **Year**, **Hour**, **Minute**, or **am/pm**.

Set these by pressing the **▲** or **▼** button.

- You can set the **Month**, **Day**, **Year**, **Hour**, and **Minute** directly by pressing the numeric buttons on the remote control.
- In the event of a power interruption or the set being turned off at the supply, the settings for the Clock will be lost.

◆ Sleep Timer

You can select a time period of between 30 and 180 minutes after which the television automatically switches to standby mode.

- Select the preset time interval (**Off**, **30**, **60**, **90**, **120**, **150**, or **180**) for staying on by pressing the **▲** or **▼** button.

- You can select these options simply by pressing the **SLEEP** button on the remote control.

◆ Timer 1 / Timer 2 / Timer 3

You can set the On/Off timers so that the television will switch on or off automatically at the time you select.

- ☛ You must set the clock first.

- Press the **◀** or **▶** button to select the required item below.
Press the **▲** or **▼** button to adjust to the setting satisfied.

On Timer : Select hour, minute, **am/pm**, and **Inactivate/Activate**.

(To activate timer with the setting satisfied, set to **Activate**.)

Off Timer : Select hour, minute, **am/pm**, and **Inactivate/Activate**.

(To activate timer with the setting satisfied, set to **Activate**.)

Repeat : Select **Once**, **Sat-Sun**, **Mon-Sat**, **Mon-Fri**, or **Everyday**.




Volume : Select the required volume level.

Programme : Select the required channel.

- You can set the hour and minute directly by pressing the numeric buttons on the remote control.

☛ Auto Power Off

When you set the timer "On", the TV will eventually turn off, if no controls are operated for 3 hours after the TV was turned on by timer. This function is only available in timer "On" mode and prevents overheating, which may occur if a TV is on for too long time.



Language / Blue Screen / Melody / Light Effect / Energy Saving / HDMI Black Level

- 1 Press the **MENU** button to display the menu.
- 2 Press the **▲** or **▼** button to select **Setup**, then press the **ENTER** button.
- 3 Select the required option by pressing the **▲** or **▼** button, then press the **ENTER** button.
- 4 When you are satisfied with your setting, press the **ENTER** button.
- 5 Press the **EXIT** button to exit.

◆ Language

It is variable depending on the model. When you start using the television for the first time, you must select the language which will be used for displaying menus and indications.

◆ Blue Screen: Off/On

If no signal is being received or the signal is very weak, a blue screen automatically replaces the noisy picture background. If you wish to continue viewing the poor picture, you must set the Blue Screen to Off.

◆ Melody: Off/Low/Medium/High

The TV power on/off melody sound can be adjusted.

◆ Light Effect: Off/Standby Mode On/Watching Mode On/Off

You can turn on/off the blue LED on the front of TV according to the situation. Use it for saving power or when the LED dazzles your eyes.

- **Off:** The blue LED is always off.
- **Standby Mode On:** The blue LED lights while in Standby mode and it turns off when your TV is turned on.
- **Watching Mode On:** The blue LED lights when watching TV and it turns off when your TV is turned off.
- **On:** The blue LED always lights.

➤ Set the **Light Effect** to **Off** to reduce the power consumption.

◆ Energy Saving: Off/Low/Medium/High

This feature adjusts the screen brightness depending on the surrounding lighting conditions.



- **Off:** Switches off the Energy Saving mode.
- **Low:** Operates in standard mode regardless of the surrounding illumination.
- **Medium:** Enters medium power saving mode regardless of the surrounding illumination.
- **High:** Enters maximum power saving mode regardless of the surrounding illumination.

➤ You can select these options simply by pressing the **E.SAVING** button on the remote control.

◆ HDMI Black Level: Normal/Low

Using this function, you can adjust the image quality when the screen burn (appearance of black level, low contrast, low color, etc.) is encountered by the HDMI input for RGB limited range (16 to 235).

➤ This function is active only when the external input connects to HDMI(RGB signals).



Using Game Mode

When connecting to a game console such as PlayStation™ or Xbox™, you can enjoy a more realistic gaming experience by selecting game menu.

- 1 Press the **MENU** button to display the menu.
- 2 Press the **▲** or **▼** button to select **Setup**, then press the **ENTER** button.
- 3 Press the **▲** or **▼** button to select **Game Mode**, then press the **ENTER** button.
- 4 Select **Off** or **On** by pressing the **▲** or **▼** button, then press the **ENTER** button.
- 5 Press the **EXIT** button to exit.

➤ **Restrictions on Game mode (Caution)**

- ◆ To disconnect the game console and connect another external device, set Game Mode to Off.
- ◆ If you display the TV menu in Game Mode, the screen shakes slightly.
- ◆ The mark () appears on the screen which means that Game Mode is On with the selected source.

➤ **If Game Mode is On :**

- ◆ Picture Mode is automatically changed to Standard and users cannot change the mode.
- ◆ Sound Mode in the Sound menu is deactivated. Adjust the sound using the equalizer.
- ◆ The Reset Sound function is activated. Selecting the Reset function after setting the equalizer resets the equalizer setting to the factory defaults.

➤ Game Mode is not available in TV mode.

- If the picture is poor when external device is connected to TV, check if Game Mode is On. Set Game Mode to Off and connect external devices.



Screen Burn Protection

To reduce the possibility of screen burn, this unit is equipped with screen burn prevention technology. This technology enables you to set picture movement up/down (Vertical Line) and side to side (Horizontal Dot). The Time setting allows you to program the time between movement of the picture in minutes.



- 1 Press the **MENU** button to display the menu.
- 2 Press the **▲** or **▼** button to select **Setup**, then press the **ENTER** button.
- 3 Press the **▲** or **▼** button to select **Screen Burn Protection**, then press the **ENTER** button.
- 4 Select the required option by pressing the **▲** or **▼** button, then press the **ENTER** button.
Available options: **Pixel Shift**, **All White**, **Signal Pattern**, **Side Gray**
- 5 When you are satisfied with your setting, press the **ENTER** button.
- 6 Press the **EXIT** button to exit.

- ◆ **Pixel Shift:** Using this function, you can minutely move pixels on the PDP in horizontal or vertical direction to minimize after image on the screen.
 - Set **Pixel Shift** to **On** by pressing the **▲** or **▼** button, then press the **ENTER** button.
 - Select the required option by pressing the **▲** or **▼** button, then press the **ENTER** button.
 Available options: **Horizontal Dot**, **Vertical Line**, **Time**
 - Optimum condition for pixel shift;

	PC	TV/AV/S-Video/ Component/HDMI
Horizontal Dot	1	2
Vertical Line	1	2
Time (minute)	2 min	2 min


➤ The Pixel Shift value may differ depending on the monitor size (inches) and mode.

- ◆ **All White:** This function helps remove after images on the screen by changing the colour of pixels to white. Use this function when there are remaining after images or symbols on the screen especially when you displayed a still image on the screen for a long time.
- ◆ **Signal Pattern:** This function helps remove after images on the screen by moving all the pixels on the PDP according to a pattern. Use this function when there are remaining after images or symbols on the screen especially when you displayed a still image on the screen for a long time.
- ◆ **Side Gray:** When you watch TV with the screen ratio of 4:3, the screen is prevented from any damage by adjusting the white balance on both extreme left and right sides.
 - **Dark:** When you set the screen ratio to 4:3, it darkens the left and right sides.
 - **Light:** When you set the screen ratio to 4:3, it brightens the left and right sides.
- To remove after images on the screen, use either **All White** or **Signal Pattern** function. Although both of the two functions remove after images on the screen, **Signal Pattern** is more effective.
- The after image removal function has to be executed for a long time (approximately 1 hour) to effectively remove after images on the screen. If after image is not improved after the execution of the function, repeat the function again.
- Press any button on the remote control to cancel this feature.




Wall- mount adjustment (Sold separately)

Once the wall mount is installed, the position of your TV can be easily adjustable.



Entering the menu

- 1 Press the **MENU** button to display the menu.
 - 2 Press the **▲** or **▼** button to select **Setup**, then press the **ENTER** button.
 - 3 Press the **▲** or **▼** button to select **Wall-Mount Adjustment**, then press the **ENTER** button.
 - 4 Adjust to the desired position using the **▲/▼/◀/▶** buttons.
 - 5 Press the **EXIT** button to exit.
- If you press an arrow button when no OSD is displayed on the TV screen, the Adjustment screen appears.
 - When you turn the power off, your TV moves to the initial installation position. When you turn the power on, your TV moves to the last remembered position you adjusted.



Using the remote Control Buttons

Button	Operations	
	Wall-mount angle adjustment	Tilt Up, Tilt Down, Move right, Move left
	Reset	Moves to the initial installation position
	Remembering the position and moving to the remembered position	Remembers 3 positions with the Red, Green and Yellow buttons. Moves to the remembered position using these 3 colour buttons.

- For installation, refer to the Installation Manual provided.
- For product installation and the installation and moving of the wall mount, make sure to consult a specialized installation company.
- This installation manual is to be used when attaching the wall mount to a wall. When attaching to other building materials, please contact your nearest dealer.

Viewing the Picture in Picture (PIP)

You can display a sub picture within the main picture. In this way you can watch TV program or monitor the video input from any connected devices.

- 1 Press the **MENU** button to display the menu.
- 2 Press the **▲** or **▼** button to select **Setup**, then press the **ENTER** button.
- 3 Press the **▲** or **▼** button to select **PIP**, then press the **ENTER** button.
- 4 Select the required option by pressing the **▲** or **▼** button, then press the **ENTER** button.

Available options: **PIP(Off/On)**, **Source**, **Size**, **Position**, **Programme**

- 5 When you are satisfied with your setting, press the **ENTER** button.
- 6 Press the **EXIT** button to exit.

◆ PIP: Off/On

You can activate or deactivate the PIP function.

- You can select these options simply by pressing the **PIP** button on the remote control.

◆ Source: TV/AV1/AV2

You can select a source of the sub-picture.

- You can select these options simply by pressing the **SOURCE** button on the remote control.

◆ Size: / /

You can select a size of the sub-picture.

- It is available in HDMI mode.

◆ Position: / / /

You can select a position of the sub-picture.

- You can select these options simply by pressing the **POSITION** button on the remote control.

◆ Programme

You can select a channel of the sub-picture only when the **Source** is set to **TV**.

- You can select the channel of the sub picture simply by pressing the **P ▲** or **P ▼** button.






Table of PIP Settings

X - This PIP combination is not available.

O - This PIP combination is available.

Main \ Sub(PIP)	TV	AV1, 2	S-Video	Component1, 2	PC	HDMI1, 2
TV	X	X	X	X	X	X
AV1, 2	X	X	X	X	X	X
S-Video	X	X	X	X	X	X
Component1, 2	O	O	X	X	X	X
PC	O	O	X	X	X	X
HDMI1, 2	O	O	X	X	X	X

Setting up Your PC Software (Based on Windows XP)

The Windows display-settings for a typical computer are shown below. But the actual screens on your PC will probably be different, depending upon your particular version of Windows and your particular video card. But even if your actual screens look different, the same, basic set-up information will apply in almost all cases. (If not, contact your computer manufacturer or Samsung Dealer.)

- 1 Right click the mouse on the Windows Desktop, then click on **Properties**.
The **Display Properties** will be displayed.
- 2 Click on **Settings tab**, then set the Display Mode with reference to the Display Modes Table. You do not need to change the Colours settings.
- 3 Click on **Advanced**. A new settings dialog box will be displayed.
- 4 Click on the **Monitor** tab, then set the **Screen refresh rate** with reference to the Display Modes Table. Set the Vertical Frequency and Horizontal Frequency individually if you can do so instead of setting the **Screen refresh rate**.
- 5 Click on **OK** to close the window, then Click on **OK** button to the **Display Properties** window. Automatic re-booting may commence at this moment.



Input Mode (PC)

Both screen position and size will vary depending on the type of PC monitor and its resolution. The table below shows all of the display modes that are supported:

Video Signal	Resolution (Dot X Line)	Vertical frequency (Hz)	Horizontal frequency (kHz)	Vertical polarity	Horizontal polarity	PS-42C9H/ PS-42C91H	PS-50C9H/ PS-50C91H
IBM PC / AT Compatible	640 x 350	70.086	31.469	N	P	✓	✓
	720 x 400	70.087	31.469	P	N	✓	✓
	640 x 480	59.940	31.469	N	N	✓	✓
		70.000	35.000	N/P	N/P	✓	✓
		72.809	37.861	N	N	✓	✓
	800 x 600	75.000	37.500	N	N	✓	✓
		60.317	37.879	P	P	✓	✓
		70.000	43.750	N/P	N/P	✓	✓
		72.188	48.077	P	P	✓	✓
	1024 x 768	75.000	46.875	P	P	✓	✓
		60.004	48.363	N	N	✓	✓
		70.069	56.476	N	N	✓	✓
		72.000	57.672	N/P	N/P	✓	✓
	1360 x 768	75.029	60.023	P	P	✓	✓
		60.015	47.712	P	P		✓

(N: Negative / P: Positive)

- ◆ The interlace mode is not supported.
- ◆ The television might operate abnormally if a non-standard video format is selected.
- ◆ 480i/p, 576i/p, 720p, or 1080i is not available in **PC** mode.
- ◆ For the PS-42C9H/PS-42C91H, PC text quality is optimum in **XGA** mode (1024 x 768 @60/70/72/75Hz).
- ◆ For the PS-50C9H/PS-50C91H, PC text quality is optimum in **WXGA** mode (1360 x 768@60Hz). (The three pixels each on the left and right are grayed at the resolution setting of 1360 x 768@60Hz. This is not a mechanical problem but a result caused by the pixel difference between the standard resolution and the PDP panel.)

Setting the PC

➤ Preset to the **PC** mode by pressing the **SOURCE** button.

- 1 Press the **MENU** button to display the menu.
- 2 Press the **▲** or **▼** button to select **Setup**, then press the **ENTER** button.
- 3 Press the **▲** or **▼** button to select **PC**, then press the **ENTER** button.
- 4 Select the required option by pressing the **▲** or **▼** button, then press the **ENTER** button.

Available options: **Image Lock**, **Position**, **Auto Adjustment**, **Image Reset**

- 5 When you are satisfied with your setting, press the **ENTER** button.
- 6 Press the **EXIT** button to exit.

◆ **Image Lock: Coarse/Fine**

The purpose of picture quality adjustment is to remove or reduce picture noise.

If the noise is not removed by Fine-tuning alone, then adjust the frequency as best as possible (coarse) and Fine-tune again. After the noise has been reduced, re-adjust the picture so that it is aligned on the center of screen.

- 1 Press the **▲** or **▼** button to select **Coarse** or **Fine**, then press the **ENTER** button.
- 2 Press the **◀** or **▶** button to adjust the screen quality, vertical stripes may appear or the picture may be blurry. Press the **ENTER** button.

◆ **Position**

Adjust the PC's screen positioning if it does not fit the TV screen.

- 1 Adjust the position by pressing the **▲/▼/◀/▶** button.
- 2 Press the **ENTER** button.





◆ **Auto Adjustment**

Auto adjustment allows the PC screen of set to self-adjust to the incoming PC video signal.

The values of fine, coarse and position are adjusted automatically.

◆ **Image Reset**

You can replace all image settings with the factory default values.




Setting the Home Theatre PC

➤ Preset to the **PC** mode by pressing the **SOURCE** button.

You can view higher quality pictures by configuring the screen settings in **PC Mode**.

If you set the Home Theatre PC function to **On**, you can configure the Detailed Settings (when Picture Mode is set to **Movie**) as in **PC Mode**.

- 1 Press the **MENU** button to display the menu.
 - 2 Press the **▲** or **▼** button to select **Setup**, then press the **ENTER** button.
 - 3 Press the **▲** or **▼** button to select **Home Theatre PC**, then press the **ENTER** button.
 - 4 Select **Off** or **On** by pressing the **▲** or **▼** button, then press the **ENTER** button.
 - 5 Press the **EXIT** button to exit.
- This function is available only in **PC** mode.





Teletext Feature (depending on the model)

Most television stations provide written information services via teletext. The index page of the teletext service gives you information on how to use the service. In addition, you can select various options to suit your requirements by using the remote control buttons.

- ☛ For teletext information to be displayed correctly, channel reception must be stable. Otherwise, information may be missing or some pages may not be displayed.

- 1  (exit)
Exit from the teletext display (depending on the model)
 - 2  (index)
Used to display the index (contents) page at any time while you are viewing teletext.
 - 3  (hold)
Used to hold the display on a given page if the selected page is linked with several secondary pages which follow on automatically. To resume, press it again.
 - 4  (store)
Used to store the teletext pages.
 - 5  (mode)
Press to select the teletext mode (LIST/FLOF).
If you press it in the LIST mode, it switches into the List save mode.
In the List save mode, you can save teletext page into list using the  (store) button.
 - 6  (sub-page)
Used to display the available sub-page.
 - 7  (page up)
Used to display the next teletext page.
 - 8  (page down)
Used to display the previous teletext page.
 - 9  (cancel)
Used to display the broadcast when searching for a page.
 - 10  (reveal)
Used to display the hidden text (answers to quiz games, for example). To display normal screen, press it again.
 - 11  (teletext on/mix)
Press to activate teletext mode after selecting the channel providing the teletext service. Press it twice to overlap the teletext with the current broadcasting screen.
 - 12 **Coloured buttons (red/green/yellow/blue)**
If the FASTEXT system is used by a broadcasting company, the different topics covered on a teletext page are colour-coded and can be selected by pressing the coloured buttons. Press one of them corresponding to the required. The page is displayed with other coloured information that can be selected in the same way.
To display the previous or next page, press the corresponding coloured button.
 - 13  (size)
Press to display the double-size letters in the upper half of the screen. For lower half of the screen, press it again.
To display normal screen, press it once again.
- You can change teletext pages by pressing the numeric buttons on the remote control.



Continued...



The teletext pages are organized according to six categories:

Part	Contents
A	Selected page number.
B	Broadcasting channel identity.
C	Current page number or search indications.
D	Date and time.
E	Text.
F	Status information. FASTEXT information.

Teletext information is often divided between several pages displayed in sequence, which can be accessed by:

- ◆ Entering the page number
- ◆ Selecting a title in a list
- ◆ Selecting a coloured heading (FASTEXT system)

➤ Press the **TV** button to exit from the teletext display.




Wall Mount Kit Specifications (VESA)

Install your wall mount on a solid wall perpendicular to the floor.

When attaching to other building materials, please contact your nearest dealer.

If installed on a ceiling or slanted wall, it may fall and result in severe personal injury.




Product Family	inch	VESA Spec. (A * B)	Standard Screw	Quantity
LCD-TV	23 ~ 26	200 * 100	M4	4
	32 ~ 40	200 * 200	M6	
	46 ~ 52	600 * 400	M8	
	57	700 * 400 (No VESA)		
	57 ~ 70	800 * 400		
	80 ~	1400 * 800		
PDP-TV	42 ~ 50	600 * 400	M8	4
	55 ~ 70	800 * 400		
	63	No VESA		6
	80 ~	1400 * 800		4

- We provided the standard dimensions for wall mount kits as shown in the table above.
- When purchasing our wall mount kit, a detailed installation manual and all parts necessary for assembly are provided.
- Do not use screws longer than the standard dimension, as they may cause damage to the inside of the TV set.
- For wall mounts that do not comply with the VESA standard screw specifications, the length of the screws may differ depending on their specifications.
- Do not use screws that do not comply with the VESA standard screw specifications.
Do not use fasten the screws too strongly, this may damage the product or cause the product to fall, leading to personal injury. Samsung is not liable for these kinds of accidents.
- Samsung is not liable for product damage or personal injury when a non-VESA or non-specified wall mount is used or the consumer fails to follow the product installation instructions.
- Our 57" and 63" models do not comply with VESA Specifications. Therefore, you should use our dedicated wall mount kit for this model.
- Do not exceed 15 degrees tilt when mounting this TV.

 Do not install your Wall Mount Kit while your TV is turned on.
It may result in personal injury due to electric shock

How to assemble the Stand-Base (depending on the model)


Using the 6 screws for securing the stand base and the monitor, firmly attach the monitor to the stand base. (The exterior of the set may be different than the picture.)



Warning

Firmly secure the stand to the TV before moving it, as the stand may fall and could cause serious injury.

- Two or more people should carry the TV. Never lay the TV on the floor because of possible damage to the screen. Always store the TV upright.



In case of installing your TV on the wall, close the cover (1) on the stand-base connection part using two screws for hiding.

Troubleshooting

Before contacting the Samsung after-sales service, perform the following simple checks. If you cannot solve the problem using the instructions below, note the model and serial number of the television and contact your local dealer.

No sound or picture

- ◆ Check that the mains lead has been connected to a wall socket.
- ◆ Check that you have pressed the  (Power) button (On/Off) on the front panel or press the **POWER** button on the remote control.
- ◆ Check the picture contrast and brightness settings.
- ◆ Check the volume.
- ◆ Check if **Internal Mute** is set to **On**.

Normal picture but no sound

- ◆ Check the volume.
- ◆ Check whether the volume **MUTE** button on the remote control has been pressed.

No picture or black and white picture

- ◆ Adjust the colour settings.
- ◆ Check that the broadcast system selected is correct.

Sound and picture interference

- ◆ Try to identify the electrical appliance that is affecting the television, then move it further away.
- ◆ Plug the television into a different main socket.

Blurred or snowy picture, distorted sound

- ◆ Check the direction, location and connections of your aerial.
This interference often occurs due to the use of an indoor aerial.

Remote control malfunctions

- ◆ Replace the remote control batteries.
- ◆ Clean the upper edge of the remote control (transmission window).
- ◆ Check that the "+" and "-" ends of the batteries are inserted correctly.
- ◆ Check that the batteries are drained.

Screen is black and power indicator light blinks steadily

- ◆ On your computer check; Power, Signal Cable.
- ◆ The TV is using its power management system.
- ◆ Move the computer's mouse or press any key on the keyboard.
- ◆ On your equipment check (STB, DVD, etc) ; Power, Signal Cable.
- ◆ The TV is using its power management system.
- ◆ Press the Source button on the panel or remote control.
- ◆ Turn the TV off and on.

The damaged picture appears in the corner of the screen

- ◆ If **Just Scan** is selected in some external devices, the damaged picture may appear in the corner of the screen. This symptom is caused by external devices, not TV.

Specifications

Model Name	PS42C9H	PS50C9H	PS42C91H	PS50C91H
Screen Size (Diagonal)	42 inch	50 inch	42 inch	50 inch
PC Resolution	1024 x 768 @ 60 Hz	1360 x 768 @ 60 Hz	1024 x 768 @ 60 Hz	1360 x 768 @ 60 Hz
Sound (Output)	10 W +10W	10 W +10W	10 W +10W	10 W +10W
Dimensions (WxHxD)				
Body	1055.0 X 699.5 X 95.0 mm	1230.9 X 788.9 X 95.0 mm	1055.0 X 699.5 X 95.0 mm	1230.9 X 788.9 X 95.0 mm
With stand	1055.0 X 759.0 X 316.0 mm	1230.9 X 848.5 X 316.0 mm	1055.0 X 759.0 X 316.0 mm	1230.9 X 848.5 X 316.0 mm
Weight				
Body	31.3 kg	41.3 kg	31.3 kg	41.3 kg
With stand	33.5 kg	43.5 kg	33.5 kg	43.5 kg
Environmental Considerations				
Operating Temperature	10 °C to 40 °C (50 °F to 104 °F)			
Operating Humidity	10% to 80%, non-condensing			
Storage Temperature	-20 °C to 45 °C (-4 °F to 113 °F)			
Storage Humidity	5% to 95%, non-condensing			

- ◆ This device is a Class B digital apparatus.
- ◆ Design and specifications are subject to change without prior notice.
- ◆ For the power supply and Power Consumption, refer to the label attached to the product.

***This page is intentionally
left blank.***

The Samsung logo is displayed in white, bold, uppercase letters within a black, horizontally-oriented oval shape.**Contact SAMSUNG WORLD-WIDE**

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care centre.

Country	Customer Care Centre ☎	Web Site
AUSTRALIA	1300 362 603	www.samsung.com/au
CHINA	800-810-5858, 010- 6475 1880	www.samsung.com.cn
HONG KONG	3698-4698	www.samsung.com/hk
INDIA	3030 8282, 1800 1100 11	www.samsung.com/in
INDONESIA	0800-112-8888	www.samsung.com/id
JAPAN	0120-327-527	www.samsung.com/jp
MALAYSIA	1800-88-9999	www.samsung.com/my
PHILIPPINES	1800-10-SAMSUNG (7267864)	www.samsung.com/ph
SINGAPORE	1800-SAMSUNG (7267864)	www.samsung.com/sg
SOUTH AFRICA	0860 7267864 (SAMSUNG)	www.samsung.com/za
TAIWAN	0800-329-999	www.samsung.com/tw
THAILAND	1800-29-3232, 02-689-3232	www.samsung.com/th
U.A.E	800SAMSUNG (7267864), 8000-4726	www.samsung.com/mea
VIETNAM	1 800 588 889	www.samsung.com/vn