


Skyworth

19" LCD TV/MONITOR
MODEL: LCD-19L3F




User Guide

Description: MANUAL(8M31)	
Job No. 83001H	Brand Name: SKYWORTH
Ref: 19L3F	P/No.
Revised:0	Scale:
Engineering Dept:	
Artwork By:	Date: 2008-04-28
Checked By:	Date:
Approved By:	Date:


SAFETY PRECAUTIONS

MAINTENANCE

- When the power cord or plug is damaged or frayed, unplug this TV from the wall outlet and refer servicing to qualified service personnel.



- Do not overload wall outlets and extension cords as this can result in fire or electric shock.



- Do not allow anything to rest on or roll over the power cord and do not place the TV where the power cord is subject to traffic or abuse. This may result in a shock or fire hazard.



- If the TV has been dropped or the cabinet has been damaged, unplug this TV from the wall outlet and refer servicing to qualified service personnel.




- Never push objects of any kind into this TV through cabinet slots as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock.



- Do not attempt to service this TV yourself as opening or removing covers may expose you to dangerous voltage. Refer all servicing to qualified service personnel.



- Do not place this TV on an unstable cart, stand or table. The TV may fall, causing serious injury to human and serious damage to the appliance.




- Avoid dusty places, since accumulated dust inside the chassis may cause failure of the TV when high humidity persists.



- Do not use this TV near water, for example, near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement, etc.



- Never cover the slots or openings of the TV with cloth or other material.



- Never block the bottom ventilation slots of the TV by placing it on a bed, sofa, rug, etc.



- Never place the TV near or over a radiator or heat register.



- Never place the TV in a "built-in" enclosure, unless proper ventilation is provided.




- The TV shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the TV.



SAFETY PRECAUTIONS

MAINTENANCE

- Choose a place where light (artificial or sunlight) does not shine directly on the screen.



- If a strange sound or smell gives off from the TV, please turn off and unplug it from the wall outlet, then refer to service personnel.



- If the TV does not work properly and you are unable to restore normal operation by following the "TROUBLESHOOTING" section in your instruction manual, do not attempt any further adjustment. Unplug the TV and consult service personnel.



- To prevent fire, never place any type of candle or naked flames on the top or near the TV.



- Adjust only those controls that are covered in the instruction manual as improper adjustment of other controls may result in damage, please ask your service personnel to restore the TV to normal operation.



- Avoid any kind of impact to the TV. Be special careful not to damage the screen face.



- For added protection for this TV during a lightning storm, unplug it from the wall outlet and disconnect the antenna or cable system.




- If the TV is to remain unused for a period of time, turn off and unplug it from the wall outlet.



Installing your LCD TV set


❶ Positioning the television set



Place your TV on a solid, stable surface, leaving a space of at least 5 cm around the appliance.


To avoid accidents, do not put anything on the set such as a cloth or cover, a container full of liquid (vase) or a heat source (lamp). The set must not be exposed to water.

❷ Connections

Insert the aerial plug into the  socket at the side of the set.


Insert the mains plug in the wall socket having a mains voltage of 220V AC, 50/60Hz.

❸ Switching on



To switch on the set, press the Power key.

❹ Remote control



- The remote control's effective range is 5 meters from the LCD screen at an angle of up to ± 30 degree. Direct light may affect the remote controls effective range.
- Avoid subjecting the remote control to shocks or vibrations.
- Avoid placing the remote control in humid and hot environments such as direct sunlight.
- Remove the batteries when not using the remote control for long periods.

IN THE BOX


You should have:

- Television x1 set
- User Guide x1 pc
- Warranty Card x1 pc
- AAA battery x2
- Stand x1 pc
- Wall Mount x1 pc
- Remote Control x1 pc

Location of Controls


Front View of TV Set

1. Remote Sensor
2. Power Indicator
3. Power Button
4. TV/AV Button
5. Menu Button
6. PROG.- Button
7. PROG.+ Button
8. VOL.- Button
9. VOL.+ Button
10. Speakers




Rear View of TV Set

1. AC Input
2. TUNER Input
3. AV Input
4. YPbPr Input
5. VGA Input
6. VGA Audio Input
7. HDMI Input



Remote Control Functions

Remote Control Unit For TV



POWER Button

Switch the TV from on to standby or from off to operate.

MUTE Button

Press once to mute the sound, press again to return to previously set sound level.

DIGIT Button

This TV allows you to select channels from 0 to 199.

Press this button to select one-digit, two-digit or three-digit channels input options.

To select a one-digit channel (e.g. Channel 8), press this button to change channel selection to "-" on screen display and press the "8" button only.

To select a two-digit channel (e.g. Channel 28), press this button to change channel selection to "--" on screen display and press "2" and "8" buttons.

To select a three-digit channel (e.g. Channel 120), press this button to change channel selection to "---" on screen display and press "1", "2" and "0" buttons.

AV/TV Button


Press this button to switch among TV broadcast, AV input program and other source. With wraparound.

TV → AV → YPbPr → PC → HDMI

MENU Button

Press this button to enter the menu screens for various optional adjustable settings.

Remote Control Unit For TV



PROGRAM UP/DOWN [PROG. +/-] Buttons
Press these buttons to select channels in ascending or descending order.

VOLUME UP/DOWN [VOL. +/-] Buttons
Press these buttons to adjust the volume level up or down.

Q.VIEW Button
Press this button to return to the previously viewed program.


S.S. Button
Sound mode set(D/K, B/G, I, L, L')

P.P. Button
TV mode, press this button to adjust the picture mode.
PERSONAL → STANDARD → DYNAMIC → SOFT

DISPLAY Button
Press this button to display the settings on the screen. (e.g. Channel number for TV input, colour system, sound system and sound mode.)

I/I SOUND MODE SELECTION Button
When stereo program is received, press this button to select STEREO or MONO.
When bilingual program is received, press this button to select NICAM-I, NICAM-II or MONO.

Remote Control Unit For TV



SLEEP Button

This key is used to set the sleep time .
The choices are 15,30,45,60 ,90,120 and off.

REVEAL Button

Press the key to reveal/conceal the hidden information. Such as solutions to riddles and puzzles.

SIZE Button

Press the key to chang the screen format:
NORMAL,FULL,ZOOM.

CANCEL - inapplicability

INDEX - inapplicability

SUB.PAGE - inapplicability


MIX - inapplicability

HOLD - inapplicability

TEXT - inapplicability

Operation Guide

PICTURE



Enter Picture menu, you can select PICTURE MODE , CONTRAST,BRIGHTNESS,SATURATION, SHARPNESS,COLOR TEMP items by pressing PROG +/- Buttons.

PICTURE MODE

Press the button to change the contrast and brightness and colour value of picture.

The choices are PERSONAL-STANDARD-DYNAMIC-SOFT, with wrap around.

CONTRAST

Press the **VOL +/-** button to increase/decrease the contrast of the picture.

BRIGHTNESS

Press the **VOL +/-** button to lighten/darken the picture.

SATURATION

Press the **VOL +/-** button to increase/decrease the colour saturation.

SHARPNESS


Press the button to sharpen or soften the picture.

COLOR TEMP.

Press the button to select a suitable colour temperature to display.

The choices are "Warm" ,"Normal" , " Cool" .

SOUND



Enter SOUND menu, you can select SOUND MODE, BASS, TREBLE,BALANCE, items by pressing PROG +/- Buttons.

SOUND MODE

Press the button to obtain special sound effects.

The choices are PERSONAL-STANDARD-NEWS-MUSIC with wrap around .

BASS

Press the **VOL+** or **VOL-** button to adjust the bass boost value.

TREBLE


Press the **VOL+** or **VOL-** button to adjust the high frequency signal value.

BALANCE

Press the **VOL+** or **VOL-** button to adjust to the left to right sound channel volume.

Operation Guide

ADVANCE



Enter ADVANCE menu you can select NR , TTX LANGUANG ,AUTO FORMAT,items by pressing PROG +/- Buttons.


NR

Press the VOL+ or VOL- to obtain special effect from "OFF, WEAK, MIDDLE,STRONG"

TTX LANGUAGE

The choices are WEST, EAST, RUSSIAN, ARABIC, FARSI .

SYSTEM



Enter SYSTEM menu, you can select OSD LANGUAGE , H-POSITION , V-POSITION , DURATION , HALFTON , FACTORY RESET, items by pressing PROG +/- Buttons.

OSD LANGUAGE

The choices are ENGLISH, CHINESE.

H-POSITION

Moving the main menu position in left or right by pressing VOL +/- buttons.

V-POSITION

Moving the main menu position in up or down by pressing VOL +/- buttons.

DURATION

Changing the main menu s display time by pressing VOL +/- buttons.

HALFTONE


Chaning the main menu s background color by pressing VOL +/- buttons.

FACTORY RESET

The function can cancel all current channels.

Operation Guide

TV-CHANNEL



Enter TV-CHANNEL menu, you can select COLOR SYSTEM, SOUND SYSTEM, MTS, AUTO SCAN, MANUAL SEARCH, CHANNEL LABEL, FINE TUNE, SKIP, AFC, PROGRAM AREA, items by pressing PROG +/- Buttons.

COLOUR SYS

Press the button to select a new colour standard value in TV. The choices are AUTO, PAL and SECAM.

SOUND SYS

Press the button to select a new sound standard value in TV. The choices are B/G, D/K, I, L and L'.

MTS

Press the button to select different sound mode as NICAM I, NICAM II and MONO.

AUTO SCAN

The auto search action takes care of program tuning, storing and retrieving program information.

MANUAL SEARCH

The manual can get program you expect by PROG +/-, and can gain frequency accordingly by VOL +/-.

CHANNEL LABEL

can choose some channel you expect by PROG +/- or VOL +/-, and can name, delete and insert the one. The red marker is call some channel. When choosing some channel and pressing the red mark, it appears one small white frame and you can start to call the channel.

Note: moving the position by VOL +/-;

choosing the letter, number and sign by PROG +/-.

The green marker is delete some channel.

The yellow marker is insert some channel.

Enter submenu,

Pressing the red marker after call some channel and ok;

Pressing the green marker after call some channel and cancel.

FINE TUNE

Press VOL +/- button to adjust the little change of frequency.

SKIP

Press the skip to enable or disable the selected program from being tuned to by pressing VOL +/- Buttons. The choices are "on" and "off".

AFC

The choices are "on" and "off".

CHANNEL



CHANNEL LABEL

PROGRAM		
	010	020
001	011	021
002	012	022
003	013	023
004	014	024
005	015	025
006	016	026
007	017	027
008	018	028
009	019	029
■NAME ■DELETE ■INSERT		

CHANNEL LABEL		
000	010	020
	011	021
002	012	022
003	013	023
004	014	024
005	015	025
006	016	026
007	017	027
008	018	028
009	019	029
■OK ■CANCEL		

Operation Guide

Other sources

AV

Press the TV/AV Button to select the AV source .
In AV state, There are 4 general menus (Picture , Sound , Advance , System) supported all functions are the same as in TV mode.


YPbPr

In YPbPr state, there are (Picture , Sound , Advance , System) supported all functions are the same as in TV mode.

HDMI

In HDMI state, There are 4 general menus (Picture , Sound , Advance , System) supported all functions are the same as in TV mode.


PC



In PC state, there are 2 general menus (sound , system) as TV. When entering the PC mode, select the PICTURE menu, you can select PICTURE MODE , CONTRAST , BRIGHTNESS , COLOR TEMP items are the same as in TV mode .
COLOR TEMP
Press the button to adjust the best visual effect of picture. the choices are user , normal , warm , cool. when choose the user, the following all items will adjust by VOL +/- . They are USER-R, are USER-G, are USER-R items by pressing PROG. +/- buttons.

When selecting GEOMETRY menu , you can select H-POSITION , V-POSITION , CLOCK , PHASE , AUTO ADJUST

GEOMETRY



H-POSITION

The H-Position menu allows control of horizontal position of the picture on the display.

V-POSITION

The V-Position menu allows control of vertical position of the picture on the display.

CLOCK

Changing the sampling clock in pc by pressing VOL +/- buttons.

PHASE

Changing the phase in pc by pressing VOL +/- buttons.

AUTO ADJUST

Start the auto-adjust procedure to automatically determine the values for horizontal position, vertical position, phase adjust and clock adjust.
Recommend: Don't change these values after auto adjust at best.


Operation Guide

Notice of PC connection

1. Power off both computer and display before making any connections.

- The monitor comes with a 15-pin PC socket. Connect the end of signal cable to the socket of the TV and connect the other end to the 15-pin connector to the computer.
- Tighten the screws of the Display cable until the connectors are fastened securely at both ends (finger-tighten only).
- If you are using Windows operating system running on a PC with a Microsoft Plug & Play compatible video card, your system will select the appropriate timing for your monitor.

15 Pin Mini D-Sub Connector



2. PC input typical display mode table:

The following table is an illustration of some of the typical video display modes.

1	640X480(recommend 60Hz)
2	800X600(recommend 60Hz)
3	1024X768(recommend 60Hz)

3. We can set different values in Frequency, phase, H-offset and V-offset. And we also can select the Auto adjust to adjust different picture modes automatically.

Component input (YPbPr)

The following table is an illustration of some of the typical video display modes.

1	480i
2	480p
3	576i
4	576p
5	720p(50/60Hz)
6	1080i(50/60Hz)
7	1080p(50/60Hz)

HDMI

The following table is an illustration of some of the typical video display modes.

	480p
	576p
	720p(50/60hz)
	1080i(50/60hz)
	1080p(50/60hz)
	640X480(recommend 60HZ)
	800X600(recommend 60HZ)
	1024X768(recommend 60HZ)

Tips(TV)

Please make these simple checks as indicated (●) on the chart for the respective symptoms and their possible remedies.

Symptoms	Possible Remedies									
	Try different channel	Check aerial connections on back of set	Re-orient aerial (if indoor type)	Probably local interference, such as an appliance	Adjust brightness control	Adjust contrast control	Check if station is broadcasting colour	Check if system is correctly set	Check if on/off switch is "on"	Check batteries in remote control unit
No picture, no sound	●	●	●	●				●	●	
Poor sound, picture OK	●	●	●	●						
Poor picture, sound OK	●	●	●	●	●			●		
Weak picture	●	●	●	●				●		
Blurred picture	●	●	●	●				●		
Double image	●	●	●	●						
Lines in picture	●	●	●	●						
Distorted picture	●	●	●	●				●		
Weak reception on some channels	●	●	●	●				●		
Horizontal bars	●	●	●	●						
Picture rolls vertically	●	●	●	●				●		
Poor colour	●	●	●	●	●	●	●	●		
No colour	●	●	●	●	●		●	●		
Misoperation of Remote control										●
Remote control unit no operation										●
On Screen Display Control outside the screen							●			