



USER'S MANUAL

MANUEL DE L'UTILISATEUR

MANUAL DEL USUARIO

DPF-0801

Digital Photo Frame

Cadre Photo Numérique

Marco de Fotos Digitales




TABLE OF CONTENTS

INSTALLATION / QUICK START.....	2
DIAGRAM OF THE DIGITAL PHOTO FRAME.....	3
OSD MENU FUNCTIONS.....	4
KEYPAD BUTTON FUNCTIONS.....	5
USING MINI USB FOR FILE TRANSFER.....	6
TECHNICAL SPECIFICATIONS.....	7
FREQUENTLY ASKED QUESTIONS	8
IMPORTANT PRODUCT SAFETY INFORMATION.....	9
CLEANING THE DIGITAL PHOTO FRAME.....	11
PRODUCT WARRANTY	13

Congratulations on your purchase of a Westinghouse 8.0" LCD Digital Photo Frame. Read carefully and follow all warnings and instructions in this User's Manual and those marked on the product before you use the Digital Photo Frame. Failing to follow warnings can result in personal injury or damage to the Digital Photo Frame. Please keep this User's Manual in a convenient location for future reference.

Important: Save the original box and all packing material for future shipping needs.

Installation



Package Contents

- Digital Photo Frame (8.0" LCD Screen)
- Ebony Wood Frame
- AC/DC Power Supply Adapter
- User's Manual

Quick Start

1. Plug the AC adapter into the Digital Photo Frame and plug it into a wall socket.
2. Insert a memory card into one of the four slots:
Slot 1 - Secure Digital™ or MultiMedia Card™
Slot 2 - Compact Flash™ or Micro Drive™
Slot 3 - xD-Picture Card™
Slot 4 - Memory Stick™, Memory Stick PRO™, Memory Stick Duo™, or Memory Stick PRO Duo™
3. Turn On the Power Switch on the back of the Digital Photo Frame.
4. Once the Digital Photo Frame has turned on, the unit will enter Slide Show Mode automatically.
5. If you wish to view images individually, press the Play (▶) Button or Menu button to bring up Thumbnail Mode. Select a Photo and press the Play (▶) button to view the image. If you wish to enter Slide Show Mode again, press the Play (▶) button.

Diagram of the Digital Photo Frame



OSD Menu Functions

All function settings for the Digital Photo Frame can be controlled via the buttons located on top of the Frame. You will be able to access the On Screen Display (OSD) at any time, except when in Slide Show Mode or playing a video, by simply holding down the “Menu” button for 2 seconds.

OSD Menus	Sub-Menus	Description and Function of Operation
Full Screen	On	All images will display in full screen.
	Off	
Photo Transition	On	When viewing photos individually, you have the option of having transitions, on or off.
	Off	
Transition Effect	Off	Select Style of Transition
	Fade	
	Shutter	
	Cross Comb	
	Mask	
	Brick	
	Dissolve	
	Random	
Slide Show Speed	3 Seconds	Select Speed of Slide Show
	5 Seconds	
	10 Seconds	
	30 Seconds	
	60 Seconds	
Video Repeat	One	Selected Video File will repeat continuously
	All	All Video Files will repeat continuously
	Off	Selected Video File will not repeat automatically
Start Slide Show	-	Unit will go into Slide Show Mode
Rotate	-	Rotate image counter-clockwise 90° on image
Zoom	-	Zoom into selected image

Note: If a card is inserted into the Digital Photo Frame, selecting “Start Slide Show” will run a Slide Show of images contained in the memory card.

Keypad Button Functions

OSD Functions

Note: To enter the OSD, hold the Menu button down for 2 seconds. To exit, simply press the Menu button.

<u>Button</u>	<u>Command</u>
<<	Up
Play	Select
>>	Down
Menu	Back/Exit

Viewing Images Individually

<u>Button</u>	<u>Command</u>
<<	Previous Image
Play	Start Slide Show Mode
>>	Next Image
Menu	Press once to exit to Thumbnail Mode or hold down for 2 seconds to enter OSD Menu

Viewing Video Files

<u>Button</u>	<u>Command</u>
<<	Previous Video File
Play	Pause Video / Play Video
>>	Next Video File
Menu	Exit to Video Selection Page

Thumbnail Mode / Select Mode Page / Card Select Page

<u>Button</u>	<u>Command</u>
<<	Left
Play	Select
>>	Right
Menu	Back one page

To get to the Card Select page from Thumbnail Mode, hit the Menu button twice to go back two pages.

Using the Mini-USB for File Transfer

The Frame comes with 8MB of built-in Flash Memory. Make sure that the Frame is first turned off before connecting a USB cable (not included) from a computer to the Digital Photo Frame and that the Power Supply is connected.

Switch on the Frame. Once the computer has recognized the device, you will be able to download compatible image or video files stored in your computer into the internal memory of the Digital Photo Frame.

Disconnecting the Frame from a computer:

1. Click the “Safely Remove Device” icon on the Task Bar located on the bottom right corner of the computer Desktop.
2. A dialogue box (“Safely Remove Hardware”) will appear.
3. Select USB Mass Storage Device and click “Stop”.
4. On the next dialogue box, click “OK”.
5. On the final dialogue box, click “Close”. Now you can safely remove the Digital Photo Frame.

The saved images will appear once you have turned off the Frame and switched it back on.

Note: Attempting to disconnect the Digital Photo Frame without using the “Safely Remove Device” procedure may cause the files in the internal memory to be unreadable.

Technical Specifications

Model No.:	DPF-0801
Product:	8.0" LCD Screen Digital Photo Frame
Input Formats:	Secure Digital™, Multi Media Card™, Compact Flash™, Micro Drive™, xD-Picture Card™, Memory Stick™, Memory Stick PRO™, Memory Stick Duo™, Memory Stick PRO Duo™ and USB Flash Drives
File Format:	JPEG, AVI Motion JPEG, MPEG1, MPEG4
Features:	Slide Show Mode Range of Transitional Styles for Slide Show Variable Speed for Slide Show AVI Motion JPEG Player MPEG 1 and 4 Video Player Extendable Stand for Angle Adjustment
Internal Memory:	8MB FLASH
USB Ports:	Mini-USB (for file transfer) USB (for USB Flash Drives)
Power:	Input: 100V-240V AC, 50~60HZ Output: 9V DC, 2A
Weight:	1.5 lbs
Dimensions:	9.8 x 8.2 x 1.5 inches

Frequently Asked Questions

Q: What other media formats can the Digital Photo Frame support? Why will it not play all images or movie files?

A: The Digital Photo Frame will support JPEGs and AVI Motion JPEGs taken from a digital camera. The Digital Photo Frame may not read all images or video files downloaded from the Internet. Many of the video formats downloaded from the Internet are not supported as well.

Q: I have a memory card in the Digital Photo Frame, but it's not reading the card. What should I do?

A: First, make sure that you are using a memory card that is supported by the Digital Photo Frame. Second, ensure that the memory card is inserted all the way into the correct slot. Third, press the Menu button until you reach the Card Select page. If the memory card is properly inserted into the slot, that memory card icon will be highlighted.

Note: Some digital cameras save images into non-standard formats. Please refer to your camera's operating manual for specifics.

Q: Why do some pictures load faster than others?

A: Higher resolution pictures load slower. Using a lower resolution when taking pictures will speed up loading time.

Q: If I have a card inserted into the frame, but I want to run the Slide Show with pictures in the internal memory, what should I do?

A: Go to the Card Select page and select "Built-in Memory". Go to Photos and select an image. Press the Play Button and the unit will go into Slide Show Mode.

IMPORTANT PRODUCT SAFETY INSTRUCTIONS

Proper Handling of the Digital Photo Frame

Always handle the Digital Photo Frame with care. Avoid touching the LCD screen. Skin oils are difficult to remove.

Always position the Digital Photo Frame on a stable and level surface. Unstable surfaces can cause the Digital Photo Frame to topple and fall, resulting in possible damage or injury.

Avoid exposing the Digital Photo Frame to direct sunlight or high temperatures, which can damage or shorten its useful life. Do not place it near heat sources such as radiators, heat registers, or other appliances that generate heat. Orient the Digital Photo Frames away from direct sunlight to reduce glare.

Avoid exposing the Digital Photo Frame to rain, water, moisture or high humidity. Do not place it near basins or sinks where it may come in contact with water.

Never place heavy or sharp objects on the LCD panel, frame, or power cord.

Overloading Outlets

Do not overload electrical power sources when using the Digital Photo Frame. Overloading wall outlets, circuits, or extension cords can result in overheating, fire, or electric shock. Use only grounded or polarized outlets.

Power Cord Protection

Minimize wear on the power supply cord. The power supply cord should be routed away from foot traffic and contact with other objects. Do not route the power cord under rugs or carpeting. The cord should never be severely bent, pinched, or twisted. Periodically inspect the power cord and each end of the cord for wear or damage. Unplug and replace the cord if it is damaged.

Ventilation

Slots and openings on the Digital Photo Frame are provided for ventilation purposes. To ensure reliable operation of the product and to protect it from overheating, these openings must not be blocked or covered. Keep the Digital Photo Frame a minimum of four (4) inches away from any wall to assure sufficient airflow and ventilation. Increased temperatures may cause fire or device failure.

To assure proper ventilation, do not block the openings by placing the Digital Photo Frame on a bed, sofa, rug or other similar surface. Do not place it in a built-in installation, such as a bookcase or enclosed rack, unless proper ventilation is provided.

Other Notices and Precautions

Caution: Never remove the plastic casing. There are no user serviceable parts inside. The Digital Photo Frame contains high voltage parts. You may be seriously injured if you touch them.

Do not attempt repairs yourself. The warranty does not cover repairs or attempted repairs by anyone not authorized by Westinghouse Digital. Refer all servicing and repairs to qualified service personnel.

If the Frame begins to emit smoke, an abnormal noise, or a strange odor, immediately turn it off and unplug the power cord. Contact the Westinghouse Service Center.

If the Digital Photo Frame will not be used for an extended period of time, unplug the power cord.

Cleaning the Digital Photo Frame

- **MAKE SURE THE DIGITAL PHOTO FRAME IS TURNED OFF**
- **NEVER SPRAY OR POUR LIQUID DIRECTLY ONTO THE SCREEN OR PLASTIC CASING**

To Clean the Screen:

1. Wipe the screen with a clean, soft, lint-free cloth. This removes dust and other particles.
2. If it still is not clean, apply a small amount of non-ammonia, non-alcohol based glass cleaner on a clean, soft, lint-free cloth to clean the screen.

To Clean the Plastic Casing:

1. Use a soft, dry cloth.
2. If it still is not clean, apply a small amount of non-ammonia, non-alcohol based, mild non-abrasive detergent on a clean, soft, lint-free cloth to clean the surface.

To Clean the Frame:

1. Use a soft, dry cloth.

Disclaimer

Westinghouse Digital does not recommend the use of any ammonia or alcohol-based cleaners on the LCD screen or plastic casing. Some chemical cleaners have been reported to damage the screen and/or display case. Westinghouse Digital will not be liable for damage resulting from the use of any ammonia or alcohol-based cleaners.



This symbol is intended to alert the user of the presence of non-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to a person.



This symbol is intended to alert the user of the presence of important operation and maintenance instructions in the Digital Photo Frame User's Manual.



CAUTION
TO REDUCE THE RISK OF FIRE OR
ELECTRIC SHOCK, DO NOT
EXPOSE THIS UNIT TO RAIN OR
MOISTURE.



CAUTION
TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE PLASTIC CASE.
NO SERVICABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL.

Product Warranty

Westinghouse Digital Electronics

LCD Digital Photo Frame Six Month Limited Warranty

Westinghouse Digital Electronics warrants this LCD Digital Photo Frame against defects in material or workmanship for a period of six (6) months from the original date of purchase, subject to the following terms and conditions:

LABOR AND PARTS — For a period of six (6) months from the original date of purchase, Westinghouse Digital Electronics will repair any defect in material or workmanship in the Product, or at its option, replace a defective Product. During the six (6) months warranty period, Westinghouse Digital Electronics will supply new or rebuilt replacement parts in exchange for defective parts. Replacement parts will be warranted for either the remainder of the original warranty period or ninety (90) days from date of installation, whichever occurs last. After the expiration of the warranty period, repairs to the Product are the responsibility of you, the purchaser.

OBTAINING WARRANTY SERVICE — To obtain warranty services, you must either personally deliver the Product to a Westinghouse Digital Electronics service center, or ship the Product to said service center freight prepaid, in its original packaging or in packaging providing an equal degree of protection. Westinghouse Digital Electronics is not responsible for damage to any Product that occurs during shipping. Please call Westinghouse Digital Electronics at (866) 287-5555 for the locations of the nearest Westinghouse Digital Electronics service center.

EXCLUSIONS TO WARRANTY — Damage to the Product resulting from acts of God, accident, misuse, abuse, negligence, commercial use (not consumer or personal use), alteration, or unauthorized repair of the Product is not covered by this warranty. This warranty does not cover damage due to: (i) improper installation, set-up adjustments, operation, or maintenance; (ii) power surges, connection to incorrect voltage, or combination with incompatible components or accessories; or, (iii) repairs attempted by anyone other than an authorized Westinghouse Digital Electronics service facility. This warranty is valid only for Products purchased and used in the United States of America or Canada.

PROOF OF ORIGINAL PURCHASE — A sales receipt, invoice, or other proof of purchase specifying the original date of purchase, must be presented within the six (6) months warranty period to obtain warranty service. This warranty extends to the original purchaser and is not transferable. The factory-applied serial number must appear on the Product or this warranty shall not apply.

EITHER REPAIR OR REPLACEMENT IS YOUR EXCLUSIVE REMEDY UNDER THIS WARRANTY. EXCEPT TO THE EXTENT PROHIBITED BY LAW, WESTINGHOUSE DIGITAL SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES CLAIMED TO ARISE FROM BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION AND SCOPE TO THE TERMS OF THIS WARRANTY.

Some States do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from State to State.

For latest product information and tips please check www.westinghousedigital.com

To register your Digital Photo Frame, please call (866) 287-5555 or visit our website to register online.



www.westinghousedigital.com