



Magellan[®] Triton[™] 2000

User Manual

IMPORTANT SAFETY WARNINGS

The Magellan Triton is a navigation aid designed to assist you in arriving to your selected destination. When using the Magellan Triton, these safety rules must be followed to prevent accidents that can result in injury or death to yourself or others:

IN THE INTEREST OF SAFETY, DO NOT USE THIS NAVIGATION DEVICE WHILE DRIVING A VEHICLE.

Please do not try and change any settings on the Magellan Triton while driving. Come to a complete stop or have a passenger make any changes. Taking your eyes off the road is dangerous and can result in an accident in which you or others could be injured.

USE GOOD JUDGEMENT

This product is an excellent navigation aid, but does not replace the need for careful orienteering and good judgement. Never rely solely on one device for navigating.

USE CARE

The Global Positioning System (GPS) is operated by the U.S. Government, which is solely responsible for the accuracy and maintenance of the GPS network. The accuracy of position fixes can be affected by the periodic adjustments to GPS satellites made by the U.S. government and is subject to change in accordance with the Department of Defense civil GPS user policy and the Federal Radionavigation Plan. Accuracy can also be affected by poor satellite geometry and obstructions, like buildings and large trees.

USE PROPER ACCESSORIES

Use only Magellan cables and antennas; the use of non-Magellan cables and antennas may severely degrade performance or damage the receiver, and will void the warranty.

LICENSE AGREEMENT

Magellan Navigation Inc. grants you, the purchaser, the right to use the software supplied in and with Magellan Navigation GPS products (the "SOFTWARE") in the normal operation of the equipment.

The SOFTWARE is the property of Magellan Navigation and/or its suppliers and is protected by United States copyright laws and international treaty provisions; therefore, you must treat this SOFTWARE like any other copyright material.

You may not use, copy, modify, reverse engineer or transfer this SOFTWARE except as expressly provided in this license. All rights not expressly granted are reserved by Magellan Navigation and/or its suppliers.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.

No part of this guide may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose other than the purchaser's personal use without the prior written permission of Magellan Navigation Inc.

IMPORTANT SAFETY WARNINGS

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.


IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

In order to maintain compliance with FCC regulations, shielded cables must be used with this equipment. Operation with non-approved equipment or unshielded cables is likely to result in interference to radio and TV reception. The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.



The Magellan Triton must be installed and operated at a distance no closer than 8 inches (20 cm) from the user.

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

IMPORTANT SAFETY WARNINGS

IC statement

Operation is subject to the following two conditions:

1. This device may not cause interference and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

IMPORTANT NOTE:

IC Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The information provided in this document is subject to change without notice. Improvements and enhancements to the product may occur without any formal notification. Check the Magellan website (www.magellanGPS) for product updates and additional information.

Underwriters Laboratories Inc. ("UL") has not tested the performance or reliability of the Global Positioning System ("GPS") hardware, operating software or other aspects of this product. UL has only tested for fire, shock or casualties as outlined in UL's Standard(s) for Safety for Information Technology Equipment, UL60950-1. UL Certification does not cover the performance or reliability of the GPS hardware and GPS operating software. UL MAKES NO REPRESENTATIONS, WARRANTIES OR CERTIFICATIONS WHATSOEVER REGARDING THE PERFORMANCE OR RELIABILITY OF ANY GPS RELATED FUNCTIONS OF THIS PRODUCT.

Maximum. normal use temperature is 66°C.

This device is a Class 1 LED PRODUCT.

© 2007 Magellan Navigation, Inc. All rights reserved. The Magellan Logo, Magellan, and Magellan Triton are trademarks of Magellan Navigation, Inc. No part of this user manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose other than the purchaser's personal use, without the prior written permission of Magellan Navigation, Inc.

631483-01 A

Table of Contents

Table of Contents	1
Fundamentals	1
Navigation Screens	3
Map Screen Overview	3
Buttons	4
Cursors	4
Navigation Fields	4
<i>Displaying Navigation Fields</i>	4
<i>Changing a Navigation Field</i>	5
Additional Navigation Screens	6
<i>Accessing the Navigation Screens</i>	6
Current Location Screen	6
Large Data Screen	6
<i>Changing a Navigation Field</i>	6
Speedometer Screen	7
<i>Resetting the Odometer or Maximum Speed</i>	7
Compass Screen	7
<i>Changing a Navigation Field</i>	7
<i>Calibrating the Electronic Compass</i>	7
<i>Calibrating the True North</i>	7
<i>Viewing the Compass, Temperature and Pressure Sensor Statistics</i>	7
Satellite Status	8
<i>Changing a Navigation Field</i>	8
Using the Keypad	9
The Keypad	9
<i>Key Functions</i>	9
Create Menu	10
<i>Accessing the Create Menu</i>	10
Waypoints	10
<i>Creating a Waypoint</i>	10
Trail	11
<i>Creating a Trail from Current Track History</i>	11
Geocache	11
<i>Creating a Geocache Waypoint</i>	11

Route	12
<i>Creating a Route</i>	12
Go To Menu	14
<i>Accessing the Go To Menu</i>	14
Waypoints	14
<i>Go To a Waypoint</i>	14
<i>Editing a Waypoint</i>	14
<i>Deleting a Waypoint</i>	15
<i>Duplicating a Waypoint</i>	15
Places	15
<i>Creating a Go To to a Place</i>	15
Trail	16
<i>Activating a Trail</i>	16
<i>Deleting a Trail</i>	16
<i>Duplicating a Trail</i>	17
Geocache	17
<i>Creating a Geocache Go To</i>	17
<i>Deleting a Geocache Waypoint</i>	18
<i>Duplicating a Geocache</i>	18
Route	19
<i>Activating a Route</i>	19
<i>Editing a Route</i>	19
<i>Duplicating a Route</i>	19
<i>Deleting a Route</i>	19
View Menu	21
Local Info	21
<i>Viewing Best Fishing and Hunting Times for Current Location</i>	21
<i>Viewing Sunrise, Sunset Times and Lunar Information for Current Location</i>	21
User Profiles	22
<i>Activating User Profiles</i>	22
<i>Display options</i>	22
<i>Map options</i>	23
<i>Navigation options</i>	23
<i>Alert options</i>	23
Tracks	24
<i>Viewing Track Vertical Profile</i>	24
<i>Saving a Track as a Trail</i>	24
<i>Erasing a Track</i>	25

<i>Setting Track Log Options</i>	25
Maps	25
<i>Viewing Map Information</i>	25
Media	25
<i>Viewing Stored Media</i>	25
Settings	26
Navigation	26
<i>Setting Navigation Options</i>	26
Volume & Brightness	26
<i>Setting Volume & Brightness</i>	26
Memory	26
<i>View Memory Usage</i>	26
<i>Clearing Memory</i>	26
<i>Restoring Factory Settings</i>	27
<i>Formatting SD Card</i>	27
About	27
<i>Displaying Information About the Triton Receiver</i>	27
Diagnostics	27
<i>Testing the touchscreen display</i>	27

Fundamentals


The Magellan Triton is a hand-held GPS receiver that has been designed for the outdoorsman. Simple to use, yet powerful enough to get you through the toughest terrain or returning to that same fishing hotspot, year after year.

- Store waypoints that can include images for the complete experience.
- Record your track from start to finish and save it as a trail to be used over and over.
- Set a quick and easy Go To route from your current position to a stored waypoint or any point on the map, simply and easily.
- Built-in flashlight to light your way in the dark.
- Load detailed Magellan maps with topographic or navaid information for the most detail possible.
- Alarms can be set to alert you when you are nearing your destination, drifted off-course, your boat has drifted from its anchor point as well as other alarms for a wide variety of choices.
- View images stored on an SD card that can be used to assist you in arriving at the proper location.
- Create a route from your current position to many different waypoints or places on the map. Plan your day for the best use of your outdoor time.

The Magellan Triton is constantly being reviewed and updated to meet the outdoorsman's needs. Be sure to visit the support page at www.magellanGPS.com for firmware updates, keeping your Magellan Triton running at it's peak.

While you are checking for firmware updates, check the support section for additional FAQs as well as updated manuals to assist you in the use of your Magellan Triton.

This document is set up to be printed on 8.5" x 11" (letter) paper should you desire a printed version for your reference.




- A Backlight / Flashlight button. Press to step through 3 levels of backlight intensity or off. Press and hold for 2-3 seconds to turn the flashlight on or off.
- B Hold Switch. Slide up to place the Magellan Triton in hold mode. During hold mode, the keys will not function, preventing accidental use.
- C Connector for optional external antenna
- D Flashlight
- E Stylus
- F Zoom out button
- G Page / Go To. Press to step through the navigation screens. Press and hold for 2-3 seconds to access the Go To function quickly.
- H Escape or cancel button
- I Zoom in button
- J Menu button. On the map screen, displays the Main Menu. On other screens, displays a pop-up menu when available.
- K Enter button and cursor control pad
- L On / Off button
- M SD card slot
- N Headphone connector (headphone is an optional accessory)
- O Reset

Navigation Screens

The Map Screen will be the most commonly viewed screen while using the Magellan Triton. It has been simplified to provide the best possible outdoor experience while providing access to all of the information needed at the touch of a finger.

Map Screen Overview



- A** Battery Level
- B** Saved Waypoint (Preloaded or User-Entered)
- C** Present Position Marker (points towards heading while moving)
- D** Map Scale Indicator
- E** Optional Navigation Field pop-up
- F** North Indicator
- G** Satellite Status
- H** Time of Day
- I** Map Area (touch and move to pan around the map)

Buttons

While viewing the map screen the keys on the Magellan Triton provide additional input and feature access.

- Menu** Accesses the Main Menu
- Go To** Pages through the Navigation screens. (Press and hold to set a Go To route to a location indicated by the panning cursor.)
- Zoom In** Zooms in on the map showing less area and more details
- Zoom Out** Zooms out from the map showing more area and less detail
- Cursor Pad** Pans around the map screen
- Enter** If the cursor has been panned to a location other than your present position, accesses the create waypoint function.
- Escape** If the cursor has been panned to a location other than your present position, returns the map to be centered on your present position.

Cursors

There are two important cursors on the map screen, the Present Position cursor and the Panning cursor.



Present position cursor (Displays your position relative to the map)



Panning cursor (Displays the location on the map that would be used to create a waypoint or Go To while panning). The red dot around the panning cursor indicates the direction of your present position.

Navigation Fields

Displaying Navigation Fields

1. Tap the Optional Navigation Field pop-up icon located in the lower right hand corner of the screen.
2. Tap the Optional Navigation Field pop-up icon again to display additional navigation fields. Tap the down arrow to hide the navigational fields.

A maximum of four navigation fields can be displayed.

Changing a Navigation Field

Each navigation field can be customized to display latitude, longitude, heading, bearing, distance to next waypoint, distance to the end of a route, time to next waypoint, time to end the route, time of day, date, destination, cross track error (XTE), elevation, current speed, average speed or maximum speed.

1. Display the navigation fields.
2. Tap on the field you want to change.
3. A screen will be displayed with all of the options available. (Note that some fields are displayed with dashes. This can




be due to the data not being computed as you are not moving or the data is only displayed when a route or a Go To are active.)

Additional Navigation Screens

There are four additional navigation screens and a Satellite Status screen that can be viewed while using the Magellan Triton.


Accessing the Navigation Screens

1. Press the Page/Go To button. Each time the Page/Go To button is pressed the next navigation screen is displayed. Pressing and holding the Page/Go To button displays the Go To screen.



Current Location Screen

The Current Location Screen provides general information about your current location.




Large Data Screen

This screen allows you to display four navigation fields in a large type face that is easy to read, even from a distance.

Changing a Navigation Field

Each navigation field can be customized to display latitude, longitude, heading, bearing, distance to next waypoint, distance to the end of a route, time to next waypoint, time to complete the route, time of day, date, destination, cross track error (XTE), elevation, current speed, average speed or maximum speed.



1. Tap on the field you want to change.


A screen will be displayed with all of the options available. (Note that some fields are displayed with dashes. This can be due to the data not being computed as you are not moving or the data is only displayed when a route or a Go To are active.)

Speedometer Screen

This screen displays your current speed, your maximum speed and two odometers in a large easy-to-read type.

Resetting the Odometer or Maximum Speed

1. While viewing the Speedometer screen, press MENU.
2. Tap 'Reset Odometer', 'Reset Trip Odometer' or 'Reset Speed'.




Compass Screen

The Compass screen displays your heading using an easily identifiable compass graphic. Outside the compass the relative direction of the sun and moon is displayed. Additionally, if you have an active route, an icon representing your next destination is shown making it simple to align your heading marker (inside the compass) to your destination.

Changing a Navigation Field

Each navigation field can be customized to display latitude, longitude, heading, bearing, distance to next waypoint, distance to the end of a route, time to next waypoint, time to complete the route, time of day, date, destination, cross track error (XTE), elevation, current speed, average speed or maximum speed.

1. Tap on the field you want to change.
A screen will be displayed with all of the options available.



Calibrating the Electronic Compass

1. While viewing the Compass screen, press the MENU button.
2. Tap 'User Calibration'.
3. Place the receiver on a flat, horizontal surface away from any metal objects.
4. Tap 'Start' and follow the instructions displayed on the screen to calibrate the compass.

Calibrating the True North

1. While viewing the Compass screen, press the MENU button.
2. Tap 'True North'.
3. Tap OK and follow the instructions displayed on the screen to calibrate the compass for True North.


Satellite Status

This screen graphically displays the satellites and their signal strength that is being used to compute your location. Handy screen to view when you are getting weak to poor signal reception. There are also two navigational screens displayed at the bottom of the display.

Changing a Navigation Field

1. Tap on the field you want to change.

A screen will be displayed with all of the options available.



Using the Keypad

The Magellan Triton displays a keypad on the screen whenever data needs to be entered. Understanding the various components of the keypad will make entering data easier.

The Keypad

The keypad is used to enter names, notes, latitude, longitude or data that the user needs to enter.

Key Functions



Moves the cursor to the left.



Moves the cursor to the right.



Deletes the character to the left of the cursor.



Carriage return.



Shift key. Alternates between lower case and apercus characters.



Displays extended characters.



Displays number keypad.



Displays symbols.



Accepts the text entered and closes the screen.



Cancel any text changes and closes the screen.



Create Menu

The Create Menu is used to access the functions needed to create waypoints, trails, geocaches and routes.

Accessing the Create Menu

1. From the Map screen, press the MENU button.
2. Tap on 'Create'.



Waypoints

Creating a Waypoint

1. Access the Main Menu and tap "Create".
2. Tap "Waypoint" from the Create Menu.
3. Select "Current Location", "Point On Map", or "Coordinates".

Current Location displays the Waypoint screen with the coordinates for your present location filled in.

Point on Map displays the Map screen. Pan around the map until the pan cursor is at the point you want the waypoint created for and press ENTER. The Waypoint screen is displayed with the coordinates for the pan cursor filled in.

Coordinates displays the Waypoint screen with all values set to zero.

4. The Waypoint screen provides the fields needed to identify the waypoint and its location. The fields can be modified to customize the waypoint.

Icon: Tap the icon to display all possible icons that can be used for a waypoint. Tap the icon desired to select and close the window.

Waypoint Name: (Default "WPXXX"). Tap the waypoint name field to display the keyboard. Enter the name and tap the green button.

Location: Tapping the latitude or longitude fields brings up the keyboard that can be used to enter the coordinates.

Elevation: Tap the Elevation field to display the keyboard. Enter the elevation and tap the green button.



Add Media:  (Top center of display). Tap the add media icon to add pictures for this waypoint.

5. Tap the green check button to accept the information and save the waypoint.

Trail

Creating a Trail from Current Track History

1. Access the Main Menu and tap “Create”.
2. Tap “Trail” from the Create Menu.
3. Select “Current Track”.
4. Use the keypad to enter a name for the trail. (The default name “TrailXXX” will be used if no name entered.)
5. When the name has been entered, tap .



Geocache


Creating a Geocache

1. Access the Main Menu and tap “Create”.
2. Tap “Geocache” from the Create Menu.
3. Select “Current Location”, “Point On Map”, or “Coordinates”.

Current Location displays the Waypoint screen with the coordinates for your present location filled in.

Point on Map displays the Map screen. Pan around the map until the pan cursor is at the point you want the waypoint created for and press ENTER. The Waypoint screen is displayed with the coordinates for the pan cursor filled in.

Coordinates displays the Waypoint screen with all values set to your current location.



- The Geocache screen provides the fields needed to identify the waypoint and its location. The fields can be modified to customize the waypoint.
- Icon: Tap the icon to display all possible icons that can be used to represent the waypoint. Tap the desired icon to select and close the window.

Geocache Name: (Default "GCXXX"). Tap the waypoint name field to display the keyboard. Enter the name and tap the green button.

Location: Tap the latitude or longitude fields brings up the keyboard that can be used to enter the desired data.

Difficulty: Assign a difficulty rating to this cache.

Terrain: Indicate the type of terrain the cache is located in.

GCType: Geocache type.

Hint: Field for including hints about the cache site.

Date: Date the cache site was created.

Add Media:  (Top center of display). Tap the add media icon to add pictures for this cache site.

- Tap  to accept the information and save the cache waypoint.



Route

Creating a Route

- Access the Main Menu and tap "Create".
- Tap "Route" from the Create Menu.
- Select the starting location for the route.

Current Location displays the Waypoint screen with the coordinates for your present location filled in.

Point on Map displays the Map screen. Pan around the map until the pan cursor is at the point you want the waypoint created for and press ENTER. The Waypoint screen is displayed with the coordinates for the pan cursor filled in.

Waypoint displays a list of saved waypoints.

Geocache displays a list of saved geocache waypoints.

Place displays the categories of places (only if a detailed map is loaded).

- After selecting the starting location the Route Screen is displayed.



5. Tap “Add Point” to repeat step 3 to continue adding waypoints to the route.
6. Tap “Done” when the route is complete.
7. Tap “Save Route”.
8. The Save Route Screen is displayed.

Tap on the Route name (default “RouteXXX”) to assign a name to the route.

Tap on the alert button to turn alerts for this route on or off.
9. Tap ‘Save’ to store the route into memory.



Go To Menu

The Go To Menu is used to access the functions used to activate Go To's and saved routes.

Accessing the Go To Menu


1. From the Map screen, press the MENU button.
2. Tap on 'Go To' and the Go To Menu will be displayed.



Waypoints

Go To a Waypoint

1. Access the Main Menu and tap "Go To".
2. Tap Waypoint icon.
3. Select a waypoint from the list of saved waypoints.
4. Tap  ,
5. The Waypoint information screen is displayed.
6. If it is correct waypoint, tap  .
7. Tap  .



Editing a Waypoint

1. Access the Main Menu and tap "Go To".
2. Tap Waypoint icon.
3. Select a waypoint from the list of saved waypoints.
4. Tap  ,
5. The Waypoint information screen is displayed.
6. Tap on the field you want to edit (icon, name, location, elevation or notes).
7. Use the keyboard to enter the information.
8. Tap  .

9. Tap  to enter or modified stored media.
10. Tap  to turn waypoint alarms on or off.
11. When the information for the waypoint is correct, tap .

Deleting a Waypoint

1. Access the Main Menu and tap “Go To”.
2. Tap Waypoint icon.
3. Select a waypoint from the list of saved waypoints.
4. Tap , ,
5. Confirm deleting the waypoint by tapping .


Duplicating a Waypoint

1. Access the Main Menu and tap “Go To”.
2. Tap Waypoint icon.
3. Select a waypoint from the list of saved waypoints.
4. Tap , ,
5. The Waypoint information screen is displayed.
6. Tap .
7. Tap ‘Duplicate Waypoint’.
8. Confirm the duplication.
9. Use the keypad to enter a waypoint name.
10. Tap  when done.

Places

Creating a Go To to a Place

1. Access the Main Menu and tap “Go To”.
2. Tap “Places” from the Go To Menu.
3. Select the map to be used. (Basemaps contain limited places to select from. Detailed maps include a wide variety of points of interest to be chosen.)
4. Select a detailed map and tap  ,
5. Select a category and tap  ,
6. Select a subcategory and tap  ,
7. Select a place from the list and tap  ,
8. The Place Information screen is displayed. To activate the Go To, tap  .
9. Tap  .



Trail

Activating a Trail

1. Access the Main Menu and tap “Go To”.
2. Tap “Trail” from the Go To Menu.
3. Select a saved trail from the list and tap  .
4. The Trail Information screen is displayed.
Tap ‘View on Map’ to get a graphical view of the trail.
Tap ‘View Vertical Profile’ to get a graphical representation of the elevation levels found on the trail.
5. To activate the trail, tap  .
6. Tap  .




Deleting a Trail

1. Access the Main Menu and tap “Go To”.
2. Tap “Trail”.
3. Select a trail from the list of saved trails.
4. Tap  ,
5. Confirm deleting the waypoint by tapping  .

Duplicating a Trail

1. Access the Main Menu and tap “Go To”.
2. Tap “Trail” from the Go To Menu.
3. Select a saved trail from the list and tap  ,
4. The Trail Information screen is displayed.
5. Tap  .
6. Tap ‘Duplicate Trail’.
7. Use the keypad to enter a name for the trail.
8. Tap  .



Geocache

Creating a Geocache Go To

1. Access the Main Menu and tap “Go To”.
2. Tap “Geocache” from the Go To Menu.
3. Select a saved geocache waypoint from the list and tap  ,
4. The Geocache Information screen provides the fields needed to identify the waypoint and its location. The fields can be modified to customize the waypoint.

Icon: Tap the icon to display all possible icons that can be used for a waypoint. Tap the icon desired to select and close the window.

Geocache Name: (Default “GCXXX”). Tap the waypoint name field to display the keyboard. Enter the name and tap the green button.

Location: Tapping the latitude or longitude fields brings up the keyboard that can be used to enter the desired data.

Elevation: Tap the Elevation field to display the keyboard. Enter the elevation and tap the green button.

Difficulty: Assign a difficulty rating to this cache.

Terrain: Indicate the type of terrain the cache is located in.

GCType: Geocache type.

Hint: Field for including hints about the cache site.

Hider: Name of the person that originated the cache site.

Date: Date the cache site was created.

Add Media:  (Top center of display). Tap the add media icon to add pictures for this cache site.

5. To activate the Go To, tap  .
6. Tap  .

Deleting a Geocache Waypoint

1. Access the Main Menu and tap “Go To”.
2. Tap the ‘Geocache’ icon.
3. Select a geocache waypoint from the list of geocache waypoints.
4. Tap  ,
5. Confirm deleting the waypoint by tapping  .

Duplicating a Geocache

1. Access the Main Menu and tap “Go To”.
2. Tap “Geocache” from the Go To Menu.
3. Select a saved geocache waypoint from the list and tap  ,
4. The Geocache Information screen is displayed.
5. Tap  .
6. Tap ‘Duplicate Geocache’
7. Tap  .

Route

Activating a Route

1. Access the Main Menu and tap “Go To”.
2. Tap “Route” from the Go To Menu.
3. Select a saved route,
4. To activate the route, tap  ,
5. Tap  .

Editing a Route

1. Access the Main Menu and tap “Go To”.
2. Tap “Route” from the Go To Menu.
3. Select a saved route,
4. Tap  .
5. Tap  to save the route.

Duplicating a Route

1. Access the Main Menu and tap “Go To”.
2. Tap “Route” from the Go To Menu.
3. Select a saved route,
4. Tap  .
5. Tap ‘Duplicate Route’.
6. Tap  to confirm.
7. Use the keypad to enter a new route name and tap  .
8. Tap  to save the route.

Deleting a Route

1. Access the Main Menu and tap “Go To”.
2. Tap “Route” from the Go To Menu.
3. Select a saved route,



4. Tap  .
5. Tap 'Delete Route'.
6. Tap  to confirm.

View Menu

Local Info

The Local Info option provides a way of viewing tide and current information (if a detailed map has been installed with tide and current information), best fishing and hunting times, and sunrise/sunset/lunar information.


Viewing Best Fishing and Hunting Times for Current Location

1. Access the Main Menu and tap “View”.
2. Tap ‘Fish And Hunt’.
3. The Fish and Hunt screen is displayed for your current location.
4. Use the left and right arrows to change the date or tap in the date field to open a calendar.
5. Tap  to close the screen.



Viewing Sunrise, Sunset Times and Lunar Information for Current Location

1. Access the Main Menu and tap “View”.
2. Tap ‘Sun And Moon’.
3. The Sun and Mood screen is displayed for your current location.
4. Use the left and right arrows to change the date or tap on the date field to open a calendar.
5. Tap  to close the screen.



User Profiles

You can set user profiles for various operations of the Magellan Triton that can be loaded easily.

Activating User Profiles

1. Access the Main Menu and tap “View”.
2. Tap ‘Profiles’.
3. Select Hiking, Marine, or Geocaching.
4. Tap  to access the display options.
Tap  to access the map options.
Tap  to access the navigation options.
Tap  to access the alert options.

Display options

BackLight Level	Off, Low, Medium, High	Decreasing backlight levels will increase battery life.
Backlight Timer	Off, 15 sec, 30 sec, 60 sec	Sets duration of no GPS or screen activity before the backlight turns off
Power Off Timer	Off, 5 min, 15 Min, 60 min	Sets duration of no GPS or screen activity before the receiver turns off in sleep mode.
Touchscreen Lock	Off, 1 min, 5 min, 10 min	
Time Format	12 hour or 24 hour	
Time Zone	Select zone	
Daylight Savings	On or Off	
Language	English or French	

Map options

Map Detail	Low, Medium, High	
Waypoint Names	On or Off	Displays waypoint names on the map screen
Geocache Icons	Not Found, All, Off	Displays geocache waypoint icons on the map screen
Place Names	On or Off	Displays names of waypoints stored in the receiver as places
Places Shown	List of possible places	Select from list of places which ones are to be displayed on the map screen
Trail Lines	On or Off	Display of trail (track) lines on the map screen
Orientation	North, Course, Track	Sets orientation for the top of the display
Position Destination Line	On or Off	Display of the Line of Sight (LOS) line from your current position to your destination

Navigation options

Electronic Compass	On or Off
Barometer	On or Off

Alert options

GPS Fix	On or Off
Alarm Clock	Set time for alarm
Alarm Tone	Beep or Ring
Alarm Volume	Off, Low, Medium, High

Beeper Volume	Off, Low, Medium, High
Beeper Mode	Keys, Alarms, Keys & Alarms, Off
Anchor	Off, 1 mi, 0.5 mi
Off Course	Off, 10 ft, 20 ft
Arrival	On or Off
Route Proximity	Off, 1 mi, 0.5 mi
Trail Proximity	Off, 1 mi, 0.5 mi
Waypoint Proximity	Off, 1 mi, 0.5 mi
Geocache Proximity	Off, 1 mi, 0.5 mi
Place Proximity	Off, 1 mi, 0.5 mi
Low Battery	On or Off

Tracks

Viewing Track Vertical Profile

1. Access the Main Menu and tap “View”.
2. Tap Track.
3. Tap Vertical Profile.
4. With a current track in memory, the vertical profile is displayed.

Saving a Track as a Trail

1. Access the Main Menu and tap “View”.
2. Tap Track.
3. Tap Save Track.
4. Select which track to create a trail from.
5. Use the keyboard to enter a name for the trail. (Default name is TrailXXX.) Tap  to save the trail with the name entered.

Erasing a Track

1. Access the Main Menu and tap “View”.
2. Tap Track.
3. Tap Erase Track.

4. Tap  to confirm deletion.

Setting Track Log Options

1. Access the Main Menu and tap “View”.
2. Tap Track.
3. Tap Options.
4. Select parameters for if and how track logs are recorded.
5. Tap  to accept.

Maps

Viewing Map Information

1. Access the Main Menu and tap “View”.
2. Tap Maps to view details on the installed background map and detail map (if loaded).
3. Tap OK to exit.

Media

Viewing Stored Media

1. Access the Main Menu and tap “View”.
2. Tap Media to view images stored on an optional SD card.


Settings

Navigation

Setting Navigation Options

1. Access the Main Menu and tap “View”.
2. Tap Settings.
3. Tap Navigation.

Units (of Measure)	Miles, Kilometers, Knots
North Reference	Magnetic or True
Coordinate system	Lat/Lon (DD), Lat/Lon (DM), Lat/Lon (DMS), UTM
Map Datum	Select from list.



Volume & Brightness

Setting Volume & Brightness

1. Access the Main Menu and tap “View”.
2. Tap Settings.
3. Tap Volume & Brightness.
4. Tap on the slider bars to set the display brightness and alarm volume.
5. Tap OK to accept.

Memory

View Memory Usage

1. Access the Main Menu and tap “View”.
2. Tap Settings.
3. Tap Memory.
4. Tap View Usage.

Clearing Memory

1. Access the Main Menu and tap “View”.
2. Tap Settings.

3. Tap Clear Memory.
4. Confirm. (Use this option with caution.)

Restoring Factory Settings

1. Access the Main Menu and tap “View”.
2. Tap Settings.
3. Tap Restore Factory Settings.
4. Confirm.

Formatting SD Card

1. Access the Main Menu and tap “View”.
2. Tap Settings.
3. Install SD card to be formatted.
4. Tap Format SD Card.
5. Confirm. (This will erase all information on the SD card.)

About

Displaying Information About the Triton Receiver

1. Access the Main Menu and tap “View”.
2. Tap Settings.
3. Tap About.
4. Tap Version, Copyright, or Owner.

Version displays information about the firmware version, application versions and map versions.

Copyright displays copyright information for the Magellan Triton.

Owner displays information about the owner of the Magellan Triton. You can tap on any of the fields available to enter your details if desired.

Diagnostics

Testing the touchscreen display

1. Access the Main Menu and tap “View”.
2. Tap Settings.
3. Tap Diagnostics.
4. Tap on the black icon displayed on the screen each time it is displayed.