

### **DIGITAL HOME THEATER SYSTEM**

**HT-P10** 

**HT-P11** 

HT-TP12

### **Instruction Manual**

















THIS APPLIANCE IS MANUFACTURED BY:



# Safety Warnings

CLASS 1 LASER PRODUCT KLASSE 1 LASER PRODUKT LUOKAN 1 LASER LAITE KLASS 1 LASER APPARAT PRODUCTO LASER CLASE 1



#### CAUTION:

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE REAR COVER. NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

#### **CLASS 1 LASER PRODUCT**

This Compact Disc player is classified as a CLASS 1 LASER product.

Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

# CAUTION-INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED, AVOID EXPOSURE TO BEAM.



This symbol indicates that dangerous voltage which can cause electric shock is present inside this unit.





This symbol alerts you to important operating and maintenance instructions accompanying the unit.

**WARNING:** To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.


CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH
WIDE BLADE OF PLUG TO WIDE SLOT, FULLY
INSERT.

### **Precautions**






Ensure that the AC power supply in your house complies with the identification sticker located on the back of your player. Install your player horizontally, on a suitable base (furniture), with enough space around it for ventilation (3-4inches). Make sure the ventilation slots are not covered. Do not stack anything on top of the player. Do not place the player on amplifiers or other equipment which may become hot. Before moving the player, ensure the disc tray is empty. This player is designed for continuous use. Switching off the DVD player to the stand-by mode does not disconnect the electrical supply. In order to disconnect the player completely from the power supply, remove the main plug from the wall outlet, especially when left unused for a long period of time.



During thunderstorms, disconnect AC main plug from the wall outlet.

Voltage peaks due to lightning could damage the unit.



Do not expose the unit to direct sunlight or other heat sources.

This could lead to overheating and malfunction of the unit.




Protect the player from moisture(i.e. vases), and excess heat(e.g.fireplace) or equipment creating strong magnetic or electric fields (i.e. speakers...). Disconnect the power cable from the AC supply if the player malfunctions. Your player is not intended for industrial use.

Use of this product is for personal use only.

Condensation may occur if your player or disc have been stored in cold temperatures

If transporting the player during the winter, wait approximately 2 hours until the unit has reached room temperature before using.



The battery used with this product contain chemicals that are harmful to the environment.

Do not dispose of batteries in the general household trash.

# **Features**

#### Multi-Disc Playback & FM /AM Tuner

The HT-P10/HT-P11/HT-TP12 combines the convenience of multi-disc playback capability, including DVD, VCD, CD, MP3-CD, CD-R/RW, and DVD-R/RW, with a sophisticated FM/AM tuner, all in a single player.

#### ODolby Pro Logic II

Dolby Pro Logic II is a new form of multi-channel audio signal decoding technology that improves upon existing Dolby Pro Logic.

### **DTS (Digital Theater Systems)**

DTS is an audio compression format developed by Digital Theater Systems Inc. It delivers full-frequency 5.1 channel sound.

#### **TV Screen Saver Function**

The HT-P10/HT-P11/HT-TP12 automatically brightens and darkens the brightness of the TV screen after 3 minutes in the stop mode. The HT-P10/HT-P11/HT-TP12 automatically switches itself into the power saving mode after 20 minutes in the screen saver mode.

#### Power Saving Function

The HT-P10/HT-P11/HT-TP12 automatically shuts itself off after 20 minutes in the stop mode.

### Customized TV Screen Display

The HT-P10/HT-P11/HT-TP12 allows you to select your favorite image during JPEG, DVD or VCD playback and set it as your background

# **Contents**

0	PREPARATION	
_	Safety Warnings	1
	Precautions	
	Features	
	Notes on Discs	
	Description	
	CONNECTIONS	
_	Connecting the Speakers	4
	Connecting the Video Out to TV.	
	P.SCAN(Progressive Scan) Function	
	Connecting External Component	1
	Connecting External Component	
	Connecting the 1 M Articinia	
0	OPERATION	
<u></u>	·· =	
	Disc Playback	
	MP3-CD Playback	
	DivX Playback	
	JPEG File Playback	
	Displaying Disc Information	
	Skipping Scenes/Songs	
	Repeat Playback	
	A-B Repeat Playback	
	Step Function	
	Angle Function	
	Zoom (Screen Enlarge) Function	
	EZ VIEW Function	2
	Selecting Audio/Subtitle Language	
	Moving Directly to a Scene/Song	
	Using Disc Menu.	
	Using the Title Menu	
0	SETUP	
8	Setting the Language	3
	Setting TV Screen type	
	Setting Parental Controls (Rating Level)	
	Setting the Password	
	Setting the Wallpaper	3
	Setting the Speaker Mode	
	Setting the Test Tone	4
	Setting the Delay Time	4
	Setting the Audio Quality	4
	Setting the DRC (Dynamic Range Compression)	
	AV SYNC Setup	
	Dolby Pro Logic II Mode	
	Dolby Pro Logic II Effect	
	Sound Field (DSP)/EQ Function	
	Sleep Timer Function	
	Adjusting Display Brightness	
	Mute Function	5
	Listening to Radio	5
	Presetting Stations	5
	MISCELLANEOUS	
_	Language Code List	
	Cautions on Handling and Storing Discs	
	Cautions on Handling and Storing Discs	5

### Notes on Discs



**DVD (Digital Versatile Disc)** offers fantastic audio and video, thanks to Dolby Digital surround sound and MPEG-2 video compression technology. Now you can enjoy these realistic effects in the home, as if you were in a movie theater or concert hall.





DVD players and the discs are coded by region. These regional codes must match in order for the disc to play. If the codes do not match, the disc will not play.

The Region Number for this player is given on the rear panel of the player. (Your DVD player will only play DVDs that are labeled with identical region codes.)

### Playable Discs

Disc Type	Mark (Logo)	Recorded Signals	Disc Size	Max. Playing Time
			12cm	Approx. 240 min. (single-sided)
חעם	DVD Audio + Video	12011	Approx. 480 min. (double-sided)	
DVD		Addio + Video	8cm	Approx. 80 min. (single-sided)
				Approx. 160 min. (double-sided)
VIDEO-CD	/IDEO-CD	Audio + Video	12cm	74 min.
VIDEO-CD			8cm	20 min.
41 IDIO 0D	AUDIO-CD	Audio	12cm	74 min.
AUDIO-CD			8cm	20 min.



### Do not use the following types of disc!

- LD, CD-G, CD-I, CD-ROM and DVD-ROM cannot be played on this player.
   If such discs are played, a "WRONG DISC FORMAT" message appears on the TV screen.
- DVD discs purchased abroad may not play on this player.
   If such discs are played, a "WRONG REGION CODE" message appears on the TV screen.

### **Copy Protection**

- Many DVD discs are encoded with copy protection. Because of this, you should only connect
  your DVD player directly to your TV, not to a VCR. Connecting to a VCR results in a distorted picture from copy-protected DVD discs.
- This product incorporates copyright protection technology that is protected by methods claims of certain
  U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights
  owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and
  is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision
  Corporation. Reverse engineering or disassembly is prohibited.

#### **Disc Recording Format**

#### **CD-R Discs**

- Some CD-R discs may not be playable depending on the disc recording device (CD-Recorder or PC) and the condition of the disc.
- Use a 650MB/74 minute CD-R disc.
- Do not use CD-R disk over 700MB/80 minute as much as possible since it may not be played back.
- Some CD-RW (Rewritable) media, may not be playable.
- Only CD-Rs that are properly "closed" can be fully played. If the session is closed but the disc is left open, you
  may not be able to fully play the disc.

#### CD-R MP3 Discs


- Only CD-R discs with MP3 files in ISO 9660 or Joliet format can be played.
- MP3 file names should be 8 characters or less in length and contain no blank spaces or special characters (. / = +).
- Use discs recorded with a compression/decompression data rate greater than 128Kbps.
- Only files with the ".mp3" and ".MP3" extensions can be played.
- Only a consecutively written Multisession disc can be played. If there is a blank segment in the Multisession disc, the disc can be played only up to the blank segment.
- If the disc is not closed, it will take longer to begin playback and not all of the recorded files may be played.
- For files encoded in Variable Bit Rate (VBR) format, i.e. files encoded in both low bit rate and high bit rate (e.g., 32Kbps ~ 320Kbps), the sound may skip during playback.
- A maximum of 500 tracks can be played per CD.
- A maximum of 300 folders can be played per CD.

#### **CD-R JPEG Discs**

- Only files with the ".jpeg" and ".JPEG" extensions can be played.
- If the disc is not closed, it will take longer to start playing and not all of the recorded files may be played.
- Only CD-R discs with JPEG files in ISO 9660 or Joliet format can be played.
- JPEG file names should be 8 characters or less in length and contain no blank spaces or special characters (. / = +).
- Only a consecutively written multisession disc can be played. If there is a blank segment in the multisession disc, the
  disc can be played only up to the blank segment.
- A maximum of 9,999 images can be stored on a single CD.
- When playing a Kodak/Fuji Picture CD, only the JPEG files in the picture folder can be played.
- Picture discs other than Kodak/Fuii Picture CDs may take longer to start playing or may not play at all.


# **Description**

### -Front Panel-




#### P.SCAN indicator **DOLBY DIGITAL indicator DTS Disc indicator REPEAT indicator** LINEAR PCM indicator **PBC** indicator **TITLE indicator TUNER** indicator **GROUP** indicator **CHAPTER** indicator STEREO indicator **TRACK** indicator **PROGRAM** indicator P.SCAN LPCM TITLE GRP CHAP TRK PRGM REP.1 PBC TUNED ST LCR DIDIGITAL des DSP (SW) DOPLII MPEG kHz MHz LS S RS DVD AUDIO DSP indicator MPEG indicator RADIO FREQUENCY indicator **DVD AUDIO indicator** System Status Display PRO LOGIC indicator SPEAKER indicator

### -Rear Panel-




### **Accessories**



# Description

### -Remote Control-




#### **Insert Remote Batteries**


Remove the battery cover on the back of the remote by pressing down and sliding the cover in the direction of the arrow.



- 2 Insert two 1.5V AAA batteries, paying attention to the correct polarities (+ and –).
  - rect

cover.





Replace the battery

#### Caution

#### Follow these precautions to avoid leaking or cracking cells:

- Place batteries in the remote control so they match the polarity:(+) to (+)and (-)to (-).
- Use the correct type of batteries. Batteries that look similar may differ in voltage.
- Always replace both batteries at the same time.
- Do not expose batteries to heat or flame.


#### **Range of Operation of the Remote Control**

The remote control can be used up to approximately 23 feet/7 meters in a straight line. It can also be operated at a horizontal angle of up to 30° from the remote control sensor.



# Connecting the Speakers

Before moving or installing the product, be sure to turn off the power and disconnect the power cord.



#### Position of the DVD Player

 Place it on a stand or cabinet shelf, or under the TV stand.

### Front Speakers **LB**

- Place these speakers in front of your listening position, facing inwards (about 45°) toward you.
- Place the speakers so that their tweeters will be at the same height as your ear.
- Align the front face of the front speakers with the front face of the center speaker or place them slightly in front of the center speakers.

#### Center Speaker C

- It is best to install it at the same height as the front speakers.
- You can also install it directly over or under the TV.

#### **Selecting the Listening Position**


The listening position should be located about 2.5 to 3 times the distance of the TV's screen size away from the TV. Example: For 32" TVs 2-2.4m (6-8feet)
For 55" TVs 3.5-4m (11-13feet)

### Rear Speakers (S) (B)


- Place these speakers behind your listening position.
- If there isn't enough room, place these speakers to face each other.
- Place them about 60 to 90cm (2 to 3feet) above your ear, facing slightly downward.
  - ★ Unlike the front and center speakers, the rear speakers are used to handle mainly sound effects and sound will not come from them all the time.

#### Subwoofer W

- The position of the subwoofer is not so critical.
   Place it anywhere you like.
- Usually, it is placed by a corner near the front speakers.



- Press and hold the terminal tab.
- 2 Insert the speaker cord.
- 3 Release the finger.






Connect the red cord to the red (+) terminal and the black cord to the black (-) terminal.

# Connecting the Video Out to TV

Choose one of the three methods for connecting to a TV.



#### METHOD 1 Composite Video ...... Good Quality

Connect the supplied video cable from the VIDEO OUT jack on the back panel of the system to the VIDEO IN jack on your television.

### METHOD 2 Component (Progressive Scan) Video ..... Better Quality

If your television is equipped with Component Video inputs, connect a component video cable (not supplied) from the Pr, Pb and Y jacks on the back panel of the system to the corresponding jacks on your television.



When the Progressive scan mode is selected, the VIDEO output do not feed any signal.

# P.SCAN(Progressive Scan) Function

Unlike regular Interlace Scan, in which two fields of picture information alternate to create the entire picture (odd scan lines, then even scan lines), Progressive Scan uses one field of information (all lines displayed in one pass) to create a clear and detailed picture without visible scan lines.

#### 1 Press STOP button.

• When disc is played back, press the STOP button twice so that "STOP", appears on the display.

#### 2 Press and hold P.SCAN button on the remote control for over 5 seconds.

- Pressing and holding the button for over 5 seconds will select "Progressive Scan" and "Interlace Scan" repetitively.
- When you select P.SCAN, "P.SCAN" will appear on the display

#### What is Progressive (or Non-Interlaced) Scanning?

#### Interlaced Scan (1 FRAME = 2 FIELDS) **Progressive Scan (FULL FRAME)** In interlaced-scan video, a frame consists of two inter-The progressive scanning method scans one full frame of laced fields (odd and even), where each field contains video consecutively down the screen, line by line. every other horizontal line in the frame. An entire image is drawn at one time, as opposed to the The odd field of alternating lines is displayed first, and interlaced scanning process by which a video image is then the even field is displayed to fill in the alternating drawn in a series of passes. gaps left by the odd field to form a single frame. The progressive scanning method is desirable for dealing One frame, displayed every 1/30th of a second, contains with moving objects. two interfaced fields, thus a total of 60 fields are displayed every 1/60th of a second.

#### Note

a still object.


The interlaced scanning method is intended for capturing

- This function works only on TVs equipped with component video inputs (Y, Pr, Pb) that support Progressive Video. (It does not work on TVs with conventional component inputs, i.e., non-progressive scan TVs.)
- Depending on the brand and model of your TV, this function may not work.

# Connecting External Component


### **Connecting an External Analog Component**

Example: Analog signal components such as a VCR or TV.



- 1 Connect Audio In on the DVD player to Audio Out on the external analog component.
  - Be sure to match connector colors.
- **2** Press **AUX** on the remote control to select AUX.
  - You can also use the **FUNCTION** button on the main unit.
     The mode switches as follows: DVD/CD → AUX → FM→ AM.

# **Connecting the FM Antenna**



#### FM antenna connection


- 1. Connect the FM antenna supplied to the FM 75Ω COAXIAL terminal.
- Slowly move the antenna wire around until you find a location where reception is good, then fasten it to a wall or other rigid surface.

#### AM antenna connection

- 1. Connect the AM loop antenna supplied to the AM and # terminals.
  - Insert the black wire into the black terminal and the white wire into the white terminal.
- If reception is poor, connect an outdoor single vinyl-covered wire to the AM terminal. (Keep the AM loop antenna connected).

#### Cooling Fan

The cooling fan supplies cool air to the unit to prevent overheating.



Please observe the following cautions for your safety.

- Make sure the unit is well-ventilated. If the unit has poor ventilation, the temperature inside the unit could rise and may damage it.
- Do not obstruct the cooling fan or ventilation holes. (If the cooling fan or ventilation holes are covered with a newspaper or cloth, heat may build up inside the unit and fire may result.)

OPERATION

# Disc Playback

Press OPEN/ **CLOSE** button to open the disc tray.

Load a disc.

• Place a disc gently into the trav with the disc's label facing up.

Press OPEN/ **CLOSE** button to close the disc trav.







· Playback starts automatically.

### Note

• Depending on the content of the disc, the initial screen may appear different.

### To stop playback, press STOP during playback.

- If pressed once, "PRESS PLAY" is displayed and the stop position will be stored in memory. If PLAY/PAUSE ( \( \bigcup \lambda \rightarrow \righta (This function works only with DVDs.)
- If pressed twice, "STOP" is displayed, and if PLAY/PAUSE (►/II) button is pressed, playback starts from the beginning.

### To temporarily pause playback, press **PLAY/PAUSE** during playback.

To resume playback, press PLAY/PAUSE (►/II) button again.

### Selecting the Video Format

Press and hold NT/PAL button on the remote controller for over 5 seconds while the power is turned off.

- By default, the video format is set to "PAL".
- "NTSC" or "PAL" will appear in the display.

At this time, press the NT/PAL button shortly to select between "NTSC" and "PAL".


- Each country has a different video format standard.
- For normal playback, the video format of the disc must be the same as the video format of your TV.

# **MP3-CD Playback**

Data CDs (CD-ROM, CD-R, CD-RW) encoded in MP3 format can be played.



(lacktriangle)



- The MP3 menu screen will appear and playback will start.
- The appearance of the menu depends on the MP3 disc.



In Stop mode, use ◆ ▶ ▲ ▼ to select the album, and then press the ENTER button.



- To change the album, use ◀ ▶ ▲ ▼ to select another album in Stop mode, and then press the **ENTER** button.
- To select another album and track, repeat Steps 2 and 3 above.

Press the STOP button to stop playback.

- Depending on the recording mode, some MP3-CDs may not play.
- Table of contents of a MP3-CD varies depending on the MP3 track format recorded on the disc.
- MP3 file support: MPEG1 LAYER3 (BITRATE: 128KBPS~320KBPS: SAMPLEING FREQ.: 32K/44.1K/48KHz)

# OPERATION

# DivX Playback

### Skip Forward/Back

#### During playback, press the I◀◀ ▶►I button.

- Go to the next file whenever you press button, if there are over
- Go to the previous file whenever you press ► button, if there are over 2 files in the disk.

### Fast playback

To play back the disc at a faster speed, press and hold ◄ or ▶ during playback.

• Each time you press and hold either button, the playback speed will change as follows:

 $2x \rightarrow 4x \rightarrow 8x \rightarrow 32x \rightarrow Normal.$ 

### ■ 5 Minute Skip function

During playback, press the ◀ ,▶ button.

- Go to the screen about 5 minutes after whenever you press ▶ button.
- Go to the screen about 5 minutes earlier whenever you press ■ button.

### Zoom Function


Press **ZOOM** button.

• Each time you press the button, your selection will toggle between "ZOOM X2" and "ZOOM OFF".

Press Cursor ▲ ,▼ . ◆ .▶ buttons to move to the area

you want to enlarge.

### • DIVX file can be zoomed only in ZOOM X2 mode.



### Subtitle Display

#### Press the **SUBTITLE** button.

- Each time you press the button, your selection will toggle between "SUBTITLE ON" (1/1, 1/2 ...) and
- If the disc has only one subtitle file, it will be played automatically.

### Audio Display

#### Press the **AUDIO** button.

• Each time you press the button, your selection will toggle between "AUDIO ON" (1/1, 1/2 ...) and "

" is displayed when there is one supported audio item in the disc.

#### **DivX**(Digital internet video express)

DivX is a video file format developed by Microsoft based on the MPEG4 so as to provide audio, and video data over the Internet in real-time.

MPEG4 is used for video encoding and MP3 for audio encoding so that the users can watch a movie in DVD-quality video and audio.

#### 1. Supported Formats

• This product only provides the following media formats. If both of the video and audio formats are not supported simultaneously, the user may experience problems such as broken image or no sound.

#### Supported Video Formats

Format	AVI	WMA
Surpported Versions	DivX3.11 ~ 5.1	V1/V2/V3/V7

#### Supported Audio Format

Format	MP3	WMA	AC3	DTS
Bit Rate	80~384kbps	56~128kbps	128~384kbps	N/A
Sampling Frequency	44.	1khz	44.1/48khz	N/A

• Aspect Ratio: Although default DivX resolution is 640\*480 pixels (4:3), this product supports up to 720\*480 pixels (16:9). It will not be supported when the screen resolution is higher than 800.

#### 2. Caption Related

• To use the caption function, save the caption file (\*.smi) in the same file name as that of the DivX media file (\*.avi) within the same folder.

Example. Root Samsung\_Bluetek\_007CD1.avi

Samsung\_Bluetek\_007CD1.smi


• Up to 60 alphanumeric characters or 30 East Asian characters (2 byte characters such as Korean and Chinese) for the file name.


# JPEG File Playback

Images captured with a digital camera or camcorder, or JPEG files on a PC can be stored on a CD and then played back with this DVD player.

# Press the **OPEN/CLOSE** button to open the disc tray, and then load the JPEG disc.

 Playback will start automatically and each image will show for 5 seconds before moving to the next image.






# **Displaying Disc Information**

You can view disc playback information on the TV screen.

#### Press INFO button.

• Each time the button is pressed, the display changes as follows:




# **Checking the Remaining Time**

#### Press the REMAIN button.

• For checking the total and remaining time of a title or chapter being played.

#### Each time the REMAIN button is pressed




# Fast/Slow Playback

### Fast Playback



#### Press and hold I◀◀ ▶▶I.


• Each time the button is held down during playback, the playback speed changes as follows:



### Slow Playback

#### Press SLOW button.

 Each time the button is pressed during playback, the playback speed changes as follows:




# Skipping Scenes/Songs

#### Briefly press ◄< ►►

- Each time the button is pressed briefly during playback, the previous or next chapter, track, or directory (file) will be played.
- · You cannot skip chapters consecutively.










# Repeat Playback

Repeat playback allows you to repeatedly play a chapter, title, track (song), or directory (MP3 file).



#### Press **REPEAT** button.

• Each time the button is pressed during playback, the repeat playback mode changes as follows:



#### Repeat Playback Options

#### CHAPTER

Repeatedly plays the selected chapter.

#### TITLE

Repeatedly plays the selected title.

#### RANDOM

Plays tracks in random order.

(A track that has already been played may be played again.)

#### RACK

Repeatedly plays the selected track.

#### DIR


Repeatedly plays all tracks in the selected folder.

#### DISC

Repeatedly plays the entire disc.

#### ~==

Cancels Repeat Playback.



#### Note

 Repeat playback operation is not possible with version 2.0 VCD discs if PBC is turned on. To use Repeat Playback on a VCD with PBC, you should set the PBC to OFF in the disc menu. (See page 30.)

### GE

You can repetitively play back a designated section of a DVD.



Press **INFO** button twice.

 For a VCD or CD, press INFO button once.

DVD ₽ EN 1/3 📭 🕞 OFF/ 02 🗘 OFF

Press Cursor ▶ button to move to REPEAT PLAYBACK (♣) display.

DVD EN 1/3 ROWN ... OFF/ 02 C) OFF

Press Cursor ▲, ▼ buttons to select 'A-' and then press ENTER button at the beginning of the desired segment.

 When ENTER button is pressed, the selected position will be stored in memory.



Press ENTER
button at the end
of the desired
segment.

 The specified segment will be played repeatedly.



To return to normal playback, press Cursor ▲ ,▼ buttons to select �� OFF.



• The A-B Repeat function will not work on an MP3 or JPEG disc.

# 

### Press **STEP** button.

 The picture moves forward one frame each time the button is pressed during playback.



- During fast playback of a CD or MP3-CD, sound is heard only at 2x speed, and not at 4x. 8x, and 32x speeds.
- No sound is heard during slow playback and step motion playback.



# **Angle Function**

This function allows you to view the same scene in different angles.



Press Cursor ► button to move to ANGLE ( (८) display.



Press Cursor ▲,▼ or numeric buttons to select the desired angle.

• Each time the button is pressed, the angle changes as follows:










Note

 The Angle function works only with discs on which multiple angles have been recorded.



# Zoom (Screen Enlarge) Function

This function allows you to enlarge a particular area of the displayed image.





Press **ZOOM** button.




Press Cursor ▲ .▼. ◆ .▶ buttons to move to the area you want to enlarge.



Press ENTER button.

• Each time the button is pressed, the zoom level changes as follows:



# **EZ VIEW Function**



#### Press **EZ VIEW** button.

- Each time the button is pressed, the zoom function will switch between On
- When a movie is played in Widescreen format, black bars at the top and bottom of the TV screen can be removed by pressing the EZ VIEW button.




### Note

- This function will not work if the DVD is recorded with multi-camera angle format
- Black bars may not disappear because some DVD discs have a built-in horizontal to vertical ratio.

# **Selecting Audio/Subtitle Language**

### Audio Language Selection Function



 You can use the AUDIO button on the remote control to select a audio language.

### ■ Subtitle Language Selection Function DVD



Press Cursor ▶ button to move to SUBTITLE (□) display.



Press Cursor ▼ button or numeric buttons to select the desired subtitle.



#### Note

- You can use the SUBTITLE button on the remote control to select a subtitle language.
- Depending on the disc, the Subtitle and Audio Language functions may not work

OPERATION

# Moving Directly to a Scene/Song



Press **INFO** button.



### Moving to a Title/Track

Press Cursor ▲ ,▼ buttons or numeric buttons to select the desired title/track and then press ENTER button.



### Moving to a Chapter

Press Cursor ◀, ► buttons to move to Chapter (♠) display.



#### Moving to a Chapter

Press Cursor , , buttons or numeric buttons to select the desired chapter and then press ENTER button.



#### Moving to a Specific Time

Press Cursor ◀, ► buttons to move to time display.



### Moving to a Specific Time

Press the numeric buttons to select the desired time and then press **ENTER** button.



### MP3 JPEG

### Press the **numeric** buttons.

- The selected file will be played.
- An MP3 or JPEG disc cannot be moved from the disc information screen.
- When playing an MP3 or JPEG disc, you cannot use ▲ ,▼ to move a folder.
   To move a folder, press (Stop) and then press ▲ ,▼ .



#### Note

- You can press I◄◄►► on the remote control to move directly to the desired title, chapter, or track.
- Depending on the disc, you may not be able to move to the selected title or time.

# Using Disc Menu 👁

You can use the menus for the audio language, subtitle language, profile, etc. DVD menu contents differ from disc to disc.

In Stop mode, press **MENU** button.

 When playing a VCD (version 2.), this toggles between PBC ON and OFF.



- Press Cursor ▲,▼
  buttons to move to
  'DISC MENU' and then
  press ENTER button.
- When you select the disc menu that is not supported by the disc, the "This menu is not supported" message appears on the screen.



- Press Cursor ▲,▼

  ◀, ▶ buttons to select the desired item.
- Press ENTER button.



### Note

#### PBC (Playback Control) Function

When playing a VCD (version 2.0), you can select and view various scenes according to the menu screen.

**PBC ON:** This VCD disc is version 2.0. The disc is played back according to the menu screen. Some functions may be disabled. When some functions are disabled, select "PBC OFF" to enable them.

PBC OFF: This VCD disc is version 1.1. The disc is played back in the same way as with a music CD.

# Using the Title Menu •••

For DVDs containing multiple titles, you can view the title of each movie. Depending on the disc, the availability of this feature may vary.

In Stop mode, press **MENU** button.



Press Cursor ▲ ,▼ button to move to 'Title Menu'.



Press ENTER button.


The title menu appears.



Press **MENU** button to exit the setup screen.

# Setting the Language

OSD (On-Screen Display) language is set to English by default.



In Stop mode, press **MENU** button.

Press Cursor ▼ button to move to 'Setup' and then press ENTER button.



3 Select 'Language' and then press ENTER button



Press Cursor ▲ ,▼
button to select 'OSD
Language' and then
press ENTER button.



Press Cursor A, V
button to select the
desired language and then
press ENTER button.

 Once the setup is complete, if the language was set to English, OSD will be displayed in English.



Press **RETURN** button to return to the previous level.

Press MENU button to exit the setup screen.

Note

 To select other language, select OTHER and enter the language code of your country. (See 53 page for language code of countries)
 AUDIO, SUB TITLE and DISC MENU language can be selected.





Selecting the OSD Language



Selecting the Audio Language (recorded on the disc)



Selecting the Subtitle Language (recorded on the disc)




Selecting the Disc Menu Language (recorded on the disc)

\* If the language you selected is not recorded on the disc, menu language will not change even if you set it to your desired language.

# **Setting TV Screen type**

Depending on your TV type (Wide Screen TV or conventional 4:3 TV), you can select the TV's aspect ratio.



In Stop mode, press MENU button.



Press Cursor ▼
button to move to
'Setup' and then
press ENTER button.



Press Cursor ▼
button to move to 'TV
DISPLAY' and then
press ENTER button.



Press Cursor ▲,▼
button to select the
desired item and then
press ENTER button.

• Once the setup is complete, you will be taken to the previous screen.



### Adjusting the TV Aspect Ratio (Screen Size)

The horizontal to vertical screen size ratio of conventional TVs is 4:3, while that of widescreen and high definition TVs is 16:9. This ratio is called the aspect ratio. When playing DVDs recorded in different screen size, you should adjust the aspect ratio to fit your TV or monitor.

\* For a standard TV, select either "4:3LB" or "4:3PS" option according to personal preference. Select "16:9" if you have a widescreen TV.

WIDE

- : Select this to view a 16:9 picture in the full-screen mode on your widescreen TV.
- · You can enjoy the widescreen aspect.



4:3LB (4:3 Letterbox)

- : Select this to play a 16:9 picture in the letter box mode on a conventional TV.
- · Black bars will appear at the top and bottom of the screen.



4:3PS (4:3 Pan&Scan)

- : Select this to play a 16:9 picture in the pan & scan mode on a conventional TV.
- You can see the central portion of the screen only (with the sides of the 16:9 picture cut off).



Note


- If a DVD is in the 4:3 ratio, you cannot view it in widescreen.
- Since DVD discs are recorded in various image formats, they will look different depending on the software, the type of TV, and the TV aspect ratio setting.

Press **RETURN** button to return to the previous level.

Press MENU button to exit the setup screen.

### GE

Use this to restrict playback of adult or violent DVDs you do not want children to view.



In Stop mode, press **MENU** button.

Press Cursor ▼
button to move to
'Setup' and then
press ENTER button.





Press Cursor ▼
button to move to
'PARENTAL' and then
press ENTER button.

Press Cursor ▲, ▼ button to select the desired rating level and then press ENTER button.

- If you have selected Level 6, you cannot view DVDs with Level 7 or higher.
- The higher the level, the closer the content is to violent or adult material.



5 Enter the password and then press ENTER button.

- The password is set to "7890" by default.
- Once the setup is complete, you will be taken to the previous screen.



Note

• This function works only if a DVD disc contains the rating level information.

Press RETURN button to return to the previous level.

# **Setting the Password**

You can set the password for the Parental (rating level) setting.



Press **MENU** button.



Press Cursor ▼ button to move to 'Setup' and then press ENTER button.



Press Cursor ▼ button to move to 'PASSWORD' and then press ENTER button.



Press ENTER button.



5 Enter the password and then press ENTER button.

- Enter the old password, a new password, and confirm new password.
- . The setting is complete.



Note

The password is set to "7890" by default.

#### If you have forgotten the rating level password, do the following:

- While "NO DISC" message appears on the display of main unit, hold the main unit's button for longer than 5 seconds. "INITIALIZE" appears on the display and all settings will return to the default values.
- · Press the POWER button.

Using the RESET function will erase all stored settings. Do not use this unless necessary.

Press **MENU** button to exit the setup screen.

# Setting the Wallpaper Setting the Wallpaper



While watching a DVD, VCD or JPEG CD, you can set the image you like as background wallpaper.

### Setting the Wallpaper

During playback, press PLAY/PAUSE button when an image you like appears.



Press LOGO button.

• "COPY LOGO DATA" will be displayed on the TV screen.



The power will turn off and then back on.

• The selected wallpaper will be displayed.

 You can set up to three wallpapers by repeating operation from Step1 to Step 3.



Samsung Logo image as your wallpaper.



Select this to set the desired image as your wallpaper.

### To Change the Wallpaper

In Stop mode, press **MENU** button.



Press Cursor ▼ button to move to 'Setup' and then press **ENTER** button.



Press Cursor ▼ button to move to 'LOGO' and then press **ENTER** button.



Press ▼ to select the desired 'USER', and then press ENTER.



Press **MENU** button to exit the setup screen.

Press RETURN button to return to the previous level.

Press **MENU** button to exit the setup screen.

# **Setting the Speaker Mode**

Signal outputs and frequency responses from the speakers will automatically be adjusted according to your speaker configuration and whether certain speakers are used or not.

In Stop mode, press **MENU** button.



In the Speaker Setup, press the ENTER button again.



Press Cursor ▼
button to move to
'Audio' and then
press ENTER button.



Press Cursor ▲, ▼,
◀,▶ buttons to move
to the desired
speaker and then
press ENTER button.

 For C, LS, and RS, each time the button is pressed, the mode switches alternately as follows: SMALL → NONE.

• For L and R, the mode is set to SMALL.



SMALL: Select this when using the speakers.

NONE: Select this when no speakers are installed.



• Depending on PRO LOGIC and STEREO, the speaker mode may vary.

# **Setting the Test Tone**

Use the Test Tone feature to check the speaker connections and to adjust the speaker levels.

In Stop mode, press **MENU** button.



Press Cursor ▼
button to move to
'Audio' and then
press ENTER button.



Press Cursor ▼ button to move to 'TEST TONE' and then press ENTER button.

 The test tone will be sent to L → C → R → RS → LS → SW in that order.
 If the ENTER button is pressed again at this time. the test tone will stop.





Press RETURN button to return to the previous level.


Press **MENU** button to exit the setup screen.

Alternate method: press the **TEST TONE** button on the remote.

### Press **TEST TONE** button.

- Test tone will be produced as follows: When playing a DVD or CD, this will work only in Stop mode.
- Use this function to check that each speaker is correctly connected and that there is no problem.

To end the test tone, press **TEST TONE** button again.



L: Front Speaker (L) C: Center Speaker

R: Front Speaker (R) LS: Rear Speaker (L)

....

SW: Subwoofer


RS: Rear Speaker (R)

39

# SEIO

# **Setting the Delay Time**

If the speakers cannot be placed at equal distances from the listening position, you can adjust the delay time of the audio signals from the center and rear speakers.



In Stop mode, press **MENU** button.

Press Cursor ▼ button to move to 'Audio' and then press ENTER button.



Press Cursor ▼ button to move to 'DELAY TIME' and then press ENTER button.



Press Cursor ▲, ▼,

◀, ▶ buttons to move
to the desired
speaker and then
press ENTER button.



**5** Press Cursor ◀, ▶ to set the Delay time.

 You can set the delay time for C between 00 and 05mSEC and for LS and RS between 00 and 15mSEC.



### **Setting up the Speaker Delay Time**

When 5.1CH Surround Sound is played, you can enjoy the best sound if the distance between you and each speaker is the same. Since the sounds arrive at the listening position at different times depending on the placement of speakers, you can adjust this difference by adding a delay effect to the sound of the Center Speaker and Surround Speakers.

### Note

- With MPL (Dolby Pro Logic II), the delay time may be different for each mode.
- With AC-3 and DTS, the delay time can be set between 00 and 15mSEC.

#### • Setting CENTER SPEAKER


If the distance of Dc is equal to or longer than the distance of Df in the figure, set the mode as 0ms. Otherwise, change the setting according to the table.

Distance between Df and Dc	Delay Time
0.00 m	0 ms
0.34 m	1 ms
0.68 m	2 ms
1.02 m	3 ms
1.36 m	4 ms
1.70 m	5 ms

• Setting REAR (SURROUND) SPEAKERS

If the distance of Df is equal to the distance of Ds in the figure, set the mode as 0ms. Otherwise, change the setting according to the table.

Distance between Df and Ds	Delay Time
0.00 m	0 ms
1.02 m	3 ms
2.04 m	6 ms
3.06 m	9 ms
4.08 m	12 ms
5.10 m	15 ms




Ds: The distance from SURROUND SPEAKER

# U

# **Setting the Audio Quality**

You can adjust the balance and level for each speaker.



Method 1 When adjusting the audio quality using the setup screen

In Stop mode, press **MENU** button.

Press Cursor ▼
button to move to
'Audio' and then press
ENTER button.



DESIREM SPEAKER SETUP

PRINCE Many
SPEAKER SETUP

PRINCE Many
SPEAKER SETUP

PRINCE MANY
SPEAKER SETUP

POWNE SPEAKER SETUP

OURS SPEAKER SETUP

O

Press Cursor ▼ button to move to 'SOUND EDIT' and then press ENTER button.

Press Cursor ▲,▼
buttons to select and
adjust the desired item.
Press the ◀,▶ buttons
to adjust the settings.





Method 2 When manually adjusting with the SOUND EDIT button

Adjusting Front Speaker Balance

Press **SOUND EDIT** button and then press Cursor



Adjusting Rear Speaker Balance

Press SOUND
EDIT button and then press Cursor



Adjusting Center Speaker Level

Press SOUND EDIT button and then press Cursor



Adjusting Rear Speaker Level

Press SOUND
EDIT button and then press Cursor
, ...



Adjusting Subwoofer Speaker Level

Press SOUND
EDIT button and then press Cursor



Press **RETURN** button to return to the previous level.

Press MENU button to exit the setup screen.

#### Note

• The adjustments will appear on the main unit's display, not on your TV screen.

#### Adjusting Front/Rear Speaker Balance

- You can select between 00 and -06 and OFF.
- The volume decreases as you move closer to -6.

#### Adjusting Center/Rear/Subwoofer Speaker Level

- The volume level can be adjusted in steps from +6dB to -6dB.
- The sound gets louder as you move closer to +6dB and guieter as you get closer to -6dB.

SETUP

# **Setting the DRC** (Dynamic Range Compression)

You can use this function to enjoy Dolby Digital sound when watching movies at low volume at night.

In Stop mode, press **MENU** button.

Press Cursor ▼ button to move to 'Audio' and then press ENTER button.






Press Cursor ▼ button to move to 'DRC' and then press **ENTER** button.



Press Cursor ▲,▼ to adjust the 'DRC'.

• The Cursor **A** button is pressed, the greater the effect, and the Cursor ▼ button is pressed, the smaller the effect.





**AV SYNC Setup** 

Video may look slower than the audio if it is connected with digital TV In this case, adjust the delay time of audio to optimal status to fit the video.

Press the **MENU** button.

· Setup menu appears.



Press Cursor ▲ , ▼ buttons to move to 'Audio' and then press **ENTER** button.

· 'Audio' menu appears.



Press Cursor ▲, ▼ buttons to move to 'AV-SYNC' and then press **ENTER** button.

· AV-SYNC screen appears.

Press Cursor ▲ ,▼ buttons to select the Delay Time of AV-SYNC and then press the **ENTER** button.

• You can set the audio delay time between 0 ms and 300 ms. Set it to the optimal status.



Press **RETURN** button to return to the previous level.

Press **MENU** button to exit the setup screen.

Press **RETURN** button to return to the previous level.

Press **MENU** button to exit the setup screen.


45

# Dolby Pro Logic II Mode


You can select the desired Dolby Pro Logic II audio mode.

#### Press **X** PL II MODE button.

• Each time the button is pressed, the mode changes as follows.




• When selecting Pro Logic II mode, connect your external device to the AUDIO INPUT jacks (L and R) on the player. If you connect to only one of the inputs (L or R), you cannot listen to 5.1 channel surround sound.



# **Dolby Pro Logic II Effect**

This function works only in Dolby Pro Logic MUSIC mode.





Press PL II EFFECT button and then press Cursor ◀,▶ buttons to select the mode.

• You can select either 0 or 1.



Press PL II EFFECT button and then press Cursor ◀,▶ buttons to select the mode.

You can select between 0 and 7.



Press PL II EFFECT button and then press Cursor ◀,▶ buttons to select the mode.

You can select between 0 and 6.



Note • When playing a DVD disc encoded with two or more channels, multi-channel mode will be selected automatically and DTPL II (Dolby Pro Logic II) button does not work.

#### **PRO LOGIC II**

- MUSIC: When listening to music, you can experience sound effects as if you are listening to the actual performance.
- . CINEMA: Adds realism to the movie soundtrack.
- . PRO LOGIC: You will experience a realistic multi-channel effect, as if using five speakers, while using just the front left and right speakers.
- . MATRIX: You will hear 5.1 channel surround sound.


STEREO: Select this to listen to sounds from the front left and right speakers and the subwoofer only.

- PANORAMA: This mode extends the front stereo image to include the surround speakers for an exciting "wraparound" effect with side wall imaging.
- . CENTER WIDTH: Sound is output to the center speaker only. The front left and right speakers produce phantom sound.
- DIMENSION: Incrementally adjusts the sound field (DSP) from the front or rear.

# SEIOF


# Sound Field (DSP)/EQ Function

DSP(Digital Signal Processor) DSP modes have been designed to simulate different acoustic environments. EQ: You can select from ROCK, POP, or CLASSIC, depending on the genre of music.



#### Press **DSP/EQ** button.

- "DSP" appears on the display panel.
- Each time the button is pressed, the selection changes as follows:



Note

- This feature works with CDs, MP3-CDs and 2 channel DVD-Audio and Dolby Digital discs.
- When playing a DVD disc encoded with two or more channels, multi-channel mode will be selected automatically and DSP/EQ function does not work.

### Note

POP, JAZZ, ROCK: Depending on the genre of music, you can select from POP, JAZZ, and ROCK.

STUDIO: Provides a sense of presence as if in a studio.

**CLUB**: Simulates the sound of a dance club with a throbbing bass beat.

HALL: Provides a clear vocal as if listening in a concert hall.

**MOVIE:** Provides the feeling of a movie theater.

CHURCH: Gives the feel of being in a grand church.

PASS: Select this for normal listening.

# **Sleep Timer Function**

You can set the time that the DVD player will shut itself off.

#### Press **SLEEP** button.

 "SLEEP" will be displayed. Each time the button is pressed the preset time changes as follows: 10 → 20 → 30 → 60 → 90 → 120 → 150 → OFF.



### To confirm the sleep timer setting, press SLEEP button.

- •The remaining time before the DVD player will shut itself off is displayed
- •Pressing the button again changes the sleep time from what you have set earlier.

To cancel the sleep timer, press **SLEEP** button until OFF appears on the display.

### **Adjusting Display Brightness**

You can adjust the brightness of the display on the main unit so it won't interfere with your movie viewing.

#### Press **DIMMER** button.


Each time the button is press, the brightness changes as follows:
 DARK → BRIGHT.

# **Mute Function**

This is useful when answering a doorbell or telephone call.

#### Press **MUTE** button.

- . 'MUTE' flash in the display.
- To switch the sound back on (at the same volume as before), press MUTE again or the VOLUME buttons.





# **Presetting Stations**

#### You can store up to:

- ♦ 15 FM stations
- ♦ 15 AM stations
- FM Frequency Modulation · AM Frequency Modulation

#### **Remote Control Unit**

manual tuning operation.

Press TUNER button.

• The selection toggles back and forth between "FM → AM" each time the TUNER button is pressed.

Tune in to the desired station.

You can listen to the chosen band (FM,AM broadcast stations) by using either the automatic or

**Listening to Radio** 

Automatic Tuning 1 When ◄◄ ►► is pressed, a preset broadcast station is selected.

Press and hold 🛇 🗸 to automatically search for

Manual Tuning Briefly press 🔿 🗸 to

#### **Main Unit**

Press the **Function** button to select the desired band (FM,AM).

Select a broadcast station.

Press the STOP (■) button to select

PRESET and then press I◄◀ ▶▶I button to select the preset station.

Press the STOP ( ) button Automatic Tuning 2 to select "MANUAL" and

then press and hold I◄◀ ▶▶I button to automatically search the band.

Manual Tuning Press STOP (■) to select MANUAL and then briefly

press | I but to tune in to a lower or higher frequency.

active broadcasting stations.

increase or decrease the frequency incrementally.

Example: Presetting FM 89.1 in the memory

Press the **TUNER** button and select the FM band.

· Each time the button is pressed, the band switches between "FM → AM".

Press 🛇 🗘 to select "89.10".

• Refer to Step 2 on page 51 to automatically or manually tune in to a station.

Press the **TUNER MEMORY** button.

. "PRGM" flashes in the display

Press I◄◀ ▶►I to select preset number.

 You can select between 1 and 15.

Press the **TUNER MEMORY** button again.

• Press the TUNER MEMORY button before 'PRGM' disappears from the display.

· 'PRGM' disappears from the display and the station is stored in memory.

To preset another station, repeat steps 2 to 5.

Press MO/ST button to listen in Mono/Stereo. (This applies only when listening to an FM station.)

- Each time the button is pressed, the sound switches between "STEREO" and "MONO".
- In a poor reception area, select MONO for a clear, interference-free broadcast.

To tune in to a preset station, press ◄◄►► on the remote control to select a channel.

# **Language Code List**

Enter the appropriate code number for the initial settings "Disc Audio", "Disc Subtitle" and/or "Disc Menu" (See page 31).

Code	Language	Code	Language	Code	Language	Code	Language
1027	Afar	1181	Frisian	1334	Latvian, Lettish	1506	Slovenian
1028	Abkhazian	1183	Irish	1345	Malagasy	1507	Samoan
1032	Afrikaans	1186	Scots Gaelic	1347	Maori	1508	Shona
1039	Amharic	1194	Galician	1349	Macedonian	1509	Somali
1044	Arabic	1196	Guarani	1350	Malayalam	1511	Albanian
1045	Assamese	1203	Gujarati	1352	Mongolian	1512	Serbian
1051	Aymara	1209	Hausa	1353	Moldavian	1513	Siswati
1052	Azerbaijani	1217	Hindi	1356	Marathi	1514	Sesotho
1053	Bashkir	1226	Croatian	1357	Malay	1515	Sundanese
1057	Byelorussian	1229	Hungarian	1358	Maltese	1516	Swedish
1059	Bulgarian	1233	Armenian	1363	Burmese	1517	Swahili
1060	Bihari	1235	Interlingua	1365	Nauru	1521	Tamil
1069	Bislama	1239	Interlingue	1369	Nepali	1525	Tegulu
1066	Bengali; Bangla	1245	Inupiak	1376	Dutch	1527	Tajik
1067	Tibetan	1248	Indonesian	1379	Norwegian	1528	Thai
1070	Breton	1253	Icelandic	1393	Occitan	1529	Tigrinya
1079	Catalan	1254	Italian	1403	(Afan) Oromo	1531	Turkmen
1093	Corsican	1257	Hebrew	1408	Oriya	1532	Tagalog
1097	Czech	1261	Japanese	1417	Punjabi	1534	Setswana
1103	Welsh	1269	Yiddish	1428	Polish	1535	Tonga
1105	Danish	1283	Javanese	1435	Pashto, Pushto	1538	Turkish
1109	German	1287	Georgian	1436	Portuguese	1539	Tsonga
1130	Bhutani	1297	Kazakh	1463	Quechua	1540	Tatar
1142	Greek	1298	Greenlandic	1481	Rhaeto-Romance	1543	Twi
1144	English	1299	Cambodian	1482	Kirundi	1557	Ukrainian
1145	Esperanto	1300	Kannada	1483	Romanian	1564	Urdu
1149	Spanish	1301	Korean	1489	Russian	1572	Uzbek
1150	Estonian	1305	Kashmiri	1491	Kinyarwanda	1581	Vietnamese
1151	Basque	1307	Kurdish	1495	Sanskrit	1587	Volapuk
1157	Persian	1311	Kirghiz	1498	Sindhi	1613	Wolof
1165	Finnish	1313	Latin	1501	Sangro	1632	Xhosa
1166	Fiji	1326	Lingala	1502	Serbo-Croatian	1665	Yoruba
1171	Faeroese	1327	Laothian	1503	Singhalese	1684	Chinese
1174	French	1332	Lithuanian	1505	Slovak	1697	Zulu

# Cautions on Handling and Storing Discs

Small scratches on the disc may reduce sound and picture quality or cause skipping. Be especially careful not to scratch discs when handling them.

### Handling discs



Do not touch the playback side of the disc. Hold the disc by the edges so that fingerprints will not get on the surface.

Do not stick paper or tape on the disc.

### Disc Storage

#### Do not keep in direct sunlight



#### Keep in a cool ventilated area



#### Keep in a clean Protection jacket. Store vertically.



#### Caution

- Do not allow the discs to become contaminated with dirt.
- · Do not load cracked or scratched discs.

### Handling and Storing Discs



When you get fingerprints or dirt on the disc, clean it with a mild detergent diluted in water and wipe with a soft cloth.

• When cleaning, wipe gently from the inside to the outside of the disc.

#### Note

• Condensation may form if warm air comes into contact with cold parts inside the player. When condensation forms inside the player, the player may not operate correctly. If this occurs, remove the disc and let the player stand for 1 or 2 hours with the power on.

# MISCELLANEOUS

# **Before Calling for Service**

Refer to the chart below when this unit does not function properly. If the problem you are experiencing is not listed below or if the instruction below does not help, turn off the unit, disconnect the power cord, and contact the nearest authorized dealer or Samsung Electronics Service Center.

Symptom	Check/Remedy
Disc tray does not open.	Is the power cord plugged securely into the outlet?     Turn off the power and then turn it back on.
Playback does not start.	Check the region number of the DVD. DVD discs purchased from abroad may not be playable. CD-ROMs and DVD-ROMs cannot be played on this DVD player. Make sure that the rating level is correct.
Playback does not start immediately when the Play/Pause button is pressed.	Are you using a deformed disc or a disc with scratches on the surface?     Wipe the disc clean.
Sound is not produced.	<ul> <li>No sound is heard during fast playback, slow playback, and step motion playback.</li> <li>Are the speakers connected properly? Is the speaker setup correctly customized?</li> <li>Is the disc severely damaged?</li> </ul>
Sound can be heard only from a few speakers and not all six.	When listening to a CD or radio, sound is output to the front speakers (L/R) only. Select "PRO LOGIC II" by pressing \□\Delta \PL \II (Dolby Pro Logic II) on the remote control to use all six speakers.      Make sure that the DVD disc is 5.1-CH compatible.      If you set C, SL, and SR to NONE in the speaker mode in the audio setup of the setup screen, no sound is heard from the center speaker and the front left and right speakers. Set C, SL, and SR to SMALL.
Picture does not appear, sound is not produced, or the disc tray opens 2 to 5 seconds later.	Was the DVD player suddenly moved from a cold place to a warm one? When condensation forms inside the player, remove the disc and let the player stand for 1 or 2 hours with the power on. (You can use the player again after condensation disappears.)
Dolby Digital 5.1 CH Surround Sound is not produced.	<ul> <li>Is there "Dolby Digital 5.1 CH" mark on the disc? Dolby Digital 5.1 CH Surround Sound is produced only if the disc is recorded with 5.1 channel sound.</li> <li>Is the audio language correctly set to DOLBY DIGITAL 5.1-CH in the information display?</li> </ul>

Symptom	Check/Remedy	
Disc is rotating but no picture is produced.     Picture quality is poor and picture is shaking.	Is the TV power on?     Are the video cables connected properly?     Is the disc dirty or damaged?     A poorly manufactured disc may not be playable.	
The remote control does not work.	Is the remote control being operated within its operation range of angle and distance?     Are the batteries exhausted?	
Audio language and subtitles do not work.	Audio language and subtitles will not work for DVDs not containing them. And depending on the disc, they may work differently.	
Menu screen does not appear even when the menu function is selected.	Are you using a disc that does not contain menus?	
Aspect ratio cannot be changed.	You can play 16:9 DVDs in 16:9 WIDE mode, 4:3 LETTER BOX mode, or 4:3 PAN SCAN mode, but 4:3 DVDs can be seen in 4:3 ratio only. Refer to the DVD disc jacket and then select the appropriate function.	
Can't receive radio broadcast.	Is the antenna connected properly?     If the antenna's input signal is weak, install an external FM antenna in an area with good reception.	
The main unit is not working.     (Example: The power goes out or strange noise is heard.)	Turn off the power and hold the button on the main unit for longer than 5 seconds.	
The DVD player is not working normally.	Using the RESET function will erase all stored settings. Do not use this unless necessary.	
The password for rating level has been forgotten.	While "NO DISC" message appears on the display of main unit, hold the main unit's button for longer than 5 seconds. "INITIALIZE" appears on the display and all settings will return to the default values.     Press the POWER button.  Using the RESET function will erase all stored settings.  Do not use this unless necessary.	

# MISCELLANEOUS

# **Specifications**

G	Power Consumption	70W
G E N E R	Weight	3.2Kg
Ë	Dimensions (W x H x D)	430 x 60 x 340 mm
A A	Operating Temperature Range	+5°C~+35°C
L	Operating Humidity Range	10%~75%
T	Usable Sensitivity	10dB
F UN E	S/N Ratio	60dB
E	Distortion	0.5%
Т	Usable Sensitivity	54dB
AM N	S/N Ratio	40dB
Ē	Distortion	2%
	Composite Video	1.0Vp-p(75Ω load)
VIDEO	Component Video	Y:1.0Vp-p(75Ω load)
OUTPUT	_	Pr:0.70Vp-p(75Ω load)
		Pb:0.70Vp-p(75Ω load)
	Front speaker output	32W(4Ω)/CH
Α	Center speaker output	63W(4Ω)
M P	Rear speaker output	32W(4Ω)/CH
Ĺ	Subwoofer speaker output	64W(8Ω)
Ī	Frequency range	20Hz~20kHz
F	S/N Ratio	75dB
Ė	Channel separation	50dB
R	Input sensitivity	(AUX)500mV

### HT-P10

	Charles austam	5.1ch speaker system			
	Speaker system	Front/Rear speaker	Center speaker	Subwoofer speaker	
S P	Impedance	4Ω x 4	4Ω	8Ω	
E	Frequency range	150Hz~20kHz	150Hz~20kHz	30Hz~150Hz	
Α	Output sound pressure level	85dB/W/M	85dB/W/M	86dB/W/M	
K E	Rated input	32W	63W	64W	
R	Maximum input	64W	126W	128W	
	Dimensions (W x H x D)	90 x 107 x 95 mm	160 x 90 x 95 mm	145 x 320 x 340 mm	
	Weights	0.36 Kg / 0.3 Kg	0.45 Kg	3.6 Kg	

### HT-P11

	Speaker system	5.1ch speaker system			
	Speaker System	Front/Rear speaker	Center speaker	Subwoofer speaker	
S	Impedance	4Ω x 4	4Ω	8Ω	
P E	Frequency range	150Hz~20kHz	150Hz~20kHz	30Hz~150Hz	
Α	Output sound pressure level	85dB/W/M	85dB/W/M	86dB/W/M	
K E	Rated input	32W	63W	64W	
R	Maximum input	64W	126W	128W	
	Dimensions (W x H x D)	85.5 x 156 x 98 mm	300 x 85.5 x 98 mm	145 x 320 x 340 mm	
	Weights	0.5 Kg / 0.35 Kg	0.65 Kg	3.6 Kg	

### HT-TP12

SPEAKER	Speaker system	5.1ch speaker system			
		Front speaker	Rear speaker	Center speaker	Subwoofer speaker
	Impedance	4Ω x 2	4Ω x 2	4Ω	8Ω
	Frequency range	150Hz~20kHz	150Hz~20kHz	150Hz~20kHz	30Hz~150Hz
	Output sound pressure level	85dB/W/M	85dB/W/M	85dB/W/M	86dB/W/M
	Rated input	32W	32W	63W	64W
	Maximum input	64W	64W	126W	128W
	Dimensions (W x H x D)	85 x 1050 x 90 mm	90 x 107 x 95 mm	160 x 90 x 95 mm	145 x 320 x 340 mm
	Weights	3.1 Kg / 2.95 Kg	0.36 Kg / 0.3 Kg	0.45 Kg	3.6 Kg