

ł

,6,F,8,A,0,8,6,9,

ELECTROMAGNETIC FLOWMETER

MODEL LF600F and LF602F

INSTRUCTION MANUAL

TOSHIBA CORPORATION

NOTES

۱ ۱

Before using the equipment, please read this manual carefully and understand the contents, and then use the equipment correctly.

- NEVER attempt to operate the equipment in any ways that are not described in this instruction manual.
- After reading this manual, store it with care in a place where it can be referred to whenever needed.
- Please be sure that this manual is delivered to the personnel who will use this product.



10th Edition June, 2007 First Edition September, 2005

SAFETY PRECAUTIONS

Safety signs and labels affixed to the product and/or described in this manual give important information for using the product safely. They help prevent damage to property and obviate hazards for persons using the product.

Make yourself familiar with signal words and symbols used for safety signs and labels. Then read the safety precautions that follow to prevent an accident involving personal injury, death or damage to property.

Explanation of signal words

The signal word or words are used to designate a degree or level of hazard seriousness.

The signal words used for the product described in this manual are WARNING and CAUTION.

Indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury .
Indicates a potentially hazardous situation, which, if not avoided, may result in minor to moderate injuries or in property damage .

Notes:

- 1 "Series injury" refers to an injury such as loss of sight, physical damage, burns (high temperature or low temperature) electric shock, bone fracture and poisoning and the after effect of the injury remains or the injury requires hospitalization or long periods of outpatient treatment.
- 2 "Minor to moderate injuries" refers to burns, electric shocks, and so on, that do not oblige the injured person to be hospitalized or go to a hospital for a long period of time for medical treatment. "Property damage" includes all kinds of damage to property, equipment or materials.

Safety symbols

The following symbols are used in safety signs and labels affixed to a product and/or in the manual for giving safety instructions.

\bigcirc	Indicates an action that is prohibited. Simply DON'T do this action. The prohibited action is indicated by a picture or text inside or next to the circle
Indicates an action that is mandatory. DO this action. The mandatory action is indicated by a picture or text inside or next to the circ	
\square	Indicates a potential hazard. The potentially hazardous situation is indicated by a picture or text inside or next to the triangle.

Color explanation

WARNINGABackground color: Yellow and Red, Border: Black, Picture display: BlackCAUTIONABackground color: Yellow,Border: Black, Picture display: Black

SAFETY PRECAUTIONS (continued)

Safety Precautions for Hazardous Locations



SAFETY PRECAUTIONS (continued)

Safety Precautions for Installation and Wiring

Install a switch and fuse to isolate the LF600F and LF602F from mains power.	Use an appropriate device to carry and install the LF600F and LF602F.	
Power supply from mains power can cause electric shock or circuit break-down.	If this product falls to the ground , injury, or malfunction of or damage to the product, can be caused.	
Turn off mains power before conducting wiring work.	Do not modify or disassemble the LF600F and LF602F unnecessarily.	
Wiring while power is applied can cause electric shock.	Modifying or disassembling this product can cause electric shock, malfunction of or damage to this product.	
Turn off mains power before working on pipes.	Ground the LF600F and LF602F independently from power equipment.	
Working on pipes while power is applied can cause electric shock.	(100 ohm or less ground resistance) Operating this product without grounding can cause electric shock or malfunction.	
Do not conduct wiring work with bare hands.	Use crimped terminal lugs for the terminal board and GND terminal.	
Remaining electric charge even if power is turned off can still cause electric shock .	Loose connections can cause electric shock, fire from excessive current or system malfunction.	
 Do not work on piping and wiring with wet hands. Wet hands may result in electric shock. 		
power supply	wn left is placed near the terminal board for on the converter. er and symbol on yellow triangle) ectric shock.	

- 4 -

SAFETY PRECAUTIONS (continued)

Safety Precautions for Maintenance and Inspection

 Do not conduct wiring work with wet hands. Wet hands may result in electric shock. 	 Do not conduct wiring work when power is applied. Wiring while power is applied can cause electric shock. 	
 DON'T Do not use a fuse other than the one specified. Using a fuse other than the one specified can cause system failure, damage or malfunction. 	 DON'T Do not touch the LF600F main body when high temperature fluid is being measured. The fluid raises the main body temperature and can cause burns when touched. 	
Use a rated fuse as follows: Fuse rating: ①0.8A(T)/250V for 100 to 240Vac or 110Vdc ②2A/150V for 24 V dc Dimensions: Diameter 5 mm × 20 mm Melting time characteristic: ①Time Lag ②Medium-Arcing (Normal blow)	The label shown left is placed near the terminal board for power input. (A black border and symbol on yellow triangle) Be alert to electric shock .	

Usage limitation

This product is **not manufactured for applying to a system requiring safety directly involved human life as follows**. Please contact you're nearest Toshiba reprehensive if there is a possibility of using this product for such use.

- Main control systems of nuclear power plants, safety protection systems in nuclear facilities or other important systems requiring safety
- Medical control systems relating to life support

Warranty and Limitation of Liability

Toshiba does not accept liability for any damage or loss, material or personal, caused as a direct or indirect result of the operation of this product in connection with, or due to, the occurrence of any event of force majored (including fire or earthquake) or the misuse of this product, whether intentional or accidental.

- 5 -

ς.

Handling Precautions

To obtain the optimum performance from the LF600F and LF602F converter for years of continuous operation, observe the following precautions.

- (1) Do not store or install the flowmeter in:
 - places where there is direct sunlight.
 - places where there is snow and ice
 - Infrared switches may not function correctly.
 - places where excessive vibration or mechanical shock occurs.
 - places where high temperature or high humidity conditions obtain.
 - places where corrosive atmospheres obtain.
 - places submerged under water.
 - place where there is slop floor. To put the flowmeter temporarily on the floor, place it carefully with something, such as stopper, to support it so that the flowmeter will not topple over.
 - Places where there is following factors.
 - Factors to impede infrared switch to operate properly
 - Intense light such as direct sunlight and reflected sunlight by window glass or metal plate
 - · Place where brightness changes always such as ON/OFF of lighting
 - Dense smoke or steam near the control panel
 - Those attached on the control panel such as rain (dew drop), snow, ice, mud and oil, and haze due to their attachment
 - Light reflecting object near the control panel, or reflecting object such as metal plate placed opposing to the control panel

When any of above factors is considered, take a measure for the proper operation of infrared switch such as to place a cover or to secure a space for at least a person to stand in front of the control panel.

When unable to avoid above factors, operate the EMF converter removing the factor by covering the control panel by hand so that light does not shine on it, by cleaning those attached on the control panel, or by standing in-between the reflecting object and the control panel to block the light.

(2) Wire cables correctly and securely.

Be sure to ground at the converter side (grounding resistance 100Ω or less). Avoid a common ground used with other equipment where earth current may flow. An independent ground is preferable

- (3) Select cable paths away from electrical equipment (motors, transformers, or radio transmitters), which causes electromagnetic or electrostatic interference.
- (4) The cable glands is not provided in the conduit port of this apparatus.
 Because 1/2-14NPT screw holes are processed to this place, please prepare yourself for the cable glands which could be used in Division2 hazardous locations.
 The cable lead-in section must be tightened securely to keep air tightness.

TOSHIBA

Handling Precautions (continued)

(5)	If the inside of the converter or cable terminals are wetted or humidified, it may cause insulation deterioration, which can result in fault or noise occurrence . So do not conduct wiring in the open air on rainy days .
	Also, be careful not to wet down the converter even in the case of indoor wiring, and complete wiring work in a short period of time.
(6)	Observe the following precautions when you open the converter housing cover:
	• Do not open the cover in the open air unprotected against rain or wind. This can cause electric shock or cause damage to the flowmeter electronics.
	• Do not open the cover under high ambient temperature or high humidity conditions or in corrosive atmospheres. This can cause deterioration of system accuracy or cause damage to the flowmeter electronics.
(7)	Since a varistor is built in converter, do not conduct a withstand voltage test for the converter.
	In addition, the voltage for checking the insulation of the converter must be 250VDC or lower.
(8)	This product may cause interference to radio and television sets if they are used near the installation site. Use metal conduits etc. for cables to prevent this interference.
(9)	Radio transmitters such as transceivers or cellular phones may cause interference to the flowmeter if they are used near the installation site. Observe the following precautions when using them:
	• Close a transmitter cover before using a transceiver.
	• Do not use a transceiver whose output power is more than 5 W.
	• Move the antenna of a transceiver or a cellular phone at least 50 cm away from the flowmeter and signal cables when using it.
	• Do not use a radio transmitter or a cellular phone near the flowmeter while it is operating online. The transmitter or cellular phone's output impulse noise may interfere with the flowmeter.
	• Do not install a radio transmitter antenna near the flowmeter and signal cables.
(10)	For reasons of flowmeter failure, inappropriate parameters, unsuitable cable
. ,	connections or poor installation conditions, the flowmeter may not operate properly.
	To prevent any of these problems causing a system failure, it is recommended that
	you have preventive measures designed and installed on the flowmeter signal receiving side.
(11)	For piping and installation of the combined detector, check the model number of detector and read the instruction manual of the relevant detector.

* We assume no responsibility for nonconformity caused by violation of precautions described in this manual or used in violation of the installation method and the operation method stipulated in a relevant ordinance or other regulations.

Table of Contents

1. Product Inspection and Storage	11
1.1 Product Inspection	11
1.2 Storage	11
2. Overview	12
3. Names of Parts	
3.1 Appearance	
3.1.1 Appearance of LF600F Type	
3.1.2 Appearance of LF602F Type	
3.2 Construction of the terminal blocks	15
3.2.1 Terminal Block Construction of LF600F Type	
3.2.2 Terminal Bock Construction of LF602F Type	16
4. Installation	17
4.1 Notes on Selecting the Installation Location	18
4.2 How to Install	19
4.2.1 LF600F Type	
4.2.2 LF602F Type	19
5. Wiring	
5.1 Cables	
5.2 External Device Connections and Grounding	
5.2.1 LF600F Type	
5.2.1 LF602F Type	
5.3 Notes on Wiring	
5.3.1 Notes on Instrumentation-Converter Wiring	
5.3.2 Notes on Wiring of the LF602F Type	
5.4 Wiring	
5.4.1 Grounding	
5.4.2 Terminal Treatment of Cables	
5.4.3 Cable Connection	
5.5 Digital I/O Connections	31
6. Operation	32
6.1 Preparatory check	
6.2 Zero Adjustment	
7. LCD Display and Controls	
7.1 Name and Function of Each Part of LCD Display	
7.2 Display Format	
7.3 Basic operations	
7.3.1 Mode Change	
7.3.2 Setting and Calibration	
7.4 Configuration Items Selection Table	
7.5 Password input	52

8.	Configuration Parameter Setting	53
	8.1 Configuration Items	53
	8.2 Check/Change of Parameters	54
	8.2.1 Menu Configuration Selection Screen	54
	8.2.2 Exciting Current Value	
	8.2.3 Meter Size	57
	8.2.4 Exciting Frequency	59
	8.2.5 Flow Direction Setting	61
•	8.2.6 Password Setting	63
	8.2.7 Address Setting	65
	8.2.8 Indicating Unit	65
	8.2.9 Custom Coefficient Setting	
	8.2.10 Custom Unit Setting	70
	8.2.11 LCD Density Adjustment	72
	8.2.12 Switch Position Setting	
	8.2.13 Span (range)	
	8.2.14 Damping Constant	
	8.2.15 Low Cutoff	
	8.2.16 Current Output Setting Used When an Alarm Occurs	
	8.2.17 Display Low Cut Setting	
	8.2.18 Output Low Limit Setting	
	8.2.19 Still Water Zero Adjustment	
	8.2.20 Digital I/O	
	8.2.21 Count Rate (Pulse Rate), Pulse Width Setting Mode, Pulse Width	
	8.2.22 Preset Count Value	
	8.2.23 Preset Point Output Function	
	8.2.24 Flow Rate High, Low, High-High and Low-Low limit Alarm Setting	
	8.2.25 Empty Alarm Setting	
	8.2.26 Self-diagnosis ON/OFF Setting	
	8.2.27 Alarm Output Preset Function Setting	
	8.2.28 Rate-Of-Change Limit and Control Limit Time	
	8.2.29 Fixed-Value Output	
	8.2.30 Zero Offset Adjustment	
	8.2.31 Parameter initial settings list	
	_	
9.	Calibration	
	9.1 Calibration Items	
	9.2 Calibration Using Converter Signal Source	
	9.2.1 0 % Flow Rate Calibration (zero point calibration)	
	9.2.2 50 % Flow Rate Calibration	
	9.2.3 100 % Flow Rate (Span) Calibration	
	9.2.4 Checking the Excitation Current Value	
10). Digital I/O Functions	114
	10.1 Digital I/O Specifications	115
	10.2 Totalizer and Pulse Output	116
	10.3 Multi-range Functions	120
	10.4 High/Low, High-high or Low-low Limit Alarm	
	10.5 Preset Count Output	127
	10.6 Remote Zero Adjustment	

TOSHIBA

$_{1}6_{1}F_{1}8_{1}A_{1}0_{1}8_{1}6_{1}9_{1}$

10.7 Remote Selection of Fixed Value Output	
10.8 Converter Failure Alarm	
10.9 Multiple range high/low limit alarm function (option)	
11. Communications Function	135
11.1 Connections with the HHT Terminal	
11.2 Procedures for Communication with HHT	
11.3 Cautionary Notes on Communications	
12. Self-Diagnostics and Alarms	
12.1 Self-diagnostics	
12.2 Output Status for Errors and Alarms	
13. Maintenance and Troubleshooting	
13.1 Maintenance	
13.2 Troubleshooting	
13.2.1 Flow rate is not indicated	
13.2.2 Flow rate indication is not correct	
13.2.3 Flow rate indication is not stable	
13.2.4 When switch operation is unable	
14. Principle of Operation	149
15. Specifications	
15.1 Specifications	
15.2 Model Number Table	
16. Outline Drawing	
16.1 LF600F Type	
16.2 LF602F Type	
Appendix 1 (Factory default standard value table)	155
Appendix 1 (Factory default standard value table)	
Appendix 2	157
2-1 A system block diagram for LF600F	
2-2 A system block diagram for LF602F	158
Appendix 3 (Electromagnetic Compatibility and Low Voltage Safety)	

1. Product Inspection and Storage

1.1 Product Inspection

LF60*F series electromagnetic flowmeter is shipped in a cardboard container filled with shock-absorbing materials. Open the package carefully and check as follows:

Make sure the following items are included in the package.

For the integral type (when a converter and detector are united)



Electromagnetic flowmeter main unit ------ One each for the converter and detector

For the separate type (when a converter and detector are separated)



	-
Electromagnetic flowmeter converter1 unit	
Electromagnetic flowmeter detector1 unit	
Instruction manual Once each for the converter and detector	

For a converter unit only

<u> </u>	-11
	v
	_
- F6	:02F

Electromagnetic flowmeter converter-----One unit Instruction manual

- Inspect the flowmeter for indications of damage that may have occurred during shipment.
- Make sure the type and specifications of the flowmeter are in accordance with the ordered specifications.

If you cannot find the items listed above or any problem exists, contact you're nearest Toshiba representative.

1.2 Storage

To store the electromagnetic flowmeter after opening the package, select a storing place as follows and keep it under the conditions described below:

- (1) Avoid places where there is direct sunlight, rain or wind.
- (2) Store the product in a well-ventilated place. Avoid places of **extremely high humidity** or **extremely high or low temperature**. The following environment is recommended:
 - Humidity range: 10 to 90% RH (no condensation)
 - Storage temperature: -25 to +65° C
- (3) Avoid places where vibrations or mechanical shock occur.
- (4) If it leaves the cover of converter open while being stored, gradual deterioration of circuit isolation can be caused. And then **don't open the cover** until it is connected with wires.
- (5) To put the flowmeter temporarily on the floor, place it carefully with something, such as stopper, to support it so that the flowmeter will not topple over.

2. Overview

The LF600F and LF602F electromagnetic flowmeter converter can be use in the following hazardous (classified) locations.

Class I, Division 2, Groups A, B, C and D, Class II, Division 2, Groups E, F and G Class III

This product is a converter used for electric flowmeters that measure the volumetric flow rate of conductive fluid using Faraday's law of electromagnetic induction.

You can bring out the functions of the converter when you place it in the converter housing you prepare and use it in combination with a fluid rate measurement detector.

The converter sends out a signal to drive the detector exciting coil, which generates a magnetic field inside the detector. The converter receives the signal electromotive force obtained by the detector, as signal electromotive force in proportion to the generated flow rate in the fluid using Faraday's law of electromagnetic induction. After carrying out operation, the converter converts the signal electromotive force to an analog signal instrumentation unified signal output and displays the status, as a flow rate value.

Features

With a linear relationship between the flow rate and output signal, the electromagnetic flowmeter is featured as an easy-to-read indicator. In addition to this feature, it has the following outstanding features:

- (1) Wide flow velocity range setting, such as a flow velocity range of 0~0.1 and 0~10m/s, is achieved.
- (2) The unique noise filter-out circuit and arithmetic operation processor enables you to obtain stable output.
- (3) Full graphic LCD that enables display of a large amount of information
 - With a large amount of a maximum of 14 characters x 8 lines, you can easily check various displays including bar graphs and alarm indications.
 - The backlight allows you to read the indicator easily.
- (4) Use of infrared switches
 - Use of infrared switches allows you to perform various operations, without opening the converter housing cover.
- (5) Intelligent functions
 - The widely used HART protocol communications system is used as a standard feature.
 - This product supports **PROFIBUS**^{*2} communication by option.
- * 1 HART protocol: "HART" stands for Highway Addressable Remote Transducer and is a communication protocol recommended by HCF (HART communication Foundation) for industrial sensors.
- * 2 PROFIBUS: PROFIBUS, which stands for PROCESS FIELDBUS, is a kind of field bus that is approved by international standard IEC61158. The electromagnetic flowmeter supports PRFIBUS PA for process automation.

3. Names of Parts

IMPORTANT

The cable glands is not provided in the conduit port of this apparatus. Please prepare yourself for the cable glands, which could be used in Division2 hazardous locations.

3.1 Appearance

3.1.1 Appearance of LF600F Type





Figure 3.1.1 Appearance of LF600F

3.1.2 Appearance of LF602F Type







- 14 —

3.2 Construction of the terminal blocks

3.2.1 Terminal Block Construction of LF600F Type

When you remove the terminal block cover shown in the figure "Appearance of LF600F Type", you can see the converter terminal block as shown below.



Figure 3.2.1 Terminal Block Construction of LF600F

15 —

3.2.2 Terminal Bock Construction of LF602F Type



Figure 3.2.2 Terminal Block Construction of LF602F

4. Installation

Safety Precautions for Installation



 Ground the LF600F and LF602F independently from power equipment. (100 ohm or less ground resistance) 		Use an appropriate device to carry and install the LF600F and LF602F.	
DO	Operating this product without grounding can cause electric shock or malfunction.	DO If his product falls to the ground , injury, or malfunction of or damage to the product, can be caused.	
	switch and fuse to isolate the F and LF602FF from mains power.	Do not modify or disassemble the LF600F and LF602F unnecessarily.	
Do	Power supply from mains power can cause electric shock or circuit break-down.	Modifying or disassembling this product can cause electric shock, malfunction or damage to this product.	
 Do not w wet hand DON'T 	ork on piping and wiring with ls. Wet hands may result in electric shock	The label shown left is placed near the terminal board for power supply to the converter. Be alert to electric shock	

4.1 Notes on Selecting the Installation Location

This product is designed for the following environment.		
• Indoor and outdoor installation	• Ambient temperature: -20 to $+60^{\circ}$ C	
Altitude: Up to 2000m	• Humidity range: 10 to 90%(no condensation)	
• Regulation of power voltage: $\pm 10\%$		
 Pollution degree 2 	Structure: IP67 (NEMA 4X)	

Do not store or install the flowmeter in :

- 1. Places within the immediate proximity of equipment producing electrical interference (such as motors, transformers, radio transmitters, electrolytic cells, or other equipment causing electromagnetic or electrostatic interference).
- 2. Places where there is direct sunlight.
- 3. Places where excessive vibration or mechanical shock occurs.
- 4. Places where high temperature or high humidity conditions obtain.
- 5. Places where corrosive atmospheres obtain.
- 6. Places submerged under water.
- 7. Place where there is slop floor. To put the flowmeter temporarily on the floor, place it carefully with something, such as stopper, to support it so that the flowmeter will not topple over.
- 8. Places of **too great an elevation or constricted areas** where clearance for installation or maintenance work is not provided.

LF602F

9.

The standard length of the cable that connects **the detector and converter is 30m**. Select the converter installation location so that the distance of the detector and converter will not exceed 30m.

10. Places where there is following factors.

- Factors to impede infrared switch to operate properly
 - · Intense light such as direct sunlight and reflected sunlight by window glass or metal plate
 - · Place where brightness changes always such as ON/OFF of lighting
 - · Dense smoke or steam near the control panel
 - Those attached on the control panel such as rain (dew drop), snow, ice, mud and oil, and haze due to their attachment
 - Light reflecting object near the control panel, or reflecting object such as metal plate placed opposing to the control panel

When any of above factors is considered, take a measure for the proper operation of infrared switch such as to place a cover or to secure a space for at least a person to stand in front of the control panel.

When unable to avoid above factors, operate the EMF converter removing the factor by covering the control panel by hand so that light does not shine on it, by cleaning those attached on the control panel, or by standing in-between the reflecting object and the control panel to block the light.

4.2 How to Install

4.2.1 LF600F Type

The LF600F type converter is used as one united body. The LF600F type is not installed by itself. For how to install the LF600F type converter and a detector, check the type of the combined detector and follow the instruction manual of the relevant detector.

4.2.2 LF602F Type

The LF602F type can be installed on a wall or to a pipe stand. Install the converter so that the front of the cover is positioned on the vertical plane. Be sure to install it so that the conduit opening of the converter will face the bottom.

LF602F

LF600F

Figure 4.1 shows examples of installation to a panel and wall. Figure 4.2 shows an example of installation to a pipe stand.





TOSHIBA



Figure 4.2 Example of Pipestand Mounting

5. Wiring

DO

DO NOT DISCONNECT WHILE CIRCUIT IS LIVE UNLESS LOCATION IS KNOWN				
TO BE NONHAZARDOUS.				
Live part of electric circuit or a high temperature department can cause explosion.				
DON'T				
Do not live circuits While assembly of all components is not over.				
Protective performance degradation for hazardous location can cause explosion.				
DON'T				
■ Install per the National Electrical Code for the US (NEC, ANSI/NFPA 70) and the Canadian Electrical code for Canada (CEC, CAN/CSA-C22.1) and the drawing				
3S8A2532,3S8A2533 (Refer to Appendix 2.).				
Unsuitable conduit connections for hazardous location can cause explosion.				

 Install a switch and fuse to isolate the LF600F and LF602F from mains power. Power supply from mains power can cause electric shock or circuit break-down. 	 Turn off mains power before conducting wiring work. Wiring while power is applied can cause electric shock. 				
 Do not work on piping and wiring with wet hands. Wet hands may result in electric shock DON'T 	 Ground the LF600F independently from power equipment. (100 ohm or less ground resistance) Operating this product without grounding can cause electric shock or malfunction. DO 				
 Do not conduct wiring work with bare hands. Remaining electric charge even if power is turned off can still cause electric shock. 	 For the power supply wiring and grounding wiring, use crimping terminals with insulated sleeve. There is a risk of electric shock due to drop-off or loosing, and a risk of fire and equipment trouble due to heat generation. 				
Do not modify or disassemble the LF600F and LF602F unnecessarily. Modifying or disassembling this product can cause electric shock, malfunction of or damage to this product.	The label shown left is placed near the power supply terminal on the converter. Be alert to electric shock .				

Flowmeter accuracy may be affected by the way wiring is executed. Proceed with correct wiring taking the precautions in following pages.

Notes on wiring

- (1) Select the cable runs away from electrical equipment (motors, transformers, or radio transmitters) which causes electromagnetic or electrostatic interference.
- (2) Deterioration of flowmeter circuit insulation occurs if the converter interior or cable ends get wet or humidified. This in turn causes malfunction of flowmeter or noise problems. Avoid a rainy day if the flowmeter is to be installed outdoors. Even indoors, prevent water from splashing over the flowmeter. Try to finish the wiring as quickly as possible
- (3) The converter has an arrestor installed inside. Therefore, do not conduct a withstand voltage test for the converter. To check the insulation of the converter, use a voltage of 250Vdc or less.
- (4) After wiring, be sure to install the terminal block protection cover.



(5) Because the excitation cable and flow rate signal cable transmit very delicate signals, pass each of them separately through a thick steel conduit tube, keep them away from the large current wiring as far as possible, and do not install them in parallel.

5.1 Cables

LF602F

LF602F

Use the kind of cables shown in Table 5.1 to wire the converter.

Name	Cable name	Nominal cross-sectional area	Finished outer diameter	Description		
Power cable	3-core vinyl sheathed cable or 2-core vinyl sheathed cable	2 mm²	11~13mm	CVV -JIS C 3401, IEC60695, IEC60754, IEC60227, IEC60245 or equivalent		
Output signal cable	The number of conductors the cable the specification of the output signa Use a shielded cable of finished ou nominal cross-sectional area 1.25m	CVV-S JIS -258-C or equivalent				
Flow rate signal cable	2-core shielded chloroprene cabtyre cable	0.75 mm²	11~13m m	2PNCT-S JIS C 3327 or equivalent		
Excitation cable	3-core shielded chloroprene cabtypre cable	2 mm² 1.25 m²	11~13m m	2PNCT JIS C 3327 or equivalent		

Table 5.1 Installation Cables

5.2 External Device Connections and Grounding

5.2.1 LF600F Type

The terminal board connections of an integral type converter LF600F are shown in Figure 5.1. Proceed with wiring as described in Section 5.4, "Wiring Procedure."



Figure 5.1 External Wiring Schematic Diagram

- * Use a heavy copper braid or wire (cross-sectional area 5.5 mm² minimum) to ground the terminal and make it as short as possible as shown in Figure 5.1 for grounding. Also, Avoid a common ground where earth current may flow. (An independent ground is preferable.)
- * The converter has no power switch. Install the power switch at the system side. Be sure to use a double-pole/single-throw (both disconnection) wiring breaker.

TOSHIBA

٢

5.2.2 LF602F Type



Figure 5.2 External Wiring Schematic Diagram

5.3 Notes on Wiring

5.3.1 Notes on Instrumentation-Converter Wiring

- To avoid 2-point grounding, ground the shield of output cable basically at the receiving side.
- Use a grounding wire of IV wire 5.5mm² or more. The size of the external grounding terminal screws is M4. Do not share a grounding wire with other instruments where grounding current may flow. (An independent grounding is preferable.)
- Power cable

When a 3-core cable is used: Ground with the FG terminal.

When a 2-core cable is used: Use an external grounding terminal and make the cable as short as possible. Note that, for a replacement from the Toshiba electromagnetic flowmeter converter LF220 type, the cable grounding position differs.



5.3.2 Notes on Wiring of the LF602F Type

- The detector is shipped with a flow rate signal cable and excitation cable. Be sure to use those cables coming with the detector.
 - Note: When the cable length exceeds 30m, cables may not be supplied. Check whether the cable is supplied with the specs.
 - The allowable cable length between the detector and converter varies depending on the conductivity of the operating fluid. **Refer to the instruction manual of the combined detector.**
 - When connecting with the detector, wire the cables in the order of the excitation cable and flow rate signal cable.
 - Because the input cables transmit very delicate signals, pass the excitation cable and input signal cable separately through a thick steel conduit tube, keep them away from the large current wiring as far as possible, and do not install them in parallel.
 - When replacing the flow rate signal cable and excitation cable, also refer to the instruction manual of the relevant detector. Order the detector terminal box cover packing from Toshiba or a Toshiba distributor.

5.4 Wiring

IMPORTANT

The cable glands is not provided in the conduit port of this apparatus.

Please prepare yourself for the cable glands which could be used in Division2 hazardous locations.



5.4.1 Grounding



(1) Grounding the LF600F type

Ground as shown in Figure 5.3. Make the grounding wire as short as possible. Use grounding wire material of IV wire 5.5mm² or more. Do not share a grounding wire with other instruments where grounding current may flow. (An independent grounding is preferable.)



Figure 5.3 Grounding the LF600F Type

TOSHIBA



(2) Grounding the LF602F type

Ground the external grounding terminal of the detector and the FG terminal of the converter (or external grounding terminal of the converter) securely (grounding resistance 100Ω or lower). Use grounding wire material of IV wire 5.5mm² or more. Do not share a grounding wire with other instruments where grounding current may flow. (An independent grounding is preferable.)

If it is difficult to perform grounding work at the detector side because of a pit installation or other reasons, use a 3-core cable for the excitation cable and connect the E terminal of the detector to the E terminal of the converter. (The E terminal of the converter is internally connected with the FG terminal and the converter case.)



Figure 5.4 (a) Wiring between Detector and Converter (For grounding the detector, see Figure 5.5 below.)

Figure 5.4 (b) Wiring between Detector and Converter (when grounidng of the detector is difficut)



 If the piping material is conductive, connect the grounding wires to the both ends of the piping flange.

 If the piping material is non-conductive, perform grounding resistance 100Ω or less.

Figure 5.5 Grounding the Separate Type Detector

5.4.2 Terminal Treatment of Cables

Follow the procedures below to treat the terminals (at the converter side) of various cables and install the cables to the terminal block. Use appropriate cables based on the description in Section 5.1 "Cables." Crimp a round type insulated crimp-type terminal to the end of the cables.

(1) Power cable, current output cable, digital I/O cables

The necessary cables should be ordered from the person responsible for the installation. Strip the sheath of each conductor as shown in Figure 5.6 and attach a crimping terminal with insulated sleeve to it. The size of the crimping terminal is as follows:

Integral type LF600F: M4

Separate type LF602F: M3.5

- Connect the power cable to terminal blocks L1 and L2.
- Connect the current output cable to terminal blocks + and -.
- Connect the digital I/O cable to terminal blocks D1, D01, D02 and COM, as required.



Figure 5.6 Terminal Treatment of Power Cable, Current Output Cable and Digital I/O cable

(2) Excitation cable

LF602F

Strip the sheath from the end of each conductor as shown in Figure 5.7, attach an M3.5 crimping terminal with insulated sleeve, and connect it to the terminal blocks X and Y. Connect the red conductor to terminal block E.



Figure 5.7 Terminal Treatment of Excitation Cable

28 —

LF602F

(3) Connecting the input signal cable:

Strip the sheath from the end of each conductor of a 2-core individually shielded cable as shown in Figure 5.9. Twist those shields and cover them with a thermal contraction tube or vinyl tube not to make contact with the case or core wires. Then attach an M3.5 crimping terminal with insulated sleeve as shown in Figure 5.8. Connect a crimping terminal to the A and B terminals on the terminal block and connect to each G terminal of the detector and converter.



Figure 5.8 **Terminal Treatment of Flow Rate Signal Cable**

Notes on signal cable shield processing work

When stripping an external sheath, intermediate and insulated sheath, be careful not to scratch or cut the internal conductors and shield mesh. Do not disjoint the shield mesh but treat it as shown in Figure 5.9.



Treating the Signal Cable Shield Mesh Figure 5.9

5.4.3 Cable Connection

- (1) Connect and install the terminal-treated cables to the terminal block.
 - *Connect the cables to the terminal block securely. A loose connection may cause incorrect measurement. After connecting a cable, try to pull it to check whether it has been connected securely.

Referring to Section 5.2 "External Device Connections and Grounding", connect each cable to the terminal block. Tighten the screws of the terminal block tightly to ensure the secure connection. A loose connection may cause incorrect measurement. After connecting a cable, try to pull it to see whether it has been connected securely.





5.5 Digital I/O Connections

Digital I/O terminals consist of contact output terminals (DO1 and DO2), voltage signal input terminal (DI, optional), and signal common terminal (COM). Each terminal (DO1, DO2 and DI) is isolated from internal circuits. Terminal (COM) is the signal common for the other three terminals (DO1, DO2 and DI).

Functions can be assigned for each terminal with the LCD control keys. See Chapter 10, "Digital I/O Functions."

To connect an electromagnetic relay or counter to the contact output terminal (DO1 or DO2), put a surge-absorbing diode into the input circuit of the relay or counter. See Figure 5.11 for an example of electromagnetic counter connection.



*1...Digital output D02 and voltage signal input DI are optional.

Figure 5.11 Electromagnetic Counter Connection Example

- Note 1: Use a surge-absorbing diode of the rating: current rating 1A and voltage rating 200 V minimum.
- Note 2: In the case of standard specification (digital input DI, no output DO2), the semiconductor contact point, photo coupler and resistor are not built in. Leave DI and DO2 disconnected.
- Note 3: When a power supply-built-in electronic counter is used, the serge-absorbing diode is not required.

6. Operation

 Do not touch the terminal board when power is supplied. Touching the terminal board when power is supplied can cause electric shock. 	 Do not touch the main body when high temperature fluid is being measured. The fluid raises the main body temperature and can cause burns. 				

6.1 Preparatory check

Follow the procedure described below to prepare before starting the flow measurement (described with regard to the entire flowmeter).

System Check

Check the items listed below

- Check the wiring between the converter and related instruments.
- Make sure all the bolts of connection flanges on which the flowmeter is mounted securely tightened.
- Make sure the direction of flow arrow is in accordance with actual flow.
- Make sure the flowmeter is grounded with 100 ohm or less ground resistance.
- Make sure the **converter housing covers** are securely tightened.

Placing System On-Stream

- Let the fluid go through the detector pipe. (Note 1)
- When the detector is filled with the fluid, stop the fluid and keep it still in the detector pipe.

Supplying Electric Power

■ Make sure the **power supply** is as specified.

Checking Converter Parameters

Check the configuration parameter settings. Refer to Chapter 7, "LCD Display and Controls," Chapter 8, "Configuration Parameter Setting," and Chapter 11, "Communications Function."

Zero Adjustment

- Wait for 30 minutes to warm up the flowmeter. Then making sure the fluid holds still in the detector pipe, starts the zero adjustment.
- Refer to 6.2, "Zero Adjustment."

On-line measurement

■ After checking the items and conducting the zero adjustment as listed above, let the fluid go through the detector pipe. Output (4–20 mA dc) directly proportional to the flow rate can be obtained.

Note 1: If the detector pipe is not filled with the fluid to be measured, the flow rate will be indefinite and unable to be measured. Before using the flowmeter, be sure to fill the detector pipe the fluid to be measured.

6.2 Zero Adjustment

To conduct zero adjustment of the flowmeter, the fluid in the detector pipe must be held still.

There are three different ways to start the zero adjustment:

- (1) Pressing a combination of control keys for the model with LCD display See 8.2.19 "Still Water Zero Adjustment"
- (2) Sending a command signal from a HART communications device (a communication device such as hand-held terminal AF900 is required) See the instruction manual of hand-held terminal you use.
- (3) **PROFIBUS communication (a communication device for PROFIBUS is required)** See the instruction manual of communication device you use.

7. LCD Display and Controls

7.1 Name and Function of Each Part of LCD Display

The LDC display and infrared switches (hereafter, called "control key") in front of the converter allows you to view or set various constants such as measured values and parameters.



Instructions

The operation principle of infrared switch is to irradiate infrared to the front of control panel and detect the reflection from finger when operating.

Normal operation is impeded depending on the conditions such as disturbing light from surroundings or stain attached to the control panel. When unable to avoid such condition, operate the EMF converter in the following manner.

Remove the factor to impede proper operation of infrared switch as below:

- · Cover the control panel by hand so that light does not shine on it
- · Clean the stain attached on the control panel
- Clean the stain on the finger or the gloves to operate the EMF converter, or wear gloves in light color
- When there is a reflecting object placed opposing to the control panel, stand in-between the reflecting object and the control panel to block the light

Following are considered as the factors to impede infrared switch to operate properly.

- · Intense light such as direct sunlight and reflected sunlight by window glass or metal plate
- Place where brightness changes always such as ON/OFF of lighting
- Dense smoke or steam near the control panel
- Those attached on the control panel such as rain (dew drop), snow, ice, mud and oil, and haze due to their attachment
- Operation of the control panel by hands wearing gloves in dark color or stained fingers and gloves
- Light reflecting object near the control panel, or reflecting object such as metal plate placed opposing to the control panel

LCD display

An 8-line × 14-character liquid crystal display. The backlit display enables an easy-to-read indication even under poor lighting conditions. Instantaneous flow rates or totalized flow in the measurement mode, or configuration parameters in the setting mode can be displayed. (Number of LCD display dots: 128 x 128 dots)



(1) Control key indicator

Indicates the function (on the current screen) of the key switches around the LCD. This indicator is usually turned off. It turns on when you hold down any of the three control keys for 3 seconds or longer.

② Measured value main display

Displays a measured value of the type the operator has selected. In the main display, a numeric value is displayed in large size.

③ Measured vale sub display

Displays a measured value/setting value of the type the operator has selected. Or displays an error message. When an error message is displayed, no measured value/setting value is displayed (error message-precedence display).

Setting switch

The control keys allow you to perform converter control and setting, without opening the converter housing.

These three controls keys function differently depending on the current display screen.

The functions of these control keys are displayed on the display screen.

In this product, the display method can be changed according to the converter installation direction. For example, if the control keys are installed so that they are located above the display, they can be displayed appropriately as shown below, by changing the display method.







Above the control keys Left of the control keys Right of the control keys
TOSHIBA

7.2 Display Format

In the measurement mode, measured data is displayed for the item set by the main display setting (MAIN DSP) and sub display setting (SUB DSP).

(For display setting, see 8.1.5 "Display Setting.")

[Format of main display]

Flow rate value display



Unit: The unit is displayed right aligned (up to 7 digits) Numeric value: Up to 7 digits including a decimal point are displayed. (Up to 9999999)

4 significant digits: For the set span

Flow direction: When the flow direction is forward direction, " " (blank) is displayed. When the flow direction is reverse direction: "-" is displayed.

Total count value display



"CNT" is displayed during total counting. Numeric value: Up to 99999999. In the case of forward flow direction, "FOR" is displayed. In the case of reverse flow direction, "REV" is displayed.

Total flow value display



Flow rate unit: Displayed right aligned (up to 5 digits). "CNT" is displayed during total counting.

Numeric value: Up to 8 digits including a decimal point are displayed. (Up to 99999999)

Displayed to the least significant digit of the set pulse rate. Total value for the forward flow direction: "FOR" is displayed.

Total value for the reverse flow direction: "REV" is displayed.

Total difference flow value display

				10.03		· · · · · · · · · · · · · · · · · · ·	
DF	T 0	T	AL	-			
0	9	9	g		9	9	
			±\$	<u> </u>			
	C	N	T			m I	<u>]</u> ,
					Y		Flow rate unit: Displayed right aligned (up to 5 digits). "CNT" is displayed during total counting.
			L				Numeric value: Up to 8 digits including a decimal point are displayed. (Up to 99999999)
							Displayed to the least significant digit of the set pulse rate.
							Sign: When the difference flow rate is in the forward direction: +
							(plus) display
							When the difference flow rate is in the reverse direction: $-(minus)$ display

- Note: The total flow value and the total difference flow value are displayed to the least significant digit of the set count rate.
 - Example: When the set count rate is 0.0001 m^3
 - The total flow / total difference flow display becomes $000.0000m^3$ and the value increases in the unit of 0.0001 m³.
 - If the values reaches 999.9999 m^3 , the display changes to 1000.000 m^3 at the next count

In the end, the display becomes 99999999 m³.

- When the set count rate is 10 m^3
- The display becomes 00000000 m^3 and the value increases in the unit of 10 m³.

Percent display



Unit: Fixed to"%".
Numeric value: A percent value of max.125.0% is displayed.
Displayed to one decimal place (0.1%).
The sign position is fixed.

Custom value display



Unit: The unit consists of a maximum of 7 digits. Numeric value: Up to 7 digits including a decimal point are displayed. (Up to 9999999)

5 significant digits: value obtained by multiplying m3/min by the set coefficient

- Sign:

In the case of forward direction: "+"

In the case of reverse direction: "-"

TOSHIBA

• Range display



In the range display, the range currently being used is displayed (any one of ranges 1 to 4). The screen example above shows that range 1 is currently being used.

If multiple ranges have been set, the range displayed is switched automatically as the range used is changed.

During communication

During HART communication, a mark is displayed in the rightmost column of the item name display field in the main display section. During PRFIBUS communication, nothing is displayed.

ΡΙ	ER	C	E		T		M	
			•	1	0	0	0	
					-		%	

- Displayed during HART communication.

[Format of sub display]

• Flow rate value display



Unit: The unit is displayed right aligned (up to 7 digits). Numeric value: Up to 7 digits including a decimal point are displayed.

(Up to 9999999)

4 significant digits: For the set span Flow direction:

Forward diction: "W"(blank) is displayed. Reverse direction: "-"is displayed.

Total count value display



"CNT" is displayed during total counting. Numeric value: Up to 99999999 In the case of total value for the forward flow direction, "FOR" is displayed. In the case of the total value for the reverse flow direction, "REV" is displayed.

Total flow value display



Flow rate unit: Displayed right aligned (up to 5 digits).

"CNT" is displayed during total counting.

Numeric value: Up to 8 digits including a decimal point are displayed. (Up to 99999999)

Displayed to the least significant digit of the set pulse rate.

In the case of total value for the forward direction, "FOR" is displayed. In the case of total value for the reverse direction, "REV" is displayed.

Total difference flow value display

	-	 			·	-	.		· · · · · · · · · · · · · · · · · · ·		7	
D	F		Τ	0	T	A	L			ļ	<u> </u>	
		L	_	0	0	9	9	9	<u> </u>	9	9	
			Υ	C	N	T	Y				m	
								-		~		 Flow rate unit: Displayed right aligned (up to 5 digits). "CNT" is displayed during total counting. Numeric value: Up to 8 digits including a decimal point displayed. (Up to 99999999) Displayed to the least significant digit of the set pulse ra Sign: When the difference flow rate is for the forward direct: + (plus) display. When the difference flow rate is the reverse direction: - (minus) is displayed.

Percent display



In the range display, the range currently being used is displayed (any one of ranges 1 to 4). The screen example above shows that range 1 is currently being used.

If multiple ranges have been set, the displayed range is switched automatically as the range used is changed.



Bar graph display

* In the percent value display in the case of range type, percent display, and graph indication, the % value to be displayed depends on the flow direction. However, the % value in the graph indication is displayed as shown in the table below.

Range type	Input signal	% value in percent display	% value in graph display	4-20mA output
Forward direction only	Forward direction 50%	50%	50%	12mA
Forward direction only	Reverse direction 50%	-50%	0%	4mA (lower limit)
Forward/Reverse	Forward direction 50%	50%	50%	12mA
Forward/Reverse	Reverse direction 50%	-50%	50%	12mA

Custom value display



7.3 Basic operations

7.3.1 Mode Change

The converter provides the setting mode and calibration mode, in addition to the measurement mode. When you want to move to the setting mode or calibration mode, use the "SET" key. To return to the measurement mode, select "MEAS MODE" from menu items (A to N).

Measurement mode:

measures the process flow and displays and outputs the measured process values. The flowmeter can measure the flow velocity, flow rates, or totalized flow. The flowmeter first goes into this mode when power is turned on.

Setting mode:

used to check or change various configuration parameters used in the measurement mode. These parameter values are displayed while checking or changing these values but the flowmeter outputs the measured process values as in the measurement mode. See 7.4, "Configuration Items Selection Table" and 8.2, "Checking or Changing Parameters" for details. Configuration items are from A1, A2, A3 to M1.

Calibration mode:

used to check the converter internal circuits. The internally generated simulation signal is used to check the measuring span and excitation current value. The current output of the

flowmeter changes in accordance with the simulation signal. The status of each digital output is held to the value just before the system moved into the calibration mode.

See 7.4, "Configuration Items Selection Table" and Chapter 9, "Calibration" for details. Configuration items are from N1 to N4.

OChange mode flow

[SET] [SEL] [ENT] in the flow chart describe the switch operation, and by pressing the switches described below, you are allowed to move to the items, which are directed by arrows.



* When the mode shifts to measurement mode from setting mode, confirmation message is displayed. You can cancel operation then.

OMode switching

The electromagnetic flowmeter usually operates in the measurement mode.

When you need to perform parameter setting, calibration and adjustment, you enter the setting mode.

To enter the setting mode, hold down center key for 3 seconds or longer.

Holding down the desired key for 3 seconds or longer will display screen of code input. When "111" was input with this screen, [SET] and [CNT] (for switch operation) are displayed in the measurement screen. When the code except "111" was input, label is not displayed.

Please operate it as follows after label was displayed.

[SET] key	You enter the setting mode (the menu configuration setting screen is displayed).					
[CNT] key	The screen is switched to the total count control screen, enabling you to manipulate the total counter.					

Note: If password has been set, the password input screen appears when you move from the measurement mode to the menu configuration setting screen (when you press the [SET] key) and when you move to the total count control screen (when you press the [CNT] key).

If the password you enter does not match, you will be unable to change some of the parameters. Also you will be unable to clear the total count when you are manipulating the total counter.

OFunction of operation time-out

When a converter is state of the setting mode, and there is not operation more than 1 minute, mode returns to the measurement mode automatically.

Menu display Parameter confirmation display	A: MEAS MODE →EX CURRENT METER SIZE EX FREQ FLOW DIRECTN PASSWORD ADDR SET [SEL] [ENT] A1: EX CURRENT 0.19000 A [EXT] [ENT]	Mode returns to the measurement mode automatically
Parameter change display	A1: EX CURRENT 0.1900 A [U P] [SEL] [SET]	Mode does not return to the measurement mode

- 44 —



7.3.2 Setting and Calibration

Process as follows to select the desired items, to check or change the item setting value.

"Key operation" indicates the key to be pressed.

When you are incrementing the numeric counter by pressing the [UP] key or when you are incrementing or decrementing the numeric and alphabet counter by pressing the [UP] key/[DWN] key, you can perform continuous operation by holding down the relevant key (Holding down the key causes the numeric or alphabetic character count to be increased/decreased).

Moving to the menu display

Key operation	Display example	Description
	FLOW	Measured value being displayed (measurement
	002.000	mode)
	m/s	
	RANGE1	
	5.000	
	m/s [CNT] [SET]	· · · · · · · · · · · · · · · · · · ·
	MENU SELECT	Pressing the [SET] button when you are in the
	→BASIC	measurement mode takes you to the menu
1057	DETAILED	configuration selection screen.
[SET]		Select BASIC or DETAILED configuration.
	[SEL] [ENT]	
		Pressing the [ENT] key in the menu configuration
	MEAS MODE	selection screen takes you to the menu display
	EX CURRENT METER SIZE	screen. The cursor is positioned on an alphabetical
[ENT]	EX FREQ	character representing a group name ([A] in this
	FLOW DIRCTN	example).
	PASSWORD	
	ADDR SET	* This screen is an example of display that appears
	UP [DWN] [ENT]	when you select the DETAILED menu.
	B:	Pressing the [UP] key when the cursor is positioned
	MEAS MODE	on an alphabetical character causes the
		alphabetical character to be incremented. (Pressing the [DWN] key causes the alphabetical character to
[UP]	SUB DISP CUSTOM DATA	be decremented.)
lori	CUSTOM UNIT	be decremented.)
	LCD ADJUST	In addition, the display contents are switched to the
	SW POSITION	menu list associated with the alphabetical character.
	[U P] [DWN] [ENT]	
	B:	When you press the [ENT] key, the cursor on the
	MEAS MODE	alphabetical character disappears and an arrow
	→MAIN DISP	mark is displayed in the item list display field.
[ENT]	SUB DISP CUSTOM DATA	In addition, the [UP] key changes to the [SEL] key.
	CUSTOM UNIT	
	LCD ADJUST	
	SW POSITION	
	[SEL] [ENT]	
	B:	Every time you press the [SEL] key, the arrow mark
	MEAS MODE	comes down one line at a time. Pressing the [SEL]
		key further when the arrow mark is positioned on
(051)	SUB DISP CUSTOM DATA	the bottom item line causes the arrow mark to return to the top item line.
[SEL]	\rightarrow CUSTOM UNIT	
	LCD ADJUST	
	SW POSITION	
	[SEL] [ENT]	
	B4:	When you press the [ENT] key, the setting screen
	CUSTOM UNIT	for the setting item that the arrow mark points to
[ENT]	XXX/YYY	appears and enables you to set/check the
[[]		parameter.
L	[EXT] [ENT]	

Key operation	Display example	Description
	C: MEAS MODE RANGE TYPE →RANGE 1 RANGE 2 RANGE 3 RANGE 4 RANGE HYS [SEL] [ENT]	Menu display for group C Use the [SEL] key to move the arrow mark to RANGE 1.
[ENT]	C2: RANGE1 2.000 m/s	Use the [ENT] key to select the item you want to check/change. The screen is changed to a screen where the current setting value is displayed, enabling you to check the setting value.
	[EXT] [ENT]	Pressing the [EXT] key will return you to the menu screen.
[ENT]	C2: RANGE1 2.00000 m/s [U P] [SEL] [SET]	When you press the [ENT] key, the cursor appears on the setting value and you are ready to change the setting value.
[UP]	[U P] [SEL] [SET]	Ready to change the setting value. Pressing the [UP] key increments the numeric character in the place where the cursor is currently positioned. (Holding down this key causes the increment operation to be continued.) * Pressing the [UP] key when the cursor is positioned below the unit will change the unit to the next one. In addition, when you set a natural number, a decimal point appears in addition to numeric characters (except for the most significant digit).

• Checking/setting of setting value

Key operation	Display example	Description
	C2:	Ready to change the setting value.
[SEL]	RANGE1 300000 m/s	Pressing the [SEL] key causes the cursor to move to the next digit.
	[U P] [SEL] [SET] C2:	Ready to change the setting value.
[UP] [SEL]	EANGE1 .00000 m/s [U P] [SEL] [SET]	You can change the setting value by using the [UP] and [SEL] keys. In this example, 5.000 m/s is selected.
(SET)	C2: RANGE1 5.00000 m/s OK? [N O] [SET]	Pressing the [SET] key causes the data to be set temporarily. The cursor disappears and a confirmation message is displayed.
[NO]	C2: RANGE1 2.00000 m/s	If you want to cancel the data change here, for example, because the temporarily set data is incorrect, press the [NO] key, which causes the temporarily set data to return to the original setting value and enables you to change the setting value again.
	[U P] [SEL] [SET] C2:	Pressing the [SET] key when data is temporarily set
[SET]	(EXT) [ENT]	Pressing the [SE I] key when data is temporality set causes the data to be determined and set. After the data is set, the cursor disappears, enabling you to check the setting value. *In the case of the flow velocity unit, the value is automatically rounded to 3 decimal places. In the case of the actual flow rate unit, the value is automatically rounded to 3 significant digits.
[EXT]	C: MEAS MODE →RANGE TYPE RANGE 1 RANGE 2 RANGE 3 RANGE 4 RANGE HYS [SEL] [ENT]	Pressing the [EXT] key returns you to the menu display screen.
[SEL] [ENT]	C: MEAS MODE OK?	By pressing the [SEL] key to move an arrow mark to MEAS MODE and pressing the [ENT] key, confirmation message is displayed. If [NO] key is pushed, operation of shift to measurement mode is canceled.
[SET]	FLOW 002.000 m/s RANGE1 5.000 m/s	By pressing the [SEL] key, you can terminate the setting mode and return to the measurement mode.

.

_

7.4 Configuration Items Selection Table

The check/change menu for each constant to be set for the converter is expanded as shown in the table below.

Details of each item are described in the configuration items (A to M) in Chapter 8 "Configuration Parameter Setting."

OBasic configuration (when the menu configuration is BASIC)

When you select "BASIC" in the menu configuration selection screen, the check/change menu for each constant setting is expanded as shown in the table blow.

	0	1	2	3
В		Main display setting	Sub display setting	
С		Range type	Range 1	
D	Return to the measurement mode	Damping constant	Low cut value	
F		Digital output 1	Digital output 2	Digital input 1
G		Count rate	Pulse width Setting mode	Pulse width

When the operation mode is switched from the measurement mode to the setting mode, group B is displayed first in the case of basic configuration. >

After that, the screen changes as follows:

Group B (start screen) \Leftrightarrow Group C \Leftrightarrow Group D \Leftrightarrow Group F \Leftrightarrow Group G \Leftrightarrow Group B

 \rightarrow :When the [U P] key is pressed (the group is incremented).

 \leftarrow :When the [DWN] key is pressed (the group is decremented).

○ Detailed configuration

When you select "DETAILED" in the menu configuration selection screen, the check/change menu for each constant setting is expanded as shown in the table below.

	0	1	2	3	4	5	6
A		Exciting current setting *1	Meter size *1	Exciting frequency *1	Flow direction setting *1	Password *1	Address setting *1
В		Main display setting	Sub display setting	Custom (coefficient) *1	Custom (unit) *1	LCD density adjustment	Switch position setting
С		Range type *1	Range 1 *1	Range 2 *1	Range 3 *1	Range 4 *1	Range hysteresis *1
D		Damping constant	Low cut value	Current output setting upon alarm occurrence *1	Display low cut Yes/No	Output low limit setting *1	
E		Still water zero point adjustment					
F	Return to the	Digital output 1 *1	Digital output 2 *1	Digital input 1 *1	DO1 alarm output state *1	DO2 alarm output state *1	DI control signal level setting *1
G	measurement mode	Count rate *1	Pulse width setting mode *1	Pulse width*1			
Н	mode	Preset count value *1	Preset output setting *1				
-		High limit alarm ON/OFF *1	High limit value setting *1	Low limit alarm ON/OFF *1	Low limit value setting *1		
J		High high limit alarm ON/OFF *1	High high limit value setting *1	Low low limit value ON/OFF *1	Low low limit value setting *1		
К		Fluid empty alarm *1	Self-diagnosis Yes/No *1	Alarm output preset *1			
M		Limit rate Fixed output *1	Limit time Fixed current *1	Fixed pulse *1			
N		Manual zero					
0		0% Flow value calculation *1	50% Flow value calculation *2	100% Flow value calculation *1	Exciting current display *2		

- Note 1 If you enter a wrong password, you are allowed to check the setting value and to perform calibration for the items with *1 mark in the table. However you are not allowed to change the setting and perform calibration for these items.
- Note 2 The items with*2, you are only allowed to check the calibration value.
- Note 3 For function A2, you are only allowed to check the setting value.

7.5 Password input

The converter provides the password function to prevent some functions that affect the flow rate measurement from being set or adjusted. For the limited functions, see Chapter 5 "Items Protected with Password.

- * If a password '000' is set, the password input screen does not appear. If a password other than '000' is set, you can enter your password following the procedures below.
- * You can also use the following procedures to enter a password for releasing adjustment menu protection.

Key operation	Display example	Description
	FLOW 002.000 m/s RANGE1	The measured value being displayed (measurement mode)
	5.000 m/s [CNT] [SET] INPUT PASS	When you switch the measurement mode to the
[SET]	000	setting mode by pressing the [SET] key, the password input screen is displayed if the password has been set.
	[U P] [SEL] [SET]	
[UP]	INPUT PASS	Press the [UP] key to increment the digit in a place where the cursor is positioned (Holding down this key causes this increment operation to be continued.) In this example, 1 is set.
	[U P] [SEL] [SET]	
[UP] [SEL]	INPUT PASS	Pressing the [SEL] key changes the position of the cursor. By pressing the [UP] and [SEL] keys, change the password to 123.
	[U P] [SEL] [SET]	
	MENU SELECT →BASIC DETAILED	Pressing the [SET] key causes the password to be written and the menu configuration selection screen to appear.
[SET]	[SEL] [ENT]	The menu configuration selection screen appears, regardless of whether the entered password is correct or wrong. However, if the entered password is wrong, you are not allowed to change the setting value or perform calibration. For more information, see Chapter 5 "Items Protected with Password."

• An example of entering a password (when the password is 123)

8. Configuration Parameter Setting

8.1 Configuration Items

To check/change menu for each constant to be set for the converter, first select the desired configuration item as described in 7.3.2. The configuration items are listed below. See each section for detailed procedure.

No.	Function item	Display example
8.2.2	Exciting current setting	EX CURRENT
8:2.3	Meter size	METER SIZE
8.2.4	Exciting frequency	EX FREQ
8.2.5	Flow direction setting	FLOW DIRCTN
8.2.6	Password	PASSWORD
8.2.7	Address setting	ADDR SET
8.2.8	Display setting	MAIN DSP / SUB DSP
8.2.9	Custom coefficient setting	CUSTOM DATA
8.2.10	Custom unit setting	CUSTOM UNIT
8.2.11	LCD density adjustment	LCD ADJUST
8.2.12	Switch position setting	SW POSITION
		RANGE TYPE,
8.2.13	Span (Range)	RANGE1 (~RANGE4),
		RANGE HYS
8.2.14	Damping constant	DAMPING
8.2.15	Low cut value	LOW CUT
8.2.16	Output at alarm occurrence	ALM mA SET
8.2.17	Display low cut Yes/No	DSP LOW CUT
8.2.18	Output low limit setting	LOW LIMIT
8.2.19	Still water zero point adjustment	ZERO ADJUST
0 0 00		DO1 FUNCTN, DI FUNCTN,
8.2.20	Digital input/output	DO1 ALM STS, DI DET LV
	Count rate	COUNT RATE, PLS MODE,
8.2.21	Pulse width setting mode	PLS WIDTH
	Pulse width	
8.2.22	Preset count value	PRESET CNT
8.2.23	Preset output state	PRESET FNC
		H ALM SET / H ALM VAL,
8.2.24	High/Low limit alarm ON/OFF	L ALM SET / L ALM VAL,
0.2.24	High high/Low low limit alarm ON/OFF	HH ALM SET / HH ALM VAL,
	· ·	LL ALM SET / LL ALM VAL,
8.2.25	Fluid empty alarm	EMPTY ALM
8.2.26	Self-diagnosis Yes/No	SELF CHECK
8.2.27	Alarm output preset	ALM PRESET
8.2.28	Limit rate Limit time	LIMIT RATE / LIMIT TIME
		FIXED OUT, FIXED CURR,
8.2.29	Fixed output	FIXED PULSE
8.2.30	Manual zero	MANUAL ZERO

8.2 Check/Change of Parameters

8.2.1 Menu Configuration Selection Screen

 \bigcirc Menu configuration selection screen

Display example

	Е	N	U		s	Е	L	Ε	С	Т	
l	В	Α	S	I	С						
	D	Е	Т	Α	1	L	Ε	D			

This screen allows you to select the menu construction you want to use.

For the menu contents to be expanded according to the selected configuration, see 7.4 "Configuration Items Selection Table."

BASIC: Only the basic parameters are displayed. Nothing is displayed in the other parameter display field.

DETAILED: All parameters are displayed.

8.2.2 Exciting Current Value

The exciting current value can be checked/changed by the following procedures.

Be sure to match the exciting current value with the value specified for the combined detector.

Specifying any other value may cause an error.

Shown below is an example of changing the exciting current value from 0.1900A to 0.2150A.

Key operation	Display example	Description
	A: MEAS MODE →EX CURRENT METER SIZE EX FREQ FLOW DIRECTN PASSWORD ADDR SET [SEL] [ENT]	In the configuration items selection screen, select "EX CURRENT."
STEP1	A1: EX CURRENT 0.20000	The currently set exciting current value (in this example 0.1900A) is displayed.
[ENT]	A [EXT] [ENT]	Then press the [ENT] key. * Pressing the [EXT] key returns you to the menu screen.
STEP2 [ENT]	A1: EX CURRENT 0.1900 A	The switch name display at the bottom changes. (three keys [UP], [SEL] and [SET]) At the same time, the cursor appears. (The digit in the place the cursor position is currently positioned is reverse-displayed.)
	[U P] [SEL] [SET]	Then press the [SEL] key.
STEP3 [SEL]	A1: EX CURRENT 0. [900 A	You can continue to change the setting value. Press the [SEL] key to move the cursor to the digit you want to change. Then press the [UP] key.
	[U P] [SEL] [SET]	
STEP4 [UP]	A1: EX CURRENT 0.2900 A	You can continue to change the setting value. Pressing the [UP] key increments the digit in the place the cursor is currently positioned. (Holding down this key causes this increment operation to be
	[U P] [SEL] [SET]	continued).

.

Key operation	Display example	Description
STEP5	A1: EX CURRENT 0.21 <mark>5</mark> 0	Repeat this operation to change the setting value to 0.2150A.
[SEL]⇔[UP]	A	When the value changes to the desired value, press the [SET] key to set the numeric value temporarily.
	[U P] [SEL] [SET]	
STEP6	A1: EX CURRENT 0.2150	Pressing the [SET] key displays a message asking you to confirm whether the setting is OK. If OK, press the [SET] key. If you need to redo the
[SET]	OK?	setting, press the [NO] key.
07507.4	[N O] [SET]	
STEP7-1	A1: EX CURRENT 0.1900	Pressing the [No] key when you are asked "OK?" causes the numeric value to return to the previous value and enables you to redo the setting.
[NO]	A .	
	[U P] [SEL] [SET]	
STEP7-2(=END)	A1: EX CURRENT 0.2150	Pressing the [SET] key when you are asked "OK?" causes the setting value to be determined. Then if you press the [EXT] key, you return to the
[SET]	A	menu screen. If you press the [ENT] key, you can restart electric current value change operation from a state of
	[EXT] [ENT]	0.2150A.

(Note) The exciting current value must be a value from 0.0000A and 0.2500A.

If you set an exciting current value higher than 0.2500A, *HIGH OVER SPEC.* is displayed and the set value is returned to the value before change. In this case you have to set a value once again.

8.2.3 Meter Size

Proceed as follows to check or change the meter size of the detector.

Key operation	Display example	Description
	A:	Select "METER SIZE" in the configuration item
	MEAS MODE	selection screen.
	EX CURRENT	
	→METER SIZE	
	EX FREQ	
	FLOW DIRECTN	
	PASSWORD	
	ADDR SET	
	SEL] [ENT]	
STEP1	A2:	The currently set meter size (50mm in this example) is
	METER SIZE	displayed.
•	50	
[ENT]	mm	Then press the [ENT] key.
		* Pressing the [EXT] key returns you to the menu screen.
	[EXT] [ENT]	
STEP2	A2:	The switch name display at the bottom changes.
	METER SIZE	(Three keys [UP], [DWN] and [SET] are displayed)
	50	At the same time, the cursor appears.
[ENT]	mm	
		Then press either [UP] or [DWN].
	[U P] [DWN] [SET]	
STEP3	A2:	You can continue to change the setting value.
	METER SIZE	Pressing [UP] or [DWN] key changes the selection item.
	65	[UP]: Selection item count increases
[UP]/[DWN]	mm	[DWN]: Selection item count decreases
	U P] [DWN] [SET]	
STEP4	A2:	Repeat this operation to change the setting value to
	METER SIZE	150mm.
	150	When the desired selection item appears, press the [SET]
[UP]/[DWN]	mm	key to temporarily set the item.
STEP5	[U P] [DWN] [SET]	Proceing the ISETI key displays a message asking you to
51642	A2:	Pressing the [SET] key displays a message asking you to confirm whether the setting is OK or not.
	METER SIZE 150	If OK, press the [SET] key. If you need to redo the setting,
ISETI		press the [NO] key.
[SET]	mm	
	OK?	
	[N O] [SET]	

Key operation	Display example	Description
STEP6-1 [NO]	A2: METER SIZE 50 mm	Pressing the [NO] key when you are asked "OK?" causes the number value to return to the previous value and enables you to redo the setting.
	[U P] [SEL] [SET] A2:	Pressing the [SET] key when you are asked "OK?" con-
STEP6-2(=END)	METER SIZE	firms the setting at this point.
	150	Then if you press the [EXT] key, you return to the menu
(SET)	mm	screen.
		If you press the [ENT] key, you can go to the frequency change operation starting from the condition of 150mm.
	(EXT) (ENT)	

Note 1: The meter size display loops as shown below:

$$1 \longrightarrow 2.5 \text{mm} \longrightarrow 4 \text{mm} \longrightarrow 6 \text{mm} \longrightarrow 15 \text{mm} - - \rightarrow 600 \text{mm} \longrightarrow 2$$

$$2 \longrightarrow 0.1 \text{inch} \longrightarrow 0.16 \text{inch} \longrightarrow 0.25 \text{inch} \longrightarrow 0.5 \text{inch} - - - \rightarrow 24 \text{inch} \longrightarrow 1$$

Note 2: The range unit and the count rate will be forcefully set as shown below when the meter size is changed. Set each parameter again, if necessary.

Range unit	"m/s"
Count rate	If the count rate goes out of the setting range when the meter
	size is changed, the set value will be forcefully set to zero.

Note 3: The exciting frequency setting may become inappropriate for the set value when the meter size of the detector is changed. If the exciting frequency is the value shown below when the meter size is changed, the exciting frequency will be forcefully changed.

Setting m	eter size	Set exciting frequency	Forcefully set exciting frequency
(mm)	(inch)		
2.5 ~ 200	0.1 ~ 8	_	Not forcefully set
250 ~ 450	10 ~ 18	24Hz	12Hz
500, 600	20, 24	12Hz, 24Hz	6Hz

8.2.4 Exciting Frequency

You can select an exciting frequency of 6Hz, 12Hz or 24Hz.

Since each exciting frequency value has its own characteristics, you should select an appropriate exciting frequency (24Hz is set at shipment. **Depending on the characteristics of the detector, a** large frequency may result in excitation failure. When a large frequency value is set and it changes the indicator value, decrease the frequency to a value that will not change the indicator value.)



Shown below is an example of changing the exciting frequency from 24Hz to 12Hz.

Key operation	Display example	Description
	A: MEAS MODE EX CURRENT METER SIZE →EX FREQ FLOW DIRECTN PASSWORD ADDR SET [SEL] [ENT]	Select "EXFREQ" in the configuration item selection screen.
STEP1	A3: EX FREQ 24	The currently set exciting frequency value (24Hz in this example) is displayed.
[ENT]	Hz	Then press the [ENT] key. * Pressing the [EXT] key returns you to the menu
	(EXT) (ENT)	screen.
STEP2 [ENT]	A3: EX FREQ Hz	The switch name display at the bottom changes (three keys [UP], [DWN] and [SET]) At the same time, the cursor appears.
	[U P] [DWN] [SET]	Then press the [UP] or [DWN] key.
STEP3 [UP]/[DWN]	A3: EX FREQ 6 Hz	You can continue to change the setting value. Pressing the [UP] or [DWN] key switches the selection item. [U P]: The selection item is incremented. [DWN]: The selection item is decremented.
	[U P] [DWN] [SET]	

۰.

Key operation	Display example	Description
STEP4	A3: EX FREQ Hz	Repeat this operation to change the setting value to 12Hz.
[UP]/[DWN]		When the value changes to the desired selection item, press the [SET] key to set the item temporarily.
	[U P] [DWN] [SET]	
STEP5	A3: EX FREQ 12	Pressing the [SET] key displays a message asking you to confirm whether the setting is OK. If OK, press the [SET] key. If you need to redo the
[SET]	Hz	setting, press the [NO] key.
	OK? [N O] [SET]	· · · · · · · · · · · · · · · · · · ·
STEP6-1	A3: EX FREQ 24	Pressing the [No] key when you are asked "OK?" causes the numeric value to return to the previous value and enables you to redo the setting.
[NO]	Hz	
	[U P] [SEL] [SET]	
STEP6-2(=END)	A3: EX FREQ 12	Pressing the [SET] key when you are asked "OK?" causes the setting value to be determined. Then if you press the [EXT] key, you return to the
[SET]	Hz	menu screen. If you press the [ENT] key, you can restart frequency value change operation from a state of
	[EXT] [ENT]	12Hz.

(Note 1) The exciting frequency is displayed cyclically, as shown below.



8.2.5 Flow Direction Setting

In the converter, you can set the flow direction of fluid arbitrarily.

• Flow direction setting

Selection item	Contents	
NORMAL	When the fluid flows in the direction of the arrow indicating the flow direction that is attached to the detector, the indicator	
	value and electric current output value increase.	
SWITCH	When the fluid flows in the reverse direction of the arrow indicating the flow direction that is attached to the detector, the indicator value and electric current output value increases.	

Key operation	Display example	Description
	A: MEAS MODE EX CURRENT METER SIZE EX FREQ →FLOW DIRCTN PASSWORD ADDR SET [SEL] [ENT]	Select "FLOW DIRECTN" in the configuration item selection screen.
STEP1	A4: FLOW DIRCTN NORMAL	The currently set flow direction (NORMAL in this example) is displayed.
[ENT]	[EXT] [ENT]	Then press the [ENT] key. * Pressing the [EXT] key returns you to the menu screen.
STEP2	A4: FLOW DIRCTN NORMAL	The switch name display at the bottom changes (three keys [UP], [DWN] and [SET]) At the same time, the cursor appears.
[ENT]		Then press the [UP] or [DWN] key.
STEP3 [UP]/[DWN]	U P] [DWN] [SET] A4: FLOW DIRCTN SWITCH	You can continue to change the setting value. Pressing the [UP] or [DWN] key switches the selection item. [U P]: The selection item is incremented. [DWN]: The selection item is decremented.
	[U P] [DWN] [SET]	

.

.

Key operation	Display example	Description
STEP4	A4: FLOW DIRCTN SWITCH	By this operation, change the setting to SWITCH.
[UP]/[DWN]		When the desired selection item is displayed, press the [SET] key to set the item temporarily.
	[U P] [DWN] [SET]	
STEP5	A4: FLOW DIRCTN SWITCH	Pressing the [SET] key displays a message asking you to confirm whether the setting is OK. If OK, press the [SET] key. If you need to redo the
[SET]	J	setting, press the [NO] key.
	OK? [N O] [SET]	
STEP6-1	A4: FLOW DIRCTN NORMAL	Pressing the [No] key when you are asked "OK?" causes the numeric value to return to the previous value and enables you to redo the setting.
[NO] [*]		
	(U P] (SEL) (SET)	
STEP6-2(=END)	A4: FLOW DIRCTN SWITCH	Pressing the [SET] key when you are asked "OK?" causes the setting value to be determined. Then if you press the [EXT] key, you return to the
[SET]		menu screen. If you press the [ENT] key, you can restart frequency value change operation from a state of
	[EXT] [ENT]	SWITCH.

ı.

8.2.6 Password Setting

The password function is provided to protest the settings and adjustment of the functions affecting the flow rate measurement. See 7.4 "Configuration Items Selection Table" for limited functions.

Proceed as follows to check or change the password.

• To check the password:

Key operation	Display example	Description
	A: MEAS MODE EX CURRENT METER SIZE EX FREQ FLOW DIRECTN →PASSWORD ADDR SET [SEL] [ENT]	Select "PASSWORD" in the configuration item selection screen.
[ENT]	A5: PASSWORD 123 [EXT] [ENT]	The currently set password is displayed.
[EXT]	A: MEAS MODE →EX CURRENT METER SIZE EX FREQ FLOW DIRECTN PASSWORD ADDR SET [SEL] [ENT]	You return to the configuration item selection screen.

* However, if a wrong password is entered when the mode is changed from the measuring mode to the setting mode, *** appears.

Key operation	Display example	Description
(ENT)	A5: PASSWORD	The currently set password is displayed as ***.
	[EXT] [ENT]	

÷

• To change the password:

The following example shows how to change the password from 123 to 453.

Key operation	Display example	Description
	A5: PASSWORD 123	Select "PASSWORD" in the configuration item selection screen. The currently set password (123 in this example) is displayed.
	[EXT] [ENT]	Then press the [ENT] key.
STEP1	A5: PASSWORD 123	The switch name display at the bottom changes (three keys [UP], [SEL] and [SET]) At the same time, the cursor appears.
[ENT]	[U P] [SEL] [SET]	(The digit on which the cursor is positioned is reverse-displayed.)
STEP2	A5: PASSWORD 45 <mark>8</mark>	Use the [SEL] key to move the cursor to the desired digit and press the [UP] key to change the numeric value. Repeat this operation to change the setting value to 453.
[SEL]⇔[UP]	[U P] [SEL] [SET]	When the desired value is displayed, press the [SET] key to set the numeric value temporarily.
STEP3	A5: PASSWORD 453	Pressing the [SET] key displays a message asking you to confirm whether the setting is OK. If OK, press the [SET] key. If you need to redo the setting,
[SET]	ОК? [N 0] [SET]	press the [NO] key.
STEP4-1	A5: PASSWORD 123	Pressing the [No] key when you are asked "OK?" causes the numeric value to return to the previous value and enables you to redo the setting.
[NO]	[U P] [SEL] [SET]	
STEP4-2(=END)	A5: PASSWORD 453	Pressing the [SET] key when you are asked "OK?" causes the setting value to be determined. Then if you press the [EXT] key, you return to the menu
[SET]	[EXT] [ENT]	screen. If you press the [ENT] key, you can restart password change operation from a state of 453.

(Note 1) If you set 000 for the password, it is considered as that the password is not used. In this case, the password input confirmation screen is not displayed when you move from the measurement mode to the setting mode and all parameter setting items and restrictions on the calibration screen are released.

(Note 2) If you set your password, manage it not to forget it. The password should be managed based on the management standard of the system you use.

- 64 —

8.2.7 Address Setting

Address setting described here is needed if optional PROFIBUS communication board is installed. For details, refer to PROFIBUS communication instruction manual.

* Address setting is not necessary if PROFIBUS communication board is not installed.

8.2.8 Indicating Unit

You can select one of the engineering units listed below as an indicating unit.

- Flow velocity: m/s, ft/s
- Flow rate:

m³/s, m³/min, m³/h, m³/d l/s, l/min, l/h, l/d ml/s, ml/min, ml/h, ml/d gal/s, gal/min, gal/h, gal/d bbl/s, bbl/min, bbl/h, bbl/d pt/s, pt/min, pt/h, pt/d

• Volumetric flow: m³, l, ml, gal, bbl, pt, qt

• Other units: %, COUNT, RANGE, GRAPH, CUSTOM

qt/s, qt/min, qt/h, qt/d

• Code of volumetric flow direction:

Forward direction (when F or B is selected)

Reverse direction (when R or B is selected)

• Total difference flow:

Difference between total forward direction flow and reverse direction flow (when total flow direction D is selected)

Note 1

If COUNT, RANGE, GRAPH or CUSTOM is selected, the display is shown as follows:
COUNT: displays totalized flow counts (8 digits) without a unit.
RANGE: displays the range number (1 to 4).
GPARH: The measured value (% value) is displayed as a bar graph. In addition, the range No. of the range being measured.
CUSTOM: Displays the result obtained by multiplying m³/min by the custom coefficient.

Note 2

GRAPH display can be selected only in the sub screen.

In display setting, you can select either one of the two types, main (MAIN DSP) or/Sub (SUB DSP). The main display setting and sub display setting are switched by the configuration item number.

B1: MAIN DSP Main display unit (display setting for the upper part of the screen)

B2: SUB DSP Sub display unit (display setting for the lower part of the screen) The display setting can be checked/set by the following procedures.

Shown below is an example of changing the main display setting from % to ml/s.

Key operation	Display example	Description
	B:	Select "MAIN DSP" in the configuration item
	MEAS MODE →MAIN DSP	selection screen.
	SUB DSP	
	CUSTOM DATA	
	CUSTOM UNIT	
	LCD ADJUST SW POSITION	
	[SEL] [ENT]	
STEP1	B1:	The currently set display setting (% in this
	MAIN DSP %	example) is displayed.
[ENT]		Then press the [ENT] key.
	[EXT] [ENT]	* Pressing the [EXT] key returns you to the menu screen.
STEP2	B1:	The switch name display at the bottom changes
	MAIN DSP	(three keys [UP], [SEL] and [SET])
	% ·	At the same time, the cursor appears.
[ENT]		(The digit on which the cursor is positioned is reverse-displayed.)
	(U P) [SEL] (SET]	
STEP3	B1:	Use the [SEL] key to move the cursor to the
	MAIN DSP ml / s	second unit \rightarrow the third unit and change the
[SEL]⇔[UP]		display unit by pressing the [UP] key. Repeat this operation to change the display
		unit to ml/s.
	[U P] [SEL] [SET]	
		When the desired display unit is selected, press
		the [SET] key to set the display unit
		temporarily.
STEP4	B1:	Pressing the [SET] key displays a message
	MAIN DSP	asking you to confirm whether the setting is
057	ml/s	OK.
[SET]		If OK, press the [SET] key. If you need to redo the setting, press the [NO] key.
	OK?	uie setting, press the [140] key.
	[N O] [SET]	

•

STEP5-1	B1: MAIN DSP 12	Pressing the [No] key when you are asked "OK?" causes the display unit to return to the previous value and enables you to redo the setting.
[NO]		
	(U P) (SEL) (SET)	
STEP5-2(=END)	B1: MAIN DSP	Pressing the [SET] key when you are asked "OK?" causes the setting value to be determined.
[SET]	ml / s	Then if you press the [EXT] key, you return to the menu screen. If you press the [ENT] key, you can restart display
	[EXT] [ENT]	unit setting change operation from a state of ml/s.

Note 1:

The first unit (volumetric units etc.) changes as shown below:



Note 2:

The second unit (time unit) changes as shown below: $\rightarrow /s \rightarrow /\min \rightarrow /h \rightarrow /d \rightarrow /d$

For sub indicating unit, select SUB DSP with setting items.

■ To change the total flow value direction

The total flow value direction is changed as following procedure.

The following example shows how to change the main indicating setting from fixed forward flow (F) to bi-directional flow (B).

Key operation	Display example	Description
	B1: MAIN DSP m3 F	Select "MAIN DSP" in the configuration item selection screen. The currently set display setting (m3 F in this example) is displayed.
	[EXT] [ENT]	Then press the [ENT] key.
STEP1 [ENT]	B1: MAIN DSP m3 F	The switch name display at the bottom changes (three keys [UP], [SEL] and [SET]) At the same time, the cursor appears. (The digit on which the cursor is positioned is reverse-displayed.)
	[U P] [SEL] [SET]	Teverae-diaplayed.)
STEP2	B1: MAIN DSP m3	Use the [SEL] key to move the cursor to the third unit (total flow value direction) and then press the [UP] key to change the direction.
[SEL]⇔[UP]	[U P] [SEL] [SET]	Then press the [SET] key to set the display unit temporarily.
STEP3 [SET]	B1: MAIN DSP m3 B	Pressing the [SET] key displays a message asking you to confirm whether the setting is OK. If OK, press the [SET] key. If you need to redo the setting, press the [NO] key.
	OK? 🕊 [N O] [SET]	
STEP4-1	B1: MAIN DSP m3 F	Pressing the [No] key when you are asked "OK?" causes the display unit to return to the previous value and enables you to redo the setting.
[NO]		······································
	[U P] [SEL] [SET]	
STEP4-2(=END) [SET]	B1: MAIN DSP m3 B	Pressing the [SET] key when you are asked "OK?" causes the setting value to be determined. Then if you press the [EXT] key, you return to the menu screen.
	[EXT] [ENT]	If you press the [ENT] key, you can restart display unit setting change operation from a state of m3 B.

Note 1 The content of the third unit (flow rate direction code) is cyclically shifted as shown below.

B(bi-directional) → F(forward direction fixed) D(difference flow rate) ← R(reverse direction fixed) ←

For sub indicating unit, select **B2: SUB DSP** with setting items.

8.2.9 Custom Coefficient Setting

Set a coefficient for the custom value displayed when you have selected CUSTOM at display setting. **Displayed value at CUSTOM setting = measured value in m³/min unit** × **custom coefficient** Shown below is an example of changing the custom coefficient value from 1.00 to 2.25.

Key operation	Display example	Description
	B:	Select "CUSTOM DATA" in the configuration item
	MEAS MODE	selection screen.
	MAIN DSP SUB DSP	
	→CUSTOM DATA	
	CUSTOM UNIT	
	LCD ADJUST	
	SW POSITION	
07504	[SEL] [ENT]	The surroutly get such as a officiant (1,00000 in this
STEP1	B3: CUSTOM DATA	The currently set custom coefficient (1.00000 in this example) is displayed.
	1.00000	example) is displayed.
[ENT]		Then press the [ENT] key.
	EXT] [ENT]	* Pressing the [EXT] key returns you to the menu
0TED0	B3:	screen. The switch name display at the bottom changes
STEP2	CUSTOM DATA	(three keys [UP], [SEL] and [SET])
	1.00000	At the same time, the cursor appears.
[ENT]		(The digit on which the cursor is positioned is
		reverse-displayed.)
· ·	[U P] [SEL] [SET]	
STEP3	B3:	Use the [SEL] key to move the cursor to the desired
	CUSTOM DATA 2.2 <mark>5</mark> 000	digit and press the [UP] key to change the numeric
	2.2 <u>0</u> 000	value.
[SEL]⇔[UP]		Repeat this operation to change the setting value to 2.25.
	[U P] [SEL] [SET]	Million the university of the designed value means
		When the value changes to the desired value, press the [SET] key to set the custom coefficient
		temporarily.
STEP4	B3:	Pressing the [SET] key displays a message asking
	CUSTOM DATA	you to confirm whether the setting is OK.
	2.25000	If OK, press the [SET] key. If you need to redo the
[SET]		setting, press the [NO] key.
	OK?	
	[N O] [SET]	
STEP5-1	B3:	Pressing the [No] key when you are asked "OK?"
	1.00000	causes the custom coefficient to return to the previous value and enables you to redo the setting.
[NO]		previous value and enables you to redo the setting.
STEP5-2(=END)	[U P] [SEL] [SET] B3:	Pressing the [SET] key when you are asked "OK?"
	CUSTOM DATA	causes the setting value to be determined.
	2.25000	Then if you press the [EXT] key, you return to the
[SET]		menu screen.
		If you press the [ENT] key, you can restart custom
	[EXT] [ENT]	coefficient change operation from a state of 2.25.

* The custom coefficient setting precision is 5 digits. Therefore, the input value changes as follows depending on the setting value:

Example) Input value, "85713038" \rightarrow After the setting is confirmed, "85713040"

8.2.10 Custom Unit Setting

Set the unit of the custom value to be displayed when you select CUSTOM at display setting.

The custom value unit must be within 7 characters. You can set any combination of the following character codes:

Alphabetical character (lowercase)	: a ~ z
alphabetical character (uppercase)	: A ~ Z
Numeric character	: 0 ~ 9
Symbol	: ()Parentheses
	%Percent
	Period
	•Point
	:Colon
	=Equal
	Minus
	*Asterisk
	/Slash
	Space (blank)

Shown below is an example of changing the custom unit from AAA/BBB to XXX/ZZZ.

Key operation	Display example	Description
	B: MEAS MODE MAIN DSP SUB DSP CUSTOM DATA →CUSTOM UNIT LCD ADJUST SW POSITION	Select "CUSTOM UNIT" in the configuration item selection screen.
STEP1	[SEL] [ENT] B4: CUSTOM UNIT	The currently set custom unit (AAA/BBB in this example) is displayed.
(ENT)	AAA/BBB	Then press the [ENT] key.
	[EXT] [ENT]	* Pressing the [EXT] key returns you to the menu screen.
STEP2	B4: CUSTOM UNIT AAA/BBB	The switch name display at the bottom changes. (three keys [UP], [DOWN] and [SET]) At the same time, the cursor appears.
[ENT]		(The digit in the place the cursor position is currently positioned is reverse-displayed.)
	[U P] (DWN] [SET]	
STEP3	B4: CUSTOM UNIT AA/BBB	Using the [UP]/[DWN] key, change the character.
[UP]/[DWN] [SET]		When the desired character is displayed, press the [SET] key. The cursor moves to the next character.
STEP4	U P] [DWN] [SET] B4: CUSTOM UNIT XXX/YY	Repeat this operation to select all characters to the 7th character.
[UP]/[DWN] [SET]	[U P] [DWN] [SET]	
STEP5 [SET]	B4: CUSTOM UNIT XXX/YYY OK? [N O] [SET]	Pressing the [SET] key when the cursor is positioned on the 7th character causes the selected unit characters to be set temporarily. And a message to confirm whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the
STEP6-1	B4:	setting, press the [NO] key. Pressing the [NO] key when you are asked "OK?"
[NO]	CUSTOM UNIT	causes the custom unit to return to the previous state and enables you to redo the setting.
STEP6-2(=END)	[U P] [DWN] [SET] B4: CUSTOM UNIT XXX/YYY	Pressing the [SET] key when you are asked "OK?" causes the setting value to be determined. Then if you press the [EXT] key, you will return to
[SET]	[EXT] [ENT]	the menu screen. If you press the [ENT] key, you can restart custom unit change operation from a state of XXX/YYY.

(Note 1) The selectable characters are displayed cyclically as shown below.

Symbol

4

alphabetical character (lowercase) — Alphabetical character (uppercase) ____
8.2.11 LCD Density Adjustment

This section describes how to set the LCD density adjustment value for the converter display. The LCD density can be set in 5 levels.

LCD density adjustment value12345LCD densityLight_______Dark

The LCD density adjustment value is set to "3" at factory.

The display of the LCD, by its natural characteristics, gradually becomes lighter over time. If the display becomes too dark, you need to adjust the density by using this parameter. Shown below is an example of changing the LCD density adjustment value from 3 to 5 DARK.

Key operation	Display example	Description
	B:	Select "LCD ADJUST" in the configuration item selection
	MEAS MODE	screen.
	MAIN DSP	
	SUB DSP	
	CUSTOM DATA CUSTOM UNIT	
	\rightarrow LCD ADJUST	
	SW POSITION	
	[SEL] [ENT]	
STEP1	B5:	The currently set LCD density adjustment value (3 in this
	LCD ADJUST	example) is displayed.
	3	Then press the [ENT] key.
[ENT]		
		* Pressing the [EXT] key returns you to the menu screen.
	[EXT] [ENT]	
STEP2	B5:	The switch name display at the bottom changes (three
	LCD ADJUST	keys [UP], [DWN] and [SET]).
	3	At the same time, the cursor appears.
[ENT]		(The digit on which the cursor is positioned is
	[U P] (DWN] [SET]	reverse-displayed).
STEP3	B5:	Change the setting item using the [UP]/[DWN] key.
	LCD ADJUST	
	5 DARK	
[UP]/[DWN]		When the desired item is displayed, press the [SET] key.
	UP [DWN] [SET]	
STEP4	B5:	When you press the [SET] key, the selected item is set
	LCD ADJUST 5 DARK	temporarily and a message confirming you whether the
	JUARN	setting is OK is displayed.
[SET]		If OK, press the [SET] key. If you want to redo the setting,
	OK?	press the [NO] key.
	[N O] [SET]	
STEP5-1	B5:	Pressing the [NO] key when you are asked "OK?" causes
	LCD ADJUST	the LCD density adjustment value to return to the previous
	3	value and enables you to redo the setting.
[NO]		
	[U P] [DWN] [SET] B5:	Pressing the [SET] key when you are asked "OK?" causes
STEP5-2(=END)	LCD ADJUST	the setting to be determined.
	5 DARK	
		Then, press the [EXT] key. You return to the menu screen. Pressing the [ENT] key enables you to restart LCD density
[SET]		adjustment from a state of 5 DARK.
	[EXT] [ENT]	

8.2.12 Switch Position Setting

This section describes how to set the switch position of the converter display.

Setting the switch position enables the display orientation to be kept fixed, regardless of in which direction relative to the piping the converter is installed.

You can set the switch position by selecting one from four items below.

(1) Switch position: TOP

The infrared switches are located at the top.



(2) Switch position: BOTTOM

The infrared switches are located at the bottom.



(3) Switch position: LEFT The infrared switches are located in the left.



(4) Switch position : RIGHT The infrared switches are located in the right



Shown below is an example of changing the switch position setting from BOTTOM to TOP.

Key operation	Display example	Description
,	B: MEAS MODE MAIN DSP SUB DSP CUSTOM DATA CUSTOM UNIT LCD ADJUST →SW POSITION [SEL] [ENT]	Select "SW POSITION" in the configuration item selection screen.
STEP1	B6: SW POSITION BOTTOM	The currently set switch position (BOTTOM in this example) is displayed.
[ENT]	[EXT] [ENT]	Then press the [ENT] key. * If you press the [EXT] switch, you return to the
STEP2	B6: SW POSITION BOTTOM	menu screen. The switch name display at the bottom changes (three keys [UP], [DWN] and [SET]). At the same time, the cursor appears.
[ENT]	(U P) (DWN) (SET)	(The digit on which the cursor is positioned is reverse-displayed.)
STEP3	B6: SW POSITION	Change the selection item using the [UP]/[DWN] key.
[UP]/[DWN]	TOP [U P] (DWN] (SET)	When you have selected the desired item, press the [SET] key.
STEP4	B6: SW POSITION TOP	When you press the [SET] key, the selected item is set temporarily and a message confirming you whether the setting is OK is displayed.
[SET]	OK? [N O] [SET]	If OK, press the [SET] key. If you want to redo the setting, press the [NO] key.
STEP5-1	B6: SW POSITION BOTTOM	Pressing the [NO] key when you are asked "OK?" causes the switch position setting to return to the previous setting and enables you to redo the
[NO]	נון פו וטאיאיז ופבדו	setting.
STEP5-2(=END)	U P] [DWN] [SET] B6: SW POSITION TOP	Pressing the [SET] key when you are asked "OK?" causes the setting to be determined. Then press the [EXT] key. You return to the menu
[SET]	[EXT] [ENT]	screen. Pressing the [ENT] key enables you to restart switch position setting from a state of TOP.

8.2.13 Span (range)

You can set the following constants in this setting item:

- (1) Range type
- (2) Unit of span (can be changed only in range 1)
- (3) Span
- (4) Hysteresis

• Range type

You can use multiple ranges by selecting range type. You can select a single range, multiple ranges, or forward/reverse multi-ranges. Select one from five types shown below:

Range type	Description
SINGLE	Single range
4F-0R	Unidirectional flow, automatic selection of multiple ranges by internal signal
2F-2R	Bidirectional flows, automatic selection of multiple ranges by internal signal
EXT.2F-0R	Unidirectional flow, multiple ranges selected by external signal
EXT.2F-2R	Bidirectional flows, multiple ranges selected by external signal

• Span (range)

- Span can be set for flow velocity and flow rates:
- (1) Setting range

Valid range of span is 0.3 m/s to 10 m/s in terms of flow velocity.

If you try to set the span outside of this range, one of the following messages appears:

- * HIGH OVER SPEC. (if the set value exceeds 10 m/s)
- * LOW OVER SPEC. (if the set value is less than 0.3 m/s)

Try again to set the span within the specified range.

(2) Limitation of multiple ranges

When multiple ranges are used, the following must be observed:

- Range 1 > Range 2 > Range 3 > Range 4 (unidirectional flow, multiple ranges)
- Range 1 > Range 2, Range 3 > Range 4 (bidirectional flows, multiple ranges)

If you try to set the ranges not conforming to the above, the following message appears:

* MULTI RANGE EROR *

Try again to set the ranges as specified above.

(3) Influence on Totalization counting rate (pulse rate)

If you have changed the span while the counting rate is set for totalization (pulse rate), the counting rate for 100% output may have exceeded the maximum counting capacity. In this kind of event, the following message appears and the system goes to the counting rate setting sequence after all ranges are set.

* H. OVER CNT RATE or

* L. OVER CNT RATE

Set the counting rate (pulse rate) in accordance with 8.2.21 "Counting Rate (pulse rate) and Pulse Width" for the newly set span.

• Unit of span

One of the following engineering units as a unit for the span can be selected. The unit is set for the range 1 and the same unit applies automatically to other ranges - range 2, range 3 and range 4.

- Flow velocity: m/s, ft/s
- Flow rate:

m³/s, m³/min, m³/h, m³/d l/s, l/min, l/h, l/d ml/s, ml/min, ml/h, ml/d gal/s, gal/min, gal/h, gal/d bbl/s, bbl/min, bbl/h, bbl/d pt/s, pt/min, pt/h, pt/d qt/s, qt/min, qt/h, qt/d

If you change the unit, the new span based on the newly set unit will be automatically displayed.

• Hysteresis

The hysteresis is the **dead band** used when multiple ranges are switched. The hysteresis can be set from 0 to 25% in increments of 0.1%. The hysteresis setting is needed only when automatic selection of multiple ranges is used.

• Setting sequence of the span(range)

The following is the setting sequence of span (range).



* If multiple range is selected, compulsory range 1 to range 4 and hysteresis settings are displayed.

Range type, Span. Hysteresis can be selected by the configuration items as follows:

Range typeC1: RANGE TYPESpan of Range 1C2: RANGE 1Span of Range 2C3: RANGE 2Span of Range 3C4: RANGE 3Span of Range 4C5: RANGE 4HysteresisC6: RANGE HYS

Each constant can be checked/changed by the following procedure.

Checking each constant

Key operation	Display example	Description
	C: MEAS MODE RANGE TYPE →RANGE1 RANGE2 RANGE3 RANGE4 RANGE HYS [SEL] [ENT]	Select "RANGE1" in the configuration item selection screen.
(ENT)	C2: RANGE1 2.00000 m/s [EXT] [ENT]	The currently set span value of Range 1 is displayed.
(EXT)	C: MEAS MODE →RANGE TYPE RANGE1 RANGE2 RANGE3 RANGE4 RANGE HYS [SEL] [ENT]	You return to the configuration item selection screen.

■ To change the range type:

Range type should be changed before changing the span.

The following example shows how to change the range type from the single range (SINGLE) to bi-directional internal signal selection multi-range (2F-2R).

Key operation	Display example	Description
	C1: RANGE TYPE SINGLE	Select "RANGE TYPE" in the configuration item selection screen. The currently set range type (SINGLE in this example) is displayed.
STEP1	[EXT] [ENT]	Then press the [ENT] key. The switch name display at the bottom changes
	RANGE TYPE SINGLE	(three keys [UP], [DWN] and [SET]). At the same, the cursor appears.
[ENT]	[U P] [DWN] [SET]	(The digit on which the cursor is positioned is reversed-displayed.)
STEP2	C1: RANGE TYPE 2F-2R	Change the selection item using the [UP]/[DWN] key.
[UP]/[DWN]		When the selection item has changed to the desired item, press the [SET] key.
	[U P] [DWN] [SET]	
STEP3	C1: RANGE TYPE 2F-2R	When you press the [SET] key, the item you have selected is set temporarily and a message confirming you whether the setting is OK is
[SET]	OK? [N O] [SET]	displayed. If OK, press the [SET] key. If you want to redo the setting, press the [NO] key.
STEP4-1	C1: RANGE TYPE SINGLE	Pressing the [NO] key when you are asked "OK?" returns the range type setting to the previous setting and enables you to redo the setting.
[NO]		
	[U P] [DWN] [SET] C1:	Pressing the ISETI key when you are asked "OK?"
STEP4-2(=END)	C1: RANGE TYPE 2F-2R	Pressing the [SET] key when you are asked "OK?" causes the setting to be determined. Then, press the [EXT] key. You return to the menu
[SET]		screen. Pressing the [ENT] key enables you to restart
	[EXT] [ENT]	switch range type setting from the position setting from a state of 2F-2R.

■ To change the span (range):

The following example shows how to change the span of Range 1 from 2.0 m/s to 100 l/min.

Key operation	Display example	Description
	C2:	Select "RANGE1" in the configuration item selection
	RANGE1	screen.
	2.00000 m/s	The currently set span value of Range1 (2.00000 in
	1105	this example) is displayed.
		Then press the [ENT] key.
	[EXT] [ENT]	
STEP1	C2:	The switch name display at the bottom changes
	RANGE1	(three keys [UP], [SEL] and [SET]).
(CALT)	m/s	At the same time, the cursor appears. (The digit on which the cursor is positioned is
[ENT]		reverse-displayed.)
		levelse-uispiayeu.
	[U P] [SEL] [SET]	
STEP2	C2:	Move the cursor to the digit of the first unit using the
	RANGE1	[SEL] key.
	2.00000	
[SEL]	m/s	
	[U P] [SEL] [SET]	
STEP3	C2:	Change the first unit to 1 using the [UP] key.
	RANGE1 3.93000	Next, move the cursor to the digit of the second unit
[UP]	J.93000	using the [SEL] key.
[SEL]		
OTEDA	[U P] [SEL] [SET] C2:	Change the second unit to "min" using the [UD] key
STEP4	RANGE1	Change the second unit to "min" using the [UP] key. Next, move the cursor to the digit you want to
[UP]	236.000	change, using the [SEL] key.
[SEL]	l/min	
[]	, i i i i i i i i i i i i i i i i i i i	
	[U P] [SEL] [SET]	
STEP5	C2:	Change the numeric value using the [UP] key.
	RANGE1	
[UP]⇔[SEL]	136.000	Repeat this operation until the setting value
	l/min	changes to the desired numeric value and press the
		[SET] key.
	[U P] [SEL] [SET]	
STEP6	C2:	When you press the [SET] key, a message
	RANGE1	confirming you whether the setting is OK is
(OET)	100.000	displayed.
[SET]		If OK, press the [SET] key. If you want to redo the setting, press the [NO] key.
	OK?	
	[N O] [SET]	

- 80 -

.

Key operation	Display example	Description
STEP7-1 [NO]	C2: RANGE1 200000 m/s [U P] (SEL) (SET)	Pressing the [NO: when you are asked "OK?" causes the span value to return to the previous value and enables you to redo the setting.
STEP7-2(=END)	C2: RANGE1 100.000	Pressing the [SET] key when you are asked "OK?" causes the setting to be determined. Then press the [EXT] key. You return to the menu
(SET)	l/min [EXT] [ENT]	screen. Pressing the [ENT] key enables you to restart span value change operation from a state of 100.000 I/min.

Note Unites of the measuring unit changes as shown below:

First unit



• However, the following first and second unit combinations cannot be selected: m/min, m/h, m/d, ft/min, ft/h, ft/d

• Changing the hysteresis

The hysteresis is set to 3% at factory, unless otherwise specified.

Shown below is an example of changing the hysteresis from 3% to 5%.

Key operation	Display example	Description
	C6: RANGE HYS 03.0 %	Select "RANGE HYS" in the configuration item selection screen. The currently set hysteresis (3.0% in this example) is displayed.
	(EXT) [ENT]	Then press the [ENT] key.
STEP1 [ENT]	C6: RANGE HYS Ø3.0 %	The switch name display at the bottom changes (three keys [UP], [SEL] and [SET]) At the same time, the cursor appears. (The digit on which the cursor is positioned is reverse-displayed.)
	[U P] [SEL] [SET]	
STEP2	C6: RANGE HYS 0 <mark>5</mark> .0	Move the cursor to the desired digit using the [SEL] key and change the numeric value using the [UP] key.
[SEL]⇔[UP]	%	Repeat this operation to change the value to 5.0%.
	(U P] [SEL] [SET]	When the setting has changed to the desired numeric value, press the [SET] key to set the hysteresis temporarily.
STEP3	C6: RANGE HYS 05.0	When you press the [SET] key, a message confirming you whether the setting is OK is displayed.
[SET]	0K? [N 0] [SET]	If OK, press the [SET] key. If you want to redo the setting, press the [NO] key.
STEP4-1	C6: RANGE HYS	Pressing the [NO] when you are asked "OK?" causes the span hysteresis to return to the previous setting and enables you to redo the setting.
[NO]	· %	
	[U P] [SEL] [SET]	
STEP4-2(=END) [SET]	C6: RANGE HYS 05.0 %	Pressing the [SET] key when you are asked "OK?" causes the setting to be determined. Then press the [EXT] key. You return to the menu screen. Pressing the [ENT] key enables you to restart
	[EXT] [ENT]	hysteresis change operation from a state of 5.0%.

Note If you set a value exceeding 25.0%, *HIGH OVER SPEC.* is displayed and the setting returns to the one before change. Set a value once again.

8.2.14 Damping Constant

The damping constant is used to **moderate output fluctuations**. (The larger the damping constant, the more the output is averaged. But the **response to an input change will be slower**.) The damping constant can be set as follows:

The damping constant is set for 0.0 sec, 0.5 sec and 1 to 60 sec (in increments of 1 second)

Note: 0.0 sec setting will work as equal to 0.1 sec damping constant.

Set 1 sec or more for normal operation.

If you set a value exceeding 60s, it is forcibly changed to 60s before data is written.

Proceed as follows to check or change the damping constant.

Shown below is an example of changing the damping constant from 0.0s to 10s.

Key operation	Display example	Description
	D:	Select "DAMPING" in the configuration item
	MEAS MODE	selection screen.
	→DAMPING	
	LOW CUT	
	ALM mA SET	
	DSP LOW CUT	
07504	[SEL] [ENT]	
STEP1	D1: DAMPING	The currently set damping constant (2.0s in this example)
	02.0	is displayed.
	S S	
[ENT]	5	Then press the [ENT] key.
	[EXT] [ENT]	* Pressing the [EXT] key returns you to the menu screen.
STEP2	D1:	The switch name display at the bottom changes (three
	DAMPING	keys [UP], [SEL] and [SET]).
	02.0	At the same time, the cursor appears.
[ENT]	s	(The digit on which the cursor is positioned is
		reverse-displayed.)
	[U P] [SEL] [SET]	
STEP3	D1:	Move the cursor to the desired digit using the [SEL] key
OTEL	DAMPING	and change the numeric value using the [UP] key.
	10.0	Repeat this operation until the value changes to 10.0 s.
[SEL]⇔[UP]	s	
		When the value has changed to the desired value, press
		the [SET] key to set the damping constant temporarily.
07504	[U P] [SEL] [SET] D1:	
STEP4	DAMPING	When you press the [SET] key, a message
	10.0	confirming you whether the setting is OK is
	S S	displayed.
[SET]		If OK, press the [SET] key. If you want to redo the setting,
	OK?	press the [NO] key.
	[N O] [SET]	
STEP5-1	D1:	Pressing the [NO] key when you are asked "OK?" causes
	DAMPING 02.0	the damping constant to return to the
	U 2.0	previous value and enables you redo the setting.
[NO]		
	[U P] [SEL] [SET]	· · · · · · · · · · · · · · · · · · ·
STEP5-2(=END)	D1:	Pressing the [SET] key when you are asked "OK?" causes
	DAMPING -	the setting to be determined.
	10.0	Then press the [EXT] switch to return to the menu screen.
(SET]	S	Pressing the [ENT] key enables you to restart damping
		constant change operation from a state of 10.0s.
	[EXT] [ENT]	
		hy changed to 60c hofers data is written



- 83 -

8.2.15 Low Cutoff

The low cutoff is the value set just above 0% flow rate. Flow rates below this level are treated as 0%, i.e. the current output is forcibly changed and fixed to 0%.

The low cutoff can be set from 0 to 10% of the span and in increments of 0.1%. Proceed as follows to check or change the low cutoff value.

Shown below is an example of changing the low cut value from 1.0% to 3.0%.

Key operation	Display example	Description
	D:	Select "LOW CUT" in the configuration item
	MEAS MODE	selection screen.
	DAMPING	
	→LOW CUT	
	ALM mA SET DSP LOW CUT	
	LOW LIMIT	
	[SEL] [ENT]	
STEP1	D2:	The currently set low cut value (1.0% in this
	LOW CUT	example) is displayed.
	01.0	
[ENT]	%	Then press the [ENT] key.
	[EXT] [ENT]	* Pressing the [EXT] key returns you to the menu screen.
STEP2	D2:	The switch name display at the bottom changes (three
	LOW CUT	keys [UP], [SEL] and [SET])
	0 1.0 %	At the same time, the cursor appears.
[ENT]	/0	(The digit on which the cursor is positioned is
		reverse-displayed.)
	[U P] [SEL] [SET]	
STEP3	D2:	Move the cursor to the desired digit using the [SEL] key
		and change the numeric value using [UP] key.
	%	Repeat this operation to change the setting value to 3.0%.
[SEL]⇔[UP]		When the value has changed to the desired value, press
		the [SET] key to set the low cut value
	[U P] [SEL] [SET]	temporarily.
STEP4	D2:	When you press the [SET] key, a message confirming you
	LOW CUT	whether the setting is OK is displayed.
	03.0	If OK, press the [SET] key. If you want to redo the setting,
[SET]	%	press the [NO] key.
	OK?	
	[N O] [SET]	
STEP5-1	D2:	Pressing the [NO] key when you are asked "OK?" causes
	LOW CUT	the low cut value to return to the previous value and
	01.0	enables you to redo the setting.
[NO]	%	
	[U P] [SEL] [SET]	
STEP5-2(=END)	D2:	Pressing the [SET] key when you are asked "OK?" causes
	LOW CUT	the setting to be determined.
	03.0	Then press the [EXT] key, You return to the menu screen.
[SET]	70	Pressing the [ENT] key enables you to restart low cut
		value change operation from a state of 3.0%.
	[EXT] [ENT]	

Note If you set a value exceeding 10.0%, *HIGH OVER SPEC.* is displayed and the setting returns to the one before change. Set a value once again.

.

8.2.16 Current Output Setting Used When an Alarm Occurs

In case an alarm occurs with the self-diagnostic function, the current output value will be fixed to the selected value.

Select the current output value used in case an alarm occurs from the following table.

ourient output ootting	
Selection	Current output setting used when an alarm occurs
UNDER 3.0mA	3.0mA or less
4.0mA	4.0mA
HOLD	Fixed to the selected value
OVER 24.0mA	24.0mA or more

Current output setting function in case an alarm occurs

The current output value at alarm generation can be checked/changed by the following procedure. Shown below is an example of changing the setting from UNDER 3.0mA to 4.0mA.

Key operation	Display example	Description
	D: MEAS MODE DAMPING LOW CUT →ALM mA SET DSP LOW CUT LOW LIMIT [SEL] [ENT]	Select "ALM mA SET" in the configuration item selection screen.
STEP1	D3: ALM mA SET UNDER 3.0mA	The current setting value (UNDER 3.0mA in this example) is displayed.
[ENT]		Then press the [ENT] key.
	[EXT] [ENT]	* Pressing the [EXT] key returns you to the menu screen.
STEP2	D3: ALM mA SET UNDER 3.0mA	The switch name display at the bottom changes (three keys [UP], [DWNL] and [SET]) At the same time, the cursor appears.
[ENT]	[U P] [DWN] [SET]	(The digit on which the cursor is positioned is reverse-displayed.)
STEP3	D3: ALM mA SET 4.0mA	Change the selection item using the [UP]/[DWN] key. When you have selected the desired item, press the [SET]
[UP]/[DWN]	[U P] [DWN] [SET]	key.
STEP4	D3: ALM mA SET 4.0mA	When you press the [SET] key, the selected item is set temporarily and a message confirming you whether the setting is OK is displayed.
[SET]	OK? [N 0] [SET]	If OK, press the [SET] key. If you want to redo the setting, press the [NO] key.
STEP5-1	D3: ALM mA SET UNDER 3.0mA	Pressing the [NO] key when you are asked "OK?" causes the setting value to return to the previous value and enables you to redo the setting.
[NO]	[U P] [DWN] [SET]	
STEP5-2(=END)	D3: ALM mA SET 4.0mA	Pressing the [SET] key when you are asked "OK?" causes the setting to be determined. Then, press the [EXT] key. You return to the menu screen.
[SET]	[EXT] [ENT]	Pressing the [ENT] key enables you to restart setting operation from a state of 4.0mA.

8.2.17 Display Low Cut Setting

The display low cut setting function enables you to set whether low cut treatment is to be reflected on the display value when you set the low cut value in 0.

To set the display low cut, select either of the following items listed in the table below.

Display low cut setting function

Selection item	Display value
ON	Low cut treatment is applied to the display value.
OFF	Low cut treatment is not applied to the display value.

For example, if the low cut value is set to 10% and the input value from the detector is 5%, the display value will be as follows, depending on the display low cut setting:

Display low cut	Display value
ON	0.0%
OFF	5.0%

The display low cut setting can be checked/changed by the following procedure. Shown below is an example of changing the display cut setting from OFF to ON.

Key operation	Display exa	mple	Description
· · · · ·	D: MEAS MODE DAMPING LOW CUT ALM mA SET →DSP LOW CUT LOW LIMIT		Select "DSP LOW CUT" In the configuration item selection screen.
	[SEL]	[ENT]	
STEP1	D4: DSP LOW CUT OFF		The current setting value (OFF in this example) is displayed.
[ENT]			Then press the [ENT] key.
	[EXT]	[ENT]	* Pressing the [EXT] key returns you to the menu screen.
STEP2 [ENT]	D4: DSP LOW CUT		The switch name display at the bottom changes (three keys [UP], [DOWN] and [SET]). At the same time, the cursor appears. (The digit on which the cursor is positioned is
			reverse-displayed.)
STEP3	[U P] [DWN] D4:	SEI	Change the selection item using the [UP]/[DWN]
	DSP LOW CUT		key.
[UP]/[DWN]			When you have selected the desired item, press the [SET] key.
STEP4	U P] [DWN] D4: DSP LOW CUT ON	[5[1]	When you press the [SET] key, the selected item is set temporarily and a message confirming you whether the setting is OK is displayed.
[SET]		[SET]	whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press the [NO] key.
STEP5-1	D4: DSP LOW CUT OFF		Pressing the [NO] key when you are asked "OK?" causes the setting value to return to the previous value and enables you to redo the setting.
[NO]			
	[U P] [DWN]	[SET]	
STEP5-2(=END) [SET]	D4: DSP LOW CUT ON		Pressing the [SET] key when you are asked "OK?" causes the setting to be determined. Then press the [EXT] key. You return to the menu screen.
	[EXT]	[ENT]	Pressing the [ENT] key enables you to restart setting operation from a state of ON.

* The measurement value transmitted from the converter by communication is data after display low cut processing.

8.2.18 Output Low Limit Setting

This function enables you to set the current output low limit value. To set the output low limit, select one of the items listed in the table below.

Output low limit setting function

Selection item	Output low limit
4.0mA	Current not lower than 4.0mA (0%) is output.
3.2mA	Current not lower than 3.2mA (-5%) is output.
2.4mA	Current not lower than 2.4mA (-10%) is output.

* If the low cut value (0) has been set to a value other than 0%, the output low limit value is fixed to 4.0mA, regardless of which value you have set.

The output low limit can be checked/changed by the following procedure.

Shown below is an example of changing the output low limit value from 4.0mA to 2.4mA.

Key operation	Display example	Description
	D:	Select "LOW LIMIT" in the configuration item
	MEAS MODE	selection screen.
	DAMPING LOW CUT	
	ALM mA SET	
	DSP LOW CUT	
	→LOW LIMIT	
	[SEL] [ENT]	
STEP1	D5:	The current setting value (4.0mA in this example) is
	LOW LIMIT	displayed.
	4.0mA	
[ENT]		Then press the [ENT] key.
	[EXT] [ENT]	*Pressing the [EXT] key returns you to the menu screen.
STEP2	D5:	The switch name display at the bottom changes (three
	LOW LIMIT 4.0mA	keys [UP], [DWN] and [SET]).
	<u>A.011/A</u>	At the same time, the cursor appears.
[ENT]		(The digit on which the cursor is positioned is
	[U P] [DWN] [SET]	reverse-displayed.)
STEP3	D5:	Change the selection item using the [UP]/[DWN] key.
	LOW LIMIT	
	2.4mA	When you have selected the desired item, press the
[UP]/[DWN]		[SET] key.
	[U P] [DWN] [SET]	
STEP4	D5:	When you press the [SET] key, the selected item is set
	LOW LIMIT	temporarily and a message confirming you whether the
	2.4mA	setting is OK is displayed.
[SET]		If OK, press the [SET] key. If you want to redo the
	OK?	setting, press the [NO] key.
	[N O] [SET]	
STEP5-1	D5:	Pressing the [NO] key when you are asked "OK?"
		causes the setting value to return to the previous value
	4.0mA	and enables you to redo the setting.
[NO]	[U P] [DWN] [SET]	
STEP5-2(=END)	D5:	Pressing the [SET] key when you are asked "OK?"
	LOW LIMIT	causes the setting to be determined.
	2.4mA	Then press the [EXT] key. You return to the menu
[SET]		screen.
	EXT] [ENT]	Pressing the [ENT] key enables you to restart
L		setting operation from a state of 2.4mA.

8.2.19 Still Water Zero Adjustment

Zero point adjustment must be performed in the state the fluid in the detector's measurement tube is held still.

Key operation	Display example	Description
	E: MEAS MODE →ZERO ADJUST	Select "ZERO ADJUST" in the configuration item selection screen.
	[SEL] [ENT]	
STEP1	E1: ZERO ADJUST 01.0	The current flow rate measurement value is displayed.
[ENT]	%	Then press the [SET] switch.
	[EXT] [SET]	* Pressing the [EXT] key returns you to the menu screen.
STEP2	E1: ADJUST READY 01.0 %	When you press the [SET] key, the title display changes to ADJUST READY, enabling you to perform adjustment.
[SET]	[EXT] [SET]	* Pressing the [EXT] key returns you to the previous screen.
STEP3	E1: ZERO ADJUST *ZERO ADJUST*	Hold down the [SET] key when ADJUST READY is displayed causes "ZERO ADJUST" to be displayed and still water zero adjustment to start.
[SET]Hold down		Switch operation is disabled during adjustment.
STEP4	E1: ZERO ADJUST 00.0 %	After approximately 30 seconds, still water zero adjustment is completed and the flow rate measurement value after adjustment is displayed. Press the [EXT] to return to the menu screen.
	[EXT] [SET]	

- Note 1: To start still water zero adjustment, hold down the [SET] key.
- Note 2: Still water zero point adjustment is possible only when the flow rate value is within a range of ± 1.25 m/s.
- Note 3: If you want to cancel the adjustment when ADJUST READY is displayed, press the [EXT] key. This returns you to the flow rate measurement value display screen.

8.2.20 Digital I/O

You can select the various digital I/O functions shown below. See Chapter 10, "Digital I/O Functions." for details.

■ Digital Output Functions (DO1 is standard and DO2 is optional)

Selection item	Digital output functions
NO USE	Not used
HALM	High limit alarm output
LALM	Low limit alarm output
HH ALM	High-high limit alarm output
LL ALM	Low-low limit alarm output
EMPTY ALM	Empty alarm output
RNG SIG 1	Range output No. 1
RNG SIG 2	Range output No. 2
PRESET	Preset counter output
CONV. ALM	Converter failure alarm output
PULSE OUT	Pulse output
PULSE OUT FRD.	Pulse output (fixed forward flow)
PULSE OUT REV.	Pulse output (fixed reverse flow)
MRH ALM	Multiple range high limit alarm(option)
MRL ALM	Multiple range low limit alarm(option)

Notes:

- 1: When the range type is set to the forward/reverse multi-range, if the pulse output (PULSE OUT) is selected, pulses of forward and reverse directions will be output. For setting method of the range type, see 0, "Span (range)."
- Digital Input Function (optional)

Selection item	Digital input function	
NO USE	Not used	
CNT STA/STP	Totalizer Start/Stop	
CNT RES/STA	Totalizer Reset/Start	
RANGE SW	Remote selection of multi-range	
ZERO ADJ.	Zero adjustment start	
FIXED OUT	Fixed-value output control	

■ Digital Output Active Status (Only for Alarm outputs)

Selection item	Alarm Output Action		
NORMAL CLOSE	Normal; contact close,	Alarm out; contact open	
NORMAL OPEN	Normal; contact open,	Alarm out; contact close	

Digital Input Detective Level

You can select the level of the control signal used for controlling the total counter and pulse output with digital input, as shown below.

Selection item	Digital input function setting	Total counter control signal
	CNT STA/STP (Total counter START/STOP)	H signal: Totalization STOP L signal: Totalization START
L LEVEL	CNT RES/STA (Total counter RESET/START)	H signal: Totalization START L signal: Totalization RESET
	CNT STA/STP (Total counter START/STOP)	H signal: Totalization START L signal: Totalization STOP
H LEVEL -	CNT RES/STA (Total counter RESET/START)	H signal: Totalization RESET L signal: Totalization START

(Only when the digital input function is set to total counter control input)

Digital output 1 (DO1), digital output 2 (DO2) and digital input (DI) can be selected by the configuration items as follows:

Digital output 1 (DO1)	DO1 FUNCTN
Digital output 2 (DO2)	DO2 FUNCTN
Digital input	DI FUNCTN
Active status of DO1	DO1 ALM STS
Active status of DO2	DO2 ALM STS
Digital input control signal	DI DET LV

- 91 -

■ To change the digital I/O functions:

The following example shows how to change the digital output 1 function from high alarm output (**H ALM**) to low alarm output (**L ALM**).

Key operation	Display example	Description
	F:	Select "DO1 FNUCTN" from the configuration item
	MEAS MODE	selection screen.
	→DO1 FNUCTN DO2 FNUCTN	
	DI FUNCTN	
	DO1 ALM STS	
	DO2 ALM STS	
	DI DET LV	
STEP1	[SEL] [ENT] F1:	The current setting value (H ALM in this example) is
JILFI	DO1 FNUCTN H ALM	displayed.
[ENT]		Then press the [ENT] key.
	(EXT) (ENT)	* Pressing the [EXT] key returns you to the menu screen.
STEP2	F1:	The switch name display at the bottom changes
	DO1 FNUCTN H ALM	(three keys [UP], [DWN] and [SET])
		At the same time, the cursor appears.
[ENT]		(The digit on which the cursor is positioned is reverse-displayed.)
	[U P] [DWN] [SET]	
STEP3	F1: DO1 FNUCTN L ALM	Change the selection item using the [UP]/[DWN] key.
[UP]/[DWN]		When you have selected the desired item, press the
	[U P] [DWN] [SET]	[SET] key
STEP4	F1:	When you press the [SET] key, the selected item is
	DO1 FNUCTN	set temporarily and a message confirming you
[SET]		whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the
		setting, press the [NO] key.
	OK?	
STEP5-1	[N O] [SET] F1:	Pressing the [NO] key when you are asked "OK?"
	DO1 FNUCTN	causes the setting value to return the previous
	H ALM	value and enables you to redo the setting.
[NO]		
	[U P] [DWN] [SET]	
STEP5-2(=END)	F1:	Pressing the [SET] key when you are asked "OK?"
	DO1 FNUCTN	causes the setting value to be determined.
	L ALM	Press the [EXT] key. You return to the menu
[SET]		screen.
	[EXT] [ENT]	Pressing the [ENT] key enables you to restart setting from a state of LALM.

8.2.21 Count Rate (Pulse Rate), Pulse Width Setting Mode, Pulse Width

You can set the volume (count rate) per count (pulse) for when the total count is output and the pulse width for when the total pulse is output to the external.

Total count output is not affected by the display setting but it is preferable to set total display for the main display setting or sub display setting, for checking the operation status.

You can switch between the count rate, pulse width setting mode and pulse width by the setting item number.

Count rate	COUNT RATE
Pulse width setting mode	PLS MODE
Pulse width	PLS WIDTH

• The count rate must be set so that the pulse output at 100% output will be within a range of 3.6 to 36000000 pulse/h (0.001 to 10000 pulse/s). If you set a value out of this range, an error message

HIGH OVER SPEC or *LOW OVER SPEC*

is displayed and the value changes to the one before change. Set a value once again.

Note: Count rate setting range

Example When the range is $3600 \text{m}^3/\text{h} (1 \text{m}^3/\text{s})$

Since the minimum value is 36000000 pulse/h,

 $3600(m^{3}/h) / 3600000(pulse/h) = 0.0001m^{3} = 0.1\ell.$

Since the maximum value is 3.6 pulse/h,

 $3600(m^{3}/h)/3.6(pulse/h) = 1000m^{3}$.

- The pulse width must be set to a value within a range of 0.3ms to 500ms. If you set a value exceeding 500 ms, the value is **forcibly changed to 500ms**.
- The pulse width must be **one half of the 100% output pulse frequency**. If a value exceeding the limit, regardless of the limit described in the section above, an error message

* HIGH OVER SPEC *

is displayed and the value returns to the one before change. Set a value once again. If the pulse width is set to 0, it is **automatically** set to one half of the pulse frequency at 100% output. However, if the calculation result exceeds 100ms, it is **forcibly set to 100ms**. • Either AUTO or MANUAL can be set for the pulse width setting mode. Depending on the pulse width mode, the pulse width to be set varies as shown in the table below:

Selection item	Pulse width value to be set
AUTO	After the count rate is set, the pulse width is automatically set to one half of the pulse frequency at 100% output.
MANUAL	Even after the count rate is set, the pulse width is not changed. * However, if the pulse width is out of the setting range as a result of count rate setting, the screen is automatically switched to the pulse width setting screen after the count rate setting.

* If the count rate exceeds 1000 (pulse/s), the pulse width setting mode is limited to the AUTO mode only and you cannot perform manual setting.

Note: Pulse width setting range

Example 1	When the range is $3600 \text{ m}^3/\text{h} (1 \text{ m}^3/\text{s})$ and the count rate is 0.001 m^3
-	Since the pulse rate is $3600 \text{ (m}^3/\text{h}) / 0.001 \text{ (m}^3) = 3600000 \text{ pulse/h} (1000 \text{ pulse/s}),$
	the full scale frequency is 1ms.
	Therefore, the pulse width can be set to $1 \text{ms x } 40\% = 0.4 \text{ms only}$.

- Example 2 When the range is $3600m^3/h (1m^3/s)$ and the count rate is $1000m^3$ Since the pulse rate is 3600(m3/h) / 1000(m3) = 3.6 pulse/h (0.001 pulse/s), the full scale frequency is 1000000ms. Therefore, the pulse width 1000000ms x 40% = 400000ms. However, since the maximum value is 500ms, the pulse width will be 500ms.
- Example 3 When the range is $3600 \text{m}^3/\text{h} (1\text{m}^3/\text{s})$, the count rate is 1m^3 and the pulse width is set to 0ms

Since the pulse rate is 3600(m3/h) / 1(m3) = 3600 pulse/h (1 pulse/s), the full scale frequency is 1000ms. Therefore, the pulse width is 1000ms x 40% = 400ms. However, since the maximum value is 100ms in the case of AUTO setting, the pulse width **becomes** 100ms.

- 94 —

The count rate and pulse width can be checked/changed by the following procedure. Shown below is an example of changing the count rate from $0.01m^3$ to 0.9 l.

Key operation	Display example	Description
	G1: COUNT RATE 0.01000 m3 [EXT] [ENT]	Select "COUNT RATE" in the configuration item selection screen. The currently set count rate (0.01m3 in this example) is displayed. Then press the [ENT] key.
STEP1 [ENT]	G1: COUNT RATE 0.01000 m3	The switch name display at the bottom changes (three keys [UP], [SEL] and [SET]). At the same time, the cursor appears. (The digit on which the cursor is positioned is
	[U P] [SEL] [SET]	reverse-displayed.).
STEP2	G1: COUNT RATE 0.0 <u>10</u> 00	Move the cursor to the digit of the unit using the [SEL] key.
[SEL]		
STEP3	[U P] [SEL] [SET] G1:	Change the unit to I using the [UP] key.
[UP] [SEL]	COUNT RATE 10.0000	Next, move the cursor to the digit you want to change using the [SEL] key.
	[U P] [SEL] [SET]	
STEP4	G1: COUNT RATE	Change the numeric value using the [UP] key.
[UP]⇔[SEL]	0. 0 0000 I [U P] [SEL] [SET]	Repeat this operation to change the setting value to the desired numeric value and press the [SET] key.
STEP5	G1: COUNT RATE 0.90000	When you press the [SET] key, a message con- firming you whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the
(SET)	OK?	setting, press the [NO] key.
STEP6-1	G1: COUNT RATE 0.01000	Pressing the [No] key when you are asked "OK?" causes the count rate to return to the previous value and enables you to redo the setting.
[NO]	m3 [U P] [SEL] [SET]	
STEP6-2(=END)	G1: COUNT RATE 0.90000	Pressing the [SET] key when you are asked "OK?" causes the setting value to be determined. Then press the [EXT] key. You return to the menu
[SET]	I [EXT] [ENT]	screen. Pressing the [ENT] key enables you to restart count rate change operation from a state of 0.9 l.

To set the pulse width setting mode or pulse width, select the relevant item shown below.Pulse width setting modePLS MODEPulse widthPLS WIDTH

Note: The unit changes as shown below by pressing $[\blacktriangle]$.

$$\rightarrow$$
 m³ \longrightarrow 1 \longrightarrow ml \longrightarrow bbl \longrightarrow gal \longrightarrow pt \longrightarrow qt \longrightarrow

8.2.22 Preset Count Value

Preset value for the preset counter can be set. Preset count value can be set within 0 to 999999999.

Preset counter will not be affected by the indicating unit but it is recommended that one of the integrating units be set as the indicating unit so that the operating condition of the counter can be checked.

* Preset output function can be selected. For details, see 0, "Preset Output Function."

Note <u>Preset counter operates only for foreword direction counts.</u>

Proceed as follows to check or change the preset count value.

■ To change the preset count value:

The following example shows how to change the preset count value from 500 to 1000.

H: MEAS MODE →PRESET CNT PRESET FNC Select "PRESET CNT" screen. STEP1 H1: PRESET CNT 00000500 The currently set value (500 in this example) is displayed. [ENT] PRESET CNT 00000500 The currently set value (500 in this example) is displayed. [ENT] PRESET CNT 00000500 Then press the [ENT] key. STEP2 H1: PRESET CNT 00000500 The switch name display at the bottom changes (three keys [UP], [SEL] and [SET]). At the same time, the cursor appears. (The digit on which the cursor is positioned is reverse-displayed.) STEP3 H1: PRESET CNT 00001000 Move the cursor to the desired digit using the [SEL] key and change the numeric value using the [UP] key. Repeat this operation to change the value the to 1000. [SEL] ↔ [UP] [U P] [SEL] [SET] When the value has changed to the desired numeric value, press the [SET] key, o set the value temporarily. STEP4 H1: PRESET CNT 00001000 When you press the [SET] key. a message confirming you whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press the [NO] key.	Key operation	Display example	Description
→PRESET CNT PRESET FNC jet j STEP1 H1: PRESET CNT 00000500 The currently set value (500 in this example) is displayed. [ENT] PRESET CNT 00000500 The nerest the [ENT] key. [ENT] [EXT] [ENT] [ENT] [EXT] * Pressing the [EXT] key returns you to the menu screen. STEP2 H1: PRESET CNT 00000500 The switch name display at the bottom changes (three keys [UP], [SEL] and [SET]). At the same time, the cursor appears. (The digit on which the cursor is positioned is reverse-displayed.) STEP3 H1: PRESET CNT 00001@00 Move the cursor to the desired digit using the [SEL] key and change the numeric value using the [UP] key. Repeat this operation to change the value the to 1000. [SEL]⇔[UP] [U P] [SEL] [SET] When the value has changed to the desired numeric value, press the [SET] key to set the value temporarily. STEP4 H1: PRESET CNT 00001000 When the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press			-
PRESET FNC [SEL] [ENT] STEP1 H1: PRESET CNT 00000500 The currently set value (500 in this example) is displayed. [ENT] PRESET CNT 00000500 Then press the [ENT] key. [ENT] [EXT] [ENT] STEP2 H1: PRESET CNT 00000500 The switch name display at the bottom changes (three keys [UP], [SEL] and [SET]). [ENT] [U P] [SEL] [SET] The same time, the cursor appears. (The digit on which the cursor is positioned is reverse-displayed.) STEP3 H1: PRESET CNT 0000100 Move the cursor to the desired digit using the [SEL] key and change the numeric value using the [UP] key. Repeat this operation to change the value the to 1000. [SEL]⇔[UP] [U P] [SEL] [SET] When the value has changed to the desired numeric value, press the [SET] key to set the value temporarily. STEP4 H1: PRESET CNT 00001000 When tyou press the [SET] key. a message confirming you whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press			screen.
STEP1 H1: PRESET CNT 00000500 The currently set value (500 in this example) is displayed. [ENT] [EXT] [ENT] STEP2 H1: PRESET CNT 00000500 * Pressing the [EXT] key returns you to the menu screen. STEP2 H1: PRESET CNT 00000500 The switch name display at the bottom changes (three keys (UP), [SEL] and [SET]). [ENT] [U P] [SEL] [SET] The same time, the cursor appears. (The digit on which the cursor is positioned is reverse-displayed.) STEP3 H1: PRESET CNT 00001000 Move the cursor to the desired digit using the [SEL] key and change the numeric value using the [UP] key. Repeat this operation to change the value the to 1000. [SEL]⇔[UP] [U P] [SEL] [SET] When the value has changed to the desired numeric value, press the [SET] key to set the value temporarily. STEP4 H1: PRESET CNT 00001000 When you press the [SET] key. a message confirming you whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press			
PRESET CNT 00000500 Then press the [ENT] key. [ENT] [EXT] [ENT] * Pressing the [EXT] key returns you to the menu screen. STEP2 H1: PRESET CNT [ENT] [00000500 The switch name display at the bottom changes (three keys [ENT] [UP] [SEL] CNT The switch name display at the bottom changes (three keys [ENT] [UP] [SEL] [SET] At the same time, the cursor appears. [ENT] [UP] [SEL] [SET] At the same time, the cursor is positioned is reverse-displayed.) STEP3 H1: PRESET CNT 00001000 [UP] [SEL] [SET] Move the cursor to the desired digit using the [SEL] key and change the numeric value using the [UP] key. [SEL] (UP] [U P] [SEL] [SET] Move the value has changed to the desired numeric value, press the [SET] key to set the value temporarily. STEP4 H1: When you press the [SET] key, a message confirming you whether the setting is OK is displayed. STEP4 H1: When you press the [SET] key. If you want to redo the setting, press		[SEL] [ENT]	
[ENT] 00000500 Then press the [ENT] key. [ENT] [EXT] [ENT] * Pressing the [EXT] key returns you to the menu screen. STEP2 H1: PRESET CNT The switch name display at the bottom changes (three keys [UP], [SEL] and [SET]). [ENT] [00000500 At the same time, the cursor appears. [ENT] [U P] [SEL] [SET] At the same time, the cursor is positioned is reverse-displayed.) STEP3 H1: Move the cursor to the desired digit using the [SEL] key and change the numeric value using the [UP] key. STEP3 H1: PRESET CNT 00001000 [U P] [SEL] [SET] When the value has changed to the desired numeric value, press the [SET] key to set the value temporarily. STEP4 H1: When you press the [SET] key, a message confirming you whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press	STEP1		The currently set value (500 in this example) is displayed.
Image: style sty			Then press the [ENT] key.
STEP2 H1: PRESET CNT ©0000500 The switch name display at the bottom changes (three keys [UP], [SEL] and [SET]). At the same time, the cursor appears. (The digit on which the cursor is positioned is reverse-displayed.) STEP3 H1: PRESET CNT 00001©00 Move the cursor to the desired digit using the [SEL] key and change the numeric value using the [UP] key. Repeat this operation to change the value the to 1000. [SEL]⇔[UP] [U P] [SEL] [SET] When the value has changed to the desired numeric value, press the [SET] key to set the value temporarily. STEP4 H1: PRESET CNT 00001000 When you press the [SET] key, a message confirming you whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press	[ENT]		
[ENT] PRESET_CNT ©0000500 [UP], [SEL] and [SET]). At the same time, the cursor appears. (The digit on which the cursor is positioned is reverse-displayed.) STEP3 H1: PRESET_CNT 00001©00 Move the cursor to the desired digit using the [SEL] key and change the numeric value using the [UP] key. Repeat this operation to change the value the to 1000. [SEL]⇔[UP] [U P] [SEL] [SET] When the value has changed to the desired numeric value, press the [SET] key to set the value temporarily. STEP4 H1: PRESET_CNT 00001000 When you press the [SET] key, a message confirming you whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press		EXT] [ENT]	* Pressing the [EXT] key returns you to the menu screen.
[ENT] Image: Construction of the same time, the cursor appears. [ENT] At the same time, the cursor appears. [UP] [SEL] [SET] (The digit on which the cursor is positioned is reverse-displayed.) STEP3 H1: PRESET CNT 00001I000 Move the cursor to the desired digit using the [SEL] key and change the numeric value using the [UP] key. [SEL]⇔[UP] [UP] [SEL] [SET] Move the cursor to change the value the to 1000. [SEL]⇔[UP] [UP] [SEL] [SET] When the value has changed to the desired numeric value, press the [SET] key to set the value temporarily. STEP4 H1: PRESET CNT 00001000 When you press the [SET] key, a message confirming you whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press	STEP2		
[ENT] [U P] [SEL] [SET] (The digit on which the cursor is positioned is reverse-displayed.) STEP3 H1: PRESET CNT 00001000 Move the cursor to the desired digit using the [SEL] key and change the numeric value using the [UP] key. Repeat this operation to change the value the to 1000. [SEL]⇔[UP] [U P] [SEL] [SET] When the value has changed to the desired numeric value, press the [SET] key to set the value temporarily. STEP4 H1: PRESET CNT 00001000 When you press the [SET] key, a message confirming you whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press			
Image: Image	(ENT)		
STEP3 H1: PRESET CNT 00001000 Move the cursor to the desired digit using the [SEL] key and change the numeric value using the [UP] key. Repeat this operation to change the value the to 1000. [SEL]⇔[UP] [U P] [SEL] [SET] When the value has changed to the desired numeric value, press the [SET] key to set the value temporarily. STEP4 H1: PRESET CNT 00001000 When you press the [SET] key, a message confirming you whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press	נבואון		
PRESET CNT 00001000 change the numeric value using the [UP] key. Repeat this operation to change the value the to 1000. [SEL]⇔[UP] [U P] [SEL] [SET] When the value has changed to the desired numeric value, press the [SET] key to set the value temporarily. STEP4 H1: PRESET CNT 00001000 When you press the [SET] key, a message confirming you whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press	STED2		
00001000 [SEL]⇔[UP] [UP] [SEL] [SET] When the value has changed to the desired numeric value, press the [SET] key to set the value temporarily. STEP4 H1: PRESET CNT 00001000 When you press the [SET] key, a message confirming you whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press	SIEFS		
[U P] [SEL] [SET] When the value has changed to the desired numeric value, press the [SET] key to set the value temporarily. STEP4 H1: When you press the [SET] key, a message confirming you whether the setting is OK is displayed. PRESET CNT 00001000 If OK, press the [SET] key. If you want to redo the setting, press		00001000	
Image: Constraint of the setting is of the	[SEL]⇔[UP]		
STEP4 H1: PRESET CNT 00001000 When you press the [SET] key, a message confirming you whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press		(U PI (SELI (SET)	
PRESET CNT 00001000 whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press			
00001000 If OK, press the [SET] key. If you want to redo the setting, press	STEP4		
	[SET]	<u>I</u>	
OK?		OK?	
[N O] [SET]			
STEP5-1 H1: Pressing the [NO] key when you are asked "OK?" causes the	STEP5-1		
PRESET CNT setting value to return to the previous value and enables you to redo the setting.			
[NO]	INO		
	[ivo]		
[U P] [SEL] [SET] STEP5-2(=END) H1: Pressing the [SET] key when you are asked "OK?" causes the	STEP5-2(=END)		Pressing the [SET] key when you are asked "OK?" causes the
PRESET CNT setting value to be determined.	OTEI O-2(-LIND)		
00001000 Then press the [EXT] key. You return to the menu screen.		00001000	
[SET] Pressing the [ENT] key enables you to restart	[SET]		Pressing the [ENT] key enables you to restart
[EXT] [ENT] setting value change operation from a state of 1000.		EXT] [ENT]	setting value change operation from a state of 1000.

8.2.23 Preset Point Output Function

The output function when a preset counter becomes the preset value can be set. The various preset point output functions shown below can be selected.

Preset Point Output Functions

DI function	Preset point output level function	
HOLD	Output status level hold	
50ms PULSE	Pulse out (pulse width 50ms)	
500ms PULSE	Pulse out (pulse width 500ms)	

Note: If you set the preset point output function to "50ms PULSE" or "500ms PULSE", you need to set the preset count value to 1, 2, 5, 25, 125×10^{n} . (If you set a value that does not meet this condition, the preset point output timing may be shifted when a total counter overflow occurs.

Proceed as follows to check or change the preset point output functions.

• To change the preset output function

The following example shows how to change the present output function from Output condition hold (HOLD) to One-shot pulse output with pulse width of 50ms (50ms PULSE).

Key operation	Display example	Description
	H: MEAS MODE PRESET CNT →PRESET FNC	Select "PRESET FNC" in the configuration item selection screen.
	[SEL] [ENT]	
STEP1	H2: PRESET FNC HOLD	The current setting value is displayed (HOLD in this example).
[ENT]	[EXT] [ENT]	Then press the [ENT] key. * Pressing the [EXT] key returns you to the menu screen.
STEP2	H2: PRESET FNC HOLD	The switch name display at the bottom changes (three keys [UP], [DOWN] and [SET]). At the same time, the cursor appears. (The digit on which the cursor is positioned is
[ENT]	[U P] [DWN] [SET]	reverse-displayed.)
STEP3	H2: PRESET FNC	Change the selection item using the [UP]/[DWN] key.
[UP]/[DWN]	50ms PULSE [U P] [DWN] [SET]	When you have selected the desired item, press the [SET] key.
STEP4	H2: PRESET FNC 50ms PULSE	When you press the [SET] key, the selected item is set temporarily and a message confirming you whether the setting is OK is displayed.
[SET]	OK?	If OK, press the [SET] key. If you want to redo the setting, press the [NO] key.
	[N O] [SET]	
STEP5-1	H2: PRESET FNC HOLD	Pressing the [NO] key when you are asked "OK?" causes the setting to return to the previous state and enables you to redo the setting.
[NO]	[U P] [DWN] [SET]	
STEP5-2(=END)	H2: PRESET FNC 50ms PULSE	Pressing the [SET] key when you are asked "OK?" causes the setting to be determined.
[SET]	[EXT] [ENT]	Then, press the [EXT] key. You return to the menu screen. Pressing the [ENT] key enables you to restart setting operation from a state of 50ms PULSE.

8.2.24 Flow Rate High, Low, High-High and Low-Low limit Alarm Setting

You can set the high, low, high-high, or low-low limit of the flow rate at which an alarm is generated, as % value of the span flow rate of the set maximum range.

Flow rate high, low, high-high, and low-low limit alarm values can be set within a range of -10% to 110% (percentage to Range 1), in increments of 0.5%.

You can use the setting item number to switch between the flow rate high, low, high-high and low-low limit alarms ON/OFF and the flow rate high, low, high-high and low-low limit alarm values.

Flow rate high limit alarm ON/OFF Flow rate high limit alarm value Flow rate low limit alarm ON/OFF Flow rate low limit alarm value Flow rate high-high limit alarm ON/OFF Flow rate high-high limit alarm value Flow rate low-low alarm ON/OFF Flow rate low-low limit value I1: H ALARM SET I2: H ALARM VAL I3: L ALARM SET I4: L ALARM VAL J1: HH ALARM SET J2: HH ALARM VAL J3: LL ALARM SET J4: LL ALARM VAL

High and low limit (high-high and low-low limit) alarms ON/OFF Shown below is an example of switching the high limit alarm setting from OFF to ON.

Key operation **Display example** Description Select "H ALM SET" in the configuration item Ŀ MEAS MODE selection screen. →H ALM SET H ALM VAL L ALM SET L ALM VAL [SEL] (ENT) 11: The current setting value (OFF in this example) is STEP1 H ALM SET displayed. OFF Then press the [ENT] key. [ENT] * Pressing the EXT] key returns you to the menu screen. (EXT) [ENT] 11: The switch name display at the bottom changes (three STEP2 H ALM SET keys [UP], [DOWN] and [SET]). OFF At the same time, the cursor appears. (The digit on which the cursor is positioned is [ENT] reverse-displayed.) [U P] [DWN] [SET] 11: Change the selection item using the [UP]/[DWN] key. STEP3 H ALM SET ON When you have selected the desired item, press the [UP]/[DWN] [SET] key. [U P] [DWN] [SET] STEP4 11: When you press the [SET] key, the selected item is set H ALM SET temporarily and a message confirming you whether the ON setting is OK is displayed. If OK, press the [SET] key. If you want to redo the [SET] setting, press the [NO] switch. OK? [SET] [N O] STEP5-1 11: Pressing the [NO] key when you are asked "OK?" H ALM SET causes the setting value to return to the previous value OFF and enables you to redo the setting. [NO] [U P] [DWN] [SET] 11: STEP5-2(=END) Pressing the [SET] key when you are asked "OK?" H ALM SET causes the setting to be determined. ON Press the [EXT] key. You will return to the menu screen. [SET] Pressing the [ENT] key enables you to restart setting (EXT) [ENT] operation from a state of ON.

• Changing the high, low, high-high, or low-low limit alarm value

Shown below is an example of changing the high limit alarm value from +105% to +103%.

Key operation	Display example	Description
	1:	Select "HALM VAL" in the configuration item
	MEAS MODE	selection screen.
	H ALM SET	
	L ALM SET	
	[SEL] [ENT]	
STEP1	12:	The currently set value (+105.0 in this example) is
	H ALM VAL	displayed.
	+105.0	
[ENT]	%	Then press the [ENT] key.
		* Processing the (EVT) key returns you to the manu
	[EXT] [ENT]	* Pressing the [EXT] key returns you to the menu screen.
STEP2	12:	The switch name display at the bottom changes
01212	H ALM VAL	(three keys [UP], [SEL] and [SET]).
	105.0	At the same time, the cursor appears.
[ENT]	%	(The digit on which the cursor is positioned is
		reverse-displayed.)
	[U P] [SEL] [SET]	
STEP3	I2: H ALM VAL	Move the cursor to the desired digit using the [SEL]
	+108.0	key and change the numeric value using the [UP] switch.
	%	Repeat this operation to change the value to
[SEL]⇔[UP]		+103.0%.
	(U P] [SEL] [SET]	When you have selected the desired item, press
		the [SET] key to set the value temporarily.
STEP4	12:	When you press the [SET] key, a message
	H ALM VAL +103.0	confirming you whether the setting is OK is
	+103.0	displayed.
[SET]		If OK, press the [SET] key. If you want to redo the
	OK?	setting, press the [NO] key.
	[N O] [SET]	
STEP5-1	I2: HALM VAL	Pressing the [NO] key when you are asked "OK?"
	105.0	causes the numeric value to return to the previous value and enables you to redo the setting.
[NO]	%	value and enables you to redo the setting.
	[U P] [SEL] [SET]	
STEP5-2(=END)		Pressing the [SET] key when you are asked "OK?"
	H ALM VAL	causes the setting to be determined.
	+103.0	Press the [EXT] key. You return to the menu
[SET]	%	screen.
		Pressing the [ENT] key enables you to restart
	[EXT] [ENT]	setting value change operation from a state of
	[(=···]	+103.0%.

Note: If you set a value that is not within a range of -10% to +110%, * LOW OVER SPEC* or *HIGH OVER SPEC* is displayed and the value returns to the one before change. Set a value once again.

8.2.25 Empty Alarm Setting

You can set the empty alarm to detect an empty condition in the pipe. If the fluid is run out when the empty alarm is set to "On", EMPTY ALARM is displayed.

• Fluid empty alarm setting

Selection item	Contents	
OFF	Fluid empty alarm disabled	
NORMAL	Fluid empty alarm enabled	Sensitivity level Low
SENSITIVE	Fluid empty alarm enabled	Sensitivity level Middle
SENSITIVE-H	Fluid empty alarm enabled	Sensitivity level High

* When setting the fluid empty alarm to be "enabled", usually set NORMAL (sensitivity level Low). Set a sensitivity level of SENSITIVE or SENSITIVE-H only when it is difficult to detect an empty condition due to the status of the operating fluid and the piping.

• Changing the empty alarm setting

Shown below is an example of changing the alarm setting from OFF to SENSITIVE-H.

Key operation	Display example	Description
r	K: MEAS MODE →EMPTY ALM SELF CHECK ALM PRESET	Select "EMPTY ALM" in the configuration item selection screen.
	[SEL] [ENT]	
STEP1	K1: EMPTY ALM OFF	The current setting value (OFF in this example) is displayed.
[ENT]	[EXT] [ENT]	Then press the [ENT] key. * Pressing the [EXT] key returns you to the menu screen.
STEP2 [ENT]	K1: EMPTY ALM OFF	The switch name display at the bottom changes (three keys [UP], [DOWN] and [SET]). At the same time, the cursor appears. (The digit on which the cursor is positioned is
	[U P] [DWN] [SET]	reverse-displayed.)
STEP3	K1: EMPTY ALM SENSETIVE-H	Change the selection item using the [UP]/[DWN] key. When you have selected the desired item, press the [SET]
[UP]/[DWN]	[U P] [DWN] [SET]	key.
STEP4	K1: EMPTY ALM SENSITIVE-H	When you press the [SET] key, the selected item is set temporarily and a message confirming you whether the setting is OK is displayed.
[SET]	OK?	If OK, press the [SET] key. If you want to redo the setting, press the [NO] key.
STEP5-1	K1: EMPTY ALM OFF	Pressing the [NO] key when you are asked "OK?" causes the setting value to return to the previous value and enables you to redo the setting.
[NO]	[U P] [DWN] [SET]	
STEP5-2(=END)	K1: EMPTY ALM SENSITIVE-H	Pressing the [SET] key when you are asked "OK?" causes the setting to be determined. Then press the [EXT] key. You return to the menu screen.
[SET]	[EXT] [ENT]	Pressing the [ENT] key enables you to restart setting operation from a state of SENSITIVE-H.

8.2.26 Self-diagnosis ON/OFF Setting

You can set the self-diagnosis function to be "enabled" or "disabled."

If the self-diagnosis function is disabled, no error message is displayed even if any of the errors listed below occurs.

- ROM defect
- RAM defect
- Own parameter error
- Excitation cable is not connected or it is disconnected
- Excitation circuit fault
- ADC circuit fault
- Total data destroy

Selection item	Description	
OFF	Self-diagnosis function is disabled.	
ON	Self-diagnosis function is enabled.	

Error message is displayed in measurement sub screen.

Changing the self-diagnosis function setting

Shown below is an example of changing the self-diagnosis setting from OFF to ON.

Key operation	Display example	Description
	K: MEAS MODE EMPTY ALM →SELF CHECK ALM PRESET	Select "SELF CHECK" in the configuration item selection screen.
	[SEL] [ENT]	
STEP1	K2: SELF CHECK OFF	The current setting value (OFF in this example) is displayed.
[ENT]	[EXT] [ENT]	Then press the [ENT] key. * Pressing the [EXT] key returns you to the menu screen.
STEP2	K2: SELF CHECK OFF	The switch name display at the bottom changes (three keys [UP], [DWN] and [SET]). At the same time, the cursor appears.
[ENT]	[U P] [DWN] [SET]	(The digit on which the cursor is positioned is reverse-displayed.)
STEP3	K2: SELF CHECK	Change the selection item using the [UP]/[DWN] key.
[UP]/[DWN]	ON	When you have selected the desired item, press the [SET] key.
	[U P] [DWN] [SET]	
STEP4	K2: SELF CHECK ON	When you press the [SET] key, the selected item is set temporarily and a message confirming you whether the setting is OK is displayed.
[SET]	OK?	If OK, press the [SET] key. If you want to redo the setting, press the [NO] key.
	[N O] [SET]	
STEP5-1	K2: SELF CHECK OFF	Pressing the [NO] key when you are asked "OK?" causes the setting value to return to the previous value and enables you to redo the setting.
[NO]		
	[U P] [DWN] [SET]	
STEP5-2(=END)	K2: SELF CHECK ON	Pressing the [SET] key when you are asked "OK?" causes the setting to be determined. Then press the [EXT] key. You return to the menu screen.
[SET]	[EXT] [ENT]	Pressing the [ENT] key enables you to restart setting operation from a state of ON.

8.2.27 Alarm Output Preset Function Setting

Setting the digital output to "failure alarm output" enables a digital signal to be output when the converter self-diagnosis function detects a defect.

When setting the digital output, you specify whether empty alarm is to be included in the failure alarm output targets.

Selection item	Description
WITHOUT EMP	Empty alarm is not included in failure alarm output.
WITH EMP	Empty alarm is included in failure alarm output.

* For other failure alarm targets, see 0 "Self-diagnosis Function Setting."

• Changing the alarm output preset function

Shown below is an example of changing the alarm output preset function from WITH EMP to WITHOUT EMP.

Key operation	Display example	Description
	K: MEAS MODE EMPTY ALM SELF CHECK →ALM PRESET	Select "ALM PRESET" in the configuration item selection screen.
	[SEL] [ENT]	
STEP1	K3: ALM PRESET WITH EMP	The current setting value (WITH EMP in this example) is displayed.
[ENT]	[EXT] [ENT]	Then press the [ENT] key. * Pressing the [EXT] key returns you to the menu screen.
STEP2	K3: ALM PRESET WITH EMP	The switch name display at the bottom changes (three keys [UP], [DWN] and [SET]). At the same time, the cursor appears.
[ENT]	[U P] [DWN] [SET]	(The digit on which the cursor is positioned is reverse-displayed.)
STEP3	K3: ALM PRESET WITHOUT EMP	Change the selection item using the [UP]/[DWN] key. When you have selected the desired item, press the [SET]
[UP]/[DWN]	[U P] [DWN] [SET]	key.
STEP4	K3: ALM PRESET WITHOUT EMP	When you press the [SET] key, the selected item is set temporarily and a message confirming you whether the setting is OK is displayed.
[SET]	OK? [N 0] [SET]	If OK, press the [SET] key. If you want to redo the setting, press the [NO] key.
STEP5-1	K3: ALM PRESET WITH EMP	Pressing the [NO] key when you are asked "OK?" causes the setting value to return to the previous value and enables you to redo the setting.
[NO]	[U P] [DWN] [SET]	
STEP5-2(=END)	K3: ALM PRESET WITHOUT EMP	Pressing the [SET] key when you are asked "OK?" causes the setting to be determined. Then press the [EXT] key. You return to the menu screen.
[SET]	[EXT] [ENT]	Pressing the [ENT] key enables you to restart setting operation from a state of WITHOUT EMP.

8.2.28 Rate-Of-Change Limit and Control Limit Time

The rate-of-change limit is used to eliminate high electrical noise contained in the process flow signal.

To check electrical noise, two parameters are defined: rate-of-change limit (set in percent value of the span) and control limit time (set in units of seconds). Normally the flowmeter produces the analog output signal by sampling the flow rate signal at 1/24 (or 1/12) of a second sampling rate. If the sampled value exceeds the set rate-of-change limit value based on the averaged flow rate value up until the sampled time, the system will reject that sampled value and instead the averaged value including the rate-of-change limit value in place of the rejected sampled value will be output.

However, if the limit-exceeding sampled value continues for the same flow direction for more than the preset control limit time, which data will be used as the output signal. The setting ranges for these two parameters are as follows:

- Rate-of-change limit 0 to 30% / 50ms (in increments of 0.1%)
- Control limit time: 0 to 20 sec (in increments of 1 second)

Note

If "0" is set in either of these parameters, the rate-of-change limit function is disabled.

You can switch between the rate-of-change limit value and control limit time by the setting item number.

Rate-of-change limit	L1: LIMIT RATE
Control limit time	L2: LIMIT TIME

• Changing the rate of change limit

Shown below is an example of changing the rate-of-change limit value from 10.0% to 15.0%.

Key operation	Display exa		Description
	L:		Select "LIMIT RATE" in the configuration item
	MEAS MODE		selection screen.
	LIMIT TIME		
	(SEL)	[ENT]	
STEP1	L1:		The current setting value (10.0% in this example) is
	LIMIT RATE		displayed.
	10.0 %		
[ENT]	70		Then press the [ENT] key.
			* Pressing the [EVT] quitch returns you to the manu
	[EXT]	[ENT]	* Pressing the [EXT] switch returns you to the menu screen.
STEP2			The switch name display at the bottom changes
01212	LIMIT RATE		(three keys [UP], [SEL] and [SET]).
	10.0		At the same time, the cursor appears.
[ENT]	%		(The digit on which the cursor is positioned is
. ,			reverse-displayed.)
	(U P] (SEL)	(SET)	
		[021]	
STEP3	L1:		Move the cursor to the desired digit using the [SEL]
	LIMIT RATE		key and change the numeric value using the [UP]
	% %		key.
[SEL]⇔[UP]	,0		Repeat this operation to change the value the to 15.0%.
			13.0%.
	(U P) (SEL)	[SET]	When you have selected the desired numeric value,
			press the [SET] key to set the value temporarily.
STEP4	L1:		When you press the [SET] key, a message
	LIMIT RATE		confirming you whether the setting is OK is
	15.0		displayed.
[SET]	×**		If OK, press the [SET] key. If you want to redo the
	OK?		setting, press the [NO] key.
	[N O]	[SET]	
STEP5-1	L1:		Pressing the [NO] key when you are asked "OK?"
			causes the numeric value to return to the previous
	10.0 %		value and enables you to redo the setting.
[NO]	70		
	[U P] [SEL]	SET]	
STEP5-2(=END)	L1:		Pressing the [SET] key when you are asked "OK?"
	LIMIT RATE 15.0		causes the setting value to be determined.
ICETI	10.0		Press the [EXT] key. You return to the menu
[SET]			screen. Pressing the [ENT] key enables you to restart
	(EXT)	[ENT]	setting value change operation from a state of

Note 1: If you try to set the value more than 30.0%, an error message * HIGH OVER SPEC* appears. Set the value within the specified range.

8.2.29 Fixed-Value Output

The fixed-value output is used to **output a fixed current and a fixed pulse output independently of the flow rate signal**. (The fixed pulse output is available only when **DO1** is used for **PULSE OUT function**.) Fixed pulse cannot be output from D02 (optional).

The fixed-value output can be set in the ranges described below. (Current output and pulse output can be set and output at the same time.)

- Fixed current output: 2.4 to 24 mA (in increments of 0.1 mA)
- Fixed pulse output: 0 to 1000pps (in increments of 1 pps)

If fixed output is ON, the sub display is used for fixed output display in the measurement mode.

Operation	when	fixed	output	is ON

Current output	Set current output
Pulse output	Pulse output at the set pulse rate
Digital output other than pulse	State held
Display	Sub display: Used for fixed output display
	(Totalization is not performed.)

Display example:

		~	1 -	D		U	U				*			
*		1	0	0	0	0		Ρ	Ρ	S	*			
*			2	0		0		m	A		*			
	 			Tł	ne ur	nit is	(mA)	fixe	d.	•	•	•	decim 5) fixec	nal poi

This fixed-value output function does not work in the calibration mode.

When OFF is selected in the fixed output function, setting for output is not needed.

Proceed as follows to check or change the enable/disable status of the fixed-value output and its output values.

Fixed-value output enable/disable status and its output values, fixed current output and fixed pulse output can be selected by the configuration items as follows:

Fixed-value enable/disable status	L1: FIXED OUT
Fixed current output	L2: FIXED CURR
Fixed pulse output	L3: FIXED PULSE

• Changing the fixed output function

Shown below are the procedures for setting the fixed output to ON and setting the fixed current value/fixed pulse value. The fixed current value and fixed pulse value can be set independently.

Key operation	Display example	Description
	M:	Select "FIXED OUT" in the configuration item selection
	MEAS MODE →FIXED OUT	screen.
	FIXED CURR	
	FIXED PULSE	
	[SEL] [ENT]	
STEP1	M1:	The current setting value (OFF in this example) is set.
	FIXED OUT OFF	Then press the [ENT] key.
[ENT]		Then press the [ENT] key.
[=]		* Pressing the [EXT] key returns you to the menu screen.
	[EXT] [ENT]	
STEP2	M1:	The switch name display at the bottom changes (three
	FIXED OUT	keys [UP], [DWN] and [SET]).
[ENT]		At the same time, the cursor appears. (The digit on which the cursor is positioned is
		reverse-displayed.)
	[U P] [DWN] [SET]	
STEP3	M1:	Change the selection item using the [UP]/[DWN] key.
	FIXED OUT	Man the second stand the desired there exceed the (CET)
(ו אארטאנסו אארט		When you have selected the desired item, press the [SET] key.
[UP]/[DWN]		NGY.
	[U P] [DWN] [SET]	
STEP4	M1:	When you press the [SET] key, the selected item is set
	FIXED OUT	temporarily and a message confirming you whether the
(CET)	ON IN	setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting,
[SET]		press the [NO] key.
	OK? [N O] [SET]	
STEP5-1	M1:	Pressing the [NO] key when you are asked "OK?" causes
	FIXED OUT	the numeric value to return to the previous value and
(1)(2)	OFF	enables you to redo the setting.
[NO]		
STEP5-2	[U P] [DWN] [SET] M2:	Pressing the [SET] key when you are asked "OK?" causes
51240-2	FIXED CURR	the fixed current output ON setting to be determined and
	20.0	the fixed current value setting screen to be automatically
[SET]	mA	developed.
	(EXT) [ENT]	At the same time, the cursor appears. (The digit on which the cursor is positioned is
		reverse-displayed.)
STEP6	M2:	Move the cursor to the desired digit using the [SEL] key
	FIXED CURR 12.0	and change the numeric value using the [UP] key.
	mA	Repeat this operation to change the value to 12.0mA.
[SEL]⇔[UP]		When the value has changed to the desired
	(U P] [SEL] [SET]	numeric value, press the [SET] key to set the value
		temporarily.

Key operation	Display example	Description
STEP6	M2: FIXED CURR 12.0 mA	Move the cursor to the desired digit using the [SEL] key and change the numeric value using the [UP] key. Repeat this operation to change the value to 12.0mA. When the value has changed to the desired
	[U P] [SEL] [SET]	numeric value, press the [SET] key to set the value temporarily.
STEP7 [SET]	M2: FIXED CURR 12.0 MA OK?	When you press the [SET] key, the selected item is set temporarily and a message confirming you whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press the [NO] key.
STEP8-1	[N O] [SET] M2:	Pressing the [NO] key when you are asked "OK?"
[NO]	FIXED CURR 20.0 mA	causes the numeric value to return to the previous value and enables you to redo the setting.
	[U P] [SEL] [SET]	
STEP8-2	M3: FIXED PULSE	Pressing the [SET] key when you are asked "OK?" causes the fixed output current value setting to be determined and the fixed output pulse setting screen to
[SET]	PPS [EXT] [ENT]	be developed automatically At the same time, the cursor appears. (The digit on which the cursor is positioned is
		reverse-displayed.)
STEP9 [SEL]⇔[UP]	M3: FIXED PULSE 00 0 00 PPS [U P] [SEL] [SET]	Move the cursor to the desired digit using the [SEL] key and change the numeric value using the [UP] key. Repeat this operation to change the value to 100 PPS. When the value has changed to the desired numeric value, press the [SET] key to set the value temporarily.
STEP10	M3:	When you press the [SET] key, a message confirming
[SET]	FIXED PULSE 00100 PPS OK?	you whether the setting is OK is displayed. If OK, press the [SET] key. If you want to redo the setting, press the [NO] key.
	[N O] [SET]	
STEP11-1	M3: FIXED PULSE	Pressing the [No] key when you are asked "OK?" causes the numeric value to return to the previous value and enables you to redo the setting.
[NO]	UP] (SEL] (SET]	
STEP11-2(=END)	M3: FIXED PULSE 00100	Pressing the [SET] key when you are asked "OK?" causes the setting value to be determined. Then press the [EXT] key. You return to the menu
[SET]	PPS [EXT] [ENT]	screen.

Note 1: If you set a value beyond the allowable range, 2.4mA or 24mA (in the case of fixed current output) or 24mA or 10000pps (in the case of fixed pulse output) is forcibly set.

Note 2: The pulse width set in Section 8.2.13 is used for fixed pulse output. The pulse width must not be greater than one half of the fixed output setting frequency. However, the pulse width will be 40% of fixed output setting frequency if **it exceeds 1000pps**.

Note 3: If the fixed output is set to ON, the fixed output current value and fixed output pulse value setting screen is automatically developed. However, fixed output actually starts when the fixed output pulse value setting is determined. (If the fixed output current value and fixed output pulse value are set independently, fixed output starts when the relevant setting is determined independently.)
8.2.30 Zero Offset Adjustment

Zero offset can be easily applied to make the flowmeter outputs comparable to process values measured by other instruments.

If the zero adjustment described in "0 Still Water Zero Adjustment" can be performed, this zero offset adjustment is not needed.

■ To change the zero offset value:

Calculate the zero offset value with the following equation:

Zero offset value (%) = {(actual flow rate) - (LF600F measured value)}

* The zero offset value should be calculated in percent value for Range 1 of converter. See the following example.

(Example)

Measured condition	Flow rate	% in measuring span
Actual flow rate obtained from other instrument.	10.0 m ³ /min	50 %
LF600F measured value	10.5 m ³ /min	52.5 %
Zero offset		-2.5 %

(If zero offset is set to -2.5 %, the converter will output 50.0 % flow rate instead of -2.5%.)

The following example shows how to change the zero offset value from +1.0% to -2.5%.

Key operation	Display example	Description
	N:	Select "MANUAL ZERO" in the configuration item
	MEAS MODE	selection screen.
	→MANUAL ZERO	
	[SEL] [ENT]	
STEP1	N1:	The current setting value (+1.0% in this example) is
	MANUAL ZERO +001.0	displayed.
(CNT)	%	Then prove the (ENT) key
(ENT)		Then press the [ENT] key.
		* Pressing the [EXT] key returns you to the menu
	[EXT] [ENT]	screen.
STEP2	N1:	The switch name display at the bottom changes
	MANUAL ZERO ±001.0	(three keys ([UP], [SEL] and [SET]).
	₩001.0 %	At the same time, the cursor appears.
[ENT]	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	(The digit on which the cursor is positioned is
		reverse-displayed.)
	[U P] [SEL] [SET]	
STEP3	N1:	Move the cursor to the desired digit using the [SEL]
	MANUAL ZERO	key and change the numeric value using the [UP]
	-002.5	key.
[SEL]⇔[UP]	76	Repeat this operation to change the value to -2.5%.
		When the value has changed to the desired
	[U P] [SEL] [SET]	numeric value, press the [SET] key to set it
		temporarily.
STEP4	N1:	When you press the [SET] key, a message
	MANUAL ZERO	confirming you whether the setting is OK is
	-002.5	displayed.
[SET]		If OK, press the [SET] key. If you want to redo the
	OK?	setting, press the [NO] key.
	[N O] [SET]	
STEP5-1	N1: MANUAL ZERO	Pressing the [NO] key when you are asked "OK?" causes the numeric value to return to the previous
	±001.0	value and enables you to redo the setting.
[NO]	%	value and enables you to redo the setting.
[]		
STEP5-2(=END)	[U P] [SEL] [SET] N1:	Pressing the [SET] key when you are asked "OK?"
	MANUAL ZERO	causes the setting value to be determined.
	-002.5	Then press the [EXT] key. You return to the menu
[SET]	%	screen.
	· · ·	Pressing the [ENT] key enables you to restart
	[EXT] [ENT]	setting value change operation from a state of
		+2.5%.

Note: The manual zero adjustment value can be set within a range of ±1 m/s equivalent (±10 % of the maximum range). If you set a value out of this range, an error message * HIGH OVER SPEC * or * LOW OVER SPEC * is displayed. In this case, redo the setting.
In addition, you perform zero adjustment with one-push key while the detector is filled with still water; the zero offset adjustment value will be automatically cleared to 0.0%.

8.2.31 Parameter initial settings list

The list of initial parameter settings is shown in the table below.

Parameter name	Initial setting value	
Exciting current	Adjusted value when the product is shipped from the factory	
5	(described on the detector nameplate)	
Meter size	Value requested when ordered.	
Exciting frequency	24Hz	
	* When meter size is 250 to 450mm: 12Hz	
	When meter size is 500 or 600mm: 6Hz	
Flow direction	NORMAL	
Password	000	
Address setting	126	
Main display setting	gal/min	
Sub display setting	COUNT B	
Custom (coefficient)	0	
Custom (unit)	" "(7 characters are all blank spaces)	
LCD density	3	
Switch position	BOTTOM (screen bottom)	
Range type	Value requested when ordered	
Range 1 to Range 4	Value requested when ordered	
Hysteresis	3.0 %	
Damping constant	5.0 s	
Low cut value	1.0 %	
Output setting at alarm occurrence	4mA output	
Display low cut	OFF	
Output low limit setting	4mA	
Digital output 1	PULSE OUT (Pulse output)	
Digital output 2	EMPTY ALM (Empty alarm output)	
Digital input	C RES/STA (Counter reset/start)	
Digital output 1 status	NORMAL OPEN	
Digital output 2 status	NORMAL OPEN	
Digital input detection level	HIGH LEVEL	
Count rate	100 gal	
Pulse width setting mode	MANUAL	
Pulse width	5 ms	
Preset count value	0000000	
Preset output function	HOLD	
High limit alarm setting	OFF	
High limit value	0.0 %	
Low limit alarm setting	OFF	
Low limit value	0.0 %	
High high limit alarm setting	OFF	
High high limit value	0.0 %	
Low low limit alarm setting	OFF	
Low low limit value	0.0 %	
Fluid empty alarm	ON detection: NORMAL	
Self-disgnosis function	ON	
Alarm output preset	WITHOUT EMP (excluding the fuild empty alram)	
Rate-of-change limit	0.0 %	
Control time	0 s	
Fixed output function	OFF	
Manual zero	0.0 % ately when ordered are set as instructed	

Note 1: Parameters specified separately when ordered are set as instructed.

Note 2: If an option board is not provided, Digital output 2 and Digital input functions do not work.

TOSHIBA

9. Calibration

9.1 Calibration Items

You can conduct the following in the calibration mode:

- Checks or calibrates the zero and span of the converter by using a simulation signal.
- Checks of the excitation current.

To change the mode to the calibration mode, see 0, "Mode Change."

To check or change the zero and span of the converter and the excitation current value, follow the procedure described below.

However, these are already checked and calibrated when shipped from the factory. Do not change these settings unless it is necessary to calibrate in the field.

Section	Configuration item	Display example
9.2.1	0 % flow rate calibration	FLOW CAL 0
9.2.2	50 % flow rate calibration	FLOW CAL 50
9.2.3	100 % flow rate calibration	FLOW CAL100
9.2.4	Checking the excitation current value	EX CURR DSP

9.2 Calibration Using Converter Signal Source

9.2.1 0 % Flow Rate Calibration (zero point calibration)

Using the converter's internal calibration circuit, 0% flow rate (hereafter called zero point) calibration can be made.

■ To check the zero point of flow measurement:

Key operation	Display example	Description
	O: MEAS MODE →FLOW CAL 0 FLOW CAL 50 FLOW CAL100 EX CURR DSP [SEL] [ENT]	Select "FLOW CAL 0" in the configuration setting item selection screen.
STEP1	O1: FLOW CAL 0	The zero point by simulation input is displayed.
[ENT]	0.1 %	Then press the [SET] key.
	[EXT] [SET]	* Pressing the [EXT] key returns you to the menu.
STEP2	O1: ADJUST READY 0.1	When you press the [SET] switch, the title display changes to ADJUST READY and enables you to perform calibration.
[SET]	% [* Pressing the [EXT] key returns you to the previous screen.
STEP3	O1: FLOW CAL 0 *CAL 0% ADJ	Holding down the [SET] key when ADJUST READY is displayed, "*CAL 0% ADJ" is displayed and zero point calibration starts.
[SET]Hold down		Switch operation is disabled during calibration.
STEP4	O1: FLOW CAL 0 0.0 %	After approximately 4 seconds, zero point calibration is completed and a new zero point is displayed.
	[EXT] [SET]	Press the [EXT] key. You return to the menu screen.

Note 1: To start calibration, hold down the [SET] key.

Note 2: To cancel the adjustment when ADJUST READY is displayed, press the [EXT] key. You return to the screen displaying the zero point by simulation input.

9.2.2 50 % Flow Rate Calibration

Using the converter's internal calibration circuit, **50% flow rate calibration** can be performed. For the calibration procedure, refer to the calibration procedure for 0% flow rate calibration (Or select the "FLOW CAL 50" from the menu).

9.2.3 100 % Flow Rate (Span) Calibration

Using the converter's internal calibration circuit, 100% flow rate calibration can be performed. For the calibration procedure, refer to the calibration procedure for 0% (Or select the "FLOW CAL100" from the menu.).

9.2.4 Checking the Excitation Current Value

You can monitor the exciting current value.

■ To check the exciting current value:

Key operation	Display example	Description
	O: MEAS MODE FLOW CAL 0 FLOW CAL 50 FLOW CAL100 →EX CURR DSP ISEL] IENT]	Select "EX CURR DSP" in the configuration item selection screen.
[ENT]	O4: EX CURR DSP 0.2000 A [EXT]	The excitation current value is displayed. Pressing the [EXT] key returns you to the menu screen.

* The excitation current value is factory adjusted when shipped. Contact you're nearest Toshiba representative if any change is necessary.

10. Digital I/O Functions

The LF60*F series electromagnetic flowmeter is equipped with two-contact-point terminals (digital output terminals: one of them is optional), enabling you to use various functions including pulse output and alarm output.

Digital I/O functions are described below.

Functions	Necessary DO/DI	Description
Totalization		■ The converter totalizes volumetric flow rate.
	DO: 1 point	■ The totalized volumetric flow can be output (pulse output)
	DI: None to	for each unit flow.
	l point	The totalizer and pulse signal (DO1 only) can be controlled (starts, stops and resets) with an external signal (DI).
Multiple Ranges	DO: 1 to 2 points DI: None to 1 point	Multiple measuring ranges can be switched according to the process flow rates either automatically or by an external signal (DI).
Forward and Reverse flow measurements	DO: 1 point	Forward and reverse flows can be measured. The forward and reverse flow measurements can be used together with multiple range switching function.
High and Low Limit Alarms	DO: 1 to 2 points	Outputs an alarm signal (DO1 or DO2) when the process signal exceeds or stays below the limit values.
Totalizer Preset Point	DO: 1 point	When the totalized flow exceeds its preset count value, the converter outputs a contact output signal (DO1 or DO2).
Remote Zero Adjustment	DI: 1 point	Zero adjustment (on-stream at zero flow rate) can be started by an external signal (DI).
Fixed-value		Fixed current output and fixed pulse output can be used to
Output	DI: 1 point	check a process loop circuit. An external signal (DI) can also be used to control this fixed-value output.
Converter Failure Alarm	DO: 1 point	The converter outputs an alarm signal (DO1 or DO2) if an error such as memory error or excitation circuit error occurs.
Multiple range High/Low alarm (option)	DO: 2 points DI: 1 point	Flow rate high/low alarm and high-high/low-low alarm are switched interlocking with the switching of high/low range by external input signal, and output HH/LL alarm.

10.1 Digital I/O Specifications

The specifications of the digital I/O terminals for the converter for electromagnetic flowmeter: LF600F are as follows:

Digital Output 1(DO)	Digital Output 1(DO1) (standard)		
Output type:	Transistor open collector		
Number of outputs:	1		
Capacity:	30 V dc, 200 mA maximum		
Digital Output 2(D)	02)		
Output type:	Solidstate relay (non polarity)		
Number of outputs:	1		
Capacity:	150 V dc, 150 mA maximum		
	150 V ac(peal-to-peak), 100 mA maximum		
Digital Input (DI)			
Input signal:	20 to 30 V dc voltage signal		
	 High input level—20 to 30 V dc 		
	 Low input level—2 V dc maximum 		
Input resistance:	Approximately 2.7 k Ω		
Number of inputs:	One point		

- Each I/O terminal can be used as a specified function terminal when selected.
- Terminal COM is the signal COMMON for the other three terminals (DO1, DO2 and DI).
- Each terminal is **isolated from the internal circuits**. (The output terminals are not isolated from each other.)
- In standard specification (without digital I/O), semiconductor contact, photo coupler, and resistor are not built in. Left DO2 and DI unconnected.



10.2 Totalizer and Pulse Output

To use the totalizer and pulse output for external use, proceed as follows.

Counting Rate and Pulse Width Settings

Set the counting rate (flow volume per count) and the pulse width. Refer to 0, "Counting Rate".

* The counting rate should be set so that its rate for 100% flow rate output is within the range from 3.6 to 3600000 pulses/h (1/1000 to 1000 pulses/s) (Note 2)

* The pulse width can be set from 0.3ms to 500ms. The pulse width should be set to less than half of the pulse rate for 100% flow rate output. (Note 3)
If the pulse width setting mode is AUTO, the pulse width is automatically set. If the pulse width setting mode is MANUAL, set it after checking the receivable signal width of the receiving measuring meter.

If the pulse output is not used, pulse width setting is not needed.

DO function setting

- According to Section 8.2.20 "Digital I/O", set the digital output 1 (DO1) to pulse output (PULSE OUT).
- If the digital output function has been disabled at count rate setting (no use), it is automatically set to pulse output.
- This is not needed if the pulse output is not used.

Measurement Mode

Set the operation mode of the system to the measurement mode. Refer to 7.3.1, "Mode Change."

Continued to next page

Continued from previous page

Clear (reset) the totalizer. (note1)

- Clear the count value by the [CLR] key on the totalization control screen.
- If you have changed the counting rate, clear (reset) the totalizer before you start the totalizer.

Start the totalizer. (note1)

- Start counting by the [STA] key on the totalization control screen and make sure "CNT" is shown on the display.
- Notes 1. The LF600F converter has a function to stat/stop the counter operation or clear the internal counter. For details of the operation method, see "Totalizer Operation."
 - 2. Example for counting rate:
 - The counting rate should be set so that its rate for 100% flow rate output is within the range from the minimum value (36000000 pulses/h) to the maximum value (3.6 pulses/h).
 - Example

In the case of range $3600 \text{m}^3/\text{h} (1 \text{m}^3/\text{s})$,

Minimum value: Since the counting rate is 36000000 pulses/h, $3600 (m3/h) / 36000000 (pulses/h) = 0.001m^3 = 0.1 L$

Maximum value: Since the counting rate is 3.6 pulses/h, $3600 \text{ (m}^3\text{/h)} / 3.6 \text{ (pulses/h)} = 1000\text{m}^3$

116 —

3.

Example for pulse width: The pulse width can be set from 0.3ms to 500ms in increments of 1ms. However, the pulse width should be set to less than 40% of the pulse rate due to the setting range and counting rate. If "0" is set, the pulse width automatically will be set to 40% of the pulse rate (100ms max.) Example1 $:3600 \text{m}^3/\text{h}$ (1m³/s) Case Range Counting rate(pulse rate) :0.001m³ the pulse rate $: 3600(m^{3}/h) / 0.001(m^{3}) = 36000000 \text{ pulses/h}$ =1000pulses/p the pulse rate for full scale = 1 ms *the pulse width = $1 \text{ms} \times 40\% = 0.4 \text{ms}$ Example2 $:3600 \text{m}^3/\text{h}$ (1m³/s) Case Range :1000m³ Counting rate (pulse rate) the pulse rate $: 3600(m^{3}/h) / 1000(m^{3}) = 3.6 \text{ pulses/h} = 0.001 \text{ pulses/p}$ the pulse rate for full scale = 1000000ms the pulse width(Max.) = 1000000ms x 40% = 400000ms but, the pulse width is 500ms Max. * the pulse width(Max.) = 500ms Example3 $:3600 \text{m}^3/\text{h}$ (1m³/s) Case Range Counting rate (pulse rate) $:1m^3$ Setting pulse width :0ms (automatically set) the pulse rate $: 3600(m^{3}/h) / 1(m^{3}) = 3600 \text{ pulses/h} = 1 \text{ pulses/p}$ the pulse rate for full scale = 1000ms the pulse width(Max.) = 1000ms x 40% = 400ms but, the pulse width that automatically set is 100ms Max.

* the pulse width (Max.) = 100ms

Totalizer Operation

• Using control keys on the panel (option)

To start, stop or clear (reset) the totalizer, follow the procedure described below:

Key operation	Display example	Description
	FLOW 2.000 m/s RANGE1 5.000 m/s [CNT] [SET]	The measured value is displayed (measurement mode).
[CNT]	COUNT CTRL TOTAL CNT 100 FOR [STA] [CLR] [EXT]	Pressing the [CNT] key when you are in the measurement mode causes the screen to switch to the total counter operation screen. In the sub display area of this screen, the total counter value (both sides) is automatically displayed. In addition, the [STA], [CLR] and [EXT] keys are displayed.
displayed. While t t If you enter a wron	unter is operating, [STP] is he total counter is stopped ng password at password key is not displayed.	
[STA]	COUNT CTRL TOTAL CNT 100 FOR CNT [STP] [CLR] [EXT]	Pressing the [STA] key causes the total counting to start and "CNT" to be displayed on the screen. In addition, the [STA] key changes to the [STP] key.
[CLR]	COUNT CTRL TOTAL CNT FOR CNT [STP] [CLR] [EXT]	Pressing the [CLR] key causes the total counter value to be cleared.
[EXT]	FLOW 2.000 m/s RANGE1 5.000 m/s	Pressing the [EXT] key causes you to return to the measurement mode.

- Notes: 1. Since the flow direction code is B (bidirectional flow (Forward/Reverse directions) automatic switching),
 - When you select forward/reverse multi-range, the forward direction totalized value (count value) is displayed for operation in the forward direction range. the reverse direction totalized value (count value) is displayed for operation in reverse direction range.
 - 2. When you reset the counter, the flow counts for both directions will be cleared to zero.
 - 3. Non-volatile memory is used to store the totalizer counter value. Therefore, the value will be retained in the memory even if the power is cut off.

■ Using the digital input signal

Remote operations for the totalizer and pulse output can be conducted using the digital input signal. The following functions in the table can be performed. See 0 "Digital I/O" to select these functions.

Operation with the digital input signal (Initial setting: H level in control level)

Digital input (DI) Functions	DI voltage level	Totalizer and pulse output
Totalizer	L level	Stops the totalizer and the pulse output.
Start/Stop	H level	Start the totalizer and the pulse output.
Totalizer	H level	Stops and clears (resets) the totalizer.
Reset/Start	L level	Start the totalizer and the pulse output.

You can reverse the digital input detective level. For detail, see 8.2.12 "Digital Input Detective Level."

- * Select H level (1:H LEVEL) :
- * Select L level (0:L LEVEL) :

The operation with the digital input signal is same as the standard converter shown in the above table.

The operation with the digital input signal is same as the standard converter shown in the below table.

Operation with the digital input signal (Control signal level: L level in control level)

Digital input (DI) Functions	DI voltage level	Totalizer and pulse output
Totalizer	L level	Start the totalizer and the pulse output.
Start/Stop	H level	Stops the totalizer and the pulse output.
Totalizer	H level	Start the totalizer and the pulse output.
Reset/Start	L level	Stops and clears (resets) the totalizer.

10.3 Multi-range Functions

Multi-range functions can be set under the configuration item "RANGE TYPE." Four types of multi-range configurations are available as shown below:

- (1) Automatic selection of unidirectional flow multi-range
- (2) Automatic selection of bidirectional flows multi-range
- (3) Remote selection of unidirectional flow multi-range with an external signal
- (4) Remote selection of bidirectional flows multi-range with an external signal

Proceed as follows to use the multi-range functions.

Range setting

- Set as follows referring to 0, "Span (Range),"
 - 1. Select "RANGE TYPE."
 - 2. Set the span for ranges 1 to 4.
 - 3. Set the hysteretic value.

DO/DI function setting

.

- Set DO1 and/or DO2 to use them as range outputs. Refer to 0, "Digital I/O"
- To use multi-range selected with a remote signal, set the switch to multi-range selected by external signal in DI.

Output performance of multi-range functions



(1) Automatic selection of unidirectional flow multi-range with an internal signal

• Current output when fluid flows in the reverse direction is the value set for the output low limit (any one of 2.4/3.2/4.0mA).



(2) Automatic selection of bidirectional flows multi-range with an internal signal



(3) Remote selection of unidirectional flows multi-range with an external signal

• Current output when fluid flows in reverse direction is the output low limit setting (any one of 2.4 / 3.2 / 4.0mA).

Reverse direction

Range output

No.2

0 Forward

From reverse range to forward range

ON

Flow rate

OFF



(4) Remote selection of bidirectional flows multi-range with an external signal

Range output

No.2

Reverse

From forward range to reverse range

ON

0

Forward

OFF

Flow rate

10.4 High/Low, High-high or Low-low Limit Alarm

To use the flow rate high, low, high-high or low-low limit alarm, follow the procedure below.

High and Low limit value setting

Set the high and/or low limit alarm enable/disable status to ON and set the limit value for high and/or low alarm. See 0, "Flow Rate High, Low, High-High and Low-Low limit Alarm Setting."
 To disable the high or low limit alarm, set its enable/disable status to OFF.

High-high or low-low limit alarm value setting

Set the high-high and/or low-low limit alarm enable/disable status to ON and set the limit value for high and/or low alarm. See 0, "Flow Rate High, Low, High-High and Low-Low limit Alarm Setting."
To disable the high on low limit alarm set its another disable status to OFF.

To disable the high or low limit alarm, set its enable/disable status to OFF.

DO function setting

According to 0 "Digital I/O", set the digital output 1 and 2 functions (DO1, D02) to high limit alarm output/low limit output alarm or high-high limit alarm output/ low-low limit alarm output and select the active status for alarm output, Normal Open or Normal Close. High and Low Limit Alarm Output Performance (Same as for High High/Low Low limit Alarm Output)



• Multi-range performance

In an example shown below, a low limit alarm is set for the Range 2 and a high limit alarm is set for the Range 1.



* When an alarm output condition occurs, Digital output 1 and 2 change to the output status set for an alarm output condition. Alarm output contact is open while the converter is powered off.

10.5 Preset Count Output

Using this preset count output function, the converter can output a contact signal when the totalized flow reaches its preset value (preset count value). Proceed as follows to use this function.



Preset count output performance

(1) The following is an example for totalizer flow counts output in which the totalizer is reset with an external signal (when preset output status level hold mode is set (contact ON)).



Input/Output signal time chart

- * When the Reset/Start signal is in H level (DI counter control signal level: H), the totalizer is reset to zero and stops counting. When the Reset/Start signal goes to L level, the totalizer starts counting. The preset point output goes ON when the totalizer counts reaches the preset point, and the output goes OFF when the totalizer is reset to zero.
- (2) The following is an example for totalizer flow counts output in which the totalizer is reset with an external signal (when one-shot pulse output mode is set).



Input/Output signal time chart

* When the Reset/Start signal is in L level (DI counter control signal level: L), the totalizer is reset to zero and stops counting. When the Reset/Start signal goes to H level, the totalizer starts counting.

The preset point output goes ON when the totalizer counts reaches the preset point. The output goes OFF when the totalizer is reset to zero or when it takes the time set pulse width from the output goes ON.

(3) The following is an example for one-shot pulse output.



Input/Output signal time chart

* Preset output goes ON when the count value exceeds the preset value of 100 and the preset output goes OFF when its width reaches the set pulse width.

When the preset value exceeds 100, the preset value is changed to 200 (adding the preset count of 100 to the current preset value of 100).

Then, the preset output goes ON when the count value exceeds the preset value of 200, and the preset output goes OFF when its width reaches the set pulse width.

When the preset value exceeds 200, the preset value is changed to 300 (adding the preset count of 100 to the current preset value of 200).

Note: When the one-shot pulse output function is selected, if its pulse width is large compared with the update period of the preset value. The output stays ON. To make sure to output as one-shot pulse, set the preset value reach interval to be 2 signals or more of the pulse width setting value.

Preset Pulse Width	The Interval of that Totalizer reaches the Preset Point	Example) Count rate:0.01 I Flow verosity:10 I/s Totalizer count up rate:1ms/COUNT
50ms	More than 100ms	Preset Count: more than 100
500ms	More than 1000ms	Preset Count: more than 1000

10.6 Remote Zero Adjustment

On-stream zero adjustment in a zero flow rate condition can be started with an external signal.

To do this, set DI as a zero adjustment start signal. See 8.2.20, "Digital I/O"



* The start signal must be set to H level first, then it must go to L level after the passage of more than 10 seconds but not more than 20 seconds, as shown above. If the signal does not go to L level within this specified period, it will be ignored.

10.7 Remote Selection of Fixed Value Output

A user-specified 4-20 mA output and pulse output can be selected with a DI signal.

Proceed as follows to use this function:

Fixed-value setting Set the fixed-value for current output and for pulse output. See 0, "Fixed-Value Output." Set the fixed-value output enable/disable status to "OFF." If the pulse output is not used, fixed-value setting for pulse output is not needed. DI function setting

• Set DI to use as a fixed-value output control signal. See 0, "Digital I/O."

Control signal input conditions:

Control signal input level	4 –20 mA and pulse output
Llevel	Outputs the measured value.
H level	Outputs the fixed-value.

10.8 Converter Failure Alarm

When one or more of the following converter errors occur in a self-diagnostics sequence, an alarm signal can be output. See Chapter 12, "Self-Diagnostics and Warning Functions" for details of each alarm status.

■ Self-diagnostics errors

						nosi) dis			,				Error contents
*		R	0	M		E	R	R	0	R		*	ROM error
*		R	A	M		E	R	R	0	R		*	RAM error
	Ρ	A	R	A	M	Ε	T	Ε	R				System parameter error
					F	A		L	U	R	E		
	Ε	χ		C	U	R	R	Ε	N	T			Excitation circuit open or disconnection
								0	Ρ	E	N		
	Ε	χ		C	U	R	R	Ε	N	T			Excitation current error, excitation circuit fault
							Ε	R	R	0	R		
		A	D	C		Ε	R	R	0	R			ADC error
													ADC elloi
	1	N	۷	A	L	I	D						Invalid totalizer counts
							T	0	Т	A	L		

* Error message is displayed in measurement sub screen.

If you want to use a converter error alarm output, set digital output 1 or 2 (DO1 or DO2) to the error alarm output of the converter following 0, "Digital Input/Output."

In addition, set the alarm output condition to normally open (NORMAL OPEN) or normally close (NORMAL CLOSE) status.

Output conditions

- Normal Open; transistor / relay contact is closed when an error occurs.
- Normal Close; transistor/relay contact is open when an error occurs.

Note: Alarm output contacts are open while the converter is powered off.

10.9 Multiple range high/low limit alarm function (option)

The procedure to use multiple range high/low limit alarm is shown below.

Range setting	
• Set the rar	ge in accordance with 8.2.13 Span (range) in the following order.
1. Set th by ex	the range type to "uunidirectional flow, multiple ranges selected aternal signal". Ange 1 and Range 2 respectively.
DO setting (Note 1)	
alarm ou accordanc	output 1 and 2 (DO1, DO2) function to multiple range high limit tput and multiple range low limit alarm output respectively in e with 8.2.20 Digital I/O. the alarm output state to either of normally open or normally close.
DI setting	
• Set digita Digital I/0	input (DI) function to RANGE SW in accordance with 8.2.20 D .
High/Low limit	
and low a High-Hig	j imit alarm and low limit alarm to ON and set alarm value to high larms respectively in accordancewith 8.2.24 Flow Rate High, Low, h and Low-Low limit Alarm Setting. arm not to use to OFF.
High High/Low Low limit alarm value setting	
respective	igh alarm and low-low alarm to ON and set alarm value to them ely in accordance with 8.2.24 Flow Rate High, Low, High-High -Low limit Alarm Setting.
Set the a	arm not to use to OFF.
as below: Mu	ing DO using HHT AF900 (Ver2.40 or older), set alarm outputs Itiple range high limit alarm output SPECIAL-B, Itiple range low limit alarm output SPECIAL-A

Multiple range high/low limit alarm output



- Note 1: Range changes to Small range when range select signal is H level, and to Large range in L level.
- Note 2: High-high/low-low limit alarm is activated when Small range is selected. High/low limit alarm is not output to display.

High/low limit alarm is activated when Large range is selected. High-high/low-low limit alarm is not output to display.

- Note 3: Alarm output state is the same state to which digital output 1 or 2 is set. When converter power is OFF, contact output is OPEN.
- Note 4: Each alarm set value % is the percent set to the first range.
- Note 5: Hysteresis of each alarm is 2.5 % for the first range.

Example

mμ	ie is a second sec		
•	When Large range and Small range	e are set as below:	
	Large range (Range 1):	$1000 \text{ m}^{3}/\text{h}$	
	Small range (Range 2):	500 m ³ /h	
	And you want to set alarm values a	s below:	
	Large range alarm set value		
	High limit value:	800 m ³ /h	
	Low limit value:	600 m ³ /h	
	Small range alarm set values		
	High-high limit value:	400 m ³ /h	
	Low-low limit value:	300 m ³ /h	
	Set the alarm set values as below:		
	High limit value:	80 % (800 m ³ /h \div 1000 m ³ /h=0.8)	
	Low limit value:	$60 \% (600 \text{ m}^3/\text{h} \div 1000 \text{ m}^3/\text{h} = 0.6)$	
	High-high limit value:	$40 \% (400 \text{ m}^3/\text{h} \div 1000 \text{ m}^3/\text{h} = 0.4)$	See Note4.
	Low-low limit value:	$30 \% (300 \text{ m}^3/\text{h} \div 1000 \text{ m}^3/\text{h}=0.3)$	See Note4

11. Communications Function

The LF60*F series electromagnetic flowmeter uses the **HART**^{*1} protocol to transmit digital signals over the 4-20mA output line. The AF900 hand-held terminal is used to communicate with the LF60*F using the HART protocol. You can check or change configuration parameters, calibrate the flowmeter or monitor the flowmeter measuring value from a remote place.

For the detailed operation and specification of HHT, refer to the "Hand-held Terminal for Sensor with Communication Function AF900 Instruction Manual" (6F8A2195).

*1 HART protocol:

The "HART protocol", which stands for Highway Addressable Remote Transducer, is the name of the communication protocol for industry sensors that is recommended by HCF (HART Communication Foundation).

By adding an optional PROFIBUS communication board to the converter for electromagnetic flowmeter converter: LF60*F, the converter can be used as the PROFIBUS-PA slave device for digital data communication with the PROFIBUS master device.

For details of PROFIBUS communication, refer to the "PROFIBUS Communication Instruction Manual".

To perform HART communication by connecting the converter for electromagnetic flowmeter: LF60*F and Emerson HHT MODEL273/375, the following device descriptor is required. If the MODEL273/375 you use does not support the device descriptor, update the internal software of MODEL273/375. For details, refer to the MODEL275/375 instruction manual.

ltem	Contents
MODEL	LF R71
Manufacturer Code	2C (TOSHIBA)
Device Revision	7
DD Revision	1~

11.1 Connections with the HHT Terminal

Connect the probe cable of the HHT terminal in parallel with the load resistance which is wired from the current output terminals (+ and -). Use points such as pins of terminal board or junction terminal to connect with the clip of the probe. To connect the HHT directly to the flowmeter, use the terminals + and -. The HHT connection cable has no polarity.

See Figure 11.2 and 11.2.



Figure 11.1 Connections to the current output line



Figure 11.2 Connections to the terminal block

11.2 Procedures for Communication with HHT

This section describes the HHT basic operation procedures for communication between the electromagnetic flowmeter and HHT. For details, refer to the HHT instruction manual.

* Applying the following preparatory operations to a commercially available PDA (OS: WindowsCE) makes the PDA serve as a HHT.

Procedure	Operation
①Prepare a hand-held terminal (1)	Install the AF900 application software to a commercially available PDA (OS: WindowsCE) main unit. Then insert the serial interface card supplied with AF900 to the card slot of the PDA.
②Prepare a hand-held terminal (2)	Connect the HART interface cable and serial interface card supplied with AF900 to each other.
③Connect	Connect the alligator clip at the head of the HART interface cable to the current output line of the converter via a load resistor.
④Start	Turn on the power supply of the PDA to start the AF900 application software.
5Preliminary communication	Execute [sensor communication]. The model of the connected sensor product is automatically identified and the converter menu screen appears.
6 Check/change data	Press the relevant parameter button and check/change data.
6 Exit the communication	When all operations are complete, press the [Exist Application] in the top screen to turn off the power supply of the PDA.

11.3 Cautionary Notes on Communications

Observe the following notes and limitations when you use the communications function.

Current output load	
Load resistance:	240 to 750 Ω (including communications line resistance)
Load capacitance:	0.25 μF maximum (including communications line capacitance)
Load inductance:	4mH maximum (including communications line inductance)
Cable length:	2 km maximum (approximate value when 1.25 mm ² shielded
	cable is used under standard operating conditions.)

Wiring cable

Use a shielded cable (CVV-S, etc) for wiring.

Interference on 4-20mA current signal

To communicate with the flowmeter, a digital signal (amplitude 0.4 to 0.8 V in the case of 500Ω load resistance) with a frequency of 1.2 to 2.2 kHz is superimposed on the 4-20mA current signal. If a high-response receiving instrument is connected to the current output line, the superimposed communications signal may interfere with the instrument. To prevent this interference, put a low-pass filter with a time constant of about 100 ms into the input circuit of the receiving instrument.



Figure 11.3 Filter connection example

12. Self-Diagnostics and Alarms

12.1 Self-diagnostics

The converter for electromagnetic flowmeter: LF60*F has a self-diagnostics function to detect such problems as setting error, I/O error or converter hardware failure and shows the resulting error or alarm messages on the LCD sub display or on the Hand held terminal (HHT) hand-held terminal through the HART protocol communications. The error or alarm messages and their corrective actions are described below.

Setting error

If you try to set the value or measuring unit **out of the range specified** for each item, one of the following error messages appears.

					LCE) dis	play						Description	Corrective action
*	H		G	H		0	۷	Ε	R			*	Setting value exceeds the	
*							S	Ρ	Ε	C		*	allowable high limit.	
*	L	0	W		0	۷	E	R				*	Setting value goes below the	
*							S	Ρ	Ε	C	•	*	allowable low limit.	Try to set the value — within the specified
*	Н		G	Н		0	۷	E	R			*	Counting rate exceeds the	range.
*				C	N	T		R	A	Т	Ε	*	allowable high limit.	
*	L	0	W		0	۷	E	R				*	Counting rate goes below the	
*				C	N	T		R	A	T	E	*	allowable low limit.	
*	M	U	L	Т			R	A	N	G	E	*	Span is not appropriate for	Try to set the span as
*		.					Ė	R	R	0	R	*	multi-range configuration.	specified.



High and low limit alarms, high-high and low-low limit alarms, empty alarm

One of the following messages appears if the flow rate reading goes out of the set range or an empty alarm is generated.

If the high or low limit alarm enable/disable status is set to OFF, its alarm function (high or low) is disabled. See **0**, "Check/Change of Parameters."

					LC) dis	play					Description	Corrective action
	H	1	G	Н		A	L	A	R	M		If high limit alarm is set, the flow rate reading exceeds the setting value.	Adjust so that the reading stays below the high limit.
	L	0	W		A	L	A	R	M			If low limit alarm is set, the flow rate reading is below the setting value.	stays above the low limit.
	Н	ł	G	H		H		G	Н			If high-high limit alarm is set, the flow rate reading exceeds	Adjust so that the reading stays below the setting
							A	L	A	R	M	the setting value.	value.
	L	0	W		L	0	W					If low-low limit alarm is set, the flow rate reading is below the	Adjust so that the reading stays above the setting
							A	L	A	R	M	setting value.	value.
	E	M	Ρ	T	Y		A	L	A	R	M	Indicates that the detector pipe is empty.	Fill the pipe with fluid.
			l	L	L	<u> </u>	<u> </u>			<u> </u>	<u> </u>	The measured value is over 125%.	The measurement value setting range is too narrow
	0	۷	E	R			1	2	5	%			or a larger volume of fluid is flowing. Check whether
													the setting is correct or if
												*	there is any problem in processing.
												The measure value is below -125%.	The measurement value setting range is too narrow
[U	N	D	Ε	R		_	1	2	5	%		or a larger volume of fluid is flowing. Check whether
													the setting is correct or if there is any problem in
													processing.

Converter hardware failure

The system checks the internal circuitry at the time of power-up for all error items and checks continuously for the specified items as described below. If an error is detected, one of the messages shown in the table below will be displayed.

If multiple errors occur, their messages will be displayed cyclically. The diagnostics items concerning the excitation cable and excitation circuit are detected using the ADC circuit.

Thus, if the ADC fails (No.6), No. 4 (excitation cable) and No. 5 (excitation circuit) errors cannot be detected correctly. Further, this entire checking system is based on the CPU in the flowmeter. Therefore, if the CPU fails, no accurate diagnostics or error message display can be obtained.

NO.						LCD	dis	olay						Description	Corrective action
1	*		R	0	M		Ε	R	R	0	R		*	ROM error	Internal components or printed-circuit board must be repaired or replaced.
2	*		R	A	M		E	R	R	0	R		*	RAM error	Contact you're nearest Toshiba representative.
3		Р	A	R	A	M	E	T	Ε	R				System parameter error	
						F	A	I	L	U	R	E			
4		E	χ		C	U	R	R	Ε	N	T			Excitation cables are not connected.	Connect the excitation cables correctly.
									0	Ρ	E	N			cubics conteerly.
5		E	Х		C	U	R	R	E	N	Т			An error occurred in the excitation circuit.	Internal components or printed-circuit board must
5								E	R	R	0	R			be repaired or replaced.
6			A	D	C		Ε	R	R	0	R			ADC error	Contact you're nearest Toshiba representative.
															rosmba representative:
			N	۷	A	L	I	D						Totalizer data was destroyed due to	The error message disappears if you press
7								T	0	T	A	L	L	external noise.	the reset key.
										_				(No message appears if totalization is not used.)	

Notes

- 1. Errors No. 1 to No. 3 can be detected **only at the time of power-on**. The flowmeter does not start measurement if any one of these errors is detected. If these errors occur after power-on, the flowmeter cannot detect these errors, and thus may indicate and output incorrect data.
- 2. Errors No. 4 to No. 6 may not be detected even if the errors result in incorrect flowmeter accuracy, because of characteristic differences in components used to detect these errors.
- 3. **CPU error cannot be detected**. If the CPU stops, the watchdog timer resets the internal circuits and the flowmeter starts again from the initial power-on condition. Depending on CPU condition, the flowmeter **may not indicate and output correct data**.

12.2 Output Status for Errors and Alarms

The flowmeter data display, current and pulse outputs will become as follows if an error or alarm occurs.

Error or alarm message	Data display	Current output (4–20mA)	Totalizer and pulse output	Remarks
ROM ERROR (Note 1)		(Note 3)	Stopped	After power-up, no measurement starts.
RAM ERROR		(Note 3)	Stopped	
PARAMETER FAIL (Note 2)	Zero	(Note 3)	Stopped	
EX. CURR OPEN	Zero	(Note 3)	Stopped	Zero adjustment (on-stream at zero flow rate) cannot be conducted.
EX. CURR ERROR	Zero	(Note 3)	Stopped	Zero adjustment (on-stream at zero flow rate) cannot be conducted.
ADC. ERROR	Zero	(Note 3)	Stopped	Zero adjustment (on-stream at zero flow rate) cannot be conducted.
INVALID TOTAL	Measured data	Measured data	Measured data	The error message disappears if you clear (reset) the totalizer.
HIGH ALARM	Measured data	Measured data	Measured data	
LOW ALARM	Measured data	Measured data	Measured data	
HIGH HIGH ALARM	Measured data	Measured data	Measured data	
LOW LOW ALARM	Measured data	Measured data	Measured data	

Notes

- 1. The display and output may not be as indicated depending on the nature of the ROM error.
- 2. If a parameter failure relating to current output occurs, the current output may not become exactly the setting value of the current output when an alarm occurs.
- 3. The current output set value used in case an alarm occurs will be output. For setting method, see 0, "Current Output Setting Used When an Alarm Occurs."

13. Maintenance and Troubleshooting



	conduct wiring work ower is applied.	Do not touch the LF600F main bo when high temperature fluid is be measured.								
DON'T	Wiring while power is applied can cause electric shock.		The fluid raises the main body temperature and can cause burns.							
13.1 Maintenance

Calibration

The converter for electromagnetic flowmeter: LF60*F has a built-in reference signal generation circuit that generates dummy flow rate signals. This reference signal can be used to check the zero and span of the converter for the purpose of instrumentation maintenance or periodical inspection. See Chapter 9, "Calibration."

Fuse

The fuse can be taken out by unscrewing the cap of the fuse holder. Check that the fuse is not damaged. The fuse has to be replaced periodically. The recommended replacement period is 3 years.

Type of fuse used: Rating:	Glass tube fuse ①0.8A(T)/250V ②2A/150V	l piece for 100 to 240 Vac or 110Vdc power supply for 24Vdc power supply
Dimensions: Melting time characteristic:	Diameter 5mm × 2	20 mm

Note: Use a fuse that complies with the Electrical Appliance and Material Safety Law.

■ Check/Replacement of the display unit

When characters displayed on the LCD display become thin or blots come out, please adjust the setting of LCD's display density. If the display is still not improved, the display unit comes to **the end of its life. Please replace the display unit with a new one.** In order to use the display unit stably for a long time, it is preferable to replace it early. For inspection and replacement, **please contact you're nearest Toshiba representative.**

Power supply unit (also used for excitation board)

Electronic components deteriorate faster when the ambient temperature is high. The life of the power supply unit in the converter is 9 to 10 years if the ambient temperature is 40°C, and 5 to 6 years if it is 50° C. To extend the life of the flowmeter, we recommend you replace the power supply unit early.

Contact you're nearest Toshiba representative for a flowmeter inspection or unit replacement.

Product disposal

The main body or parts of the converter for electromagnetic flowmeter I: LF60*F must be disposed of, according to the rules and regulations of your local government.

Especially if you dispose of electrolytic capacitors to replace parts, have it done by an agency which is licensed to handle industry waste materials.

Operative life

The operative life of this flowmeter is 10 years from the date of shipment.

The life of the flowmeter differs depending on the environmental conditions and the way it was used. To extend the life of the flowmeter, inspect the flowmeter periodically and clean or replace components if necessary.

- 144 -

13.2 Troubleshooting

If a problem occurs while using the LF60*F, follow the flowcharts described below. You may find a way to solve the problem. The flowcharts are based on three symptoms (1) to (3). If you cannot solve the problem, contact you're nearest Toshiba representative.

13.2.1 Flow rate is not indicated.



13.2.2 Flow rate indication is not correct.



13.2.3 Flow rate indication is not stable.



13.2.4 When switch operation is unable



14. Principle of Operation

The operating principle of the electromagnetic flowmeter is based on Faraday's Law of electromagnetic induction and it is designed to measure the volumetric flow rate of fluid. An insulated pipe of diameter D is placed vertically to the direction of a magnetic field with flux density B (see Figure 14.1). When an electrically conductive fluid flows in the pipe, an electrode voltage E is induced between a pair of electrodes placed at right angles to the direction of magnetic field. The electrode voltage E is directly proportional to the average fluid velocity V.

The following expression is applicable to the voltage.

$$\mathbf{E} = \mathbf{K} \times \mathbf{B} \times \mathbf{D} \times \mathbf{V} [\mathbf{V}] \dots (\mathbf{Eq. 14.1})$$

E = induced electrode voltage [V]

D = meter pipe diameter [m]

V =fluid velocity [m/s]

Volumetric flow rate Q $[m^3/s]$ is:

$$Q = \frac{\pi \times D^2}{4} \times V$$
(Eq. 14.2)

Using the Equation 14.1 and 14.2

$$E = K \times B \times D \times \frac{4}{\pi \times D^2} \times Q$$
$$E = \frac{4 \times K \times B}{\pi \times D} \times Q \dots (Eq. 14.3)$$

Therefore, volumetric flow rate is directly proportional to the induced voltage.



Figure 14.1 Principle of Operation

The LF60*F electromagnetic flowmeter uses the square-wave excitation method, which provides long-term stable operation. With square-wave excitation, the LF60*F offers reliable measurement without being affected by electrostatic or electromagnetic interference, or electrochemical polarization between the electrodes and the fluid to be measured.

15. Specifications

15.1 Specifications

General Specifications

Measuring range: (measuring range by flow rate conversion)

0-0.3m/s to 0-10m/s

(A range of 0-0.1m/s to 0-0.3m/s can be dealt with by an option specified at order time.)

Accuracy:	(Accuracy	when	combined	with	the detector)
-----------	-----------	------	----------	------	---------------

Flow rate to the	Accuracy						
range (%)	0.1 \sim less than 0.3 m/s	0.3 \sim less than 1.0 m/s	1.010 m/s				
$0 \sim 20 \%$			\pm 0.1 % FS				
20 ~100 %			\pm 0.5 % of rate				
$0 \sim 50 \%$	±0.25 % FS	\pm 0.25 % FS					
50 ~100 %	\pm 0.5 % of rate	\pm 0.5 % of rate					

(Note) Accuracy under the basic operation conditions with Toshiba calibration facility)

Conductivity: 5μ S/cm or moreAmbient temperature: -20 to +60°CStorage temperature : -25 to +65°CPower supply: 100 to 240Vac (allowable voltage range: 80 to 250Vac 50/60Hz)
24Vdc
(allowable voltage range: 18 to 36Vdc) or
110Vdc
(allowable voltage range:90 to 130Vdc)Power consumption: 27VA (17W) or less

Input

Input signal: • Flow rate proportional signal from the detector

nal

Digital input function (option): Select either of the following.

- Range switching input: Large/Small range switching of unidirectional double range, forward/reverse direction double range
- Counter control input: Internal totalization counter start/stop/reset control
- Output hold input: The current output and pulse output are kept to their preset values.
- Zero adjustment input: Start still water zero adjustment.

TOSHIBA

	4 to 20mAdc (l	oad resistance 750 Ω or less)
Digital output 1:	Output type:	Transistor open collector
	Capacity:	30Vdc, Max 200mA
	Number of outp	out points: 1
Digital output 2:	(Option)	
	Output type:	Semiconductor contact signal output (no polarity)
	Capacity:	150Vdc, Max. 150mA
	Number of out	150Vac (peak value), Max. 100mA
Digital output functi	Number of outp on: Select one of the	
	talization pulse outp	
10	Pulse rate	Max. 10kHz(10000pps) · · · DO1
	1 4150 1410	Max. 100Hz(100pps) ··· DO2 (option)
	Pulse width	Can be set within a range of 0.3 to 500ms.
		However, must be 1/2 or less of the full-scale cycle.
		If the full scale 1000pps is exceeded,
		automatically set to 40% of the full-scale cycle.
• Mu	ulti-range switching of	
		double range, you need to add digital output optionally.
	gh and low alarm out	
	gh-high and low-low	alarm output
	npty alarm output	
	eset counter output	alarm output
	nverter malfunction	d low limit alarm output (option)
		8-dot LCD (with back light)
Communication sig	Inal	
Method (protocol):	HART or PRO	FIBUS (option)
Load resistance:	240 to 750 Ω (
LUAU IUSISTAIIUU.	0.25μ F or less	(HART)
Load capacity:		
Load capacity:	NEMA 4X)	
Load capacity: Structure: IP67 (NEMA 4X)	
Load capacity: Structure: IP67 (Housing: Alum	inum alloy	
Load capacity: Structure: IP67 (Housing: Alum	inum alloy	g, pearl-gray colored
Load capacity: Structure: IP67 (Housing: Alum Coating: Acryli	inum alloy	g, pearl-gray colored
Load capacity: Structure: IP67 (Housing: Alum Coating: Acryli	inum alloy ic resin-baked coatin	g, pearl-gray colored read

15.2 Model Number Table

Converter Model Number Table

Model number Specification code		Contents	Ъ	12F								
1 2 3 4 5	6	7	8	9	10	11	12	13	14		LF600F	LF602F
L F 6 0										LF600 series electromagnetic flowmeter converter		
02										Usage Combined type Separate type	0	-0
	F									Area of use FM Approval and CSA Certification (Division 2 Hazardous Locations)	0	0
		A B								Shape Round for combined type Square for separate type	0	- 0
			A C E							Installation fitting Not provided Wall-mounting fitting available (Bolts and Nuts material: 304 stainless steel) Pipe-mounting fitting available (Bolts and Nuts material: 304 stainless steel)	0 - -	0000
				1 2						I/O and Communication function Digital output points 1(DO1) Digital output points 2(DO1+DO2)+Digital input point 1(DI)	0	00
				L	1 2					Current output and Communication function Current output + HART communication PROFIBUS communication (Current output is not usable)	00	00
						1 2				Power supply 80 to 250Vac, 50/60Hz 18 to 36Vdc	000	00
						3				90 to 130Vdc	0	0
							E			Language English	0	0
								*	*	No use	-	

 \bigcirc : Selectable -: Unselectable

16. Outline Drawing

16.1 LF600F Type



unit: mm



16.2 LF602F Type



unit: mm



Appendix 1

Factory default standard value table

When parameter value was appointed in order, parameter value may be different from list.

ltem	Default value (SI unit)	Default value (English unit)	Changed value
Exciting current setting	Value(*1)	Value(*1)	
Flow direction setting	NORMAL	NORMAL	
Password	000	000	
Address setting	126	126	
Main display setting	m3/h	gal/min	
Sub display setting	m3	COUNT B	
Custom (coefficient)	0	0	
Custom (unit)	(all blanks)	(all blanks)	
LCD density adjustment	3	3	
Switch position setting	BOTTOM	BOTTOM	
Range type	SINGLE	SINGLE	
Range 1	Value(*1)	Value(*1)	
Range 2 to 4	0.00 m ³ /h	0.00 gal/min	
Range hysteresis	3.0 %	3.0 %	
Damping constant	1.0 s	5.0 s	
Low cut value	1.0 %	1.0 %	
Current output setting upon	4mA	4mA	
alarm occurrence			
Display low cut Yes/No	OFF	OFF	
Output low limit setting	4mA	4mA	
Digital output 1	PULSE OUT	PULSE OUT	
Digital output 2 (*2)	NOUSE	EMPTY	
Digital input 1(*2)	C RES/STA	C RES/STA	
DO1/DO2 alarm output state(*2)	NORMAL OPEN	NORMAL OPEN	
DI control signal level setting(*2)	HLEVEL	H LEVEL	
Count rate	1 m3	Value(*1)	
Pulse width setting mode	AUTO	MANUAL	
Pulse width	100 ms	5 ms	
Preset count value	0000000	0000000	
Preset output setting	HOLD	HOLD	
High limit alarm ON/OFF	OFF	OFF	
High limit value setting	0.0 %	0.0 %	
Low limit alarm ON/OFF	OFF	OFF	
Low limit value setting	0.0 %	0.0 %	
High high limit alarm ON/OFF	OFF	OFF	
High high imit value setting	0.0 %	0.0 %	
Low low limit alarm ON/OFF	OFF	OFF	·
Low low limit value setting	0.0 %	0.0 %	
Fluid empty alarm	NORMAL	NORMAL	

Factory default standard value table (continuance)

ltem	Default value (SI unit)	Default value (English unit)	Changed value
Self-diagnosis Yes/No	ON	ON	
Alarm output preset	WITHOUT EMP	WITHOUT EMP	
Limit rate	0.0 %	0.0 %	
Limit time	0.0 s	0.0 s	
Fixed output	OFF	OFF	
Fixed current	4mA	4mA	
Fixed pulse	0 pps	0 pps	
Manual zero	0.0 %	0.0 %	

*1 : Setting value by meter size please refer to the next list.*2 : Digital output2 and digital input are option.

Setting value in each size

Meter Size	Ex. Freq	Range 1(SI unit)	Range 1 (Eng	glish unit)	Count rate
(mm/inch)	(Hz)	(m³/h)	(m/s)	(gal/min)	(ft/s)	(gal)
15 / 0.5	24	2	3.144	25	29.283	· 1
25 / 1	24	6	3.395	75	31.625	1
32 / 1.25	24	10	3.454	125	32.171	. 1
40 / 1.5	24	15	3.316	175	28.826	1
50 / 2	24	25	3.537	300	31.625	10
80/3	24	60	3.316	650	26.766	10
100 / 4	24	100	3.537	1000	26.354	10
150 / 6	24	200	3.144	2500	29.283	100
200 / 8	24	300	2.653	4500	29.649	100
250 / 10	12	600	3.395	7000	29.517	100
300 / 12	12	900	3.537	10000	28.283	100
350 / 14	12	1200	3.465	12000	25.817	100
400 / 16	12	1600	3.537	16000	26.354	100
450 / 18	12	2000	3.493	20000	26.029	100
500 / 20	6	3000	4.244	25000	26.354	100
600 / 24	6	4000	3.930	40000	29.283	100

TOSHIBA

$_{1}6_{1}F_{1}8_{1}A_{2}0_{1}8_{1}6_{1}9_{1}$

Appendix 2





· 157 —



— 158 —

Appendix 3

Electromagnetic Compatibility and Low Voltage Safety

LF600F and LF602F electromagnetic flowmeter converter has been confirmed to comply with the requirements of the EMC directive 89/336/EEC and the low voltage directive 93/68/EEC.

EMC directive

This device has been tested in a typical configuration in accordance with the following standards in an industrial environment.

 Generic emission standard 	EN50081-2
Conducted RF emissions	EN55011
Radiated RF emissions	EN55011
Generic immunity standard	EN50082-2
Conducted RF immunity	ENV50141
Radiated RF immunity	ENV50140/ENV50204
Electrostatic discharge	EN61000-4-2
Fast transient burst	EN61000-4-4

The above EMC tests have been carried out with the flowmeter installed properly in accordance with this instruction manual. However, there is no guarantee that interference will not occur in a particular installation.

To reduce interference to or from other equipment, please check the following installation points.

- (1) Use shielded cables for all I/O cables. When the flowmeter is the separated type, the signal cable and excitation cable for the connection between the detector and the converter are supplied by Toshiba. To improve immunity, pass each cable through a thick steel conduit tube.
- (2) If this device is installed in an area where RFI exists, deviation of the current output signal may be caused. In this case, ferrite cores will be required on each I/O cable. Please contact Toshiba or the agency if required.
- (3) This device is designed to be used in an industrial environment and may cause reception interference to radio, television or wireless communications. In this case, relocate the receiving antenna.
- (4) The use of a transceiver or wireless equipment near this device may cause interference to the accurate measurement. If deviation of the output signal appears during use of a radio, increase the distance between the converter or the signal cable and the antenna.

Low voltage directive

_	
Low voltage standards	EN61010-1
Environmental conditions:	
Installation category	П
Pollution degree	2
Altitude	Up to 2000 m
Other conditions are	specified in Chapter 15, "Specifications."

٦

Write down the address and phone number of the distributor from which you purchased this product, the product code, SER.NO. and so on.

Distributor Address	
Name	
Phone number () —	
Product code	
SER.NO	

TOSHIBA CORPORATION

FCF50017