

Franklin®
Electronic Publishers

B·O·O·K·M·A·N™
Cartridge

ADVANCED THESAURUS

User's Guide

ATH-2011

License Agreement

READ THIS LICENSE AGREEMENT BEFORE USING ANY BOOKMAN CARTRIDGE.

YOUR USE OF THE BOOKMAN CARTRIDGE DEEMS THAT YOU ACCEPT THE TERMS OF THIS LICENSE. IF YOU DO NOT AGREE WITH THESE TERMS, YOU MAY RETURN THIS PACKAGE WITH PURCHASE RECEIPT TO THE DEALER FROM WHICH YOU PURCHASED THE BOOKMAN CARTRIDGE AND YOUR PURCHASE PRICE WILL BE REFUNDED. BOOKMAN CARTRIDGE means the software product and documentation found in this package and FRANKLIN means Franklin Electronic Publishers, Inc.

LIMITED USE LICENSE

All rights in the BOOKMAN CARTRIDGE remain the property of FRANKLIN. Through your purchase, FRANKLIN grants you a personal and nonexclusive license to use the BOOKMAN CARTRIDGE on a single FRANKLIN BOOKMAN at a time. You may not make any copies of the BOOKMAN CARTRIDGE or of the data stored therein, whether in electronic or print format. Such copying would be in violation of applicable copyright laws. Further, you may not modify, adapt, disassemble, decompile, translate, create derivative works of, or in any way reverse engineer the BOOKMAN CARTRIDGE. You may not export or reexport, directly or indirectly, the BOOKMAN CARTRIDGE without compliance with appropriate governmental regulations. The BOOKMAN CARTRIDGE contains Franklin's confidential and propriety information which you agree to take adequate steps to protect from unauthorized disclosure or use. This license is effective until terminated. This license terminates immediately without notice from FRANKLIN if you fail to comply with any provision of this license.

Contents

With your new Franklin *Advanced Thesaurus* (ATH-2011), you can find a total of more than 500,000 synonyms, antonyms, Classmates™, and Confusables™.

You can also correct misspellings and play three exciting and educational word games at different skill levels. Simply install this cartridge into your BOOKMAN to get started.

Key Guide	3
Installing Cartridges	4
Selecting Books	4
Using the Color Keys	5
Changing Settings	5
Viewing a Demonstration	6
Finding Synonyms	6
Correcting Misspellings	7
Finding Confusables	8
Highlighting Words	8
Sending Words	9
Playing the Games	9
Cartridge Care	11
Resetting BOOKMAN	11
Index	14

Key Guide

Function Keys

- CLEAR** Clears the word you entered.
- MENU** Shows the menu.
- SKILL** (red) Shows the game skill levels.
- CONF** (green) Shows Confusables (words that you may confuse with others).
- GAMES** (yellow) Shows games you can play.
- HINT** (blue) Provides hints during games.
- CARD** Exits the selected book.
- ON/OFF** Turns BOOKMAN on or off.

► Understanding the Color Keys

The color keys (red, green, yellow, and blue) perform the functions listed above only for the book described in this User's Guide.

Other BOOKMAN books have their own color key functions, which are labelled on their keyboards or cartridges. To learn more, see "Using the Color Keys."

Other Keys

- BACK** Erases a letter, shows a previous screen, or unhighlights a word.
- CAP** Shifts keys to type capitals.
- ENTER** Looks up a word, selects a menu item, or highlights a word.
- HELP** Shows a help message.
- ?*** Types a ? to stand for a letter in a word (shifted, types an * to stand for a series of letters).

Direction Keys



Scroll text, or move the cursor or the highlight.



Page down or up.

- SPACE** Types a space, or pages down in thesaurus entries and help.

Star Key Combinations*

-  + **CARD** Sends a word between books.
-  +  Shows the next or previous thesaurus entry.
- or  + 

* Hold  while pressing the other key.

Installing Cartridges

Warning: Never install or remove a BOOKMAN cartridge when your BOOKMAN is on. If you do, information you have entered in the built-in book as well as in the cartridge will be erased.

1. Turn **BOOKMAN** off.
2. Turn **BOOKMAN** over.
3. **Align the tabs of the cartridge with the notches in the slot.**



4. **Press the cartridge down until it snaps into place.**

▶ Removing Cartridges

Warning: When you remove a BOOKMAN cartridge to install another, information that you entered in the removed cartridge is erased.

Selecting Books

Once you have installed a cartridge in your BOOKMAN, you can select which book you want to use.

1. Turn **BOOKMAN** on.
2. Press **CARD**.



These are sample books.

3. Press **↔** or **↔** to **highlight the book you want to use.**



4. Press **ENTER** to select it.


▶ About Screen Illustrations

Some screen illustrations in this User's Guide may differ from what you see on screen. This does not mean that your BOOKMAN is malfunctioning.

Using the Color Keys

The red, green, yellow, and blue keys change functions according to which book you are using.

When you have selected and are using the built-in book, the color keys function as labelled on the keyboard. When you are using a BOOKMAN cartridge, the color keys function as labelled on that cartridge.



Remember, when you have selected and are using a BOOKMAN cartridge, the color keys function as labelled on that cartridge, not as on the keyboard.

Changing Settings

You can adjust the font size and shutoff time of this book. The font size sets how large the letters appear on screen. The shutoff time sets how long your BOOKMAN stays on if you forget to turn it off.

1. Press **CLEAR**.
2. Press **MENU**.
3. Press **↓** to highlight **Set Font** or **Set Shutoff**.



4. Press **ENTER**.
5. Press **↓** to highlight a setting.
To leave the settings as they are, press **BACK**.
6. Press **ENTER** to select it.

► Changing the Contrast

When you're using the ATH-2011, you can change the BOOKMAN's screen contrast by pressing **CLEAR** and then repeatedly pressing **↑** or **↓**.

Viewing a Demonstration

When no book cartridge is installed in your BOOKMAN, a demonstration automatically appears after you select this book. To stop the demo, press **CLEAR**. To disable it, press **MENU** and then select *Disable Demo*. To re-enable it, select *Enable Demo*.

When a book cartridge is installed, select *View Demo* from the menu to view the demo.

► Help is Always at Hand

You can view a help message at virtually any screen by pressing **HELP**. Press \downarrow or ∇ to read it. To exit help, press **BACK**.

To read about what the keys do when you're using this book, press **MENU** and then select *Tutorial*.


► Just Follow the Arrows

The flashing arrows on the right of the screen show which arrow keys you can press to view more text.

Finding Synonyms

To look up synonyms, simply type a word and then press **ENTER**. Try this example.

1. Press **CLEAR**.
2. Type a word (e.g., *happy*).




ENTER your word:
happy

To type capitals, hold **CAP**.

To erase a letter, press **BACK**.

To move the cursor, press \leftarrow or \rightarrow .

3. Press **ENTER** to view its first thesaurus entry.



happy <adjective> in a pleased mood
[synonyms] blithe, cheerful,

4. Press \downarrow or ∇ to read.
5. Hold **☆** and press ∇ repeatedly to view its next entries, if any.



happy <adjective> very happy indeed
[synonyms] blissful,

To view a previous thesaurus entry, hold **☆** and press \triangleleft .

6. Press **CLEAR** when done.

Finding Synonyms

► Understanding Thesaurus Entries

When you see *THES* flash in the upper right of the screen, the entered or highlighted word has a thesaurus entry. Each thesaurus entry begins with the word's part of speech (noun, verb, adjective, etc.) and a brief definition.

Then synonyms, Classmates, and antonyms, if any, are listed. Classmates are words related by subject or class. Special uses, such as slang, Briticisms, and technical words, are noted in brackets.

► Selecting Multiple Forms

When you enter a word that has more than one form, a word list appears. Highlight the form you want and then press **ENTER** to select it.

► Viewing Next Entries

When a word has more than one thesaurus entry, you can view a next entry by scrolling or paging down at the end of an entry.

Correcting Misspellings

Don't worry if you misspell a word. Corrections automatically appear.

1. Press **CLEAR**.
 2. Type a misspelled word (e.g., *ecskwizzit*).
 3. Press **ENTER**.
- 1 ~~ecskwizzit~~
2 *exquisites*
3 *exquisitely*
4. Highlight a correction.
 5. Press **ENTER** to view its thesaurus entry, if any.
 6. Press **CLEAR** when done.

► Finding Spellings and Words

If you're not sure how to spell a word, or want to find a list of similarly spelled words, type a question mark in place of each unknown or variable letter (e.g., *conc??ve*). Then press **ENTER**. You can also type an asterisk in place of a series of letters (e.g., *conc*ve*). To type an asterisk, hold **CAP** and press **?**.

Finding Confusables™

Confusables are words that sound alike or are spelled similarly. When you see *CONF* flash in the upper right of the screen, the entered or highlighted word has Confusables. Try this example.

1. Type *rein*.

2. Press **ENTER**.

Notice that *CONF* flashes.

3. Press **CONF**.

```
rein: harness
rain: precipitation
reign: rule
```

Each Confusable is followed by a word identifying its meaning.

4. Press **ENTER** to start the highlight.

5. Press the arrow keys to highlight a word.

```
rein: harness
rain: precipitation
reign: rule
```

6. Press **ENTER** to view its thesaurus entry.

7. Press **CLEAR** when done.

Highlighting Words

Another way to find synonyms and Confusables is by highlighting words in thesaurus entries. Try this example.

1. Type *demeanor*.

2. Press **ENTER**.

3. Press **ENTER** again.

Notice the highlight. You can turn it off by pressing **BACK**.

4. Press the arrow keys to highlight a word (e.g., *air*).

```
demeanor <noun> the form
in which one appears
[synonyms] air, appearance,
```

5. Press one of these keys:

To View... Press...

its thesaurus entry **ENTER**

confusables, if any **CONF**

6. Press **BACK** to go back to the highlighted word.

7. Press **CLEAR** when done.

Sending Words

You can look up words from this book in certain other BOOKMAN books, and vice versa.

To send or receive a word to or from another book, you must first install a book cartridge in your BOOKMAN, and that cartridge must be able to send or receive words, too. To learn if a cartridge can send or receive words, read its User's Guide.

1. Highlight a word in this book.

To highlight a word in a list, press the arrow keys.

To highlight a word in text, press  and then press the arrow keys.

2. Hold and press .

3. Highlight the other book.

4. Press .

The word that you highlighted appears in the other book.

5. Press to look up the word.

Playing the Games

Picking Levels and Games

You can pick a skill level before you play or during a game. If you pick a level during a game, the new level does not take effect until the next round begins.

- To pick a skill level, first press . Then highlight a level and press  to select it.
- To pick a game, first press . Then highlight a game and press  to start playing.

Playing Hangman

Hangman challenges you to guess a mystery word, indicated by ?'s, before the little man is hanged. Simply type your letter guesses. The number of wrong guesses you can make appears to right of the #'s.

To end a round, press . To view the thesaurus entry of the word, press . Then press  to go back to the game.

Playing Anagrams

Anagrams challenges you to find anagrams of a word. (An anagram is a word formed from all or some of the letters of another word.)

To play, type an anagram and then press **ENTER**. Use the arrows to view anagrams you've already entered.

To end a round and reveal the remaining anagrams, press **?**. After a round, you can press **ENTER** and  to highlight a word. Then press **ENTER** to view its thesaurus entry. Press **BACK** to go back to the game.

NOTE: Each letter can only be used in an anagram as many times as it appears in the selected word. Each anagram must be a specified minimum length, which flashes on the screen before each round. The number of possible anagrams is shown on the right side of the screen.

Playing Word Train™

All aboard! You and the Word Train take turns typing letters to form a word. Whoever types the last letter wins.

Press **?** to end a round and reveal the word. Press **ENTER** to view the thesaurus entry of the word.

► Keeping Score

After each round of Hangman and Word Train, the number of rounds that you have won and lost appears.

► Getting Hints

You can get hints during the games by pressing **HINT**. In Hangman, letters in the mystery word are revealed. In Anagrams, the letters are shuffled. In Word Train, possible next letters are displayed.

NOTE: If you ask for a hint, the game continues but you cannot win the round. To win rounds, you must play without hints.

Cartridge Care

- **Do not touch the metal contacts on the book cartridges.**

Caution: Touching these electrical contacts with statically charged objects, including your fingers, could erase information entered in a cartridge or built-in book.



- **Do not put excessive pressure on the book cartridges.**



- **Do not expose the book cartridges to heat, cold, or liquids.**



Resetting BOOKMAN

If the BOOKMAN keyboard fails to respond, or if its screen performs erratically, first press **CLEAR** and then press **ON/OFF** twice. If nothing happens, follow the steps below.

Warning: Pressing the reset button with more than very light pressure may permanently disable your BOOKMAN. In addition, resetting BOOKMAN erases settings and information entered into its built-in book and in an installed cartridge.

1. Hold **CLEAR** and press **ON/OFF**.
If nothing happens, try Step 2.
2. Use a paper clip to **gently press reset button on BOOKMAN**.

The reset button is recessed in a pin-sized hole on the back of BOOKMAN. Look for it on the battery cover or near the cartridge slot.

► Troubleshooting Tips

- Check that the book cartridge, if any, is installed correctly.
- Check that the cartridge's metal contacts are dirt-and dust-free.

Optional Features



AC adaptor jack: Some BOOKMAN models are equipped with a standard 3.5 mm jack for use with a 9-volt, 200-300 milliamp AC/DC adaptor.



This symbol indicates that the inner core of the plug of an AC adaptor is negative and that the outer part of the plug is positive. If your AC/DC adaptor does not have this symbol, confirm its compatibility at its place of purchase.

Headphone jack: Some BOOKMAN models also have a 3.5 mm stereo headphone jack for use with a standard impedance 8 Ohm headset.

Limited Warranty (U.S. only)

FRANKLIN warrants to you that the BOOKMAN PRODUCT will be free from defects in materials and workmanship for one year from purchase. In the case of such a defect in your BOOKMAN PRODUCT, FRANKLIN will repair or replace it without charge on return, with purchase receipt, to the dealer from which you made your purchase or Franklin Electronic Publishers, Inc., 122 Burrs Road, Mt. Holly, NJ 08060, within one year of purchase. Alternatively, FRANKLIN may, at its option, refund your purchase price.

Data contained in the BOOKMAN PRODUCT may be provided under license to FRANKLIN. FRANKLIN makes no warranty with respect to the accuracy of data in the BOOKMAN PRODUCT. No warranty is made that the BOOKMAN PRODUCT will run uninterrupted or error free. You assume all risk of any damage or loss from your use of the BOOKMAN PRODUCT.

This warranty does not apply if, in the sole discretion of FRANKLIN, the BOOKMAN PRODUCT has been tampered with, damaged by accident, abused, misused, or misapplication, or as a result of service or modification by any party, including any dealer, other than FRANKLIN. This warranty applies only to products manufactured by or for FRANKLIN. Batteries, corrosion, or battery contacts and any damage caused by batteries are not covered by this warranty. NO FRANKLIN DEALER, AGENT, OR EMPLOYEE IS AUTHORIZED TO MAKE ANY ADDITIONAL WARRANTY IN THIS REGARD OR TO MAKE ANY MODIFICATION OR EXTENSION OF THIS EXPRESS WARRANTY. THE FOREGOING WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ALL OTHER EXPRESS OR IMPLIED WARRANTIES, WRITTEN OR ORAL, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. YOUR SOLE AND EXCLUSIVE REMEDY SHALL BE FRANKLIN'S OBLIGATION TO REPLACE OR REFUND AS SET FORTH ABOVE IN THIS WARRANTY. Some States do not allow the exclusion of implied warranties, or limitations on how long a warranty lasts. This warranty gives you specific rights; you may also have additional rights which vary from State to State. This warranty shall not be applicable to the extent that enforcement of any provision may be prohibited by applicable law.

FRANKLIN SHALL IN NO EVENT BE LIABLE TO YOU OR TO ANY OTHER PERSON FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, OR ANY OTHER INDIRECT LOSS OR DAMAGE, ARISING OUT OF YOUR PURCHASE, THE MANUFACTURE OR SALE OF THE BOOKMAN PRODUCT, THIS LICENSE, OR ANY OBLIGATION RESULTING THEREFROM OR THE USE OR PERFORMANCE OF THE BOOKMAN PRODUCT UNDER ANY LEGAL THEORY, WHETHER BREACH OF CONTRACT, TORT, STRICT LIABILITY OR ANY OTHER CAUSE OF ACTION OR PROCEEDING, WHICH DAMAGES SHALL INCLUDE, BUT NOT BE LIMITED TO, LOST PROFITS, DAMAGES TO PROPERTY, OR PERSONAL INJURY (BUT ONLY TO THE EXTENT PERMITTED BY LAW). FRANKLIN'S ENTIRE LIABILITY FOR ANY CLAIM OR LOSS, DAMAGE, OR EXPENSE FROM ANY SUCH CAUSE SHALL IN NO EVENT EXCEED THE PRICE PAID FOR THE BOOKMAN PRODUCT. THIS CLAUSE SHALL SURVIVE FAILURE OF AN EXCLUSIVE REMEDY. This license and warranty is governed by the laws of the United States and the State of New Jersey.

Specifications

Model: ATH-2011

- size: 5.9 x 4.2 x 0.6 cm
- weight: 0.4 oz

© 1987-1995 Franklin Electronic Publisher, Inc., Mount Holly, NJ 08060 USA. Classmates, confusables, and Word Train are trademarks of Franklin. All rights reserved.

BOOKMAN is a trademark of Sherwin M. Borsuk. Used under license.

FCC Notice: Complies with the limits for a Class B computing device pursuant to Subpart B of part 15 of FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

U.S. Patents 4,490,811; 4,830,618; 4,891,775; 5,007,019; 5,113,340; 5,203,705; 5,218,536; 5,249,965; 4,982,181; 5,153,831; 5,229,936; 5,295,070; 5,321,609; 5,333,313; European Patent 0 136 379. Pat. Pend.

ISBN 1-56712-172-1

Your Notes

Index

?* key

- using during games 9
- using to find spellings and words 7

AC adaptor jack 12

Anagrams game 10

Arrows

- keys 6
- on screen 6

Asterisks 7

BOOKMAN

- resetting 11
- specifications 13

Capital letters 6

CARD key 4, 9

Cartridges

- care of 11
- installing 4
- removing 4

Changing

- font size 5
- screen contrast 5
- shutoff time 5

Classmates 7

CLEAR key 5

Color keys

- understanding 3
- using 5

FRB-28010-00
P/N 7201198

CONF key 8

Confusables 8

Cursor, moving 6

Direction keys 3

DN key 3

Erasing typed letters 6

Font size 5

Function keys 3

Games

- hints during 10
- scores after rounds 10
- selecting 9
- skill levels 9

GAMES key 9

Hangman 9

Headphone jack: 12

HELP key 6

Help messages 6

Highlighting words 8

Hints during games 10

Installing cartridges 4

Limited Warranty 12

MENU key 5

Multiple forms 7

Parts of speech 7

Question marks 7

Screen contrast 5

Selecting

- books 4
- games 9

- skill levels 9

Shutoff time 5

SKILL key 9

Special usages 7

Specifications 13

Spellings

- correcting 7
- finding 7

STAR key 6, 9

- combinations 3
- with CARD 9
- with DN 6

Synonyms, finding

- by highlighting words 8
- by typing words 6

Thesaurus entries 6, 7

Typing

- asterisks 7
- capitals 6

Viewing

- confusables 8
- help messages 6
- hints during games 10
- next entries 7
- thesaurus entries 7
- words from other books 9

Word Train™ 10

Printed in U.S.A.
Rev A.