

INSTALLATION MANUAL

COLOR DGPS/PLOTTER/SOUNDER

GP-1850DF

COLOR GPS/PLOTTER/SOUNDER

GP-1850F

Safety Instructions for the Installer	i
Equipment Lists	ii
System Configuration	iv

1. Installation of Standard Equipment 1-1

1.1 Installation of Display Unit	1-1
1.2 Installation of Antenna Unit	1-3
1.3 Installation of Transducers	1-4
1.4 Installation of Sensors	1-14

2. Wiring 2-1

3. Initial Settings 3-1

3.1 NMEA Setting	3-1
3.2 Output Data Sentences	3-3
3.3 Antenna Height	3-4
3.4 Baud Rate Setting (GP-1850DF only)	3-4
3.5 Beacon frequency Setting (GP-1850DF only)	3-5
3.6 Depth Adjustment	3-6
3.7 External Equipment Setup (Option)	3-7
3.8 Selecting the Echo Sounder Output Power	3-10

4. Installation of DGPS Beacon Receiver (for GP-1850F) 4-1

APPENDIX TRIDUCER 525ST-PWC/PWD AP-1

PACKING LIST A-1

OUTLINE DRAWINGS D-1

INTERCONNECTION DIAGRAM S-1

SCHEMATIC DIAGRAM S-2



© **FURUNO ELECTRIC CO., LTD.**

9-52, Ashihara-cho,
Nishinomiya, Japan

Telephone: 0798-65-2111
Telefax: 0798-65-4200

•Your Local Agent/Dealer

All rights reserved.

Printed in Japan

FIRST EDITION : FEB. 1999
J : NOV. 01, 2001

(HIMA)

PUB. No. IME-43950-J
GP-1850F/1850DF



* 00080862200 *



* IME43950J00 *



SAFETY INSTRUCTIONS

Safety Instructions for the Installer



WARNING



Do not work inside the equipment unless totally familiar with electrical circuits.

Hazardous voltage which can shock, burn or cause serious injury exists inside the equipment.



Turn off the power at the mains switchboard before beginning the installation. Post a sign near the switch to indicate it should not be turned on while the equipment is being installed.

Fire, electrical shock or serious injury can result if the power is left on or is applied while the equipment is being installed.



CAUTION



Ground the equipment to prevent electrical shock and mutual interference.

Confirm that the power supply voltage is compatible with the voltage rating of the equipment.

Connection to the wrong power supply can cause fire or equipment damage. The voltage rating appears on the label at the rear of the display unit.

Use the correct fuse.

Use of a wrong fuse can cause fire or equipment damage.

Keep the following compass safe distance.

	Standard	Steering
Display Unit	0.98 m	0.74 m

When handling the transducer cable, keep in mind the following points.

- **Keep the cable away from oil and fuel.**
- **Keep the cable away from the place where it may be damaged during the installation.**
- **Do not paint the cable.**

The sheath of the transducer cable is made of chlorophrene rubber (or vinyl chloride). Therefore, do not paint the sheath with organic liquid (such as toluene) since it may harm the sheath.

Equipment Lists

Standard supply

No.	Name	Type	Code No.	Qty	Remarks
1	Display unit	GP-1850F-E	-	1	for GP-1850F
		GP-1850DF-E	-		for GP-1850DF
2	Antenna unit	GPA-017	-	1	for GP-1850F
		GPA-018	-		for GP-1850DF
		GPA-019	-		for GP-1850DF
3	Transducer	520-5PSD	000-015-125	1	for 600W output, select one.
		520-5PWD	000-015-126		
		520-5MSD	000-015-127		
4	Spare parts	SP14-02501	004-375-260	1	Fuse
5	Installation materials	CP14-05200	000-041-496	1	Power cable, Cable assy.
6	Accessories	FP14-02401	004-375-270	1	Hard cover
		FP14-02402	004-376-150	1	Screws, output mark label, rubber cushion

Optional equipment


NO.	Name	Type	Code No.	Remarks
1	Beacon receiver kit	GR-802-1850-10A-018	000-041-498	GPA-018, GR-7000A, whip antenna
		GR-802-1850-10N-018	000-041-504	GPA-018, GR-7000A
		GR-902-1850-15A-018S	000-041-499	GPA-018S, GR-7000A, whip antenna
		GR-802-1850-15N-018S	000-041-505	GPA-018, GR-7000A
		GP-802-1850-10N-019	000-041-648	GPA-019, GR-7000A
		GR-902-1850-15N-019S	000-041-649	GPA-019S, GR-7000A
2	Antenna cable assy.	TNC-PS-3D-15	000-133-670	15m, for antenna cable extension
3	Antenna cable set	CP20-01700	004-372-110	30m, for antenna cable extension
		CP20-01710	004-372-120	50m, for antenna cable extension
4	Cable Assy.	MJ-A7SPF0003-050	000-136-730-01	
5	Mast mount fixture	CP20-0111	004-365-780	
6	Right-angle antenna base	No.13-QA330	000-803-239	for mounting antenna unit
7	L-angle antenna base	No.13-QA310	000-803-240	
8	Antenna base for rail mounting	No.13-RC5160	000-806-114	

Optional equipment (con't)

No.	Name	Type	Code No.	Remarks
9	Antenna unit	GPA-018S	000-041-462	for GP-1850DF
		GPA-016	000-041-536	for GP-1850F
		GPA-019S	000-041-554	for GP-1850DF
10	Transducer	520-5PSD	000-015-125	for 600 W
		520-5PWD	000-015-126	w/8m cable transom mount, for 600 W
		520-5MSD	000-015-127	w/8m cable and water proof connector, for 600 W
		50/200-1T	000-015-170	for 1 kW
11	Cable assy	02S4092	000-134-484	for 1 kW transducer connection
12	Matching box	MB-1000	000-040-809	for 1 kW transducer connection
13	ST sensor	ST-02MSB	000-137-986	Thru-hull type
		ST-02PSB	000-137-987	w/8m cable, thru-hull type
14	Inner hull kit S	No.13-QA330	000-803-240	for mounting antenna unit
15	Temperature sensor	T-02MTB	000-040-026	
		T-02MSB	000-040-040	
		T-03MSB	000-040-027	
16	Triducer	524ST-MSD	000-015-224	for 600 W
		525ST-MSD	000-015-263	
		520ST-PWD	000-015-128	for 600 W
		525ST-PWD	000-015-261	
17	Converter connection	02S4147	000-141-082	
18	Rectifier	PR-62	000-013-484	for 100VAC
			000-013-485	for 110 VAC
			000-013-486	for 220 VAC
			000-013-487	for 230 VAC
19	Cable assy.	MJ-A6SPF0011-050	000-132-244	for connection radar, 6P-4P, 5m
		MJ-A6SPF0011-100	000-132-336	for connection radar, 6P-4P, 10m
		MJ-A6SPF0012-050	000-134-424	for navaid or E/S, 6P-6P, 5m
		MJ-A6SPF0012-100	000-133-817	for navaid or E/S, 6P-6P, 10m
20	Whip antenna	FAW-1.2	000-136-046	for GP-1850DF
21	Remote controller	RMC-185F-E	004-375-320	Controller, vinyl cover, battery
22	RAM Card	00RAM02MC-004	004-371-790	2MB
23	DGPS Beacon Receiver	GR-80	-	for GP-1850F

System Configuration

The GP-1850F/1850DF mainly consists of a display unit, a GPS antenna and a dual frequency transducer. A DGPS beacon receiver is provided inside the display unit for GP-1850DF type. The mini chart card drive in the display unit loads electronic charts. External equipment which can be connected include water temperature and speed sensors, autopilot, and DGPS beacon receiver (GP-1850F).



*Required for 1 kW transducer only

1. Installation of Standard Equipment

1.1 Installation of Display Unit

Mounting considerations

The display unit can be installed on a tabletop, on the overhead or flush mounted in a console or panel.




Figure 1-1 Tabletop, overhead mounting methods


When selecting a mounting location for the display unit keep the following in mind:

- Keep the display unit out of direct sunlight.
- The temperature and humidity should be moderate and stable.
- Locate the unit away from exhaust pipes and vents.
- The mounting location should be well ventilated.
- Mount the unit where shock and vibration are minimal.
- Keep the unit away electromagnetic field generating equipment such as motor, generator.
- For maintenance and checking purposes, leave sufficient space at the sides and rear of the unit and leave slack in cables.
- A magnetic compass will be affected if placed too close to the display unit. Observe the following compass safe distances to prevent disturbance to the magnetic compass:

Standard compass: 0.98 meters

Steering compass: 0.74 meters

- Rubber cushions which absorb vibration (supplied) may be attached as below if vibration is a problem.



Mounting procedure

Follow the procedure below to mount the display unit on a tabletop or the overhead.

Tabletop, overhead mounting

1. Fix the hanger by four tapping screws M5 X 16.
2. Screw knob bolts in display unit, set it to hanger, and tighten knob bolts.
3. Attach hard cover to protect LCD.





Figure 1-2 Tabletop, overhead mounting of display unit

Flush mounting

Note: Use supplied pan head screws when the thickness of the bulkhead is from 11 to 14 mm. For bulkhead which exceeds 14 mm in thickness the length of the pan head screws should be bulkhead thickness plus 7.3 ± 1.5 mm. Also the length of B below should max. 7 mm.



1. Prepare a cutout in the mounting location whose dimensions are as shown in Figure 1-3.
2. Fix the display unit by six pan head screws. Refer to the outline drawing on page D-2.




Figure 1-3 Flush mounting of display unit

1.2 Installation of Antenna Unit

Mounting considerations

Install the antenna unit referring to the installation diagram on page D-3 or D-4. When selecting a mounting location for the antenna unit, keep in mind the following points:

- Select a location out of the radar beam. The radar beam will obstruct or prevent reception of the GPS satellite signal.
- The location should be well away from a VHF antenna. A GPS receiver is interfered by a harmonic wave of a VHF antenna.
- There should be no interfering object within the line-of-sight to the satellites. Objects within line-of-sight to a satellite, for example, a mast, may block reception or prolong acquisition time.
- Mount the antenna unit as high as possible. Mounting the antenna unit as high as possible keeps it free of interfering objects and water spray, which can interrupt reception of GPS satellite signal if the water freezes.
- The length of the whip antenna for the GP-1850DF should be no longer than 1.2 meter to prevent antenna damage. **Do not use a 2.5 meter whip antenna.**
- If the antenna cable is to be passed through a hole which is not large enough to pass the connector, you may unfasten the connector with a needle nose pliers and 3/8-inch open-end wrench. Refasten it as shown in Figure 1-4 after running the cable through the hole.




Figure 1-4 How to assemble the connector

Attaching the transducer

1. Clean the transducer face to remove any foreign material. Lightly roughen the transducer face with #100 sandpaper. Also, roughen the inside of the hull where the transducer is to be mounted.
2. Warm the silicone sealant to 40°C before usage to soften it. Coat the transducer face and mounting location with silicone sealant.




Figure 1-6 Coating the transducer face with silicone sealant

3. Press the transducer firmly down on the hull and gently twist it back and forth to remove any air which may be trapped in the silicone sealant.




Figure 1-7 Attaching transducer to hull with silicone sealant

Observing the picture

1. Press the [POWER] key to turn on the display unit.
2. Press the [SNDR] key to select the sounder display.
3. Press the soft key labeled "MODE/FREQ" to display the following message.




Figure 1-8 MODE FREQ selection screen

4. Select "MANUAL" by the arrow key.
5. Press the soft key labeled "RETURN".
6. Press the soft key labeled "GAIN" to display the following message.




Figure 1-9 GAIN adjustment screen

7. Confirm that Gain is set at 50 (midpoint).
8. Press the soft key labeled "RETURN".
9. Press the soft key labeled "RANGE".
10. Select "15ft" by the [▲] key.
11. Note the depth to the seabed.




Figure 1-10 Video sounder picture

If the bottom is displayed in red and the light-blue color appears the mounting location is suitable. You can leave the transducer in position.

If the bottom is not displayed in reddish brown, the mounting location is unsuitable. Relocate the transducer and do the following.

1. Press the [POWER] key to turn off the power.
2. Gently dismount the transducer with piece of wood.
3. Do steps 1 through 5 in the previous procedure. Repeat until a suitable location is found.

Final preparation

Support the transducer with a piece of wood to keep it in place while it is drying. Let the transducer dry 24–72 hours.

Installing the thru-hull mount transducer

Transducer mounting location

This type of mounting provides the best performance of all, since the transducer protrudes from the hull and the effect of air bubbles and turbulence near the hull skin is reduced. When the boat has a keel, the transducer should be at least 30 cm away from it. Typical through hull mountings are shown in the figure on the next page.

The performance of the video sounder is directly related to the mounting location of the transducer, especially for high-speed cruising. The installation should be planned in advance, keeping the standard cable length (8 m) and the following factors in mind:

- Air bubbles and turbulence caused by movement of the boat seriously degrade the sounding capability of the transducer. The transducer should, therefore, be located in a position where water flow is the smoothest. Noise from the propellers also adversely affects performance and the transducer should not be mounted nearby. The lifting strakes are notorious for creating acoustic noise, and these must be avoided by keeping the transducer inboard of them.
- The transducer must always remain submerged, even when the boat is rolling, pitching or up on a plane at high speed.
- A practical choice would be somewhere between 1/3 and 1/2 of the boat's length from the stern. For planing hulls, a practical location is generally rather far astern, so that the transducer is always in water regardless of the planing attitude.

Transducer outline drawings





Figure 1-11 Transducer outline drawings

Acceptable transducer mounting locations


Deep-V hull



- Position 1/2 to 1/3 length of the hull from stern
- 15 to 30 cm off center line (inside first lifting strakes).

Figure 1-12 Transducer mounting location on deep-V hull

High speed V-planing hull



- Within the wetted bottom area
- Deadrise angle within 15°

Figure 1-13 Transducer mounting location on high speed V-planing hull

Typical through-hull mount transducer installations




Figure 1-14 Typical through-hull mount transducer installations

Procedure for installing the thru-hull mount transducer

1. With the boat hauled out of the water, mark the location selected for mounting the transducer on the bottom of the hull.
2. If the hull is not level within 15° in any direction, fairing blocks made out of teak should be used between the transducer and hull, both inside and outside, to keep the transducer face parallel with the water line. Fabricate the fairing block as shown below and make the entire surface as smooth as possible to provide an undisturbed flow of water around the transducer. The fairing block should be smaller than the transducer itself to provide a channel to divert turbulent water around the sides of the transducer rather than over its face.




Figure 1-15 Construction of fairing block

3. Drill a hole just large enough to pass the threaded stuffing tube of the transducer through the hull, making sure it is drilled vertically.
4. Apply a sufficient amount of high quality caulking compound to the top surface of the transducer, around the threads of the stuffing tube and inside the mounting hole (and fairing blocks if used) to ensure watertight mounting.
5. Mount the transducer and fairing blocks and tighten the locking nuts. Be sure that the transducer is properly oriented and its working face is parallel to the waterline.

Note: Do not over-stress the stuffing tube and locking nuts through excessive tightening, since the wood block will swell when the boat is placed in the water. It is suggested that the nut be tightened lightly at installation and retightened several days after the boat has been launched.

Installing the transom mount transducer

This type of mounting is very commonly employed, usually on relatively small I/O or outboard boats. Do not use this method on an inboard motor boat because turbulence is created by the propeller ahead of the transducer.

There are two methods of installation: flush with hull (for flat hulls) and projecting from hull (for deep V-hulls).




Figure 1-16 Transom mount transducer mounting locations

Installing the transom mount transducer flush with hull (for flat hulls)

A suitable mounting location is at least 50 cm away from the engine and where the water flow is smooth.

1. Drill four pilot holes in the mounting location.
2. Attach the transducer to the bracket with tapping screws (supplied).
3. Adjust the transducer position so the transducer faces right to the seabed.

Note: If necessary, to improve water flow and minimize air bubbles staying on the transducer face, incline the transducer about 5° at the rear. This may require a certain amount of experimentation for fine tuning at high cruising speeds.

4. Fill the gap between the wedge front of the transducer and transom with epoxy material to eliminate any air spaces.




Figure 1-17 Transom mount transducer, mounting flush with hull

Installing the transom mount transducer projecting from hull (for deep-V hulls)

This method is employed on deep-V hulls and provides good performance because the effects of air bubbles are minimal. Install the transducer parallel with water surface; not flush with hull. If the boat is placed on a trailer care must be taken not to damage the transducer when the boat is hauled out of the water and put on the trailer.




Figure 1-18 Transom mount transducer, projecting from hull

Transducer preparation

Before putting the boat in water, wipe the face of the transducer thoroughly with a detergent liquid soap. This will lessen the time necessary for the transducer to have good contact with the water. Otherwise the time required for complete "saturation" will be lengthened and performance will be reduced.

Do not paint the transducer. Performance will be affected.

Triducer 524ST-MSD, 525ST-MSD

The triducer is designed for thru-hull mounting.

Mounting considerations

When selecting a mounting location keep the following points in mind:

- Air bubbles and turbulence caused by movement of the boat seriously degrade the sounding capability of the transducer. The transducer should, therefore, be located in a position where water flow is the smoothest. Noise from the propellers also adversely affects performance and the transducer should not be mounted nearby. The lifting strakes are notorious for creating acoustic noise, and these must be avoided by keeping the transducer inboard of them.
- The transducer must always remain submerged, even when the boat is rolling, pitching or up on a plane at high speed.
- A practical choice would be somewhere between 1/3 and 1/2 of the boat's length from the stern. For planing hulls, a practical location is generally rather far astern, so that the transducer is always in water regardless of the planing attitude.




Figure 1-19 Dimensions of triducer 524ST-MSD/525ST-MSD

1.4 Installation of Sensors

Transom mount water temperature sensor T-02MTB

- Fix the cable at a convenient location with cable clamp.
- When the cable is led in through the transom board, make a hole of approx. 17 mm diameter to pass the connector. After passing the cable, fill the hole with a sealing compound.




Figure 1-20 How to install transom mount water temperature sensor T-02MTB

Thru-hull mount water temperature sensor T-02MSB, T-03MSB

- Select a mid-boat flat position. The sensor does not have to be installed perfectly perpendicular. The sensor must not be damaged in dry-docking operation.
- Select a place apart from equipment generating heat.
- Select a place in the forward direction viewing from the drain hole, to allow for circulation of cooling water.
- Select a place free from vibration.

Mount the sensor as shown below.





Figure 1-21 Thru-hull mount water temperature sensors
T-02MSB, T-03MSB

Through-hull mount water temperature/speed sensor ST-02MSB, ST-02PSB

Select a suitable mounting location considering the following:

- Select a mid-boat flat position. The sensor does not have to be installed perfectly perpendicular. The sensor must not be damaged in dry-docking operation.
- Select a place apart from equipment generating heat.
- Select a place in the forward direction viewing from the drain hole, to allow for circulation of cooling water.
- Select a place free from vibration.

1. Dry-dock the boat.
2. Make a hole of approx. 51 mm diameter.
3. Unfasten locknut and remove the sensor section.
4. Apply high-grade sealant to the flange of the sensor.
5. Pass the sensor casing through the hole.
6. Face the notch on the sensor toward boat's bow and tighten the flange.
7. Set the sensor section to the sensor casing and tighten the locknut.
8. Launch the boat and check for water leakage around the sensor.



*Figure 1-22 Water temperature/speed sensor ST-02MSB,
ST-02PSB*

2. Wiring

All wiring are terminated at the rear of the display unit.




Figure 2-1 Display unit, rear view

Power cable

Connect the power cable to the power connector. Connect the leads to the battery (12 or 24 VDC); white to plus(+) terminal and black to minus(-) terminal.




Figure 2-2 Connecting the power cable to the battery

Antenna unit

Connect the antenna cable to the ANT connector.

Transducer



Connect the transducer cable to the XDR connector.

Water temperature/speed sensor


Connect the water temperature sensor (option) or water temperature/speed sensor (option) to the TEMP/SPD connector.

Ground

The display unit contains several CPUs. While they are operating, they radiate noise, which can interfere with radio equipment. Ground the unit to prevent interference. The grounding wire should be 1.25 sq or larger and as short as possible. Connect the grounding wire to ship's ground. On a fiberglass boat, it is best to install a ground plate that measures about 20 cm by 30 cm on the outside of the hull bottom to provide a ground point. If this is not practical, the engine block can be used.

	CAUTION
	Ground the equipment to prevent electrical shock and mutual interference.

Also, the antenna unit GPA-018S (option) should be grounded.

Note: Use a “closed” lug to make the ground connection at the display unit. Do not use an “open-type” lug (.

Extending antenna cable length

The standard cable is 10m long. For extension, in case of the GPA-016, GPA-018 and GPA-018S, an antenna cable set of 15m (GPA-018S and GPA-019S), 30m or 50m is available. Extension cable cannot be used with the GPA-017 or GPA-018.

◆ Extension cable line-up (in case of 30 m or 50 m)

Fabricate the end of the antenna cable and attach the coaxial connector. Details are shown on next page.




Figure 2-3 Cable extension

◆ Waterproofing connector

Wrap connector with vulcanizing tape and then vinyl tape. Bind the tape end with cable-tie.




Figure 2-4 Waterproofing connector

How to attach the N-P-8DFB connector




Figure 2-5 Fabrication of coaxial cable

3. Initial Setting

3.1 NMEA Setting

NMEA port

1. Press the [MENU] key.
2. Press the software key labeled "CONFIGURATION".
3. Press the software key labeled "SETUP NMEA PORT 1".
4. Select "FORMAT" by the arrow key.
5. Press the software key labeled "EDIT" to display the following message.

The screenshot shows a graphical user interface for NMEA port setup. At the top right, a title bar reads "SETUP PORT 1". On the left, a vertical menu has "FORMAT" selected with a right-pointing arrow. The main area is titled "OUTPUT FORMAT" and contains two radio button options: "NMEA0183 Ver1.5" (unselected) and "NMEA0183 Ver2.0" (selected with a filled circle). Up and down arrow keys are positioned above and below these options. At the bottom left, a button labeled "DGPS 3D" is visible. At the bottom right, there are two buttons: "ENTER" and "CANCEL".

Figure 3-1 Output Format Display, NMEA port

6. Select NMEA version desired by the arrow key.
7. Press the software key labeled "ENTER".
8. Press the [PLOT] key to finish.

DGPS port

1. Press the [MENU] key.
2. Press the software key labeled "CONFIGURATION".
3. Press the software key labeled "SETUP NMEA/DGPS PORT 2".
4. Select "FORMAT" by the arrow key.
5. Press the software key labeled "EDIT" to display the following message.




Figure 3-2 Output Format Display, DGPS port

6. Select NMEA version, external DGPS or internal DGPS by the arrow key.
NMEA0183 Ver1.5/Ver2.0 : Select one when connecting PC or RS-232C equipment.
RTCM104(EXTRN) : Select this when connecting external DGPS beacon receiver.
RTCM104(INTRN) : Select this for builtin internal DGPS beacon receiver.
RTCM104(OUTPUT) : Select this when outputting differential data of the internal DGPS beacon receiver to other GPS navigator.

Note 1) You cannot setup sentences when you select RTCM104 as the format.

Note 2) For RS-422 format, the level converter (IF-1432) is required for connection of external equipment.

7. Press the software key labeled "ENTER".
8. Press the [PLOT] key to finish.

3.2 Output Data Sentences

Select output data sentences for external equipment as follows.

1. Press the [MENU] key.
2. Press the software key labeled "CONFIGURATION".
3. Press the software key labeled "SETUP NMEA PORT 1".
4. Press the software key labeled "SELECT SENTNC." to display the following list.

The screenshot shows a menu titled "SELECT SENTNC." with a list of NMEA sentences and their status. The status is either "ON" or "--".

Sentence	Status
AAM	--
APB	ON
BOD	--
BWR	--
GGA	--
GLL	ON
MTW	--
RMA	--
RMB	ON
RMC	ON
VTG	ON
WPL	--
XTE	--
ZDA	ON

At the bottom left is a button labeled "DGPS 3D". At the bottom right is a button labeled "RETURN". To the right of the list is a button labeled "ON/OFF".

Figure 3-3 Output Date Sentences Display

5. Select data sentence you want to output data by the arrow key.
6. Press the software key labeled "ON/OFF". To output data, set to "ON".
7. Repeat to select other sentences.
8. Press the software key labeled "RETURN".
9. Press the [PLOT] key to finish.

Input/Output Sentences

Port	I/O	Format	Data	Remarks
1	Input	<ul style="list-style-type: none"> NMEA-0183 Ver. 2.0 Ver. 1.5 IEC1162 	TLL*1, DWM, WPL*1	WPL : GP talker only
	Output		AAM, APB, BOD, BWC/BWR, GGA, GLL, RMA, RMB, RMC, VTG, WPL, XTE, ZDA, DBT/DPT, MTW, GTD*2	GREAT CIRCLE: BWC RHUMB LINE: BWR NMEA Ver 1.5: DBT NMEA Ver 2.0: DPT
2	Input	<ul style="list-style-type: none"> NMEA-0183 Ver. 2.0 Ver. 1.5 RS232C RTCM104 	TLL*1, DWM, WPL*1	WPL: GP talker only
	Output		AAM, APB, BOD, BWC/BWR, GGA, GLL, RMA, RMB, RMC, VTG, WPL, XTE, ZDA, DBT/DPT, GTD*2	GREAT CIRCLE: BWC RHUMB LINE: BWR NMEA Ver 1.5: DBT NMEA Ver 2.0: DPT

*1: Cannot be input consecutively.

*2: Output automatically when LC or LA is selected.

3.3 Antenna Height

1. Press the [MENU] key.
2. Press the software key labeled "GPS/DGPS/TD OPTIONS".
3. Press the software key labeled "GPS SETUP OPTIONS".
4. Select "ANT. HEIGHT" by the arrow key.
5. Press the software key labeled "EDIT" to display the following message.




Figure 3-4 Antenna Height Display

6. Enter the height (3 digits) of the antenna above sea level using the numeric keys.
If you enter wrong antenna height, press the software key labeled "CLEAR".
7. Press the [ENTER] key.
8. Press the [PLOT] key to return to finish.

3.4 Baud Rate Setting (GP-1850DF only)

This setting may not be done when AUTO MODE is selected.

1. Press the [MENU] key.
2. Press the software key labeled "GPS/DGPS/TD OPTIONS".
3. Press the software key labeled "DGPS SETUP OPTIONS" to display the following message.




Figure 3-5 DGPS Setup Options Display

4. Confirm that "ON" is selected at "DGPS MODE" field for GP-1850DF.
5. Select "BEACON BAUD RATE" by the arrow key.
6. Press the software key labeled "EDIT" to display the following message.

BEACON BAUD RATE	
▲	
<input type="radio"/>	200
<input checked="" type="radio"/>	100
<input type="radio"/>	50
▼	

Figure 3-6 Beacon Baud Rate Display

7. Select beacon baud rate corresponding to DGPS reference station to use.
8. Press the [ENTER] key.
9. Press the [PLOT] key to return to finish.

3.5 Beacon Frequency Setting (GP-1850DF only)

1. Press the [MENU] key.
2. Press the software key labeled "GPS/DGPS/TD OPTIONS".
3. Press the software key labeled "DGPS SETUP OPTIONS" to display the following message.

DGPS OPTION	
DGPS MODE	ON
BEACON FREQUENCY	AUTO
▶ BEACON BAUD RATE	AUTO
DGPS ALARM	OFF
EDIT	
DGPS 3D	RETURN

Figure 3-7 DGPS Setup Options Display

4. Select "BEACON FREQUENCY" by the arrow key.
5. Press the software key labeled "EDIT" to display the following message.

BEACON FREQUENCY	
▲	
●	AUTO
○	MANUAL ► 284.0 kHz
▼	

Figure 3-8 Beacon Frequency Display

6. Select "AUTO" or "MANUAL" by the arrow key. When you select "MANUAL", operate the cursor pad to move the cursor to frequency dialog box. And press the arrow key to select the frequency desired.
7. Press the [ENTER] key.
8. Press the [PLOT] key to finish.

3.6 Depth Adjustment

1. Press the [MENU] key.
2. Press the software key labeled "DISPLAY OPTIONS".
3. Press the software key labeled "NEXT PAGE".
4. Select "DEPTH ADJ." by the arrow key.
5. Press the software key labeled "EDIT" to display the following message.

DEPTH ADJ	
▲	
+	0.0 ft
▼	

Figure 3-9 Depth Adjustment Display

6. Set depth adjustment by the arrow key. The adjustment range is -9.9~+9.9 ft.
For example, if the depth readout from the draft to the transducer is 5 feet lower than actual depth, enter +5 feet.
7. Press the software key labeled "RETURN".
8. Press the [PLOT] key to finish.

3.7 External Equipment Setup (Option)

This section shows you how to set up the GP-1850F/1850DF when external equipment is connected. If a water temperature/speed sensor is installed, you should complete this section with the boat in the water and running, to confirm speed/water temperature readout.

Speed Source

1. Press the [MENU] key.
2. Press the software key labeled "DISPLAY OPTIONS".
3. Press the software key labeled "NEXT PAGE" to display the following display.

▶ SPEED SOURCE		GPS	DISPLAY SETUP2
TEMP SOURCE		OWN XDCR	
TEMP GRAPH		OFF	
ZOOM MARKER		OFF	
SPEED ADJ.		+00%	
TEMP ADJ.		+00.0°F	
DEPTH ADJ.		+0.0ft	
SPD	TEMP	DEPTH	EDIT
12.3kt	62.5°F	2000.0ft	
DGPS 3D			RETURN

Figure 3-10 Display Setup 2 Display

4. Select "SPEED SOURCE" by the arrow key.
5. Press the software key "EDIT" to display the following message.

SPEED SOURCE	
▲	
○	OWN PDDWHL
●	GPS
▼	

Figure 3-11 Speed Source Display

6. Select source of speed by the arrow key; "OWN PDDWHL" (speed sensor) or "GPS".
Adjust speed when you select "OWN PDDWHL". Refer to next page.
7. Press the software key labeled "ENTER".
8. Press the [PLOT] key to finish.

Speed Adjustment

Adjust speed when you select own speed source "OWN PDDWHL".

1. Press the [MENU] key.
2. Press the software key labeled "DISPLAY OPTIONS".
3. Press the software key labeled "NEXT PAGE" to display the following display.

▶ SPEED SOURCE		GPS	DISPLAY SETUP2
TEMP SOURCE		OWN XDCR	
TEMP GRAPH		OFF	
ZOOM MARKER		OFF	
SPEED ADJ.		+00%	
TEMP ADJ.		+00.0°F	
DEPTH ADJ.		+0.0ft	
SPD	TEMP	DEPTH	EDIT
12.3kt	62.5°F	2000.0ft	
DGPS 3D			RETURN

Figure 3-12 Display Setup 2 Display

4. Select "SPEED ADJ." by the arrow key.
5. For speed sensor-equipped sets, you may offset the speed readout if it is wrong. Run the boat at various speeds and watch the speed readout at the bottom of the screen. If it is unreasonably wrong, press the software key "EDIT" to display the following message.

SPEED ADJ		
▲		
+	00	%
▼		

Figure 3-13 Speed Adjustment Display

6. Correct speed readout by the arrow key. The adjustment range is -50%~+50%. For example, if readout is 10% lower than actual speed, enter +10%.
7. Press the software key "RETURN".
8. Press the [PLOT] key to finish.

Temperature Adjustment

1. Press the [MENU] key.
2. Press the software key labeled "DISPLAY OPTIONS".
3. Press the software key labeled "NEXT PAGE" to display the following display.

► SPEED SOURCE GPS TEMP SOURCE OWN XDCR TEMP GRAPH OFF ZOOM MARKER OFF SPEED ADJ. +00% TEMP ADJ. +00.0°F DEPTH ADJ. +0.0ft		DISPLAY SETUP2 EDIT RETURN
SPD 12.3kt	TEMP 62.5°F	DEPTH 2000.0ft
DGPS 3D		

Figure 3-14 Display Setup 2 Display

4. Select "TEMP ADJ." by the arrow key.
5. For water temperature sensor-equipped sets, you may offset the water temperature readout if it is wrong. Watch the water temperature readout at the bottom of the screen. If it is unreasonably wrong, press the software key labeled "EDIT" to display the following message.

TEMP ADJ
▲
+ 00.0 °F
▼

Figure 3-12 Temperature Adjustment Display

6. Correct water temperature readout by the arrow key. The adjustment range is -99.9°~+99.9°.
For example, if the readout is 2° higher than actual temperature, enter -2°.
7. Press the software key labeled "RETURN".
8. To display a water temperature graph (shows present water temperature), select "TEMP GRAPH" by arrow key.
9. Press the software key labeled "EDIT" to display following message.

TEMP GRAPH
▲
<input type="radio"/> ON
<input checked="" type="radio"/> OFF
▼

Figure 3-13 Temperature Graph Display

10. Select "ON".
11. Press the software key labeled "ENTER".
12. Press the [SNDR] key to finish.

3.8 Selecting the Echo Sounder Output Power

The echo sounder output power can be selected for 600 W (for transducer 520-5PSD, 520-5PWD, 520-5MSD) or 1 kW (50/200-1T), and the default setting is 600 W.

Note: Matching Box MB-1000 and cable assembly 02S4092 are required for 1kW transducer connection. For details, see the interconnection diagram at the end of this manual.

Attach the TX power label (supplied) to the place shown below, and draw a line through the power which you don't use by oil base magic marker.




Figure 3-14 Display unit, top view

To change to 1 kW power, do the following:

1. Turn off the power. Wait at least one minute before opening the cover, to allow capacitors to discharge.
2. Remove nuts attached to XDR, SPD/TEMP. DGPS, NMEA and power supply connectors at the rear of the display.
3. Remove nut and washer attached to the ANT connector.
4. Remove ten binding screws (M3 x 10) from the rear of the display unit to separate the panel/chassis assembly from the cover assembly.




Figure 3-15 Removing cover assembly



5. Move the jumper block on JP1 from 3-4 to 1-2 on the ANLG Board.




Figure 3-16 ANLG Board

6. Remount the cover assembly.

Note: Confirm that the following parts are attached:

- Inside of the cover: Shield gaskets, GN gasket (See Figure 3-17.)
- On ANLG Board: Connector gasket (See Figure 3-15.)




Figure 3-17 Inside of the cover

7. Tighten nuts to torque shown below and in the order shown in Figure 3-18.

No. 1 through No. 5 : 7.5 - 8 kgf/cm

No. 6 : 14 -16 kgf/cm




Figure 3-18 Display unit, rear view

8. Tighten ten binding screws (M3 x 10) fixing the cover to torque of 7.5-8 kgf/cm.

4. Installation of DGPS Beacon Receiver (for GP-1850F)

The DGPS beacon receiver GR-7000A can be incorporated in the GP-1850F to provide it with DGPS capability. Six installation kits are available as shown.

GR-802-1650-10A-018 (W/whip ant.) GR-802-1650-10N-018

Name	Type	Code No.	Qty
Antenna Unit	GPA-018	000-041-471	1
Beacon Receiver	GR-7000A	000-143-249	1
Whip antenna (10A type only)	FAW-1.2	000-130-046	1
Connector Assy.	PH6P-W-L240	000-141-548	1
Cable tie	CV-100	000-570-322	2
Pan head screws*	M3X10 C2700W	000-881-405	4
Screw*	M3X12 SUS304	000-805-905	6
Cable Assy.*	S.FL2-2LP0.7-D-WHT (121)	000-141-491	1
Clamp	HP-2N	000-570-000	1
Cable Assy.	S.FL2-2LP0.7-D-WHT (250)	000-143-877	1
Screw	3X8 SUS410	000-802-951	4

* Not used

GR-802-1650-15A-018S (W/whip ant.) GR-802-1650-15N-018S

Name	Type	Code No.	Qty
Antenna Unit	GPA-018S	000-041-462	1
Beacon Receiver	GR-7000A	000-143-249	1
Cable Assy.	TNC-PS-3D-15	000-133-670	1
Whip antenna (15A type only)	FAW-1.2	000-130-046	1
Connector Assy.	PH6P-W-L240	000-141-548	1
Cable tie	CV-100	000-570-322	2
Pan head screws*	M3X10 C2700W	000-881-405	4
Screw*	M3X12 SUS304	000-805-905	6
Cable Assy.*	S.FL2-2LP0.7-D-WHT (121)	000-141-491	1
Clamp	HP-2N	000-570-000	1
Cable Assy.	S.FL2-2LP0.7-D-WHT (250)	000-143-877	1
Screw	3X8 SUS410	000-802-951	4

* Not used

GR-802-1650-10N-019

Name	Type	Code No.	Qty
Antenna Unit	GPA-019	000-041-552	1
Beacon Receiver	GR-7000A	000-143-249	1
Connector Assy.	PH6P-W-L240	000-141-548	1
Cable tie	CV-100	000-570-322	2
Pan head screws*	M3X10 C2700W	000-881-405	4
Screw*	M3X12 SUS304	000-805-905	6
Cable Assy.*	S.FL2-2LP0.7-D-WHT (121)	000-141-491	1
Clamp	HP-2N	000-570-000	1
Cable Assy.	S.FL2-2LP0.7-D-WHT (250)	000-143-877	1
Screw	3X8 SUS410	000-802-951	1

* Not used

GR-802-1650-15N-019S


Name	Type	Code No.	Qty
Antenna Unit	GPA-019S	000-041-554	1
Beacon Receiver	GR-7000A	000-143-249	1
Cable Assy.	TNC-PS-3D-15	000-133-670	1
Connector Assy.	PH6P-W-L240	000-141-548	1
Cable tie	CV-100	000-570-322	2
Pan head screws*	M3X10 C2700W	000-881-405	4
Screw*	M3X12 SUS304	000-805-905	6
Cable Assy.*	S.FL2-2LP0.7-D-WHT (121)	000-141-491	1
Clamp	HP-2N	000-570-000	1
Cable Assy.	S.FL2-2LP0.7-D-WHT (250)	000-143-877	1
Screw	3X8 SUS410	000-802-951	4

* Not used

Disassembly

Procedure

1. Turn off the power. Wait at least one minute before opening the cover, to allow capacitors to discharge.
2. Remove nuts attached to DGPS, NMEA and power supply connectors at the rear of the display unit.



WARNING

Do not connect the power cable with the cover removed.

Figure 4-1 Removing cover assembly

3. Remove nut and washer attached to ANT connector.
4. Remove ten screws at rear of the display unit to detach panel/chassis assembly from the cover assembly.

Installation of DGPS receiver

Procedure

1. Dismount chassis assembly from panel/chassis assembly by disconnecting the connector and PH8P from J8 on MAIN Board shown in the figure below.




Figure 4-2 Dismounting chassis assembly

2. Dismount heat sink from chassis assembly by unfastening three screws on the ANLG board, loosening two screws at TR fixing plates and disconnecting the connector of the mini pin coaxial cable.




Figure 4-3 Chassis assembly

Handling of Coaxial Cable

- Do not touch the connector with bare hands; use gloves.
- Use radio pincers to remove, and pull out straightly.
- Plug in connector straightly.

3. Fasten the GR-7000A (DGPS beacon receiver) to the heat sink with four 3X8 screws as shown in the figure below.




Figure 4-4 Installation of DGPS beacon receiver

4. Open the cover of GR-7000A to connect two coaxial cables shown below.




Figure 4-5 Connecting the coaxial cables in GR-7000A

5. Close the cover of GR-7000A passing the two cables out through respective notches in the cover.
6. Plug PH6P-W-L240 connector to J2 on the GR-7000A through the cover.

7. Wire cable assembly as shown in the figure below.




Figure 4-6 Wiring the Cable assembly

8. Mount the ANLG board on the heat sink referring to step 2. Fasten cable assy. S.FL2-2LP0.7-D-WHT (250), 8P connector cable and 6P connector cable by cable tie (CV-100, supplied) as shown in the figure below. Fix cable assy. S.FL2-2LP0.7-D-WHT (250) with vinyl tape.




Figure 4-7 Attaching cable tie

9. Connect J1 of GR-7000A to J8 of ANLG board (Refer to Figure 4-6).
10. Mount chassis assembly on the panel assembly. Connect 8P connector and 6P connector to Main board as shown in Figure 4-8.





Figure 4-8 Attaching chassis assembly

11. Reassemble the display unit.




Figure 4-9 Remounting the cover

Note : When reattaching the cover, confirm the following parts are attached.

- Inside of the cover : Shield gaskets, GN gasket (See Figure 4-10.)
- On ANLG Board : Connector gasket (See Figure 4-1.)





Figure 4-10 Inside of the cover

Checking the DGPS installation

1. Press the [MENU] key.
2. Press the software key labeled "CONFIGURATION".
3. Press the software key labeled "SYSTEM MENU".
4. Press the software key labeled "SELF TEST".
5. Press the software key labeled "MEMORY•I/O TEST" to display the following message.



*: Special connections are required to check these port.
Otherwise, "--" (bar) appears.

Figure 4-10 Memory, I/O Test Display

6. Confirm that "BEACON RECEIVER: OK" is displayed.
7. Press the soft key labeled "RETURN".
8. Press the [PLOT] key to return the plotter display.

APPENDIX

TRIDUCER 525ST-PWC/PWD

This appendix provides a copy of the installation instructions for AIRMAR triducer. If you loose the original supplied with the triducer, use this appendix.

INSTALLATION INSTRUCTIONS

Transom Mount Transducer or TRIDUCER® Multisensor with Integral Release Bracket

Model P66

U.S. Patents: 4,555,938; 4,644,787; 5,606,253; Des. 334,335
Canadian Patent 1,233,341

IMPORTANT Please read the instructions completely before proceeding with the installation. These directions supersede any other instructions in your instrument manual if they differ.



Applications

- Powerboats with outboard, inboard, inboard/outboard, or jet drive.
Not recommended for boats with large or twin screw inboard motor.
- Bracket protects the sensor form frontal impact only
- Good operation up to 44kn (50MPH)
- Orients the sound beam vertically on hulls with a deadrise angle up to 30°
- Adjusts to transom angles from 2-22°

Tools and Materials Needed

Scissors
Masking tape
Safety goggles
Dust mask
Electric drill
Drill bit for:
Bracket holes 4mm, #23, or 9/64"
Fiberglass hull chamfer bit (preferred), 6mm, or 1/4"
Transom hole 19mm or 3/4" (optional)
Cable clamp holes 3mm or 1/8"
Screwdrivers
Straight edge
Marine sealant
Pencil
Zip-ties
Water-based antifouling paint (**mandatory in salt water**).

Height without
speed sensor
191mm (7-1/2")

Height with
speed sensor
213mm (8-1/2")




Figure 1. Height required at mounting location

Pre-test for Speed and Temperature

Connect the sensor to the instrument and spin the paddlewheel. Check for a speed reading and the approximate air temperature. If there is no reading, return the sensor to your place of purchase.

Mounting Location

To ensure the best performance, the sensor *must* be submerged in aeration-free and turbulence-free water. Mount the sensor close to the centerline of the boat. On slower heavier displacement hulls, positioning it farther from the centerline is acceptable.

Allow adequate space above the bracket for it to release and rotate the sensor upward (see Figure 1).

Caution: Do not mount the sensor in an area of turbulence or bubbles:
*Near water intake or discharge openings;
Behind strakes, struts, fittings, or hull irregularities;
Behind eroding paint (an indication of turbulence).*

Caution: Avoid mounting the sensor where the boat may be supported during trailering, launching, hauling, and storage.

- **Single drive boat**—Mount on the starboard side at least 75mm (3") beyond the swing radius of the propeller (see Figure 2).
- **Twin drive boat**—Mount between the drives.




Figure 2. Mounting location on single drive boat

P66 Installation template for starboard side of boat

Drill at locations labeled "B"
for the following transom angles:
16° through 22°



Drill at locations labeled "A"
for the following transom angles:
2° through 15°

Align arrow with bottom of transom




Figure 3. Template position

Caution: Never Use Solvents!

Cleaners, gasoline, paint, sealants, and other products may contain strong solvents such as acetone which can attack many plastics dramatically reducing their strength.

Installation

Bracket

1. Cut out the installation template shown on the left.
2. At the selected location, position the template, so the arrow at the bottom is aligned with the bottom edge of the transom. *Being sure* the template is parallel to the waterline, tape it in place (see Figure 3).

Warning: Always wear safety goggles and a dust mask.

3. Using a 4mm, #23, or 9/64" bit, drill three holes 22mm (7/8") deep at the locations indicated. To prevent drilling too deeply, wrap masking tape around the bit 22mm (7/8") from the point.
Fiberglass hull—Minimize surface cracking by chamfering the gelcoat. If a chamfer bit or countersink bit is not available, start drilling with a 6mm or 1/4" bit to a depth of 1mm (1/16").
4. **If you know your transom angle**—The bracket is designed for a standard 13° transom angle.
11°-18° angle—No shim is required. Skip to "Adjusting", step 3.
Other angles—The shim is required. Skip to "Adjusting", step 2.

If you do not know the transom angle—Temporarily attach the bracket and sensor to the transom to determine if the plastic shim is needed.

5. Using the two #10 x 1-1/4" self-tapping screws, temporarily screw the bracket to the hull. *Do not* tighten the screws completely at this time. Follow the instructions for "Attaching the Sensor to the Bracket", steps 1-4 before proceeding with "Adjusting".

Adjusting

1. Using a straight edge, sight the underside of the sensor relative to the underside of the hull. The stern of the sensor should be 1-3mm (1/16-1/8") below the bow of the sensor or parallel to the bottom of the hull (see Figure 5).

Caution: Do not position the bow of the sensor lower than the stern because aeration will occur.





Figure 4. Attaching the sensor to the bracket



- To adjust the sensor's angle relative to the hull, use the tapered plastic shim provided. If the bracket has been temporarily fastened to the transom, remove it. Key the shim in place on the back of the bracket.

2°-10° transom angle (stepped transom and jet boats)—Position the shim with the tapered end down.

19°-22° transom angle (small aluminum and fiberglass boats)—Position the shim with the tapered end up.

- If the bracket has been temporarily fastened to the transom, remove it. Apply a marine sealant to the threads of the two #10 x 1-1/4" self tapping screws to prevent water seeping into the transom. Screw the bracket to the hull. *Do not* tighten the screws completely at this time.
- Repeat step 1 to ensure that the angle of the sensor is correct.

Caution: Do not position the sensor farther into the water than necessary to avoid increasing drag, spray, and water noise and reducing boat speed.

- Using the vertical adjustment space on the bracket slots, slide the sensor up or down to provide a projection of 3mm (1/8"). Tighten the screws (see Figure 6).

Attaching the Sensor to the Bracket

- If the retaining cover near the top of the bracket is closed, open it by depressing the latch and rotating the cover downward (see Figure 4).
- Insert the sensor's pivot arms into the slots near the top of the bracket.
- Maintain pressure until the pivot arms click into place.
- Rotate the sensor downward until the bottom snaps into the bracket.
- Close the retaining cover to prevent the accidental release of the sensor when the boat is underway.


Cable Routing

Route the sensor cable over the transom, through a drain hole, or through a new hole drilled in the transom **above the waterline**.

Caution: Never cut the cable or remove the connector; this will void the warranty.

Warning: Always wear safety goggles and a dust mask.



- If a hole must be drilled, choose a location well above the waterline. Check for obstructions such as trim tabs, pumps, or wiring inside the hull. Mark the location with a pencil. Drill a hole through the transom using a 19mm or 3/4" bit (to accommodate the connector).
- Route the cable over or through the transom.
- On the outside of the hull secure the cable against the transom using the cable clamps. Position a cable clamp 50mm(2") above the bracket and mark the mounting hole with a pencil (see Figure 6).
- Position the second cable clamp halfway between the first clamp and the cable hole. Mark this mounting hole.
- If a hole has been drilled in the transom, open the appropriate slot in the transom cable cover. Position the cover over the cable where it enters the hull. Mark the two mounting holes.
- At each of the marked locations, use a 3mm or 1/8" bit to drill a hole 10mm (3/8") deep. The prevent drilling too deeply, wrap masking tape around the bit 10mm (3/8") from the point.
- Apply marine sealant to the threads of the #6 x 1/2" self-tapping screw to prevent water from seeping into the transom. If you have drilled a hole through the transom, apply marine sealant to the space around the cable where it passes through the transom.
- Position the two cable clamps and fasten them in place. If used, push the cable cover over the cable and screw it in place.
- Route the cable to the instrument being careful not to tear the cable jacket when passing it through the bulkhead(s) and other parts of the boat. To reduce electrical interference, separate the sensor cable from other electrical wiring and "noise" sources. Coil any excess cable and secure it in place with zip-ties to prevent damage.
- Refer to your echosounder owner's manual to connect the sensor to the instrument.




14CF-X-9858-2 1/1

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
ハードカバー組品		FP14-02401	1
HARD COVER ASSY.		004-375-270	

その他工材 OTHER INSTALLATION MATERIALS

ケーブル組品MJ CABLE ASSY.	 L=3.5M	MJ-A3SPF0013-035	1
ケーブル組品MJ CABLE ASSY.	 L=5M	MJ-A6SPF0003-050	1

<p> $t_1 - \lambda^*$ FUSE </p>		<p>FGB0-A 5A AC125V</p>	<p>3</p>
		<p>000-549-064</p>	

FP14-02402

出カハリマ-ク (E)	14-063-1025-1	1
OUT PUT MARK LABEL (E)	100-274-611	
ゴ-ムフツ	TW-166 No. 18 ヲ	2
RUBBER FOOT	000-808-732	
+トラスタップ・ソネヅ	5X16 SUS304 1種	4
+TAPPING SCREW	000-805-494	
+ナハ・セムソネヅ B	M4X20 SUS304	6
WASHER HEAD SCREW	000-804-742	








FP14-02401

注記) 1 送受波器他オプション等は別梱包になります。
OPTIONS, FOR EXAMPLE TRANSDUCER ARE SUPPLIED IN OTHER BOX.




(略図の寸法は、参考値です。DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

PACKING LIST (E018)

14CF-X-9860-1 1/1

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
ユニット UNIT			
指示器 DISPLAY UNIT		GP-1850DF-E	1
空中線部 ANTENNA UNIT		000-041-495 GPA-018 000-041-407	1
予備品 SPARE PARTS SP14-02501			
ヒューズ FUSE		FGB0-A 5A AC125V 000-549-064	3
付属品 ACCESSORIES FP14-02402			
出力パネル(E) OUT PUT MARK LABEL (E)		14-063-1025-1 100-274-611	1
ゴムの足 RUBBER FOOT		TM-166 No.18 2個	2
+プラスネジ +TAPPING SCREW		000-808-732 5X16 SUS304 1種	4
+ワッシャーB WASHER HEAD SCREW		000-805-494 M4X20 SUS304 000-804-742	6
付属品 ACCESSORIES FP14-02401			

注記) 1.ホイップアンテナ、送受波器他オプション等は別梱包になります。
OPTIONS, FOR EXAMPLE WHIP ANTENNA, TRANSDUCER ARE SUPPLIED IN OTHER BOX.

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
ハードカバー組品 HARD COVER ASSY.		FP14-02401 004-375-270	1
その他工材 OTHER INSTALLATION MATERIALS			
ケーブル組品MJ CABLE ASSY.		MJ-A3SPF0013-035 000-129-613	1
ケーブル組品MJ CABLE ASSY.		MJ-A6SPF0003-050 000-117-603	1

(略図の寸法は、参考値です。DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

DWG NO. C4395-Z12-A A-2

PACKING LIST

GP-1850DF (E019)

14CF-X-9862-2 1/1

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
ユニット UNIT			
空中線部 ANTENNA UNIT		GPA-019	1
指示器 DISPLAY UNIT		000-142-416 GP-1850DF-E 000-041-495	1
予備品 SPARE PARTS SP14-02501			
ヒューズ FUSE		FG80-A 5A AC125V 000-549-064	3
付属品 ACCESSORIES FP14-02402			
出力マーク(E) OUT PUT MARK LABEL (E)		14-063-1025-1 100-274-611	1
ゴムの足 RUBBER FOOT		TM-166 No. 18 40 000-808-732	2
+プラスティックネジ +TAPPING SCREW		5X16 SUS304 1種 000-805-494	4
+ワッシャー WASHER HEAD SCREW		M4X20 SUS304 000-804-742	6
付属品 ACCESSORIES FP14-02401			

注記) 1.送受波器他オプション等は別梱包になります。
OPTIONS, FOR EXAMPLE WHIP ANTENNA ARE SUPPLIED IN OTHER BOX.

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
ハードカバー組品 HARD COVER ASSY.		FP14-02401 004-375-270	1
その他工材 OTHER INSTALLATION MATERIALS			
ケーブル組品MJ CABLE ASSY.		MJ-A3SPF0013-035 000-129-613	1
ケーブル組品MJ CABLE ASSY.		MJ-A6SPF0003-050 000-117-603	1

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

DWG NO.

C4395-Z08-B







A-3

PACKING LIST

GP-1850D/DF (E/J)



14CF-X-9863-1

1/1

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
ユニット UNIT			
指示器 DISPLAY UNIT		GP-1850D-J	1
予備品 SPARE PARTS			
SP14-02501			
ヒューズ FUSE		FG80-A 5A AC125V	3
付属品 ACCESSORIES			
FP14-02403			
ゴッド RUBBER FOOT		TM-166 No. 18 4個	2
+プラスティックネジ +TAPPING SCREW		000-808-732 5X16 SUS304 1種	4
+ナベネジ WASHER HEAD SCREW		000-805-494 W4X20 SUS304	6
付属品 ACCESSORIES			
FP14-02401			
ハードカバー組品 HARD COVER ASSY.		FP14-02401	1

その他工材 OTHER INSTALLATION MATERIALS

注記) 1.コード末尾に「**」の付いたユニットは代表の型式/コードを表示しています。
 DOUBLE ASTERISK DENOTES COMMONLY USED EQUIPMENT.
 2.送受波器他オプション等は別梱包になります。
 OPTIONS, FOR EXAMPLE WHIP ANTENNA ARE SUPPLIED IN OTHER BOX.
 (略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
ケーブル組品MJ CABLE ASSY.		MJ-A3SPF0013-035	1
ケーブル組品MJ CABLE ASSY.		000-129-613 MJ-A6SPF0003-050	1
		000-117-603	

Connecting DGPS beacon receiver

A DGPS beacon receiver whose output format is RS-232C can be connected to the GP-1850F.

Below is the example of interconnection between the GP-1850F and FURUNO beacon receiver GR-80.








Figure 4-11 Connecting DGPS beacon receiver

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
$L \leq 50$	± 1.5
$50 < L \leq 100$	± 2.5
$100 < L \leq 500$	± 3

表 1 TABLE 1



矢視 A VIEW A





注 記

- 1) 装備ケーブルはサービス時、指示部を前方に十分引き出せるよう余裕を持たせること。
- 2) 取付用ネジはトラスアップネジ呼び径5×16を使用のこと。
- 3) 指定外寸法公差は、表 1 による。
- 4) #印寸法は最小サービス空間とする。


NOTE

1. KEEP ENOUGH CABLE LENGTH BEHIND UNIT.
2. USE $\phi 5 \times 16$ TAPPING SCREW FOR FIXING UNIT.
3. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS.
4. #: RECOMMENDED SERVICE CLEARANCE.


DRAWN Dec 8 '98 K. Kikunishi	TITLE GP-1850/D/F/DF
CHECKED Dec 8 '98 K. Kikunishi	名称 指示部 (ハンガー付)
APPROVED Dec 8 '98 K. Kikunishi	外寸図
SCALE 1/4	NAME DISPLAY UNIT W/ HANGER
MASS 3.0 kg	OUTLINE DRAWING
DWG. No. C4395-001-A	14-063-1000-G1



A部詳細
DETAIL OF 'A'




取付穴寸法 (正面)
CUTOUT DIMENSIONS (FRONT)



寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
$L \leq 50$	± 1.5
$50 < L \leq 100$	± 2.5
$100 < L \leq 500$	± 3

表 1 TABLE 1



取付ネジ断面 (尺度 1/1)
DETAIL FOR FASTENING
(SCALE: 1/1)

注 記

- 1) 装備ケーブルはサービスタブ時、指示部を前方に十分に引き出せるよう余裕を持たせること。
- 2) 取付用ネジは、セムスネジB M4 X 20を使用のこと。壁の厚さ (A) は最小14とする。上記以外の壁に装備する場合、使用するネジの長さは (A+7.3) ± 1.5とする。 (セムスネジBを使用) 筐体にはネジ部を7mm以上入れないこと。 (B ≤ 7)
- 3) 指定外寸法公差は、表1による。
- 4) #印寸法は最小サービスタブ空間とする。


NOTE

1. KEEP ENOUGH CABLE LENGTH BEHIND UNIT.
2. USE $\phi 4 \times 20$ TAPPING SCREWS FOR FIXING THE UNIT. THICKNESS A: $11 \leq A \leq 14$ OR SCREW LENGTH: (A+7.3) ± 1.5. DO NOT FASTEN SCREWS INTO UNIT MORE THAN 7 mm. (B ≤ 7)
3. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS.
4. #: RECOMMENDED SERVICE CLEARANCE.


DRAWN	Jan. 21 '01	I. YAMASAKI	TITLE	GP-1850/D/F/DF
CHECKED	Jan. 22 '01	Y. Kuroki	名称	指示部 (フラッシュマウント)
APPROVED	Jan. 23 '01	S. Yamashita	外寸図	
SCALE	1/4	1/50	NAME	DISPLAY UNIT (FLASH MOUNT)
DWG. No	C4395-002-B		14-063-1100-GI	OUTLINE DRAWING

A) MAST MOUNTING

a) USE MAST MOUNTING KIT GP20-0111.




b) USE A PIPE ONLY.



B) HANDRAIL MOUNTING

USE HANDRAIL MOUNTING BASE No. 13-RG5160 (CODE No. 000-806-114, OPTION).
THE DIAMETER OF THE HANDRAIL MAY BE FROM $\phi 19\text{mm}$ TO $\phi 32\text{mm}$.




NOTE 1 FASTEN PIPE (ANTENNA BASE) TO ANTENNA UNIT FIRST THEN FIX THEM TO MAST OR HANDRAIL.
2. WHEN FIXING ANTENNA, TURN PIPE OR ANTENNA BASE, NOT THE ANTENNA.
TURNING THE ANTENNA MAY TWIST THE CABLE AND PLACE STRESS ON CONNECTOR.

C) ANTENNA BASE MOUNTING

USE OPTIONAL ANTENNA BASE No. 13-QA330/QA310.


INCLINATION	-5° - 33°	32° - 65°	65° - 98°
MOUNTING METHOD			
ANTENNA BASE TYPE	RIGHT ANGLE ANTENNA BASE No. 13-QA330	L-TYPE ANTENNA BASE No. 13-QA310	4-M5 COUNTERSUNK
CODE No.	000-803-239	000-803-240	

MOUNTING DIMENSIONS OF ANTENNA BASE



MOUNTING LOCATION

THE FIGURE BELOW SHOWS THE RECOMMENDED SEPARATION DISTANCES FROM OTHER ANTENNAS TO AVOID MUTUAL INTERFERENCE.




* DISTANCE DEPENDS ON MAST DIAMETER OF "a"

DIA. OF "a"	DISTANCE (MIN.)
10 cm	1.5 m
30 cm	3 m

DIMENSION (mm)	TOL. (mm)
L ≤ 50	±1.5
50 < L ≤ 100	±2.5
100 < L ≤ 500	±3

TABLE 1

THREAD DIMENSION (FOR PIPE)
THREAD TYPE: 1x14UNS1B
THREADS PER INCH (25.4mm): 14
PITCH: 1.8143 mm
THREAD LENGTH: 19 mm OR MORE
PITCH DIAMETER: 24.17 mm



NOTE
1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS

DRAWN	17.99 T. YAMASAKI	TITLE	GPA-017
CHECKED	17.99 K. KAWASAKI	名称	空中線部
APPROVED	17.99 K. KAWASAKI	外寸図	
SCALE	1/1	NAME	ANTENNA UNIT
DWG. No.	E4384-G04-F	OUTLINE DRAWING	

a) USE MAST MOUNTING KIT CP20-01111.

b) USE A PIPE ONLY.



USE HANDRAIL MOUNTING BASE No. 13-RC5160 (CODE No. 000-806-114, OPTION).

USE HANDRAIL MOUNTING BASE No. 13-RC5160 (CODE No. 000-806-1)
THE DIAMETER OF THE HANDRAIL MAY BE FROM $\phi 19\text{mm}$ TO $\phi 32\text{mm}$.



NOTE 1. FASTEN PIPE (ANTENNA BASE) TO ANTENNA UNIT FIRST THEN FIX THEM TO WAST OR HANDRAIL.

2. WHEN FIXING ANTENNA, TURN PIPE OR ANTENNA BASE; NOT THE ANTENNA.

TURNING THE ANTENNA MAY TWIST THE CABLE AND PLACE STRESS ON CONNECTOR


USE OPTIONAL ANTENNA BASE No. 13-QA330/QA310.

MOUNTING DIMENSIONS OF ANTENNA BASE

Technical drawing of a shaft-hub assembly. The shaft is on the left, and the hub is on the right. The hub has a 4-H5 countersunk hole. The hole is shown with concentric circles. The outer circle has a diameter of 61, and the inner circle has a diameter of 76. The hole is 15 degrees wide. The shaft has a diameter of 76. The hub has a diameter of 90.

THE FIGURE BELOW SHOWS THE RECOMMENDED SEPARATION DISTANCES

THE FIGURE BELOW SHOWS THE RECOMMENDED SEPARATION DISTANCES FROM OTHER ANTENNAS TO AVOID MUTUAL INTERFERENCE.



* DISTANCE DEPENDS ON MAST DIAMETER OF "a"

DIA. OF 's'	DISTANCE (MIN)
10 cm	1.5 m
30 cm	3 m

THREAD TYPE: 1x14JNS1B

THREADS PER INCH (25.4mm) : 14

PITCH: 1.8143 mm

THREAD LENGTH: 19 mm OR MORE

PITCH DIAMETER: 24.17 mm

TABLE 1

DIMENSION (mm)	TOL. (mm)
$L \leq 50$	± 1.5
$50 < L \leq 100$	± 2.5
$100 < L \leq 500$	± 3





TABLE 2

TYPE	CABLE LENGTH(m)	PLAG	MASS (kg)
GPA-018	10	TNC-P-3	0.79
GPA-018S	0.2	TNC-J-3	0.35


NOTE

1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS

DRAWN <i>June 17 '99</i> TRAMASAKI CHECKED <i>June 17 '99</i> KENJUTAKI APPROVED <i>June 17 '99</i> KENJUTAKI	TITLE 名称 空中線部 外寸図 NAME ANTENNA UNIT OUTLINE DRAWING	GPA-018/018S
SCALE 1/2	MASS TABLE 2	DRAWING No. F4385-G01-6

A) Mast mounting

Use mast mounting kit CP20-01111.



NOTES


- 1) Fasten pipe to antenna first then fix them to mast.
- 2) When fixing antenna to pipe, turn pipe; not the antenna. Turning the antenna may twist the cable and place stress on connector.

B) Antenna base mounting

Use optional antenna base No.13-QA300 or No.13-QA310.

Inclination -5° to 33°	32° to 65°	65° to 98°
Right angle antenna base No.13-QA330 (code No. 000-803-239)	L-type antenna base No.13-QA310 (code No. 000-803-240)	

C) Handrail mounting




Use handrail mounting base No.13-RC5160 (Code No. 000-861-114, option). The diameter of the handrail may be from $\phi 19$ mm to $\phi 32$ mm.

NOTES

- 1) Fasten antenna base to antenna first then fix them to handrail.
- 2) When fixing antenna to antenna base, turn antenna base; not the antenna. Turning the antenna may twist the cable and place stress on connector.



Mounting location

The figure below shows the recommended separation distances from other antennas to avoid mutual interference.



- * Distance depends on mast diameter of ③
- ③ mast diameter 10cm : minimum 1.5m
- ③ mast diameter 30cm : minimum 3m

Mounting dimensions of antenna base (option)




Thread Type	Threads per 25.4 mm (1 inch)	Pitch	Thread Length	Pitch Diameter
1 X 14UNS1B	14	1.8143 mm	15.17 mm	24.17 mm

DRAWN	APPROVED	CHECKED	TYPE	NAME	DATE
APPROVED	APPROVED	APPROVED	GP-50MK3	GP-016	GP-016
APPROVED	APPROVED	APPROVED	GP-8000M2	GP-016	GP-016
APPROVED	APPROVED	APPROVED	GP-1600/F	GP-016	GP-016
APPROVED	APPROVED	APPROVED	GP-8000M2	GP-016	GP-016
APPROVED	APPROVED	APPROVED	GP-3100M2	GP-016	GP-016
APPROVED	APPROVED	APPROVED	GP-80	GP-016	GP-016
SCALE	1/1	MASS	0.1 kg	APPLICABLE TO:	ANTENNA UNIT
DATE	1/1	DATE	1/1	DATE	1/1
E4374-G04-F					
OUTLINE DRAWING					


A) マストへの取付け

USE MAST MOUNTING KIT 0220-0111.
a) マスト取付金具0220-0111(工事材料)でマストに固定する。
b) パイプのみを使うとき
USE A PIPE ONLY.



B) スタンションやパルピットにつけるととき


USE HANDRAIL MOUNTING BASE No. 13-RC5160 (CODE No. 000-806-114, OPTION)
THE DIAMETER OF THE HANDRAIL MAY BE FROM $\phi 19$ mm TO $\phi 32$ mm.
B) スタンションやパルピットにつけるととき HANDRAIL MOUNTING
レール用アンテナベース No. 13-RC5160 (取付可能レール直径: $\phi 19 \sim \phi 32$)
(コード番号: 000-806-114)



注記 1) パイプ(アンテナベース)はアンテナユニットにねじ込んだ後に固定する。
2) アンテナを固定するときパイプ (アンテナベース) をアンテナにねじ込むこと。
アンテナ側をねじるとコネクター部やケーブルに無理がかり、故障の原因となる。
NOTE 1. FASTEN PIPE (ANTENNA BASE) TO ANTENNA UNIT FIRST THEN FIX THEM TO MAST OR HANDRAIL.
2. WHEN FIXING ANTENNA, TURN PIPE OR ANTENNA BASE; NOT THE ANTENNA.
TURNING THE ANTENNA MAY TWIST THE CABLE AND PLACE STRESS ON CONNECTOR.


C) 取付ける場所が傾斜しているとき

アンテナベース基部
MOUNTING DIMENSIONS OF ANTENNA BASE
オプションのアンテナベースを使う。
USE OPTIONAL ANTENNA BASE No. 13-QA330/QA310.



取付場所

THE FIGURE BELOW SHOWS THE RECOMMENDED SEPARATION DISTANCES FROM OTHER ANTENNAS TO AVOID MUTUAL INTERFERENCE.
他の機器のアンテナから下の図の距離以上離す。




*支柱の太さにより変わる。
* DISTANCE DEPENDS ON MAST DIAMETER OF "a".

支柱径 DIA. OF "a"	推奨する距離 DISTANCE (MIN)
10 cm	1.5 m
30 cm	3 m

寸法区分 (mm)	公差 (mm)	TOL.
$L \leq 50$	± 1.5	
$50 < L \leq 100$	± 2.5	
$100 < L \leq 500$	± 3	

表 1 TABLE 1

1-14UNS1B
ねじ山数 (25.4mmにつき) : 14
ねじ山径: 1.8143 mm (1 INCH) : 14
ネジの長さ: 24.17 mm
オネジの径: 24.17 mm
THREAD PER 25.4mm (1 INCH) : 14
PITCH: 1.8143 mm
THREAD LENGTH: 15.17 mm
PITCH DIAMETER: 24.17 mm




注記: 指定外の寸法公差は表 1 による

NOTE: TABLE 1 INDICATES TOLERANCE OF DIMENSIONS.

型式 TYPE	ケーブル長 (m) CABLE LENGTH	プラグ PLUG	質量 (kg) MASS
GPA-019	10	TNC-P-3	1.0
GPA-019S	0.2	TNC-J-3	0.54

表 2 TABLE 2

ORGAN	DESIGNED	APPROVED	SCALE	DWG. No.	TITLE
17199 K. KAWAKI	17199 K. KAWAKI	17199 K. KAWAKI	1/2	C4400-G01-D	GPA-019/019S
					空中線部
					外寸図
					NAME
					ANTENNA UNIT
					OUTLINE DRAWING




ケーブル導入口
CABLE ENTRY

24VDC
OUTPUT
(2.5A max)

AC INPUT

入力電圧に応じて接続を変更して下さい。
CHANGE TAP CONNECTIONS DEPENDING ON SUPPLY VOLTAGE.

	AC100V	AC110/ 115V	AC220V	AC230V
※1	(A)	(A)	(B)	(B)
※2	(C)	(D)	(D)	(D)






DRAWN Sep. 14 '01 CHECKED APPROVED SCALE 1/2 DWG.No.	TYAMASAKI Y.K.I. Y.K.I. MASS 3 ±10% kg C5003-034-E	TITLE PR-62 名称 整流器 外寸図 NAME RECTIFIER OUTLINE DRAWING
--	--	--

ホイップアンテナ
1.2m WHIP ANTENNA
(OPTION FOR EXPORT)
FAW-1.2

空中線部
ANTENNA UNIT

いすれかを選擇 *5
SELECT ONE TYPE



注記

- * 1) 現地手配
- * 2) コネクターは工場にて取付済み
- * 3) オプション
- * 4) オプションの変換ケーブル組品が必要。
- * 5) 空中線部の選択は表 1 による。
- * 6) カレントループ、RS-422の接続にはオプションのレベル変換器が必要。







NOTE

- * 1. LOCAL SUPPLY.
- * 2. FITTED AT FACTORY.
- * 3. OPTION
- * 4. THREE-WAY CONVERSION CABLE NEEDED (OPTION).
- * 5. REFER TO TABLE 1 FOR ANTENNA UNIT SELECTION.
- * 6. OPTIONAL LEVEL CONVERTER REQUIRED FOR CURRENT LOOP OR RS422 OUTPUT.

表 1. TABLE 1

型式	空中線部
TYPE	ANTENNA UNIT
GP-1850/F	GPA-017
	GPA-016
GP-18500/DF	GPA-018/018S
	GPA-019/019S

GP-1850/D/F/DF
DISPLAY UNIT
指示器



4

3

2

B6 CHASSIS

B3 ANLG
14P0313 *

* : A → GP-1850/D-E/J
B → GP-1850F/DF-E/J

B1 MAIN
14P0311 *

80-5072-230-981-883
J5 80-5072-230-981-883

B2 PNL
14P0312

J1 80-5280-528-330-800

* : A → GP-1850/D-E
B → GP-1850F/DF-E
C → GP-1850/D-J
D → GP-1850F/DF-J

(GP-1850F/DF ONLY)

(GP-1850F/DF ONLY)

B5 LCD
EDTCA0300F

J4 86-5212-428-749-888

J5 A15A38ND

1 GND
2 12V.P
3 12V.P
4 12V.P
5 12V.P
6 12V.P

J5 A15A38ND

1 GND
2 12V.P
3 12V.P
4 12V.P
5 12V.P
6 12V.P

J5 A15A38ND

1 GND
2 12V.P
3 12V.P
4 12V.P
5 12V.P
6 12V.P

J5 A15A38ND

1 GND
2 12V.P
3 12V.P
4 12V.P
5 12V.P
6 12V.P

J5 A15A38ND

1 GND
2 12V.P
3 12V.P
4 12V.P
5 12V.P
6 12V.P

J5 A15A38ND

1 GND
2 12V.P
3 12V.P
4 12V.P
5 12V.P
6 12V.P

J5 A15A38ND

1 GND
2 12V.P
3 12V.P
4 12V.P
5 12V.P
6 12V.P

J5 A15A38ND

1 GND
2 12V.P
3 12V.P
4 12V.P
5 12V.P
6 12V.P

J5 A15A38ND

1 GND
2 12V.P
3 12V.P
4 12V.P
5 12V.P
6 12V.P

J5 A15A38ND

1 GND
2 12V.P
3 12V.P
4 12V.P
5 12V.P
6 12V.P

J5 A15A38ND



1 GND
2 12V.P
3 12V.P
4 12V.P
5 12V.P
6 12V.P

J5 A15A38ND

1 GND
2 12V.P
3 12V.P
4 12V.P
5 12V.P
6 12V.P

MINI CARD
BN-5S02MF4F0
(14S4498)

OPTION




DRAWN Dec 22 97 T. Yamashita	CHECKED Dec 22 97 K. Kusunoki	APPROVED Dec 22 97 K. Kusunoki	SCALE 1/1	MASS kg	DWG NO. C4395-K01-D	14-063-0001-3	SCHEMATIC DIAGRAM	FURUNO ELECTRIC CO., LTD.
TYPE GP-1850/D/F/DF			名称 指示器 (総合)			回路図		
GP-1850DF GP-1850F GP-1850/D GP-1850F/D			BLOCK NO.			DISPLAY UNIT (GENERAL)		
APPLICABLE TO:			MODEL			SCHEMATIC DIAGRAM		

4

3

2

1



NAME	TYPE	NAME	TYPE
Dec 17 '88 T. Kikuchi	14P0313	Dec 17 '88 T. Kikuchi	14P0313
Dec 17 '88 K. Kikuchi	741850SER	Dec 17 '88 K. Kikuchi	741850SER
Dec 17 '88 K. Kikuchi	GP1850SER	Dec 17 '88 K. Kikuchi	GP1850SER
SCALE	1/1	SCALE	1/1
APPLICABLE TO:	KG	APPLICABLE TO:	KG
UWG NO.	C4395-K03-A	UWG NO.	C4395-K03-A
	14-063-0004-1		14-063-0004-1
	SCHEMATIC DIAGRAM		SCHEMATIC DIAGRAM
	FURUNO ELECTRIC CO., LTD		FURUNO ELECTRIC CO., LTD