10 ф

Owner's Operating Service Instruction Manual

- ASSEMBLY
- OPERATION
- REPAIR PARTS

Model Nos. 136-430A 136-435A

30" RIDING MOWERS

IMPORTANT

It is suggested that this manual be read in its entirety before attempting to assemble or operate. Keep this manual in a safe place for future reference and for ordering replacement parts.

This unit is shipped WITHOUT GASOLINE or OIL. After assembly, see operating section of this manual for proper fuel and amount.

SAFE OPERATION PRACTICES FOR RIDING VEHICLES

- 1. Know the controls and how to stop quickly— READ THE OWNER'S MANUAL.
- 2. Do not allow children to operate vehicle. Do not allow adults to operate it without proper instruction.
- 3. Do not carry passengers. Keep children and pets a safe distance away.
- 4. Clear work area of objects which might be picked up and thrown.
- 5. Disengage all attachment clutches and shift into neutral before attempting to start engine.
- 6. Disengage power to attachment(s) and stop engine before leaving operator position.
- Disengage power to attachment(s) and stop engine before making any repairs or adjustments
- 8. Disengage power to attachment(s) when transporting or not in use.
- Take all possible precautions when leaving vehicle unattended such as disengaging power-take-off, lowering attachments, shifting into neutral, setting parking brake, stopping engine and removing key.
- 10. Do not stop or start suddenly when going uphill or downhill. Mow up and down face of steep slopes; never across the face.
- Reduce speed on slopes and in sharp turns to prevent tipping or loss of control. Exercise extreme caution when changing direction on slopes.
- 12. Stay alert for holes in terrain and other hidden hazards.
- 13. Use care when pulling loads or using heavy equipment.
 - A. Use only approved drawbar hitch points.
 - B. Limit loads to those you can safely control.
 - C. Do not turn sharply. Use care when backing.
 - D. Use counterweight(s) or wheel weights when suggested in owner's manual.
- 14. Watch out for traffic when crossing or near roadways.
- 15. When using any attachments never direct discharge of material toward bystanders nor allow anyone near vehicle while in operation.

- 16. Handle gasoline with care—it is highly flammable.
 - A. Use approved gasoline container.
 - B. Never remove cap or add gasoline to a running or hot engine or fill fuel tank indoors. Wipe up spilled gasoline.
 - C. Open doors if engine is run in garage—exhaust fumes are dangerous. Do not run engine indoors.
- 17. Keep the vehicle and attachments in good operating condition, and keep safety devices in place. Use guards as instructed in owner's manual.
- 18. Keep all nuts, bolts, and screws tight to be sure the equipment is in safe working condition.
- 19. Never store the equipment with gasoline in the tank inside a building where fumes may reach an open flame or spark. Allow engine to cool before storing in any enclosure.
- 20. To reduce fire hazard keep engine free of grass, leaves or excessive grease.
- 21. The vehicle and attachments should be stopped and inspected for damage after striking a foreign object, and the damage should be repaired before restarting and operating the equipment.
- 22. Do not change the engine governor settings or overspeed the engine.
- 23. When using the vehicle with mower, proceed as follows:
 - (1) Mow only in daylight or in good artificial light.
 - (2) Never make a cutting height adjustment while engine is running if operator must dismount to do so.
 - (3) Shut engine off when removing grass catcher and/or unclogging chute.
 - (4) Check blade mounting bolts for proper tightness at frequent intervals.
- 24. Check grass catcher bags frequently for wear or deterioration. Replace with new bags for safety protection.
- 25. Look behind to make sure the area is clear before placing the transmission in reverse and backing up.

2

INDEX

Safe Operation Practices	Troubleshooting Chart Recoil Start	16
ndex and Assembly Instructions	Troubleshooting Chart Electric Start	17
Activating the Battery4	Illustrated Parts Rider	18
Battery Warranty5	Parts List for Rider	19
Controls6	Illustrated Parts Control Linkages	20
Operating Instructions8	Parts List for Control Linkages	21
Maintenance and Adjustments9	Illustrated Parts Frame	22
Belt Removal	Parts List for Frame	23
_ubrication11	Illustrated Parts Deck and Belt System	24
Electrical Systems	Parts List for Deck and Belt System	25
Schematic for Recoil Start12	Battery Box Breakdown	26
Schematic for Electric Start	Deck Linkage	27
Transmission Breakdown14	Parts Information	
Differential Breakdown15		

ASSEMBLY

GRASS CATCHER Model No. 196-015A is available as optional equipment for the mowers shown in this manual.



1. The mower should not be operated without the entire grass catcher or chute deflector in place.



Under normal usage bag material is subject to wear, and should be checked periodically. Be sure any replacement bag complies with the mower manufacturer's recommendations.

For replacement bags, use only factory authorized replacement bag No. 764-0121.



After striking a foreign object, stop the engine. Remove wire from spark plug, thoroughly inspect the mower for any damage, and repair the damage before restarting and operating the mower.



Reference to right-hand or left-hand side of machine is from the driver's seat facing forward.

Your mower is shipped assembled except for the steering wheel and seat (and battery on the electric start model.)

TIRE PRESSURE

FOR SHIPPING PURPOSES, THE TIRES ON YOUR UNIT MAY BE OVER-INFLATED. TIRE PRESSURE SHOULD BE REDUCED BEFORE UNIT IS PUT INTO OPERATION. PRESSURE SHOULD BE APPROXIMATELY 15 P.S.I. EQUAL TIRE PRESSURE SHOULD BE MAINTAINED ON ALL TIRES. MAXIMUM TIRE PRESSURE IS 30 P.S.I.

STEERING WHEEL ASSEMBLY See figure 1.

Step 1. Line up the hole in the steering column and the hole in the tubing assembly and drive in the roll pin with a hammer.



It may be necessary to use a drift to line up the holes.

- Step 2. Slide the spacer over the tubing assembly until it lays flush against the steering box.
- Step 3. Place the steering wheel on the tubing shaft.
- Step 4. Secure in place with believille washer and hex nut.
- Step 5. Put on steering wheel cap by hand.




FIGURE 1. STEERING WHEEL ASSEMBLY

Step 6. Place the seat in desired hole on seat bracket. Secure with hex nut and lockwasher. See figure 2.




FIGURE 2. SEAT ASSEMBLY

Step 7. Check ALL nuts and bolts for correct tightness.

BATTERY INFORMATION FOR ELECTRIC START MODELS



- A. Battery acid must be handled with great care as it will blister the skin and damage clothing. It is advisable to wear goggles, rubber gloves, and a protective apron when working with it.
- B. Neutralize acid spilled on clothing with dilute ammonia water or a water solution of baking soda. If acid gets on clothes, dilute it with clean water first, then neutralize.
- C. If for any reason acid should be spattered in the eyes, wash it out immediately with clean cold water. Seek medical aid if discomfort continues.
- D. Since battery acid is corrosive to metals, do not pour into any sink or drain. Rinse empty electrolyte containers and mutilate before discarding.



BATTERIES CONTAIN SULFURIC ACID AND MAY CONTAIN EXPLOSIVE GASES (when electrolyte has been added)

- A. Keep sparks, flame, cigarettes away.
- B. Hydrogen gas is generated during charging and discharging.
- C. Ventilate when charging or using in enclosed space.
- D. When using a charger—to avoid sparks, NEVER connect or disconnect charger clips to battery while charger is turned on.
- E. Always shield eyes, protect skin and clothing when working near batteries.

A. Activating the Battery

- Place battery to be filled on bench or workbench. NEVER activate battery in unit. Remove vent caps from all cells.
- Fill each cell carefully using battery grade 1.250-1.265 specific gravity. Sulfuric acid to be 3/8" above the top of the separators or to the split ring.
- 3. Allow battery to set for 20 minutes to ½ hour. Add additional acid if necessary to bring it up to the proper level.
- 4. Replace the vent caps.

5. The battery can now be charged after the 20 minutes setting period. Battery can be SLOW CHARGED (DO NOT FAST CHARGE) at a maximum bench rate of 4-5 amperes until the specific gravity reading is 1.265-1.275. A charging rate in excess of this will buckle and warp the positive plates and perforate the separators. If electrolyte bubbles violently while charging, reduce charging rate until excessive bubbling action subsides, then continue charging until specific gravity is reached.



After the battery has been in service, add only approved water. DO NOT ADD ACID.

B. To Install Battery

To install the battery in this unit, refer to next column.

C. Maintenance

- Check periodically (every two weeks or before and after charging) to be sure electrolyte level is 9/16" above separator plates. Add only distilled water or good quality drinking water. NEVER add additional acid or other chemicals to battery after initial activation.
- 2. The battery should be checked with a hydrometer after every 25 hours of operation. If the specific gravity is less than 1.225 remove battery and recharge.
- Coat the terminals and exposed wiring with a thin coat of grease or petroleum jelly for longer service and protection against electrolyte corrosion.
- 4. The battery should be kept clean. Any deposits of acid should be neutralized with soda and water. Be careful not to get this solution in the cells.

D. Storage

- Charge battery using normal methods. NEVER store discharged battery as it will not recover.
- 2. Store in cold, dry place.
- Recharge battery whenever the specific gravity is less than 1.225 before returning to service or every two months, whichever occurs first.

E. Common Causes For Battery Failure Are:

- 1. Overcharging
- 2. Undercharging
- 3. Lack of water
- 4. Loose hold downs and/or corroded connections
- 5. Excessive loads
- 6. Battery electrolyte substitutes
- 7. Freezing of electrolyte



THESE FAILURES DO NOT CONSTITUTE WARRANTY.

LIMITED WARRANTY

For ninety (90) days of original retail purchase, the battery carries a limited warranty against faulty material or workmanship by the battery manufacturer.

INSTALLING THE BATTERY (Electric Start Models Only)

See figure 3.

- Step 1. Tip the seat bracket forward to expose the battery box.
- Step 2. Remove screw (A) and lockwasher (B).




FIGURE 3. INSTALLING THE BATTERY

- Step 3. Lift out the battery box bracket.
- Step 4. Place the battery in the battery box with the positive terminal (+) to the front of the riding mower.

- Step 5. Attach the large red wire from the solenoid and the small red wire to the positive (+) terminal of the battery with a 1/4" screw (E), washer (D) and nut (C).
- Step 6. Attach the large red wire from the ground (-) to the negative (-) terminal of the battery with a 1/4" screw (E), washer (D) and nut (C).
- Step 7. Replace the battery box bracket with screw (A) and washer (B). See figure 3.

CONTROLS See figure 5.

This manual should be read in its entirety before you operate your Riding Mower. The more you know and understand about the machine and its operation, the better job it will do for you. While reading the manual, compare the illustrations with your mower to familiarize yourself with the locations of various controls, lubrication points, attachments and adjustment features.

IGNITION KEY

Recoil Model. The key must be turned to the ON position before the recoil handle is pulled to start the engine. Remove the key when the mower is not in use. Turn the key to the left (to the OFF position) to stop the engine.

LIFT AND DISENGAGEMENT LEVER

The lift and disengagement lever is used to raise and lower the cutting deck, set the cutting height, and disengage the cutting blades.

Move the lever to the left and pull the lever all the way back and lock it to disengage the blades. The lever may be set in any one of the five cutting height positions. This lever works in conjunction with the deck wheel adjusters.

Electric Model. The key must be turned to the START position to start the engine. After the engine is running let the key return to the ON position. Remove the key when the mower is not in use. Turn the key to the OFF position to stop the engine.

Study the operating instructions and safety precautions thoroughly to insure proper functioning of your mower and to prevent injury to yourself and others. Be sure to save this manual for future reference.

THROTTLE CONTROL

The throttle control is used to regulate the engine speed and to activate the choke on the engine. To get the maximum efficiency on cutting, the throttle should be in the FAST position when operating the mower. Pushing the throttle all the way forward, past FAST will choke the engine.

INTERLOCKS (Not Shown)

An interlock safety switch is located on the clutch pedal and the lift and disengagement lever.

The clutch pedal must be depressed all the way down (the speed control handle can be pulled back to lock it down) and the lift and disengagement lever must be in the STOP position (all the way back) before the engine can be started. Failure to follow these instructions will prevent starting.

On the recoil start model, the ignition will be grounded. On the electric start model, the starter will not run.

GEAR SHIFT LEVER

The gear shift lever has three positions, FORWARD, NEUTRAL and REVERSE. The clutch pedal must be depressed and the riding mower must not be moving when shifting gears. Shifting gears may be difficult when the speed control handle is all the way back. Do not force the shift lever. Release the clutch pedal slightly to line up the shifting collar in the transmission. Then try to shift the gears.

BRAKE

To operate the brake depress the right pedal all the way down. To lock the brake in the park position, pivot the pedal forward with your foot as you depress it. It will stay in the depressed position. To release the parking brake, pivot the pedal to the rear.

DECK WHEEL ADJUSTERS

Always set both deck wheels in the same relative position. Set these wheels after the Lift and Disengagement Lever is set. The wheels should just clear the ground. This will prevent scalping the grass.

CLUTCH PEDAL

The clutch pedal on the left side when depressed reduces the ground speed. It disengages the engine from the transmission when depressed all the way down. It can be held in the disengaged position by pulling the Speed Control Lever into the locked position (all the way back). To stop the mower, depress the Clutch and Brake Pedals.

SPEED CONTROL LEVER. See figures 4 and 5.

The Speed Control Lever can be used as a hand control for the clutch pedal. It is also used to lock the clutch pedal in the disengaged position by pulling it all the way back towards the operator and locked to the right.

The control lever allows you to regulate the maximum ground speed of the riding mower by setting the control lever in any one of four settings.



The further forward the control lever is set, the faster the ground speed.





FIGURE 4. SPEED CONTROL LEVER

STOPPING

Engine—Turn the ignition key to the left to the OFF position.

Rider—Depress the clutch and brake pedals.

Blades—Pull the lift and disengagement lever all the way back and lock it.



OPERATING INSTRUCTIONS

CAUTION

- 1. Keep all shields and guards in place.
- 2. Before leaving operator's position:

Shift controls into neutral Set parking brake Disengage attachment drive Shut off engine

Remove ignition key

- 3. Wait for all movement to stop before servicing
- 4. Keep people and pets a safe distance away from machine.



Parking Brake MUST be disengaged before unit is put into motion.



NOTE

Unit is equipped with separate brake and clutch pedals. To efficiently stop, it is necessary to disengage the clutch when applying the brakes.

STARTING THE ENGINE

- 1. Be sure the crankcase is filled with oil as recommended in the engine manual. Put regular gasoline in the gasoline tank.
- 2. Be sure the fuel shut off valve located on the carburetor is open.
- 3. Attach the wire to the spark plug.
- 4. Depress the clutch pedal and lock it down with the speed control lever.
- Pull the lift and disengagement lever all the way back to the disengaged position and lock it.
- 6. Set the throttle control lever in the CHOKE position.
- Recoil Model. Turn the ignition key to the ON position. Twist the recoil starter handle until it is free and pull it with a quick steady motion. After the engine starts, return the recoil starter handle. Twist it until it locks. See figure 6.



If these instructions are not followed the engine will stop running when you engage the clutch or blades are engaged.



FIGURE 6. RECOIL STARTER

Electric Start Model. Turn the ignition key to the START position. When the engine starts let the key return to the ON position.

Slowly return the throttle to the running position as soon as the engine starts.

8. To stop either model, turn the ignition key to the OFF position. Remove the key when the rider is not in use.

PUTTING THE RIDING MOWER IN MOTION

- 1. Advance the throttle control from 3/4 to full throttle to prevent strain on the engine and to operate the cutting blades.
- Set the stop lever in the slowest position.
- Hold the clutch pedal down with your left foot and release the speed control lever.
- 4. Place the gear shift lever in either the FORWARD or REVERSE position.
- 5. Slowly release the clutch pedal.
- 6. To stop, depress the clutch and the brake pedals.
- The blades can be engaged while moving or while standing still. Move the lift and disengagement lever forward slowly until the blades are running.

After learning to control the machine at slow speeds, set the stop lever in a faster position. The unit will maintain the highest speed set without touching the controls. To slow down, depress the clutch pedal until the speed desired is obtained. When the clutch pedal is released, the riding mower will operate at the highest speed set on the stop lever.

MAINTENANCE AND ADJUSTMENTS

THROTTLE CONTROL

To Check Operation:

- 1. Remove air cleaner.
- 2. Move throttle control lever to CHOKE position. The carburetor choke should be closed.
- 3. Move throttle control lever to STOP position. Lever should make good contact with stop switch.

To Adjust: See figure 7.

Place throttle control lever in FAST (high speed) position. Loosen control casing clamp screw "B". Move control casing "A" and wire until lever "D" touches choke operating link at "C". Tighten casing clamp screw "B". Replace air cleaner.





FIGURE 7. THROTTLE ADJUSTMENT CARBURETOR ADJUSTMENT

Carburetors are adjusted at the factory and normally do not need adjustment unless they have been disassembled.

Initial Adjustment After Re-assembly. See figure a

Turn needle valve clockwise until it just closes.



Valve may be damaged by turning it too far. Now open needle valve 1-1/8 turns counterclockwise. Close idle valve in same manner and open 1-1/8 turns. This initial adjustment will permit the engine to be started and warmed up prior to final adjustment.

Final Adjustment. See figure 8.

Turn needle valve in until engine misses (lean mixture). Then turn it out past smooth operating point until engine runs unevenly (rich mixture). Now turn needle valve to the mid-point between rich and lean so the engine runs smoothly.

Hold throttle at idle position and set idle speed adjusting screw until fast idle is obtained (1750 RPM). Hold throttle in idle position and turn idle valve in (lean) and out (rich) until engine idles smoothly. Then reset idle speed adjusting screw so that engine idles at 1750 RPM. Release throttle—engine should accelerate without hesitation or sputtering. If engine does not accelerate properly the carburetor should be re-adjusted to a slightly richer mixture.




FIGURE 8. CARBURETOR ADJUSTMENT

CHAIN ADJUSTMENT

After the first five hours of operation the initial slack should be removed from the chain. The chain should be tight enough so that it deflects approximately ½" when it is depressed with the thumb.

To Adjust:

The adjusting bolt is located under the frame, above the cutting deck on the right side of the mower.

Turn the adjusting bolt clockwise with an open end wrench until the chain reaches the proper tension.



If the transmission mounting plate will not slide forward to adjust the chain tension, it may be necessary to loosen the four nuts mounting the transmission to the frame.

To adjust the brake, tighten the locknut one half turn and then test the brakes. Repeat if necessary.

The brake is located by the right rear wheel inside the frame.




FIGURE 9. BRAKE ADJUSTMENT

BLADES



Disconnect the spark plug wire and remove the ignition key before removing the blades.

Sharp and balanced blades are essential for efficient mowing and long mower and engine life. When sharpening blades, file equal amounts of metal from each side. The blades should be balanced before they are reinstalled. An unbalanced blade will cause excessive vibration and undue wear on the mower and the engine. When reassembling, all parts must be installed in the proper order and fastened securely.

Remove the 3/8" bolt and lockwasher. Pull the blade and adapter off the mower deck. To remove the adapter from the blade, remove the two 5/16" bolts, lockwashers and nuts. See figure 11.




FIGURE 10. BLADE REMOVAL

MOWER DECK

The underside of the mower deck should be cleaned after each period of use as grass clippings, leaves, dirt and other matter will accumulate. This accumulation of grass clippings, etc., is undesirable as it will invite rust and corrosion and may cause an uneven discharge of grass clippings at the next mowing.

The deck may be cleaned by tilting the mower on its left side. Scrape clean with a suitable tool or by washing with a stream of water from a garden hose. Be sure to disconnect the spark plug wire and ground it while performing this maintenance.

PREPARING FOR BELT REMOVAL

- 1. To prevent gasoline from leaking from the engine, remove the fuel tank cap, place a piece of thin plastic over the neck of the fuel tank and screw on the cap.
- 2. Disconnect the spark plug wire and ground it against the engine.



If the unit is equipped with a battery, continue with step 3.

3. Remove the battery to prevent acid from leaking.



Disconnect the negative terminal first and connect last when installing the battery.

BELT REMOVAL. See figure 11.

To remove either or both belts:

- 1. Place the speed control lever in the locked position.
- 2. Move the lift and disengagement lever into the disengaged position.
- 3. Remove the two rear hex nuts on the engine bolts to remove the engine belt guard and slide the guard away from the chain to remove it
- 4. Lower the cutting deck to its lowest position.
- 5. Remove the blade drive belt from the engine pulley.



The blade drive belt need not be removed. Go to Step 8.

- 6. Remove the deck belt quards.
- 7. Remove and replace the belt.

To remove the variable speed belts:

- 8. Remove the variable speed pulley by removing the center hex nut and lockwasher.
- 9. Remove the transmission pulley by removing the hex nut and washer.
- 10. The belts can now be removed.




FIGURE 11. BELT REMOVAL

LUBRICATION


- **1. Engine.** Maintain the engine oil according to the engine manual.
- 2. Bearings. The following bearings are oil impregnated and do not require lubrication, however, their normal life can be extended by lubricating them once a season with a light, non-detergent oil.
 - A. King Pin Bearings (total 4 bearings)
 - B. Rear Axle Bearings (total 3 bearings)
 - C. Front Wheel Bearings (total 4 bearings)
 - D. Deck Wheel Bearings (total 4 bearings)
- 3. Throttle Control and Cable. Wipe oiled rag along entire length of cable.

Chain. Wipe oiled rag along entire length of chain.



Under extremely dusty conditions do not oil the chain.

- 5. Linkage. Oil all deck linkage and height adjustment linkage.
- 6. Transmission. Lubricated at the factory, does not require checking. Lubricate with 5 oz. of grease, high temp. 450°F, if disassembled.
- Differential. Lubricated at the factory, does not require checking. Lubricate with 2 oz. of grease, high temp. 450°F if disassembled. If ordered from the factory use Part No. 737-0120.




SCHEMATIC FOR ELECTRICAL SYSTEM

PARTS LIST FOR SCHEMATIC MODEL 136-430A

REF. NO.	1	DESCRIPTION				
	725-0269 725-0266 725-0281 712-0121 710-0425 736-0338 732-0257	Wire Harness Hex Nut #10-24 Truss Mach. Scr. #10-24 x .62 Fiber Washer Switch Spring	de deservações de la companya de la			
8	736 - 0237	Internal L-Wash, % I.D.				


136-435A



SCHEMATIC FOR ELECTRIC START MODEL

PARTS LIST OF SCHEMATIC FOR MODEL 136-435A

REF. PART NO. NO.		DESCRIPTION			
1	725-0117	Battery			
2	725-0270	Solenoid			
3	725-0267	Key Switch			
4	725-0268	Safety Switch—Black			
5	725-0122	Electric Wire			
6	725-0150	Electric Wire			
7	725-0280	Wire Harness			




SINGLE SPEED TRANSMISSION PART NO. 717-0223

PARTS LIST FOR TRANSMISSION USED ON MODELS 136-430A AND 136-435A

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART	REF. NO.	PART NO.	COLOR	DESCRIPTION	NEW PARI
1	716-010)4	Snap Ring		13	710- 0195	5	Hex Hd. Cap Scr. 1/4-28 x .62*	
2	748-085	52	Sprocket 8T #41		14	741-0862	2	Detent Ball	
3	714-012	29	Key Hi-Pro #4		15	732 -0863	3	Detent Spring	1
4	711-085		Shaft Output		16	736- 0116	5	Washer	
5	714-012	26	Key Hi-Pro #606 (Hardened)		17	716 -0106	5	E-ring	
6	717-012	23	Housing Half	1 1	18	716 -0865	5	Snap Ring #3100-50	
7	748-085	55	Bearing		19	7.48- 0866	5	Bevel Pinion	
8	712-011	17	Locknut 14-28 Thd.*		20	748-0867	7	Bearing	
9	748-085	56	Bevel Gear		21	738- 0159		Pinion Shaft	
10	748-085	57	Clutch Collar		22	736-0192	2' ⋅ 〔	Washer	
11	0858	33	Detent Shaft Assembly	1	23	736-0921	,	Lockwasher ½"*	
12	717-012	24	Housing Half with Detent Hole		24	712-0922	?	Hex Jam Nut 1/2-20 Thd.*	
					25	737-0120)	Grease High Temp. 450°F.	
					, ,	·		(5.07)	i

^{*}For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally order by part number and size as shown on parts list,

14



PARTS LIST FOR DIFFERENTIAL ASSEMBY PART NUMBER 717-0328

Ref. No.	Part No.	Qty. Req'd.	Description	New Part
1	715-0247	2	Spring Pin Spir. 3/16" Dia. x 1.00" Lg.	
2	748-0185	2	Gear—Double "O" Hole	
3	738-0300		Shaft—Long 19.31" Lg.	N
4	736-0188	2	FI-Wash760 I.D. x 1.49 O.D.	
5	717-0341	2 2 2 2 2	Housing Half	N
6	736-0119	2.	L-Wash. 5/16" Scr.*	
7	710-0363	2	Hex Scr. 5/16-24 x 4.00" Lg.*	
8	736-0187	2	FI-Wash640 I.D. x 1.24 O.D.	
9	748-0158	2	Gear—Round Hole	
10	711-0276		Drive Pin	
	712-0237	2	Hex Cent. L-Nut 5/16-24 Thd.	İ
. 12	09054	1	Sprocket—40 Tooth	
13	738-0301	1	Shaft—Short 7.07" Lg.	N

^{*}For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.


TROUBLE SHOOTING CHART FOR RECOIL START MODELS

CAUTION: ALWAYS DISCONNECT SPARK PLUG BEFORE ATTEMPTING ANY REMEDY.

engaged; blade controls disengaged, the throttle control set and the key is turned on. A. Disconnect the yellow wire from the engine. This cor from the ignition switch. B. If the engine fails to start the problem is with the engine not the safety system. C. If the engine starts, the problem is with the safety syster. Check the yellow wire for a ground. D. Check the operation of the switch behind the recoil she of the endine. E. If the engine stops when the clutch or blade is a gaged, the recoil handle is not pushed into the recepta and twisted a quarter turn. Blocked fuel line or empty gas tank. Defective spark plug. Spark plug lead wire disconnected. Faulty spark plug—spark should jump gap between con electrode and side electrode. If spark does not jump, place spark plug. NOTE: Use insulated pliers to hold the spark plug wire. Throttle setting. Throttle control lever not in the starting position. Loose connections Spark plug wire loose. Hard starting or loss of power. Dirty air cleaner. Remove air cleaner and clean as outlined in Engine Manual. Excessive vibration. Bent or damaged blade spindle. Stop engine immediately; tighten all bolts and make all ressary repairs. If vibration continues, have the unit serviby a competent repairman. Clean discharge chute and inside of deck.	TROUBLE	LOOK FOR	REMEDY
from the ignition switch. B. If the engine fails to start the problem is with the engine fails to start the problem is with the engine of the safety system. C. If the engine starts, the problem is with the safety system. D. Check the operation of the switch behind the recoil she of the switch behind the switch behind the recoil she of the switch behind the switch beh	Engine fails to start.	Safety System	If the engine will not start be sure the clutch control is disengaged; blade controls disengaged, the throttle control is set and the key is turned on.
C. If the engine starts, the problem is with the safety syster. C. If the engine starts, the problem is with the safety syster. Check the yellow wire for a ground. D. Check the operation of the switch behind the recoil stern handle. E. If the engine stops when the clutch or blade is or gaged, the recoil handle is not pushed into the recepts and twisted a quarter turn. Clean fuel line; check fuel supply. Also check fuel shutvard valve. Defective spark plug—spark should jump gap between con electrode and side electrode. If spark does not jump, place spark plug. NOTE: Use insulated pliers to hold the spark plug wire. Throttle setting. Loose connections Spark plug wire loose. Hard starting or loss of power. Carburetor improperly adjusted. Carburetor improperly adjusted. Excessive vibration. Bent or damaged blade spindle. Carburetor improperly adjusted. Stop engine immediately; tighten all bolts and make all ressary repairs. If vibration continues, have the unit servic by a competent repairman. Unit fails to discharge chute clogged. Foreign object lodged in deck. Clean discharge chute and inside of deck. Engine overheats. Obstructions in air Remove any obstruction from air passages in shroud.			A. Disconnect the yellow wire from the engine. This comes from the ignition switch.
Check the yellow wire for a ground. D. Check the operation of the switch behind the recoil streer handle. E. If the engine stops when the clutch or blade is or gaged, the recoil handle is not pushed into the recepts and twisted a quarter turn. Blocked fuel line or empty gas tank. Defective spark plug. Defective spark plug. Defective spark plug. Spark plug lead wire disconnected. Faulty spark plug—spark should jump gap between con electrode and side electrode. If spark does not jump, place spark plug. NOTE: Use insulated pliers to hold the spark plug wire. Throttle setting. Loose connections Spark plug wire loose. Hard starting or loss of power. Dirty air cleaner. Remove air cleaner and clean as outlined in Engine Manual. Carburetor improperly adjusted. Excessive vibration. Bent or damaged blade spindle. Stop engine immediately; tighten all bolts and make all ressary repairs. If vibration continues, have the unit serviby a competent repairman. Unit fails to discharge chute clogged. Foreign object lodged in deck. Postructions in air Remove any obstruction from air passages in shroud.			B. If the engine fails to start the problem is with the engine, not the safety system.
E. If the engine stops when the clutch or blade is a gaged, the recoil handle is not pushed into the recepta and twisted a quarter turn. Blocked fuel line or empty gas tank. Defective spark plug. Defective spark plug. Spark plug lead wire disconnected. Faulty spark plug—spark should jump gap between con electrode and side electrode. If spark does not jump, place spark plug. NOTE: Use insulated pliers to hold the spark plug wire. Throttle setting. Loose connections Spark plug wire loose. Hard starting or loss of power. Carburetor improperly adjusted. Excessive vibration. Bent or damaged blade spindle. Discharge chute clogged. Poreign object lodged in deck. Engine overheats. Obstructions in air Remove any obstruction from air passages in shroud.			C. If the engine starts, the problem is with the safety system. Check the yellow wire for a ground.
Blocked fuel line or empty gas tank. Defective spark plug. Defective spark plug. Defective spark plug. Defective spark plug. Throttle setting. Loose connections Dirty air cleaner. Carburetor improp erly adjusted. Excessive vibration. Bent or damaged blade spindle. Discharge chute clogged. Foreign object lodged in deck. Engine overheals. Obstructions in air Remove any obstruction from air passages in shroud.			D. Check the operation of the switch behind the recoil start- er handle.
empty gas tank. Defective spark plug. Spark plug lead wire disconnected. Faulty spark plug—spark should jump gap between con electrode and side electrode. If spark does not jump, place spark plug. NOTE: Use insulated pliers to hold the spark plug wire. Throttle setting. Loose connections Spark plug wire loose. Hard starting or loss of power. Dirty air cleaner. Carburetor improp erly adjusted. Excessive vibration. Bent or damaged blade spindle. Excessive vibration. Bent or damaged blade spindle. Discharge chute clogged. Discharge chute clogged. Foreign object lodged in deck. Engine overheats. Obstructions in air Remove any obstruction from air passages in shroud.			E. If the engine stops when the clutch or blade is engaged, the recoil handle is not pushed into the receptacle and twisted a quarter turn.
Faulty spark plug—spark should jump gap between con electrode and side electrode. If spark does not jump, place spark plug. NOTE: Use insulated pliers to hold the spark plug wire. Throttle setting. Loose connections Spark plug wire loose. Hard starting or loss of power. Dirty air cleaner. Carburetor improperly adjusted. Review paragraph Carburetor Adjustment. Excessive vibration. Bent or damaged blade spindle. Stop engine immediately; tighten all bolts and make all ressary repairs. If vibration continues, have the unit serviby a competent repairman. Unit fails to discharge chute clogged. Foreign object lodged in deck. Engine overheats. Obstructions in air Remove any obstruction from air passages in shroud.			Clean fuel line; check fuel supply. Also check fuel shut-off valve.
Faulty spark plug—spark should jump gap between con electrode and side electrode. If spark does not jump, place spark plug. NOTE: Use insulated pliers to hold the spark plug wire. Throttle setting. Throttle control lever not in the starting position. Loose connections Spark plug wire loose. Hard starting or loss of power. Dirty air cleaner. Remove air cleaner and clean as outlined in Engine Manual. Carburetor improperly adjusted. Excessive vibration. Bent or damaged blade spindle. Stop engine immediately; tighten all bolts and make all ressary repairs. If vibration continues, have the unit serviby a competent repairman. Unit fails to discharge grass. Discharge chute clogged. Foreign object lodged in deck. Exemove object from deck. See CAUTION following step paragraph Operation. Remove any obstruction from air passages in shroud.		· · · · · · · · · · · · · · · · · · ·	Spark plug lead wire disconnected.
Throttle setting. Throttle control lever not in the starting position. Loose connections Spark plug wire loose. Hard starting or loss of power. Dirty air cleaner. Remove air cleaner and clean as outlined in Engine Manual. Carburetor improp erly adjusted. Excessive vibration. Bent or damaged blade spindle. Bent or damaged blade spindle. Discharge chute clogged. Discharge chute clogged. Clean discharge chute and inside of deck. Foreign object lodged in deck. Chartele control lever not in the starting position. Remove air cleaner and clean as outlined in Engine Manual. Carburetor improp erly adjusted. Stop engine immediately; tighten all bolts and make all ressary repairs. If vibration continues, have the unit servi by a competent repairman. Clean discharge chute and inside of deck. Foreign object lodged in deck. Remove object from deck. See CAUTION following step paragraph Operation. Engine overheats. Obstructions in air Remove any obstruction from air passages in shroud.		plug.	Faulty spark plug—spark should jump gap between control electrode and side electrode. If spark does not jump, replace spark plug.
Loose connections Spark plug wire loose. Hard starting or loss of power. Dirty air cleaner. Carburetor improperly adjusted. Review paragraph Carburetor Adjustment. Excessive vibration. Bent or damaged blade spindle. Stop engine immediately; tighten all bolts and make all ressary repairs. If vibration continues, have the unit serviby a competent repairman. Unit fails to discharge chute clogged. Foreign object lodged in deck. Foreign object lodged in deck. Clean discharge chute and inside of deck. Remove object from deck. See CAUTION following step paragraph Operation. Engine overheats. Obstructions in air Remove any obstruction from air passages in shroud.			NOTE: Use insulated pliers to hold the spark plug wire.
Hard starting or loss of power. Dirty air cleaner. Remove air cleaner and clean as outlined in Engine Manual. Review paragraph Carburetor Adjustment. Review paragraph Carburetor Adjustment. Stop engine immediately; tighten all bolts and make all ressary repairs. If vibration continues, have the unit serview by a competent repairman. Unit fails to discharge chute clogged. Discharge chute clogged. Foreign object lodged in deck. Remove object from deck. See CAUTION following step paragraph Operation. Engine overheats. Obstructions in air Remove any obstruction from air passages in shroud.		Throttle setting.	Throttle control lever not in the starting position.
Carburetor improperly adjusted. Review paragraph Carburetor Adjustment. Excessive vibration. Bent or damaged blade spindle. Stop engine immediately; tighten all bolts and make all ressary repairs. If vibration continues, have the unit serviby a competent repairman. Unit fails to discharge chute clogged. Discharge chute clogged. Clean discharge chute and inside of deck. Foreign object lodged in deck. Remove object from deck. See CAUTION following step paragraph Operation. Engine overheats. Obstructions in air Remove any obstruction from air passages in shroud.		Loose connections	Spark plug wire loose.
Excessive vibration. Bent or damaged blade spindle. Unit fails to discharge grass. Discharge chute clogged. Discharge chute clogged. Clean discharge chute and inside of deck. Foreign object lodged in deck. Engine overheats. Stop engine immediately; tighten all bolts and make all ressary repairs. If vibration continues, have the unit servit by a competent repairman. Clean discharge chute and inside of deck. Remove object from deck. See CAUTION following step paragraph Operation. Remove any obstruction from air passages in shroud.	-	Dirty air cleaner.	1
Unit fails to discharge grass. Discharge chute clogged. Discharge chute clogged. Clean discharge chute and inside of deck. Foreign object lodged in deck. Engine overheats. Discharge chute clogged. Remove object from deck. See CAUTION following step paragraph Operation. Remove any obstruction from air passages in shroud.	•		Review paragraph Carburetor Adjustment.
clogged. Foreign object lodged in deck. Remove object from deck. See CAUTION following step paragraph Operation. Engine overheats. Obstructions in air Remove any obstruction from air passages in shroud.	Excessive vibration.		Stop engine immediately; tighten all bolts and make all necessary repairs. If vibration continues, have the unit serviced by a competent repairman.
Indged in deck. paragraph Operation. Engine overheats. Obstructions in air Remove any obstruction from air passages in shroud.	-	•	Clean discharge chute and inside of deck.
			Remove object from deck. See CAUTION following step 1 in paragraph Operation .
the form of the second of the	Engine overheats.		Remove any obstruction from air passages in shroud.
Grass and dirt in engine shroud.			Clean cooling fins.
Oil level. Fill crankcase to proper oil level.	ļ	Oil level.	Fill crankcase to proper oil level.

TROUBLE SHOOTING CHART FOR ELECTRIC START MODELS

TROUBLE	LOOK FOR	REMEDY
ngine fails to start.	Safety System	A. Check for a blown fuse in the wire leading from the positive terminal of the battery.
		B. Before checking the safety system further, be sure the clutch control and the blade control are disengaged; only the starting system is being checked. Therefore remove the spark plug lead and ground it to prevent the engine from starting.
		C. Attach a wire (minimum 18 gauge) to the positive terminal of the battery and touch the other end to the small terminal (coil primary) of the solenoid. If the engine cranks, the problem is in the safety system.
		D. Check for continuity from the battery to the solenoid. NOTE: The positive terminal of the battery should have a large cable (#8 guage) and a small wire (#18 gauge) attached to it.
		E. Check all wires and cable for tightness.
		F. Use a #8 gauge wire and jump between the two large terminals of the solenoid. If the unit starts, replace the solenoid.
		G. If the unit fails to start after following the above procedure the problem is probably in the starting motor of the engine.
	Blocked fuel line or empty gas tank.	Clean fuel line; check fuel supply. Also check fuel shut-oft valve.
	Defective spark plug.	Spark plug lead wire disconnected. Faulty spark plug—spark should jump gap between controllelectrode and side electrode. If spark does not jump, replace spark plug.
		NOTE: Use insulated pliers to hold the spark plug wire.
	Throttle setting.	Throttle control lever not in the starting position.
	Loose connections	Spark plug wire loose.
Hard starting or loss power.	of Dirty air cleaner.	Remove air cleaner and clean as outlined in Engine Manual.
	Carburetor improperly adjusted.	Review paragraph Carburetor Adjustment.
Excessive vibration.	Bent or damaged blade spindle.	Stop engine immediately; tighten all bolts and make all necessary repairs. If vibration continues, have the unit serviced by a competent repairman.
Unit fails to dischar grass.	ge Discharge chute clogged.	Clean discharge chute and inside of deck.
	Foreign object lodged in deck.	Remove object from deck. See CAUTION following step 1 in paragraph Operation.
Engine overheats.	Obstructions in air passages.	Remove any obstruction from air passages in shroud.
	Grass and dirt in engine shroud.	Clean cooling fins.
 		Fill crankcase to proper oil level.



PARTS LIST FOR MODEL 136-430A AND 136-435A

	PARTS LIST FOR MODEL 136-430A AND 136-435A								
Ref. No.	Part No.	Color Code	Danaulinālau	New Part	Ref. No.	Part No.	Color Code	Description	New Part
1	757-0264		Seat Ass'y.—Comp.	N	40	736-0	921	L-Wash. 1/2" Scr.*	
2	731-0219		Steering Wheel 12" Dia.		41	712-0	206	Hex Nut 1/2-13 Thd.*	
. 3	731-0220		Steering Wheel Cap		42	736-0	119	L-Wash. 5/16" Scr.*	
4	712-0158		Hex Cent. L-Nut 5/16-18		43	712-0		Hex Nut 5/16-18 Thd.*	
"	1.12 0.00		Thd.		44	11168		Lift Bracket	
5	736-0219		Belleville Wash400 l.D. x		45	736-0		L-Wash. 1/4" Scr.*	
3	100-0210		1.13		46	712-0		Hex Nut 1/4-20 Thd.*	
			1.10		47	710-0		Hex Scr. 1/4-20 Thd.*	
6	750-0316		Steering Tube	N	48	736-0		Belleville Wash345 I.D. x	
7	710-0224		Hex AB-Tap Scr. #10 x .50"		.0			.88 O.D.	
'	110-0224		Lg.		49	710-0	627	Hex Scr. w/lock 5/16-24 x	
0	746-0177		Throttle Control 53.0" Lg.		73	1.00	021	.75" Lg.	
8			Spring Pin Spir. ¼" Dia. x		50	734-0	517	Rear Wheel Rim Ass'y.	
9	715-0114		1.50" Lg.		30	104-0	017	w/hub	
10	740 0007				51	734-0	522	Rear Wheel Ass'y.—Comp.	
10	748-0227		Hex Flange Brg630 I.D.	NI NI	31			Tire Only 13 x 5.00 Tubeless	
11	12812		Steering Shaft Ass'y.	N	E0.	734-0 741-0			
12	735-0117		Floor Mat		52		99 —462	Flange Brg.—Plastic—	N
13	10810 -		Fender—L.H.		53			Fender—R.H.	
14	712-0287		Hex Nut 1/4-20 Thd.*		54	713-0	357	#41 Chain ½" Pitch x 67	
15	736-0329		L-Wash. 1/4" Scr. *			7400	700	Links	
16	710-0134		Carriage Bolt 1/4-20 x .62"			713-0	1723	#41 Master Link 1/2" Pitch	
1			Lg.*			4000	4 400	Type II	
17	748-0227		Hex Flange Brg630 I.D.		55		4 —462	Eng. Box—Side Panel R.H.	
18	711-0198		Pivot Bushing (Tie Rod End)		56	710-0	198	Hex Sems Scr. 5/16-18 x	
19	09709 -	-462	Front Wheel Axle Ass'y.—				_	.75" Lg.*	1
			L.H		57	10470		Bearing Plate	1
20	11376 -		Front Pivot Bracket		58	10471		Rear Axle Sup. Brkt. Ass'y.	ł
21	710-0198	}	Hex Sems Scr. 5/16-18 x		59	710-0	1198	Hex Sems Scr. 5/16-18 x	<u> </u>
			.75" Lg.*			l		.75" Lg.*	1
22	712-0923		Hex Cent. L-Nut 5/8-18 Thd.		60	712-0		Hex Nut 5/16-18 Thd.*	
23	736-0158		L-Wash 5/8" Scr.*		61	736-0		L-Wash. 5/16" Scr.*	1
24		-462	Pivot Bar Ass'y.		62		7 —462	Eng. Box—Top Panel	1
25	710-0312	2	Hex Hd. Cap Scr. 5/8-18 x		63	720-0	1165	Ball Knob—Black 3/8-16	1
			1.31" Lg.			l		Thd.	
26	711-0335		Tie Rod		64	720-0		Grip—Black—Lift Handle	
27	09706 -	-462	Front Wheel Axle Ass'y.—	1	65		- 462	Eng. Box—Front Panel	
ľ			R.H.	1	66	10846		Shift Lever Ass'y.	ļ
28	734-0484	ļ	Tire 10.5 x 3.50 Only—Front		67	10060		Seat Bracket	
			Wheel		68	1082		Engine Box Side Panel—L.F	۱.
29	734-0483	3	Front Wheel Ass'y.—Comp.		69	750-0	296	Steering Wheel Adapter	1
			10.5 x 3.50					Ass'y.	N
30	711-0169)	Collar 5/8" I.D.		70	11053		Switch Brkt. Ass'y. (430A)	
31	710-0494	ļ	Sq. Hd. Set Scr. 5/16-18 x		71	710-0	224	Hex AB-Tap Scr. #10 x .50"	
			.38" Lg.					Lg.	
32	710-0134	ļ	Carriage Bolt 1/4-20 x .62"		72	11528		Eng. Box Top Bezel (430A)	
			Lg.*				7 —462	Eng. Box Top Bezel (435A)	
33	10806 -	-462	Fender Brace	1	73	712-0		Hex Nut #10-24 Thd. (430A)	
34	714-0507		Cotter Pin 3/32" Dia. x		74	732-0	257	Switch Spring (430A)	
			1.00" Lg.*		75	736-0	338	Fiber Wash. (430A)	ı
35	736-0329)	L-Wash. 1/4" Scr.*		76	710-0		Truss Mach. Scr. #10-24 x .6	2"
36	712-0287		Hex Nut 1/4-20 Thd.*			1		Lg. (430A)	1
37	710-0252		Hex Scr. 1/4-20 x .75" Lg.*		77	710-0	351	Truss Mach Scr. #10 x .50"	
38	712-0287		Hex Nut 1/4-20 Thd.*					Lg. (430A)	
39	726-0221		Push Cap 1/2" Dia.		78	11263	3	Handle—Plastic (430A)	
					11	1		1	1

^{*}For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.


(462-Red Flake)

When ordering parts, if color or finish is important use the appropriate color code shown above (e.g. Red Flake finish—10057 (462)).

NOTE: This instruction manual covers various models and all accessories shown do not necessarily apply to your model mower.

NOTE: The engine is not under warranty by the mower manufacturer . . . If repairs or service is needed on the engine, please contact your nearest authorized engine service outlet. Check the "Yellow Pages" of your telephone book under "Engines—Gasoline."

136-430A 136-435A




PARTS LIST FOR MODEL 136-430A AND 136-435A

			1 ANTO LIGIT ON W				100-4		
Ref.	Part No.	Color Code		NEW PART	Ref. No.	Part No.	Color Code	Description	NEW PART
					30	11825		Index Bracket	ĺ
1	731-034		Steering Box Top Cover	N	31	725-026	9	Safety Switch (435A)	į l
2	12819		Steering Support Brkt.	N	31	725-026		Safety Switch (430A)	i
3	710-022	4	Hex AB-Tap Scr. #10 x .50"		00	736-032		L-Wash. 1/4" Scr.*	1
1			Lg.*		32			Hex Nut 1/4 - 20 Thd. *	
4	10818	462	Front Cover Steering Box		33	712-028			
5	712-026		Hex Nut 5/16-18 Thd.*		34	710-055		Hex Scr. 1/4-28 x 1.75" Lg.*	
6	736-011	9	L-Wash. 5/16" Scr.*		35	732-023		Torsion Spring	
7	710-019	8	Hex Sems Scr. 5/16-18 x		36	736-016		L-Wash. 3/8" Scr. *	ĺ
'			.75" Lg.*	1	37	712-079	В	Hex Nut 3/8-16 Thd.*	ĺ
8	710-035	52	Hex Tap Scr. 1/4" x .38" Lg.*	1	38	11826	_	Lift Handle	1
9	11375	-462	Steering Box		39	720-014		Grip	
10	710-022	24	Hex AB-Tap Scr. #10 x .50"			712-011		Hex Cent. L-Nut 1/4-28 Thd.*	ĺ
'`		-	Lg.*	1	41	715-010	7	Spring Pin Spirol 5/16" Dia.	1
11	712-021	4	Hex Cent. L-Nut 3/8-24 Thd.					x 1.38" Lg.	1
12	736-018		FI-Wash406 I.D. x .74 O.D.		42	11830		Lift Shaft Ass'y.	
13	712-026		Hex Nut 5/16-18 Thd.*		43	710-026	0	Carriage Bolt 5/16-18 x .62"	
14	736-011		L-Wash. 5/16" Scr.*					Lg.*	
15	710-019		Hex Sems Scr. 5/16-18 x		44	712-026	7	Hex Nut 5/16-18 Thd.*	
13	710-018	70	.75" Lg.*		45	736-011	9	L-Wash. 5/16" Scr.*	
146	712-079	10	Hex Nut 3/8-16 Thd.*		46	738-014	0	Shld. Scr437" Dia. x .180	
16	736-016		L-Wash. 3/8" Scr.*		47	09721		Pivot Link Ass'y.	
17		9	Brake Lever Bracket		48	711-033	2	Lift Brkt Pin	
18	10832) <i>E</i>	Ball Knob—Black	1	49	12337		Deck Link Ass'y.	
19	720-016	၁၁	Shift Lever Handle Ass'y.	N	50	736-019	2	FI-Wash531 I.D. x .93 O.D.	!
20	12817	20	Silit Level Hallule Ass y.	IN.	51	714-010		Int. Cotter Pin 1/2" Dia.	
21	736-016		FI-Wash530 I.D. x .930 O.D.		52	09735	•	Conn. rod 3/16 x 1.0 x 12.5"	
22	738-023	34	Shid. Scr500" Dia. x .295		50	10007		Lg.	
/*** ?3	736-023	35	FI-Wash406 I.D. x 1.25	}	53	12337		Deck Link Ass'y.	
			O.D.	1	54	09737		Link Slotted	
1 24	712-01	16	Hex Ins. L-Nut 3/8-24 Thd.		55	11831		Lift Hub Ass'y.	
25	12825		Lock Link Ass'y.	N	56	11827	_	Handle Lift Brkt. Ass'y.	
26	12378		Brake Pedal Pad	1	57	750-019	5	Roller—Spacer .505 l.D. x	
_	12379		Clutch Pedal Pad (not shown	1)				.628	
27	11379		Clutch Foot Pedal Rod	Ì	58	738-023		Shld. Scr500" Dia. x .295	
			Ass'y.		59	736-011		L-Wash. 5/16" Scr.*	
28	738-02	13	Shld. Scr498" Dia. x 1.450	1	60	712-026		Hex Nut 5/16-18 Thd.*	
29	710-02		Hex Scr. 1/4-20 x .62" Lg.*		61	735-018	5	Rubber Wash500 I.D.	N
				1	1	1			

136-430A 136-435A


NOTE: If for any reason Disc Brake is disassembled, be sure round end of push pins (Ref. No. 59) is toward the cam lever (Ref. No. 60)



FRAME VIEW

PARTS LIST FOR MODELS 136-430A AND 136-435A

Ref.	Part No.	Color Code		New Part	Ref. No.	Part No.	Color Code	Description	New Part
1			Engine		36	747-010)9	Brake Rod .25" Dia. x 31.62	,,
2	10804		Engine Brace Ass'y.		37	761-013	30	Disc. Brake Ass'y.—Comp.	
3	09785		Vari. Spd. Brkt. Ass'y.		38	732-011		Extension Spring (Brake)	
	10599		Vari. Spd. Pulley & Brkt.		39	10245	-462	Disc Brake Brkt. Ass'y.	
	10000		Ass'y.—Comp.		40	710-019		Hex Sems Scr. 5/16-18 x	
4	712-026	7	Hex Nut 5/16-18 Thd.*		-		•	.75"	1
5	736-011		L-Wash. 5/16" Scr.*		41	714-012	29	#4 Hi-Pro Key 3/32 x 5/8"	
6	10173		Var. Spd. Guide Brkt. Assy.					Dia. Hardened	1
7	10080		Vari. Spd. Rod		42	732-019	92	Spring .88 O.D. x 3.75 (Var.	İ
8	710-013	4	Carriage Bolt 1/4-20 x .62"*					Drive)	1
9	761-015		Blade Brake Ass'y.		43	710-032	22	Hex Sems Scr. 5/16-18 x	
10	732-019		Spring .75 O.D. x 11.0" Lg.	1				1.00" Lg.*	
'0	702 010	•	(Variable Spd. Pedal)		44	715-01	19	Spring Pin Spir. 5/32" Dia.	×
11	732-019	11	Spring .75 O.D. x 11.0" Lg.					.75" Lg.	i
' '	702 0,0	, ı	(Variable Spd. Pedal)		45	714-03	65	#6 Hi-Pro Key 5/32 x 5/8"	
12	10801	—462	Fender Brace					Dia.	
13	712-028		Hex Nut 1/4-20 Thd.*		46	710-04	42	Hex Hd. Cap Scr. 5/16-18 x	
14	710-013		Hex Hd. Cap Scr. 1/4-20 x		.0		-	1.50" Lg. H.T.	
'-	710-010	,0	1.75"		47	10247	—462	Transmission Plate	
15	10057	—462	Frame		48	717-02		Transmission Ass'y. —	İ
16	11379	462	Clutch Foot Pedal Rod		70	02		Comp.	
10	11079		Ass'y.		49	10404		Engine Brace	ļ
17	10057	462	Frame		50	712-04	29	Hex Ins. L-Nut 5/16-18 Thd	
18	715-013		Spring Pin Roll 1/4" Dia. x		51	710-03		Hex Hd. Cap Scr. 5/16-18 x	
10	715-013	,,	2.50"		13,	11000		2.50" Lg.*	`
19	10848	—462	Foot Pedal Latch Ass'y.		52	761-01	33	Spacer for Disc Brake .322	
20	11378		Brake Foot Pedal Rod	1	102	10.0.	00	I.D. x .38	
21	732-024	15	Brake Spring		53	712-01	58	Hex Center L-Nut 5/16-18	
22	715-010		Sprg. Pin Spir. 1/8" Dia. x		33	112-01	50	Thd.*	
22	113-010)3	.75"		54	HH-12	-03293	Casting Carrier Side	
22	736-032	20	L-Wash. 1/4" Scr.*		55	HH-15		Friction Pad 1.110" Dia. x	
23 24	712-028		Hex Nut 1/4 - 20 Thd. *		33	1111111	00170	.245 Thk.	
25	10078) [Foot Pedal Rod—18.80" Lg.	1	56	HH-03	-03303	Friction Pad 1.110" Dia. x	
26	711-040	n/	Shoulder Nut	`l	30	1111 00	00000	.472 Thk.	Ì
27	7112-04		Hex Cent. L-Nut 5/16-18		57	HH-03	-03303	Back-up Disc	
21	112-04	23	Thd.		58	HH-12		Casting Cam Side	
28	11382	_462	Clutch Bar Rod		59	HH-05		Push Pin	
29	710-03		Hex Sems Scr. 5/16-18 x	1	60	HH-18		Cam Lever	
29	710-03	2	1.00"*		61	HH-03		Washer	
20	710-019	ne	Hex Sems Scr. 5/16-18 x		62	HH-02		Hex Locknut	.]
30	110-013	30	.75"*		63	HH-06		Spring	
31	712-02	67	Hex Nut 5/16-18 Thd.*	1	66	737-01		Sq. Hd. Pipe Plug 1/4" (For]
32	710-01		Hex Hd. Cap Scr. 5/16-24 x		3	101-01	U 7	Eng. Oil Drain—Not	1
32	110-01	1 /	1.00" Lg. H.T.	1	1			Shown)	
33	00790	—462		1.	67	737-01	14	Pipe Nipple 3/8-1/4 x 3.0"	
34	711-04		Shoulder Nut	1	10'	1.01.01	• •	Lg. (For Eng. Oil Drain-	-
35	712-04		Hex Ins. L-Nut 5/16-18 Thd	.1				Not Shown)	1
33	112-04	£.J	TION IIIO. E ITACOTTO TO THA	1	1	1		1	1



PARTS LIST FOR MODELS 136-430A AND 136-435A


	Ref. No.	Part No.	Color Code	Description	Ref. No.	PART NO.	Color Code	Description	New Part
I	1	10426		Belt Keeper Ass'y.	40	712-0267	•	Hex Nut 5/16-18 Thd.*	
	2	756-0232)	Two Step Engine Pulley	41	736-0119		L-Wash. 5/16" Scr.*	
	3	10438	-	Vari. Speed Pulley Ass'y.	42	710-0289		Hex Hd. Cap Scr. 1/4-20 x	
	4	736-0921		L-Wash. ½" Scr.*		0200		.50"*	
	5	712-0922		Hex Jam Nut ½-20" Thd.	43	736-0329)	L-Wash. 1/4" Scr. *	
	6	756-0124		Pulley 4.75 O.D. (Deck)	44	710-0195		Hex Hd. Cap Scr. 1/4-28 x	
		754-012		V-Belt 21/32 x 66.0" Lg.	7.7	110 0100	•	.62"*	
	7 8	712-024		Hex Jam Nut 5/8-11 Thd.	45	712-0267	,	Hex Nut 5/16-18 Thd.*	
	0	112-024	_	(Deck)	46	736-0119		L-Wash. 5/16" Scr.*	
	0	736-016	2	Flat Washer .641 I.D.	47	09164	,	Deck Reinforcement Plate	ļ
	9	09321	_	Blade Spindle Ass'y.	48	09733		Belt Guard (Deck)	
	10			Housing—Bearing	49	741-0919	,	Ball Brg787 I.D. x 1.85 O.D.	
	11	08253	E	Blade spindle	50	710-0312		Hex Sems Scr. 5/16-18 x	"
	12	711-025		#6 Hi-Pro Key 5/32 x 5/8"	50	110-0322	•	1.00"*	
•	13	714-036	3	Dia.	51	710-0152)	Hex Hd. Cap scr. 3/8-24 x	
		44007		Wheel Brkt. Ass'y. L.H.	51	110-0152	-	11ex 11d. Oap 301. 370-24 x	
	14	11237		(Deck)				1.00" Lg. H.T.	
	4-	00700		Belt Guard (Deck)	52	736-0217	,	L-Wash. 3/8" Scr. H.D.	
	15	09733	^	Spring .750" O.D. x 8.65" Lg.	53	736-0217		Flat Wash406 I.D. x 1.25	
	16	732-015	3	30 Inch Deck Ass'y.	53	730-0230	,	O.D.	
	17	12340	^	Hex Nut 5/16-24 Thd.*		710-0152	,	Hex Hd. Cap Scr. 3/8-24 x	
	18	712-012		L-Wash. 5/16" Scr.*	54	710-0152	-	1.00" Lg. H.T.	
	19	736-011			55	726 0021		L-Wash. ½" Scr.*	
	20	742-011		15 Inch Blade	55	736-0921			
	21	710-011	<i>(</i>	Hex Hd. Cap Scr. 5/16-24 x	56	754-0136)	V-Belt 21/32 x 31" Lg. (For	
		40700		1.00" Lg. H.T.	F 7	756 017		Transmission Pulley	
	22	10769	^	Blade Adapter Kit Hex Hd. Cap Scr. 3/8-24 x	57	756-0174	+	Split Transmission Pulley .50 l.D.	
N. C. C. C. C. C. C. C. C. C. C. C. C. C.	23	710-045	9		E0	712-0267	7	Hex Nut 5/16-18 Thd.*	
		10700		1.50" Lg. H.T.	58	736-0119		L-Wash. 5/16" Scr.*	
	24	10769		Blade Adapter Kit Push Nut 1/4" Rod	59				
	25	726-010		Pivot Pin	60	754-0135)	V-Belt 21/32 x 25" Lg. (From Eng. Pulley to Var. Spd.	ĺ
	26	711-057							
	27	732-026	7	Torsion Spring		10404		Pulley)	
	28	11399		Adapter Plate Ass'y.	61	10424		Belt Guard Cup Ass'y. (For	
	29	726-010	00	Push Nut 1/4" Rod Chute Deflector Ass'y.	00	740 047	7	Eng. Pulley) Sheave Half	
	30	11574	^	Shid. Scr625" Dia. x 1.75	62	748-0177			
	31	738-011	9	(Axle Bolt)	63	715-0124		Spring Pin Spir. 5/32" Dia. x .62" Lg.	
	32	712-011	6	Hex Ins. L-Nut 3/8-24 Thd.	64	748-0181	1	Moveable Sheave Ass'y.	
	33	10937		Wheel Pivot Bar	65	741-0139		Ball Brg50 I.D. x 1.38 O.D.	
	34	734-029	95	5.0 Inch Wheel Ass'y. (Deck)	66	750-0144		Steel Tubing	
	35	736-010)5	Belleville Wash400 l.D. x	67	750-0146		Spacer .520 I.D. x .692 O.D.	-
	1			.88 O.D.	68	741-0139		Ball Brg50 l.D. x 1.38 O.D.	
	36	10949		Spring Lever Ass'y. with	69	748-0177	7	Sheave Half	
				Knob	70	736-0217	7 ·	L-Wash. 3/8" Scr. H.D.	-
	37	11236		Wheel Brkt. Ass'y.—R.H.	71	11530		Blade Brake Disc Ass'y.	
	38	736-011	19	L-Wash. 5/16" Scr.*	72	1,2347		30" Deck Ass'y.—Comp.	1
	39	712-026		Hex Nut 5/16-18 Thd.*	1				
				_1		1		The state of the s	-

WHEEL CHART

FRONT WHEEL

REAR WHEEL

Part. No.	Description	Part. No.	Description
734-0483 748-0184	Wheel Ass'y.—Comp. Bearing	734-0523 734-0517 734-0298 734-0255 — 734-0249	Wheel Ass'y.—Comp. Rim with Hub Ass'y. Tire Only Tubeless 13 x 5.00 Air Valve Hub Part of Rim Inner Tube (Service Only)



BATTERY BOX BREAKDOWN

PARTS LIST FOR BATTERY BREAKDOWN MODELS 136-430A AND 136-435A


								ON NITE 100-400M		
Ref. No.		Color Code	llectintian	New Part	Ref. No.	Part No.	Color Code	Decorintion	New Part	
1 2		-462	Stem Bumper Battery Box Bracket Ass'y.		11	710-025	2	Hex Hd. Cap Scr. ¼-20 x .75" Lg.* (435A)		
3 4	10060 —462 712-0267		Seat Bracket Hex Nut 5/16-18 Thd.* Flat Washer .344 I.D. x .88 O.D.		12	725-011	7	Battery Dry 12 Volt with Acid Pack (435A)		
5	736-0159				13	710-0322		Hex Sems Scr. 5/16-18 x 1.00" Lg.*		
6	735-0127	7	Rubber Washer .33 I.D. x .87 O.D.		14	736-011	9	Spring Lockwasher 5/16" Scr. *		
7	710-0198	3	Hex Sems Scr. 5/16-18 x .75" Lg.*		15 16	712-026 10059		Hex Nut 5/16-18 Thd.*		
8	712-0287		Hex Nut 1/4-20 Thd.* (435A)		17	10059 —462 710-0216		Battery Box Hex Hd. Cap Scr. 3/8-16 x		
9	736-0329)	Spring Lockwasher ¼" Scr.* (435A)		18	736-016	9	.75" Lg.* Spring Lockwasher 3/8"		
10	725-0150)	Battery Ground Wire (435A)					Scr.*		

^{*}For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

DECK LINKAGE



Refer to illustration below for proper deck link hookup. If the deck is removed for any reason use the illustration below for correct assembly.



PARTS INFORMATION

POWER EQUIPMENT PARTS AND SERVICE

Parts and service for all MTD manufactured power equipment are available through the authorized service firms listed below. All orders should specify the model number of your unit, parts numbers, description of parts and the quantity of each part required.

ALABAMA	BIRMINGH	AM		
Auto Electric & Ca	rburetor Co.	2625	4th Ave. S	5 35233
ヘレン マレンタン	NURIHLI	TTIF	BUCK	
Sutton's Lawn Mov	FORT SMI	.Kt.4,	Box 368	72117
Mity Mite Motors,	nc:	. 2515	Towson A	va 72001
CALIFORNIA	SAN RERN	APNIN	$^{\wedge}$	
Lawn Mower Suppl	y Co	25608	E. Basel	ine 92410
J.W. Jewett Co	SAN FRAN	CISCO	.l C.	04107
	SACRAMEN	ito		
Luttig & Severson		2030 2	28th St	95818
COLORADO	DENVER			
South Denver Lawr	CILEBIEL D	52/ W	est Evans	80223
The Jones & Rams	ey Co	850 Th	omn sonvi	_ P.J. 04070
FLURIDA	JACK SONV	HIF		
Radco Distributors	COD 41	2403 N	larket St.	32206
Moz-All of Florida,	CORAL GA	BLES		20244
GEURGIA	EAST POIN	T		
East Point Cycle &	Key	2834 C	hurch St.	30344
IFFIGO13	LIUNS			
Keen Edge Co INDIANA	ELKHART	86 15 C	gden Ave	60534
Parts & Sales Inc.	KIIAK I	2101 ln	dustrial P	hwy 46514
	CORYDON			
Brown Equip. Dist.	DUBUUULE			
Power Lawn & Gard KANSAS	den Equip WICH!TA	2551 J	.F. Kenne	dy 52001
Hixon, Inc		3030 M	ascot	67204
LUUISIANA	NEW ORLE.	ANS		
Suhren Engine Co.	TAKOMA P	8330 E	arhart Blv	/d 70118
Center Supply Co		ARN A7 New	Hamnehie	- Aug 20012
WW33WCUO3E(12	SPRINGFIE	LD		
Morton B. Collins C	OUNT CLI	300 Bir	nie Ave.	01107
Power Equipment D	ist	36463 S	South Grat	int 48043
	LANSING			
Lorenz Service Co.	MINNETONE	2500 S.	Pennsylv	ania 48900
Hance Distributing	NIMME I UNI	(A 11212 V	Vavrata B	ld ==2.42
W1221221551 I	3I LOXI			
Biloxi Sales & Servi	ce, Inc	506 Cai	illavet St.	39533
MISSOURI Automotive Equip.	LANSAS CIT	Y		
	N. LOUIS			
Henzler, Inc.		2015 Le	may Ferr	y Rd. 63125
R.P.W., Inc.	MAHA	7400 ***	· · ·	40107
		7-7-U.Z. I	- Jį	0812/

BRIGGS & STRATTON, TECUMSEH AND PEERLESS PARTS AND SERVICE

Briggs & Stratton, Tecumseh and Peerless parts ar service should be handled by your nearest authorized engine service firm. Check the yellow pages of your telephone directory under the listing Engines

Gasoline, Briggs & Stratton or Tecumseh Lauson

	NEW YORK	CARTHAGE
	Gamble Dist., Inc	SYRACUSE West End Ave 13619
	Kimber's, Inc	ROCHESTER 13204
	Henry W. O'Neil &	Associates410 N. Goodman St. 14400
	NOR IN CARULINA	GREENSBORO any
		GOLDSBORO 27530
(OUIO .	WADSWORTH
		CLEVELAND
		CARROL 7900 Lorain Ave 44102
	Stebe's Mid-State N	Nower Supply Box 366
	Sunshine Wholesale	Tire Outlet Route 224
	McClure Lawn & Ga	MANSFIELD Irden Supply1114 Lexington Ave 44903
(JULAHUMA	MUSKOGÉE605 S. Cherokee 74401
		ADA
C	REGON SUPPLY	907 E. 12th St 74820
F	PENNSYLVANIA	LANCASTER
		James & Mulberry Sts17604 PITTSBURGH
7	Bluemont Co	KNOXVILLE
•	Master Repair Serv	ice 2423 Broadway, N.E37917
	Memphis Cycle & Su	MEMPHIS pply Co 421 Monroe Ave38103
Т	- American Sales & Se EXAS	prvice, Inc 1922 Lynnbrook 38117
	Marr Brothers, Inc.	
	Bullard Supply Co.	2409 Commerce St 77003
	Catto & Putty, Inc.	SAN ANTONIO
		FORT WORTH 21702 N. Sylvania76111
U	I AD	SALT LAKE CITY r Co 437 E. 9th St84111
٧	ERMUNI	BURLINGTON
٧	IKGINIA	Co 44 Lakeside Ave05401
W	ASHING LUN :	5EATTLE
W	Bailey's Rebuild, In EST VIRGINIA	C 1325 F. Madison St. 99102
	ioung's, inc	
741	Automotive Supply (Co 123 S. Linwood Ave54911

WARRANTY PARTS AND SERVICE POLICY

The purpose of warranty is to protect the customer from defects in workmanship and materials, defects which are NOT detected at the time of manufacture, it does not provide for the unlimited and unrestricted replacement of parts. Use and maintenance are the responsibility of the customer. The manufacturer cannot assume responsibility for conditions over which it has no control. Simply put, if it's the manufacturer's fault, it's the manufacturer's responsibility; if it's the customer's fault, it's the customer's

CLAIMS AGAINST THE MANUFACTURER'S WARRANTY INCLUDES

- 1. Replacement of Missing Parts on new equipment.
- 2. Replacement of Defective Parts within the warranty period.
- 3. Repair of Defects within the warranty period.
- All claims MUST be substantiated with the following information:
- 1. Model Number of unit involved.
- 2. Date unit was purchased or first put into service.
- 3. Date of failure.
- 4. Nature of failure.