
# OWNER'S GUIDE

ASSEMBLY • OPERATION • MAINTENANCE • PARTS •



18 H.P.
GARDEN
TRACTORS

**Model Numbers** 

142-840H000

142-842H000

142-843H000

142-844H000

142-846H000

142-848H000

142-849H000

#### **IMPORTANT!**

(Model 840H Shown with Optional Grass Collector)

Record the **Model No.** and **Mfg. Code** which appear on your unit in the space below. You **must** have these numbers, along with the date of purchase, in order to receive warranty or service.

**MEETS ANSI SAFETY STANDARDS** 

MODEL NO.

MFG. CODE

Important:
Read Safety Rules
and Instructions Carefully



**WARNING:** This unit is equipped with an internal combustion engine and should not be used on or near any unimproved forest-covered, brush-covered or grass-covered land unless the engine's exhaust system is equipped with a spark arrester meeting applicable local or state laws (if any). If a spark arrester is used, it should be maintained in effective working order by the operator.

In the State of California the above is required by law (Section 4442 of the California Public Resources Code). Other states may have similar laws. Federal laws apply on federal lands. A spark arrester for the muffler is available through your nearest engine authorized service dealer or contact the service department, P.O. Box 360900, Cleveland, Ohio 44136.

# **IMPORTANT**

# **SAFE OPERATION PRACTICES**



THIS SYMBOL POINTS OUT IMPORTANT SAFITY INSTRUCTIONS WHICH, IF NOT FOLLOWED, COULD ENDANGER THE PERSONAL SAFETY AND/OR PROPERTY OF YOURS :LF AND OTHERS. READ AND FOLLOW ALL INSTRUCTIONS IN THIS MANUAL BEFORE ATTEMPTING TO OPERATE YOUR UN T. WHEN YOU SEE THIS SYMBOL— HEED ITS WARNING.



**DANGER:** 

This cutting machine is capable of amputating hands and feet and throwing objects. Failure to observe the following safety instructions could result in serious injury or death.

#### I. GENERAL OPERATION

- Read, understand, and follow all instructions in the manual and on the machine before starting. Keep this manual in a safe place for future reference and for ordering replacement parts.
- Only allow responsible adults familiar with the instructions to operate the machine. Know controls and how to stop the machine quickly.
- Do not put hands or feet under cutting deck or near rotating parts.
- 4. Clear the area of objects such as rocks, toys, wire, etc. which could be picked up and thrown by the blade. A small object may have been overlooked and could be accidently thrown by the mower in any direction and cause injury to you or a bystander. Always wear safety glasses or eye shields during operation or while performing an adjustment or repair, to protect eyes from foreign objects. Stop the blade(s) when crossing gravel drives, walks or roads.
- Be sure the area is clear of other people before mowing. Stop machine if anyone enters the area.
- 6. Never carry passengers.
- Disengage blade(s) before shifting into reverse and backing up. Always look down and behind before and while backing.
- 8. Be aware of the mower and attachment discharge direction and do not point it at anyone. Do not operate the mower without either the entire grass catcher or the chute guard in place.
- Slow down before turning. Operate the tractor smootl ly. Avoid erratic operation and excessive speed.
- Never leave a running machine unattended. Always turn off blade(s), place transmission in neutral, set park brike, stop engine and remove key before dismounting.
- Turn off blade(s) when not mowing.
- 12. Stop engine and wait until blade(s) comes to a complete stop before (a) removing grass catcher or unclogging chu:e, or (b) making any repairs, adjusting or removing any grass (r debris.
- 13. Mow only in daylight or good artificial light.
- Do not operate the machine while under the influence of alcohol or drugs.
- 15. Watch for traffic when operating near or crossing roac ways.
- 16. Use extra care when loading or unloading the machine into a trailer or truck. This unit should not be driven up o down a ramp onto a trailer or truck under power, because the unit could tip over, causing serious personal injury. The tinit must be pushed manually to load or unload properly.
- 17. Never make a cutting height adjustment while engine is running if operator must dismount to do so.
- 18. Wear sturdy, rough-soled work shoes and close-fitting slacks and shirts. Do not wear loose fitting clothes or jewe ry. They can be caught in moving parts. Never operate a unit in bare feet, sandals, or sneakers.
- 19. Check overhead clearance carefully before driving under power lines, wires, bridges or low hanging tree branches, before entering or leaving buildings, or in any other situation where the operator may be struck or pulled from the unit, which could result in serious injury.
- Disengage all attachment clutches, thoroughly degrees the brake pedal, and shift into neutral before attempting to start engine.

#### II. SLOPE OPERATION

Slopes are a major factor related to loss of control and tip-over accidents which can result in severe injury or death. **All** slopes require extra caution. If you cannot back up the slope or if you feel uneasy on it, do not mow it.

#### DO:

Mow up and down slopes, not across.

Remove obstacles such as rocks, limbs, etc.

Watch for holes, ruts or bumps. Uneven terrain could overturn the machine. Tall grass can hide obstacles.

Use slow speed. Choose a low enough gear so that you will not have to stop or shift while on the slope. Always keep tractor in gear when going down slopes to take advantage of engine braking action.

Follow the manufacturer's recommendations for wheel weights or counterweights to improve stability.

Use extra care with grass catchers or other attachments. These can change the stability of the machine.

Keep all movement on the slopes **slow** and **gradual.** Do not make sudden changes in speed or direction. Rapid engagement or braking could cause the front of the machine to lift and rapidly flip over backwards which could cause serious injury.

Avoid starting or stopping on a slope. If tires lose traction, disengage the blade(s) and proceed slowly **straight** down the slope.

For your safety, use the slope gauge included as part of this manual to measure slopes before operating this unit on a sloped or hilly area. If the slope is greater than 15° as shown on the slope gauge, do not operate this unit on that area or serious injury could result.

#### DO NOT:

**Do not** turn on slopes unless necessary; then, turn slowly and gradually downhill, if possible.

**Do not** mow near drop-offs, ditches or embankments. A wheel over the edge or an edge caving in could cause sudden overturn.

**Do not** mow on wet grass. Reduced traction could cause sliding. **Do not** try to stabilize the machine by putting your foot on the

**Do not** try to stabilize the machine by putting your foot on the ground.

Do not use grass catcher on steep slopes.


#### III. CHILDREN

Tragic accidents can occur if the operator is not alert to the presence of children. Children are often attracted to the machine and the mowing activity. **Never** assume that children will remain where you last saw them.

- Keep children out of the mowing area and in watchful care of an adult other than the operator.
- 2. Be alert and turn machine off if children enter the area.
- Before and when backing, look behind and down for small children.
- 4. Never carry children. They may fall off and be seriously injured or interfere with the safe machine operation.
- Never allow children under 14 years old to operate the machine. Children 14 years and over should only operate machine under close parental supervision and proper instruction.
- 6. Use extra care when approaching blind corners, shrubs, trees or other objects that may obscure vision.

# **SLOPE GAUGE**

(Keep this sheet in a safe place for future reference.)





Do not mow on inclines with a slope in excess of 15 degrees (a rise of approximately 2-1/2 feet every 10 feet). A riding mower could overturn and cause serious injury. If operating a walk-behind mower on such a slope, it is extremely difficult to maintain your footing and you could slip, resulting in serious injury.

Operate WALK-BEHIND mowers across the face of slopes, never up and down slopes. Operate RIDING mowers up and down slopes, never across the face of slopes.




FIGURE 2.




FIGURE 3.



#### **DANGER**

Battery contains sulfuric acid. Refer to warning on page 5. Antidote: EXTERNAL—Flush with water. INTERNAL—Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg or vegetable oil. Seek prompt medical attention. EYES: Flush with cool water for at least 15 minutes, then seek immediate medical attention

Since batteries produce explosive gases, keep all lighted materials (cigarettes, lighters, matches, etc.) away. Be sure to charge battery only in well-ventilated areas.

KEEP BATTERIES
OUT OF THE REACH OF CHILDREN!

#### **ACTIVATING THE BATTERY**

Do not activate battery (fill with battery acid) until battery is actually placed in service. Be certain to read previous warnings before activating the battery.

- 1. Open the battery pack. Be careful not to puncture the box. It contains the battery fluid (acid) in a plastic container and one short plastic tube.
- Remove the battery from the tractor by lifting the hood and removing the wing nuts and battery cover.
- 3. Place the battery on a table or workbench. Make certain the long plastic drain tube is in place on the vent elbow.
- 4. Remove the six fill caps from the top of the battery. See figure 2.
- Place the battery fluid container on the table or workbench. Carefully cut off tip of the spout and attach the short plastic tube provided. Do not squeeze the container when cutting tip.
- Fill each battery cell slowly and carefully to the UPPER LEVEL line marked on battery. See figure 3. Use caution as the acid level will rise rapidly after the bottom of the cell is filled.
- 7. Allow battery to stand for 30 minutes with the fill caps removed, while the plates absorb acid.
- If acid level has fallen after the 30 minute standing period, refill each cell with battery acid to the UPPER LEVEL line on battery. Replace the fill caps.
- Before discarding the empty container, neutralize any residue with baking soda and rinse container with water. Puncture container several times before discarding.
- 10. Charge the battery after the 30 minute standing period. SLOW CHARGE THE BATTERY (DO-NOT FAST CHARGE) at a maximum bench rate of 2 amperes until the specific gravity reading is 1.265. Charge for a minimum of 3 hours and a maximum of 5 hours.

**NOTE:** This engine is equipped with an alternator. The current for the battery charger alternator is unregulated. During normal operation, it is only necessary to charge the battery:

- 1. When it is activated for the first time.
- 2. Before winter storage.
- 3. Before using the lawn tractor after winter storage.

NOTE: After battery has been charged, add only distilled water. Do not add acid.





FIGURE 4.






FIGURE 5.

### STEERING WHEEL INSTALLATION (Hardware A)

- There are four height positions for the steering wheel. For shipping purposes, the steering shaft is assembled in the lowest position. Lift the hood of the tractor. Remove the hex bolt and hex lock nut on the steering shaft. Raise the shaft to desired position and secure with hex bolt and hex lock nut. See figure 4.
- 2. Attach one end of the plastic steering bellow to the steering wheel as shown in figure 4, inset.
- 3. Position the front wheels of the tractor so they are pointing straight forward.
- Place the steering wheel (with steering bellow attached) over the steering shaft extending through the dash, positioning steering wheel as desired.
- 5. Place the washer with the cupped side down over the steering shaft. Secure with 5/16" hex lock nut. See figure 4.
- 6. Place the steering wheel cap over the center of the steering wheel so the logo can be read from the operator's position, and press on by hand.

## ATTACHING THE DECK LINKS (Hardware B)

The three adjustable deck links have been shipped unassembled. Attach as follows.

- Start 1/2" hex nuts on eyebolts provided. Insert the hex nuts and eyebolts into the adjustable lift links as shown in figure 5.
- 2. Thread eyebolts into the lift links and hex nuts. The left rear link should be adjusted so the eyebolt is to the **lower** mark as shown. The two front links should be adjusted to the **higher** mark.

**NOTE:** This adjustment is for 46" decks only. For 44" decks, the eyebolts should be at the lower marks for all three links.





FIGURE 6.

#### **INSTALLING THE BATTERY**

- 1. Place the battery on the battery plate with the terminals toward the rear of the tractor.
- 2. Remove the hex bolt and hex nut from each battery terminal.
- 3. Attach the positive cable (heavy red wire) to the positive battery terminal (+) with one hex bolt and hex nut. See figure 6.

**NOTE:** The positive battery terminal is marked Pos. (+). The negative battery terminal is marked Neg. (–).



- 4. Attach the negative cable (heavy black wire) to the negative battery terminal (-) with the other hex bolt and hex nut.
  - 5. Place the black plastic battery cover in position over the hold-down rods. Secure with wing nuts.

**NOTE:** It may be necessary to pull up on the hold-down rods in order to start the wing nuts.

FIGURE 7.




FIGURE 8.

6. Route the battery drain tube over to the left side of the tractor. Loosen the self-tapping screw which secures the mounting clamp. See figure 8. Slip the end of the drain tube into the mounting clamp. Tighten the self-tapping screw to secure the clamp. Do not overtighten which could collapse the drain tube.

**NOTE:** The vented battery allows any gases or liquid from the battery to be drained onto the ground.

7. Trim end of drain tube if more than 1 inch extends below the frame.





FIGURE 9.



#### FINAL ASSEMBLY (Hardware C)

- 1. **Optional foot pads:** If not already assembled, attach foot pads as follows. Position one foot pad on top of the running board on the tractor, lining up the studs on the bottom of pad with the holes in the running board. Pull the studs through the holes in the running board using a pair of pliers.

  Repeat on other side of tractor. See figure 9.
- 2. If your tractor is equipped with **optional hub** caps, attach the four hub caps as follows.
  - a. Slide five mounting clips on each hub cap as shown in figure 10, with the tabs on the mounting clips facing outward.
- b. Line up hub caps with wheel rims. Push hub caps on by hand.
  - 3. Make certain **all** nuts and bolts are tightened securely.

#### **TIRE PRESSURE**

The tires on your unit may be over-inflated for shipping purposes. Reduce the tire pressure before operating the unit. Recommended operating tire pressure is approximately 12 p.s.i. (check sidewall of tire for tire manufacturer's recommended pressure).



WARNING: Maximum tire pressure under any circumstances is 30 p.s.i. Equal tire pressure should be maintained on all tires.

### ATTACHING THE CUTTING DECK

If your tractor is equipped with a cutting deck, attach as instructed in the separate deck manual packed with your unit.

# **CONTROLS**

#### **IGNITION SWITCH**

The ignition switch is located on the dashboard. Turn the key to the START position to start the engine. When the engine is running, leave the key in the ON position. To stop the engine, turn the key to the OFF position. See figure 11.



WARNING: Remove the key from the tractor when the tractor is not in use to prevent accidental starting.

#### THROTTLE CONTROL

The throttle control is located on the left side of the

dashboard and is used to regulate the engine speed. See figure 11. The engine should be operated from 3/4 to full throttle (FAST) when operating any equipment that uses the tractor engine as a source of power such as the mowing deck, snow thrower or rotary tiller.

#### **CHOKE CONTROL**

The choke control is located on the right side of the dashboard and is operated manually. Details for the choke operation are covered in the separate engine manual packed with your unit. See figure 11.




FIGURE 11A.—Models 843 and 848 Shown




FIGURE 11B.—Models 842 and 847 Shown

### **LIGHT SWITCH (Optional)**

The head lamps are operated by pushing the light switch located on the dashboard. The head lamps will only operate when the engine is running. See figure 11.

**NOTE:** If your unit is not equipped with a light switch, the lights will be on when the engine is running.

### **AMMETER (Optional)**

The ammeter registers the rate of battery charge or discharge. The ammeter will register on the discharging side when starting the engine. It should register on the opposite side (charging) when the engine is running in the fast position until the battery is completely charged. With a fully charged battery or with the engine idling, the ammeter will not show a charge. See figure 11.

#### **CLUTCH-BRAKE PEDAL**

The clutch-brake pedal is located on the left side of the tractor. See figure 11. Depressing the clutchbrake pedal partway disengages the clutch. Pressing the pedal all the way down disengages the clurch and engages the disc brake.

**NOTE:** The clutch-brake pedal must be depressed to start the engine.


#### **SHIFT LEVER**

The shift lever is located in the center of the console and has four positions, HIGH, LOW, NEUTRAL and REVERSE. See figure 12. The clutch-brake pedal must be depressed and the lawn tractor must not be moving when shifting gears. Do not force the shift lever. Release the clutch-brake pedal slightly to line up the shifting collar in the transmission. Then try to shift gears.

#### **PARKING BRAKE**

To set the parking brake, depress the clutch-brake pedal and pull up the parking brake knob. It will stay in the raised position. To release the parking brake, depress and release the clutch-brake pedal. See figure 12.

**NOTE:** The parking brake must be set if the operator leaves the seat with the engine running.



#### FIGURE 12.

#### SPEED CONTROL LEVER

The speed control lever is located on the left fender. It allows you to regulate the ground speed of the lawn tractor. See figure 13. To select the ground speed, depress clutch pedal. Push speed control lever outward and move backward to slow lawn tractor, move forward to increase speed. When desired speed has been obtained, release lever in that position. Whenever clutch is engaged, unit will automatically go to the pre-set speed.




FIGURE 13.

#### LIFT LEVER

The five position lift lever is used to change the operating position of the attachments. To operate, pull the lever towards you. To release, move the lever to the right and then forward. See figure 11.

#### **POWER TAKE-OFF (PTO) LEVER**

The PTO lever is located on the right side of the dash-

board. The PTO lever is used to engage and disengage the power to the attachments. To engage the PTO, lift the lever slowly and lock it into the notch. See figure 11.

**NOTE:** The PTO lever **must** be in the disengaged position (down) when starting the engine when shifting into reverse and if the operator leaves the seat.

# **OPERATION**



### **WARNING**

#### AVOID SERIOUS INJURY OR DEATH

- GO UP AND DOWN SLOPES, NOT ACROSS.
   AVOID SUDDEN TURNS.
   DO NOT OPERATE THE UNIT WHERE IT COULD SLIP OR TIP.
- IF MACHINE STOPS GOING UPHILL, STOP BLADE(S) AND BACK DOWNHILL SLOWLY.
- DO NOT MOW WHEN CHILDREN OR OTHERS ARE AROUND.
- NEVER CARRY CHILDREN.
- LOOK DOWN AND BEHIND BEFORE AND WHILE BACKING.
- KEEP SAFETY DEVICES (GUARDS, SHIELDS, AND SWITCHES) IN PLACE AND WORKING.
- REMOVE OBJECTS THAT COULD BE THROWN BY THE BLADE(S).
- . KNOW LOCATION AND FUNCTION OF ALL CONTROLS.
- BE SURE BLADE(S) AND ENGINE ARE STOPPED BEFORE PLACING HANDS OR FEET NEAR BLADE(S).
- BEFORE LEAVING OPERATOR'S POSITION, DISENGAGE BLADE(S), PLACE THE SHIFT LEVER IN NEUTRAL, ENGAGE BRAKE LOCK, SHUT ENGINE OFF AND REMOVE KEY.

READ OPERATOR'S MANUAL

### **GAS AND OIL FILL-UP**

Check oil level and add if necessary. Service the engine with gasoline as instructed in the separate engine manual packed with your tractor. Read instructions carefully.

**IMPORTANT:** Your tractor is shipped with oil; however, you must check the oil level before operating. Be careful not to overfill.

The gasoline tank is located under the seat. The filler neck is behind the seat. Do not overfill.



WARNING: Never fill fuel tank indoors, with engine running or while engine is hot.

#### STARTING THE ENGINE

**IMPORTANT:** This unit is equipped with a **safety interlock system** for your protection. The purpose of the safety interlock system is to prevent the engine from cranking or starting unless the clutch-brake pedal is depressed and the PTO lever is in the disengaged position. In addition, the PTO lever must be in the disengaged position when the unit is put into reverse or the engine will shut off. If the operator leaves the seat with the PTO lever engaged and/or without setting the parking brake, the engine will shut off.



WARNING: Do not operate the tractor if the interlock system is malfunctioning because it is a safety device, designed for protection.

- 1. Place the PTO lever in the disengaged (down) position.
- 2. Depress the clutch-brake pedal and set the parking brake.
- 3. Place the shift lever in the NEUTRAL position.
- 4. Set the throttle control in the FAST position.
- 5. Pull out the choke control (a warm engine may not require choking).
- 6. Turn the ignition key to the right to the START position. After the engine starts, release the key. It will return to the ON position.
- 7. Slowly push in the choke as the engine warms up.

#### STOPPING THE ENGINE

Turn the ignition key to the left to the OFF position. Remove the key to prevent accidental starting.

**IMPORTANT:** If you strike a foreign object, stop the engine. Remove wire from spark plug, thoroughly inspect the unit for any damage, and repair the damage before restarting and operating the mower.

**NOTE:** If any problems are encountered, refer to the Trouble Shooting Chart on page 18.

#### **OPERATING THE TRACTOR**

- 1. Start the engine as instructed previously.
- Move throttle control to 3/4 or full throttle to prevent strain on the engine and to operate attachments.
- Place the shift lever in one of the two forward positions (LOW or HIGH), or in REVERSE. Place the speed control lever in desired position. Use first speed position when operating the tractor for the first time.



WARNING: Look to the rear before backing up.

- 4. Release the parking brake by depressing the clutch-brake pedal. Release clutch-brake pedal slowly to put unit into motion.
- 5. The tractor is brought to a stop by depress ng the clutch-brake pedal.
- 6. The cutting blades (or other attachment) riay be engaged while the tractor is moving or standing still. DO NOT engage the cutting blades a pruptly as the sudden belt tension on the pulley may cause the engine to stall.



WARNING: Keep feet and hands away from the discharge opening, the blades or any part of the deck.

**NOTE:** When operating the unit initially, there will be little difference between the highest two speec's until after the belts have seated themselves into the pulleys during the break-in period. Be certain to change oil in the crankcase after the first 5 hours of operation.

Be sure that the lawn is clear of stones, sticks, vire, or other objects which could damage tractor or engine. For best results and to insure more even grass distribution, do not mow when lawn is excessively we:.



WARNING: Before leaving the operator's position for any reason, disengage the blades, place the shift lever in neutral, engage the parking brake, shut engine off and remove the key.

When stopping the unit to empty a grass bag, etc., follow the instructions above. This procedure will also eliminate "browning" the grass, which is caused by hot exhaust gases from a running engine.

If unit stalls with speed control in sixth or seventh speed, or if unit will not operate with speed control lever in first or second speed position, proceed as follows.

- 1. Place shift lever in NEUTRAL.
- 2. Restart engine.
- 3. Place speed control lever in seventh speed position.
- 4. Release clutch-brake pedal fully.
- 5. Depress clutch-brake pedal.
- 6. Place speed control lever in desired positior.
- 7. Place shift lever in one of the forward positions (HIGH or LOW) or REVERSE, and follow r ormal operating procedures.

#### **HIGH-LOW TRANSMISSION RANGES**

HIGH range position is for normal load cond tions, such as mowing or transporting.

LOW range position is for situations which require more torque when the tractor is used under high load conditions, such as tilling, snow removal or hauling heavy loads.

GRASS COLLECTOR Model 190-083 is available as optional equipment for tractors with 46" mowing decks.



WARNING: The mower should not be operated without the entire grass catcher or chute deflector in place.

**NOTE:** Under normal usage bag material is subject to wear, and should be checked periodically. Be sure any replacement bag complies with the mower manufacturer's recommendations.

For replacement bags, use only factory authorized replacement bag.

# **ADJUSTMENTS**



WARNING: Disconnect the spark plug wire and ground against the engine before performing any adjustments, repairs or maintenance.

#### **SEAT ADJUSTMENT**

To adjust the position of the seat, loosen the four self-tapping screws on the bottom of the seat. See figure 1. Slide the seat forward or backward as desired. Retighten the self-tapping screws.


## **SPEED CONTROL ADJUSTMENT (See figure 14)**

**NOTE:** When operating the unit initially or after replacing the belts, there will be little difference between the sixth and seventh speeds until after the belts have gone through a break-in period and have seated themselves into the pulleys.

SHOULD SAY TOP SPD?

If speed control adjustment is needed, adjust the speed control links as follows. (A 1/2" shim or suitable spacer is required.)

- 1. Start the engine.
- 2. Place the shift lever in NEUTRAL position.
- 3. Place the speed control lever in seventh speed position.
- 4. Release the clutch-brake pedal completely, then slowly depress the pedal all the way (to park position). Hold the pedal in this position.
- 5. Turn the engine off.
- 6. After engine stops completely, release the clutch-brake pedal.
- 7. Disconnect the rear speed control link from the variable speed torque bracket by removing the cotter pin and flat washer.
- 8. Place the speed control lever in the first position.
- Disconnect the front speed control link from the variable speed torque bracket by removing the cotter pin and flat washer.



#### FIGURE 14.

- 10. Place a 1/2" shim or other suitable object under the point on the bracket on the clutch-brake pedal as shown.
- 11. Thread the front speed control link in or out of the ferrule until the hole in the link lines up with the pin on the variable speed torque bracket. Secure with the flat washer and cotter pin removed in step 9.
- 12. Push the rear speed control link backward using light pressure, and hold it in this position as you thread it into or out of the ferrule until the hole in the link lines up with the pin on the variable speed torque bracket. Then turn the link clockwise two more times (making it longer).
- 13. Move the speed selector toward the right so the hole in the rear speed control link fits over the pin on the variable speed torque bracket. Secure with the flat washer and cotter pin removed in step 7.
- 14. Remove the 1/2" shim from beneath the bracket on the clutch-brake pedal.

#### LEVELING THE DECK

- 1. Check tire pressure in all four tires. Recommended pressure is approximately 12 p.s.i.
- Make certain all deck wheels are mounted in same relative location.
- 3. On a level surface, engage the PTO and lower the deck until it reaches the ground.

All four deck wheels should reach the ground at the same time. If they do not, adjust the deck links as necessary. **NOTE:** When adjusting the deck links, disengage the PTO. Remove the hairpin clip and washer from the weld bolt. Thread eyebolt up or down the link as necessary, and reassemble.

4. Raise the deck 1/2" to 1" above the ground.

Check to be certain the distance from the bottom edge of the deck to the ground is the same on both sides of the deck. If it is not, adjust the links on the left side of the unit.

Check to be certain the front of the deck is 1/4" to 3/8" lower than the rear of the deck. If it is not, adjust the two front links to obtain this distance.

#### STEERING WHEEL ADJUSTMENT

There are four height positions for the steering wheel. To adjust the height of the steering wheel, remove the hex bolt and hex lock nut on the steering shaft. Place the steering wheel in the position desired and secure with hex bolt and hex lock nut. Refer to figure 4.

**NOTE:** When raising the height of the steering wheel, stretch the steering bellow to cover the steering shaft.

The steering shaft may also be adjusted if there is too much play between the steering gear and segment. To adjust, loosen the hex bolt and nut on the front of the bearing retainer bracket. See figure 15. Pry the bearing retainer bracket toward the right until the steering gear engages solidly into the teeth of the steering segment. Retighten the hex bolt and nut.




FIGURE 15.

### **BRAKE ADJUSTMENT (See figure 16)**

The brake is located on the left side of the transaxle. During normal operation of this machine, the brakes are subject to wear and will require periodic examination and adjustment.



WARNING: Do not adjust the brake while the engine is running. Be sure to block the wheels of the tractor before making the brake adjustment.

To adjust the brake, remove the cotter pin. Adjust the castle nut so the brake starts to engage when the brake lever is 1/4" to 5/16" away from the axle housing.




FIGURE 16.

#### CARBURETOR ADJUSTMENTS



WARNING: If any adjustments are made to the engine while the engine is running (e.g. carburetor), disengage all clutches and blades. Keep clear of all moving parts. Be careful of heated surfaces and muffler.

Minor carburetor adjustments may be required to compensate for differences in fuel, temperature, altitude and load. Refer to separate engine manual for carburetor adjustment information.

**NOTE:** A dirty air cleaner will cause an engine to run rough. Be certain air cleaner is clean and attached to the carburetor before adjusting carburetor.

# **LUBRICATION**



WARNING: Always stop engine and disconnect spark plug wire before cleaning, lubricating or doing any kind of work on lawn tractor.

#### STEERING GEARS

Lubricate teeth of steering gears with automotive multi-purpose grease after every 25 hours of operation or once a season. Refer to figure 15.

#### STEERING SHAFT

Lubricate steering shaft at least once a season with light oil.

### **TRANSAXLE**

The transaxle is lubricated and sealed at the factory and does not require checking. If disassembled for any reason, lubricate with 32 oz. of Shell Darina grease, part number 737-0148 (16 oz. tube).

#### LINKAGE

Once a season lubricate all the pivot points on the clutch, brake and lift linkage with SAE 30 engine oil.

#### WHEELS

The front wheels may be provided with grease fittings. The rear wheels must be removed from the axle for lubrication. Lubricate at least once a season with automotive multi-purpose grease.

#### **PIVOT POINTS**

Lubricate all pivot points with light oil at least once a season.

#### **BALL JOINTS**

The ball joints and drag link ends are permanently lubricated.

# **MAINTENANCE**



WARNING: Disconnect the spark plug wire and ground against the engine before performing any adjustments, repairs or maintenance.

### **TROUBLE SHOOTING**

Refer to the chart on pages 18 and 19 for trouble shooting engine problems.

#### **CRANKCASE OIL**

Check the oil level in the crankcase before each use of the machine and after every two hours of operation. Oil level should be maintained as instructed in the separate engine manual.

After the first two hours of operating a new engine, drain the oil from the crankcase while engine is still hot and refill crankcase with new oil; thereafter change the oil after every 25 hours of operation. Refer to the engine manual.

#### **FUEL FILTER**

Your unit is equipped with a replaceable in-line fuel filter. Replace filter whenever contamination or discoloration is noticed. Order replacement filter through your authorized engine service dealer.

#### WHEEL ADJUSTMENT

The caster (forward slant of the king pin) and the camber (tilt of the wheels out at the top) require no adjustment. Automotive steering principles have been used to determine the caster and camber on the tractor. The front wheels should toe-in 1/8 inch.

Some units have adjustable tie rods so the toe-in can be adjusted. To adjust the toe-in on these units, follow these steps.

- Remove the hex nut and lock washer, and drop the end of the tie rod from the axle bracket. See figure 17.
- 2. Loosen the hex jam nut on tie rod.
- 3. Adjust the tie rod assembly for correct toe-in.




FIGURE 17.—Units with adjustable tie rods

Dimension "B" should be approximately 1/8" less than Dimension "A." See figure 18. To increase Dimension "B," screw tie rod into tie rod end. To decrease Dimension "B," unscrew tie rod from tie rod end. Reassemble tie rod. Check dimensions. Readjust if necessary.




FIGURE 18.—Units with adjustable tie rods

#### **DRAG LINK**

If the drag link or ball joints are changed, the new assembly must be adjusted to the exact same length as the original. If adjusted incorrectly, it will allow the tractor to turn sharper one direction than the other.

To take off the drag link, remove the nuts and lock washers holding the ball joint to the steering gear and right front axle bracket. See figure 17.

#### **ENGINE**

Refer to separate engine manual for all engine maintenance procedures.

#### MAINTENANCE OF BATTERY

- Check electrolyte level periodically (at least every two weeks). Keep the level to the split rings. Use only distilled water or a good quality drinking water. Never add acid or any other chemicals to the battery after initial activation.
- 2. The battery should be checked with a hydrometer after every 25 hours of operation. If the specific gravity is less than 1.225, the battery should be recharged. Maximum charge rate 5 AMPS.
- 3. Coat the terminals and exposed wire with a thin coat of grease or petroleum jelly for longer service and protection against corrosion.
- 4. The battery should be kept clean. Any deposits of acid should be neutralized with soda and water. Be careful not to get this solution in the cells.
- 5. Avoid tipping the battery. Even a "sealed" battery will leak electrolyte when tipped.

#### STORAGE OF THE BATTERY

- 1. Charge battery using normal methods. NEVER store discharged battery as it will not recover.
- When storing battery for extended periods, disconnect battery cables. Removing battery from unit is recommended.
- 3. Store in cold, dry place.

4. Recharge battery whenever the specific gravity is less than 1.225, before returning to service, or every two months, whichever occurs first.

#### **COMMON CAUSES FOR BATTERY FAILURE**

- 1. Overcharging
- 2. Undercharging
- 3. Lack of water
- 4. Loose hold downs and/or corroded connections
- 5. Excessive loads
- 6. Battery electrolyte substitutes
- 7. Freezing of electrolyte

NOTE: These failures do not constitute warrant /.

#### BATTERY REMOVAL OR INSTALLATION



WARNING: When removing the battery, follow this order of disassembly to prevent your wrench from shorting against the frame.

- 1. Remove the Negative cable.
- 2. Remove the Positive cable.

To install a battery:

- 1. Attach the Positive cable.
- 2. Attach the Negative cable.

#### **JUMP STARTING**

- 1. Attach the first jumper cable from the Positive terminal of the good battery to the Positive terminal of the dead battery.
- Attach the second jumper cable fron the Negative terminal of the good battery to the FRAME OF THE UNIT WITH THE DEAL BAT-TERY.



WARNING: Failure to use this starting procedure could cause sparking, and the gases in either battery could explore.

#### **TIRES**

Recommended operating tire pressure is approximately 12 p.s.i. (check sidewall of tire for tire manufacturer's recommended pressure). Maximum tire pressure under any circumstances is 30 p.s.i. Equal tire pressure should be maintained on all tires.

When installing a tire to the rim, be certain rim is clean and free of rust. Lubricate both the tire and rim generously. Never inflate to over 30 p.s.i. to seat beads.




WARNING: Excessive pressure (o'er 30 p.s.i.) when seating beads may cause tire/rim assembly to burst with force sufficient to cause serious injury.

#### **BELT REPLACEMENT**


#### **Front Drive Belt**

- 1. Depress the clutch pedal and set parking brake.
- 2. Remove the deck from the tractor.
- 3. Raise and block the front wheels of the tractor so you can work under it.
- 4. Remove the four self-tapping screws which hold the belt keeper assembly to the frame at the engine pulley. Push the belt keeper assembly forward, out of the way. See figure 19.



#### FIGURE 19.

- 5. Remove the two pins which act as belt keepers by the variable speed pulley. See figure 20.
- 6. Roll the belt off the variable speed pulley, then remove from the engine pulley.
- 7. Reassemble the new belt, following instructions in reverse order.



#### FIGURE 20.

#### Rear Drive Belt

1. First remove the front drive belt as instructed in the previous section.

- 2. Disconnect the spring which secures the idler pulley to the frame.
- Remove the transmission cover by unscrewing the two knobs, and removing two truss machine screws.
- 4. Roll the belt over the top of the transmission pulley. Remove belt from the variable speed pulley.
- Reassemble the new belt, following instructions in reverse order.

# **OFF-SEASON STORAGE**

If the machine is to be inoperative for a period longer than 30 days, prepare for storage as follows.

1. Clean the engine and the entire unit thoroughly.

- 2. Lubricate all lubrication points. Wipe the entire machine with an oiled rag to protect the surfaces.
- Refer to the engine manual for correct engine storage instructions. The engine must be completely drained of fuel to prevent gum deposits from forming on essential carburetor parts, fuel lines and fuel tanks.
- 4. Refer to battery storage instructions on page 15.
- 5. Store unit in a clean, dry area.


**NOTE:** When storing any type of power equipment in an unventilated or metal storage shed, care should be taken to rustproof the equipment. Using a light oil or silicone, coat the equipment, especially any chains, springs, bearings and cables.

# TROUBLE SHOOTING GUIDE

TROUBLE	LOOK FOR	REMEDY
Engine will not crank	Battery installed incor- rectly	The battery must be installed with the negative terminal, identified at the terminal post by (Neg, N or –), grounded. The positive terminal (Pos, P or +) attaches to the large cable from the solenoid. The small red wire from the fuse holder or circuit breaker is also attached to the positive terminal.
	Blown fuse or circuit breaker	Replace fuse vith 7-1/2 amp. automotive type fuse. Fuses seldom fail without a reason. The problem must be corrected. Check for loose connections in the fuse holder. Replace fuse holder if necessary. A dead short may be in the cranking or charging circuit where the insulation may have rubbed through and exposed the bare wire. Replace the wire or repair with electrician's tape if the wire strands have not been damaged.  Note: Look for a wire pinched between body panels, burned by the exhaust pipe or muffler or rubbed against a moving part.
	Battery is dead or weak	Use a hydrom ster to check the condition of the battery. The Specific Gravity (s.g.) should be 1.265 at 80°F. (1.215 s.g. minimum needed for cranking engine). The reason for the battery failing must be determined. (1) Defective battery. Battery will not accept or hold a full charge. (2) Short circuit. Check for grounded vire. (3) Charging system not working.
		The charging system is an alternator located under the flywheel. It is unregulated and rated 3 amp. at 3600 r.p.m. A diode (rectifier) is located in the output lead just before the wire harness plug on the engine side.
		Shrink 3 AMP DC Wire Diode Tube (Batt.)
		To Alternator  Black Wire  Polarized Plug
		The diode changes A.C. to D.C. to charge the battery. A bad diode can either fail to charge the battery or discharge the battery if the alternator is shorted as well as the diode. To test: (1) Disconnect charger lead from the battery (small red wire). (2) Connect 12 V small test lamp between the 3 amp. D.C. charge lead ar d the positive terminal of the battery. (3) With the engine off, the lamp should not light. If it does, the dic de and possibly the alternator should be replaced. (4) Start the engine. The lamp should light. If it does not, the alternator (stator) or lead wire is bad and should be replaced.
	Mechanical failure (Wires and switches)	The interlock system includes two mechanical activated switches which are wired in series in the circuit used to energize the starter solenoid. While testing the interlock system, you will make the mower temporarily unsafe by permitting the engine to be started with the blade and clutch engaged. WARNING: While testing, disengage the clutch, shut off the blade control, set the parking brake and place the gear shift lever in neutral. Attach a wire (minimum 18 gauge) to the positive terminal of the battery and torach the other end to the small terminal on the solenoid. If the engine does not crank:  (1) There is a loose connection or poor ground. (2) The solenoid may be bad. The solenoid can be checked by using a heavy wire (#8 gauge minimum) and jumping between the two large terminals. If the engine cranks, the solenoid is bad. (3) If the engine does not crank when you jump the solenoid, have the starter motor tested by an authorized engine dealer. If the engine does crank, the problem is with one of the safety switches, ignition switch or the wire between the fuse holder (or circuit breaker) and the small reminal on the solenoid. Note: Look for a poor connection at the switches or a defective switch. Replac if necessary.
Engine cranks but will not start	Throttle or choke not in starting position	Check owner's guide for correct position for throttle control and choke for starting.
	No spark to spark plug	Spark plug lead disconnected. Connect lead. Hold spark plug lead away from engine block about 1/8". Crank engine. There should be a spark. If not, have engine repaired at authorized engine service dealer.
		Faulty spark p ug. To test, remove spark plug. Attach spark plug lead to spark plug. Ground the spark plug body against the engine block. Crank the engine. The spark plug should fire at the electrode. Replace if it does not.

# **TROUBLE SHOOTING GUIDE (Continued)**


TROUBLE	LOOK FOR	REMEDY
	No fuel to the carburetor	Gasoline tank empty. Fill.  Fuel line or in-line fuel filter plugged. Remove and clean fuel line. Replace filter if necessary.
	Air filter dirty	If the air cleaner is dirty, the engine may not start. Clean or replace as recommended by the engine manufacturer.
Engine smokes	Engine loses crankcase vacuum	Dipstick not seated or broken. Replace defective part. Engine breather defective. Replace.
Excessive vibration	Bent or damaged blade spindle	Stop engine immediately. Check all pulleys, blade adapters, keys and bolts for tightness and damage. Tighten or replace any damaged parts.
	Bent blade	Stop engine immediately. Replace damaged blade. Only use original equipment blades.
Mower will not discharge grass or leaves uncut strips	Engine speed low Transmission selection Blades short or dull	Throttle must be set at full throttle. Use lower transmission speed. The slower your ground speed, the better the quality of cut. Sharpen or replace blades (uncut strip problem only).



#### PARTS LIST FOR ELECTRICAL SYSTEM

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	725-1635		Battery (275 Cold Crank Amps)	12	725-0963		Lamp
2	725-1426		Solenoid	13	725-1649	N	Socket (Style 0, 6)
3	725-1625	N	Fuse 7.5 Amp		725-1650	N	Socket (Style 2, 3, 4, 8, 9)
4	725-0925		Ammeter† '	14	629 <del>-2890</del>	N	Wire Harness Used w/Ammeter
5	725-0267		Ignition Switch		<b>9</b> 687		& Light Switch
6	725-0634		Light Switch†		629-0075	N	Wire Harness Used w/o
7	725-3169A		Safety Switch (Clutch)				Ammeter & Light Switch
8	725-0465A		Safety Switch (PTO)	15	725-1643	N	Spring Switch (Reverse)
9	725-0561		Electric Wire 14" Lg.	16	725-1303		Spring Switch (Seat)
11	725-0996		Ground Wire 7.5" Lg.	17	725-1439	-	Spring Switch (Seat)

†Optional Parts



#### PARTS LIST FOR MODELS 840 THRU 849 GARDEN TRACTORS

REF NO.		CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	16512		Steering Column Ass'y.	42	16915		Front Axle Ass'y.—L.H.
2	738-0763		Lower Steering Shaft	43	16914		Front Axle Ass'y.—R.H.
3	710-0958		Hex Bolt 1/4-20 x 1.31" Lg.	44	736-0286		Bowed Washer
4	712-0324		Hex L-Nut 1/4-20 Thd.	45	748-0160		Spacer .755" I.D. x 1.25" O.D.
5	712-0318		Hex Jam Nut 5/8-18 Thd.*	46	710-0331		Hex Bolt 3/8-24 x 2.25" Lg.
6	717-0943A		Steering Gear Segment	47	712-0798		Hex Nut 3/8-16 Thd.*
7	736-0317		Bell-Wash. 5/8" I.D. x 1.25" O.D.	48	**		Bearing
8	712-0241		Hex Nut 3/8-24 Thd.	49	736-0316		Fl-Wash71" I.D. x 1.5" O.D.
9	712-0711		Hex Jam Nut 3/8-24 Thd.	50	**		Wheel Ass'y. Comp.
10	736-0169		L-Wash. 3/8" I.D.*		**		Tire Only
11	738-0768		Steering Gear Segment Shaft	51			Rim Only
12	736-0187		Fl-Wash64" I.D. x 1.24" O.D.	52	726-0271		Push Nut
13	748-0227A		Hex Flange Brg63" I.D.	53	711-0222		Battery Hold Down Rod
14	723-3018		Ball Joint Ass'y.	54	17635		Battery Plate
15	710-0599		Hex Wash. Hd. TT-Tap Scr.		17634		Battery Plate (840 Only)
1.0	10000		1/4-20 x .5" Lg.	55	710-0258		Hex Bolt 1/4-20 x .62" Lg.*
16	16888		Deck Idler Support Brkt.	56	736-0329		L-Wash. 1/4" I.D.*
17	736-0343		Fl-Wash33" I.D. x 1.25" O.D.	57 58	712-0287		Hex Nut 1/4-20 Thd.*
18	750-0532		Spacer .985" I.D. x 1.25" O.D.	58 59	725-1635		Battery (275 Cold Crank Amps)
19	736-0119		L-Wash. 5/16" I.D.*	60	731-1132 712-0113		Battery Cover Wing Nut Plastic 1/4-20 Thd.
20	712-0123		Hex Nut 5/16-24 Thd.* Bell-Wash345" I.D. x .88" O.D.	61	712-0113 731-0954		
21 22	736-0242		Bearing Retainer Brkt.	0,1	731-0954		Steering Bellow (840, 844, 846 & 849)
23	16894		Hex Bolt 5/16-24 x .75" Lg.		731-0559	٠,	Steering Bellow (842, 843 & 848)
24	710-0157 710-0793		Ribbed Neck Bolt 3/8-24 x .8" Lg.	62	710-0459	**	Hex Bolt 3/8-24 x 1.5" Lg. (Gr. 5)
25	710-0793		Hex Wash. TT-Tap Scr.	64	731-0805		Steering Wheel (3 Spoke)
23	710-0004		5/16-18 x .62" Lg.	04	731-0806A		Steering Wheel (4 Spoke)
26	747-0579		Steering Drag Link	65	731-0220		Steering Wheel Cap
27	16896		Pivot Bar Side Plate—R.H.	66	712-0237		Hex L-Nut 5/16-24 Thd.
28	16897		Pivot Bar Side Plate—L.H.	67	17359A		Lower Frame
29	710-0538		Hex Bolt 5/16-18 x .62" Lg.	68	731-1049		Pivot Bar End Cap†
30	16918		Steering Arm	69	737-0280		Grease Fitting†
31	738-0777		Deck Connecting Rod	70	714-0149B		Internal Cotter Pin
32	738-0775		Pivot Bar Shld. Bolt 3/8-16 x	71	731-0484A		Hub Cap
			5/8" Lg.		734-1 <del>503</del> I	504	Hub Cap (5 Spoke)†
33	731-0484A		Cap	72	727-0425	,	Spring Clip† '
34	714-0121		Cotter Pin 5/32" Dia.	73	710-0837		Oval Hd. CrSunk Scr. #10 x
35	736-0316		Flat Washer				5/8" Lg. (Not Used on Styles
36	741-0523		Flange Brg757" I.D.				0, 4, 6, 9)
37	747-0721		Tie Rod 20.25" Lg. (Adjustable)	74	741-0356		Flange Brg89" I.D. x 1.36"
	747-0862	N	Tie Rod 21.83" Lg. (Non-				O.D. (Not Used on Styles
			Adjustable)				0, 4, 6, 9)
38	16843		Pivot Bar Assy.	75	**		Air Valve
39	16889		Pivot Bar Support Brkt.—Front	76	710-0776A		Hex AB-Tap Scr. 1/4 x .62" Lg.
40	16890		Pivot Bar Support Brkt.—Rear	77	712-0446		Hex Jam L-Nut 3/8-24 Thd.
41	736-0188		FI-Wash76" I.D. x 1.49" O.D.			L	


†Optional Parts

\*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

#### \*\*FRONT WHEEL CHART


Description	16" x 6.5" w/Plastic Bearing	16" x 6.5" w/Ball Bearing
Wheel Ass'y. Comp.	734-1500A	734-1722
Tire Only	734-0275	734-0275
Rim Only	734-1501A	734-1688
Bearing	741-0516	741-3032
Air Valve	734-0255	734-0255
Grease Fitting	737-0280	737-0280

**Note:** If brand of tire is important, order by part number and description (description is printed on the sidewall of tire) [i.e. Armstrong Super Turf, Goodyear Softrac, Carlisle Turf Saver, etc.].



# PARTS LIST FOR MODELS 840 THRU 849 GARDEN TRACTORS

REF.	PART	CODE	DESCRIPTION	REF.	PART	CODE	DESCRIPTION
NO.	NO.			NO.	NO.		
1	17343		Hitch Plate	58	17962		Switch Plate
2	710-0726		Hex AB-Tap Scr. 5/16" x .75"	59	732-0698		Ext. Spring 5.2" Lg.
3	738-0482		Hitch Rod	60	736-0156		Fl-Wash635" I.D. x 1.12" O.D.
4	714-0147		Hitch Pin Clip	67			Deck Control Rod (Refer to
5	712-0267		Hex Nut 5/16-18 Thd.*	-	700 0100		Style Sheet)
6	736-0119		L-Wash. 5/16" I.D.*	68 69	720-0166		Ball Knob Brake Bell-Wash. 9/16" I.D. x 1.25"
7 8	17340 710-3008		Transaxle Bracket Hex Bolt 5/16-18 x .75" Lg.	70	736-0427 756-0534		V-Pulley 91/4" O.D.
0	710-3006		(Gr. 5)	71	710-0539		Hex Bolt 3/8-24 x 1.75" Lg.
9	732-0601		Brake Extension Spring	72	732-0614		Wire Ring
10	711-0723A		Adjustment Ferrule 3/8-24 Thd.	73	738-0769		Shld. Bolt 5/16-24 Thd.
11	736-0267		FI-Wash385" I.D. x .87"	74	16904		Idler Brkt. Ass'y.
13	747-0729		Speed Control Link (Rear)	75	756-0542		Flat Idler 3.5" Ó.D.
14	736-0192		Fl-Wash531" l.D. x .94"	76	732-0384		Extension Spring 6.12" Lg.
15	16906		Speed Selector Lever Ass'y.	77	754-0362		V-Belt
16	738-0155		Shld. Bolt .437" Dia. x .162"	78	736-0414		Teflon Washer 1.20" O.D.
17	710-0672		Hex Bolt 5/16-24 x 1.25" Lg.	79	717-0945		Variable Speed Pulley 6" Dia.
18	732-0429A		Extension Spring 3.9" Lg.	80	754-0358		V-Belt
19	712-3057		Hex Nut 5/16-24 Thd. (Gr. 5)	81	738-0778		Pivot Bushing
20	710-0620		Hex Bolt 3/8-24 x 4.5" Lg.	82	736-0355		Fl-Wash56 I.D. x 1.0 O.D.
21	732-0603		Extension Spring 11" Lg.	83	741-0405		Thrust Brg56" I.D. x 1.25"
22	738-0779		Shld. Bolt .625" Dia. x 3.5" Lg.	84	17485		Retainer Cup
23	747-0726		Speed Control Link (Front)	85	13887		Deck Control Pivot Brkt.
24	710-0157		Hex Bolt 5/16-24 x .75" Lg.	86 87	13833		Parking Brake Mtg. Brkt.
25 26	735-0196		Foot Pad	88	736-0105 738-0129		Bell-Wash38" I.D. x .88" O.D. Shld. Bolt .498" Dia. x 2.05"
20 27	747-0722 17914		Parking Brake Link Variable Speed Torque Brkt.	89	732-0478		Extension Spring 6.12" Lg.
1	17314		Ass'y.	90	732-0308		Extension Spring 6.37" Lg.
28	732-0568		Extension Spring 2.59" Lg.	91	731-0483		Convoluted Conduit 4" Lg.
29	17908		Pulley Plate Ass'y.	92	712-0214		Hex Cent. L-Nut 3/8-24 Thd.
30	741-0591		Flanged Brg630" I.D.	93	756-0293A		V-Belt Idler
31	732-0395		Extension Spring 2.51" Lg.	94	714-0104		Internal Cotter Pin
32	710-0528		Hex Bolt 5/16-18 x 1.25" Lg.*	95	748-0278		Spacer
33	750-0214		Spacer .34" I.D. x .88"	96	14076A	1	Idler Brkt. Deck Ass'y.
34	16980		Brake Lockout Bracket	97	710-0459		Hex Bolt 3/8-24 x 1.5" Lg.
35	16924A		Clutch Ass'y. Mtg. Bracket	98	710-0599		Hex TT-Tap Scr. 1/4-20 x .5"
36	741-0225		Hex Flange Brg634" I.D.	99	756-0531A	N	Engine Pulley
37	748-0234		Shld. Spacer .5" Dia.	100	714-0118		Sq. Key 1/4 x 1.5" Lg.
38	736-0187		FI-Wash64" I.D. x 1.24"	101	736-0242		Bell-Wash345" I.D. x .88"
39	710-0118		Hex Bolt 5/16-18 x .75" Lg.*	102 103	710-0833		Hex Bolt 5/16-18 x 5.25" Lg. Belt Keeper Brkt. Ass'y.
40 41	710-0436 736-0185		Hex B-Tap Scr. #10 x 5/8 Lg. Fl-Wash406" I.D. x .75" O.D.	103	17358C 711-0829		U-Bolt
42	714-0115		Cotter Pin 1/8" Dia.	105	710-0523		Hex Bolt 5/16-24 x 2.25" Lg.
43	736-0275		FI-Wash34" I.D. x .68" O.D.	106	16888		Deck Idler Support Brkt.
44	714-0111		Cotter Pin 3/32" Dia.	107	736-0264		Fl-Wash344" I.D. x .62" O.D.
45	17910		Foot Pedal Ass'y.	108	16979		Front Trans. Support Brkt.—L.H.
46	736-0169		L-Wash. 3/8" I.D.*	109	712-0123		Hex Nut 5/16-24 Thd.*
47	712-0241		Hex Nut 3/8-24 Thd.	110	16978		Front Trans. Support Brkt.—R.H.
48	736-0329		L-Wash. 1/4" I.D.*	111	717-0985		Shift Lever Ass'y. Complete
49	712-0287	-	Hex Nut 1/4-20 Thd.*	112	710-1048		Socket Hd. Cap Scr. #10 x 24
50	17349		Brake Link Bracket	113	618-0009	N	2-Speed Transmission Comp.
51	747-0724		Front Brake Rod Link	114	736-0258		Fl-Wash. 3/8" I.D. x 1.0" O.D.
52	712-0375		Hex Cent. L-Nut 3/8-16 Thd.	118	741-0419		Nyliner Flanged Brg.
53	710-0501		Hex Bolt 1/4-20 x 2.0" Lg.	119	17180		Variable Speed Support Brkt.
54	711-0828		Belt Guard Pin	120	725-3169A		Safety Switch (Clutch)
55	720-0218		Shift Knob	121	711-0832		Adjustment Ferrule 3/8-24 Thd.
56	712-3035		Hex Jam Nut 9/16-18 Thd.	122	736-0204		FI-Wash344" I.D. x .62" O.D.
57	17912		Foot Pedal Brkt. Ass'y.				



### PARTS LIST FOR MODELS 840 THRU 849 GARDEN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	720-0233		Grip	34	711-0817		Eye Bolt Adj. Link 1/2-13 Thd.
2	17282		Lift Handle Ass'y.	36	712-0158		Hex Cent. L-Nut 5/16-18 Thd.
3	710-0442		Hex Bolt 5/16-18 x 1.5" Lg.*	37	710-0237		Hex Bolt 5/16-24 x .62" Lg.*
4	748-0274A		Lift Shaft Drive	38	736-0119		L-Wash. 5/16" I.D.*
5	741-0225		Plastic Hex Brg. 5/8" I.D.	39	712-0181		Hex Top L-Nut 3/8-16 Thd.
6	14231		Index Brkt. Deck Lift	40	732-0369		Compression Spring
7	737-0164		Pipe Nipple 3/8-18 Npt.	41	738-0777		Deck Connecting Rod
8	737-0143		Pipe Cap 3/8-18 Npt.	42	712-0287		Hex Nut 1/4-20 Thd.*
9	714-0118		Sq. Key 1/4" x 1/4" x 1.50" Lg.	43	14170		Index Brkt. Reinforcement
10	736-0163		FI-Wash. 1.03" I.D. x 1.62" O.D.				Plate
11	736-0171		L-Wash. 7/16" I.D.	46	726-0273		Mounting Clamp
12	710-0757		Hex Scr. 7/16-20 x 1.50" Lg.	47	731-0556	س م	Hub Cap
13	750-0762		Spacer 1.0" I.D. x 1.25" O.D.			1505	Hub Cap (5 Spoke—Optional)
14	13889		Lift Shaft Ass'y.	48	710-0599		Hex Wash. Hd. TT-Tap Scr.
15	13895		Lift Pivot Brkt. Ass'y.				1/4-20 x .5" Lg.
16	17303		Adj. Deck Lift Link	50	714-0111		Cotter Pin .09 Dia. x 1.0" Lg.
17	736-0192		Fl-Wash. 1/2" I.D. x 1.00"	51	714-0149B		Int. Cotter Pin
			O.D. x .090"	52	736-0231		Flat Wash34" I.D. x 1.12"
18	714-0101		Hairpin Cotter				O.D. x .125"
19	741-0295		Nyliner 5/8" I.D. x .88" Lg.	53	710-0600		Hex Wash. Hd. AB-Tap Scr.
20	738-0445		Shld. Bolt 5/8" Dia. x .96"				5/16-24 x .5" Lg.
			Lg. 3/8-16	54	712-0206		Hex Nut 1/2-13 Thd.
21	13790		Connecting Link	55	14399		Deck Link
22	714-0142		Cotter Pin 3/16" Dia. x 1.5" Lg.	56	736-0264		Fl-Wash344" I.D.
23	736-0322		Flat Wash44" I.D. x 1.25"	57	736-0219		Bell-Wash4" I.D. x 1.13" O.D.
			O.D. x .17"	60	710-0118		Hex Bolt 5/16-18 x .75" Lg.*
24	756-0531A	N	Two-Step Engine Pulley	63	736-0329		L-Wash. 1/4" I.D.*
25	710-0502A		Hex Wash. Hd. Scr. 3/8-16 x	65	751-0535-4	ŀ6	Fuel Line 46" Lg.
			1.25" Lg.	66	726-0205		Hose Clamp
26	710-0726		Hex Thd. Rolling Scr. 5/16-18	67	710-0776A		Hex AB-Tap Scr. 1/4 x .62" Lg.
			x .75" Lg.	68	17424		Fuel Tank Strap
27	738-0435		Running Board Rod	69	751-0566_	N N	Gas Tank
28	726-0272		Clamp	70	751-0531B		Gas Gauge
29	734-0255		Air Valve	71	16848C	N	Seat Plate
30	734-1005A		Rear Wheel Ass'y. Comp.	72	17343		Hitch Plate
	734-0322		Tire Only	73	738-0482		Hitch Rod
31	734-1015		Rear Wheel Rim Only	74	726-0272		Hose Clamp
32	736-0345		Flat Washer	75	727-0425		Spring Clip (Optional)
33	710-0258		Hex Bolt 1/4-20 x .62" Lg.	76	714-0120	ļ.	Sq. Key 1/4" x 3" Lg.

\*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.



This instruction manual covers various models, and all specifications shown do not necessarily apply to your model. Specifications subject to change without notice or obligation.

NOTE: The engine is not under warranty by the mower manufacturer. . .If repairs or service is needed on the engine, please contact your


nearest authorized engine service outlet. Check the "Yellow Pages" of your telephone book under "Engines-Gasoline."



**CODE:** N notates a **new part** (not previously existing). A three digit number is the **color code**. Specify color code as shown below if color or finish is important when ordering parts. [i.e., 638 for Red Finish].

#### **Color Codes**

	The second secon
456—Radiant Tangerine	637—Black
460Green Flake	638—Red
483—Charcoal Gray	640—Green
498—Yellow	646—CM Blue
499Beige	657—Teal
629—Silver Flake	



### PARTS LIST FOR MODEL 618-0009 TRANSAXLE

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	17434		Brake Return Bracket	46	712-0335		Castle Nut 5/16-24 Thd.
2	710-0809		Hex Bolt 1/4-20 x 1.25" Lg.	47	717-0700		Brake Actuating Arm
3	710-0009		Hex Bolt 1/4-20 x 1.5" Lg. (Gr. 5)	48	717-0796		Sq. Hd. Bolt 5/16-24 Thd.
4	710-3201		Hex Wash. Tap Scr. 1/4-20 x .5"	49	717-1179		Brake Yoke
4	710-0399		Lg.	50	736-0371		FI-Wash. 11/32" I.D. x 7/8" O.D.
6	717-0678		Brake Puck	51	741-0343		Brake Actuating Pin
7	717-0678		Puck Plate	53	713-0326		#420 Chain 1/2 Pitch x 28 Links
8	716-0171		Retainer Ring	54	716-0149		Retainer Ring
9	717-1164		Upper Housing	55	717-1141		Reverse Sprocket Ass'y.
10	721-0253		Oil Seal	57	717-1157		Bevel Gear 47T
11	741-0525		Needle Brg. 5/8" I.D. x 7/8"	58	711-0860	N	Drive Shaft
''	741-0525		O.D.	59	717-1174		Spur Gear Ass'y.
12	716-0114		Snap Ring	61	717-1182		Sprocket 22T
13	717-1133		Input Pinion 15T	62	736-0421		FI-Wash81" I.D. x 1.18" O.D.
14	717-1134		Input Shaft	63	717-1155		Spur Gear 31T
15	732-0614		Wire Ring	64	717-1156		Spur Gear 45T
16	736-0335		Thrust Washer 5/8" I.D.	65	717-1158		Output Shaft 9T
17	736-0419		Thrust Washer	66	717-1172		Spacer
18	741-0469		Thrust Bearing	67	718-0183	N	Shift Spring Plug
19	717-1161		Lower Housing	69	717-1167B	N	Forward Shift Collar
20	717-1166		Shift Guide	70	717-1184		Drive Pin
21	710-0151		Hex Bolt 3/8-24 x 2.0" Lg.*	71	732-0590A		Drive Spring
22	712-3054		Hex L-Nut 3/8-24 Thd. (Gr. 5)	7 <u>2</u> 73	717-1168B	N	Creeper Shift Collar
23	717-1120		Differential Gear 10T		717-1193		Creeper Collar Plate Ass'y.
24	717-1147		Differential Housing Cover Ass'y.	76	736-0353		FI-Wash65" I.D. x .97" O.D.
26	716-0172		Retainer Ring	77	**		FI-Wash. (See Below)
27	717-1112		Axle R.H.	78	736-0424		FI-Wash. 1.0" I.D. x 1.56" O.D.
28	717-1119		Differential Gear 14T	80	732-0545	l	Ext. Spring 1.14" Lg.
29	717-1159		Differential Bull Gear 60T	81	732-0659	N	Detent Spring
30	717-1111		Axle L.H.	82	736-0329		L-Wash. 1/4" I.D.*
31	717-1173		Cross Shaft	83	736-0349		FI-Wash. 5/8" I.D. x 1.0" O.D.
32	717-1178		Cross Shaft—Special	84	736-0422		FI-Wash68" x 1.12"
33	717-1180		Differential Pinion Block	87	741-0124		Ball Brg669" I.D.
34	717-1190		Differential Thrust Block	88	741-0524		Ball Bearing
35	736-0413		Spr. Wash39" I.D. x .62" O.D.	89	741-0862		Ball Detent .25" Dia.
36	717-1138		Shift Pin	90	750-0555		Spacer .254" I.D. x .5" O.D.
37	717-1139		Spring Plate	91	736-0333		Fi-Wash69" I.D. x 1.06" O.D.
38	741-1143		Axle Bearing Ass'y.	92	i		FI-Wash. (See Below)
40	717-1144		Axle Bearing Ass'y.	93	710-1225		Hex Wash Hd. Patch Bolt
41	717-1177		Brake Disc	1 01	750 0000		1/4-20 x 2-1/4" Lg.
42	717-1185		Shift Arm Ass'y.—R.H.	94	750-0893		Spacer .256" I.D. x .75" O.D. Shell Darina Grease 14 oz. Tube
43	717-1186		Shift Arm Ass'y.—L.H.	-	737-0148		(32 oz. Reg'd.)
45	714-0111		Cotter Pin 3/32" Dia.		L	1	(SZ UZ. Med u.)


IF UNIT MAKES A CLICKING Noise REPLACE BOTH SHIFT COLLARS WITH NEW PARTS

\*\*\* Ref. No. 92 736-0349 Fl-Wash. 5/8" l.D. x 1.0" O.D. x .020" Thk. 736-0336 Fl-Wash. 5/8" l.D. x 1.0" O.D. x .030" Thk. 736-0337 Fl-Wash. 5/8" l.D. x 1.0" O.D. x .040" Thk.

717-1188B + 717-1187B

2000 UNITS MADE THIS I TAB ON SHIFT FORK HITS GROOVE ON COLLAR

27



PARTS LIST FOR MOLELS 840 THRU 849 GARDEN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	738-0296		Shld. Bolt .437" Dia. x .162"	26	15846		Fender Bracket—R.H.
2	736-0141		Spr. Wash445" I.D.		15847		Fender Bracket—L.H.
3	732-0581B	N	Ext. Spring 5.31" Lg.		17406		Fender Bracket—R.H.
4	736-0119		L-Wash. 5/16" I.D.*				(849 Only)
5	712-0267		Hex Nut 5/16-18 Thd.*		17407		Fender Bracket—L.H.
6	710-0601		Hex Wash. Hd. Tap Scr.				(849 Only)
_			5/16-18 x .7" Lg.	27	736-0242		BeÌl-Wash345" I.D. x .88"
7	736-0159		Fl-Wash344" I.Ď.				O.D.
8	722-0160		Bushing	28	710-0323		Truss Mach. Scr. 5/16-18 x
9	732-0588		Compression Spring				.75" Lg.
10	17702		Seat Pivot Brkt. Support —R.H.	29	710-1012		Rib Neck Bolt 5/16-24 x .75" Lg.
11	710-0726		Hex Wash. Hd. AB-Tap Scr.	30	738-0435		Running Board Rod
			5/16 x .75" Lg.	31	16922		Running Board—R.H.
12	710-0227	-	Hex Wash. Hd. AB-Tap Scr.		16921		Running Board—L.H.
			_ #8 x .5" Lg.	32	712-0123		Hex Nut 5/16-24 Thd.
13	710-1228		Torx Hd. AB-Tap Scr. 5/16-18 x	33	726-0139		Speed Nut #10Z
	705 4000		.75" Lg.	34	17360		R.H. Side Frame
14	725-1303		Spring Switch	35	17361A		L.H. Side Frame
15	726-0279		Insulator Plate	36	17359A		Lower Frame
16	738-0155		Shld. Bolt .437" Dia. x .162"	37	731-1052		Rubber Foot Pad (Optional)
17	17701		Seat Pivot Brkt. Support -L.H.	38	757-0345		Seat 8-7/8" High
18 19	16848C	N	Seat Plate		757-0350		Seat 14-1/4" High
19	710-0351		Truss Mach. B-Tap Scr.		757-0338		Seat 10-5/8" High
20	731-0405		#10 x .5" Lg.	39	15607D		Seat Pivot Bracket
21	725-1643	N	Snap Bushing	40	710-0623		Hex Tap Scr. 3/8-16 x .75" Lg.
22	120-1043	IN	Reverse Safety Switch	41	831-0823A		Throttle Control Box Ass'y.
~~			Shift Cover (Refer to Style	42	746-0634		Throttle Control Wire 35" Lg.
23	736-0329		Sheet) L-Wash. 1/4" I.D.*	43	17239A		Seat Lift Bracket
24	712-0287		Hex Nut 1/4-20	44	725-1439		Seat Spring Switch
25	710-0118		Hex Bolt 5/16-18 x .75" l.g.	45 46	726-0278	N.	Insulator Boss Plate
	7 10-0110		TIEN DOIL 3/10-10 X ./3 L.g.	40	726-0320	N	Insulator Nut Plate

FOR REPLACEMENT PARTS, CONTACT:
SERVICE DEPARTMENT • P.D. BOX 360900 • CLEVELAND, OHIO 44136