






ROLLER COMPACT



IMPORTANT INFORMATION
Read before use
& retain for future reference

For all customer enquiries or for replacement parts, contact:-

☎ 0870 609 1901


🖱 www.flymo.com




customer.services@husqvarna.co.uk

Carton Contents

ROLLER COMPACT 340/3400/400



ROLLER COMPACT 4000



IMPORTANT! Please check the contents of the carton are correct BEFORE assembling your new Flymo product. IF ANY PARTS ARE MISSING CONTACT:-

Husqvarna Outdoor Products Customer Service Department direct
Telephone : 0870 609 1901

Safety



If not used properly this lawnmower can be dangerous! This lawnmower can cause serious injury to the operator and others, the warnings and safety instructions must be followed to ensure reasonable safety and efficiency in using this lawnmower. The operator is responsible for following the warning and safety instructions in this manual and on the lawnmower. Never use the mower unless the grass-box or guards provided by the manufacturer are in the correct position.

Explanation of Symbols on the Roller Compact



Warning



Read the user instructions carefully to make sure you understand all the controls and what they do.



Always keep the lawnmower on the ground when mowing. Tilting or lifting the lawnmower may cause stones to be thrown out



Keep bystanders away. Do not mow whilst people especially children or pets are in the mowing area



Switch off! Remove plug from mains before adjusting, cleaning or if cable is entangled or damaged. Keep the cable away from the blade.



Beware of severing toes or hands. Do not put hands or feet near a rotating blade.



Blade continues to rotate after the machine is switched off. Wait until all machine components have completely stopped before touching them.



Do not mow in the rain or leave the lawnmower outdoors while raining



(RC3400/4000 only)
Unwind and remove fully before use.

General

1. Never allow children or people unfamiliar with these instructions to use the mower. Local regulations may restrict the age of the operator.
2. Only use the lawnmower in the manner and for the functions described in these instructions.
3. Never operate the lawnmower when you are tired, ill or under the influence of alcohol, drugs or medicine.
4. The operator or user is responsible for accidents or hazards occurring to other people or their property.

Electrical

1. The British Standards Institute recommend the use of a Residual Current Device (R.C.D.) with a tripping current of not more than 30mA. Even with a R.C.D. installed 100% safety cannot be guaranteed and safe working practice must be followed at all times. Check your R.C.D. every time you use it.
2. Before use, examine cable for damage, replace it if there are signs of damage or ageing.
3. Do not use the lawnmower if the electric cables are damaged or worn
4. Immediately disconnect from the mains electricity supply if the cable is cut, or the insulation is damaged. Do not touch the electric cable until the electrical supply has been disconnected. Do not repair a cut or damaged cable. Replace it with a new one.
5. Your extension cable must be uncoiled or unwound, coiled or wound cables can overheat and reduce the efficiency of your mower.
6. Keep cable away from lawnmower, always work away from the power point mowing up and down, never in circles.
7. Do not pull cable around sharp objects.
8. Always switch off at the mains before disconnecting any plug, cable connector or extension cable.
9. Switch off, remove plug from mains and examine electric supply cable for damage or ageing **before** winding cable for storage. Do not repair a damaged cable, replace it with a new one. Use only Flymo replacement cable.
10. Always wind cable carefully, avoiding kinking.
11. Never carry the product by the cable.
12. Never pull on the cable to disconnect any of the plugs.
13. Use only on AC mains supply voltage shown on the product rating label.
14. Our products are double insulated to EN60335. Under no circumstance should an earth be connected to any part of the product.

Preparation

1. While using your product always wear substantial footwear and long trousers.
2. Make sure the lawn is clear of sticks, stones, bones, wire and debris; they could be thrown by the blade.
3. Before using the machine and after any impact, check

for signs of wear or damage and repair as necessary.

4. Replace worn or damaged blades together with their fixings in sets to preserve balance.

Use

1. Use the lawnmower only in daylight or good artificial light.
2. Avoid operating your lawnmower in wet grass, where feasible.
3. Take care in wet grass, you may lose your footing.
4. On slopes, be extra careful of your footing and wear non-slip footwear.
5. Mow across the face of slopes, never up and down.
6. Exercise extreme caution when changing direction on slopes. Walk never run.
7. Mowing on banks and slopes can be dangerous. Do not mow on **banks** or **steep** slopes.
8. Do not walk backwards when mowing, you could trip.
9. Never cut grass by pulling the mower towards you.
10. Switch off before pushing the mower over surfaces other than grass.
11. Never operate the lawnmower with damaged guards or without guards in place.
12. Keep hands and feet away from the cutting means at all times and especially when switching on the motor.
13. Do not tilt lawnmower when the motor is running, except when starting and stopping. In this case, do not tilt more than absolutely necessary and lift only the part which is away from the operator. Always ensure that both hands are in the operating position before returning the appliance to the ground.
14. Never pick up or carry a mower when it is operating or still connected to the mains supply.
15. Remove the plug from the mains :
 - before leaving the mower unattended for any period;
 - before clearing a blockage;
 - before checking, cleaning or working on the appliance;
 - if you hit an object. Do not use your lawnmower until you are sure that the entire lawnmower is in a safe operating condition.;
 - if the lawnmower starts to vibrate abnormally. Check immediately. Excessive vibration can cause injury.

Maintenance and storage

1. Keep all nuts, bolts and screws tight to be sure the lawnmower is in safe working condition.
2. Check the grassbox/grassbag frequently for wear or deterioration.
3. Replace worn or damaged parts for safety.
4. Only use the replacement blade, blade bolt, spacer and impeller specified for this product.
5. Be careful during adjustment of the lawnmower to prevent entrapment of the fingers between moving blades and fixed parts of the machine.

CABLES

IMPORTANT

- Use only 1.00mm² size cable up to 40 metres length maximum.

Maximum rating :

- 1.00mm² size cable, 10 amps 250 volts AC.
 - **THE ROLLER COMPACT IS SUPPLIED WITH AN ELECTRIC MAINS CABLE FITTED WITH A FEMALE CONNECTOR**
1. Flymo Mains Cables and Extension Cables are available from your local Approved Service Centre.
 2. Do not wire an extension cable directly to your product yourself. Please contact your local Husqvarna Outdoor Products Approved Service Centre for further information on the connectors and kits available.
 3. Only use extension cables specifically designed for outdoor use.

CONNECTORS

IMPORTANT





- Flymo connectors are suitable for use with 2 core cable only. Under no circumstances should these connectors be used for earthed products.
- All Flymo connectors and cables are of splashproof construction. They are not waterproof and must not be left outside permanently nor should they be submerged or immersed in water. Do not let cable lay or trail through pools of water or splashed with water from hose pipes.

MAINS PLUG REPLACEMENT

IMPORTANT

- If the plug supplied is cut off it should be destroyed. There is an electric shock hazard if a cut off plug is inserted into a 13 amp socket.
1. No earth required. Flymo products are double insulated to EN60335 and under no circumstances should an earth be connected to any part of the product.
 2. Ensure the mains voltage suits your product
 3. **IMPORTANT!**
The wires in the mains lead are coloured in accordance with the following code:
BLUE - NEUTRAL
BROWN - LIVE
The wire which is coloured BLUE must be connected to the Terminal which is marked with the letter 'N' or coloured BLACK.
The wire which is coloured BROWN must be connected to the Terminal which is marked with the letter 'L' or coloured RED.
 4. It is important that the outer sheath is clamped correctly into the 3-pin plug.
 5. If in doubt consult your local Service Repairer or qualified electrician before the machine is used.
 6. A 13 Amp fuse must be fitted to the Mains Plug.
 7. The normal plug fuse and household fuse only protect the electrical equipment and are not a safeguard against electrocution.

Assembly Instructions





Assembly of Lower Handles to Deck

1. Insert lower handle into holes in the deck (A).
2. Release the grassbox catch and lift the grassbox lid (B).
3. Rest the grassbox lid against the lower handle and remove the grassbox.
4. Push the lower handle into place ensuring that the holes in the lower handle are correctly located behind the holes in the deck.
5. Secure the lower handles to the inside of the deck with the lower handle fixing pins (C).
6. Ensure the fixing pins are securely located.
7. Should a problem occur when securing lower handle to deck,

- carefully lever fixing pins out of location and repeat steps 4 to 6.
8. Replace the grassbox and close the grassbox lid.

Assembly of Upper Handles to Lower Handles.

- Ensure the upper handle is located correctly with the lock-off button on the switchbox uppermost
1. Insert the nut into the handle knob (D1).
 2. Ensure the upper handle and the lower handle are aligned correctly. (D2)
 3. Fit the bolts, washers and handle knobs.(D)
 4. Fit the cable to the handles with the clips provided. Make sure the cable is not trapped between the upper and lower handles.




Cable Winder Assembly (E & F) RC3400 only

1. Insert cable winder attachment onto left upper handle as viewed from rear of product (E1).
2. Insert cable winder onto attachment and turn

- downward to secure. (E2).
3. Continue turning the cable winder downward until it can be located onto the top of the lower handle (F1).

Cutting Height Adjustment




Adjusting the cutting height

1. Lift the lever out of location and rotate to the desired position. (G)

Heights of cut:-

1 & 2 - low, 3 - medium, 4 & 5 - high




The height of cut can be reduced further by the addition of the spacer provided (H)

Always handle blade with care - sharp edges could cause injury. USE GLOVES.

1. Remove the blade bolt and blade as described in Removing the Blade and Fan
2. Place the spacer between the fan and the blade (H)
3. Replace the blade as described in Fitting the Blade and Fan

Removing, Emptying and Refitting the Grassbox




Grassbox Full


- As the grassbox fills up, grass will be visible through the window in the lid (J).
- When the window is full it is time to empty the grassbox.

Emptying the Grassbox

- Stop the lawnmower, as described in 'To Stop your Lawnmower' and wait until the blade has stopped rotating, BEFORE lifting the grassbox lid.
1. Release grassbox catch and lift grassbox lid (B). See Assembly Instructions.
 2. Rest grassbox lid against lower handle and remove grassbox (K).
 3. Empty grassbox.
 4. Replace grassbox and close grassbox lid.




Cut Out Device






- **IMPORTANT**
- The Roller Compact is fitted with a cut-out device (L) which will prevent the lawnmower from being started until the grassbox lid is firmly close and clicked into place.
- Do not attempt to use your lawnmower without the grassbox in place or with the lid open.

IMPORTANT INFORMATION



When received from the Manufacturer, the front wheels are in a raised position. **Do not switch on this product before removing from the raised position into a desired height of cut. (M)**

Starting and Stopping



- Important:- Your lawnmower will not start until the grassbox lid is firmly closed and clicked into place.

To Start your Lawnmower

1. Connect female extension cable connector to the back of the switchbox. (N)
2. Form loop in mains cable and push the loop through the slot as illustrated in picture (P)
3. To secure, position loop over the hook and pull the cable back through the slot as illustrated in picture (Q).
4. Connect plug to mains and switch on.
5. Tilt the handle downwards to slightly raise the front of the lawnmower and to reduce the risk of lawn damage whilst starting.

The switchbox is provided with a lock-off button (R1) to prevent accidental starting.

6. Press and hold the lock-off button (R) on the switchbox, then squeeze one of the Start/Stop levers towards the upper handle (S).
7. Continue to squeeze the start/stop lever towards the upper handle and release the lock-off button.
8. Lower the lawnmower to its proper operating position and commence mowing.

• **NOTE:** There are two start/stop levers fitted. Either one can be used for starting the lawnmower.

- **IMPORTANT:** Do not use the start/stop levers intermittently

To Stop your Lawnmower

1. Release the pressure on the Start/Stop lever.

How to Mow

1. Start mowing the edge of the lawn nearest to the power point so the cable is laid out on the lawn you have already cut.
2. Mow twice a week during the growing season, your lawn will suffer if more than a third of its length is cut at one time and this may also result in poor collection.

Do Not Overload Your Mower: Mowing long thick grass may cause the motor speed to drop, you will hear a change in the motor sound. If the motor speed drops you may overload your lawnmower which may cause damage. When mowing in long thick grass a first cut with the cutting height set higher will help reduce the load. See Cutting Height Adjustment.

Removing and Fitting the Blade and Fan (T)


Always handle the blade with care - sharp edges could cause injury. **USE GLOVES.**

Removing the Blade and Fan

1. To remove the blade bolt, hold the fan firmly and, with the spanner provided, loosen the blade bolt by turning it anti-clockwise.
 2. Remove the blade bolt, blade and fan from the pulley.
- Renew your metal blade after 50 hours mowing or 2 years whichever is the sooner - regardless of condition. If the blade is cracked or damaged replace it with a new one.

Fitting the Blade and Fan

1. Ensure the fan is located correctly.
2. Fit the blade to the fan.
3. Re-assemble blade bolt through blade and fan.
4. Hold the fan and tighten blade bolt firmly with the spanner provided. Do not over tighten.



Easi-Reel Cable Winder (Roller Compact 3400/4000 only)



Storing your cable in the Easi-Reel cable winder

1. Insert the female connector into the centre of the cable winder (V1)
2. Place the cable under the cable guide (V2)
3. Turn the cable winder (V3) until all of the cable is wound in. (V4)

Warning:- When cable is fully wound, lid becomes heavy - Roller Compact 4000 only.

Unwinding the cable before re-use

1. Pull the cable by the plug and unwind the cable fully.
- Ensure that the cable is released from the cable guide (V2) before using your machine.
 - Ensure cable is not entangled with any other cables and that it is not trapped in any parts of the product.



Caring for your Lawnmower

Cleaning (W)


- USE GLOVES
 - **IMPORTANT:** It is very important that you keep your lawnmower clean. Grass clippings left in any of the air intakes or under the deck could become a potential fire hazard.
 - **IMPORTANT:** Never use water for cleaning your lawnmower. Do not clean with chemicals, including petrol, or solvents - some can destroy critical plastic parts.
1. Remove grass from under the deck with the spanne/scrapper tool
 2. Remove the blade, see Figure T, to gain access to the fan and clean with a soft brush.
 3. Raise the roller to its highest position, see Cutting Height Adjustment, and clean with a soft brush.
 4. Remove grass clippings from: all air intakes, wheels, height adjustment lever and grassbox with a soft brush.
 5. Clean the grassbox lid and the inside of the window with a soft brush.
 6. Thoroughly clean around the cut-out switch with a soft brush
 7. Wipe over the surface of your lawnmower with a dry cloth.

Cleaning Easi-Reel cable winder (Roller Compact 3400/4000 only)


- **Roller Compact 3400** - At the back of the cable winder, squeeze together the two catches (X) and remove the cable spool.
 - **Roller Compact 4000** - Lift grassbox lid, squeeze together the two catches (Y) and remove the cable spool.
2. Clean the cable spool and the area it was located with a soft brush (Z)
 3. Replace the cable spool, ensuring it clicks into place.
- At the End of the Mowing Season
1. Replace blade, bolts, nuts or screws, if necessary.
 2. Clean your lawnmower thoroughly.
 3. Ask your local Service Centre to clean the air filter thoroughly and carry out any service or repairs required.
 4. Make sure that the electric cable is wound properly.

Storing the lawnmower


- The handles can be folded to take up the minimum of space.
- Loosen the handle knobs
 - Fold the upper handle over the lawnmower.
 - Ensure the switchbox cable is not trapped.
 - Store in a dry place where your lawnmower is protected from damage.




X Roller Compact 3400




X Roller Compact 4000



Z Roller Compact 3400



Roller Compact 4000



Fault Finding Hints

Fails to Operate

1. Is the correct Starting procedure being followed? See 'To Start your Lawnmower'.
2. Is the grassbox lid firmly closed?
3. Is the Power Turned On?
4. Check the fuse in the plug, if blown replace.
5. Fuse continues to blow?
Immediately disconnect from the mains electricity supply and consult your local approved Service Centre.

Poor Grass Collection

1. Disconnect from the mains electricity supply.
2. Check that the grass chute and the underside of the deck are free from grass.
3. Raise to a higher height of cut. See Cutting Height Adjustment.
4. Clean Fan Blades.
5. If poor collection persists.
Immediately disconnect from the mains electricity supply and consult your local approved Service Centre.

Lawnmower becomes heavy to push

1. Disconnect from the mains electricity supply.
2. In long grass or uneven ground, the height of cut should be raised to a higher position. See Cutting Height Adjustment
3. Check that the wheels and roller can rotate freely.
4. If problem persists?
Immediately disconnect from the mains electricity supply and consult your local approved Service Centre.

Excessive Vibration

1. Disconnect from the mains electricity supply.
2. Check that the blade is fitted correctly?
3. If the blade is damaged or worn, replace it with a new one.
4. If vibration persists, turn the blade through 180° by first loosening the blade bolt, turning the blade and re-tightening the blade bolt.
5. If vibration persists?
Immediately disconnect from the mains electricity supply and consult your local approved Service Centre.


Service Recommendations

1. We strongly recommend that your product is serviced at least every twelve months, more often in a professional application.
 2. Always use genuine Flymo Spare Parts.
 3. Prepacked spares are available from most Husqvarna Outdoor Products stockists.
 4. Your product is uniquely identified by a silver and black product rating label
 5. If you have a problem with your machine contact your local Approved Service Centre ensuring you have full details of your product as described on the product rating label.
 6. Should it be necessary for work to be carried out by your Service Centre, it is important to take your complete machine including cable and any extension cables used.
- A network of specialist dealers can be found in your local Yellow Pages. To obtain service on your Flymo product simply telephone or visit your local Service Centre. Should you require service under the terms of our guarantee the Service Centre will require proof of purchase. All of the centres listed stock genuine Flymo Spare Parts.
- NOTE: Our Service Repairers act on their own behalf and are not empowered to commit or legally bind Husqvarna Outdoor Products in any manner whatsoever.

Environmental Information

Husqvarna Outdoor Products are manufactured under an Environmental Management System (ISO 14001) using, where practical, components manufactured in the most environmentally responsible manner, according to company procedures, and with the potential for recycling at the end of the products' life.

- Packaging is recyclable and plastic components have been labelled (where practical) for categorised recycling.
- Awareness of the environment must be considered when disposing of 'end-of-life' product.
- If necessary, contact your local authority for disposal information.

The symbol  on the product or on its packaging indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local council office, your household waste disposal service or the shop where you purchased the product.

Guarantee & Guarantee Policy

If any part is found to be defective due to faulty manufacture within the guarantee period, Husqvarna Outdoor Products, through its Authorised Service Repairs will effect the repair or replacement to the customer free of charge providing:

- (a) The fault is reported directly to the Authorised Repairer.
- (b) Proof of purchase is provided.
- (c) The fault is not caused by misuse, neglect or faulty adjustment by the user.
- (d) The failure has not occurred through fair wear and tear.
- (e) The machine has not been serviced or repaired, taken apart or tampered with by any person not authorised by Husqvarna Outdoor Products.
- (f) The machine has not been used for hire.
- (g) The machine is owned by the original purchaser.
- (h) The machine has not been used commercially.
- * This guarantee is additional to, and in no way diminishes the customers statutory rights.

Failures due to the following are not covered, therefore it is important that

you read the instructions contained in this Operator's Manual and understand how to operate and maintain your machine:

- Failures not covered by guarantee
 - * Replacing worn or damaged blades
 - * Failures as a result of not reporting an initial fault.
 - * Failures as a result of sudden impact.
 - * Failures as a result of not using the product in accordance with the instructions and recommendations contained in this Operator's Manual.
 - * Machines used for hire are not covered by this guarantee.
 - * The following items listed are considered as wearing parts and their life is dependent on regular maintenance and are, therefore not normally subject to a valid warranty claim: Blade, Electric Mains cable, Belt
 - * Caution!
- Husqvarna Outdoor Products does not accept liability under the warranty for defects caused in whole or part, directly or indirectly by the fitting of replacement parts or additional parts that are not either manufactured or approved by Husqvarna Outdoor Products, or by the machine having been modified in any way.

EC Declaration of Conformity

I, the undersigned M. Bowden of Husqvarna Outdoor Products, Aycliffe Industrial Park, NEWTON AYCLIFFE, Co. Durham. DL5 6UP. Certify that the product:- Category..... Electric Wheeled Rotary Make.....Husqvarna Outdoor Products Conforms to the specifications of Directive 2000/14/EEC	I, the undersigned M. Bowden of Husqvarna Outdoor Products, Aycliffe Industrial Park, NEWTON AYCLIFFE, Co. Durham. DL5 6UP Certify that a sample of the above product has been tested using directive 81/1051/EEC as a guide. The maximum A-weighted sound pressure level recorded at operator position under free field semi anechoic chamber conditions was :-	I, the undersigned M. Bowden of Husqvarna Outdoor Products, Aycliffe Industrial Park, NEWTON AYCLIFFE, Co. Durham. DL5 6UP Certify that a sample of the above product has been tested using ISO 5349 as a guide. The maximum weighted root mean square value of vibration recorded at operator's hand position was:-
Type of Cutting Device.... Rotary Blade Identification of Series.....See Product Rating Label Conformity Assessment Procedure...ANNEX VI Notified Body.....Intertek, Cleeve Road, Leatherhead, Surrey, KT22 7SB England Other Directives:-.....98/37/EEC, 89/336/EEC, 73/23/EEC & applicable standards:- EN61000-3-2, EN61000-3-3, EN55014-1, EN55014-2, EN836, EN60335-1, EN60335-2-77	Type.....RCV340 RCV3400 RCV400/4000 Width of Cut..... 34 cm 34 cm 40 cm Speed of Rotation of Cutting Device...3,800 RPM 4,300 RPM 4,350 RPM Guaranteed sound power level.....96 dB (A) 96 dB (A) 90 dB (A) Measured Sound Power Level.....95 dB (A) 95 dB (A) 89 dB (A) Level.....87.5 dB (A) 87.5 dB (A) 79.1 dB (A) Value.....3.25 m/s ² 3.25 m/s ² 2.97 m/s ² Weight.....13.5 kg 13.5 kg 11 kg	



Newton Aycliffe, 08/02/06
M. Bowden,
Research & Development Director

Husqvarna Outdoor Products
Aycliffe Industrial Park
NEWTON AYCLIFFE
Co.Durham DL5 6UP
ENGLAND

Telephone - (00) 44 870 609 1901 Fax - (00) 44 870 609 1902

Our policy of continuous improvement means that the specification of products may be altered from time to time without prior notice.

5107353-02

