Husqvarna



CTH2036 TWIN

Owner's Manual

A

SAFETY RULES

Safe Operation Practices for Ride-On Mowers



DANGER: THIS CUTTING MACHINE IS CAPABLE OF AMPUTATING HANDS AND FEET AND THROWING OBJECTS. FAILURE TO OBSERVE THE FOLLOWING SAFETY INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.



WARNING: In order to prevent accidental starting when setting up, transporting, adjusting or making repairs, always disconnect spark plug wire and place wire where it cannot contact spark plug.



WARNING: Do not coast down a hill in neutral, you may lose control of the tractor.



WARNING: Tow only the attachments that are recommended by and comply with specifications of the manufacturer of your tractor. Use common sense when towing. Operate only at the lowest possible speed when on a slope. Too heavy of a load, while on a slope, is dangerous. Tires can lose traction with the ground and cause you to lose control of your tractor.

I. GENERAL OPERATION

- Read, understand, and follow all instructions on the machine and in the manual before starting.
- Do not put hands or feet near rotating parts or under the machine. Keep clear of the discharge opening at all times
- Only allow responsible adults, who are familiar with the instructions, to operate the machine.
- Clear the area of objects such as rocks, toys, wire, etc., which could be picked up and thrown by the blades.
- Be sure the area is clear of bystanders before operating. Stop machine if anyone enters the area.
- Never carry passengers.
- Do not mow in reverse unless absolutely necessary. Always look down and behind before and while backing.
- Never direct discharged material toward anyone. Avoid discharging material against a wall or obstruction. Material may ricochet back toward the operator. Stop the blades when crossing gravel surfaces.
- Do not operate machine without the entire grass catcher, discharge guard, or other safety devices in place and working.
- Slow down before turning.
- Never leave a running machine unattended. Always turn off blades, set parking brake, stop engine, and remove keys before dismounting.

- Disengage blades when not mowing. Shut off engine and wait for all parts to come to a complete stop before cleaning the machine, removing the grass catcher, or unclogging the discharge guard.
- Operate machine only in daylight or good artificial light.
- Do not operate the machine while under the influence of alcohol or drugs.
- Watch for traffic when operating near or crossing roadways.
- Use extra care when loading or unloading the machine into a trailer or truck.
- Always wear eye protection when operating machine.
- Data indicates that operators, age 60 years and above, are involved in a large percentage of riding mower-related injuries. These operators should evaluate their ability to operate the riding mower safely enough to protect themselves and others from serious injury.
- Follow the manufacturer's recommendation for wheel weights or counterweights.
- Keep machine free of grass, leaves or other debris build-up which can touch hot exhaust / engine parts and burn. Do not allow the mower deck to plow leaves or other debris which can cause build-up to occur. Clean any oil or fuel spillage before operating or storing the machine. Allow machine to cool before storage.

II. SLOPE OPERATION

Slopes are a major factor related to loss of control and tip-over accidents, which can result in severe injury or death. Operation on all slopes requires extra caution. If you cannot back up the slope or if you feel uneasy on it, do not mow it.

- Mow up and down slopes, not across.
- Watch for holes, ruts, bumps, rocks, or other hidden objects. Uneven terrain could overturn the machine.
 Tall grass can hide obstacles.
- Choose a low ground speed so that you will not have to stop or shift while on the slope.
- Do not mow on wet grass. Tires may lose traction. Always keep the machine in gear when going down slopes. Do not shift to neutral and coast downhill.
- Avoid starting, stopping, or turning on a slope. If the tires lose traction, disengage the blades and proceed slowly straight down the slope.
- Keep all movement on the slopes slow and gradual.
 Do not make sudden changes in speed or direction, which could cause the machine to roll over.
- Use extra care while operating machine with grass catchers or other attachments; they can affect the stability of the machine. Do no use on steep slopes.
- Do not try to stabilize the machine by putting your foot on the ground.
- Do not mow near drop-offs, ditches, or embankments.
 The machine could suddenly roll over if a wheel is over the edge or if the edge caves in.

A

SAFETY RULES

Safe Operation Practices for Ride-On Mowers



III. CHILDREN

Tragic accidents can occur if the operator is not alert to the presence of children. Children are often attracted to the machine and the mowing activity. *Never* assume that children will remain where you last saw them.

- Keep children out of the mowing area and in the watchful care of a responsible adult other than the operator.
- Be alert and turn machine off if a child enters the area.
- Before and while backing, look behind and down for small children.
- Never carry children, even with the blades shut off. They
 may fall off and be seriously injured or interfere with
 safe machine operation. Children who have been given
 rides in the past may suddenly appear in the mowing
 area for another ride and be run over or backed over
 by the machine.
- Never allow children to operate the machine.
- Use extra care when approaching blind corners, shrubs, trees, or other objects that may block your view of a child.

IV. TOWING

- Tow only with a machine that has a hitch designed for towing. Do not attach towed equipment except at the hitch point.
- Follow the manufacturer's recommendation for weight limits for towed equipment and towing on slopes.
- Never allow children or others in or on towed equipment
- On slopes, the weight of the towed equipment may cause loss of traction and loss of control.
- Travel slowly and allow extra distance to stop.

V. SERVICE

SAFE HANDLING OF GASOLINE

To avoid personal injury or property damage, use extreme care in handling gasoline. Gasoline is extremely flammable and the vapors are explosive.

- Extinguish all cigarettes, cigars, pipes, and other sources of ignition.
- Use only approved gasoline container.
- Never remove gas cap or add fuel with the engine running. Allow engine to cool before refueling.
- Never fuel the machine indoors.
- Never store the machine or fuel container where there is an open flame, spark, or pilot light such as on a water heater or other appliances.
- Never fill containers inside a vehicle or on a truck or trailer bed with plastic liner. Always place containers on the ground away from your vehicle when filling.
- Remove gas-powered equipment from the truck or trailer and refuel it on the ground. If this is not possible, then refuel such equipment with a portable container, rather than from a gasoline dispenser nozzle.
- Keep the nozzle in contact with the rim of the fuel tank or container opening at all times until fueling is complete.
 Do not use a nozzle lock-open device.
- If fuel is spilled on clothing, change clothing immediately.
- Never overfill fuel tank. Replace gas cap and tighten securely.

GENERAL SERVICE

- · Never operate machine in a closed area.
- Keep all nuts and bolts tight to be sure the equipment is in safe working condition.
- Never tamper with safety devices. Check their proper operation regularly.
- Keep machine free of grass, leaves, or other debris build-up. Clean oil or fuel spillage and remove any fuel-soaked debris. Allow machine to cool before storing.
- If you strike a foreign object, stop and inspect the machine. Repair, if necessary, before restarting.
- Never make any adjustments or repairs with the engine running.
- Check grass catcher components and the discharge guard frequently and replace with manufacturer's recommended parts, when necessary.
- Mower blades are sharp. Wrap the blade or wear gloves, and use extra caution when servicing them.
- Check brake operation frequently. Adjust and service as required.
- · Maintain or replace safety and instruction labels, as











- Be sure the area is clear of bystanders before operating. Stop machine if anyone enters the area.
- · Never carry passengers.
- Do not mow in reverse unless absolutely necessary. Always look down and behind before and while backing.
- Never carry children, even with the blades shut off. They
 may fall off and be seriously injured or interfere with
 safe machine operation. Children who have been given
 rides in the past may suddenly appear in the mowing
 area for another ride and be run over or backed over
 by the machine.
- Keep children out of the mowing area and in the watchful care of a responsible adult other than the operator.
- Be alert and turn machine off if a child enters the area.
- Before and while backing, look behind and down for small children.
- Mow up and down slopes (15° Max), not across.
- Be alert and turn machine off if a child enters the area.
- Choose a low ground speed so that you will not have to stop or shift while on the slope.
- Avoid starting, stopping, or turning on a slope. If the tires lose traction, disengage the blades and proceed slowly straight down the slope.
- If machine stops while going uphill, disengage blades, shift into reverse and back down slowly.
- Do not turn on slopes unless necessary, and then, turn slowly and gradually downhill, if possible.

PRODUCT SPECIFICATIONS

| Gasoline Capacity and type: | 2.5 Gallons Unleaded Regular |
|-----------------------------|--|
| Oil Type (API-SG-SL): | SAE 10W30 (above 32°F) SAE 5W-30 (below 32°F) |
| Oil Capacity: | W/ Filter: 58 oz. |
| Spark Plug: | Champion RC12YC (Gap: .030") |
| Ground Speed (MPH): | Forward: $0-5.5$ Reverse: $0-2.4$ |
| Charging System: | 15 AMPS @ 3600 RPM |
| Battery: | AMP/HR: 35 MIN. CCA: 280 CASE SIZE: U1R |
| Blade Bolt Torque: | 27-35 FT. LBS. |

CONGRATULATIONS on your purchase of a new tractor. It has been designed, engineered and manufactured to give you the best possible dependability and performance.

Should you experience any problem you cannot easily remedy, please contact your nearest authorized service center. We have competent, well-trained technicians and the proper tools to service or repair this tractor.

Please read and retain this manual. The instructions will enable you to assemble and maintain your tractor properly. Always observe the "SAFETY RULES".

CUSTOMER RESPONSIBILITIES

- · Read and observe the safety rules.
- Follow a regular schedule in maintaining, caring for and using your tractor.
- Follow the instructions under the "Maintenance" and "Storage" sections of this owner's manual.

WARNING: This tractor is equipped with an internal combustion engine and should not be used on or near any unimproved forest-covered, brush-covered or grass-covered land unless the engine's exhaust system is equipped with a spark arrester meeting applicable local or state laws (if any). If a spark arrester is used, it should be maintained in effective working order by the operator.


In the state of California the above is required by law (Section 4442 of the California Public Resources Code). Other states may have similar laws. Federal laws apply on federal lands.

TABLE OF CONTENTS


| SAFETY RULES2-3 | | MAINTENANCE SCHEDULE | 19 |
|----------------------------|---|-------------------------|-------|
| PRODUCT SPECIFICATIONS4 | | MAINTENANCE | 19-22 |
| CUSTOMER RESPONSIBILITIES4 | | SERVICE AND ADJUSTMENTS | 23-27 |
| ASSEMBLY6-10 | | STORAGE | 28 |
| OPERATION11-18 | | TROUBLESHOOTING | 29-30 |
| | 4 | REPAIR PARTS - TRACTOR | 31-47 |


UNASSEMBLED PARTS

Steering Wheel



Steering Wheel Insert






(1) Large Flat Washer





(1) Locknut

Seat



(1) Seat








(1) Knob




Keys



(2) Keys

Slope Sheet



Your new tractor has been assembled at the factory with exception of those parts left unassembled for shipping purposes. To ensure safe and proper operation of your tractor all parts and hardware you assemble must be tightened securely. Use the correct tools as necessary to insure proper tightness.

TOOLS REQUIRED FOR ASSEMBLY

A socket wrench set will make assembly easier. Standard wrench sizes are listed.

(2) 7/16" wrenches Utility knife

(1) 3/4" wrenches Tire pressure gauge

(1) 3/4" socket w/drive ratchet Pliers

When right or left hand is mentioned in this manual, it means when you are in the operating position (seated behind the steering wheel).

TO REMOVE TRACTOR FROM CAR-TON

UNPACK CARTON

- Remove all accessible loose parts and parts cartons from carton.
- Cut along dashed lines on all four panels of carton.
 Remove end panels and lay side panels flat.
- Check for any additional loose parts or cartons and remove.

BEFORE REMOVING TRACTOR FROM SKID

ATTACH STEERING WHEEL (See Fig. 1)

- Remove locknut and large flat washer from steering shaft.
- Position front wheels of the tractor so they are pointing straight forward.
- Slide the steering sleeve over the steering shaft.
- Position steering wheel so cross bars are horizontal (left to right) and slide onto steering wheel adapter.
- Secure steering wheel to steering shaft with locknut and large flat washer previously removed. Tighten securely.
- Snap steering wheel insert into center of steering wheel.
- Remove protective materials from tractor hood and grill.

IMPORTANT: CHECK FOR AND REMOVE ANY STAPLES IN SKID THAT MAY PUNCTURE TIRES WHERE TRACTOR IS TO ROLL OFF SKID.




FIG. 1

CONNECT BATTERY (See Figs. 2)



CAUTION: Do not short battery terminals by allowing a wrench or any other object to contact both terminals at the same time. Before connecting battery, remove metal bracelets, wristwatch bands, rings, etc.

Positive terminal must be connected first to prevent sparking from accidental grounding.

- If this battery is put into service after month and year indicated on label (label located between terminals) charge battery for minimum of one hour at 6-10 amps. (See "BATTERY" in the Maintenance section of this manual for charging instructions).
- Remove battery cover.
- Remove terminal protective caps and discard.
- First connect RED battery cable to positive (+) terminal with hex bolt and keps nut as shown. Tighten securely.
- Connect BLACK grounding cable to negative (-) terminal with remaining hex bolt and keps nut. Tighten securely.
- Replace battery cover.

Open battery cover for:

- Inspection for secure connections (to tighten hardware).
- Inspection for corrosion.
- Testing battery.
- Jumping (if required).
- Periodic charging.




FIG. 2

INSTALL SEAT (See Fig. 3)

Adjust seat before tightening adjustment knob.

- Remove adjustment knob and flat washer securing seat to cardboard packing and set aside for assembly of seat to tractor.
- Pivot seat upward and remove from the cardboard packing. Remove the cardboard packing and discard.
- Place seat on seat pan so head of shoulder bolt is positioned over large slotted hole in pan.
- Push down on seat to engage shoulder bolt in slot and pull seat towards rear of tractor.
- Pivot seat and pan forward and assemble adjustment knob and flat washer loosely. Do not tighten.
- Lower seat into operating position and sit on seat.
- Slide seat until a comfortable position is reached which allows you to press clutch/brake pedal all the way down.
- · Get off seat without moving its adjusted position.
- · Raise seat and tighten adjustment knob securely.




FIG. 3

NOTE: You may now roll or drive your tractor off the skid. Follow the appropriate instruction below to remove the tractor from the skid.

AWARNING: Before starting, read, understand and follow all instructions in the Operation section of this manual. Be sure tractor is in a well-ventilated area. Be sure the area in front of tractor is clear of other people and objects.

TO ROLL TRACTOR OFF SKID (See Operation section for location and function of controls)

- Press lift lever plunger and raise attachment lift lever to its highest position.
- Release parking brake by depressing clutch/brake pedal.
- Place freewheel control in "transmission disengaged position" (See "TO TRANSPORT" in the Operation section of this manual).
- · Roll tractor forward off skid.
- Remove banding holding the deflector shield up against tractor.

TO DRIVE TRACTOR OFF SKID (See Operation section for location and function of controls)

WARNING: Before starting, read, understand and follow all instructions in the Operation section of this manual. Be sure tractor is in a well-ventilated area. Be sure the area in front of tractor is clear of other people and objects.

- Be sure all the above assembly steps have been completed.
- · Check engine oil level and fill fuel tank with gasoline.
- Place freewheel control in "transmission engaged" position (see "TO TRANSPORT" in Operation section of this manual).
- Sit on seat in operating position, depress clutch/brake pedal and set the parking brake.
- Place motion control lever in neutral (N) position.
- Press lift lever plunger and raise attachment lift lever to its highest position.
- Remove key from bag and start the engine (see "TO START ENGINE" in the Operation section of this manual). After engine has started, move throttle control to idle (slow) position.
- Release parking brake.
- Slowly move the motion control lever forward and slowly drive tractor off skid.
- Apply brake to stop tractor, set parking brake and place motion control lever in neutral position.
- Turn ignition key to "STOP" position.

Continue with the instructions that follow.

TO INSTALL BAGGER COMPONENTS TO TRACTOR (See Figs. 4A-4D)

- Remove discharge chute from rear of tractor. Unhook the two (2) straps and pull chute out and away from tractor.
- Remove the two (2) 3/8 nuts and flat washers from the bolts at the tractor back plate.




FIG. 4A

 Using the nuts and flat washers removed from tractor back plate, install the bagger support tube to the back plate as shown. Tighten securely.




FIG. 4B

- Install the two upper support brackets through the back plate and to the chassis, install the clevis pin 10x17mm and secure with retainer spring.
- Assemble both support brackets to the outside of the bagger support tube using two each 3/8 x 63,5mm hex bolts13/32" I.D. flat washers and 3/8 locknuts from parts bag. Tighten securely.
- Replace discharge chute into rear opening of tractor.
 Secure the chute with the two hook straps.




FIG. 4C

NOTE: The strap hook must go through the discharge chute only. Do not allow the hook to enter the slot in the tractor back plate. This will allow the discharge chute to float with the mower deck when moving on uneven terrain.




FIG. 4D

TO ASSEMBLE BAGGER (See Figs. 5A-5C)

- Unfold bag by pivoting front bagger tube all the way forward and pressing the bottom vinyl binding onto the tube.
- Inside the bag, install spreader bars and retainer springs onto pins on both sides of bag as shown.
- Press the vinyl bindings onto the sides of front bagger tube.
- Slide the bagger dump handle through the hole in the bagger top, install the clevis pin 10 x 44mm and secure with retainer spring.




FIG. 5A




FIG. 5B

Push cap over end of bagger dump handle.

NOTE: For future use, the clevis pin may be removed in order to use the handle to clear the chute in the event it has become clogged.




FIG. 5C

BAGGER ADJUSTMENT (See Fig. 6 & 7)

For proper bag function and appearance, it may be necessary to adjust the bagger assembly. There should be 6mm (1/4")-9mm (3/8") gap between the bagger top and fender and the bagger top surface should be even with the top surface of the fender. To adjust bagger position:

HORIZONTAL ADJUSTMENT

- Slightly loosen the nuts securing the bagger RH and LH horizontal adjustment brackets. Loosen only enough so the brackets keep their position, but allow them to be moved.
- Move the brackets the amount forward or backward you wish the bag assembly to move. Retighten the nuts securely.

VERTICAL ADJUSTMENT

- Slightly loosen the nuts securing the vertical adjustment brackets. Loosen only enough so the brackets keep their position, but allow them to be moved.
- Move the brackets the amount up or down you wish the bag assembly to move. Retighten the nuts securely.
- Reinstall the bagger assembly and check the bagger to fender fit. If necessary, repeat the procedure until proper fit is attained.
- After proper fit is attained, remove bagger from tractor and install bagger latch (4) to tractor back plate as shown. Tighten securely.
- Install and carefully lower bagger to actuate latch.
- Measure distance between bagger and latch as shown.




FIG. 6




FIG. 7

If distance is not 10mm - 16mm carefully remove bagger and repeat vertical adjustment as needed.

TO ASSEMBLE AND INSTALL MULCHER PLUG (See Fig. 8)

- · Remove spring retainer and pin from handle.
- Insert plug into handle. Make sure that the letter "A"
 on both the plug and handle are on the same side and
 that they can both be seen from the top when laying
 on the ground.
- Secure with pin and retainer spring provided. For installation see "To Convert Mower" in Section 5 of this manual




FIG. 8

CHECK TIRE PRESSURE

The tires on your tractor were overinflated at the factory for shipping purposes. Correct tire pressure is important for best cutting performance.

· Reduce tire pressure to PSI shown on tires.

CHECK DECK LEVELNESS

For best cutting results, mower housing should be properly leveled. See "TO LEVEL MOWER HOUSING" in the Service and Adjustments section of this manual.

CHECK FOR PROPER POSITION OF ALL BELTS

See the figures that are shown for replacing motion and mower blade drive belts in the Service and Adjustments section of this manual. Verify that the belts are routed correctly.

CHECK BRAKE SYSTEM

After you learn how to operate your tractor, check to see that the brake is operating properly. See "TO CHECK BRAKE" in the Service and Adjustments section of this manual.

✓ CHECKLIST

BEFORE YOU OPERATE AND ENJOY YOUR NEW TRACTOR, WE WISH TO ASSURE THAT YOU RECEIVE THE BEST PERFORMANCE AND SATISFACTION FROM THIS QUALITY PRODUCT.


PLEASE REVIEW THE FOLLOWING CHECKLIST:

- ✓ All assembly instructions have been completed.
- ✓ No remaianing loose parts in carton.
- ✓ Battery is properly prepared and charged.
- ✓ Seat is adjusted comfortably and tightened securely.
- ✓ All tires are properly inflated. (For shipping purposes, the tires were overinflated at the factory).
- ✓ Be sure mower deck is properly leveled side-to-side/ front-to-rear for best cutting results. (Tires must be properly inflated for leveling).
- ✓ Check mower and drive belts. Be sure they are routed properly around pulleys and inside all belt keepers.
- ✓ Check wiring. See that all connections are still secure and wires are properly clamped.
- ✓ Before driving tractor, be sure freewheel control is in drive position.

WHILE LEARNING HOW TO USE YOUR TRACTOR, PAY EXTRA ATTENTION TO THE FOLLOWING IMPORTANT ITEMS:

- ✓ Engine oil is at proper level.
- ✓ Fuel tank is filled with fresh, clean, regular unleaded gasoline.
- ✓ Become familiar with all controls their location and function. Operate them before you start the engine.
- ✓ Be sure brake system is in safe operating condition.
- ✓ It is important to purge the transmission before operating your tractor for the first time. Follow proper starting and transmission purging instructions (See "TO START ENGINE" and "PURGE TRANSMISSION" in the Operation section of this manual).

These symbols may appear on your tractor or in literature supplied with the product. Learn and understand their meaning.







ATTACHMENT **CLUTCH ENGAGED**



BRAKE/CLUTCH PEDAL











ATTACHMENT CLUTCH DISENGAGED



LIGHTS ON

DANGER, KEEP HANDS AND FEET AWAY





BEWARE OF THROWN OBJECTS









UNLOCKED

MOWER LIFT

SLOPE HAZARDS **KEEP AREA CLEAR** (SEE SAFETY RULES SECTION)





DO NOT OPERATE WITHOUT

BAGGER OR DEFLECTOR

DRAWBAR LOADING



FREE WHEEL (Automatic Models only)

Failure to follow instructions could result in serious injury or death. The safety alert symbol is used to identify safety information about hazards which can result in death, serious injury and/or property damage.



DANGER indicates a hazard which, if not avoided, will result in death or serious injury.



WARNING indicates a hazard which, if not avoided, could result in death or serious injury.



CAUTION indicates a hazard which, if not avoided, might result in minor or moderate injury.

CAUTION when used without the alert symbol, indicates a situation that could result in damage to the tractor and/or engine.



HOT SURFACES indicates a hazard which, if not avoided, could result in death, serious injury and/or property damage.



FIRE indicates a hazard which, if not avoided, could result in death, serious injury and/or property damage.

KNOW YOUR TRACTOR

READ THIS OWNER'S MANUAL AND SAFETY RULES BEFORE OPERATING YOUR TRACTOR

Compare the illustrations with your tractor to familiarize yourself with the locations of various controls and adjustments. Save this manual for future reference.




FIG. 9

Our tractors conform to the applicable safety standards of the American National Standards Institute.

ATTACHMENT CLUTCH SWITCH - Used to engage the mower blades, or other attachments mounted to your tractor.

ATTACHMENT LIFT LEVER - Used to raise and lower the mower deck or other attachments mounted to your tractor.

CHOKE CONTROL - Used when starting a cold engine. **CLUTCH/BRAKE PEDAL** - Used for declutching and braking the tractor and starting the engine.

FREEWHEEL CONTROL - Disengages transmission for pushing or slowly towing the tractor with the engine off.

HEIGHT ADJUSTMENT KNOB - Used to adjust the mower cutting height.

SERVICE REMINDER/HOURMETER - Indicates when service is required for the engine and mower.

IGNITION SWITCH - Used for starting and stopping the engine.

LIFT LEVER PLUNGER - Used to release attachment lift lever when changing its position.

LIGHT SWITCH - Turns the headlights on and off.

MOTION CONTROL LEVER - Selects the speed and direction of tractor.

PARKING BRAKE - Locks clutch/brake pedal into the brake position.

THROTTLE CONTROL - Used to control engine speed.

REVERSE OPERATION SYSTEM (ROS) "ON" POSITON

- Allows operation of mower deck or other powered attachment while in reverse.



The operation of any tractor can result in foreign objects thrown into the eyes, which can result in severe eye damage. Always wear safety glasses or eye shields while operating your tractor or performing any adjustments or repairs. We recommend a wide vision safety mask over spectacles or standard safety glasses.

HOW TO USE YOUR TRACTOR

TO SET PARKING BRAKE (See Fig. 10)

Your tractor is equipped with an operator presence sensing switch. When engine is running, any attempt by the operator to leave the seat without first setting the parking brake will shut off the engine.

- Depress clutch/brake pedal into full "BRAKE" position and hold.
- Place parking brake lever in "ENGAGED" position and release pressure from clutch/brake pedal. Pedal should remain in "BRAKE" position. Make sure parking brake will hold tractor secure.




FIG. 10

STOPPING (See Fig. 10)

MOWER BLADES -

 To stop mower blades, move attachment clutch switch to "DISENGAGED" position.

GROUND DRIVE -

- To stop ground drive, depress clutch/brake pedal into full "BRAKE" position..
- Move motion control lever to neutral (N) position.
 ENGINE -
- Move throttle control between half and full speed (fast) position.

NOTE: Failure to move throttle control between half and full speed (fast) position, before stopping may cause engine

- Turn ignition key to "STOP" position and remove key. Always remove key when leaving tractor to prevent unauthorized use.
- Never use choke to stop engine.

IMPORTANT: LEAVING THE IGNITION SWITCH IN ANY POSITION OTHER THAN "STOP" WILL CAUSE THE BATTERY TO BE DISCHARGED, (DEAD).

NOTE: Under certain conditions when tractor is standing idle with the engine running, hot engine exhaust gases may cause "browning" of grass. To eliminate this possibility, always stop engine when stopping tractor on grass areas.



CAUTION: Always stop tractor completely, as described above, before leaving the operator's position; to empty grass catcher, etc.

TO USE THROTTLE CONTROL (See Fig. 10)

Always operate engine at full speed (fast).

- Operating engine at less than full speed (fast) reduces the engine's operating efficiency.
- Full speed (fast) offers the best mower performance.

TO USE CHOKE CONTROL (See Fig. 10)

Use choke control whenever you are starting a cold engine. Do not use to start a warm engine.

 To engage choke control, pull knob out. Slowly push knob in to disengage.

TO MOVE FORWARD AND BACKWARD (See Fig. 10)

The direction and speed of movement is controlled by the motion control lever.

- Start tractor with motion control lever in neutral (N) position.
- Release parking brake.
- Slowly move motion control lever to desired position.

TO ADJUST MOWER CUTTING HEIGHT (See Fig. 10)

The cutting height is controlled by turning the height adjustment knob in desired direction.

- Turn knob clockwise () to raise cutting height.
- Turn knob counterclockwise () to lower cutting height.

The cutting height range is approximately 1-1/2" to 4". The heights are measured from the ground to the blade tip with the engine not running. These heights are approximate and may vary depending upon soil conditions, height of grass and types of grass being mowed.

- The average lawn should be cut to approximately 2-1/2 inches during the cool season and to over 3 inches during hot months. For healthier and better looking lawns, mow often and after moderate growth.
- For best cutting performance, grass over 6 inches in height should be mowed twice. Make the first cut relatively high; the second to desired height.

TO ADJUST GAUGE WHEELS (See Fig. 11)

Gauge wheels are properly adjusted when they are slightly off the ground when mower is at the desired cutting height in operating position. Gauge wheels then keep the deck in proper position to help prevent scalping in most terrain conditions.

NOTE:Adjust gauge wheels with tractor on a flat level surface.

- Adjust mower to desired cutting height (See "TO AD-JUST MOWER CUTTING HEIGHT" in the Operation section of this manual).
- With mower in desired height of cut position, gauge wheels should be assembled so they are slightly off the ground. Install gauge wheel in appropriate hole with shoulder bolt, 3/8 washer, and 3/8-16 locknut and tighten securely.
- Repeat for opposite side installing gauge wheel in same adjustment hole.




FIG. 11

TO OPERATE MOWER (See Fig. 12)

Your tractor is equipped with an operator presence sensing switch. Any attempt by the operator to leave the seat with the engine running and the attachment clutch engaged will shut off the engine. You must remain fully and centrally positioned in the seat to prevent the engine from hesitating or cutting off when operating your equipment on rough, rolling terrain or hills.

- Select desired height of cut.
- Lower mower with attachment lift control.
- Start mower blades by engaging attachment clutch control.
- TO STOP MOWER BLADES disengage attachment clutch control.




FIG. 12



CAUTION: Do not operate the mower without either the entire grass catcher, on mowers so equipped, or the deflector shield in place.

REVERSE OPERATION SYSTEM (ROS)

Your tractor is equipped with a Reverse Operation System (ROS). Any attempt by the operator to travel in the reverse direction with the attachment clutch engaged will shut off the engine unless ignition key is placed in the ROS "ON" position.

AWARNING: Backing up with the attachment clutch engaged while mowing is strongly discouraged. Turning the ROS "ON", to allow reverse operation with the attachment clutch engaged, should only be done when the operator decides it is necessary to reposition the machine with the attachment engaged. Do not mow in reverse unless absolutely necessary.

USING THE REVERSE OPERATION SYSTEM (See Fig. 13)

Only use if you are certain no children or other bystanders will enter the mowing area.

- Move motion control lever to neutral (N) position.
- With engine running, turn ignition key counterclockwise to ROS "ON" position.
- Look down and behind before and while backing.
- Slowly move motion control lever to reverse (R) position to start movement.
- When use of the ROS is no longer needed, turn the ignition key clockwise to engine "ON" position.




FIG. 13

TO OPERATE ON HILLS



WARNING: Do not drive up or down hills with slopes greater than 15° and do not drive across any slope.

- Choose the slowest speed before starting up or down hills.
- Avoid stopping or changing speed on hills.
- If stopping is absolutely necessary, push clutch/brake pedal quickly to brake position and engage parking brake.
- Move motion control lever to neutral (N) position.

IMPORTANT: THE MOTION CONTROL LEVER DOES NOT RETURN TO NEUTRAL (N) POSITION WHEN THE CLUTCH/BRAKE PEDAL IS DEPRESSED.

- To restart movement, slowly release parking brake and clutch/brake pedal.
- Slowly move motion control lever to slowest setting.
- · Make all turns slowly.

TO TRANSPORT (See Figs. 9 and 14)

When pushing or towing your tractor, be sure to disengage transmission by placing freewheel control in freewheeling position. Free wheel control is located under the seat.

- Raise attachment lift to highest position with attachment lift control.
- Raise seat and pull freewheel control up and back into the slot and release so it is held in the disengaged position.
- Do not push or tow tractor at more than two (2) MPH.
- To reengage transmission, reverse above procedure.




FIG. 14

NOTE: To protect hood from damage when transporting your tractor on a truck or a trailer, be sure hood is closed and secured to tractor. Use an appropriate means of tying hood to tractor (rope, cord, etc.).

TOWING CARTS AND OTHER ATTACHMENTS

Tow only the attachments that are recommended by and comply with specifications of the manufacturer of your tractor. Use common sense when towing. Too heavy of a load, while on a slope, is dangerous. Tires can lose traction with the ground and cause you to lose control of your tractor.

SERVICE REMINDER/HOUR METER

Service reminder shows the total number of hours the engine has run and flashes to indicate that the engine or mower needs servicing. When service is required, the service reminder will flash for two hours. To service engine and mower, see the Maintenance section of this manual.

NOTE: Service reminder runs when the ignition key is in any position but "STOP". For accurate reading, be sure key remains in the "STOP" position when engine is not running.

BEFORE STARTING THE ENGINE

CHECK ENGINE OIL LEVEL

The engine in your tractor has been shipped, from the factory, already filled with summer weight oil.

- Check engine oil with tractor on level ground.
- Unthread and remove oil fill cap/dipstick; wipe oil
 off. Reinsert the dipstick into the tube and rest oil fill
 cap on the tube. Do not thread the cap onto the tube.
 Remove and read oil level. If necessary, add oil until
 "FULL" mark on dipstick is reached. Do not overfill.
- For cold weather operation you should change oil for easier starting (See the oil viscosity chart in the Maintenance section of this manual).
- To change engine oil, see the Maintenance section in this manual.

ADD GASOLINE

Fill fuel tank to bottom of filler neck. Do not overfill.
Use fresh, clean, regular unleaded gasoline with a
minimum of 87 octane. (Use of leaded gasoline will
increase carbon and lead oxide deposits and reduce
valve life). Do not mix oil with gasoline. Purchase fuel
in quantities that can be used within 30 days to assure
fuel freshness.



CAUTION: Wipe off any spilled oil or fuel. Do not store, spill or use gasoline near an open flame.

IMPORTANT: WHEN OPERATING IN TEMPERATURES BELOW32°F(0°C), USE FRESH, CLEAN WINTER GRADE GASOLINE TO HELP INSURE GOOD COLD WEATHER STARTING.

CAUTION: Alcohol blended fuels (called gasohol or using ethanol or methanol) can attract moisture which leads to separation and formation of acids during storage. Acidic gas can damage the fuel system of an engine while in storage. To avoid engine problems, the fuel system should be emptied before storage of 30 days or longer. Drain the gas tank, start the engine and let it run until the fuel lines and carburetor are empty. Use fresh fuel next season. See Storage Instructions for additional information. Never use engine or carburetor cleaner products in the fuel tank or permanent damage may occur.

TO START ENGINE (See Fig. 9)

When starting the engine for the first time or if the engine has run out of fuel, it will take extra cranking time to move fuel from the tank to the engine.

- Be sure freewheel control is in the transmission engaged position.
- Sit on seat in operating position, depress clutch/brake pedal and set parking brake.
- Place motion control lever in neutral (N) position.
- Move attachment clutch to "DISENGAGED" position.
- Move throttle control to fast position
- Pull choke control out for a cold engine start attempt.
 For a warm engine start attempt the choke control may not be needed.

NOTE: Before starting, read the warm and cold starting procedures below.

 Insert key into ignition and turn key clockwise to "START" position and release key as soon as engine starts. Do not run starter continuously for more than fifteen seconds per minute. If the engine does not start after several attempts, push choke control in, wait a few minutes and try again. If engine still does not start, pull the choke control out and retry.

WARM WEATHER STARTING (50° F and above)

- When engine starts, slowly push choke control in until the engine begins to run smoothly. If the engine starts to run roughly, pull the choke control out slightly for a few seconds and then continue to push the control in slowly.
- The attachments and ground drive can now be used. If the engine does not accept the load, restart the engine and allow it to warm up for one minute using the choke as described above.

COLD WEATHER STARTING (50° F and below)

When engine starts, slowly push choke control in until
the engine begins to run smoothly. Continue to push
the choke control in small steps allowing the engine to
accept small changes in speed and load, until the choke
control is fully in. If the engine starts to run roughly, pull
the choke control out slightly for a few seconds and
then continue to push the control in slowly. This may
require an engine warm-up period from several seconds
to several minutes, depending on the temperature.

AUTOMATIC TRANSMISSION WARM UP

- Before driving the unit in cold weather, the transmission should be warmed up as follows:
 - Be sure the tractor is on level ground.
 - Place the motion control lever in neutral.
 Release the parking brake and let the clutch/brake slowly return to operating position.
 - Allow one minute for transmission to warm up. This can be done during the engine warm up period.
- The attachments can be used during the engine warmup period after the transmission has been warmed up and may require the choke control be pulled out slightly.

NOTE: If at a high altitude (above 3000 feet) or in cold temperatures (below 32 F) the carburetor fuel mixture may need to be adjusted for best engine performance. See "TO ADJUST CARBURETOR" in the Service and Adjustments section of this manual.

PURGE TRANSMISSION



CAUTION: Never engage or disengage freewheel lever while the engine is running.

To ensure proper operation and performance, it is recommended that the transmission be purged before operating tractor for the first time. This procedure will remove any trapped air inside the transmission which may have developed during shipping of your tractor.

IMPORTANT: SHOULD YOUR TRANSMISSION REQUIRE REMOVAL FOR SERVICE OR REPLACEMENT, IT SHOULD BE PURGED AFTER REINSTALLATION BEFORE OPERATING THE TRACTOR.

- 1. Place tractor safely on a level surface that is clear and open with engine off and parking brake set.
- Disengage transmission by placing freewheel control in freewheeling position (See "TO TRANSPORT" in this section of manual).
- Sitting in the tractor seat, start engine. After the engine is running, move throttle control to slow position. With motion control lever in neutral (N) position, slowly disengage clutch/brake pedal.



CAUTION: At any time, during step 4, there may be movement of the drive wheels.

- 4. Move motion control lever to full forward position and hold for five (5) seconds. Move lever to full reverse position and hold for five (5) seconds. Repeat this procedure three (3) times.
- Move motion control lever to neutral (N) position. Shutoff engine and set parking brake.
- Engage transmission by placing freewheel control in engaged position (See "TO TRANSPORT" in this section of manual).
- Sitting in the tractor seat, start engine. After the engine is running, move throttle control to half (1/2) speed. With motion control lever in neutral (N) position, slowly disengage clutch/brake pedal.
- 8. Slowly move motion control lever forward, after the tractor moves approximately five (5) feet, slowly move motion control lever to reverse position. After the tractor moves approximately five (5) feet return the motion control lever to the neutral (N) position. Repeat this procedure with the motion control lever three (3) times

Your transmission is now purged and now ready for normal operation.

MOWING TIPS

- Mower should be properly leveled for best mowing performance. See "TO LEVEL MOWER HOUSING" in the Service and Adjustments section of this manual.
- The left hand side of mower should be used for trimming.
- If grass is extremely tall, it should be mowed twice to reduce load and possible fire hazard from dried clippings. Make first cut relatively high; the second to the desired height.
- Do not mow grass when it is wet. Wet grass will plug mower and leave undesirable clumps. Allow grass to dry before mowing.
- Always operate engine at full throttle when mowing to assure better mowing performance and proper discharge of material. Regulate ground speed by selecting a low enough gear to give the mower cutting performance as well as the quality of cut desired.
- When operating attachments, select a ground speed that will suit the terrain and give best performance of the attachment being used.

MULCHING MOWING TIPS

IMPORTANT: FOR BEST PERFORMANCE, KEEP MOWER HOUSING FREE OF BUILT-UP GRASS AND TRASH. CLEAN AFTER EACH USE.

- The special mulching blade will recut the grass clippings many times and reduce them in size so that as they fall onto the lawn they will disperse into the grass and not be noticed. Also, the mulched grass will biodegrade quickly to provide nutrients for the lawn. Always mulch with your highest engine (blade) speed as this will provide the best recutting action of the blades.
- Avoid cutting your lawn when it is wet. Wet grass tends to form clumps and interferes with the mulching action. The best time to mow your lawn is the early afternoon. At this time the grass has dried the newly cut area will not be exposed to direct sunlight.
- For best results, adjust the mower cutting height so that the mower cuts off only the top one-third of the grass blades (See Fig. 15). For extremely heavy mulching, reduce your width of cut on each pass and mow slowly.




FIG. 15

- Certain types of grass and grass conditions may require that an area be mulched a second time to completely hide the clippings. When doing a second cut, mow across (perpendicular) to the first cut path.
- Change your cutting pattern from week to week. Mow north to south one week then change to east to west the next week. This will help prevent matting and graining of the lawn.

TO DUMP BAGGER (See Fig.16)

Your tractor is equipped with a Dump Bag Alarm. To turn off the alarm disengage the attachment clutch switch.

- Position tractor in location you wish to dump bagger.
- Place motion control lever in Neutral position and set parking brake.
- Raise dump handle to its highest position. Pull handle forward to raise bagger and dump clippings.
- To continue mowing, be sure bagger is down and in proper operating position which will allow mower to operate.




FIG. 16

TO CONVERT MOWER (See Fig.17)

(Converting to mulching or rear discharging will require a mulcher plug and discharge deflector)

MULCHING (Requires mulcher plug)

- Place deck into the high cut position.
- Remove bagger or optional rear discharge deflector.
- Unhook the two (2) straps and remove discharge chute
- Insert mulcher plug and handle assembly through back plate and onto the mower deck chute adaptor.
- Secure the plug assembly by connecting the two straps over the handle and hook into the holes provided.
- Replace bagger or optional rear discharge deflector to allow mower to operate.

You are now ready to begin mulching.




FIG. 17

BAGGING (See Fig.18)

- Place deck into the high cut position.
- Remove the rear discharge deflector or mulching plug.
- Insert the discharge chute into the opening in the backplate and onto the mower deck adaptor.
- Attach the chute to the tractor by hooking the two straps to the flange of the chute.

NOTE: The strap hook must go through the discharge chute only. Do not allow the hook to enter the slot in the tractor back plate. If it does, the discharge chute will not float with the mower deck when mowing on uneven terrain.

Install bagger onto tractor.




FIG. 18

REAR DISCHARGING (optional accessory required)

- Place deck into the high cut position.
- · Remove bagger and mulching plug (if installed).
- Depress rear door and install discharge chute through opening in backplate and slide over deck adaptor.
- Attach the chute by hooking the two straps into the holes in the flange of the chute.

NOTE: The strap hook must go through the discharge chute only. Do not allow the hook to enter the slot in the tractor back plate. If it does, the discharge chute will not float with the mower deck when mowing on uneven terrain.

- Install the discharge deflector to the backplate by screwing the four (4) wing screws into the threaded inserts located in the backplate.
- Tighten the wing screws securely.

| | MAINTENANCE SCHEDULE | BEFORE EACH USE | EVERY 8 HOURS | EVERY 25 HOURS | EVERY 50 HOURS | EVERY 100 HOURS | EVERY SEASON | BEFORE STORAGE |
|----------------|--|-----------------------|---------------------|----------------------|----------------------|-----------------------|-----------------|-------------------|
| Г | Check Brake Operation | / | | | | | | |
| I٠ | Check Tire Pressure | / | / | | | | | |
| I _R | Check Operator Presence & ROS Systems | / | | | | | | |
| ΙÄ | Check for Loose Fasteners | / | | | | / | | V |
| C | Check/Replace Mower Blades | | | √ 3 | | | | |
| ĮΤ | Lubrication Chart | = | | / | | | | / |
| 10 | Check Battery Level | | | 1 /4 | | | | |
| R | Clean Battery and Terminals | | | / | | | | / |
| | Check Transaxle Cooling | | | / | | | | |
| | Check Mower Levelness | | | | / | | | |
| | Check V-Belts | | | | | / | | |
| Г | Check Engine Oil Level | V | / | | | | | |
| | Change Engine Oil (with oil filter) | | | | 1,2 | | | V |
| l_ | Change Engine Oil (without oil filter) | | | 1,2 | | | | / |
| E N | Clean Air Filter | | | 1 2 | | | | |
| G | Clean Air Screen | | | 1 2 | | | | |
| ۱ĭ | Inspect Muffler/Spark Arrester | | | | / | | | |
| N | Replace Oil Filter (If equipped) | | | | | 1,2 | | |
| E | Clean Engine Cooling Fins | | | | | ✓ 2 | | |
| | Replace Spark Plug | | | | | V | V | |
| | Replace Air Filter Paper Cartridge | | | | | 1 2 | | |
| | Replace Fuel Filter | | | | | | V | |

- Change more often when operating under a heavy load or in high ambient temperatures.
- 2 Service more often when operating in dirty or dusty conditions.
- 3 Replace blades more often when mowing in sandy soil.
- 4 Not required if equipped with maintenance-free battery.

GENERAL RECOMMENDATIONS

The warranty on this tractor does not cover items that have been subjected to operator abuse or negligence. To receive full value from the warranty, operator must maintain tractor as instructed in this manual.

Some adjustments will need to be made periodically to properly maintain your tractor.


At least once a season, check to see if you should make any of the adjustments described in the Service and Adjustments section of this manual.

 Åt least once a year you should replace the spark plug, clean or replace air filter, and check blades and belts for wear. A new spark plug and clean air filter assure proper air-fuel mixture and help your engine run better and last longer.

BEFORE EACH USE

- Check engine oil level.
- Check brake operation.
- Check tire pressure.
- Check operator presence and interlock systems for proper operation.
- Check for loose fasteners.

LUBRICATION CHART



- ① General Purpose Grease
- ② Refer to Maintenance "ENGINE" Section

IMPORTANT: DO NOT OIL OR GREASE THE PIVOT POINTS WHICH HAVE SPECIAL NYLON BEARINGS. VISCOUS LUBRICANTS WILL ATTRACT DUST AND DIRT THAT WILL SHORTEN THE LIFE OF THE SELF-LUBRICATING BEARINGS. IF YOU FEEL THEY MUST BE LUBRICATED, USE ONLY A DRY, POWDERED GRAPHITE TYPE LUBRICANT SPARINGLY.

TRACTOR

Always observe safety rules when performing any maintenance.

BRAKE OPERATION

If tractor requires more than five (5) feet to stop at highest speed in highest gear on a level, dry concrete or paved surface, then brake must be checked and adjusted. (See "TO ADJUST BRAKE" in the Service and Adjustments section of this manual).

TIRES

- Maintain proper air pressure in all tires (See "PRODUCT SPECIFICATIONS" section of this manual).
- Keep tires free of gasoline, oil, or insect control chemicals which can harm rubber.
- Avoid stumps, stones, deep ruts, sharp objects and other hazards that may cause tire damage.

NOTE: To seal tire punctures and prevent flat tires due to slow leaks, tire sealant may be purchased from your local parts dealer. Tire sealant also prevents tire dry rot and corrosion.

OPERATOR PRESENCE SYSTEM AND REVERSE OPERATION SYSTEM (ROS) (See Fig. 19)

Be sure operator presence and reverse operation systems are working properly. If your tractor does not function as described, repair the problem immediately.

 The engine should not start unless the brake pedal is fully depressed, and the attachment clutch control is in the disengaged position.

CHECK OPERATOR PRESENCE SYSTEM

- When the engine is running, any attempt by the operator to leave the seat without first setting the parking brake should shut off the engine.
- When the engine is running and the attachment clutch is engaged, any attempt by the operator to leave the seat should shut off the engine.
- The attachment clutch should never operate unless the operator is in the seat.

CHECK REVERSE OPERATION (ROS) SYSTEM

- When the engine is running with the ignition switch in the engine "ON" position and the attachment clutch engaged, any attempt by the operator to shift into reverse should shut off the engine.
- When the engine is running with the ignition switch in the ROS "ON" position and the attachment clutch engaged, any attempt by the operator to shift into reverse should NOT shut off the engine.




FIG.19

BLADE CARE(See Figs.20-22)

For best results mower blades must be kept sharp. Replace bent or damaged blades.

IMPORTANT: THE BLADES ON YOUR MOWER ARE NOT THE SAME AND MUST BE INSTALLED ON THE CORRECT SIDE. IT IS SUGGESTED THAT YOU WORK ON ONE BLADE AT A TIME TO ENSURE PROPER ASSEMBLY OF COMPONENTS.



CAUTION: Use only a replacement blade approved by the manufacturer of your tractor. Using a blade not approved by the manufacturer of your tractor is hazardous, could damage your tractor and void your warranty.




FIG.20

5 STAR PATTERN BLADE

The center of this blade has a five (5) star pattern. The bolt that attaches this blade has normal **Right Hand threads** that loosens by turning (\sim) counterclockwise and tightens by turning (\sim) clockwise.




FIG.21

6 STAR PATTERN BLADE

The center of this blade has a 6 star pattern. The bolt attaching this blade has **Left Hand threads** that loosens by turning (\sim) clockwise and tighten by turning (\sim) counterclockwise.




FIG. 22

BLADE REMOVAL

- Raise mower to highest position to allow access to blades.
- Remove blade bolt, lock washer and flat washer securing blade.
- Install new or resharpened blade with trailing edge up towards deck as shown.

IMPORTANT: To ensure proper assembly, center hole in blade must align with star on mandrel assembly.

- Reassemble blade bolt, lock washer and flat washer in exact order as shown.
- Tighten blade bolt securely (27-35 Ft. Lbs. torque).

IMPORTANT: Blade bolt is grade 8 heat treated

BATTERY

Your tractor has a battery charging system which is sufficient for normal use. However, periodic charging of the battery with an automotive charger will extend its life.

- · Keep battery and terminals clean.
- Keep battery bolts tight.
- · Keep small vent holes open.
- Recharge at 6-10 amperes for 1 hour.

NOTE: The original equipment battery on your tractor is maintenance free. Do not attempt to open or remove caps or covers. Adding or checking level of electrolyte is not necessary.

TO CLEAN BATTERY AND TERMINALS

Corrosion and dirt on the battery and terminals can cause the battery to "leak" power.

- Remove battery cover.
- Disconnect BLACK battery cable first then RED battery cable and remove battery from tractor.
- · Rinse the battery with plain water and dry.
- Clean terminals and battery cable ends with wire brush until bright.
- · Coat terminals with grease or petroleum jelly.
- Reinstall battery (See "CONNECT BATTERY" in the Assembly section of this manual).

V-BELTS

Check V-belts for deterioration and wear after 100 hours of operation and replace if necessary. The belts are not adjustable. Replace belts if they begin to slip from wear.

TRANSAXLE COOLING

The transmission fan and cooling fins should be kept clean to assure proper cooling.

Do not attempt to clean fan or transmission while engine is running or while the transmission is hot. To prevent possible damage to seals, do not use high pressure water or steam to clean transaxle.

- Inspect cooling fan to be sure fan blades are intact and clean.
- Inspect cooling fins for dirt, grass clippings and other materials. To prevent damage to seals, do not use compressed air or high pressure sprayer to clean cooling fins.


TRANSAXLE PUMP FLUID

The transaxle was sealed at the factory and fluid maintenance is not required for the life of the transaxle. Should the transaxle ever leak or require servicing, contact your nearest authorized service center/department.

ENGINE

LUBRICATION

Only use high quality detergent oil rated with API service classification SF-SJ. Select the oil's SAE viscosity grade according to your expected operating temperature.



oil visc chart4 e

Change the oil after every 50 hours of operation or at least once a year if the tractor is not used for 50 hours in one year.

Check the crankcase oil level before starting the engine and after each eight (8) hours of operation.

TO CHANGE ENGINE OIL (See Fig. 23)

Determine temperature range expected before oil change. All oil must meet API service classification SG-SL.

- Be sure tractor is on level surface.
- · Oil will drain more freely when warm.
- Catch oil in a suitable container.
- Remove oil fill cap/dipstick. Be careful not to allow dirt to enter the engine when changing oil.
- Remove yellow cap from bottom fitting of drain valve and install the drain tube onto the fitting.




FIG. 23

- Unlock drain valve by pushing inward and turning counterclockwise.
- To open, pull out on the drain valve.
- After oil has drained completely, close and lock the drain valve by pushing inward and turning clockwise until the pin is in the locked position as shown.
- Remove the drain tube and replace the cap onto to the bottom fitting of the drain valve.
- Refill engine with oil through oil fill dipstick tube. Pour slowly. Do not overfill. For approximate capacity see "PRODUCT SPECIFICATIONS" section of this manual.
- Use gauge on oil fill cap/dipstick for checking level. Insert dipstick into the tube and rest the oil fill cap on the tube. Do not thread the cap onto the tube when taking reading. Keep oil at "FULL" line on dipstick. Tighten cap onto the tube securely when finished.

CLEAN AIR SCREEN

Air screen must be kept free of dirt and chaff to prevent engine damage from overheating. Clean with a wire brush or compressed air to remove dirt and stubborn dried gum fibers. See engine manual.

AIR FILTER

Your engine will not run properly using a dirty air filter. Clean the foam pre-cleaner after every 25 hours of operation or every season. Service paper cartridge every 50 hours of operation or every season, whichever occurs first. See engine manual.

MUFFLER

Inspect and replace corroded muffler and spark arrester (if equipped) as it could create a fire hazard and/or damage.

SPARK PLUGS

Replace spark plugs at the beginning of each mowing season or after every 100 hours of operation, whichever occurs first. Spark plug type and gap setting are shown in "PRODUCT SPECIFICATIONS" section of this manual.

ENGINE OIL FILTER

Replace the engine oil filter every season or every other oil change if the tractor is used more than 100 hours in one year. See engine manual.

IN-LINE FUEL FILTER (See Fig. 24)

The fuel filter should be replaced once each season. If fuel filter becomes clogged, obstructing fuel flow to carburetor, replacement is required.

- With engine cool, remove filter and plug fuel line sections.
- Place new fuel filter in position in fuel line with arrow pointing towards carburetor.
- Be sure there are no fuel line leaks and clamps are properly positioned.
- · Immediately wipe up any spilled gasoline.




FIG. 24

CLEANING

- Clean engine, battery, seat, finish, etc. of all foreign matter.
- Keep finished surfaces and wheels free of all gasoline, oil, etc.
- Protect painted surfaces with automotive type wax.

We do not recommend using a garden hose or pressure washer to clean your tractor unless the engine and transmission are covered to keep water out. Water in engine or transmission will shorten the useful life of your tractor. Use compressed air or a leaf blower to remove grass, leaves and trash from tractor and mower.



WARNING: TO AVOID SERIOUS INJURY, BEFORE PERFORMING ANY SERVICE OR ADJUST-MENTS:

- Depress clutch/brake pedal fully and set parking brake.
- Place motion control lever in neutral (N) position.
- Place attachment clutch in "DISENGAGED" position.
- Turn ignition key to "STOP" and remove key.
- Make sure the blades and all moving parts have completely stopped.
- Disconnect spark plug wire from spark plug and place wire where it cannot come in contact with plug.

TRACTOR

TO REMOVE MOWER (See Fig. 25)

Mower will be easier to remove from the right side of tractor.

- Place attachment clutch control in "DISENGAGED" position.
- Move attachment lift lever forward to lower mower to its lowest position.
- · Roll belt off clutch pulley.
- Disconnect anti-sway bar from chassis bracket by removing retainer spring.
- Disconnect suspension arms from rear deck brackets by removing retainer springs.
- Disconnect front links from deck by removing retainer springs.
- Raise lift lever to raise suspension arms. Slide mower out from under tractor.

IMPORTANT: IF AN ATTACHMENT OTHER THAN THE MOWER DECK IS TO BE MOUNTED ON THE TRACTOR, REMOVE THE FRONT LINKS.


TO INSTALL MOWER (See Fig. 25)

Be sure tractor is on level surface and mower suspension arms are raised with attachment lift control. Engage parking brake.

Slide mower under tractor.

IMPORTANT: Check belt for proper routing in all mower pulley grooves.

- Install belt into clutch pulley groove.
- Install left front link into the left hand front mower bracket (retain with single loop retainer springs as shown).
- Slide right side of mower back and install right front link into right hand front mower bracket (retain with single loop retainer springs).
- Place the suspension arms on mower pins, if necessary, rock and raise front of mower to align mower pins with the holes in suspension arms. Retain with double loop retainer spring, loop down as shown.
- Connect anti-sway bar to chassis bracket under left footrest and retain with double loop retainer spring.
- Raise deck to highest position.



TO LEVEL MOWER HOUSING

Adjust the mower while tractor is parked on level ground or driveway. Make sure tires are properly inflated (See "PRODUCT SPECIFICATIONS" section of this manual). If tires are over or underinflated, you will not properly adjust your mower.

SIDE-TO-SIDE ADJUSTMENT (See Figs. 26 and 27)

- Raise mower to its highest position.
- At the midpoint of both sides of mower, measure height from bottom edge of mower to ground. Distance "A" on both sides of mower should be the same or within 1/4" of each other.
- If adjustment is necessary, make adjustment on one side of mower only.
- To raise one side of mower, tighten lift link adjustment nut on that side.
- To lower one side of mower, loosen lift link adjustment nut on that side.

NOTE: Three full turns of adjustment nut will change mower height about 1/8".

Recheck measurements after adjusting.




FIG. 26




FIG. 27

FRONT-TO-BACK ADJUSTMENT (See Figs. 28 and 29) IMPORTANT: DECK MUST BE LEVEL SIDE-TO-SIDE. IF THE FOLLOWING FRONT-TO-BACK ADJUSTMENT IS NECESSARY, BE SURE TO ADJUST BOTH FRONT LINKS EQUALLY SO MOWER WILL STAY LEVEL SIDE-TO-SIDE.

To obtain the best cutting results, the mower housing should be adjusted so that the front is approximately 1/8" to 1/2" lower than the rear when the mower is in its highest position.

Check adjustment on right side of tractor. Measure distance "D" directly in front and behind the mandrel at bottom edge of mower housing as shown.

- Before making any necessary adjustments, check that both front links are equal in length.
- If links are not equal in length, adjust one link to same length as other link.
- To lower front of mower loosen nut "E" on both front links an equal number of turns.
- When distance "D" is 1/8" to 1/2" lower at front than rear, tighten nuts "F" against trunnion on both front links
- To raise front of mower, loosen nut "F" from trunnion on both front links. Tighten nut "E" on both front links an equal number of turns. The two front links must remain equal in length.
- When distance "D" is 1/8" to 1/2" lower at front than rear, tighten nut "F" against trunnion on both front links.
- · Recheck side-to-side adjustment.




FIG. 28




FIG. 29




FIG. 30

TO REPLACE MOWER BLADE DRIVE BELT (See Fig. 30)

Park the tractor on level surface. Engage parking brake.

BELT REMOVAL -

- Remove mower from tractor (See "TO REMOVE MOWER" in this section of this manual).
- Remove screws from RH mandrel cover and remove cover.
- Remove screws from LH mandrel cover and remove cover
- Work belt off both mandrel pulleys and idler pulleys.
- · Pull belt away from mower.

BELT INSTALLATION -

- Install new belt in reverse order of removal. See belt routing decal located on right mandrel cover.
- Make sure belt is in all pulley grooves and inside all belt guides.
- Install left and right mandrel covers and tighten securely.
 Make sure belt is in mandrel pulley cover.
- Install mower (see "To install mower" in this section of this manual).




FIG. 31

TO CHECK BRAKE

If tractor requires more than five (5) feet to stop at highest speed in highest gear on a level, dry concrete or paved surface, then brake must be serviced.

You may also check brake by:

- 1. Park tractor on a level, dry concrete or paved surface, depress brake pedal all the way down and engage parking brake.
- Disengage transmission by placing freewheel control in "transmission disengaged" position. Pull freewheel control out and into the slot and release so it is held in the disengaged position.

The rear wheels must lock and skid when you try to manually push the tractor forward. If the rear wheels rotate, then the brake needs to be serviced. Contact a Sears or other qualified service center.

TO REPLACE MOTION DRIVE BELT (See Fig. 32)

Park the tractor on level surface. Engage parking brake. For assistance, there is a belt installation guide decal on bottom side of left footrest.

BELT REMOVAL -

 Remove mower (See "TO REMOVE MOWER" in this section of manual).

NOTE: Observe entire motion drive belt and position of all belt guides and keepers.

- Disconnect clutch wire harness.
- · Remove clutch locator.
- Remove belt from clutching idler and all stationary idlers.
- Remove belt downward from engine pulley and around electric clutch.
- Pull belt slack toward rear of tractor. Carefully remove belt upwards from transmission input pulley and over cooling fan blades.

BELT INSTALLATION -

- Carefully work new belt down around transmission cooling fan and onto the input pulley.
- Pull belt toward front of tractor and roll belt around electric clutch and onto engine pulley.
- Install belt through all stationary idlers and clutching idler
- Reinstall clutch locator and tighten nut securely.
- Reconnect clutch harness.
- Make sure belt is in all pulley grooves and inside all belt guides and keepers.
- Install mower (See "TO INSTALL MOWER" in this section of manual).




FIG. 32

TRANSMISSION REMOVAL/REPLACEMENT

Should your transmission require removal for service or replacement, it should be purged after reinstallation and before operating the tractor. See "PURGE TRANSMISSION" in the Operation section of this manual.

TRANSAXLE MOTION CONTROL LEVER NEUTRAL ADJUSTMENT (See Fig. 33)

The motion control lever has been preset at the factory and adjustment should not be necessary.

- Loosen adjustment bolt in front of the right rear wheel, and lightly tighten.
- Start engine and move motion control lever until tractor does not move forward or backward.
- Hold motion control lever in that position and turn engine off
- While holding motion control lever in place, loosen the adjustment bolt.
- Move motion control lever to the neutral (N) (lock gate) position.
- Tighten adjustment bolt securely.

NOTE: If additional clearance is needed to get to adjustment bolt, move mower deck height to the lowest position.

After above adjustment is made, if the tractor still creeps forward or backward while motion control lever is in neutral position, follow these steps:

- Loosen the adjustment bolt.
- Move the motion control lever 1/4 to 1/2 inch in the direction it is trying to creep.
- Tighten adjustment bolt securely.
- Start engine and test.
- If tractor still creeps, repeat above steps until satisfied




FIG. 33

TO ADJUST STEERING WHEEL ALIGNMENT

If steering wheel crossbars are not horizontal (left to right) when wheels are positioned straight forward, remove steering wheel and reassemble per instructions in the Assembly section of this manual.

FRONT WHEEL TOE-IN/CAMBER

The front wheel toe-in and camber are not adjustable on your tractor. If damage has occurred to affect the front wheel toe-in or camber, contact your nearest authorized service center/department.

TO REMOVE WHEEL FOR REPAIRS (See Fig. 34)

- Block up axle securely.
- Remove axle cover, retaining ring and washers to allow wheel removal (rear wheel contains a square key - Do not lose).
- Repair tire and reassemble.

- On rear wheels only: align grooves in rear wheel hub and axle. Insert square key.
- Replace washers and snap retaining ring securely in axle groove.
- Replace axle cover.

NOTE: To seal tire punctures and prevent flat tires due to slow leaks, tire sealant may be purchased from your local parts dealer. Tire sealant also prevents tire dry rot and corrosion.




FIG. 34

TO START ENGINE WITH A WEAK BATTERY

(See Fig. 35)



WARNING: Lead-acid batteries generate explosive gases. Keep sparks, flame and smoking materials away from batteries. Always wear eye protection when around batteries.

If your battery is too weak to start the engine, it should be recharged. (See "BATTERY" in the MAINTENANCE section of this manual).

If "jumper cables" are used for emergency starting, follow this procedure:

IMPORTANT: YOUR TRACTOR IS EQUIPPED WITH A 12 VOLT SYSTEM. THE OTHER VEHICLE MUST ALSO BE A 12 VOLT SYSTEM. DO NOT USE YOUR TRACTOR BATTERY TO START OTHER VEHICLES.

TO ATTACH JUMPER CABLES -

- Connect one end of the RED cable to the POSITIVE (+) terminal of each battery(A-B), taking care not to short against tractor chassis.
- Connect one end of the BLACK cable to the NEGATIVE
 (-) terminal (C) of fully charged battery.
- Connect the other end of the BLACK cable (D) to good chassis ground, away from fuel tank and battery.




FIG. 35

TO REMOVE CABLES, REVERSE ORDER -

- BLACK cable first from chassis and then from the fully charged battery.
- · RED cable last from both batteries.

TO REPLACE HEADLIGHT BULB

- Raise hood.
- Pull bulb holder out of the hole in the backside of the grill.
- Replace bulb in holder and push bulb holder securely back into the hole in the backside of the grill.
- · Close hood.

INTERLOCKS AND RELAYS

Loose or damaged wiring may cause your tractor to run poorly, stop running, or prevent it from starting.

 Check wiring. See electrical wiring diagram in the Repair Parts section.

TO REPLACE FUSE

Replace with 20 amp automotive-type plug-in fuse. The fuse holder is located behind the dash.

TO REMOVE HOOD AND GRILL ASSEMBLY (See Fig. 36)

- Raise hood.
- · Unsnap headlight wire connector.
- Stand in front of tractor. Grasp hood at sides, tilt toward engine and lift off of tractor.
- To replace, reverse above procedure.




FIG. 36

ENGINE

TO ADJUST THROTTLE CONTROL CABLE

The throttle control has been preset at the factory and adjustment should not be necessary. If adjustment is necessary, see engine manual.

TO ADJUST CARBURETOR

The carburetor has been preset at the factory and adjustment should not be necessary. However, minor adjustment may be required to compensate for differences in fuel, temperature, altitude or load. If the carburetor does need adjustment, see engine manual.

STORAGE

Immediately prepare your tractor for storage at the end of the season or if the tractor will not be used for 30 days or more.



WARNING: Never store the tractor with gasoline in the tank inside a building where fumes may reach an open flame or spark. Allow the engine to cool before storing in any enclosure.

TRACTOR

Remove mower from tractor for winter storage. When mower is to be stored for a period of time, clean it thoroughly, remove all dirt, grease, leaves, etc. Store in a clean, dry area.

- Clean entire tractor (See "CLEANING" in the Maintenance section of this manual).
- Inspect and replace belts, if necessary (See belt replacement instructions in the Service and Adjustments section of this manual).
- Lubricate as shown in the Maintenance section of this manual.
- Be sure that all nuts, bolts and screws are securely fastened. Inspect moving parts for damage, breakage and wear. Replace if necessary.
- Touch up all rusted or chipped paint surfaces; sand lightly before painting.

BATTERY

- Fully charge the battery for storage.
- After a period of time in storage, battery may require recharging.
- To help prevent corrosion and power leakage during long periods of storage, battery cables should be disconnected and battery cleaned thoroughly (see "TO CLEAN BATTERY AND TERMINALS" in the Maintenance section of this manual).
- After cleaning, leave cables disconnected and place cables where they cannot come in contact with battery terminals.
- If battery is removed from tractor for storage, do not store battery directly on concrete or damp surfaces.

ENGINE

FUEL SYSTEM

IMPORTANT: IT IS IMPORTANT TO PREVENT GUM DEPOSITS FROM FORMING IN ESSENTIAL FUEL SYSTEM PARTS SUCH AS CARBURETOR, FUEL FILTER, FUEL HOSE, OR TANK DURING STORAGE. ALSO, EXPERIENCE INDICATES THAT ALCOHOL BLENDED FUELS (CALLED GASOHOL OR USING ETHANOL OR METHANOL) CANATTRACT MOISTURE WHICH LEADS TO SEPARATION AND FORMATION OF ACIDS DURING STORAGE. ACIDIC GAS CAN DAMAGE THE FUEL SYSTEM OF AN ENGINE WHILE IN STORAGE.

- Empty the fuel tank by starting the engine and let it run until the fuel lines and carburetor are empty.
- Never use engine or carburetor cleaner products in the fuel tank or permanent damage may occur.
- Use fresh fuel next season.

NOTE: Fuel stabilizer is an acceptable alternative in minimizing the formation of fuel gum deposits during storage. Add stabilizer to gasoline in fuel tank or storage container. Always follow the mix ratio found on stabilizer container. Run engine at least 10 minutes after adding stabilizer to allow the stabilizer to reach the carburetor. Do not empty the gas tank and carburetor if using fuel stabilizer.

ENGINE OIL

Drain oil (with engine warm) and replace with clean engine oil. (See "ENGINE" in the Maintenance section of this manual).

CYLINDER(S)

- Remove spark plug(s).
- Pour one ounce of oil through spark plug hole(s) into cylinder(s).
- Turn ignition key to "START" position for a few seconds to distribute oil.
- Replace with new spark plug(s).

OTHER

- Do not store gasoline from one season to another.
- Replace your gasoline can if your can starts to rust.
 Rust and/or dirt in your gasoline will cause problems.
- If possible, store your tractor indoors and cover it to give protection from dust and dirt.
- Cover your tractor with a suitable protective cover that does not retain moisture. Do not use plastic. Plastic cannot breathe which allows condensation to form and will cause your tractor to rust.

IMPORTANT: NEVER COVER TRACTOR WHILE ENGINE AND EXHAUST AREAS ARE STILL WARM.


TROUBLESHOOTING POINTS

| PROBLEM | CAUSE | CORRECTION |
|----------------------------------|--|---|
| Will not start | Out of fuel. Engine not "CHOKED" properly. Engine flooded. Bad spark plug. Dirty air filter. Dirty fuel filter. Water in fuel. Loose or damaged wiring. Carburetor out of adjustment. Engine valves out of adjustment. | Fill fuel tank. See "TO START ENGINE" in Operation section. Wait several minutes before attempting to start. Replace spark plug. Clean/replace air filter. Replace fuel filter. Empty fuel tank and carburetor, refill tank with fresh gasoline and replace fuel filter. Check all wiring. See "To Adjust Carburetor" in Service Adjustments section. Contact an authorized service center/department. |
| Hard to start | Dirty air filter. Bad spark plug. Weak or dead battery. Dirty fuel filter. Stale or dirty fuel. Loose or damaged wiring. Carburetor out of adjustment. 8. Engine valves out of adjustment. | Clean/replace air filter. Replace spark plug. Recharge or replace battery. Replace fuel filter. Empty fuel tank and refill tank with fresh, clean gasoline. Check all wiring. See "To Adjust Carburetor" in Service Adjustments section. Contact an authorized service center/department. |
| Engine will not turn over | Brake pedal not depressed. Attachment clutch is engaged. Weak or dead battery. Blown fuse. Corroded battery terminals. Loose or damaged wiring. Faulty ignition switch. Faulty solenoid or starter. Faulty operator presence switch(es). | Depress brake pedal. Disengage attachment clutch. Recharge or replace battery. Replace fuse. Clean battery terminals. Check all wiring. Check/replace ignition switch. Check/replace solenoid or starter. Contact an authorized service center/department. |
| Engine clicks but will not start | Weak or dead battery. Corroded battery terminals. Loose or damaged wiring. Faulty solenoid or starter. | Recharge or replace battery. Clean battery terminals. Check all wiring. Check/replace solenoid or starter. |
| Loss of power | Cutting too much grass/too fast. Throttle in "CHOKE" position. Build-up of grass, leaves and trash under mower. Dirty air filter. Low oil level/dirty oil. Faulty spark plug. Dirty fuel filter. Stale or dirty fuel. Water in fuel. Spark plug wire loose. Dirty engine air screen/fins. Dirty/clogged muffler. Loose or damaged wiring. Carburetor out of adjustment. Engine valves out of adjustment. | Raise cutting height/reduce speed. Adjust throttle control. Clean underside of mower housing. Clean/replace air filter. Check oil level/change oil. Clean and regap or change spark plug. Replace fuel filter. Empty fuel tank and refill tank with fresh, clean gasoline. Empty fuel tank and carburetor, refill tank with fresh gasoline and replace fuel filter. Connect and tighten spark plug wire. Clean engine air screen/fins. Clean/replace muffler. Check all wiring. See "To Adjust Carburetor" in Service Adjustments section. Contact an authorized service center/department. |
| Excessive vibration | Worn, bent or loose blade. Bent blade mandrel. Loose/damaged part(s). | Replace blade. Tighten blade bolt. Replace blade mandrel. Tighten loose part(s). Replace damaged parts. |


TROUBLESHOOTING POINTS

| PROBLEM | CAUSE | CORRECTION | | |
|--|---|--|--|--|
| Engine continues to run when operator leaves seat with attachment clutch engaged | Faulty operator-safety presence control system. | Check wiring, switches and connections. If not corrected, contact an authorized service center/department. | | |
| Poor cut - uneven | Worn, bent or loose blade. Mower deck not level. Buildup of grass, leaves, and trash under mower. Bent blade mandrel. Clogged mower deck vent holes from buildup of grass, leaves, and trash around mandrels. | Replace blade. Tighten blade bolt. Level mower deck. Clean underside of mower housing. Replace blade mandrel. Clean around mandrels to open vent holes. | | |
| Mower blades will not rotate | Obstruction in clutch mechanism. Worn/damaged mower drive belt. Frozen idler pulley. Frozen blade mandrel. | Remove obstruction. Replace mower drive belt. Replace idler pulley. Replace blade mandrel. | | |
| Poor grass discharge | Engine speed too slow. Travel speed too fast. Wet grass. Mower deck not level. Low/uneven tire air pressure. Worn, bent or loose blade. Buildup of grass, leaves and trash under mower. Mower drive belt worn. Blades improperly installed. Improper blades used. Clogged mower deck vent holes from buildup of grass, leaves, and trash around mandrels. | Place throttle control in "FAST" position. Shift to slower speed. Allow grass to dry before mowing. Level mower deck. Check tires for proper air pressure. Replace/sharpen blade. Tighten blade bolt. Clean underside of mower housing. Replace mower drive belt. Reinstall blades sharp edge down. Replace with blades listed in this manual. Clean around mandrels to open vent holes. | | |
| Headlight(s) not working (if so equipped) | Light switch is "OFF". Bulb(s) or lamp(s) burned out. Faulty light switch. Loose or damaged wiring. Blown fuse. | Turn light switch "ON". Replace bulb(s) or lamp(s). Check/replace light switch. Check wiring and connections. Replace fuse. | | |
| Battery will not charge | Bad battery cell(s). Poor cable connections. Faulty regulator (if so equipped). Faulty alternator. | Replace battery. Check/clean all connections. Replace regulator. Replace alternator. | | |
| Loss of drive | Freewheel control in "disengaged" position. Motion drive belt worn, damaged, or broken. Air trapped in transmission during shipment or servicing. | Place freewheel control in "engaged" position. Replace motion drive belt. Purge transmission. | | |
| Engine "backfires" when turning engine "OFF" | Engine throttle control not set between half and full speed (fast) position before stopping engine. | Move throttle control between half and full speed (fast) position before stopping engine. | | |
| Mower will not operate | Bagger or optional rear discharge deflector is not installed correctly. | Check bagger or optional rear discharge deflector for proper installation | | |

TRACTOR- -MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17 SCHEMATIC



TRACTOR- -MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17 ELECTRICAL



TRACTOR- -MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17 ELECTRICAL

| KEY NO. | | DESCRIPTION |
|-------------|------------------------------|---|
| 1 | 532 14 49-27 | Battery |
| 2 | 874 76 04-12 | Bolt Hex Hd 1/4-20 unc x 3/4 |
| 16 | 532 17 61-38 | Switch Interlock |
| 21 | 532 18 37-59 | Harness Asm Light W/4152J |
| 22 | | Bulb Light #1156 |
| 24 | | Cable Starter 6 Ga. 16" Red |
| 25 | 532 16 59-87 | Cable Battery Crd 56" Red Fuse |
| 26 27 | 532 17 51-58 873 51 04-00 | |
| 28 | 532 12 77-25 | Nut Keps Hex 1/4-20 unc Cable Ground 6 Ga. 18" Black |
| 29 | 532 12 77-23 | Switch Seat |
| 30 | 532 19 33-50 | Switch Ignition |
| 33 | 532 14 04-01 | Key Ign Molded |
| 34 | 532 11 07-12 | Switch Light |
| 40 | 532 19 74-34 | Harness Ign |
| 41 | 871 11 04-08 | Bolt Flk Fin Hex 1/4-20 unc x 1/2 |
| 42 | 532 13 15-63 | Cover Terminal Red |
| 43 | 532 19 25-07 | Solenoid |
| 46 | 532 40 17-63 | Gauge Hourmeter |
| 48 | 532 14 08-44 | Adapter Ammeter Rectangular |
| 50 | 532 17 46-51 | Switch PTO |
| 58 | 532 16 94-19 | Buzzer Crd |
| 59 | 532 18 03-79 | Switch FBI CRD |
| 66 | 817 49 06-08 | Screw Thdrol 3/8-16 x 1/2 Ty-Tt |
| 81 92 | 532 10 97-48 532 19 66-15 | Relay Asm Harness Pigtail |
| 93 | 532 19 00-15 | Screw Plastite 10-14 x 2.0 |
| 94 | 532 19 23-40 | Module Reverse |
| 5 -1 | 332 10 10 04 | 11104410 11010100 |

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm.


chassis-tex_62_Tex GT Husq_CRD

TRACTOR--MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17 **CHASSIS AND ENCLOSURES** -216

TRACTOR- -MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17 CHASSIS AND ENCLOSURES

| KEY NO. | PART NO. | DESCRIPTION | KEY NO. | PART NO. | DESCRIPTION |
|------------|------------------------------|--------------------------------|------------|------------------------------|--|
| 1 | 532 17 46-20 | Chassis | 171 | 872 14 06-20 | Bolt Rdhd Sqnk |
| 2 | 532 18 03-84 | Drawbar | | | 3/8-16 x 2-1/2 Gr. 5 |
| 3 | 817 06 06-12 | Screw 3/8-16 x 3/4 | 172 | 819 13 20-16 | Washer 13/32 x 1-1/4 x 16 Ga. |
| 5 | 532 40 75-90 | Bumper Hood/Dash | 173 | 873 51 06-00 | Nut, Keps Hex 3/8-16 unc |
| 6 | 532 18 44-19 | Saddle | 175 | 532 18 82-03 | Guard Trap |
| 8 | 532 12 64-71 | Clip Insulator 13/32 Mtg. Hole | 179 | 532 18 82-02 | Rod Pivot FBI CRD |
| 9 | 532 40 89-11 | Dash Upper | 184 | 532 17 46-62 | Bracket Actuator Bagger CRD |
| 10 | 872 14 06-08 | Bolt, Carriage 3/8-16 x 3/4 | 185 | 532 18 11-01 | Knob Rod Brake Parking |
| 11 | 532 16 72-03 | Panel, Dash, L.H. | 186 | 532 16 07-93 | Latch Asm Mulch/Bagger |
| 13 | 532 17 82-98 | Panel, Asm. Dash R.H. | 187 | 532 12 50-04 | Nut Weld |
| 15 | 874 18 05-12 | Screw, Machine, THD | 188 189 | 819 06 12-16 | Washer #10 |
| 16 | 072 51 05 00 | 5/16-18 unc x 3/4 | 190 | 810 07 10-00 871 08 10-10 | Washer Lock #10 |
| 16 17 | 873 51 05-00 | Nut Keps 5/16-18 unc Hood | 198 | 532 16 89-37 | Screw Pan Hd Phillip 10-24 x 5/8 Nut, Push |
| 18 | 532 41 10-46 532 40 47-42 | Bumper Hood | 205 | 817 49 06-08 | Screw Thdrol 3/8-16 x 1/2 |
| 24 | 874 78 06-16 | Bolt | 207 | 817 67 05-08 | Screw Thdrol 5/16-18 x 1/2 |
| 25 | 819 13 13-12 | Washer 13/32 x 13/16 x 12 Ga. | 209 | 817 00 06-12 | Screw Hex Wsh Thdrol 3/8-16 |
| 26 | 873 80 06-00 | Nut | 213 | 532 40 17-11 | Skirt Side LH |
| 28 | 532 40 86-07 | Grille /Lens Asm | 214 | 532 40 17-11 | Skirt Side RH |
| 30 | 532 19 73-76 | Fender | 216 | 817 06 04-10 | Hex Tapping Screw |
| 31 | 532 16 51-56 | Bracket, Fender Support | 256 | 532 18 13-61 | Cover Fender Rack |
| 33 | 532 18 10-57 | Footrest, L.H. | 258 | 532 19 89-06 | Lens RH |
| 34 | 532 18 10-58 | Footrest, R.H. | 259 | 532 19 89-07 | Lens LH |
| 35 | 872 11 06-06 | Bolt | 263 | 532 19 71-98 | Bezel RH |
| 37 | 817 49 05-08 | Screw Thdrol 5/16-18 x 1/2 TYT | 264 | 532 19 71-99 | Bezel LH |
| 38 | 532 18 17-48 | Bracket Asm Pivot Mower Rear | 265 | 532 18 57-04 | Seal RH Side Bagger |
| 39 | 532 41 02-50 | Bracket Pivot | 266 | 532 18 57-03 | Seal LH Side Bagger |
| 58 | 532 19 85-12 | Duct Air | 272 | 532 40 30-48 | Vent Hood RH |
| 64 | 532 19 93-95 | Dash Lower | 273 | 532 40 30-76 | Vent Hood LH |
| 69 | 532 14 24-32 | Screw Hx Wsh Hi-Lo 1/4-1/2 | 278 | 532 19 16-11 | Screw 10 x 3/4 Single Lead-Hex |
| 89 | 532 19 73-77 | Console Crd Auto Grey | 295 | 532 40 05-39 | Vent Top Hood |
| 145 | 532 15 65-24 | Rod Pivot Chassis/Hood | 300 | 532 19 91-31 | Insert Tex Top LH |
| 154 | 532 40 86-90 | Bracket Mounting Dash RH | 301 | 532 19 91-30 | Insert Tex Top RH |
| 155 | 532 40 86-91 | Bracket Mounting Dash LH | 302 | 532 19 91-32 | Insert Tex Bottom RH |
| 162 | 532 18 03-82 | Bracket Exten Chassis Lh CRD | 303 | 532 19 91-33 | Insert Tex Bottom LH |
| 163 | 532 18 03-83 | Bracket Exten Chassis Rh CRD | | | |
| 164 | 532 16 56-05 | Support Battery CRD | | | |
| 165 | 532 18 11-00 | Cover Battery | NOT | | nt dimensions given in U.S. inches. |
| 170 | 532 19 94-88 | Backplate CRD | | 1 inch = 25.4 n | nm. |


TRACTOR--MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17



TRACTOR- -MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17 DRIVE

| KEY NO. | PART NO. | DESCRIPTION | KEY NO. | PART NO. | DESCRIPTION |
|------------|------------------------------|---|------------|--|--|
| 1 | | Transaxle Hydro Gear 321-0510 (Order parts from transaxle manufacture) | 83 84 | 819 17 12-16 532 17 00-07 532 17 00-15 | Washer 17/32 x 3/4 x 16 Ga. Link, Transaxle |
| 8 | 532 19 27-06 | facturer) Rod, Shift Fender Adjust Lt | 95 96 | 532 17 00-15 | Control Asm Bypass Hydro Spring, Retainer 1" |
| 9 | 532 19 81-43 | Clutch Electric | 112 | 819 09 12-10 | Washer 9/32 x 3/4 x 10 Ga. |
| 10 14 | 876 02 04-16 810 04 04-00 | Pin, Cotter 1/8 x 1 Washer, Lock Hvy Helical | 120 150 | 873 90 06-00 532 16 58-50 | Nut Lock Flg. 3/8-16 unc Bushing, Bellcrank Grnd Dr |
| 15 | 874 49 05-44 | Bolt Hex FGHD 5/16-18 x Gr 5 | 151 | 819 13 32-10 | Washer 13/32 x 2 x 10 Ga. |
| 16 17 | 873 80 05-00 | Nut Lock Hex W/Ins 5/16-18 unc | 156 | 532 16 60-02 | Washer Streed 5/16 ID x 1.125 |
| 19 | 532 12 61-97 873 80 06-00 | Washer 1-1/2 x 15/32 x .250 Nut Lock Hex w/Ins 3/8-16 unc | 158 159 | 532 16 55-89 532 18 39-00 | Bracket Shift Mount Hub Shift |
| 20 | 532 17 39-37 | Bolt Hex 7/16-20 x 4 Gr.5 | 161 | 872 14 04-06 | Bolt Rdhd Sqnk 1/4-20 x 3/4 Gr 5 |
| 21 22 | 532 12 12-74 532 17 56-07 | Knob Duckhead 1/4-13 unc Blk Rod Brake Main | 162 163 | 873 68 04-00 874 78 04-16 | Nut Crownlock 1/4-20 unc Bolt Hex Fin 1/4-20 unc x 1 Gr 5 |
| 24 | 873 35 06-00 | Nut Hex Jam 3/8-16 unc | 165 | 532 16 56-23 | Bracket Pivot Lever |
| 25 | 532 19 20-36 | Spring, Rod, Brake | 166 | 817 49 05-10 | Screw 5/16-18 x 5/8 |
| 27 28 | 876 02 04-12 532 17 57-65 | Pin, Cotter 1/8 x 3/4 Rod, Parking Brake | 167 168 | 532 16 55-88 532 16 54-92 | Bracket Support Shift CRD Bolt Shoulder 5/16-18 x .561 |
| 29 | 532 07 16-73 | Cap, Parking Brake | 169 | 532 16 55-80 | Plate Fastening Lt |
| 30 | 532 16 95-92 | Bracket, Mfg. Transaxle | 171 | 817 49 06-08 | Screw Thdrol 3/8-16 x 1/2 Ty-Tt |
| 34 35 | 532 17 55-78 532 12 01-83 | Shaft, Asm Pedal Foot CRD Bearing, Nylon | 172 177 | 532 17 02-71 532 16 59-32 | Shaft Asm Shifter Frt CRD Keeper Flat Idler 3.06" CRD |
| 36 | 819 21 16-16 | Washer 21/32 x 1 x 16 Ga. | 181 | 532 18 02-11 | Bracket Idler Ground Drive CRD |
| 37 | 532 12 49-63 | Pin, Roll 3/16 x 1" | 182 | 532 18 26-82 | Keeper Belt 2.5" Od V-Idler CRD |
| 38 39 | 532 16 59-36 874 76 06-44 | Pulley Flat Composite 3.06" Bolt Fin Hex 3/8-16 unc x 2-3/4 | 183 185 | 532 19 95-32 532 17 00-08 | Pulley V-Idler 2.50" Od CRD Link Shift |
| 40 | 532 12 49-65 | Spacer, Split 395 x 59 Bzp | 186 | 532 16 56-14 | Hub Tapered Round CRD |
| 42 | 819 13 13-12 | Washer 13/32 x 13/16 x 12 Ga. | 187 | 817 58 05-20 | Screw Thdrol 5/16-18 x 1.25 |
| 43 47 | 819 11 10-12 532 12 77-83 | Washer 11/32 x 5/8 x 12 Ga. Pulley, Idler, V Groove Plasitc | 197 199 | 532 16 96-13 532 16 96-12 | Nyliner Snap-In 5/8 Bolt Shoulder 5/16-18 unc |
| 48 | 532 15 44-07 | Bellcrank Clutch Grnd Drv | 200 | 872 14 05-08 | Bolt RDHD SQNK 5/16-18 x 1 |
| 49 50 | 532 12 32-05 | Retainer, Belt Style Spring | 207 | 532 16 98-45 | Washer Nylon Rear |
| 50 51 | 872 11 06-12 873 68 06-00 | Bolt Carr. Sh. 3/8-16 x 1-1/2 Gr. 5 Nut, Crownlock 3/8-16 unc | 214 215 | 532 17 56-09 532 17 56-52 | Shaft Asm. Brake Rod Brake Hydro |
| 52 | 873 68 05-00 | Nut Crownlock 5/16-18 | 243 | 532 19 07-36 | Bracket Anti Rotation |
| 53 55 | 532 19 96-52 532 10 57-09 | Link, Clutch 7.66 | 252 254 | 819 13 16-16 817 00 06-16 | Washer 13/32 x 1 x 16 Ga. Screw 3/8-16 x 1 |
| 56 | 817 06 06-20 | Spring, Return, Clutch Screw 3/8-16 x 1-1/4 | 255 | 532 17 56-08 | Brace Shaft Brake Mtg. |
| 57 | 532 17 01-40 | V-Belt Kev 112" 0650 CRD | 258 | 532 17 80-62 | Clip Retainer |
| 62 63 | 532 12 35-33 532 18 03-97 | Cover, Pedal Pulley Engine | 259 260 | 532 18 02-12 532 19 76-07 | Bracket Pulley Bracket Idler Chassis |
| 65 | 810 04 07-00 | Washer | 261 | 532 13 14-94 | |
| 66 | 532 15 47-78 | Keeper, Belt Engine F-Proof | 262 | 872 11 06-22 | Bolt Carr. 3/8-16 x 2-3/4 Gr.5 |
| 71 73 | 532 16 91-83 532 16 91-82 | Strap, Torque, Lh Strap, Torque, Rh | 263 266 | 817 00 06-12 532 18 20-61 | Screw 3/8-16 x 3/4 Shield Idler Mower |
| 73 74 | 532 13 70-57 | Spacer, Split | 279 | 872 11 06-16 | |
| 75 | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga. | 292 | 532 40 02-71 | Spacer |
| 76 77 | 812 00 00-01 532 12 35-83 | Ring, E Key, Square | 295 | 532 17 91-14 | Pulley Idler Composite |
| 78 | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga. | | | |
| 81 | 532 17 00-06 | Asm, Shaft, Cross Rear | | _ | |
| 82 | 532 16 57-11 | Spring, Torsion | | E: All compone n = 25.4 mm | nt dimensions given in U.S. inches |

TRACTOR- -MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17 STEERING ASSEMBLY




TRACTOR- -MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17 STEERING ASSEMBLY

| KEY | PART | |
|------------|--------------|------------------------------------|
| NO. | NO. | DESCRIPTION |
| 1 | 532 19 36-51 | Steering Wheel |
| 2 | 532 18 47-06 | Axle Asm Cast Iron Lt |
| 3 | 532 16 98-40 | Spindle Assembly, L.H. |
| 4 | 532 16 98-39 | Spindle Assembly, R.H. |
| 5 | 532 12 49-31 | Bearing, Race, Thrust, Hardened |
| 6 | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga. |
| 8 | 812 00 00-29 | Ring, Klip |
| 10 | 532 17 51-21 | Link, Drag |
| 11 | 810 04 06-00 | Washer, Lock |
| 12 | 873 94 08-00 | Nut Hex Jam Toplock 1/2-20 unf |
| 13 | 532 13 65-18 | Spacer Brg Axle Front |
| 15 | 532 14 52-12 | Nut Hex Flange Lock |
| 17 | 532 17 78-83 | Shaft, Steering |
| 29 | 817 00 06-12 | Screw 3/8-16 x 3/4 |
| 32 | 532 17 18-88 | Rod, Tie |
| 33 | 819 11 12-16 | Washer 11/32 x 3/4 x 16 Ga. |
| 34 | 810 04 05-00 | Washer Lock Hvy Hlcl Spr 5/16 |
| 35 | 873 54 05-00 | Crownlock Nut 5/16-24 unf 3847 |
| 36 | 532 15 51-05 | Bushing, Steering |
| 37 | 532 15 29-27 | Screw TT #I0-32 x 5 x 3/8 Flange |
| 38 | 532 19 36-52 | Cap Wheel Steering |
| 39 | 819 18 38-12 | Washer 9/16ID x 2- 3/8 OD x 12 Ga. |
| 40 | 873 54 06-00 | Nut Lock 3/8-24 |
| 41 | 532 18 67-37 | Adaptor, Steering Wheel |
| 43 | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga. |
| 46 | 532 12 12-32 | Cap, Spindle |
| 65 | 532 16 03-67 | Spacer Brace Axle |
| 67 | 872 11 06-18 | Bolt Rdhd Sqnk 3/8-16 x 2-1/4 |
| 68 | 532 16 98-27 | Brace Axle |
| 71 | 532 17 51-46 | Steering Asm. |
| 82 | 532 19 99-78 | Bracket Susp Chassis Front |
| 87 | 532 17 39-66 | Washer Flat .781 x 1 1/2 x .14 |
| 88 | 532 17 51-18 | Bolt Shoulder 7/16-20 unc |
| 91 | 532 17 55-53 | Clip Steering |
| 95 | 532 18 89-67 | Washer |

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

TRACTOR- -MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17 ENGINE




TRACTOR- -MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17 ENGINE

| KEY NO. | PART NO. | DESCRIPTION |
|------------|--------------|---|
| 1 | 532 18 29-37 | Control Throttle |
| 2 | 532 19 16-11 | Screw 10 x 3/4 Single Lead Hex |
| 3 | | Engine Kohler SV710 |
| | | (Order Parts from Engine Manufacturer) |
| 4 | 532 14 97-23 | Muffler Exhaust |
| 5 | 532 14 66-99 | Tube, Exhaust LH |
| 6 | 532 14 67-00 | Tube, Exhaust RH |
| 8 | 532 17 18-77 | Bolt 5/16-18 x 3/4 |
| 10 | 532 14 66-29 | Shield Browning Intek |
| 13 | | Gasket (Order Parts from Engine Manufacturer) |
| 14 | 532 14 84-56 | Tube Drain Oil Easy |
| 17 | 817 12 06-16 | Screw 3/8-16 x 1 |
| 23 | 532 16 98-37 | Shield Browning/Debris Guard |
| 25 | | Choke Control |
| 29 | 532 13 71-80 | Arrestor Spark |
| 31 | 532 40 74-89 | Tank Fuel |
| 32 | | Cap Asm Fuel Top |
| 33 | 532 12 34-87 | Clamp Hose Blk |
| 37 | 532 13 70-40 | Line Fuel 20" |
| 38 | 532 18 16-54 | Plug Drain Oil Easy |
| 44 | 817 67 04-12 | Screw Hexwsh Thdrol 1/4-20 x 3/4 |
| 45 | 817 00 06-12 | Screw Hexwsh Thdr 3/8-16 x 3/4 |
| 46 | 819 09 14-16 | Washer 9/32 x 7/8 x 16ga |
| 72 | 532 19 23-34 | Screw Socket HD 5/16-48 x .75 |
| 81 | 873 51 04-00 | Nut Keps 1/4-20 unc |


NOTE: All component dimensions given in U.S. inches 1 inch = 25.4 mm

TRACTOR- -MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17 SEAT ASSEMBLY




| KEY NO. | PART NO. | DESCRIPTION | KEY NO. | PART NO. | DESCRIPTION |
|------------|--------------|--------------------------------|------------|----------------|-------------------------------------|
| 1 | 532 18 87-15 | Seat | 13 | 532 12 12-48 | Bushing Snap Blk Nyl 50 ld |
| 2 | 532 14 05-51 | Bracket Pnt Pivot Seat (blk) | 14 | 872 05 04-12 | Bolt Rdhd Sht Nk 1/4-20 x 1-1/2 |
| 3 | 871 11 06-16 | Bolt Fin Hex 3/8-16 x 1 | 15 | 532 12 12-49 | Spacer Split |
| 4 | 819 13 16-10 | Washer Flat 13/32 x 1 x 10 Ga. | 16 | 532 12 37-40 | Spring Cprsn Plate |
| 5 | 532 14 50-06 | Clip Push In Hinged | 17 | 532 12 39-76 | Nut Lock 1/4 Lge Flg Gr 5 Zinc |
| 6 | 873 80 06-00 | Nut Lock Hx w/Ins. 3/8-16 | 21 | 532 17 18-52 | Bolt Shoulder 5/16-18 unc-2A |
| 7 | 532 12 41-81 | Spring Seat Cprsn 2 250 Blk Zi | 22 | 873 80 05-00 | Nut Hex Lock w/Ins 5/16-18 |
| 8 | 817 00 06-16 | Screw 3/8-16 x 1-1/2 | 24 | 819 17 19-12 | Washer 17/32 x 1-3/16 x 12 Ga. |
| 9 | 819 13 16-14 | Washer 13/32 x 1 x 14 Ga. | 25 | 532 12 70-18 | Bolt Shoulder 5/16-18 x 62 |
| 10 | 532 19 55-30 | Pan Pnt Seat | | | |
| 11 | 532 16 63-69 | Knob Seat Adj. Wingnut | NOTE | E: All compone | nt dimensions given in U.S. inches. |
| 12 | 532 17 46-48 | Bracket Pnt Mounting Switch | 1 inch | n = 25.4 mm | |

TRACTOR- -MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17 DECALS



| KEY NO. | PART NO. | DESCRIPTION | KEY NO. | PART NO. | DESCRIPTION |
|------------|--------------|--------------------------------|------------|--------------|--------------------------------|
| 1 | 532 41 00-63 | Decal, Hood | 11 | 532 18 21-66 | Decal, Mower Cut Finger Symbol |
| 2 | 532 40 03-89 | Decal, Warning Symbols CE | 14 | 532 15 97-36 | Decal, Chassis Hot Muffler |
| 3 | 532 40 21-28 | Decal, Hood Top | 15 | 532 19 68-42 | Decal, Warning Cut Finger |
| 4 | 532 12 44-33 | Decal, 80 DBA | 16 | 532 16 88-69 | Decal, Tick Mark |
| 5 | 532 40 44-84 | Decal, Wheel Logo | 17 | 532 14 08-37 | Decal, Saddle Brake Parking |
| 6 | 532 19 68-41 | Decal, Warning Engine Symbols | 21 | 532 16 62-86 | Decal, Deck Sch 92 CRD |
| 7 | 532 40 28-32 | Decal, Hood Rh/LH | | 532 18 19-16 | Pad Footrest LH |
| 8 | 532 15 97-37 | Decal, Brake/Clutch Symbol | | 532 18 19-17 | Pad Footrest RH |
| 10 | 532 14 50-05 | Decal, Bat Dan/Poi P/L Sym Wpn | | 532 16 69-60 | Decal, Bypass |
| | | | | 532 41 02-43 | Manual Ówner's(English) |


WHEELS & TIRES



| KEY | PART | |
|------------|--------------|--------------------------------|
| NO. | NO. | DESCRIPTION |
| 1 | 532 05 91-92 | Cap Value Tire |
| 2 | 532 06 51-39 | Stem Value |
| 3 | 532 10 62-22 | Tire F Ts 15 x 6 0 - 6 Service |
| 4 | 532 05 99-04 | Tube Inner Front #35060 |
| 5 | 532 13 83-36 | Rim Asm 6" front Service |
| 6 | 532 12 49-57 | Fitting Grease |
| 7 | 532 12 49-59 | Bearing Flange |
| 8 | 532 13 83-37 | Rim Asm 8" rear Service |
| 9 | 532 12 20-82 | Tire R Ts 20 x 10-8 Service |
| 10 | 532 12 49-26 | Tube Rear 9 5 x 8 Service |
| 11 | 532 17 50-39 | Cap Axle Blk 1 50 x 1 00 |
| | 532 14 43-34 | Sealant, Tire (10 oz. tube) |

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm


TRACTOR- -MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17 MOWER



TRACTOR- -MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17 MOWER


| KEY NO. | PART NO. | DESCRIPTION | KEY NO. | PART NO. | DESCRIPTION |
|-------------|--|---|----------------------|--|--|
| 1 2 3 | 532 40 01-08 872 14 05-06 532 16 55-69 | Housing Asm. Mower 92 CRD Bolt Rdhd Sqnk 5/16-18 unc x 3/4 Bracket Asm. S-Bar Chass 92 CRD | 34 35 36 40 | 532 40 01-07 532 40 01-06 532 14 67-63 873 68 06-00 | Bracket Gauge Wheel Lf 92 CRD Bracket Gauge Wheel Rf 92 CRD Pulley Idler V-Groove Dim 4.25 Nut Crownlock 3/8-16 unc |
| 4 5 | 532 16 55-58 532 12 46-70 | Bracket Bar Sway Deck 92 CRD Retainer Spring | 41 44 | 873 90 06-00 532 17 55-38 | Nut Lock Flg. 3/8-16 unc Cover Mandrel LH 92 CRD |
| 6 | 532 16 55-57 | Bar Sway 92 CRD | 45 | 532 17 55-39 | Cover Mandrel RH 92 CRD |
| 8 | 532 18 17-12 | Bolt 3/8-24 x 1.25 Gr. 8 Patched | 46 | 532 13 77-29 | Screw Thd Roll 1/4-20 x 5/8 |
| 9 | 810 03 06-00 | Washer Lock Hvy 3/8 Unplated | 55 | 532 19 94-98 | Arm Idler 92 CRD |
| 10 | 532 14 02-96 | Washer Hardened | 56 | 532 16 57-23 | Spacer Retainer Mower |
| 11 | 532 18 63-85 | Blade 3-1 Lh 92 CRD | 61 68 | 532 19 94-86 532 40 20-08 | Spring Tension Belt Hex-Belt 92 Mower |
| 13 | 532 13 76-45 | Shaft Asm. W/Lower Bearing | 69 | 532 40 20-06 | Shaft Asm W/Lwr Brg RH Thd CRD |
| 14 15 | 532 12 87-74 532 11 04-85 | Housing Mandrel Vented (Machd) Bearing Ball Mandrel | 84 | 532 15 60-85 | Keeper Belt Idler |
| 16 | 532 18 63-86 | Blade 3-1 Rh 92 CRD | 116 | 532 19 34-06 | Bolt Shoulder |
| 17 | 872 14 06-10 | Bolt Carriage 3/8-16 x 1-1/4 | 117 | 532 17 48-73 | Wheel Gage |
| 18 | 872 11 06-06 | Bolt Rdhd Sqnk 3/8-16 x 3/4 | 118 | 873 93 06-00 | Nut Centerlock 3/8-16 unc |
| 19 | 532 13 28-27 | Bolt Shoulder 5/16-18 Thd Form | 119 | 819 13 20-12 | Washer 13/32 x 1-1/4 x 12 |
| 20 | 532 18 17-13 | Bolt 3/8-24 x 1.25 Gr. 8 Ptch Lhthd | 124 | 872 11 06-12 | Bolt Carr Sh 3/8-16 x 1-1/2 Gr. 5 |
| 21 | 873 68 05-00 | Nut Crown Lock 5/16-18 | 130 | 872 11 05-06 | Bolt Rdhdsqnk 5/16-18 unc x 3/4 |
| 22 | 532 19 95-90 | Bracket Idler Sprt 92 CRD | 131 | 532 16 56-61 532 18 18-57 | Chute Bagger CRD 92cm Mandrel Asm Service |
| 23 24 | 532 16 54-46 532 16 52-42 | Bracket Idler Sprt RF 92 CRD Bracket Suspension LF 92 CRD | | 532 18 18-58 | Mandrel Asm CRD LH Threads SVC |
| 25 | 532 16 52-42 | Bracket Suspension RF 92 CRD | | 532 40 36-41 | Replacement Mower, Complete |
| 26 | 532 40 01-10 | Brace Susp Frt CRD | | | (Std. Deck - Order separately |
| 27 | 532 16 55-68 | Bracket Asm. Susp RR 92 CRD | | | guage wheel components key nos. |
| 28 | 532 16 55-67 | Bracket Asm. Susp LR 92 CRD | | | 116 - 119) |
| 30 | 532 17 39-84 | Screw Thd Rolling | | | |
| 31 | 532 18 76-90 | Washer Spacer Mower Vented | | | |
| 32 | 532 17 57-07 | Mandrel Pulleys | NOT | | nt dimensions given in U.S. inches |
| 33 | 532 40 02-34 | Nut Flg Top Lock | | 1 inch = 25.4 | mm |

TRACTOR- -MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17 MOWER LIFT



| KEY | PART | | KEY | PART | |
|-----|--------------|---------------------------------|-----|-----------------|------------------------------------|
| NO. | NO. | DESCRIPTION | NO. | NO. | DESCRIPTION |
| 1 | 532 19 84-17 | Wire Asm Inner Spring W/Plunger | 25 | 532 16 40-24 | Spring 2-1/8 |
| 2 | 532 19 80-70 | Shaft Asm. Lift | 26 | 532 16 94-84 | Retainer Clip |
| 3 | 532 18 88-22 | Pin Groove | 27 | 532 16 45-43 | Rod Adj Lift Zinc |
| 4 | 812 00 00-02 | E Ring #5133-62 | 28 | 873 35 06-00 | Nut Hex Jam 3/8-16 unc |
| 5 | 819 21 16-21 | Washer 21/32 x 1 x 21 Ga. | 29 | 532 13 80-57 | Knob Inf 3/8-16 unc |
| 6 | 532 12 01-83 | Bearing Nylon | 30 | 532 15 02-33 | Trunnion Infin Height |
| 7 | 532 12 56-31 | Grip Handle | 31 | 532 16 98-65 | Bearing, Pvt. Lift. |
| 8 | 532 12 45-26 | Button Plunger Black | 32 | 873 54 06-00 | Nut Crownlock 3/8-24 |
| 11 | 532 16 58-29 | Link Lift L.H. | 36 | 532 15 50-97 | Pointer Height Indicator |
| 12 | 532 16 58-31 | Link Lift R.H. | 37 | 532 12 39-35 | Plug Hole Blk |
| 13 | 532 12 46-70 | Retainer Spring | 38 | 817 06 05-16 | Screw 5/16-18 x 1 |
| 15 | 532 17 32-88 | Link Front | 40 | 819 11 24-10 | Washer 11/32 x 1-1/2 x 10 Ga. |
| 16 | 873 35 08-00 | Nut Jam Hex 1/2-13 unc | 41 | 532 12 39-34 | Scale Ind Height Blk |
| 17 | 532 17 56-89 | Trunnion | 49 | 532 14 52-12 | Nut Hex flange lock |
| 18 | 873 80 08-00 | Nut Lock W/Wsh 1/2-13 unc | 50 | 532 11 04-52 | Nut Push Phos &Oil |
| 19 | 532 13 98-68 | Arm Suspension Mower | | | |
| 20 | 532 19 42-09 | Pin Cotter 7/16 Bow Tie Lock | | | |
| 23 | 532 11 08-07 | Nut Special | NOT | E: All componer | nt dimensions given in U.S. inches |
| 24 | 819 13 10-16 | Washer 13/32 x 5/8 x 16 Ga. 4 | | n = 25.4 mm | • |

TRACTOR- -MODEL NO. CTH2036TWIN (96061021700), PRODUCT NO. 960 61 02-17 BAGGER




| KEY | PART | | KEY | PART | |
|------------|--------------|--------------------------------------|--------|--------------|------------------------------------|
| NO. | NO. | DESCRIPTION | NO. | NO. | DESCRIPTION |
| 1 | 532 16 52-49 | Tube Handle Bagger CRD | 32 | 532 12 68-75 | Rivet Rd Hd Drilled 3/8 Dia |
| 3 | 532 12 39-76 | Nut Lock 1/4 Lge Flg Gr. 5 Zinc | 33 | 532 16 55-71 | Plug Mulcher 92 CRD |
| 4 | 532 16 99-16 | Handle Bagger w/Lvrs Blk CRD | 34 | 532 16 55-70 | Handle Mulcher 92/107 CRD |
| 5 | 874 98 10-24 | Screw Pan Head #10-24 x 1.50 Blk | 35 | 532 16 55-72 | Pin Mulcher 92/107 CRD |
| 6 | 874 98 10-32 | Screw Pan Hd | 36 | 819 13 20-12 | Washer 13/32 x 1-1/4 x 12 Ga. |
| 7 | 873 40 10-00 | Nut Wiz Lock Hex Serr/Hd 10-24 | 37 | 532 17 54-01 | Plug Support Bagger CRD |
| 8 | 532 18 10-95 | Cover Bagger CRD MS422 | 38 | 872 01 05-20 | Bolt 5/16-18 x 2-1/2 |
| 9 | 872 14 04-18 | Bolt Carriage 1/4-20 x 2.25d x Gr. 5 | 39 | 532 18 09-85 | Seal 37" |
| 10 | 532 18 12-82 | Tube Support Bagger CRD | 41 | 532 16 96-83 | Bracket Vert Adj Bagger CRD |
| 11 | 532 16 57-19 | Bracket Support Upper Bag CRD | 43 | 532 17 40-83 | Plug Tubing |
| 12 | 532 18 88-48 | Bracket Pivotn Lh | 44 | 532 19 33-12 | Pin Clevis |
| 14 | 874 52 06-36 | Bolt Carr. | 46 | 872 11 05-10 | Bolt Carr. 5/16-18 x 1-1/4 Gr.5 |
| 16 | 873 90 06-00 | Nut Lock Flg. 3/8-16 UNC | 47 | 532 19 37-04 | Tube Upper Bagger |
| 15 | 532 12 46-70 | Retainer Spring | 49 | 532 19 33-05 | Bar Spreader |
| 17 | 872 14 05-06 | Bolt Rdhd 5/16 -18 unc x 3/4 | 50 | 873 80 05-00 | Nut Lock Thx w/Ins. 5/16-18 unc |
| 19 | 873 90 05-00 | Nut Lock Hexflange 5/16-18 | 51 | 532 19 99-03 | Latch Spring Bagger |
| 20 | 532 18 88-47 | Bracket Pivot Rh | 53 | 873 51 04-00 | Nut Keps Hex 1/4-20 unc |
| 21 | 532 40 61-80 | Bag Asm CRD | 54 | 872 14 04-06 | Bolt Carr. |
| 22 | 532 16 57-81 | Bracket Side Bagger CRD | | | |
| 24 | 532 16 57-83 | Tube Pivot Bagger CRD | | | |
| 25 | 532 19 37-05 | Tube Front Bagger CRD | | | |
| 28 | 532 16 57-87 | Grip Handle Black | | | nt dimensions given in U.S. inches |
| 31 | 532 16 94-84 | Retainer Clip | 1 inch | n = 25.4 mm | |

SERVICE NOTES

SERVICE NOTES

SERVICE NOTES

SUGGESTED GUIDE FOR SIGHTING SLOPES FOR SAFE OPERATION



4. Compare the angle of the fold with the slope of the hill.

51

