


12 H.P. 38" Lawn Tractors

---

# Operating Manual

---

Model Nos. TMO-33905A  
TMO-33927A



(Model TMO-33905A Shown)

---

**Montgomery Ward**

---

# INDEX

Slope Gauge .....	3
Contents of Hardware Pack .....	4
Rules for Safe Operation .....	5
Assembly Instructions .....	6
Controls .....	10
Operation .....	11
Adjustments .....	13
Lubrication .....	16
Maintenance .....	16
Off-Season Storage .....	20
Trouble Shooting Chart .....	21, 22
Electrical System .....	22
Illustrated Parts for Lawn Tractor .....	23-33
Illustrated Parts for Transaxle .....	34, 35
Parts Information .....	Back Cover

Dear Customer,

So often throughout the year we are all in a rush to meet our daily obligations.

However, we at Montgomery Ward are taking a quick moment out to say . . .

**"Thank you for your business."**

Sincerely,  
MONTGOMERY WARD



**INSTRUCTIONS GIVEN WITH THIS SYMBOL ARE FOR PERSONAL SAFETY. BE SURE TO FOLLOW THEM.**

**NOTICE:** A data plate with the model number and serial numbers of your unit is located on the frame, under the seat. Record these numbers in the spaces provided on the back cover of this guide.

## BEFORE YOU CALL SERVICE

### Check Spark Plug Wire

- Firmly attached?
- Wire terminal clean?

### Check Crankcase Oil Level

- Overfilled/underfilled?

### Check Fuel Tank

- Fuel in tank?
- Fuel dirty or stale?
- If tank has been empty for a long period, fill tank completely.

### Check Air Cleaner

- Clean?
- Choke plate stuck?
- Governor spring free to move?

### Check Under Blade Housing (Disconnect Spark Plug First)

- Blade obstructed or bent?

### Check Starting Instructions

- Read instruction manuals and labels for specific instructions.

**WARNING:** This unit is equipped with an internal combustion engine and should not be used on or near any unimproved forest-covered, brush-covered or grass-covered land unless the engine's exhaust system is equipped with a spark arrester meeting applicable local or state laws (if any). If a spark arrester is used, it should be maintained in effective working order by the operator.

In the State of California the above is required by law (Section 4442 of the California Public Resources Code). Other states may have similar laws. Federal laws apply on federal lands. A spark arrester for the muffler is available through your nearest engine authorized service dealer.




# CONTENTS OF HARDWARE PACK


Remove this sheet from your owner's manual and lay the hardware on the illustration for identification purposes. After assembly, keep the Slope Gauge which is on the reverse side of this sheet for future use.

(Hardware pack may contain extra items which are not used on your unit.)


## A INSTALLING THE BATTERY



## B ATTACHING THE STEERING WHEEL




## C ATTACHING THE SEAT



## D IGNITION KEYS



(May Be  
Attached to  
Tractor)



INCHES

# IMPORTANT

## RULES FOR SAFE OPERATION

THIS SYMBOL POINTS OUT IMPORTANT SAFETY INSTRUCTIONS WHICH, IF NOT FOLLOWED, COULD EN-DANGER THE PERSONAL SAFETY AND/OR PROPERTY OF YOURSELF AND OTHERS. READ AND FOLLOW ALL INSTRUCTIONS IN THIS MANUAL BEFORE ATTEMPTING TO OPERATE YOUR UNIT. FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY RESULT IN PERSONAL INJURY. WHEN YOU SEE THIS SYMBOL—  HEED ITS WARNING. 



### DANGER

Your unit was built to be operated according to the rules for safe operation in this manual. As with any type of power equipment, carelessness or error on the part of the operator can result in serious injury. If you violate any of these rules, you may cause serious injury to yourself or others.

1. READ THIS OWNER'S MANUAL carefully in its entirety before attempting to assemble or operate this unit. Keep this manual in a safe place for future and regular reference and for ordering replacement parts.
2. This unit is a precision piece of power equipment, not a plaything. Therefore exercise extreme caution at all times.
3. Know the controls and how to stop the machine quickly.
4. Do not allow children to operate vehicle. Do not allow adults to operate it without proper instruction. Only persons well acquainted with these rules of safe operation should be allowed to use your mower.
5. Wear sturdy, rough-soled work shoes and close-fitting slacks and shirts to avoid entanglement in the moving parts. Never operate a unit in bare feet, sandals, or sneakers.
6. To prevent injury, do not carry passengers or give rides. Keep children, pets and bystanders out of the area while mowing. Only the operator should ride on the unit and only ride in the seat.
7. Check overhead clearance carefully before driving under power lines, guy wires, bridges or low hanging tree branches, before entering or leaving buildings, or in any other situation where the operator may be struck or pulled from the unit, which could result in serious injury.
8. To maintain control of the unit and reduce the possibility of upset or collision, operate the tractor smoothly. Avoid erratic operation and excessive speed.
9. Keep the area of operation clear of all persons, particularly small children and pets. Stop engine when they are in the vicinity of your mower. Although the area of operation should be completely cleared of foreign objects, a small object may have been overlooked and could be accidentally thrown by the mower in any direction and cause injury to you or a bystander.
10. Stop the blade(s) when crossing gravel drives, walks or roads.
11. Disengage all attachment clutches and shift into neutral before attempting to start engine.
12. Disengage power to attachment(s) and stop engine before leaving operating position.
13. Do not put hands or feet near or under rotating parts. Keep clear of the discharge opening at all times as the rotating blade(s) can cause injury.
14. Disengage power to attachment(s) and stop engine before making any repairs or adjustments. Disconnect the spark plug wire and keep the wire away from the plug to prevent accidental starting.
15. Before attempting to unclog the mower or discharge chute, stop the engine. The mower blade(s) may continue to rotate for a few seconds after the engine is shut off. Therefore, be sure the blade(s) have stopped completely. Disconnect the spark plug wire and keep the wire away from the plug to prevent accidental starting.
16. Disengage power to attachment(s) when transporting or not in use.
17. Take all possible precautions when leaving vehicle unattended such as disengaging power take-off, lowering attachments, shifting into neutral, setting parking brake, stopping engine and removing key.
18. For your safety, use the slope gauge included as part of this manual to measure slopes before operating this unit on a sloped or hilly area. If the slope is greater than 15° as shown on the slope gauge, do not operate this unit on that area or serious injury could result.
19. Do not stop or start suddenly when going uphill or downhill. Mow up and down face of steep slopes; never across the face. Use extreme caution if it is necessary to drive the tractor up an incline or back the tractor down an incline because the front of the tractor could lift and rapidly flip over backward which could cause serious injury.
20. Reduce speed on slopes and in sharp turns to prevent tipping or loss of control. Always keep the tractor in gear when going down steep hills to take advantage of engine braking action.
21. Stay alert for holes in terrain and other hidden hazards which may cause the unit to tip over.
22. Use care when pulling loads or using heavy equipment.
  - A. Use only approved drawbar hitch points.
  - B. Limit loads to those you can safely control.
  - C. Do not turn sharply. Use care when backing.
  - D. Use counterweight(s) or wheel weights when suggested in owner's manual.
23. Watch out for traffic when crossing or near roadways.
24. When using any attachments, never direct discharge of material toward bystanders nor allow anyone near vehicle while in operation.
25. Handle gasoline with care. It is highly flammable.
  - A. Use approved gasoline container.
  - B. Never remove cap or add gasoline to a running or hot engine or fill fuel tank indoors. Wipe up spilled gasoline.
  - C. Open doors if engine is run in garage. Exhaust fumes are dangerous. Do not run engine indoors.

# Rules for Safe Operation (continued)

26. Keep the vehicle and attachments in good operating condition, and keep safety devices in place. Use guards as instructed in operator's manual.
27. Keep all nuts, bolts, and screws tight to be sure the equipment is in safe working condition.
28. Never store the machine with fuel in the fuel tank inside a building where ignition sources are present, such as hot water and space heaters, clothes dryers, and the like. Allow the engine to cool before storing in any enclosure.
29. To reduce fire hazard, keep engine free of grass, leaves or excessive grease.
30. The vehicle and attachments should be stopped and inspected for damage after striking a foreign object. The damage should be repaired before restarting and operating the equipment.
31. Do not change the engine governor settings or overspeed the engine.
32. When using the vehicle with mower, proceed as follows:
  - (1) Mow only in daylight or in good artificial light.
  - (2) Never make a cutting height adjustment while engine is running if operator must dismount to do so.
  - (3) Shut the engine off and wait until the blade comes to a complete stop before removing the grass catcher.
  - (4) Check blade mounting bolts for proper tightness at frequent intervals.
33. Check grass catcher bags frequently for wear or deterioration. For safety protection, replace only with new bag meeting original equipment specifications.
34. Look behind to make sure the area is clear before placing the transmission in reverse and continue looking behind while backing up. Disengage blades before shifting into reverse and backing up.
35. This unit should not be driven up a ramp onto a trailer or truck under power, because the unit could tip over, causing serious personal injury. The unit must be pushed manually to load properly.

**➡ IMPORTANT:** This unit is shipped **WITHOUT GASOLINE or OIL**; however, a small amount of oil may be present from the factory. Do not overfill. After assembly, service engine with gasoline and oil as instructed in the separate engine manual packed with your unit.

**➡ NOTE:** Reference to right or left hand side of the unit is observed from the driver's seat, facing forward.

## ASSEMBLY

This owner's manual covers two models of lawn tractors. The units illustrated may vary slightly from your unit. Follow the instructions which pertain to your unit.

### UNPACKING

1. Remove the lawn tractor from the carton as follows. Open the top flaps. Remove all loose parts and carton inserts. Cut the front corners of the carton. Make certain brake is released, and push the unit out of the carton.
2. Remove page four from this manual and lay the contents of the hardware pack on the illustration for identification.

### BATTERY INFORMATION



**WARNING**

- A. Battery acid must be handled with great care as contact with it can burn and blister the skin. It is also advisable to wear protective clothing (goggles, rubber gloves and apron) when working with it.

- B. Should battery acid accidentally splatter into the eyes or onto the face, rinse the affected area immediately with clean cold water. If there is any further discomfort, seek prompt medical attention.
- C. If acid spills on clothing, first dilute it with clean water, then neutralize with a solution of ammonia/water or baking soda/water.
- D. Since battery acid is corrosive, do not pour it into any sink or drain. Before discarding empty electrolyte containers, rinse them with a neutralizing solution.
- E. NEVER connect or disconnect charger clips to battery while charger is turned on as it can cause sparks.
- F. Keep all lighted materials (cigarettes, matches, lighters) away from the battery as the hydrogen gas generated during charging can be combustible.
- G. As a further precaution, only charge the battery in a well-ventilated area.  
**\*Always shield eyes, protect skin and clothing when working near batteries.**




FIGURE 1.




FIGURE 2.



Battery contains sulfuric acid. Refer to warning on page 6. Antidote: EXTERNAL—Flush with water. INTERNAL—Drink large quantities of water or milk. Follow with milk of magnesia, beaten eggs or vegetable oil. Call physician immediately. EYES: Flush with cool water for at least 15 minutes, then get prompt medical attention.

Since batteries produce explosive gases, keep all lighted materials (cigarettes, lighters, matches, etc.) away. Be sure to charge battery only in well-ventilated areas. Make certain venting path of battery (drain tube) is always open.

KEEP BATTERIES  
OUT OF THE REACH OF CHILDREN!

## ACTIVATING THE BATTERY

Do not activate battery (fill with battery acid) until battery is actually placed in service. Be certain to read previous warnings before activating the battery.

1. Open the battery pack. Be careful not to puncture the box. It contains the battery with a long plastic tube attached, battery fluid (acid) in a plastic container, one short plastic tube and one hardware pack (two hex bolts and nuts).
2. Place the battery on a table or workbench. Make certain the long plastic drain tube is in place on the vent elbow.
3. Remove the six fill caps from the top of the battery with a screwdriver. Be careful not to damage the fill caps. See figure 1.
4. Place the battery fluid container on the table or workbench. Carefully cut off tip of the spout and attach the short plastic tube provided. Do not squeeze the container when cutting tip.
5. Fill each battery cell slowly and carefully to the UPPER LEVEL line marked on battery. See figure 2. Use caution as the acid level will rise rapidly after the bottom of the cell is filled.
6. Allow battery to stand for 30 minutes with the fill caps removed, while the plates absorb acid.
7. If acid level has fallen after the 30 minute standing period, refill each cell with battery acid to the UPPER LEVEL line on battery. Replace the fill caps.
8. Before discarding the empty container, neutralize any residue with baking soda and rinse container with water. Puncture container several times before discarding.
9. Charge the battery after the 30 minute standing period. SLOW CHARGE THE BATTERY (DO NOT FAST CHARGE) at a maximum bench rate of 1.4 amperes until the specific gravity reading is 1.260-1.280. Charge for a minimum of 2 hours and a maximum of 8 hours.

### NOTE

Charging rate after battery has been put into operation: The battery is to be charged for a period of 14-16 hours. NO LONGER THAN 30 HOURS. After battery has been charged, add only distilled water. Do not add acid.

### NOTE

This engine is equipped with an alternator. The current for the battery charger alternator is unregulated. During normal operation, it is only necessary to charge the battery:

1. When it is activated for the first time.
2. Before winter storage.
3. Before using the lawn tractor after winter storage.




FIGURE 3.




FIGURE 4.




FIGURE 5.

### INSTALLING THE BATTERY (Hardware A)

1. Install the battery box as follows.
  - a. Raise the seat bracket (on top of the fenders).
  - b. Push any electrical wires out of the way so they are not disconnected when installing the battery box.
  - c. Place the plastic battery box into the opening beneath the seat bracket. The hinge on the battery box goes toward the rear of the unit.
  - d. Snap the battery box in place so the retaining edges on the box are beneath the fender. Make certain the battery cables are routed up along each side of the box. See figure 3.

2. Place the battery inside the battery box so that the positive terminal is toward the right side of the unit. See figure 3. Route the battery drain tube down beside the battery box.

3. Slide the hex nut (provided with battery hardware) into the positive (+) terminal. Place the positive (heavy red wire) cable on the positive terminal. Secure with bolt provided. See figure 3.

4. Slide the hex nut (provided with battery hardware) into the negative (-) terminal. Place the negative (heavy black wire) cable on the negative terminal. Secure with bolt provided.

5. Secure the battery drain tube to the transaxle support bracket, using the cable tie as shown in figure

4. Be certain drain tube is routed away from the wheel rim. Trim excess end of cable tie.


6. Close the top of the battery box and lower the seat.

### ATTACHING THE STEERING WHEEL (Hardware B)

1. Open the hood of the lawn tractor by lifting up on both sides of the hood.

2. Insert large end of the upper steering shaft through the hole in the dash panel, over the lower steering shaft. See figure 5. The four holes in the upper steering shaft provide four steering wheel heights. Select desired hole, and secure with hex bolt and hex lock nut.





3. Attach one end of steering bellow to the steering wheel as shown in figure 6, inset.


4. Position the front wheels of the tractor so they are pointing straight forward.

5. Place the steering wheel and steering bellow over the steering shaft, positioning steering wheel as desired.

6. Place the washer with the cupped side down over the steering shaft. Secure with 5/16" hex lock nut. See figure 6.

7. Place the steering wheel cap over the center of the steering wheel and seat it with your hand.


FIGURE 6.



#### ATTACHING THE SEAT (Hardware C)

Place the seat in position against the seat pivot bracket, lining up the slotted holes in the pivot bracket with the holes in the seat. Select desired position for the seat, and secure with hex self-tapping screws. See figure 7.

FIGURE 7.



#### ATTACHING THE CHUTE DEFLECTOR

The chute deflector on your unit may be either plastic or steel. Assemble the chute, using the holes shown in figure 8.



**WARNING**

Do not operate your unit unless the chute deflector has been properly installed.

1. Remove the truss machine screws, cupped washers and hex jam nuts which are attached to the deck next to the chute opening.

2. Place the chute deflector in position as shown in figure 8. Secure with hardware just removed.

FIGURE 8.

# CONTROLS




FIGURE 9.

## THROTTLE CONTROL

The throttle control is used to regulate the engine speed. To get maximum efficiency from cutting, the throttle should be in the FAST position when operating the mower. See figure 9.

## CHOKE CONTROL

The choke control is located on the dashboard and is operated manually. Details for the choke operation are covered in the separate engine manual packed with your unit. See figure 9.

## SHIFT LEVER

The shift lever is located in the center of the console and has three positions, FORWARD, NEUTRAL and REVERSE. See figure 9. The clutch-brake pedal must be depressed and the lawn tractor must not be moving when shifting gears. Do not force the shift lever. Release the clutch-brake pedal slightly to line up the shifting collar in the transmission. Then try to shift gears.

## SPEED CONTROL LEVER

The speed control lever allows you to regulate the ground speed of the lawn tractor. See figure 10. To select the ground speed, depress clutch pedal. Push speed control lever outward and move backward to slow lawn tractor, move forward to increase speed. When desired speed has been obtained, release lever in that position. Whenever clutch is engaged, unit will automatically go to the pre-set speed.

## IGNITION SWITCH

Turn the key to the START position to start the engine. When the engine is running, let the key return to the ON position. To stop the engine, turn the key to the left to the OFF position and remove it to prevent accidental starting. See figure 9.

## LIGHT SWITCH

Push the light switch to turn on the lights. The lights will only operate when the engine is running. See figure 9.

## AMMETER

The ammeter registers the rate of battery charge or discharge. The ammeter will register on the discharging side when starting the engine. It should register on the opposite side (charging) when the engine is running in the fast position until the battery is completely charged. With a fully charged battery or with the engine idling, the ammeter will not show a charge. See figure 9.

## CLUTCH-BRAKE PEDAL

The clutch-brake pedal is located on the left side of the lawn tractor. Depressing the clutch-brake pedal part way disengages the clutch. Pressing the pedal all the way down disengages the clutch and engages the disc brake. See figure 9.



The clutch-brake pedal must be depressed to start the engine.

## PARKING BRAKE

The speed control lever is used to set the parking brake. To set the parking brake, depress the clutch-brake pedal. Press the speed control lever outward and all the way to the rear of the unit. Release the speed control lever and the clutch-brake pedal.

To release the parking brake, depress the clutch-brake pedal, press the speed control lever outward and move to desired position. Release the speed control lever and the clutch-brake pedal.

## INCLINE ASSISTANCE BRAKE

When stopping on a hill, hold the incline assistance brake lever back while you release the clutch-brake pedal until the lawn tractor begins to move, then release the lever. This lever permits smoother starts and clutch engagement by holding the tractor during the brake release/clutch engagement operation. See figure 10.




FIGURE 10.

## INTERLOCKS (Not Shown)

Interlock safety switches are located on the clutch-brake pedal, the lift and disengagement lever, the gear shift lever and under the seat.

Before the engine will start, the clutch-brake pedal must be depressed all the way and the lift and disengagement lever must be in the disengaged position.

Before the unit can be shifted into reverse or if the operator leaves the seat, the lift and disengagement lever must be in the disengaged position.

## CUTTING CONTROLS

### A. LIFT AND DISENGAGEMENT LEVER

The lift and disengagement lever is used to raise and lower the cutting deck. Pulling it all the way back and locking it disengages the blades. The lift and disengagement lever **must** be in the disengaged position when starting the engine, when shifting into reverse or if the operator leaves the seat. See figure 10.

### B. DECK LIFT INDICATOR

The deck lift indicator marks the position being used for the lift lever. Select the lift lever position desired, press the indicator lever outward, move it to the position immediately below the lift lever and release the indicator lever. See figure 10.

### C. DECK WHEEL HEIGHT ADJUSTMENT

Move the deck wheel to the desired hole location in the deck.

### D. SETTING THE CUTTING HEIGHT

1. Select the position for the lift lever which gives the desired cutting height. Move the deck lift indicator so that the lift lever can be returned to the same position after it is raised.
2. Set the deck wheels so that the wheels are  $\frac{1}{4}$  to  $\frac{1}{2}$  inch above the ground.

# OPERATION

## CAUTION

- READ OPERATOR'S MANUAL(S) • NEVER CARRY CHILDREN
- KNOW LOCATION AND FUNCTION OF ALL CONTROLS
- KEEP SAFETY DEVICES (GUARDS SHIELDS AND SWITCHES) IN PLACE AND WORKING
- REMOVE OBJECTS THAT COULD BE THROWN BY BLADE(S)
- DO NOT OPERATE THE UNIT WHEN CHILDREN AND OTHERS ARE AROUND
- ALWAYS LOOK BEHIND THE UNIT BEFORE BACKING UP
- DO NOT OPERATE THE UNIT WHERE IT COULD SLIP OR TIP
- IF THE UNIT STOPS GOING UPHILL, STOP BLADE(S) AND BACK SLOWLY DOWNHILL
- BE SURE BLADE(S) AND ENGINE ARE STOPPED BEFORE PLACING HANDS OR FEET NEAR BLADE(S)
- BEFORE LEAVING OPERATOR'S POSITION, SHUT ENGINE OFF AND REMOVE KEY

## TIRE PRESSURE

The tires on your unit may be over-inflated for shipping purposes. Reduce the tire pressure before operating the unit. Recommended operating tire pressure is approximately 12 p.s.i. (check sidewall of tire for tire manufacturer's recommended pressure).



Maximum tire pressure under any circumstances is 30 p.s.i. Equal tire pressure should be maintained on all tires.

## STARTING THE ENGINE



To open the hood, simply lift up on both sides of the hood.

1. Service the engine with oil and gasoline as described in the engine manual.
2. Depress the clutch-brake pedal and set the parking brake.
3. Place the lift and disengagement lever in the DISENGAGED position. See figure 10.



This unit is equipped with a **safety interlock system** for your protection. The purpose of the safety interlock system is to prevent the engine from cranking or starting unless the clutch-brake pedal is depressed and the lift and disengagement lever is in the disengaged position. In addition, the lift and disengagement lever must be in the disengaged position when the unit is put into reverse or the engine will shut off. If the operator leaves the seat with the lift and disengagement lever engaged, the engine will shut off.



Do not operate the lawn tractor if the interlock system is malfunctioning because it is a safety device, designed for protection.

4. Set the throttle control in the FAST position. See figure 9.
5. Pull out choke knob to choke engine. A warm engine may not require choking.

6. Turn the ignition key to the START position. When the engine is running, let the key return to the ON position. See figure 9.
7. Push choke knob in gradually. Move the throttle control to desired engine speed.

### STOPPING THE ENGINE

Turn the ignition key to the left to the OFF position. Remove the key to prevent accidental starting.

#### ➡ IMPORTANT

If you strike a foreign object, stop the engine. Remove wire from spark plug, thoroughly inspect the unit for any damage, and repair the damage before restarting and operating the mower.

#### ➡ NOTE

If any problems are encountered, refer to the Trouble Shooting Chart on page 21.

### OPERATING THE LAWN TRACTOR

1. Set the desired cutting height.
2. Start the engine as instructed on page 11.
3. Move throttle control to  $\frac{3}{4}$  or full throttle to prevent strain on the engine and to operate the cutting blades.
4. Place the shift lever in either the FORWARD or REVERSE position.



#### CAUTION

Look to the rear before backing up.

5. Release the parking brake by depressing the clutch-brake pedal, pressing outward on the speed control lever and moving to desired position. Use first speed position when operating the lawn tractor for the first time.
6. Release clutch-brake pedal slowly to put unit into motion.
7. The lawn tractor is brought to a stop by depressing the clutch-brake pedal.

#### ➡ NOTE

When operating the unit initially, there will be little difference between the highest two speeds until after the belts have seated themselves into the pulleys during the break-in period. Be certain to change oil in the crankcase after the first 5 hours of operation.

Be sure that the lawn is clear of stones, sticks, wire, or other objects which could damage lawn tractor or engine. For best results and to insure more even grass distribution, do not mow when lawn is excessively wet.

When stopping the unit to empty a grass bag, etc., move the throttle to idle position to avoid "browning" the grass (caused by air from the engine hitting the same spot for a period of time). This "browning" is a temporary condition, which may not appear for 1 to 2 days after mowing.



#### CAUTION

If the unit is not to be used for a long period, place the shift lever in NEUTRAL, stop the engine, set the parking brake and remove the key. DO NOT leave the machine on an incline.

If unit stalls with speed control in high speed, or if unit will not operate with speed control lever in a low speed position, proceed as follows.

1. Place shift lever in NEUTRAL.
2. Restart engine.
3. Place speed control lever in high speed position.
4. Release clutch-brake pedal fully.
5. Depress clutch-brake pedal.
6. Place speed control lever in desired position.
7. Place shift lever in either FORWARD or REVERSE, and follow normal operating procedures.

### OPERATING THE CUTTING BLADES

The cutting blades may be engaged while the lawn tractor is moving or standing still. DO NOT engage the cutting blades abruptly as the sudden belt tension on the pulley may cause the engine to stall.



When the blade drive is engaged, keep feet and hands away from the discharge opening, the blades or any part of the deck. When the unit is used for other than mowing operations, the blade drive should be disengaged.

Move the lift and disengagement lever into the DISENGAGED position to raise the deck and disengage the blades.

GRASS COLLECTOR Stock Number 89-35108R is available as optional equipment for the lawn tractors shown in this manual.



## WARNING

The mower should not be operated without the entire grass catcher or chute deflector in place.



## NOTE

Under normal usage bag material is subject to wear, and should be checked periodically. Be sure any replacement bag complies with the mower manufacturer's recommendations.

For replacement bags, use only factory authorized replacement bag.

# ADJUSTMENTS

## SEAT ADJUSTMENT

The seat may be adjusted to different positions. Refer to seat installation section of assembly instructions.

## STEERING WHEEL ADJUSTMENT

There are four height positions for the steering wheel. To adjust the height of the steering wheel, remove the hex bolt and hex lock nut on the steering shaft. Place the steering wheel in the position desired and secure with hex bolt and hex lock nut. Refer to figure 5.



## NOTE

When raising the height of the steering wheel, stretch the steering bellows to cover the steering shaft.

## DECK LEVELING ADJUSTMENT

If an uneven cut is obtained, the deck may be leveled as follows.

1. Remove the transmission cover:
  - a. Place the shift lever in the neutral position. Unscrew the shift knob.
  - b. Remove the two truss head screws which secure the transmission cover.
  - c. Lift the transmission cover. Unplug the safety wire from beneath the transmission cover, and remove cover.
2. Using a 1/2" wrench, loosen the jam nut. See figure 11.
3. With unit on hard, level surface, measure the distance from the bottom edge of the center of the left side of deck to the ground. Measure the same distance on the center of the right side of the deck (just behind the chute area on side discharge

units). Or, place the blades in a straight line, and measure the distance from the outside edge of the blade tips to the ground.

4. Adjust the deck as follows: To lower the left side of the deck, tighten the adjusting screw. To raise the left side of the deck, back the adjusting screw off several turns. Remeasure the deck as described in step 3, and readjust if necessary. Tighten the jam nut to secure the adjusting screw when the deck is level.
5. Replace the transmission cover, following the instructions in step 1 in reverse order. Be certain to reconnect the safety wire.




FIGURE 11.

## SPEED CONTROL ADJUSTMENT (See figure 12)



## NOTE

When operating the unit initially or after replacing the belts, there will be little difference between the highest two speeds until after the belts have gone through a break-in period and have seated themselves into the pulleys.

First, adjust the speed control lever by pushing the clutch-brake pedal forward until the stop on the speed control rod is against the running board rod. See figure 12. Have another person hold the pedal in this position as you make the following adjustment. Place the speed control lever in parking brake position. Remove the hairpin cotter and flat washer, and adjust the ferrule on the rod so it is against the back end of the slot. See figure 12. Replace the flat washer and hairpin cotter.

Next, adjust the speed control link as follows to obtain the correct neutral adjustment.

1. Start the engine.




FIGURE 12.

2. Place the shift lever in Neutral position.
3. Place the speed control lever in high speed position.
4. Release the clutch-brake pedal completely, then slowly depress the pedal all the way (to park position). Hold the pedal in this position.
5. Turn the engine off.
6. After engine stops completely, release the clutch-brake pedal.
7. **Model TMO-33927A:** Place speed control lever in second position.  
**Model TMO-33905A:** Place speed control lever between first and second position (hold in this position).
8. Remove the cotter pin and flat washer which secures the speed control link to the variable speed torque bracket assembly.
9. Push the clutch-brake pedal backward by hand as far as it will go using light pressure. Hold it in this position as you thread the speed control link in or out of the ferrule until it lines up with the pin on the variable speed torque bracket assembly.
10. Secure speed control link to variable speed torque bracket assembly with flat washer and cotter pin.

#### NEUTRAL ADJUSTMENT

1. Place the transmission in neutral. (The unit will move freely when pushed forward and backward with the parking brake released.)
2. Loosen the bolt which secures the shift lever assembly to the shift lever link. See figure 13.
3. Place the shift lever in the neutral slot. See figure 13.
4. Tighten the bolt to 13 foot pounds.




FIGURE 13.

## WHEEL ADJUSTMENT

The caster (forward slant of the king pin) and the camber (tilt of the wheels out at the top) require no adjustment. Automotive steering principles have been used to determine the caster and camber on the tractor. The front wheels should toe-in 1/8 inch.

To adjust the toe-in, follow these steps.

1. Remove the hex nut and lock washer, and drop the tie rod end from the wheel bracket. See figure 14.
2. Loosen the hex jam nut on tie rod.
3. Adjust the tie rod assembly for correct toe-in.




FIGURE 14.

Dimension "B" should be approximately 1/8" less than Dimension "A." See figure 15.

- A.) To increase Dimension "B," screw tie rod into tie rod end.
- B.) To decrease Dimension "B," unscrew tie rod from tie rod end.
- C.) Reassemble tie rod. Check dimensions. Readjust if necessary.




FIGURE 15. TOE-IN DIAGRAM

## CARBURETOR ADJUSTMENT



**WARNING**

If any adjustments are made to the engine while the engine is running (e.g. carburetor), disengage all clutches and blades. Keep clear of all moving parts. Be careful of heated surfaces and muffler.

Minor carburetor adjustment may be required to compensate for differences in fuel, temperature, altitude and load. To adjust the carburetor, refer to the separate engine manual packed with your unit.

### NOTE

A dirty air cleaner will cause an engine to run rough. Be certain air cleaner is clean and attached to the carburetor before adjusting carburetor. Refer to the separate engine manual.

## BRAKE ADJUSTMENT (See figure 16)

The brake is located by the right rear wheel inside the frame. During normal operation of this machine, the brake is subject to wear and will require periodic examination and adjustment.



**WARNING**

Do not have the engine running when you adjust the brake.

To adjust the brake, remove the cotter pin. Adjust the castle nut so the brake starts to engage when the brake lever is 1/4" to 5/16" away from the axle housing.

### NOTE

Figure 16 is shown with the unit tipped up on rear wheels for clarity only.




FIGURE 16.

# LUBRICATION



**WARNING**

Always stop engine and disconnect spark plug wire before cleaning, lubricating or doing any kind of work on lawn tractor.

## STEERING GEARS

Lubricate teeth of steering gears with automotive multi-purpose grease after every 25 hours of operation or once a season. See figure 17.

## STEERING SHAFT

Lubricate steering shaft at least once a season with light oil.




FIGURE 17.

## TRANSAXLE

The transaxle is lubricated at the factory and does not require checking. If disassembled for any reason, lubricate with 10 oz. of Shell grease, part number 737-0148.

The rear axles may be lubricated once a season, using the access hole on each side of the transaxle housing. See figure 16. A push-type hand grease gun, equipped with a special flush coupler is required. Use Shell grease, part number 737-0148.

## WHEELS

The front wheels are provided with grease fittings. The rear wheels must be removed from the axle for lubrication. Lubricate both front and rear wheels at least once a season with automotive multi-purpose grease.

## PIVOT POINTS

Lubricate all pivot points with light oil at least once a season.

# MAINTENANCE



**WARNING**

Disconnect the spark plug wire and ground against the engine before performing any repairs or maintenance.

## TROUBLE SHOOTING

Refer to page 21 of this manual for trouble shooting information.

## CRANKCASE OIL

Check the oil level in the crankcase before each use of the machine and after every five hours of operation. Oil level should be maintained as instructed in the separate engine manual.

After the first five hours of operating a new engine, drain the oil from the crankcase while engine is still hot and refill crankcase with new oil; thereafter change the oil every 25 hours of operation. Refer to the engine manual.

## AIR CLEANER

Under normal operating conditions, the air cleaner, located on top of the carburetor, must be serviced after every ten hours of use. Under extremely dusty operating conditions, the air cleaner must be serviced after every hour of operation. To service the air cleaner, refer to the separate engine manual packed with your unit.

## CLEANING ENGINE AND BLADE HOUSING

Any fuel or oil spilled on the machine should be wiped off promptly. Grass, leaves, and other dirt must not be left to accumulate around the cooling fins of the engine or on any part of the machine.

Clean the underside of the blade housing after each mowing.

## SPARK PLUG

The spark plug should be cleaned and the gap reset once a season. Spark plug replacement is recommended at the start of each mowing season; check engine manual for correct plug type and gap specification.

## CUTTING BLADE

### A. Removal for Sharpening or Replacement



**WARNING**

Be sure to disconnect and ground the spark plug wire and remove ignition key before working on the cutting blade to prevent accidental engine starting. Protect hands by using heavy gloves or a rag to grasp the cutting blades.



1. Remove the large bolt and lock washer which holds the blade and adapter to the blade spindle.
2. Remove the blade and adapter from the spindle.
3. If the blade or blade adapter needs replacing, remove the two small bolts, lock washers and nuts which hold the blade to the adapter.

### B. Sharpening

Remove the cutting blade by following the directions of the preceding section.

When sharpening the blade, follow the original angle of grind as a guide. It is **extremely important** that each cutting edge receives an equal amount of grinding to prevent an unbalanced blade. An unbalanced blade will cause excessive vibration when rotating at high speeds, may cause damage to the mower and could break, causing personal injury.

The blade can be tested for balance by balancing it on a round shaft screwdriver. Remove metal from the heavy side until it balances evenly.

### NOTE

It is recommended that the blade always be removed from the adapter for the best test of balance.

### C. Reassembly

Before reassembling the blade and the blade adapter to the unit, lubricate the spindle and the inner surface of the blade adapter with light oil. Lubricating the bolt holes, bolts and inner surface of the nuts with light oil is also recommended. A 4 oz. plastic bottle of light oil lubricant is available. Order part number 737-0170. Engine oil may also be used.

When replacing the blade, be sure to install the blade with the side of the blade marked "Bottom" (or with part number) facing the ground when the mower is in the operating position.

#### Blade Mounting Torque

3/8" Dia. Bolt 375 in. lb. min., 450 in. lb. max.

5/16" Dia. Bolt 150 in. lb. min., 250 in. lb. max.

To insure safe operation of your unit, ALL nuts and bolts must be checked periodically for correct tightness.

### FUEL FILTER

Your unit is equipped with a replaceable in-line fuel filter. Replace filter whenever contamination or discoloration is noticed. Order replacement filter through your engine authorized service dealer.

### DRIVE BELT REMOVAL AND REPLACEMENT



Disconnect the spark plug wire and ground it against the engine. Block the wheels of the unit.

### NOTE

Figures 18, 22, 23 and 24 are shown with the unit tipped up for clarity. It is not necessary to tip the unit to remove the belts.

However, if tipping the unit is desired, remove the battery from the unit. To prevent gasoline leakage, drain the gasoline, or remove the fuel tank cap, place a thin piece of plastic over the neck of the fuel tank and screw on the cap. Be certain to remove the plastic when finished changing the belts. Block unit securely.

### Deck Belt

1. Place the lift lever in the disengaged position.
2. Remove the three hex bolts (belt keepers) from the engine pulley belt guard. See figure 18.




FIGURE 18.

### NOTE

Make certain hex bolts are reassembled as shown in figure 18.

3. Unhook the deck belt from the engine pulley.
4. Place the lift lever in the engaged (all the way forward) position.
5. Disconnect the six deck links by removing the hair-pin cotters and flat washers.
6. Place the lift lever in the disengaged position.
7. Slide the deck from beneath the lawn tractor.
8. Remove the belt guards at each deck pulley by removing the hex bolts, lock washers and hex nuts. See figure 19.
9. Remove and replace the belt, following the instructions in reverse order.




FIGURE 19.

### Rear Drive Belt

1. Place shift lever in neutral position. Unscrew the shift knob. Remove the two truss head screws which secure the transmission cover. See figure 20A.
2. Lift the transmission cover. Unplug the safety wire from beneath the transmission cover. See figure 20B. Remove transmission cover.




FIGURE 20.

3. Push the idler pulley toward the right side of the unit. Lift the belt over the idler pulley. See figure 21.
4. Remove the belt from the variable speed pulley.
5. Remove the two bolts which hold the shift lever bracket to the frame on the left side of the unit. Swing the bracket toward the right so the belt can be removed from the transmission pulley. See figure 21.
6. Replace belt, and reassemble in reverse order.




FIGURE 21.

### Front Drive Belt

1. To remove the front drive belt, first remove the rear drive belt from the idler pulley and variable speed pulley.
2. Place the lift lever in the disengaged position.
3. Remove the three hex bolts (belt keepers) from the engine pulley belt guard. Refer to figure 18.

### NOTE

Make certain hex bolts are reassembled as shown in figure 18.

4. Unhook the deck belt from the engine pulley.
5. Remove the two bolts, lock washers and nuts on each side of the frame which hold the engine pulley belt guard to the frame. See figure 22.




FIGURE 22.

6. Remove the engine pulley belt guard by slipping it back and to the right. See figure 23.




FIGURE 23.

7. Place the clutch-brake pedal in park position.
8. Push forward on the variable speed pulley, and lift the belt off the engine and remove the belt from the engine pulley.
9. Release the clutch-brake pedal. Using the pedal to move the variable speed pulley as necessary, lift the belt up and off the variable speed pulley.

**NOTE**

When reassembling, make certain belt is inside the pins. See figure 24.




FIGURE 24.

10. Reassemble with a new belt, following instructions in reverse order.

**BATTERY REMOVAL OR INSTALLATION**



**WARNING**

When removing the battery, follow this order of disassembly to prevent the screwdriver from shorting against the frame.

1. Remove the Negative cable.
2. Remove the Positive cable.

To install a battery:

1. Attach the Positive cable.
2. Attach the Negative cable.

**JUMP STARTING**

1. Attach the first jumper cable from the Positive terminal of the good battery to the Positive terminal of the dead battery.
2. Attach the second jumper cable from the Negative terminal of the good battery to the FRAME OF THE UNIT WITH THE DEAD BATTERY.



**WARNING**

Failure to use this starting procedure could cause sparking, and the gas in either battery could explode.

**BATTERY MAINTENANCE**

1. Check periodically (every two weeks or before and after charging) to be sure electrolyte level is above the lowest line on battery. Add only distilled water or a good quality drinking water. NEVER add additional acid or other chemicals to battery after initial activation.
2. The battery should be checked with a hydrometer after every 25 hours of operation. If the specific gravity is less than 1.225, remove battery and recharge.
3. Coat the terminals and exposed wiring with a thin coat of grease or petroleum jelly for longer service and protection against electrolyte corrosion.
4. The battery should be kept clean. Any deposits of acid should be neutralized with soda and water. Be careful not to get this solution in the cells.

**BATTERY STORAGE**

1. Charge battery using normal methods. NEVER store discharged battery as it will not recover.
2. When storing battery for extended periods, disconnect battery cables. Removing battery from unit is recommended.

3. Store in cold, dry place.
4. Recharge battery whenever the specific gravity is less than 1.225, before returning to service, or every two months, whichever occurs first.

#### COMMON CAUSES FOR BATTERY FAILURE ARE:

1. Overcharging
2. Undercharging
3. Lack of water
4. Loose holds downs and/or corroded connections
5. Excessive loads
6. Battery electrolyte substitutes
7. Freezing of electrolyte



#### NOTE

THESE FAILURES DO NOT CONSTITUTE WARRANTY.

#### TIRES

Recommended operating tire pressure is approximately 12 p.s.i. (check sidewall of tire for tire manufacturer's recommended pressure). Maximum tire pressure under any circumstances is 30 p.s.i. Equal tire pressure should be maintained on all tires.

When installing a tire to the rim, be certain rim is clean and free of rust. Lubricate both the tire and rim generously. Never inflate to over 30 p.s.i. to seat beads.



#### WARNING

Excessive pressure (over 30 p.s.i.) when seating beads may cause tire/rim assembly to burst with force sufficient to cause serious injury.

## OFF-SEASON STORAGE

If the machine is to be inoperative for a period longer than 30 days, prepare for storage as follows.

1. Clean the engine and the entire unit thoroughly.
2. Lubricate all lubrication points. Wipe the entire machine with an oiled rag to protect the surfaces.
3. Refer to the engine manual for correct engine storage instructions. The engine must be completely drained of fuel to prevent gum deposits from forming on essential carburetor parts, fuel lines and fuel tanks.
4. Refer to battery storage instructions on page 19.
5. Store unit in a clean, dry area.



#### NOTE

When storing any type of power equipment in an unventilated or metal storage shed, care should be taken to rustproof the equipment. Using a light oil or silicone, coat the equipment, especially any chains, springs, bearings and cables.


# TROUBLE SHOOTING CHART FOR ELECTRIC START MODELS

TROUBLE	LOOK FOR	REMEDY
Engine will not crank	Battery installed incorrectly	The battery must be installed with the negative terminal, identified at the terminal post by (Neg. N or -), grounded. The positive terminal (Pos, P or +) attaches to the large cable from the solenoid. The small red wire from the fuse holder or circuit breaker is also attached to the positive terminal.
	Blown fuse or circuit breaker	Replace fuse with 7½ amp. fuse ¼ x 1¼" lg. Circuit breaker will reset itself when it cools off. Fuses or circuit breakers seldom open or fail without a reason. The problem must be corrected. Check for loose connections in the fuse holder. Replace fuse holder if necessary. A dead short may be in the cranking or charging circuit where the insulation may have rubbed through and exposed the bare wire. Replace the wire or repair with electrician's tape if the wire strands have not been damaged. Note: Look for a wire pinched between body panels, burned by the exhaust pipe or muffler or rubbed against a moving part.
	Battery is dead or weak	<p>Use a hydrometer to check the condition of the battery. The Specific Gravity (s.g.) should be 1.265 at 80°F. (1.215 s.g. minimum needed for cranking engine). The reason for the battery failing must be determined. (1) Defective battery. Battery will not accept or hold a full charge. (2) Short circuit. Check for grounded wire. (3) Charging system not working.</p> <p>The charging system is an alternator located under the flywheel. It is unregulated and rated 3 amp. at 3600 r.p.m. A diode (rectifier) is located in the output lead just before the wire harness plug on the engine side.</p> <div style="text-align: center;"> </div> <p>The diode changes A.C. to D.C. to charge the battery. A bad diode can either fail to charge the battery or discharge the battery if the alternator is shorted as well as the diode. To test: (1) Disconnect charger lead from the battery (small red wire). (2) Connect 12 V small test lamp between the 3 amp. D.C. charge lead and the positive terminal of the battery. (3) With the engine off, the lamp should not light. If it does, the diode and possibly the alternator should be replaced. (4) Start the engine. The lamp should light. If it does not, the alternator (stator) or lead wire is bad and should be replaced.</p>
Mechanical failure (Wires and switches)	The interlock system includes two mechanical activated switches which are wired in series in the circuit used to energize the starter solenoid. While testing the interlock system, you will make the mower temporarily unsafe by permitting the engine to be started with the blade and clutch engaged. <b>WARNING:</b> While testing, disengage the clutch, shut off the blade control, set the parking brake and place the gear shift lever in neutral. Attach a wire (minimum 18 gauge) to the positive terminal of the battery and touch the other end to the small terminal on the solenoid. <b>If the engine does not crank:</b> (1) There is a loose connection or poor ground (2) The solenoid may be bad. The solenoid can be checked by using a heavy wire (#8 gauge minimum) and jumping between the two large terminals. If the engine cranks, the solenoid is bad. (3) If the engine does not crank when you jump the solenoid, have the starter motor tested by an authorized engine dealer. If the engine does crank, the problem is with one of the safety switches, ignition switch or the wire between the fuse holder (or circuit breaker) and the small terminal on the solenoid. Note Look for a poor connection at the switches or a defective switch. Replace if necessary.	
Engine cranks but will not start	Throttle or choke not in starting position	Check owner's guide for correct position for throttle control and choke for starting.
	No spark to spark plug	<p>Spark plug lead disconnected. Connect lead. Hold spark plug lead away from engine block about 1/8" Crank engine. There should be a spark. If not, have engine repaired at authorized engine service dealer.</p> <p>Faulty spark plug. To test, remove spark plug. Attach spark plug lead to spark plug. Ground the spark plug body against the engine block. Crank the engine. The spark plug should fire at the electrode. Replace if it does not.</p>

# TROUBLE SHOOTING CHART FOR ELECTRIC START MODELS

TROUBLE	LOOK FOR	REMEDY
	No fuel to the carburetor	Gasoline tank empty. Fill. Fuel line or in-line fuel filter plugged. Remove and clean fuel line. Replace filter if necessary.
	Air filter dirty	If the air cleaner is dirty, the engine may not start. Clean or replace as recommended by the engine manufacturer.
Engine smokes	Engine loses crankcase vacuum	Dipstick not seated or broken. Replace defective part. Engine breather defective. Replace.
Excessive vibration	Bent or damaged blade spindle	<b>Stop engine immediately.</b> Check all pulleys, blade adapters, keys and bolts for tightness and damage. Tighten or replace any damaged parts.
	Bent blade	<b>Stop engine immediately.</b> Replace damaged blade. Only use original equipment blades.
Mower will not discharge grass or leaves uncut strips	Engine speed low Transmission selection Blades short or dull	Throttle must be set between 3/4 and full throttle. Use lower transmission speed. The slower your ground speed, the better the quality of cut. Sharpen or replace blades (uncut strip problem only).


## TMO-33905A TMO-33927A



### PARTS LIST FOR ELECTRICAL SYSTEM

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	725-0459	Circuit Breaker	14	725-0976A	Ground Wire 7.25" Lg.
2	725-0759	Spring-Switch—Reverse	15	725-0634	Light Switch
3	725-0977	Ground Wire 11.5" Lg.	16	725-0803B	Safety Switch
4	725-0201	Ignition Key	17	725-0514A	Battery
5	725-0267	Ignition Switch	18	725-1351	Electric Wire 8.0" Lg.
6	725-0925	Ammeter	19	725-0771	Solenoid
8	725-0577	Safety Switch	20	725-1308A	Wire Harness
12	725-0963	Lamp	21	725-1303	Spring Switch
13	725-1058	Socket			

# TMO-33905A TMO-33927A



## 12 H.P. 38" LAWN TRACTORS PARTS LIST FOR MODELS TMO-33905A AND TMO-33927A


REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	16521	Chute Bracket (Steel)††	20	736-0217	L-Wash. 3/8" I.D.—H.D.
2	16566	Chute Deflector (Steel)††	22	738-0373	Shld. Bolt .498" Dia. x 1.53"
3	16575A 801-6576	38" Deep Deck Ass'y. 38" Deep Deck Ass'y. Comp. (For Service Only)	23	742-0473A	High-Lift Blade
4	16607	Belt Guard Deck—L.H.	25	748-0300	Blade Adapter
5	16608A	Belt Guard Deck—R.H.	26	754-0329	5L V-Belt
6	710-0152	Hex Bolt 3/8-24 x 1.00"	27	736-0270	Bell-Wash. 1/4" I.D.
7	710-0195	Hex Bolt 1/4-28 x .62"	28	09322	Brake Disc
8	710-0255	Truss Mach. Scr. 1/4-20 x .75"	33	710-1013	Rib Neck Bolt 5/16-24 x 1.05" Lg.
9	710-0888	Hex Bolt Special 5/16-24 x 1.0"	34	742-0473A	High-Lift Blade
10	711-0792	Hinge Pin	35	712-0318	Hex Jam Nut 5/8-18 Thd.
11	712-0123	Hex Nut 5/16-24 Thd.*	37	736-0158	L-Wash. 5/8" I.D.*
12	712-0138	Hex Nut 1/4-28 Thd.	38	736-0119	L-Wash. 5/16" I.D.*
13	712-0181	Hex Top L-Nut 3/8-16 Thd.	39	717-0906	Blade Spindle Ass'y. Comp. (Incl. Ref. 33)
14	712-0298	Hex Jam Nut 1/4-20 Thd.	42	756-0486	5" Dia. Pulley
16	732-0542	Torsion Spring††	52	703-1693	Hinge Mtg. Brkt.†
17	734-0973	Deck Wheel—5"	53	732-0602	Torsion Spring†
18	736-0105	Bell-Wash. .40" I.D. x .88" O.D.	54	726-0106	Push Nut†
19	736-0119	L-Wash. 5/16" I.D.*	55	731-1032	Chute Ass'y. Comp. (Plastic)†

†Used with Plastic Chute Deflector  
††Used with Steel Chute Deflector

\*For faster service obtain standard nuts, bolts and washers locally.  
If these items cannot be obtained locally, order by part number and size as shown on parts list.

# TMO-33905A

Parts shown are for Model TMO-33905A Only—  
For Model TMO-33927A, see page 26.





# TMO-33905A

## 12 H.P. 38" LAWN TRACTOR PARTS LIST FOR MODEL TMO-33905A


REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	732-0414A	Hood Spring	49	17243	Seat Pivot Brkt. Support—L.H.
2	14665ACC621	Hood	50	17225	Hitch Plate
3	712-0272	Hex Sems Nut #10-24 Thd.*	51	712-0267	Hex Nut 5/16-18 Thd.*
4	738-0145	Shld. Bolt .50" Dia. x .84"	52	736-0119	L-Wash. 5/16" I.D.*
5	723-0302	Hood Stop 7" Lg.	53	17239A	Seat Lift Brkt.
6	710-0473	Truss Hd. Scr. #10-24 x 1/2"*	54	757-0345	Seat
7	723-0333	Fuel Cap Gauge	55	17244	Seat Pivot Brkt. Support—R.H.
8	751-0172	Fuel Tank	56	738-0296	Shld. Bolt .437" Dia. x .268"
9	726-0209	Tie Strap	57	725-1303	Spring Switch
10	751-0173A	Fuel Line	58	722-0160	Bushing
11	726-0207	Hose Clamp	59	731-0561	Tool Tray
13	712-0287	Hex Nut 1/4-20 Thd.*	60	736-0607	External L-Wash. 5/16" I.D.
14	736-0329	L-Wash. 1/4" I.D.	61	710-0351	Truss Mach. Tap Scr. #10 x .50" Lg.
15	710-0971	Truss Hd. Screw 5/16-18 x 1" Lg.	62	736-0413	Washer .39" I.D. x .62" O.D.
16	732-0548	Compression Spring	63	736-0159	Fl-Wash. .344" I.D. x .875"
17	723-0360	Foot Pad	64	710-0602	Hex Wash. Hd. Tap Scr. 5/16-18 x 1.0" Lg.
20	17025	Grille			Shld. Bolt .437" Dia. x .162"
21	731-0705	Headlight Housing	65	738-0155	Spr-Wash. .445" I.D. x .75
22	731-0706	Headlight Lens	66	736-0141	Grille Support Rod
23	16643A	Mounting Brkt.	67	749-0721	Seat Pivot Bracket
24	14619A	Front Pivot Brkt.	68	15607D	Truss Hd. Scr. 1/4-20 x .75"*
25	16644A	Mounting Brkt.	69	710-0255	R.H.—Grille Side Panel
26	710-0726	Hex Wash. Hd. AB-Tap Scr. 5/16 x .75" Lg.	70	16619	L.H.—Grille Side Panel (Not Shown)
27	710-0495	Carriage Bolt 1/4-20 x 2.0" Lg.*		16621	Dash Panel Ass'y.
28	710-0134	Carriage Bolt 1/4-20 x .62"*	71	17301	Throttle Control Box Ass'y.
29	14604E	Running Board (R.H. & L.H.)	72	831-0823A	Throttle Control Wire
30	761-0168	Blade Brake Ass'y.	73	746-0638A	Ignition Switch
31	725-0963	Head Lamp	75	725-0267	Ignition Key
32	725-1058	Twist Lock Lamp Socket	79	725-0201	Light Switch
33	710-0323	Truss Mach. Scr. 5/16-18 x .75" Lg.*	84	725-0634	Ammeter
34	15930B	Lower Frame	86	725-0925	Molding Strip 27" Lg.
35	736-0169	L-Wash. 3/8" I.D.*	88	731-0511	Running Board Rod
36	14671	Fender Clamp	89	738-0526	Hex Sems Nut #10-24 Thd.
37	16197ACC621	Fender (R.H.)	92	712-0272	Shld. Bolt .375" Dia. x .125"
	14666CC621	Fender (L.H.)	93	738-0724	L-Nut 1/4-28 Thd.
38	710-0118	Hex Bolt 5/16-18 x .75" Lg.*	94	712-0380	Trim Strip—57" Lg.
39	14602GCC621	R.H. Side Frame	95	731-0511	Hex Wash. Hd. AB-Tap Scr. #8 x .50" Lg.
40	710-0258	Hex Bolt 1/4-20 x .62" Lg.*	96	710-0227	Speed Nut #10Z
41	712-0798	Hex Nut 3/8-16 Thd.*	97	726-0139	Hex Tap Scr. 3/8-16 x .75"
42	732-0581	Extension Spring 5.31" Lg.	98	710-0623	Choke Control 29" Lg.
43	731-0871A	Battery Box w/Cover	102	746-0615A	Truss Mach. AB-Tap Scr. #10 x .50" Lg.
44	725-0514A	12-V Battery	103	710-0779A	Foam Strip 3/8 x 1-1/8 x 1 1/2
45	14603GCC621	L.H. Side Frame			Fiber Washer
46	17286	Shift Cover	104	722-0157	
47	725-0759	Reverse Safety Switch	106	736-0426	
48	726-0222	Insulator Nut Plate			

\*Common Hardware—May be purchased locally.  
Important: Do not order by reference number (Ref. No.).

NOTE: Specifications subject to change without notice or obligation.

# TMO-33927A

Parts shown are for Model TMO-33927A Only—  
For Model TMO-33905A, see page 24.



# TMO-33927A


## 12 H.P. 38" LAWN TRACTOR PARTS LIST FOR MODEL TMO-33927A

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	16787ACC621	Hood	51	14603G	L.H. Side Frame
2	710-0206	Hex Bolt 1/4-20 x .88" Lg.	52	750-0583	Spacer 1.30" Lg.
3	736-0413	Washer .39" I.D. x .62"	53	14605	Fuel Tank Support
4	712-0798	Hex Nut 3/8-16 Thd.*	54	710-0255	Truss Hd. Scr. 1/4-20 x .75"*
5	736-0169	L-Wash. 3/8" I.D.*	55	17308	Side Cover—R.H.
6	712-0272	Hex Sems Nut #10-24 Thd.*		17309	Side Cover—L.H. (Not Shown)
7	736-0931	Fl-Wash. .203" I.D. x .41"	56	710-0286	Truss Mach. Scr. 1/4-20 x .50" Lg.*
8	727-0290	Hood Stop			
9	710-0473	Truss Hd. Scr. #10-24 x 1/2"*	57	736-0173	Fl-Wash. .281" I.D. x .73"
10	723-0333	Fuel Cap Gauge	59	831-0823A	Throttle Control Box Ass'y.
11	751-0172	Fuel Tank	60	746-0500	Throttle Control Wire
12	726-0209	Tie Strap	62	726-0152	Mounting Clamp
13	726-0207	Hose Clamp	63	725-0201	Ignition Key
14	751-0173A	Fuel Line	64	725-0267	Ignition Switch
15	725-0963	Lamp	65	17295	Dash Panel
16	725-1058	Twist Lock—Lamp Socket	66	725-0634	Light Switch
17	731-0705	Headlight Housing	67	725-0925	Ammeter
18	736-0222	Ext. L-Wash. 1/4" I.D.	68	731-0511	Trim Strip—27"
19	710-0971	Truss Hd. Screw 5/16-18 x 1" Lg.	69	732-0462	Hood Spring
			70	757-0338	Seat
20	710-0118	Hex Bolt 5/16-18 x .75" Lg.*	72	726-0139	Speed Nut #10Z
21	16456BCC621	Grille	73	710-0749	Hex Scr. #10-24 x 1.0" Lg.
22	17300	Dash Support Bracket	74	738-0145	Shld. Bolt .50 Dia. x .84
23	736-0119	L-Wash. 5/16" I.D.*	76	731-0511	Trim Strip—81"
24	712-0267	Hex Nut 5/16-18 Thd.*	77	710-0642	Hex Wash. Hd. Tap Scr. 1/4 x .75" Lg.
25	738-0759	Shld. Spacer			
26	731-0871A	Battery Box w/Cover	78	722-0157	Foam Strip 3/8 x 1-1/8" x 1 1/2" Lg. (4 Req'd.)
27	725-0514A	12V Battery			
28	15930B	Lower Frame	79	710-0227	Hex Wash. Hd. AB-Tap #8 x .50" Lg.
29	14619A	Front Pivot Brk't.			
30	15821	Grille Mount Brk't.—L.H.	82	746-0615A	Choke Control 29" Lg.
31	15822	Grille Mount Brk't.—R.H.	83	710-0779A	Truss Mach. AB-Tap Scr. #10 x .5" Lg.
32	710-0726	Hex Wash. Hd. AB-Tap Scr. 5/16 x .75" Lg.			
33	738-0526	Running Board Rod	86	731-0967	Headlight Bezel
34	14604E	Running Board (R.H. & L.H.)	87	731-0909	Rubber Foot Pad—L.H.
35	761-0168	Blade Brake Ass'y.		731-0910	Rubber Foot Pad—R.H.
36	712-0287	Hex Nut 1/4-20 Thd.*	88	732-0581	Ext. Spring 5.31" Lg.
37	736-0329	L-Wash. 1/4" I.D.*	89	17239A	Seat Lift Brkt.
38	710-0323	Truss Mach. Scr. 5/16-18 x .75" Lg.*	90	738-0296	Shld. Bolt .437" Dia.
			91	17243	Seat Pivot Brkt. Support—L.H.
39	712-0264	Acorn Nut 1/4-20 Thd.	92	738-0155	Shld. Bolt .437" Dia.
40	710-0134	Carriage Bolt 1/4-20 x .62"*	93	17244	Seat Pivot Brkt. Support—R.H.
41	14602G	R.H. Side Frame	94	725-1303	Spring Switch
42	710-1026	Hex TT-Tap Scr. 1/4-20 x 1.75" Lg.	95	736-0141	Spr-Wash. .445" I.D.
			96	710-0602	Hex Wash. Hd. Tap Scr. 5/16-18 x 1" Lg.
43	17228CC621	Rear Fender	97	736-0159	Fl-Wash. .344" I.D.
45	710-0167	Carriage Bolt 1/4-20 x .50"*	98	722-0160	Bushing
46	736-0607	External L-Wash. 5/16" I.D.	99	732-0588	Compression Spring
47	17286	Transmission Panel	100	15607D	Seat Pivot Bracket
48	725-0759	Reverse Safety Switch	101	710-0623	Hex Tap Scr. 3/8-16 x .75"
49	726-0222	Insulator Nut Plate	102	736-0426	Fiber Washer
50	17225	Hitch Plate	105	731-0511	Trim Strip

\*Common Hardware—May be purchased locally.  
Important: Do not order by reference number (Ref. No.).

NOTE: Specifications subject to change without notice or obligation.

# TMO-33905A TMO-33927A



# TMO-33905A

# TMO-33927A

## 12 H.P. 38" LAWN TRACTORS


### PARTS LIST FOR MODELS TMO-33905A AND TMO-33927A

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	731-0220	Steering Wheel Cap	31	712-0711	Hex Jam Nut 3/8-24 Thd.*
2	712-0237	Hex L-Nut 5/16-24 Thd.	32	14650A	Front Axle Ass'y.—R.H.
3	736-0242	Belleville Wash. .345" I.D.	33	734-0863	Wheel Ass'y. Comp.
4	731-0805	Steering Wheel (TMO-33905A)		734-0864	Tire Only
	731-0806A	Steering Wheel (TMO-33927A)	34	734-0997A	Front Wheel Rim Only
5	731-0559	Steering Bellow—4.5"		734-0255	Air Valve
6	16512	Steering Column Ass'y.		737-0146	Grease Fitting
7	741-0356	Flange Bearing .890 I.D. x 1.36 O.D.	35	741-0487	Bearing
8	712-0324	Hex L-Nut 1/4-20 Thd.	36	736-0285	Fl-Wash. .635 I.D. x 1.59" O.D.
9	17198	Retainer Plate	37	731-0484A	Front Wheel Hub Cap
10	738-0141	Shoulder Bolt .437" Dia. x .35 Lg. 5/16-18 Thd.	38	714-0470	Cotter Pin 1/8" Dia. x 1.25" *
11	710-0152	Hex Bolt 3/8-24 x 1.0" Lg. (Grade 5)	39	736-0187	Fl-Wash. .640" I.D. x 1.24" O.D.
13	750-0535	Spacer .380" I.D. x .625" O.D. x .227	40	726-0214	Push Cap 5/8" Dia. Rod
14	736-0169	L-Wash. 3/8" I.D.*	42	712-0711	Hex Jam Nut 3/8-24 Thd.*
15	710-0726	Hex Wash. Hd. Self-Tap Scr.	43	710-0538	Hex L-Bolt 5/16-18 x .62" *
16	711-0788	Steering Drag Link	44	736-0119	L-Wash. 5/16" I.D.*
17	14619A	Front Pivot Brkt.	45	736-0343	Fl-Wash. .33" I.D. x 1.25" O.D.
18	738-0527	Shoulder Bolt .498" Dia. x 2.04 Lg. 3/8-16 Thd.	46	750-0532	Spacer (Plastic)
19	712-0798	Hex Nut 3/8-16 Thd.*	47	712-0241	Hex Nut 3/8-24 Thd.*
20	736-0169	L-Wash. 3/8" I.D.*	48	736-0169	L-Wash. 3/8" I.D.*
21	712-0237	Hex Cent. L-Nut 5/16-24 Thd.	49	712-0267	Hex Nut 5/16-18 Thd.*
22	16481	Steering Arm Front Axle	50	736-0119	L-Wash. 5/16" I.D.*
23	710-0772	Hex Bolt 5/16-24 x 2.00" Lg. (Grade 5)	51	717-0622	Steering Gear Segment
24	741-0225	Hex Flg. Brg. .634 I.D.	52	741-0225	Hex Flg. Brg. .634 I.D.
25	14608	Pivot Bar Ass'y.	53	736-0187	Fl-Wash. (Hardened)
26	16479	Front Axle Ass'y.—L.H.	54	738-0522A	Steering Shaft Lower
27	712-0241	Hex Nut 3/8-24 Thd.*	55	710-0958	Hex Bolt 1/4-20 x 1.25" Lg. (Special)
28	736-0169	L-Wash. 3/8" I.D.*	57	710-0837	Oval Hd. Cr.—Sunk Scr. #10 x 5/8" Lg.
29	723-3018	Ball Joint 3/8-24 Thd.	58	736-0271	Wave-Wash. .32" I.D. x .62" O.D.
30	711-0613	Tie Rod	59	736-0187	Fl-Wash. (Hardened)
			60	723-3018	Drag Link Ball Joint 3/8-24 Thd.
			61	736-0607	Ext. L-Wash. 5/16" I.D.

Part No.	Description	Part No.	Description
788-0638	Red Spray Paint	777-7094	Labels—Hood Stripe (TMO-33927A)
788-0452	Black Spray Paint	777-7100	Plastic Hood Side Stripe (TMO-33927A)
777-5268	Steering Cap Label	777-6890	Label—6 Speed (TMO-33905A)
777-6827	Montgomery Ward Logo—Grille	777-6891	Label—7 Speed (TMO-33927A)
777-7002	Montgomery Ward Logo—Side of Hood	777-7528	F-N-R Shift Label
777-7105	Transmatic Label	777-6681	Label—Dash Panel (TMO-33905A)
777-7068	Labels—Frame Side (TMO-33905A)	777-7289	Label—Dash Panel (TMO-33927A)
777-6932	Labels—Frame Side (TMO-33927A)	770-6518D	Operating Manual
777-7093	Labels—Hood Stripe (TMO-33905A)		

**Note:** If brand of tire is important, order by part number and description (description is printed on the sidewall of tire) [i.e. Armstrong Super Turf, Goodyear Softrac, Carlisle Turf Saver, etc.].

# TMO-33905A TMO-33927A



††REAR WHEEL CHART

Description	18 x 9.50 (TMO-33927A)	18 x 8.50 (TMO-33905A)
Wheel Assembly Comp.	734-0817	734-0601
Tire Only	734-0448	734-0516
Rim Only	734-0603	734-0603

# TMO-33905A TMO-33927A

## 12 H.P. 38" LAWN TRACTORS PARTS LIST FOR MODELS TMO-33905A AND TMO-33927A

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	12 H.P.	Engine—B&S 280707-0128-01 (TMO-33905A)	55	710-0176	Hex Bolt 5/16-18 x 2.75" *
	12 H.P.	Engine—B&S 281707-0137-01 (TMO-33927A)	56	††	Wheel Ass'y. Comp.
2	710-0258	Hex Bolt 1/4-20 x .62" Lg. *	57	††	Wheel Rim Only
3	725-0977	Ground Wire	58	734-0255	Air Valve (Service Only)
4	712-0123	Hex Nut 5/16-24 Thd. *	59	710-0627	Hex Bolt 5/16-24 x .75" Lg. *
5	736-0119	L-Wash. 5/16" I.D. *	60	717-1050	Transaxle Complete
6	14791A	Engine Mounting Plate	61	732-0454	Brake Return Spring Anchor
7	736-0343	Fl-Wash. .320" I.D. x 1.25"	62	711-0768	Belt Guard Pin 1/4-20 Thd.
8	722-0153	Engine Mounting Grammet	63	736-0275	Fl-Wash. .34" I.D. x .68" O.D.
9	750-0539	Spacer	64	710-0428	Hex Bolt 1/4-28 x 1.25" Lg. *
10	710-0654A	Hex Bolt 3/8-16 x 1.25" Lg.	65	732-0568	Ext. Spring
11	15930B	Lower Frame Ass'y.	66	732-0384	Ext. Spring .62" O.D. x 6.12"
12	710-0158	Hex Bolt 5/16-24 x 1.25" *	67	16554A	Variable Speed Torque Brkt. Ass'y.
13	712-0287	Hex Nut 1/4-20 Thd. *	68	741-0419	Flanged Bearing
14	736-0329	L-Wash. 1/4" I.D. *	69	714-0507	Cotter Pin 3/32" Dia. *
15	710-0781	Hex Wash. Hd. AB-Tap Scr. 5/16" x .75" Lg.	70	748-0234	Shoulder Spacer .27" Lg.
16	15898	Belt Guard Brkt. Ass'y.	71	747-0530	Speed Control Link
17	736-0242	Bell-Wash. .345" I.D. x .88"	72	741-0405	Truss Bearing .56 Dia. x 1.25"
18	712-0267	Hex Nut 5/16-18 Thd. *	73	720-0165	Ball Knob
19	710-0190	Hex Bolt 5/16-18 x 4.0" *	74	756-0437	Fl-Idler Pulley 3.25" x .75"
20	714-0114	Sq. Key 1/4" x 1/4" x 2.00"	75	756-0374	1/2" "V"-Pulley 8.0" O.D. x .501" I.D.
21	756-0488	Engine Pulley	76	736-0921	L-Wash. 1/2" I.D. *
22	736-0322	Fl-Wash. 7/16" I.D. x 1.25"	77	712-0922	Hex Jam Nut 1/2-20 Thd. *
23	736-0171	L-Wash. 7/16" I.D. *	78	710-0539	Hex Bolt 3/8-24 x 1.75" Lg.
24	710-0757	Hex Bolt 7/16-20 x 1.50" Lg.	79	754-0281	Variable Speed Belt
25	754-0280	Variable-Speed Belt	80	716-0114	Snap Ring .56" Dia.
26	710-0118	Hex Bolt 5/16-18 x .75" Lg.	81	736-0355	Fl-Wash.
27	16553	Bearing Shaft Bracket Ass'y.	82	717-0800	Variable Speed Pulley Ass'y. 5" O.D.
28	741-0295	Flanged Nyliner Brg. 5/8" I.D. x .88" Lg.	84	16354B	Variable Speed Brkt. Ass'y.
29	712-0241	Hex Nut 3/8-24 Thd. *	85	732-0525	Comp. Spring—Clip
30	15891B	Idler Bracket	86	14770	Axle Support Brkt.—R.H.
31	736-0169	L-Wash. 3/8" I.D. *		14769A	Axle Support Brkt.—L.H. (Not Shown)
32	712-0241	Hex Nut 3/8-24 Thd. *	87	736-0231	Fl-Wash. .34 I.D. x 1.12 O.D.
33	15945E	Transaxle Support Brkt.	88	725-0771	Solenoid
34	732-0459	Ext. Spring .94" O.D. x 6.7"	89	16429A	Shift Lever Bracket
35	714-0149B	Inter. Cott-Pin	90	736-0414	Teflon Washer .565" I.D.
37	714-0507	Cotter Pin 3/32" Dia. x .75" *	91	725-0459	Circuit Breaker
38	720-0223	Grip—Black	92	710-0959	Hex Bolt 5/16-18 x 1.50" Lg.
39	712-0138	Hex Nut 1/4-28 Thd.	94	738-0755	Shld. Bolt 3/8-24 x 3.12" Lg.
40	710-0597	Hex Bolt 1/4-20 x 1.00" Lg. *	95	732-0307	Ext. Spring .99" O.D. x 11"
41	732-0582	Switch Actuator	97	736-0105	Bell-Wash. .38" I.D. x .88"
42	725-0577	Safety Switch	98	738-0569	Shaft .56" Dia. x 3.875" Lg.
43	710-0599	Hex Wash. Hd. S-Tap Scr. 1/4-20 x .50" Lg.	99	736-0331	Bell-Wash. .39" I.D. x 1.12"
44	16235A	Clutch/Brake Pedal Ass'y.	100	736-0256	Fl-Wash.
45	736-0117	Fl-Wash.	101	714-0111	Cotter Pin 3/32" Dia. x 1.0" *
47	747-0519	Brake Rod 20.9" Lg.	102	710-0604	Hex Wash. Hd. Scr. 5/16-18 x .62" Lg.
48	735-0196	Foot Pad	104	736-0362	Fl-Wash. .32" I.D. x 1.25"
49	15889B	Brake Lever Bracket	105	16067	Belt Guard
50	15888	Hill Holder Brake Handle	106	710-0323	Truss Mach. Scr. 5/16-18 x .75" Lg. *
51	16430	Shift Lever Ass'y.	107	15835A	Pedal Bracket
52	710-0559	Hex Bolt 1/4-28 x 1.75" Lg. *	108	714-0507	Cotter Pin 3/32" Dia. x .75"
53	732-0264	Ext. Spring .38" O.D. x 2.5"	109	711-0198	Ferrule
54	732-0413	Ext. Spring .59" O.D. x 7.08"			

**12 H.P. 38" LAWN TRACTORS  
PARTS LIST FOR MODELS TMO-33905A AND TMO-33927A (CONTINUED)**

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
110	710-0376	Hex Bolt 5/16-18 x 1.0" Lg.— (Gr. 5)	123	738-0636	Shoulder Bolt†
111	710-0195	Hex Bolt ¼-28 x .50" Lg.	124	710-0224	Hex AB-Tap Scr. #10 x .5"†
112	736-0270	Bell-Wash. .265" I.D. x .75"	125	738-0175	Spr. Wash. ¼" I.D.†
113	16437A	Shift Lever Link Ass'y.	126	710-0294	Hex Bolt ¼-20 x 3/8" Lg.†
114	**	Muffler	127	16812	Muffler Heat Shield—Front†
115	736-0140	FI-Wash. .385" I.D. x .62"	128	16811	Muffler Heat Shield—R.H.†
116	17199,†	Cooling Fan†	129	710-0323	Truss Mach. Scr. 5/16-18 x .75" Lg.†
117	722-0247	Foam Strip	130	736-0119	L-Wash. 5/16" I.D.†
118	736-0329	L-Wash. ¼" I.D.†	131	16813	Heat Shield Bracket†
119	710-0599	Hex Tap Scr. ¼-20 x .5"†	132	750-0709	Spacer†
120	**	Muffler†	133	721-0208	Exhaust Gasket†
121	16801	Muffler Heat Shield—L.H.†	134	710-0252	Hex Bolt ¼-20 x .85" Lg.†
122	712-0147	U-Type Speed Nut #10-24 Thd.†	135	725-0977	Ground Wire


†Model TMO-33927A Only.

**\*\*MUFFLER CHART**

Engine	Muffler	Hardware & Related Parts
TMO-33905A	751-0302	712-0250 Conduit L-Nut
TMO-33927A	751-0465	See Parts List

# TMO-33905A

# TMO-33927A




**12 H.P. 38" LAWN TRACTORS  
PARTS LIST FOR MODELS TMO-33905A AND TMO-33927A**

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	710-0924	Truss Mach. Scr. ¼-20 x .75" Lg.	8	16355A	Speed Control Rod Ass'y.
2	16236	6 Speed Selector Plate (TMO-33905A)	9	714-0507	Cotter Pin 3/32" Dia. x .75"*
	16194	7 Speed Selector Plate (TMO-33927A)	10	736-0226	FI-Wash. .469" I.D. x .88"
3	720-0218	Shift Knob	11	736-0119	L-Wash. 5/16" I.D.*
4	16192	Speed Selector Cam Ass'y.	12	712-0267	Hex Nut 5/16-18 Thd.*
5	736-0192	Flat Washer .53" I.D. x .93"	13	714-0507	Cotter Pin 3/32" Dia. x .75"*
6	711-0198	Ferrule 3/8-24 x .37" Dia.	14	732-0303	Spring .38" O.D. x 3.18" Lg.
7	738-0155	Shoulder Bolt .435" Dia. x .160	15	16196	Clamping Plate
			17	736-0140	FI-Wash. .385" I.D. x .62"
			18	726-0235	Speed Clip



# TMO-33905A TMO-33927A




12 H.P. 38" LAWN TRACTORS  
PARTS LIST FOR MODELS TMO-33905A AND TMO-33927A

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	732-0307A	Extension Spring 11" Lg.	26	736-0425	Bell-Wash. .325" I.D. x .93"
2	741-0313	Flange Bearing .634" I.D.	27	736-0119	L-Wash. 5/16" I.D. "
3	736-0231	Fl-Wash. .344" I.D. x 1.125"	28	712-0267	Hex Nut 5/16-18 Thd. "
4	710-0604	Hex Wash. Hd. 5/16-18 x .62" Lg.	29	16462	Index Brkt.
5	14802A	Link Deck Lift Ass'y.	30	711-0425	Spacer .523" I.D. x .640"
6	711-0790A	Stabilizer Rod	31	732-0530	Ext. Spring 13.25" Lg.
7	16234A	Stabilizer Shaft Ass'y.	32	732-0573	Ext. Spring
8	710-0602	Hex Tap Scr. 5/16-18 x 1"	33	16465A	Lift Handle (TMO-33905A)
9	714-0470	Cotter Pin 1/8" Dia. x 1 1/4" "		17194	Lift Handle (TMO-33927A)
10	736-0156	Fl-Wash. .635" I.D. x 1.12"	34	720-0233	Grip (Lift Handle)
11	736-0160	Fl-Wash. .531" I.D. x .940"	35	714-0145	Intern. Cotter Pin 3/8" Dia.
12	714-0111	Cotter Pin 3/32" Dia.	36	710-0118	Hex Bolt 5/16-18 x .75" "
13	17154A	Lift Shaft Ass'y.	37	14804	Link Deck Hanger Ass'y.
14	712-3007	Hex Jam Nut 5/16-18 Thd.	38	14800	Link Deck Hanger Ass'y. (Dog Leg)
15	09735A	Connecting Rod	39	15925	Link Deck Hanger Ass'y.—L.H.
16	736-0117	Fl-Wash. .385" I.D. x .62"	40	08540	Knob
17	714-0101	Inter. Cotter Pin 1/2" Dia.	41	710-0351	Hex AB-Tap Scr. #10 x .50"
20	748-0176	Flange Brg. .630" I.D.	42	725-0803B	Safety Switch
21	732-0412A	Deck Lift—Down Stop	43	726-0175	Clamp
24	09721	Pivot Link Ass'y.			
25	738-0140	Shld. Bolt .437" Dia. x .180" Lg. (5/16-18)			

# TMO-33905A

# TMO-33927A



SINGLE SPEED TRANSAXLE—R.H.  
MODEL 717-1050

# TMO-33905A

# TMO-33927A

## PARTS LIST FOR SINGLE SPEED TRANSAXLE RIGHT HAND 717-1050

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	714-0129	#4 Hi-Pro Key 3/32 x 5/8" Dia.	33	736-0351	Fl-Wash. .75" I.D. x 1.5" O.D.
2	716-0115	Snap Ring .625" Shaft	34	717-0761	Lower Housing
3	710-0854	Hex Bolt 1/4-20 x 1.75" Lg.*	35	750-0555	Spacer .53" O.D. x 3/8" Lg.
4	710-0809	Hex Bolt 1/4-20 x 1.25" Lg.*	36	736-0329	L-Wash. 1/4" I.D.*
5	717-0764	Upper Housing	37	710-0886	Hex Bolt 1/4-20 x 1.50" Lg. (Grade 5)
6	710-0642	Hex Fl-Bolt 1/4-20 x .75" Lg.	38	712-0335	Castle Nut 5/16-24 Thd.*
7	712-0287	Hex Nut 1/4-20 Thd.*	39	736-0371	Fl-Wash. .34" I.D. x .875" O.D.
8	717-0634	Input Shaft			
9	721-0178	Square Seal 5/8" I.D.			
10	736-0335	Thrust Washer 5/8" I.D. x 1.25" O.D.	40	717-0700	Actuating Arm—R.H.
11	717-0633	Pinion Input 14T	41	717-0679	Brake Yoke
12	716-0108	Retaining Ring 7/16" Ext.	42	717-0682	Puck Plate
13	717-0758	Drive Shaft—R.H.	43	717-0678	Brake Puck
14	741-0336	Flange Brg. 5/8" I.D. x 3/4" Lg.*	44	717-1011	Axle L.H.
15	**	Fl-Wash. (See Below)	45	717-0677	Brake Disc
16	717-0757	Bevel Gear 42T	46	741-0337	Flange Bearing 5/8" I.D. x 15/16" Lg.
17	717-0667	Clutch Collar	47	714-0161	Woodruif Key 3/16 x 5/8 HT
18	717-1020	Miter Gear 15T	48	717-0754	Shift Fork Ass'y.
19	716-0142	Snap Ring	49	741-0862	Ball Detent .250" Dia.
20	717-0690	Thrust Bearing 1/2" I.D. x 1.0" O.D.	50	732-0863	Spring Detent
21	710-0862	Pan Head Scr. 1/4-20 x .50" Lg. w/Patch	51	714-0169	#9 Hi-Pro Key 3/16" x 3/4" Dia. HT
22	717-1012	Axle R.H.	52	741-0335	Needle Brg. 5/8" I.D. x 1/2" Lg.
23	741-0340	Sleeve Bearing 3/4" I.D. x 1.0" Lg.	53	710-0855	Hex Bolt 1/4-20 x 1.00" Lg.
24	721-0179	Oil Seal 3/4" I.D.	54	736-0336	Fl-Wash. 5/8" I.D. x .030
25	741-0339	Flange Bearing 3/4" I.D. x 15/16" Lg.	54A	736-0337	Fl-Wash. 5/8" I.D. x .040
26	736-0188	Fl-Wash. .760" I.D. x 1.49" O.D.	54B	736-0349	Fl-Wash. 5/8" I.D. x .020
27	717-0673	Cross Shaft	55	741-0343	Actuating Pin 5/16" Dia.
28	717-0777	Differential Housing Ass'y.	56	710-0886	Hex Bolt 1/4-20 x 1.50" Lg. (Grade 5)
29	—	Comes with Ref. 28	57	717-1059	Differential Gear 72T Ass'y. w/Bearing
30	717-1019	Miter Gear	58	717-0796	Sq. Hd. Bolt 5/16-24 Thd.
31	712-0200A	Hex Ins. L-Nut 1/2-20 Thd.	59	1544-013	Cotter Pin 3/32" Dia. x .50" Lg.
			—	737-0148	Grease—Shell (10 oz.)

\*\*Ref. No. 15 736-0349 Fl-Wash. 5/8" I.D. x 1.0" O.D. x .020 Thk.  
736-0336 Fl-Wash. 5/8" I.D. x 1.0" O.D. x .030 Thk.  
736-0337 Fl-Wash. 5/8" I.D. x 1.0" O.D. x .040 Thk.

At the time of manufacture of lawn tractor, the optional accessories listed below are available.

Description	Stock No.
36" Snow Thrower	89-33848R
42" Snow Blade	89-33879R
Grass Collector	89-35108R
38" Lawn Sweeper	89-37952R
30 Lb. Wheel Weights	89-33862R
Gang Reel	89-27R

SERVICE NATIONWIDE

## Montgomery Ward

### HOW TO OBTAIN REPLACEMENT PARTS AND SERVICE

The merchandise you have purchased from us has been carefully engineered and manufactured under Montgomery Ward's rigid quality standards and should give you satisfactory and dependable operation. However, like all mechanical merchandise, it may occasionally require adjustment, replacement parts or maintenance.

#### Toll Free Parts Sales Center

When you need a replacement part or accessory for a major appliance, home electronic item or lawn and garden product that is not under warranty or covered by a service contract or if you need the location of the nearest service facility, call our Parts Sales Center toll free 1-800-323-1965.

#### Provide the following:

1. Model, serial number and all of the other data shown on the model plate.
2. Also give the part number or numbers as shown in the parts list that came with the product.

Replacement Parts will be made available at current prices. If requested, prices will be quoted in advance when not listed.

If you order parts by mail, you will pay the transportation charges from the shipping point.

UNIT MODEL NO. \_\_\_\_\_

UNIT SERIAL NO. \_\_\_\_\_

ENGINE MODEL NO. \_\_\_\_\_

TYPE NO. \_\_\_\_\_

CODE NO. \_\_\_\_\_