



# Operating/Service Instructions

## RIDING MOWER

### IMPORTANT

Model Nos.  
133-430, 133-434  
& 133-435

## SAFE OPERATION PRACTICES FOR RIDING VEHICLES

1. Know the controls and how to stop quickly—**READ THE OWNER'S MANUAL.**
2. Do not allow children to operate vehicle. Do not allow adults to operate it without proper instruction.
3. Do not carry passengers. **Keep children and pets a safe distance away.**
4. Clear work area of objects which might be picked up and thrown.
5. Disengage all attachment clutches and shift into neutral before attempting to start engine (motor).
6. Disengage power to attachment(s) and stop engine (motor) before leaving operator position.
7. Disengage power to attachment(s) and stop engine (motor) before making any repairs or adjustments.
8. Disengage power to attachment(s) when transporting or not in use.
9. Take all possible precautions when leaving vehicle unattended such as disengaging power-take-off, lowering attachments, shifting into neutral, setting parking brake, stopping engine and removing key.
10. Do not stop or start suddenly when going uphill or downhill. Mow up and down face of steep slopes; never across the face.
11. Reduce speed on slopes and in sharp turns to prevent tipping or loss of control. Exercise extreme caution when changing direction on slopes.
12. Stay alert for holes in terrain and other hidden hazards.
13. Use care when pulling loads or using heavy equipment.
  - A. Use only approved drawbar hitch points.
  - B. Limit loads to those you can safely control.
  - C. Do not turn sharply. Use care when backing.
  - D. Use counterweight(s) or wheel weights when suggested in owner's manual.
14. Watch out for traffic when crossing or near roadways.
15. When using any attachments never direct discharge of material toward bystanders nor allow anyone near vehicle while in operation.
16. Handle gasoline with care—it is highly flammable.
  - A. Use approved gasoline container.
  - B. Never remove cap or add gasoline to a running or hot engine or fill fuel tank indoors. Wipe up spilled gasoline.
  - C. Open doors if engine is run in garage — exhaust fumes are dangerous. Do not run engine (motor) indoors.
17. Keep the vehicle and attachments in good operating condition, and keep safety devices in place. Use guards as instructed in owner's manual.
18. Keep all nuts, bolts, and screws tight to be sure the equipment is in safe working condition.
19. Never store the equipment with gasoline in the tank inside a building where fumes may reach an open flame or spark. Allow engine to cool before storing in any enclosure.
20. To reduce fire hazard keep engine free of grass, leaves or excessive grease.
21. The vehicle and attachments should be stopped and inspected for damage after striking a foreign object, and the damage should be repaired before restarting and operating the equipment.
22. Do not change the engine governor settings or overspeed the engine.
23. When using the vehicle with mower, proceed as follows:
  - (1) Mow only in daylight or in good artificial light.
  - (2) Never make a cutting height adjustment while engine (motor) is running if operator must dismount to do so.
  - (3) Shut engine (motor) off when removing grass catcher and/or unclogging chute.
  - (4) Check blade mounting bolts for proper tightness at frequent intervals.
24. Check grass catcher bags frequently for wear or deterioration. Replace with new bags for safety protection.

## ASSEMBLY

GRASS CATCHER Model No. 193-015 is available as optional equipment for the mowers shown in this manual.

### WARNING

1. The mower should not be operated without the entire grass catcher or chute deflector in place.

### NOTE

Under normal usage bag material is subject to wear, and should be checked periodically. Be sure any replacement bag complies with the mower manufacturer's recommendations.

For replacement bags, use only factory authorized replacement bag No. 764-121.

**IMPORTANT:** After striking a foreign object, stop the engine (motor). Remove wire from spark plug, thoroughly inspect the mower for any damage, and repair the damage before restarting and operating the mower.

### NOTE

Reference to right-hand or left-hand side of machine is from the driver's seat facing forward.

Your mower is shipped assembled except for the steering wheel, seat and battery on the electric start model.

### STEERING WHEEL ASSEMBLY See figure 1.

Step 1. Line up the hole in the steering column and the hole in the tubing assembly and drive in the roll pin with a hammer.

### NOTE

It may be necessary to use a drift to line up the holes.

Step 2. Place the end caps on the spacer.

Step 3. Slide the spacer over the tubing assembly until it lays flush against the steering box.

Step 4. Place the steering wheel on the tubing shaft.

Step 5. Secure in place with Belleville washer and hex nut.

Step 6. Put on steering wheel cap by hand.




FIGURE 1. STEERING WHEEL ASSEMBLY

### SEAT ASSEMBLY. See figure 2.

Step 7. Your molded seat comes with the mounting bolt molded in the seat.

- Select one of three hole locations on seat bracket.
- Place seat on bracket and secure with spring lockwasher and hex nut.




FIGURE 2. SEAT ASSEMBLY

## TIRE PRESSURE

The tire are over-inflated for shipping. Reduce the tire pressure from 7 to 10 Psi front and rear.

## ACTIVATING THE BATTERY (Electric Start Models Only)

### **WARNING**

Since battery acid is corrosive to metals, do not pour into any sink or drain. Rinse empty Electrolyte containers and mutilate before discarding. If acid is accidentally spilled on battery during filling or charging, or on bench or clothing, etc., flush off with clear water and neutralize with soda or ammonia solution.

- Step 1. Place the battery to be filled on a bench. Never activate the battery in the mower.
- Step 2. Remove the vent plugs.
- Step 3. Place the acid pack in the upright position, pull the tab back to the edge of the carton, pull out hose, snip off end.
- Step 4. Fill each cell until the electrolyte level rises to the splitting at the bottom of the vent well.

### **CAUTION**

Do not over-fill.

- Step 5. After filling the cells, wait five to ten minutes and add additional electrolyte if necessary to bring it up to the proper level.
- Step 6. Replace the vent caps.
- Step 7. Using the battery charger packed with your mower, charge the new battery for 2 hours before installing it in the riding mower.

### **NOTE**


If you want to use a larger rated charger, use this guide.

25-30 amps	10 to 15 minutes
4-6 amps	30 minutes

## INSTALLING THE BATTERY (Electric Start Models Only) See figure 3.

- Step 1. Tip the seat bracket forward to expose the battery box.
- Step 2. Remove screw (A) and lockwasher (B).
- Step 3. Lift out the battery box bracket.

- Step 4. Place the battery in the battery box with the positive (+) to the front of the rider.
- Step 5. Attach the large red wire from the solenoid and the small red wire to the positive (+) terminal of the battery with a 1/4" screw (E), washer (D) and nut (C).
- Step 6. Attach the large red wire from the ground (-) to the negative (-) terminal of the battery with a 1/4" screw (E), washer (D) and nut (C).
- Step 7. Replace the battery box bracket with screw (A) and washer (B). See figure 3.



**FIGURE 3. INSTALLING THE BATTERY**

## BATTERY CHARGER

1. Your battery may be charged in your rider without removing it or without disturbing the cable connectors at the battery terminals.
2. Be sure the switch is in the 12 o'clock position.
3. Connect battery clips to battery terminals. Clip with (+) mark connects to positive terminal of the battery. Clip with no marking connects to negative terminal of battery. (Red clips are + and black clips are -.) Be sure that battery terminals are clean where charger clips are to be connected. Move clips back and forth several times to be sure a tight connection is made.
4. If sparking occurs at battery clips when connecting them to battery terminals the clips should be reversed on the battery terminals.

5. Make sure the voltage of the battery is the same as that of the charger, as mentioned before. Connect AC plug to an alternating current outlet of the same voltage and frequency as shown on the name plate of the charger. (To prevent short circuiting of the battery charger, be sure to connect clips to battery terminals before plugging into the AC outlet.)

6. Your battery charger is equipped with an automatic circuit breaker which protects the charger against short circuits and overloads which cause the circuit breaker to trip open when they occur. After a short cooling off period the circuit breaker will "reset" automatically and allow the charger to operate normally. If the circuit-breaker trips open, make sure battery connections are correct.

7. If the charger continues to trip and you have checked your connections to see that they are correct, the probable cause is in the battery, which may have been allowed to discharge below its normal discharge condition or it may have one or more shorted cells. If this condition exists it will draw too much current and cause the circuit breaker to trip on and off. This will continue until the battery has recovered sufficiently to allow a normal charging current.

8. The charging rate depends upon the AC supply voltage and the internal condition of the battery. Under certain of these conditions the charger may not deliver its maximum charging rate to the battery, but this should not be taken as an indication that the charger is inefficient.

9. The average time required to charge a battery is 8-10 hours for a completely discharged battery.

### **CONTROLS See figure 5.**

This manual should be read in its entirety before you operate your Riding Mower. The more you know and understand about the machine and its operation, the better job it will do for you. While reading the manual, compare the illustrations with your mower to familiarize yourself with the locations of various controls, lubrication points, attachments and adjustment features.

Study the operating instructions and safety precautions thoroughly to insure proper functioning of your mower and to prevent injury to yourself and others. Be sure to save this manual for future reference.

### **THROTTLE CONTROL**

The throttle control is used to regulate the engine speed and to activate the choke on the engine. To get the maximum efficiency on cutting, the throttle should be in the FAST position when operating the mower. Pushing the throttle all the way forward, past FAST will choke the engine.

### **IGNITION KEY**

**Recoil Model.** The key must be turned to the ON position before you pull the recoil handle to start the engine. Remove the key when the mower is not in use. Turn the key to the left to the OFF position to stop the engine.

### **LIFT AND DISENGAGEMENT LEVER**

The lift and disengagement lever is used to raise and lower the cutting deck, set the cutting height, and disengage the cutting blades.

Move the lever to the left and pull the lever all the way back and lock it to disengage the blades. The lever may be set in any one of the five cutting height positions. This lever works in conjunction with the deck wheel adjusters.

**Electric Model.** The key must be turned to the START position to start the engine. After the engine is running let the key return to the ON position. Remove the key when the mower is not in use. Turn the key to the OFF position to stop the engine.

### **INTERLOCKS (Not Shown)**

An interlock safety switch is located on the clutch pedal and the lift and disengagement lever.

The clutch pedal must be depressed all the way down (the speed control handle can be pulled back to lock it down) and the lift and disengagement lever must be in the STOP position (all the way back) before the engine can be started.

On the recoil start model, the ignition will be grounded and on the electric start model, the starter will not run.

### **GEAR SHIFT LEVER**

The gear shift lever has three positions, FORWARD, NEUTRAL and REVERSE. The clutch pedal must be depressed and the rider must not be moving when shifting gears. You may not be able to shift gears when the speed control handle is all the way back. Do not force the shift lever. Release the clutch pedal slightly to line up the shifting collar in the transmission and then try to shift.

### **BRAKE**


To operate the brake depress the right pedal all the way down. To lock the brake in the park position, pivot the pedal forward with your foot as you depress it. It will stay in the depressed position. To release the parking brake, pivot the pedal to the rear.

### **DECK WHEEL ADJUSTERS**

Always set both deck wheels in the same relative position. Set these wheels after you set the Lift and Disengagement Lever so they just clear the ground. This will prevent scalping the grass.

### **CLUTCH PEDAL**

The clutch pedal on the left side when depressed reduces your ground speed and disengages the engine from the transmission when depressed all the way down. It can be held in the disengaged position by pulling the Speed Control Handle into the locked position (all the way back). To stop the mower, depress the Clutch and Brake Pedals.



**FIGURE 4. CONTROLS**


**SPEED CONTROL HANDLE. See figures 4 and 5.**

The Speed Control Handle can be used as a hand control for the clutch pedal and is also used to lock the clutch pedal in the disengaged position by pulling it all the way back towards the operator.

**NOTE**

The farther forward the Stop Lever is set, the faster your ground speed.

Depressing the clutch pedal at any time will slow you down or, if depressed all the way, will stop the mower.



**FIGURE 5. SPEED CONTROL**

**STOP LEVER. See figures 4 and 5.**

The Stop Lever allows you to regulate the maximum ground speed of the riding mower by setting the Stop Lever in any one of the five settings.

**STOPPING**

**Engine**—Turn the ignition key to the left to the OFF position.

**Rider**—Depress the clutch and brake pedals.

**Blades**—Pull the lift and disengagement lever all the way back and lock it.

**OPERATING INSTRUCTIONS**

**CAUTION**


1. Keep all shields and guards in place.
2. Before leaving operator's position:
  - Shift controls into neutral
  - Set parking brake
  - Disengage attachment drive
  - Shut off engine
  - Remove ignition key
3. Wait for all movement to stop before servicing machine.
4. Keep people and pets a safe distance away from machine.

## STARTING THE ENGINE

1. Be sure the crankcase is filled with oil as recommended in the engine manual and put regular gasoline in the gasoline tank.
2. Be sure the fuel shut off valve located on the carburetor is open.
3. Attach the wire to the spark plug.
4. Depress the clutch pedal and lock it down with the speed control lever.
5. Pull the lift and disengagement lever all the way back to the disengaged position and lock it.
6. Set the throttle control lever in the CHOKE position.
7. **Recoil Model.** Turn the ignition key to the ON position, twist the recoil starter handle until it is free and pull it with a quick steady motion. After the engine starts, return the recoil starter handle and twist it until it locks. See figure 6.

### NOTE

If you do not do this the engine will quit running as soon as you engage the clutch or blades.



**FIGURE 6. RECOIL STARTER**

**Electric Start Model.** Turn the ignition key to the START position. As soon as the engine starts let the key return to the ON position.

Slowly return the throttle to the running position as soon as the engine starts.

8. To stop either model, turn the ignition key to the OFF position and remove the key when the rider is not in use.

## PUTTING THE RIDER IN MOTION

1. Advance the throttle control from  $\frac{3}{4}$  to full throttle to prevent strain on the engine and to operate the cutting blades.
2. Set the stop lever in the slowest position.
3. Hold the clutch pedal down with your left foot and release the speed control lever.
4. Place the gear shift lever in either the FORWARD or REVERSE position.
5. Slowly release the clutch pedal.
6. To stop the rider, depress the clutch pedal and the brake pedal.
7. The blades can be engaged either while moving or while standing still. Move the lift and disengagement lever forward slowly until the blades are running.

After you feel you can control the machine in the slower speeds, set the stop lever in a faster position. The rider will maintain the highest speed you set without you touching the controls. If you want to slow down, depress the clutch pedal until you attain the speed you want. When you remove your foot from the clutch pedal the rider will operate at the highest speed that you set on the stop lever.

## MAINTENANCE AND ADJUSTMENTS


### THROTTLE CONTROL

#### **To Check Operation:**

1. Remove air cleaner.
2. Move throttle control lever to CHOKE position. The carburetor choke should be closed.
3. Move throttle control lever to STOP position. Lever should make good contact with stop switch.

#### **To Adjust: See figure 7.**

Place throttle control lever in FAST (high speed) position. Loosen control casing clamp screw "B". Move control casing "A" and wire until lever "D" touches choke operating link at "C". Tighten casing clamp screw "B". Replace air cleaner.




## CARBURETOR ADJUSTMENT

Carburetors are adjusted at the factory and normally do not need adjustment unless they have been disassembled.

### **Initial Adjustment After Re-assembly. See figure 8.**

Turn needle valve clockwise until it just closes. **CAUTION:** Valve may be damaged by turning it too far. Now open needle valve 1-1/8 turns counterclockwise. Close idle valve in same manner and open 1-1/8 turns. This initial adjustment will permit the engine to be started and warmed up prior to final adjustment.



**FIGURE 8. CARBURETOR ADJUSTMENT**

### **Final Adjustment. See figure 8.**

Turn needle valve in until engine misses (lean mixture). Then turn it out past smooth operating point until engine runs unevenly (rich mixture). Now turn needle valve to the mid-point between rich and lean so the engine runs smoothly.

Hold throttle at idle position and set idle speed adjusting screw until fast idle is obtained (1750 RPM). Hold throttle in idle position and turn idle valve in (lean) and out (rich) until engine idles smoothly. Then reset idle speed adjusting screw so that engine idles at 1750 RPM. Release throttle—engine should accelerate without hesitation or sputtering. If engine does not accelerate properly the carburetor should be re-adjusted to a slightly richer mixture.

## CHAIN ADJUSTMENT

After the first five hours of operation the initial slack should be removed from the chain. The chain should be tight enough so that it deflects approximately 1/2" when it is depressed with the thumb.

### **To Adjust:**

The adjusting bolt is located under the frame, above the cutting deck on the right side of the mower.


Turn the adjusting bolt clockwise with an open end wrench until the chain reaches the proper tension.

### **NOTE**

If the transmission mounting plate will not slide forward to adjust the chain tension, it may be necessary to loosen the four nuts mounting the transmission to the frame.

To adjust the brake tighten the locknut one half turn and then test the brakes.

The brake is located by the right rear wheel inside the frame.



**FIGURE 9. BRAKE ADJUSTMENT**


## BLADES



Disconnect the spark plug wire and remove the ignition key before removing the blades.

Sharp and balanced blades are essential for efficient mowing and long mower and engine life. When sharpening blades, file equal amounts of metal from each side. The blades should be balanced before they are reinstalled. An unbalanced blade will cause excessive vibration and undue wear on the mower and the engine. When reassembling, all parts must be installed in the proper order and fastened securely.

Remove the 3/8" bolt and lockwasher. Pull the blade and adapter off the mower deck. To remove the adapter from the blade, remove the two 5/16" bolts, lockwashers and nuts. See figure 10.



**FIGURE 10. BLADE REMOVAL**

## MOWER DECK

The underside of the mower deck should be cleaned after each period of use as grass clippings, leaves, dirt and other matter will accumulate. This accumulation of grass clippings, etc., is undesirable as it will invite rust and corrosion and may cause an uneven discharge of grass clippings at the next mowing.

The deck may be cleaned by tilting the mower on its front wheels until the frame and the steering wheel supports the entire unit. Scrape clean with a suitable tool or by washing with a stream of water from a garden hose. Be sure to disconnect the spark plug wire and ground it while performing this maintenance.

**BELT REMOVAL. See figure 11.**

To remove either or both belts:

1. Place the speed control lever in the locked position.
2. Move the lift and disengagement lever into the disengaged position.
3. Remove the two rear hex nuts on the engine bolts to remove the engine belt guard and slide the guard away from the chain and remove it.
4. Remove the blade drive belt from the engine pulley.

5. With the lift and disengagement lever lower the cutting deck all the way down.


**NOTE**

If you do not want to remove the blade drive belt go to step 8.

6. Remove the deck belt guards.
7. Remove and replace the belt.

**To remove the variable speed belts:**

8. Remove the variable speed pulley by removing the center hex nut and lockwasher.
9. Remove the transmission pulley by removing the hex nut and washer.
10. The belts can now be removed.



**FIGURE 11. BELT REMOVAL**



## **LUBRICATION**

1. **Engine.** Maintain the engine oil according to the engine manual.
2. **Bearings.** The following bearings are oil impregnated and do not require lubrication, however, their normal life can be extended by lubricating them once a season with a light, non-detergent oil.
  - A. King Pin Bearings (total 4 bearings)
  - B. Rear Axle Bearings (total 3 bearings)
  - C. Front Wheel Bearings (total 4 bearings)
  - D. Deck Wheel Bearings (total 4 bearings)
3. **Throttle Control and Cable.** Wipe oiled rag along entire length of cable.

4. **Chain.** Wipe oiled rag along entire length of chain.

### **NOTE**

Under extremely dusty conditions do not oil the chain.

5. **Linkage.** Oil all deck linkage and height adjustment linkage.
  6. **Transmission.** Lubricated at the factory, does not require checking. Lubricate with 5 oz. of grease, high temp. 450°F, if disassembled.
  7. **Differential.** Lubricated at the factory, does not require checking. Lubricate with 2 oz. of grease, high temp. 450° F if disassembled. If ordered from the factory use Part No. 737-120.
-

IF YOU WRITE TO US ABOUT THIS ARTICLE OR  
 IF YOU ORDER REPLACEMENT PARTS ALWAYS  
 MENTION THIS STOCK AND MODEL NUMBER

STOCK No. \_\_\_\_\_ MODEL No. \_\_\_\_\_




FIGURE 12. EXPLODED VIEW


PARTS LIST FOR FIGURE 12 MODEL NO. 133-430, 434 AND

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART
1	757-241		Seat Ass'y. 10.0" Back	N
2	731-219		Steering Wheel 12." Dia.	N
3	731-220		Steering Wheel Cap	N
4	712-158		Hex Center Locknut 5/16-18 Thd.	
5	736-219		Belleville Washer .400 I.D. x 1.13 O.D.	
6	710-224		Hex AB-Tapp. Scr. #10 x .50" Lg.	
7	746-177		Throttle Control 53.0" Lg.	
8	11375		Steering Box	
9	710-224		Hex AB-Tapp. Scr. #10 x .50" Lg.	
10	11373		Steering Box—Top Cover	
11	712-429		Hex Inserted Locknut 5/16-18 Thd.	
12	736-159		Flat Washer .344 I.D. x .88 O.D.	
13	10358		Handle Stop	
14	11249		Plastic Knob—For Handle Stop	
15	738-234		Shoulder Scr .500 Dia. x .295	
16	735-126		Rubber Washer .33 I.D. x .87 O.D.	
17	10818		Steering Box—Front Cover	
18	720-142		Flat Bar End Grip	
19	738-234		Shoulder Scr. .500 Dia. x .295	
20	712-107		Hex Center Locknut 1/4-20 Thd.	
21	10614		Pedal Pad—Vinyl	
22	11379		Clutch Foot Pedal Rod Ass'y.	
24	736-119		Spring Lockwasher 5/16" Scr.*	
25	712-267		Hex Nut 5/16-18 Thd.*	
26	712-798		Hex Nut 3/8-16 Thd.*	
27	736-169		Spring Lockwasher 3/8" Scr.*	
28	10832		Brake Lever Bracket	
29	736-232		Wave Washer .530 I.D. x .78 O.D.	
30	10064		Lockout Link Ass'y.	
31	11277		Lockout Lever	
32	10810—458		Fender L.H. (133-430 & 435 Only)	
33	712-287		Hex Nut 1/4-20 Thd.*	
34	736-329		Spring Lockwasher 1/4" Scr.*	
35	710-134		Carriage Bolt 1/4-20 x .62" Lg.*	
36	748-227		Hex Flange Bearing .630 I.D. Bronze	
37	711-198		Pivot Bushing (Tie Rod End)	
38	9709—458		Front Wheel Axle Ass'y.—L.H.	
39	11376—458		Front Pivot Bracket	
40	710-198		Hex Sems Scr. 5/16-18 x .75" Lg.*	
41	712-923		Hex Center Locknut 5/8-18 Thd.	
42	736-158		Spring Lockwasher 5/8" Scr.*	
43	9922		Steering Shaft Assembly	
44	748-227		Hex Flange Bearing .630 I.D. Bronze	
45	711-335		Tie Rod	
46	9706—458		Front Wheel Axle Ass'y.—R.H.	
47	734-483		Front Wheel Ass'y.—Comp. 10.5 x 3.50	N
	734-484		Front Wheel—Tire Only 10.5 x 3.50	N
48	734-486		Front Wheel Rim Ass'y. Only (Includes Hub)	N
49	711-169		Collar 5/8" I.D.	
50	710-494		Sq. Hd. Set Scr. 5/16-18 x .38" Lg. Cup	
51	710-134		Carriage Bolt 1/4-20 x .62" Lg.*	
52	10806—458		Fender Brace (133-430 & 435 Only)	
53	714-507		Cotter Pin 3/32" Dia. x 1.00" Lg.*	
54	736-329		Spring Lockwasher 1/4" Scr.*	
55	712-287		Hex Nut 1/4-20 Thd.*	
56	710-312		Hex Hd. Cap Scr. 5/8-18 x 1.31" Lg.	
57	9711—458		Pivot Bar Assembly	
58	710-252		Hex Hd. Cap Scr. 1/4-20 x .75" Lg.*	
59	712-287		Hex Nut 1/4-20 Thd.*	
60	726-221		Push Cap 1/2" Dia.	
61	735-117		Floor Mat 3/32"—Running Board	
62	736-921		Spring Lockwasher 1/2" Scr.*	

\*For faster service obtain standard nuts and bolts locally. If these items cannot be obtained locally, order by part number and size as shown on the parts list.

When ordering parts if color or finish is important, use the appropriate color code shown at left (e.g. Arctic Blue Flake finish—10057 (458)).

The engine is not under warranty by the mower manufacturer. If repairs or service is needed on the engine, please contact your nearest authorized engine service outlet. Check the "Yellow Pages" of your telephone book under "Engines—Gasoline."




**PARTS LIST FOR FIGURE 12 (CONTINUED)**

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART
63	712-206		Hex Nut 1/2-13 Thd.*	
64	736-119		Spring Lockwasher 5/16" Scr.*	
65	712-267		Hex Nut 5/16-18" Thd.*	
66	11168		Lift Bracket	
67	736-329		Spring Lockwasher 1/4" Scr.*	
68	712-287		Hex Locknut 1/4-20 Thd.*	
69	710-289		Hex Hd. Cap Scr. 1/4-20 x .50" Lg.*	
70	712-267		Hex Nut 5/16-18 Thd.*	
71	736-119		Spring Lockwasher 5/16" Scr.*	
72	738-140		Shoulder Scr. .437" Dia. x .180	
73	9721-458		Pivot Link Assembly	
74	711-332		Lift Bracket Pin	
75	9761-458		Deck Link Assembly	
76	736-192		Flat Washer .531 I.D. x .93 O.D.	
77	714-101		Internal Cotter Pin 1/2" Dia.	
78	9735-458		Connecting Rod 3/16 x 1.0 x 12.5" Lg.	
79	710-260		Carriage Bolt 5/16-18 x .62" Lg.*	
80	9737-458		Link Slotted	
81	11830-458		Lift Shaft Assembly	N
82	11831-458		Lift Hub Assembly	N
83	750-195		Roller—Spacer .505 I. D. x .628 O.D.	N
84	11827-458		Handle Lift Bracket Ass'y.	N
86	738-234		Shoulder Scr. .500" Dia. x .295	
87	738-213		Shoulder Screw .498" Dia. x 1.450	
88	710-258		Hex Hd. Cap Scr. 1/4-20 x .62" Lg.*	
89	11825-458		Index Bracket	N
90	725-268		Safety Switch (133-434 & 435)	
	725-269		Safety Switch (133-430 Only)	
91	736-329		Spring Lockwasher 1/4" Scr.*	
92	712-287		Hex Nut 1/4-20 Thd.*	
93	710-559		Hex Hd. Cap Scr. 1/4-28 x 1.75" Lg.*	
94	732-231		Torsion Spring	N
95	736-169		Spring Lockwasher 3/8" Scr.*	
96	712-117		Hex Center Lock Nut 1/4-28 Thd.	
97	715-107		Spring Pin Spirol 5/16" Dia. x 1.38" Lg.	N
98	712-798		Hex Nut 3/8-16 Thd.*	
99	11826		Lift Handle	
100	720-143		Grip Black—Lift Handle	
101	736-242		Belleville Washer .345 I.D. x .88 O.D.	
102	710-0568		Hex Hd. Cap Scr. 5/16-18 x .75 <del>62-Speciet</del>	
103	734-517		Rear Wheel Rim Ass'y. Only (Includes Hub)	N
104	734-523		Rear Wheel Ass'y.—Comp. 13.0 x 5.0	N
	734-298		Rear Wheel Tire Only 13.0 x 5.0	N
105	10809-458		Fender R.H. (133-430 & 435 Only)	
106	<del>735-19</del> 748-0151		Flange Bearing <del>with Flats</del>	
107	713-357 713-723		#41 Chain 1/2" Pitch x 67 Links #41 Master Link 1/2" Pitch Type II	
108	10824-458		Engine Box Side Panel—R.H.	
109	10827-458		Engine Box Top Panel	
110	722-115		Ball Knob—Black 1 1/8 x 3/8-16 Thd.	
111	720-143		Grip Black—Lift Handle	
112	10826-458		Engine Box—Front Panel	
113	710-198		Hex Sems Scr. 5/16-18 x .75" Lg.*	
114	748-151		Flange Bearing with Flats .753 I.D.	
115	10470		Bearing Plate	
116	10471		Rear Axle Support Brkt. Ass'y.	
117	710-198		Hex Sems Scr. 5/16-18 x .75" Lg.*	
118	736-119		Spring Lockwasher 5/16" Scr.*	

\*For faster service obtain standard nuts and bolts locally. If these items cannot be obtained locally, order by part number and size as shown on the parts list.

When ordering parts if color or finish is important, use the appropriate color code shown at left (e.g. Arctic Blue Flake finish—10057 (458)).

**Find It Fast  
in The  
'Yellow Pages'**



The engine is not under warranty by the mower manufacturer. If repairs or service is needed on the engine, please contact your nearest authorized engine service outlet. Check the "Yellow Pages" of your telephone book under "Engines—Gasoline."

PARTS LIST FOR FIGURE 12 (CONTINUED)

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART
119	712-267		Hex Nut 5/16-18 Thd.*	
120	712-287		Hex Nut 1/4-20 Thd.*	
121	11053		(133-430 Only) Switch Bracket Ass'y.	
122	710-224		(133-430 Only) Hex AB-Tapp Scr. #10 x .50" Lg.	
123	11528-458		Engine Box Top Bezel (133-430 Only)	
	11527-458		Engine Box Top Bezel (133-434 & 435)	
124	712-121		Hex Nut #10-24 Thd. (133-430 Only)	
125	732-257		Switch Spring (133-430 Only)	
126	736-338		Fiber Washer (133-430 Only)	
127	710-425		Truss Hd. Mach. Scr. #10-24 x .62" (133-430)	
128	710-351		Truss Hd. Self Tap Scr. #10 x .50" Lg. (133-430)	
129	11263		Handle—Plastic (133-430 Only)	
130	10846		Shift Lever Assembly	
131	10060-458		Seat Bracket	
132	10825-458		Engine Box Side Panel—L.H.	
133	750-209		Steering Tube Assembly	N
134	9920		Steering Tube Spacer	
135	9921		Bearing Cap	
136	715-108		Spring Pin Spiral 1/4" Dia. x 1.00" Lg.	
137	9964		Steering Tube Spacer Ass'y. (Made up of Ref. No's. 134 and 135.)	
138	9963-458		Hitch Bracket (Not Shown)	
139	11228		Plastic Funnel (Not Shown)	
140	725-156		Battery Charger (Not Shown) (Electric Start Only)	N
141	736-105		Spring Lock Washer 3/8" Ser. #	BELLEVILLE WASHER
142	712-342		Hex Jam Nut 3/8-16 Thd.*	

#143 736-156 F.L. WASHER  
 144 736-134 F.L. WASHER


\*For faster service obtain standard nuts and bolts locally. If these items cannot be obtained locally, order by part number and size as shown on the parts list.

When ordering parts if color or finish is important, use the appropriate color code shown at left (e.g. Arctic Blue Flake finish—10057 (458) .



The engine is not under warranty by the mower manufacturer. If repairs or service is needed on the engine, please contact your nearest authorized engine service outlet. Check the "Yellow Pages" of your telephone book under "Engines—Gasoline."

**NOTE:** If for any reason disc brake is disassembled, be sure round end of push pins (Ref. No. 10) is toward the cam lever (Ref. No. 9).



**FIGURE 13. DECK AND FRAME VIEW**

**PARTS LIST FOR FIGURE 13. DECK AND FRAME VIEW**

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART	REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART
1	—		Engine		42	748-177		Sheave Half	
2	761-130		Disc Brake Ass'y. Complete		43	715-124		Spring Pin Spirol 5/32" Dia. x .62" Lg.	
3	710-378		Hex Hd. Cap Scr. 5/16-18 x 2.50" Lg.*		44	748-181		Moveable Sheave Ass'y.	
4	761-133		Spacer for Disc Brake .322 I.D. x .38		45	741-139		Ball Bearing .50 I.D. x 1.38 O.D.	
5	712-158		Hex Center Locknut 5/16-18 Thd.*		46	750-144		Steel Tubing	
6	06-1029-0000		Spring		47	750-146		Spacer .520 I.D. x .692 O.D.	
7	02-1011-0000		Hex Locknut		48	11237		Wheel Bracket Ass'y. L.H. (Deck)	
8	03-1030-0000		Washer		49	9733		Belt Guard (Deck)	
9	18-1687-0000		Cam Lever		50	732-153		Spring .750" O.D. x 8.65" Lg.	
10	05-1033-0000		Push Pin		51	11390		30 Inch Deck Ass'y.	
11	12-1984-0007		Casting Cam Side		52	9733		Belt Guard (Deck)	
12	03-1345-0000		Back-up Disc		53	9164		Deck Reinforcement Plate	
13	15-1154-1079		Friction Pad .450 Thick		54	736-119		Spring Lockwasher 5/16" Scr.*	
14	15-1154-1049		Friction Pad .250 Thick		55	712-267		Hex Nut 5/16-18 Thd.*	
15	12-1329-0000		Casting Carrier Side		56	736-329		Spring Lockwasher 1/4" Scr.*	
16	9785 10599		Variable Speed Brkt. Ass'y. Variable Speed Pulley & Brkt. Ass'y. Comp.		57	710-195		Hex Hd. Cap Scr. 1/4-28 x .62" Lg.*	
17	712-267		Hex Nut 5/16-18 Thd.*		58	712-123		Hex Nut 5/16-24 Thd.*	
18	736-119		Spring Lockwasher 5/16" Scr.*		59	736-119		Spring Lockwasher 5/16" Scr.*	
19	10804		Engine Brace Assembly		60	742-118		15 Inch Blade	
20	10173		Variable Speed Guide Brkt. Ass'y.		61	710-117		Hex Hd. Cap Scr. 5/16-24 x 1.00" Lg. Heat Treated	
21	10080		Variable Speed Rod		62	10769		Blade Adapter Kit	
22	710-134		Carriage Bolt 1/4-20 x .62" Lg.*		63	710-459		Hex Hd. Cap Scr. 3/8-24 x 1.50" Lg. Heat Treated	
23	761-148		Blade Brake Assembly		64	736-217		Spring Lockwasher 3/8" Scr. Heavy Duty	
24	732-191		Spring .75 O.D. x 11.0" Lg. (Variable Sp. Pedal)		65	10769		Blade Adapter Kit	
25	10438		Variable Speed Pulley Ass'y.		66	726-106		Push Nut 1/4" Rod	
26	10801—458		Fender Brace (133-430 and 435 Only)		67	711-571		Pivot Pin	
27	712-287		Hex Nut 1/4-20 Thd.*		68	732-261		Torsion Spring	
28	710-136		Hex Hd. Cap Scr. 1/4-20 x 1.75" Lg. (133-430 & 435 Only)		69	11399		Adapter Plate Ass'y.	
29	10057—458		Frame		70	11574		Chute Deflector Ass'y.	
30	711-404		Shoulder Nut		71	710-289		Hex Hd. Cap Scr. 1/4-20 x .50" Lg.*	
31	712-429		Hex Center Locknut 5/16-18 Thd.		72	738-119		Shoulder Scr. .625" Dia. x 1.75 (Axle Bolt)	
32	10078		Foot Pedal Rod—18.80" Lg.		73	712-116		Hex Inserted Locknut 3/8-24 Thd.	
33	712-287		Hex Nut 1/4-20 Thd.*		74	10937		Wheel Pivot Bar	
34	736-329		Spring Lockwasher 1/4" Scr.*		75	734-225		6.0 Inch Wheel Ass'y. (Deck)	
35	715-103		Spring Pin Spirol 1/8" Dia. .75" Lg.		76	736-105		Belleville Washer .400 I.D. x .88 O.D.	
36	11379—458		Clutch Foot Pedal Rod Ass'y.		77	10949		Spring Lever Ass'y. with Knob	
37	10848—458		Foot Pedal Latch Ass'y.		78	11236		Wheel Bracket Ass'y. R.H.	
38	732-245		Brake Spring		79	736-119		Spring Lockwasher 5/16" Scr.*	
39	11530		Blade Brake Disc Ass'y.		80	712-267		Hex Nut 5/16-18 Thd.*	
40	754-127		V-Belt 21/32 x 66.0" Lg.		81	714-365		#6 Hi-Pro Key 5/32 x 5/8" Dia.	
41	11914		30 Inch Deck Ass'y. Comp. (Includes deck, blades, pulley, belt, belt guards and wheels)	N	82	711-255		Blade Spindle	

\*For faster service obtain standard nuts and bolts locally. If these items cannot be obtained locally, order by part number and size as shown the parts list.

458—Arctic Blue Flake

When ordering parts if color or finish is important, use the appropriate color code shown at left (e.g. Arctic Blue Flake finish—10057 (458)).

The engine is not under warranty by the mower manufacturer. If repairs or service is needed on the engine, please contact your nearest authorized engine service outlet. Check the "Yellow Pages" of your telephone book under "Engines—Gasoline."

**Find It Fast  
In The  
'Yellow Pages'**



**PARTS LIST FOR FIGURE 13 (CONTINUED)**

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART	REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART
83	9321		Blade Spindle Ass'y.		107	710-117		Hex Hd. Cap Scr. 5/16-24 x 1.00" Lg. Heat Treated	
84	741-919		Ball Bearing .787 I.D. x 1.85 O.D.		108	9780—458		Transmission Belt Guard Ass'y.	
85	8253		Housing—Bearing		109	747-109		Brake Rod .25" Dia. x 31.62" Lg.	
86	736-162		Flat Washer .641 I.D.		110	732-118		Extension Spring (Brake)	
87	710-322		Hex Sems Scr. 5/16-18 x 1.00" Lg.*		111	10245—458		Disc Brake Brkt. Ass'y.	
88	710-152		Hex Hd. Cap Scr. 5/16-24 x 1.00" Lg. Heat Treated		112	712-429		Hex Inserted Locknut 5/16-18 Thd.	
89	736-217		Spring Lockwasher 3/8" Scr. Heavy Duty		113	711-404		Shoulder Nut	
90	736-235		Flat Washer .406 I.D. x 1.25 O.D.		114	732-192		Spring .88 O.D. x 3.75 (Var. Drive)	
91	712-922		Hex Jam Nut 1/2-20" Thd.		115	710-322		Hex Sems Scr. 5/16-18 x 1.00" Lg.*	
92	736-921		Spring Lockwasher 1/2" Scr.*		116	714-365		#6 Hi-Pro Key 5/32 x 5/8" Dia.	
93	712-242		Hex Jam Nut 5/8-11 Thd. (Deck)		117	710-442		Hex Hd. Cap Scr. 5/16-18 x 1.50" Lg. Heat Treated	
94	756-124		Pulley 4.75 O.D. (Deck)		118	715-119		Spring Pin Spirol 5/32" Dia. x .75" Lg.	
95	754-136		V-Belt 21/32 x 31" Lg. (For Transmission Pulley)		119	714-129		#4 Hi-Pro Key 3/32 x 5/8" Dia. Hardened	
96	756-174		Split Transmission Pulley .50 I.D.		120	710-198		Hex Sems Scr. 5/16-18 x .75" Lg.*	
97	712-267		Hex Nut 5/16-18 Thd.*		121	10247—458		Transmission Plate	
98	736-119		Spring Lockwasher 5/16" Scr.*		122	717-223		Transmission Ass'y. Comp.	
99	754-135		V-Belt 21/32 x 25" Lg. (From Eng. Pulley to Var. Sp. Pulley)		123	10404		Engine Brace	
100	10424		Belt Guard Cup Ass'y. (For Eng. Pulley)		124	712-429		Hex Inserted Locknut 5/16-18 Thd.	
101	756-142		Two Step Engine Pulley		125	737-104		Sq. Hd. Pipe Plug 1/4" (For Eng. Oil Drain Not Shown)	
102	10426		Belt Keeper Assembly		126	737-114		Pipe Nipple 3/8-1/4 x 3.0" Lg. (For Eng. Oil Drain Not Shown)	
103	11382—458		Clutch Bar Rod		127	11378		Brake Foot Pedal Rod	
104	710-322		Hex Sems Scr. 5/16-18 x 1.00" Lg.*		128	715-131		Spring Pin Roll 1/4" Dia. x 2.50" Lg.	
105	710-198		Hex Sems Scr. 5/16-18 x .75" Lg.*						
106	712-267		Hex Nut 5/16-18 Thd.*						


\*For faster service obtain standard nuts and bolts locally. If these items cannot be obtained locally, order by part number and size as shown on the parts list.

458—Arctic Blue Flake

When ordering parts if color or finish is important, use the appropriate color code shown at left (e.g. Arctic Blue Flake finish—10057 (458)).

The engine is not under warranty by the mower manufacturer. If repairs or service is needed on the engine, please contact your nearest authorized engine service outlet. Check the "Yellow Pages" of your telephone book under "Engines—Gasoline."

Find It Fast  
In The  
**'Yellow Pages'**








FIGURE 14. BATTERY BOX BREAKDOWN

PARTS LIST FOR FIGURE 14 BATTERY BOX BREAKDOWN

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART	REF. NO.	PART NO.	DESCRIPTION	NEW PART
1	735-109		Stem Bumper		11	710-252	Hex Hd. Cap Scr. 1/4-20 x .75" Lg.* (133-434 & 435)	
2	10062-458		Battery Box Bracket Ass'y.		12	725-117	Battery Dry 12 Volt with Acid Pack (133-434 & 435)	
3	10060-458		Seat Bracket		13	710-322	Hex Sems Scr. 5/16-18 x 1.00" Lg.*	
4	712-267		Hex Nut 5/16-18 Thd.*		14	736-119	Spring Lockwasher 5/16" Scr.*	
5	736-159		Flat Washer .344 I.D. x .88 O.D.		15	712-267	Hex Nut 5/16-18 Thd.*	
6	735-127		Rubber Washer .33 I.D. x .87 O.D.		16	10059-458	Battery Box	
7	710-198		Hex Sems Scr. 5/16-18 x .75" Lg.*		17	710-216	Hex Hd. Cap Scr. 3/8-16 x .75" Lg.*	
8	712-287		Hex Nut 1/4-20 Thd.* (133-434 & 435)		18	736-169	Spring Lockwasher 3/8" Scr.*	
9	736-329		Spring Lockwasher 1/4" Scr.* (133-434 & 435)					
10	725-150		Battery Ground Wire (133-434 & 435)					

\*For faster service obtain standard nuts and bolts locally. If these items cannot be obtained locally, order by part number and size as shown on the parts list.




FIGURE 15. ELECTRICAL SYSTEM (ELECTRIC START MODEL)

PARTS LIST FOR ELECTRIC START MODEL

REF. NO.	PART NO.	DESCRIPTION
1	725-117	Battery
2	725-122	Wire
3	725-179	Key Only for Switch
4	725-268	Safety Switch (Black)
5	725-270	Solenoid—Cole #24022
6	725-280	Wire Harness
7	725-150	Wire
8	725-267	Switch
9	725-156	Battery Charger 1 1/4 Amps. (Not Shown)




FIGURE 16. ELECTRICAL SYSTEM (RECOIL START MODEL)

PARTS LIST FOR RECOIL START MODEL

REF. NO.	PART NO.	DESCRIPTION
1	725-128	Key Only for Switch
2	725-269	Safety Switch (Red)
3	725-281	Wire Harness
4	725-266	Switch




FIGURE 17. SINGLE SPEED TRANSMISSION PART NO. 717-223

PARTS LIST FOR FIGURE 17

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART	REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART
1	716-104		Snap Ring		13	710-195		Hex Hd. Cap Scr. 1/4-28 x .62*	
2	748-852		Sprocket 8T #41		14	741-862		Detent Ball	
3	714-129		Key Hi-Pro #4		15	732-863		Detent Spring	
4	711-854		Shaft Output		16	736-116		Washer	
5	714-126		Key Hi-Pro #606 (Hardened)		17	716-106		E-ring	
6	717-123		Housing Half		18	716-865		Snap Ring #3100-50	
7	748-855		Bearing		19	748-866		Bevel Pinion	
8	712-117		Locknut 1/4-28 Thd.*		20	748-867		Bearing	
9	748-856		Bevel Gear		21	738-159		Pinion Shaft	
10	748-857		Clutch Collar		22	736-192		Washer	
11	8583		Detent Shaft Assembly		23	736-921		Lockwasher 1/2"	
12	717-124		Housing Half with Detent Hole		24	712-922		Hex Jam Nut 1/2-20 Thd.*	
					25	737-120		Grease High Temp. 450°F. (5 oz.)	N

\*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally order by part number and size as shown on parts list.




FIGURE 18. DIFFERENTIAL ASSEMBLY

PARTS LIST FOR FIGURE 18 DIFFERENTIAL  
PART NUMBER 717-271

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART
1	710-363		Hex Hd. Cap Scr. 5/16-24 x 4.00" Lg.*	
2	719-150		Differential Housing	
3	748-169		Sleeve Bearing	
4	736-188		Washer	
5	738-192		Shaft—Long	N
6	748-185		Motor Gear Double "D" Hole	
7	736-187		Flat Washer	
8	716-101		Snap Ring for .750 Shaft	
9	738-191		Shaft—Short	N
10	9054		Sprocket	
11	712-237		Hex Center Locknut 5/16-24 Thd.	
12	711-276		Drive Pin	
13	748-158		Miter Gear Round Hole	
14	715-123		Dowel Pin 3/16" Dia. x 5/8" Lg.	
15	736-119		Spring Lockwasher 5/16" Scr.*	

Lubricate with grease—High Temp. 450° F (5 oz.)  
#737-120.

N

\*For faster service obtain standard nuts, bolts, and washers locally. If these items cannot be obtained locally, order by part number and size as shown on the parts list.

## BATTERY WARRANTY CERTIFICATE

The following general warranty policy applies to all batteries sold by IBMA members using this warranty. The nationwide warranty applies only to batteries bearing the IBMA seal of approval.

All new batteries sold by IBMA members carry a warranty against faulty material or workmanship for 90 days from date of purchase. A faulty battery is to be adjusted, repaired or replaced with a new battery by an IBMA member, jobber or dealer only, or the warranty becomes void. An IBMA type battery that is faulty within the 90 day period is to be repaired or replaced with a new battery F.O.B. any IBMA factory supplier or any IBMA authorized dealer, without charge.

Your battery carries a further warranty on a pro-rata adjustment basis covering the number of months determined by the class of service and type of battery. In determining the exchange cost of a new battery, charges will be made for months of service used and the warranty is valid to the original purchaser only.

IBMA approved factory suppliers, as well as all IBMA authorized dealers, are to honor this Warranty. If your IBMA approved battery carries the IBMA seal of approval, this Warranty is to be honored by dealers handling IBMA approved batteries everywhere. (Independent Battery Manufacturers Association, Inc.)

Failures in service that are caused by fire, collision, freezing, abuse, faulty electrical equipment or the use of a battery of a group size smaller or specifications lower than the original battery are not covered by this policy.

## BATTERY MANUFACTURER MEMBERSHIP LIST

<b>ALABAMA</b>	Express Bty. Div.	Contract Bty. Mfg.	Shreveport	Maryland Heights	<b>OREGON</b>	Memphis
Birmingham	Leath Brothers	Yocam Batteries	Central Bty.	Electro Bty. Mfg.	Beaverton	Central Battery
Southern Bty.	<b>FLORIDA</b>	<b>ILLINOIS</b>	<b>MARYLAND</b>	Sikeston	Western Bty., Inc.	Laher Bty. Prod.
Yocam Batteries	Fort Lauderdale	Belleville	Baltimore	Electro Bty.	Portland	Southern Bty.
Mobile	Florida Bty.	Bell City Bty. Mfg.	East Penn Mfg.	<b>NEW JERSEY</b>	Laher Bty. Prod.	Nashville
Yocam Batteries	Hialeah	Chicago	<b>MASSACHUSETTS</b>	Atlantic City	<b>PENNSYLVANIA</b>	Electro-Lite Bty.
Montgomery	East Penn Mfg.	Illinois Bty. Mfg.	Watertown	Landis Battery		Southern Bty.
Ebco Battery	Jacksonville	Universal Bty.	Atlantic Bty.	<b>NEW MEXICO</b>		<b>TEXAS</b>
<b>ALASKA</b>	Tropex Batteries	Volta Bty. Corp.	<b>MICHIGAN</b>	Albuquerque	Altoona	Dallas
Anchorage	Yocam Batteries	<b>Peoria</b>	Detroit	Sandia Bty. Mfg.	East Penn Mfg.	Continental Bty.
Alaska Husky Bty.	Miami	Red Diamond Bty.	Batteries Mfg.	<b>NEW YORK</b>	Erie	Reliable Battery
<b>ARKANSAS</b>	Tropex Batteries	<b>INDIANA</b>	Flint	Buffalo	New Castle Bty.	El Paso
Hot Springs	Yocam Batteries	Muncie	ABC Batteries	East Penn Mfg.	Lancaster	El Paso Bty.
Red Diamond Bty.	Orlando	Stout Storage Bty.	Holly	Lockport	Lancaster Bty.	Houston
<b>CALIFORNIA</b>	Yocam Batteries	<b>IOWA</b>	Detroit Battery	Great Lakes Battery	Lyon Station	Texford Bty. Co.
Los Angeles	Pensacola	Corydon	Madison Heights		East Penn Mfg.	Reliable Battery
Estee Battery	Yocam Batteries	Voltmaster	C & W Lektra	<b>NORTH CAROLINA</b>	New Castle Bty.	San Antonio
Laher Bty. Prod.	St. Petersburg	Council Bluffs	Warren	Charlotte	New Castle Bty.	Reliable Battery
Oakland	Electro Battery Co.	Reliance Bty. Prod.	G & M Battery	Yocam Batteries	Philadelphia	UTAH
Laher Bty Prod.	Tampa	Des Moines	<b>MINNESOTA</b>	Thomasville	East Penn Mfg.	Salt Lake City
Sacramento	Bilt-Rite Bty. Mfg.	Voltmaster	St. Paul	East Penn Mfg.	Pittsburgh	Laher Bty. Prod.
Laher Bty. Prod.	Contract Bty. Mfg.	<b>KANSAS</b>	Standard Storage Bty.	Geidel Bty. Div.	Simon Bty. & Res.	<b>VIRGINIA</b>
San Francisco	DeSoto Bty. & Elec.	Kansas City	<b>MISSISSIPPI</b>	<b>RHODE ISLAND</b>	East Penn Mfg.	Arlington
Amp King Bty.	Tropex Batteries	American Batteries	Florence	Providence	Pittsburgh	Express Bty. Div.
Laher Bty. Prod.	Yocam Batteries	Contract Bty. Mfg.	Contract Bty. Mfg.	Pilof Mfg., Inc.	Simon Bty. & Res.	Leath Bros.
Pico Bty. Mfg.	<b>GEORGIA</b>	<b>KENTUCKY</b>	Jackson	<b>SOUTH CAROLINA</b>	Geidel Bty. Div.	Lynchburg
Stockton	Albany	Whitesburg	Central Bty.	Columbia		Hydrate Battery
Stockton Battery	Ebco Battery	Electro-Lite Bty.	New Albany	Yocam Batteries		<b>WASHINGTON</b>
<b>COLORADO</b>	Atlanta	<b>LOUISIANA</b>	Laher Bty. Prod.	Tennessee		Seattle
Denver	Ebco Battery	New Orleans	<b>MISSOURI</b>	Chattanooga		Laher Bty. Prod.
Moore Battery	Southern Bty.	Central Bty.	Joplin	Electro-Lite Bty.		Spokane
D. C.	Yocam Batteries	Reliable Bty.	Lead Products	Knoxville		Laher Bty. Prod.
Washington	Columbus			Southern Bty.		<b>CANADA</b>
	Ebco Battery					Vancouver, B. C.
						Industrial Bty. & Supply

## WARRANTY

For one year from date of purchase, MTD Products Inc will replace for the original purchaser, free of charge, F.O.B. factory or authorized service firm, any part or parts found to be defective in material or workmanship. All transportation charges on parts submitted for replacement under this warranty must be paid by the purchaser. This warranty does not include replacement of parts which become inoperative through misuse, excessive use, accident, neglect, improper maintenance or alterations by unauthorized persons. This warranty does not include the engine, motor, battery, battery charger or any component parts thereof. For service on these units refer to the applicable manufacturer's warranty.

The above warranty will apply only to the original owner and will be effective only if the warranty card has been properly processed. It will not apply where the unit has been used commercially.

Warranty service is available through your local authorized service dealer or distributor. **UNDER NO CIRCUMSTANCES WILL THE RETURN OF A COMPLETE UNIT BE ACCEPTED BY THE FACTORY UNLESS PRIOR WRITTEN PERMISSION HAS BEEN EXTENDED.**

# PARTS INFORMATION

**DEFECTIVE OR MISSING PARTS** must be reported to the factory immediately. Such claims must include your model number and date of purchase.

## **MOWER, TILLER, SNOW THROWER, TRACTOR, TRAIL BIKE AND MUD BUG PARTS**

Mower, tiller, snow thrower, tractor, trail bike and mud bug parts are available through the authorized service firms listed below. All orders should specify the model number of your unit, parts numbers, de-

scription of parts and the quantity of each part required.

## **BRIGGS & STRATTON, TECUMSEH AND PEERLESS PARTS AND SERVICE**

Briggs & Stratton, Tecumseh and Peerless parts and service should be handled by your nearest authorized engine service firm. Check the yellow pages of your telephone directory under the listing *Engines — Gasoline*, Briggs & Stratton or Tecumseh Lauson — Power Products.

**A 1 Engine & Mower Co.**  
327 East 9th Street  
Salt Lake City, Utah 84102

**American Electric Ignition Co.**  
124 N. W. 8th Street  
Oklahoma City, Oklahoma 73102

**Auto Electric & Carburetor Co.**  
2625 4th Avenue, S.  
P. O. Box 1948  
Birmingham, Alabama 35233

**Automotive Equipment Service Co.**  
3117 Holmes Street  
Kansas City, Missouri 64109

**Bailey's Rebuild Inc.**  
1325 E. Madison Street  
Seattle, Washington 98102

**Brown Equipment Distributor Inc.**  
110 Beech Street  
Corydon, Indiana 47112

**Bullard Supply**  
2409 Commerce Street  
Houston, Texas 77003

**Catto & Putty, Inc.**  
P. O. Box 2408  
510 Soledad Street  
San Antonio, Texas 78205

**Center Supply Company**  
6867 New Hampshire Avenue  
Takoma Park, Maryland 20012

**Charles B. Wright Co.**  
309 4th Avenue, South  
Nashville, Tennessee 37201

**W. B. Clements**  
400 Salem Avenue  
Roanoke, Virginia 24016

**Morton B. Collins Co.**  
300 Birnie Avenue  
Springfield, Massachusetts 01107

**Dixie Sales Company**  
P. O. Box 1408  
327 Battleground Avenue  
Greensboro, North Carolina 27402

**East Point Cycle & Key Shop**  
1617 Whiteway  
East Point, Georgia 30044

**Gamble Distributors**  
West End Avenue  
Carthage, New York 13619

**Garden Equipment Co., Inc.**  
6600 Cherry Avenue  
Long Beach, California 90805

**Henzler, Inc.**  
2015 Lemay Ferry Road  
St. Louis, Missouri 63125

**Frank E. Ives & Son**  
1101 Lincoln Avenue  
Prospect Park, Pennsylvania 19076

**J. W. Jewett Co.**  
981 Folsom Street  
San Francisco, California 94107

**Kenton Supply**  
8216 North Denver Avenue  
Portland, Oregon 97217

**Kimber's Inc.**  
115 W. Geddes St.  
Syracuse, New York 13204

**The Lawnmower Shop**  
1340 El Camino Real  
San Carlos, California 94070

**Marr Brothers**  
423 E. Jefferson  
Dallas, Texas 75203

**Mathews Auto Electric Co.**  
420 East 2nd Street  
Tulsa Oklahoma 74120

**McClure Lawn & Garden Supply**  
1114 Lexington Avenue  
Mansfield, Ohio 44907

**Memphis Cycle & Supply Co.**  
421 Monroe Avenue  
Memphis Tennessee 38103

**Moz-All of Florida, Inc.**  
365 Greco Avenue  
Coral Gables, Florida 33146

**National Central, Div. of  
Joe Sterling, Inc.**  
Drawer "D" 687 Seville Rd.  
Wadsworth, Ohio 44281

**Power Equipment Distributor**  
36463 So. Gratiot Avenue  
Mt. Clemens, Michigan 48043

**Parts & Sales Inc.**  
2101 Industrial Pkwy.  
Elkhart, Indiana 46514

**Parts & Sales Inc.**  
335 West St. Charles Road  
Villa Park, Illinois 60181

**Power Lawn & Garden Equip. Co.**  
2551-2571 J. F. Kennedy Road  
Dubuque, Iowa 52001

**Raub Supply Company**  
James & Mulberry Sts.  
Lancaster, Pennsylvania 17604

**Radco Distributors**  
2403 Market Street  
P. O. Box 3216  
Jacksonville, Florida 32206

**Richmond Battery & Ignition**  
P. O. Box 25369 — 957 Myers St.  
Richmond, Virginia 23260

**Smith Hardware Company**  
515 N. George Street  
Goldsboro, North Carolina 27530

**South Denver Lawn Equip. Co.**  
527 West Evans  
Denver, Colorado 80223

**Suhren Engine**  
8330 Earhart Blvd.  
New Orleans, Louisiana 70118

**Sutton's Lawn Mower Shop**  
Route 4, Box 343  
North Little Rock, Arkansas 72117

**Warner Equipment**  
7520 Lyndale Avenue, So.  
Minneapolis, Minnesota 55423

## **WARRANTY PARTS AND SERVICE POLICY**

The purpose of warranty is to protect the customer from defects in material and workmanship, defects which are not detected at the time of manufacture.

Our aim is to build into our product quality and reliability. Considerable emphasis is placed on quality control in order to assure our customer of satisfactory product performance. To achieve this goal, it is necessary to gain the cooperation of all concerned, MTD, our sales force and our customers.

MTD's responsibility is to build a quality product and to back up that product. MTD must build this quality product at a competitive price. This cannot be achieved without production in quantity. Quantity production is mass production. In mass production it is always possible for undetected defects to be present when the product reaches the customer. Our warranty is extended to assure the customer that any such defects will be corrected.

Use and maintenance are the responsibility of the customer. MTD cannot assume responsibility for conditions over which it has no control. MTD's responsibility does not cover misuse, excessive use, accident, neglect, improper maintenance or alterations by unauthorized persons. Satisfactory product performance can only result when a manufacturer provides and backs up a quality product and the customer follows through with proper use and proper maintenance of that product. When both the manufacturer and the customer recognizes and assumes his responsibility, satisfactory product performance and customer satisfaction are assured.