

Owner's Operating Service Instruction Manual

10¢

**Model No.
136-400A**

- ASSEMBLY
- OPERATION
- REPAIR PARTS

26" RIDING MOWER

IMPORTANT

It is suggested that this manual be read in its entirety before attempting to assemble or operate. Keep this manual in a safe place for future reference and for ordering replacement parts.

This unit is shipped WITHOUT GASOLINE or OIL. After assembly, see operating section of this manual for proper fuel and amount.

SAFE OPERATION PRACTICES FOR RIDING VEHICLES

1. Know the controls and how to stop quickly—**READ THE OWNER'S MANUAL.**
2. Do not allow children to operate vehicle. Do not allow adults to operate it without proper instruction.
3. Do not carry passengers. **Keep children and pets a safe distance away.**
4. Clear work area of objects which might be picked up and thrown.
5. Disengage all attachment clutches and shift into neutral before attempting to start engine.
6. Disengage power to attachment(s) and stop engine before leaving operator position.
7. Disengage power to attachment(s) and stop engine before making any repairs or adjustments.
8. Disengage power to attachment(s) when transporting or not in use.
9. Take all possible precautions when leaving vehicle unattended such as disengaging power-take-off, lowering attachments, shifting into neutral, setting parking brake, stopping engine and removing key.
10. Do not stop or start suddenly when going uphill or downhill. Mow up and down face of steep slopes; never across the face.
11. Reduce speed on slopes and in sharp turns to prevent tipping or loss of control. Exercise extreme caution when changing direction on slopes.
12. Stay alert for holes in terrain and other hidden hazards.
13. Use care when pulling loads or using heavy equipment.
 - A. Use only approved drawbar hitch points.
 - B. Limit loads to those you can safely control.
 - C. Do not turn sharply. Use care when backing.
 - D. Use counterweight(s) or wheel weights when suggested in owner's manual.
14. Watch out for traffic when crossing or near roadways.
15. When using any attachments never direct discharge of material toward bystanders nor allow anyone near vehicle while in operation.
16. Handle gasoline with care—it is highly flammable.
 - A. Use approved gasoline container.
 - B. Never remove cap or add gasoline to a running or hot engine or fill fuel tank indoors. Wipe up spilled gasoline.
 - C. Open doors if engine is run in garage—exhaust fumes are dangerous. Do not run engine indoors.
17. Keep the vehicle and attachments in good operating condition, and keep safety devices in place. Use guards as instructed in owner's manual.
18. Keep all nuts, bolts, and screws tight to be sure the equipment is in safe working condition.
19. Never store the equipment with gasoline in the tank inside a building where fumes may reach an open flame or spark. Allow engine to cool before storing in any enclosure.
20. To reduce fire hazard keep engine free of grass, leaves or excessive grease.
21. The vehicle and attachments should be stopped and inspected for damage after striking a foreign object, and the damage should be repaired before restarting and operating the equipment.
22. Do not change the engine governor settings or overspeed the engine.
23. When using the vehicle with mower, proceed as follows:
 - (1) Mow only in daylight or in good artificial light.
 - (2) Never make a cutting height adjustment while engine is running if operator must dismount to do so.
 - (3) Shut engine off when removing grass catcher and/or unclogging chute.
 - (4) Check blade mounting bolts for proper tightness at frequent intervals.
24. Check grass catcher bags frequently for wear or deterioration. Replace with new bags for safety protection.
25. Look behind to make sure the area is clear before placing the transmission in reverse and backing up.

INDEX

Safe Operation Practices.....	2
Assembly Instructions.....	3
Controls.....	4
Operating Instructions.....	6
Starting the Engine.....	6
Maintenance and Adjustments.....	7
Belt Removal.....	9
Lubrication.....	11

Storage.....	12
Trouble Shooting Chart.....	13
Electrical Diagram.....	14
Exploded View of Differential.....	15
Repair Parts for Mower.....	16
Exploded View of Transmission.....	22
Parts Information.....	Back Cover

GRASS CATCHER Model No. 195-015A is available as optional equipment for the mowers shown in this manual.



The mower should not be operated without the entire grass catcher or chute deflector in place.



Under normal usage bag material is subject to wear, and should be checked periodically. Be sure any replacement bag complies with the mower manufacturer's recommendations.

For replacement bags, use only factory authorized replacement bag No. 764-0121.



After striking a foreign object, stop the engine. Remove wire from spark plug, thoroughly inspect the mower for any damage, and repair the damage before restarting and operating the mower.

The steering wheel with the necessary hardware are easily assembled to the machine.

TIRE PRESSURE

FOR SHIPPING PURPOSES, THE TIRES ON YOUR UNIT MAY BE OVER-INFLATED. TIRE PRESSURE SHOULD BE REDUCED BEFORE UNIT IS PUT INTO OPERATION. PRESSURE SHOULD BE APPROXIMATELY 15 P.S.I. EQUAL TIRE PRESSURE SHOULD BE MAINTAINED ON ALL TIRES. MAXIMUM TIRE PRESSURE IS 30 P.S.I.

ASSEMBLY



Reference to right-hand or left-hand side of machine is from the driver's seat facing forward.

STEERING WHEEL ASSEMBLY See figures 1, 2 and 3.



Due to vibration during shipment, it is possible that the steering shaft on your unit may have dropped to a position where alignment of parts is difficult. This must be kept in mind during the assembly operation.

1. Check the upper and lower hex bearings, be sure they are seated and in position. See figure 1.




FIGURE 1. STEERING ASSEMBLY

2. Place your hand under the front of the unit, push up on the steering shaft assembly.
3. Hold up the shaft assembly. Place the steering tube assembly on the shaft and start the hex screw through the hole. See figure 2.
4. Fasten the tubing assembly to the steering shaft assembly with hex screw and hex nut provided.
5. Place the cover over the steering tube assembly.
6. Place the steering wheel on the tubing assembly and fasten with belleville washer and hex nut. See figure 1.
7. Again, it may be necessary to raise the steering shaft assembly in order to put the hex nut on.
8. Place the steering wheel cap on by hand. See figure 3.




FIGURE 2. STEERING TUBE ASSEMBLY




FIGURE 3. STEERING WHEEL ASSEMBLY

CONTROLS See figures 4 and 7.

This manual should be read in its entirety before you operate your riding mower. The more you know and understand about the machine and its operation, the better job it will do for you. While reading the manual, compare the illustrations with your mower to familiarize yourself with the locations of various controls, lubrication points, attachments and adjustment features.

Study the operating instructions and safety precautions thoroughly to insure proper functioning of your mower and to prevent injury to yourself and others. Be sure to save this manual for future reference.

THROTTLE CONTROL

The throttle control is used to regulate the engine speed and to activate the choke on the engine. To get the maximum efficiency on cutting, the throttle should be in the FAST position when operating the mower. Pushing the throttle all the way forward, past FAST will choke the engine.

IGNITION KEY

Recoil Model. The key must be turned to the ON position before the recoil handle is pulled to start the engine. Remove the key when the mower is not in use. Turn the key to the left (to the OFF position) to stop the engine.




FIGURE 4. CONTROLS

LIFT AND DISENGAGEMENT LEVER

The lift and disengagement lever is used to raise and lower the cutting deck, set the cutting height, and disengage the cutting blades.

Move the lever to the right and move the lever all the way back and lock it to disengage the blades. The lever may be set in any one of the five cutting height positions.

INTERLOCKS (Not Shown)

An interlock safety switch is located on the clutch pedal and the lift and disengagement lever. The clutch pedal must be depressed down and locked.

The lift and disengagement lever must be in the STOP position (all the way back) before the engine can be started. Failure to follow these instructions will prevent starting.

GEAR SHIFT LEVER

The gear shift lever has three positions, FORWARD, NEUTRAL and REVERSE. The clutch pedal must be depressed and the riding mower must not be moving when shifting gears. Do not force the shift lever. Release the clutch pedal slightly to line up the shifting collar in the transmission. Then try to shift gears.

BRAKE

To operate the brake, depress the right pedal all the way down. To lock the brake in park position, depress the right pedal all the way down and lift the brake lock. Pedal will stay in the depressed position. To release the parking brake, depress the pedal.




FIGURE 5. BRAKE PEDAL LOCK

CLUTCH PEDAL

The clutch pedal on the left side when depressed, disengages the engine from the transmission. It can be held in the disengaged position by lifting the clutch lock. To stop the mower, depress the clutch and brake pedals. See figure 6.



FIGURE 6. CLUTCH PEDAL LOCK




FIGURE 7. CONTROLS

OPERATING INSTRUCTIONS

CAUTION

1. Keep all shields and guards in place.
2. Before leaving operator's position:
 - Shift controls into neutral
 - Set parking brake (Brake Lock)
 - Disengage attachment drive
 - Shut off engine
 - Remove ignition key
3. Wait for all movement to stop before servicing machine.
4. Keep people and pets a safe distance away from machine.

CAUTION

Parking brake **must** be disengaged before unit is put into motion.

NOTE

Unit is equipped with separate brake and clutch pedals. To efficiently stop, it is necessary to disengage the clutch when applying the brakes.

STARTING THE ENGINE

1. Be sure the crankcase is filled with oil as recommended in the engine manual and put regular gasoline in the gasoline tank.
2. Attach the wire to the spark plug.
3. Depress the clutch pedal and lock it down.
4. Move the lift and disengagement lever back to the disengaged position and lock it.
5. Set the throttle control lever in the CHOKE position.
6. Turn the ignition key to the ON position. Twist the recoil starter handle until it is free and pull it with a quick steady motion. After the engine starts, return the recoil starter handle. Twist it until it locks. See figures 8 and 9.

NOTE

If these instructions are not followed the engine will stop running when the clutch or blades are engaged.




FIGURE 8. RECOIL HANDLE




FIGURE 9. RECOIL HANDLE

Slowly return the throttle to the running position as soon as the engine starts.

7. To stop, turn the ignition key to the OFF position and remove the key when the rider is not in use.

PUTTING THE RIDING MOWER IN MOTION

1. Advance the throttle control from $\frac{3}{4}$ to full throttle to prevent strain on the engine and to operate the cutting blades.
2. Place the gear shift lever in either the FORWARD or REVERSE position.
3. Slowly release the clutch pedal.
4. To stop, depress the clutch and the brake pedals.
5. The blades can be engaged either while moving or while standing still. Move the lift and disengagement lever forward slowly until the blades are running.

STOPPING

Engine—Turn the ignition key to the left to the OFF position.

Rider—Depress the clutch and brake pedals.

Blades—Pull the lift and disengagement lever all the way back and lock it.

MAINTENANCE AND ADJUSTMENTS

THROTTLE CONTROL

To Check Operation:

1. Remove air cleaner.
2. Move throttle control lever to CHOKE position. The carburetor choke should be closed.
3. Move throttle control lever to STOP position. Lever should make good contact with stop switch.

To Adjust: See figure 10.

Place remote control lever on equipment in FAST (high speed) position.

Lever C on carburetor should be just touching choke arm at D. To adjust, loosen casing clamp screw A on blower housing. Move control casing B forward or backward until correct position is obtained. Tighten screw A.

Recheck operation of controls after adjustment. Replace air cleaner.




FIGURE 10. THROTTLE CONTROL ADJUSTMENT

CARBURETOR ADJUSTMENTS See figure 11.

Minor carburetor adjustment may be required to compensate for differences in fuel, temperature, altitude and load.

Initial Adjustment:

Turn needle valve clockwise to close it. Then open 2 turns. This initial adjustment will permit the engine to be started and warmed up before making final adjustment.




FIGURE 11. CARBURETOR ADJUSTMENT

Final Adjustment:

With engine running at normal operating speed (approximately 3000 RPM without load) turn needle valve clockwise until engine starts to lose speed (lean mixture). Then slowly turn needle valve counterclockwise past the point of smoothest operation, until engine just begins to run unevenly. This mixture will give best performance under load.

To check adjustment move engine control from SLOW to FAST speed. If engine tends to stall or die out, it usually indicates that the mixture is slightly lean and it may be necessary to open the needle valve slightly to provide a richer mixture. This richer mixture may cause a slight unevenness in idling.

CHAIN ADJUSTMENT See figure 12.

After the first five hours of operation the initial slack should be removed from the chain. The chain should be tight enough so that it deflects approximately 1/2" when it is depressed with the thumb.

To adjust:

The adjusting bolt is located under the frame, above the cutting deck on the right side of the mower.

Turn the adjusting bolt clockwise with an open end wrench until the chain reaches the proper tension.



If the transmission mounting plate will not slide forward to adjust the chain tension, it may be necessary to loosen the four nuts mounting the transmission to the frame.




FIGURE 12. CHAIN ADJUSTMENT



Deck was removed for photographing.

BRAKE ADJUSTMENTS See figure 13.

To adjust the brake tighten the locknut one-half turn and then test the brakes.

The brake is located by the right rear wheel inside the frame.




FIGURE 13. BRAKE ADJUSTMENT



Deck was removed for photographing.

BLADES



Disconnect the spark plug wire and remove the ignition key before removing the blades.

Sharp and balanced blades are essential for efficient mowing and long mower and engine life. When sharpening blades, file equal amounts of metal from each side. The blades should be balanced before they are reinstalled. An unbalanced blade will cause excessive vibration and undue wear on the mower and the engine. When reassembling, all parts must be installed in the proper order and fastened securely.

Remove the 3/8" bolt and lockwasher. Pull the blade and adapter off the mower deck. To remove the adapter from the blade, remove the two 5/16" bolts, lockwashers and nuts. See figure 14.




FIGURE 14. BLADE REMOVAL

MOWER DECK

The underside of the mower deck should be cleaned after each period of use as grass clippings, leaves, dirt and other matter will accumulate. This accumulation of grass clippings, etc., is undesirable as it will invite rust and corrosion and may cause an uneven discharge of grass clippings at the next mowing.

The deck may be cleaned by tilting the mower on its front wheels until the frame and the steering wheel supports the entire unit. Scrape clean with a suitable tool or by washing with a stream of water from a garden hose. Be sure to disconnect the spark plug wire and ground it while performing this maintenance.



To insure safe operation, ALL nuts and bolts must be checked periodically for correct tightness.

PREPARING FOR BELT REMOVAL

1. To prevent gasoline from leaking from the engine, remove the fuel tank cap, place a piece of thin plastic over the neck of the fuel tank and screw on the cap.
2. Disconnect the spark plug wire and ground it against the engine.

BELT REMOVAL See figures 15 through 19.

To Remove the Deck Belt

- Step 1. Put the lift and disengagement lever into the ENGAGED position.
- Step 2. Remove two belt keepers at the engine pulley. See figure 15.




FIGURE 15. REMOVAL OF BELT KEEPERS

- Step 3. Remove two belt keepers at the deck pulley and shoulder bolt. See figures 16 and 17.
- Step 4. DISENGAGE the deck and unhook the belt from the engine pulley.




FIGURE 16. REMOVAL OF DECK BELT KEEPERS




FIGURE 17. SHOULDER BOLT REMOVAL

- Step 5. ENGAGE the deck and remove the belt.

To Remove the Drive Belt:

- Step 1. Remove the two belt keepers at the engine pulley. DISENGAGE the deck and remove the belt.
- Step 2. ENGAGE the deck and unhook the deck springs.



CAUTION

Deck will drop when last bolt is removed in step 3.

- Step 3. Remove six hex screws, nuts and lockwashers holding the deck. See figure 18.
- Step 4. Remove the belt guard at the engine pulley. See figure 19.
- Step 5. Remove the nut and lockwashers at the idler pulley. See figure 19.
- Step 6. Remove the hex nut and lockwasher at the transmission pulley. Remove and replace the belt.



NOTE

When reassembling the transmission pulley, place hub side up.




FIGURE 18. DECK REMOVAL




FIGURE 19. ENGINE BELT GUARD REMOVAL

LUBRICATION See figure 20.

1. **Engine.** Maintain the engine oil according to the engine manual.

2. **Bearings.** The following bearings are oil impregnated and do not require lubrication, however, their normal life can be extended by lubricating them once a season with a light, non-detergent oil.
3. King Pin Bearings (total 4 bearings)
4. Rear Axle Bearings (total 3 bearings)
5. Front Wheel Bearings (total 4 bearings)
6. **Throttle Control and Cable.** Wipe oiled rag along entire length of cable.
7. **Chain.** Wipe oiled rag along entire length of chain.



Under extremely dusty conditions do not oil the chain.

8. **Linkage.** Oil all deck linkage and height adjustment linkage.
9. **Transmission.** Lubricated at the factory, does not require checking. Lubricate with 4 oz. of Lubriplate No. 310 if disassembled.
10. **Differential.** Lubricated at the factory, does not require checking. Lubricate with 2 oz. of grease High Temp. 450° F. if disassembled. If ordered from the factory use Part No. 737-0120.
11. **Steering.** Lubricate at least once a season with oil.




FIGURE 20. LUBRICATION POINTS

OFF-SEASON STORAGE



NOTE

Engines to be stored over 30 days should be completely drained of fuel to prevent gum deposits forming on essential carburetor parts, fuel filters, fuel lines and tank.


1. Remove all fuel from fuel tank. Run the engine until it stops from lack of fuel. The small amount of fuel that remains in the sump of the tank should then be removed by absorbing it with a clean, dry cloth.
2. While engine is still warm, drain oil from crankcase. Refill with fresh oil.
3. Remove spark plug, pour 1 ounce of SAE 30 oil into cylinder and crank slowly to distribute oil. To prevent accidental starting, DO NOT replace the spark plug.
4. Clean dirt and chaff from cylinder, cylinder head fins and blower housing.
5. Clean all grass from under side of deck.
6. Clean the air filter.
7. Place blocks under frame of mower so that the wheels are off the ground.
8. Cover all bare metal parts, such as the mowing edge of the blades, with grease to prevent rusting.
9. Cover the mower with a tarpaulin or other protective covering.

TROUBLE SHOOTING CHART

CAUTION: ALWAYS DISCONNECT SPARK PLUG BEFORE ATTEMPTING ANY REMEDY.

TROUBLE	LOOK FOR	REMEDY
Engine fails to start.	Safety System	<p>If the engine will not start be sure the clutch control is disengaged; blade controls disengaged, the throttle control is set and the key is turned on.</p> <p>A. Disconnect the yellow wire from the engine. This comes from the ignition switch.</p> <p>B. If the engine fails to start the problem is with the engine, not the safety system.</p> <p>C. If the engine starts, the problem is with the safety system. Check the yellow wire for a ground.</p> <p>D. Check the operation of the switch behind the recoil starter handle.</p> <p>E. If the engine stops when the clutch or blade is engaged, the recoil handle is not pushed into the receptacle and twisted a quarter turn.</p>
	Blocked fuel line or empty gas tank.	Clean fuel line; check fuel supply. Also check fuel shut-off valve.
	Defective spark plug.	<p>Spark plug lead wire disconnected.</p> <p>Faulty spark plug—spark should jump gap between control electrode and side electrode. If spark does not jump, replace spark plug.</p> <p>NOTE: Use insulated pliers to hold the spark plug wire.</p>
	Throttle setting.	Throttle control lever not in the starting position.
	Loose connections	Spark plug wire loose.
Hard starting or loss of power.	Dirty air cleaner.	Remove air cleaner and clean as outlined in Engine Manual .
	Carburetor improperly adjusted.	Review paragraph Carburetor Adjustment .
Excessive vibration.	Bent or damaged blade spindle.	Stop engine immediately; tighten all bolts and make all necessary repairs. If vibration continues, have the unit serviced by a competent repairman.
Unit fails to discharge grass.	Discharge chute clogged.	Clean discharge chute and inside of deck.
	Foreign object lodged in deck.	Remove object from deck. See CAUTION following step 1 in paragraph Operation .
Engine overheats.	Obstructions in air passages.	Remove any obstruction from air passages in shroud. Grass and dirt in engine shroud. Clean cooling fins.
	Oil level.	Fill crankcase to proper oil level.

136-400A




SCHEMATIC FOR ELECTRICAL SYSTEM

PARTS LIST FOR SCHEMATIC

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART
1	725-0269		Safety Switch Norm Closed—Red	
2	725-0266		Magneto Ignition Switch w/Nut	
3	725-0407		Wire Harness	
4	712-0121		Hex Nut #10-24	
5	710-0425		Truss Mach. Scr. #10-24 x .62	
6	736-0338		Fiber Washer	
7	732-0257		Switch Spring	
8	736-0225		Internal L-Wash. 5/8 I.D.	

*For faster service obtain standard nuts and bolts locally. If these items cannot be obtained locally, order by part number and size as shown on the parts list.

136-400A




PARTS LIST FOR DIFFERENTIAL ASSEMBLY 717-0328

Ref. No.	Part No.	Qty. Req'd.	Description	New Part
1	715-0247	2	Spring Pin Spir. 3/16" Dia. x 1.00" Lg.	
2	748-0185	2	Gear—Double "O" Hole	
3	738-0300	1	Shaft—Long 19.31" Lg.	N
4	736-0188	2	FI-Wash. .760 I.D. x 1.49 O.D.	
5	717-0341	2	Housing Half	N
6	736-0119	2	L-Wash. 5/16" Scr. *	
7	710-0363	2	Hex Scr. 5/16-24 x 4.00" Lg. *	
8	736-0187	2	FI-Wash. .640 I.D. x 1.24 O.D.	
9	748-0158	2	Gear—Round Hole	
10	711-0276	1	Drive Pin	
11	712-0237	2	Hex Cent. L-Nut 5/16-24 Thd.	
12	09054	1	Sprocket—40 Tooth	
13	738-0301	1	Shaft—Short 7.07" Lg.	N

*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

136-400A

IF YOU WRITE TO US ABOUT THIS ARTICLE
OR IF YOU ORDER REPLACEMENT PARTS AL-
WAYS MENTION THIS MODEL & SERIAL NO
MODEL



PARTS LIST FOR MODEL 136-400A RIDING MOWER

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART
1	757-0265		Seat Comp.	N
2	12131	—462	Cover Ass'y.	
3	11263		Plastic Handle	
4	710-0425		Truss Mach. Scr. #10-24 .62" Lg.*	
5	736-0338		Fiber Washer	
6	712-0121		Hex Nut #10-24 Thread	
7	11053		Switch Brkt. Ass'y.	
8	712-0344		Speed Nut #10Z	
9	732-0257		Switch Spring	
10	710-0351		Truss Mach. B-Tapp. Scr. #10 x .50" Lg.*	
11	712-0429		Hex Ins. L-Nut 5/16-18 Thd.	
12	12144		Latch—Engine Cover	
13	725-0128		Ignition Key	
14	725-0266		Ignition Switch	
15	723-0241		Foot Pad	
16	710-0351		Truss Mach. B-Tapp. Scr. #10 x .50" Lg.*	
17	12175	—452	Cover Plate	
18	710-0227		Hex Wash. Hd. AB Tapp. Scr. #8 x .38" Lg.	
19	710-0351		Truss Mach. B-Tapp. Scr. #10 x .50" Lg.*	
20	12128	—462	Floor Pan	
21	746-0239		Throttle Control—R.H.	
22	12150	—462	Index and Support Brkt.	
23	12125	—452	Main Frame	
24	710-0198		Hex Sems Scr. 5/16-18 x .75" Lg.*	
25	12142		Deck Lift Handle Ass'y.	
26	720-0143		Grip	
27	712-0158		Hex Cent. L-Nut 5/16-18 Thd.	
28	723-0241		Foot Pad	
29	736-0119		L-Wash. 5/16" Scr.*	
30	712-0267		Hex Nut 5/16-18 Thd.	
31	732-0118		Extension Spring	
32	710-0352		Hex B-Tapp. Scr. 1/4 x .38" Lg.*	
33	738-0155		Shld. Scr. .437 Dia. x .162	
34	736-0225		Internal L-Wash. 5/8 I.D.	
35	726-0141		Adjustment Clamp	

WHEEL CHART

FRONT WHEEL		REAR WHEEL	
734-0510	Wheel Ass'y.—Comp.	734-0522	Wheel Ass'y.—Comp.
10152	Rim with Hub Ass'y.	734-0517	Rim with Hub Ass'y.
748-0146	Bearing	734-0301	Tire Only 12.2 x 3.7
—	Hub Part of Rim	—	Hub Part of Rim
		734-0255	Air Valve

*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

(462—Red Flake)


When ordering parts, if color or finish is important use the appropriate color code shown above (e.g. Red Flake Finish—12131 (462).)

NOTE: The engine is not under warranty by the mower manufacturer . . . If repairs or service is needed on the engine, please contact your nearest authorized engine service outlet. Check the "Yellow Pages" of your telephone book under "Engines—Gasoline."



136-400A

NOTE: If for any reason Disc Brake is disassembled, be sure round end of push pins (Ref. No. 88) is toward the cam lever (Ref. No. 86).



FRAME VIEW

PARTS LIST FOR MODEL 136-400A RIDING MOWER

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART	REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART
1	731-0220		Steering Wheel Cap		48	12147		Rear Axle Support Brkt.	
2	712-0158		Hex Cent. L-Nut 5/16-18 Thd.*		49	10470		Bearing—Plate	
3	736-0242		Belleville Wash.		50	741-0199		Plastic Flange Brg. w/Flats .753 I.D.	N
4	731-0219		Steering Wheel Ass'y.		51	717-0271		Differential Ass'y.—Comp.	
5	731-0262		Cover—Steering Column		52	12148		Axle Brkt.	
6	750-0233		Steering Tube Ass'y.		53	736-0134		FI-Wash. .812 I.D. x 1.38 O.D.	
7	738-0140		Shld. Scr. .437 Dia. x .180" Lg.		54	734-0522		Wheel Ass'y.—Comp. Rear 12.2 x 3.7	
8	12138		Steering Shaft Ass'y.		55	736-0105		Belleville Wash. .400 I.D. x .88 O.D.	
9	712-0222		Push Speed Nut .62 Dia.		56	710-0568		Scr. 5/16-18 x .75" Lg.	
10	736-0156		FI-Wash. .635 I.D. x 1.120 O.D.		57	736-0119		L-Wash. 5/16" Scr.*	
11	748-0227		Hex Flange Brg. .630 I.D.		58	712-0267		Hex Nut 5/16-18 Thd.*	
12	712-0267		Hex Nut 5/16-18 Thd.*		59	710-0198		Hex Sems Scr. 5/16-18 x .75" Lg.*	
13	736-0119		L-Wash. 5/16" Scr.*		60	712-0267		Hex Nut 5/16-18 Thd.*	
14	712-0107		Hex Cent. L-Nut 1/4-20 Thd.		61	736-0119		L-Wash. 5/16" Scr.*	
15	710-0106		Hex Scr. 1/4-20 x 1.25" Lg.		62	710-0395		Hex Scr. 5/16-18 x 2.25" Lg.*	
16	12125	—452	Main Frame		63	10086		Belt Guard Ass'y.—Trans.	
17	712-0267		Hex Nut 5/16-18 Thd.*		64	761-0130		Disc Brake Ass'y.—Comp.	
18	736-0119		L-Wash. 5/16" Scr.*		65	12145		Brake Brkt. Ass'y.	
19	712-0267		Hex Nut 5/16-18 Thd.*		66	732-0118		Ext. Spring	
20	736-0119		L-Wash. 5/16" Scr.*		67	710-0117		Hex Scr. 5/16-24 x 1.00" Lg. H.T.	
21	710-0198		Hex Sems Scr. 5/16-18 x .75" Lg.*		68	710-0198		Hex Sems Scr. 5/16-18 x .75" Lg.*	
22	09709		Axle Ass'y.—Front—L.H.		69	761-0133		Spacer for Disc Brake	
23	710-0198		Hex Sems Scr. 5/16-18 x .75" Lg.*		70	710-0198		Hex Sems Scr. 5/16-18 x .75" Lg.*	
24	747-0147		Tie Rod 3/8" Dia. L.H.		71	10247		Transmission Plate	
25	09706		Axle Ass'y.—Front—R.H.		72	713-0723		#41 Master Link 1/2" Pitch Type II	
26	711-0169		Collar		73	713-0190		#41 Chain 1/2" Pitch x 71 Links	
27	710-0494		Sq. Hd. Set Scr. 5/16-18 x 38 Cup		74	717-0223		Single Spd. Trans.—Comp.	
28	748-0146		Flange Brg. w/Flats .630 I.D.		75	715-0103		Spring Pin Roll 1/8 x .75" Lg.	
29	734-0510		Wheel Ass'y.—Front 10.25 x 3.25		76	12170		Shift Brkt Ass'y.	
30	714-0507		Cotter Pin 3/32" Dia. x .75" Lg.*		77	712-0429		Hex Ins. L-Nut 5/16-18 Thd.	
31	12151		Front Wheel Brkt.		78	747-0136		Shift Rod	
32	710-0198		Hex Sems Scr. 5/16-18 x .75" Lg.*		79	712-0267		Hex Nut 5/16-18 Thd.*	
33	712-0375		Hex Cent. L-Nut 3/8-16 Thd.		81	736-0119		L-Wash. 5/16" Scr.*	
34	738-0234		Shld. Scr. .500" Dia. x .295" Lg.		82	12169		Shift Lever	
35	712-0267		Hex Nut 5/16-18 Thd.*		83	720-0142		Grip—Flat Bar Type	
36	736-0119		L-Wash. 5/16" Scr.*		84	712-0134		Hex Top L-Nut 5/16-24 Thd.	
37	12155		Pedal Pivot Brkt. w/1/2" Hole		85	HH-03-03032		Wash. .349 I.D. x 1.004 O.D. x .066 Thk.	
38	12156		Pedal Pivot Brkt. w/3/8" Hole		86	HH-18-03493		Cam Lever 22°	
39	12136		Brake Pedal Ass'y.		87	HH-06-03031		Spring—Compres. .350" Dia. x 4 Coils	
40	12419		Pedal Lockout Rod 5/16"		88	HH-05-03034		Push Pin .309" Dia. x .857"	
41	714-0104		Int. Cotter Pin 5/16" Dia.*		89	HH-12-03292		Casting—Cam	
42	726-0109		Push Cap—.312 I.D.		90	HH-03-03303		Back Up Wash. 1.115" Dia. x .018 Thk. (D-Shaped)	
43	747-0128		Brake Rod 1/4" Dia. x 25.25" Lg.		91	HH-15-02124		Pad-Friction (D-Shaped) 1.110" Dia. x .472 Thk.	
44	732-0245		Brake Spring		92	HH-15-03149		Pad-Friction (D-Shaped) 1.110" Dia. x .245 Thk.	
45	710-0198		Hex Sems Scr. 5/16-18 x .75" Lg.*		93	HH-12-03293		Casting—Carrier	
46	712-0267		Hex Nut 5/16-18 Thd.*		94	747-0146		Tie Rod 3/8" Dia.—R.H.	
47	736-0119		L-Wash. 5/16" Scr.*		95	712-0158		Hex Cent. L-Nut 5/16-18 Thd.	


*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.
(462—Red Flake)

When ordering parts, if color or finish is important use the appropriate color code shown above (e.g. Red Flake Finish—12131 (462).)

NOTE: The engine is not under warranty by the mower manufacturer . . . If repairs or service is needed on the engine, please contact your nearest authorized engine service outlet. Check the "Yellow Pages" of your telephone book under "Engines—Gasoline."



136-400A



➔ IMPORTANT
 Belts listed by Part Number are of special construction and should be used when replacement is necessary. The dimensions and description given are for general reference only and belts purchased by description and dimension generally will only provide temporary service.

PARTS LIST FOR MODEL 136-400A RIDING MOWER

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART	REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART
1	—		Engine		56	12153		Front Deck Brkt.	
2	717-0223		Trans, Ass'y.—Comp.		57	736-0185		FI-Wash. .406 I.D. x .734 O.D. x .063*	
3	10247		Trans. Plate						
4	712-0798		Hex Nut 3/8-16 Thd.*		58	714-0507		Cot. Pin 3/32 Dia. x .75" Lg.	
5	736-0217		L-Wash. 3/8" Scr. H.D.		59	710-0195		Hex Scr. 1/4-28 x .62	
6	710-0442		Hex Scr. 5/16-18 x 1.50" Lg.*		60	726-0166		Push Cap 1/4" Dia.	
7	747-0127		Lift Handle Rod 3/8" Dia.		61	11399		Adapter Ass'y.	
8	720-0143		Grip		62	11634		Chute Cover Ass'y.—Comp.	
9	12142		Deck Lift Handle Ass'y.		63	732-0261		Torsion Spring	
10	12150		Index and Support Brkt.		64	710-0198		Hex Sems Scr. 5/16-18 x .75" Lg.*	
11	735-0126		Rubber Washer						
12	736-0101		FI-Wash. .406 I.D. x 1.00 O.D. x .030		65	738-0141		Shld. Scr. .437 Dia. x .350	
					66	748-0180		Pivot Slide	
13	712-0112		Hex Nut #6-32 Thd.*		67	12154		Rear Deck Brkt.	
14	736-0217		L-Wash. 3/8" Scr. H.D.		68	10426		Belt Keeper Ass'y.	
15	712-0798		Hex Nut 3/8-16 Thd.*		69	710-0322		Hex Sems Scr. 5/16-18 x 1.00" Lg.*	
16	738-0183		Shoulder Scr.						
17	12152		Deck Hanger Link		70	736-0119		L-Wash. 5/16" Scr.*	
18	747-0132		Clutch Rod		71	712-0267		Hex Nut 5/16-18 Thd.*	
19	714-0104		Hair Pin Cotter		72	736-0119		L-Wash. 5/16" Scr.*	
20	12133		Clutch Pedal Ass'y.		73	712-0267		Hex Nut 5/16-18 Thd.*	
21	731-0142		Foot Pedal Bar		74	12154		Rear Deck Brkt.	
22	726-0221		Push Cap 1/2" I.D.		75	12419		Pedal Lockout Rod 5/16"	
23	12125		Main Frame		76	726-0109		Push Cap—.312 I.D.	
24	761-0148		Blade Brake Ass'y. 1.38		77	747-0125		Deck Lift Rod 3/8" Dia.	
25	736-0329		L-Wash. 1/4" Scr.*		78	710-0167		Carriage Bolt 1/4-20 x .50" Lg.	
26	712-0287		Hex Nut 1/4-20 Thd.*		79	12139		Deck Lift Shaft Ass'y.	
27	712-0261		Hex Cent. L-Nut 5/8-11 Thd.		80	712-0158		Hex Cent. L-Nut 5/16-18 Thd.	
28	736-0158		FI-Wash. 5/8" Scr.*		81	736-0116		FI-Wash. .635 I.D. x .93 O.D.	
29	11073		Brake Disc		82	714-0507		Cot. Pin 3/32 Dia. x .75" Lg.*	
30	756-0143		Split Pulley .63 I.D.		83	732-0233		Tension Spring	
31	754-0188		V-Belt 21/32-51" Lg.		84	738-0147		Shld. Scr. .500 Dia. x .170	
32	08253		Housing—Bearing		85	756-0212		Engine Two Step Pulley and 5.81	
33	12172		Belt Keeper Ass'y.						
34	11537		Belt Guard Plate Ass'y.		86	756-0116		V-Belt Idler	
35	738-0129		Shld. Scr. .498 Dia. x 2.005		87	736-0217		L-Wash. 3/8" Scr. H.D.	
36	736-0105		Bell. Wash. .400 I.D. x .88 O.D.		88	712-0711		Hex Jam Nut 3/8-24 Thd.*	
					89	710-0151		Hex Scr. 3/8-24 x 2.00" Lg.*	
37	12157		26" Deck Ass'y.		90	736-0217		L-Wash. 3/8" Scr. H.D.	
38	732-0153		Spring .75 O.D. x 8.65 Lg.		91	711-0572		Step Washer	
39	712-0267		Hex Nut 5/16-18 Thd.*		92	712-0922		Hex Jam Nut 1/2-20*	
40	736-0119		L-Wash. 5/16" Scr.*		93	736-0921		L-Wash. 1/2" Scr.*	
41	710-0198		Hex Sems Scr. 5/16-18 x .75" Lg.*		94	754-0101		V-Belt 1/2 x 35" Lg.	
					95	756-0175		Trans. Split Pulley .50 I.D.	
42	714-0388		#61 Hi-Pro Key 3/16 x 5/8" Dia.		96	10086		Belt Guard Ass'y.—Trans.	
					97	12162		Idler Brkt. Ass'y.	
43	711-0405		Blade Spindle		98	714-0365		#6 Hi-Pro Key 5/32 x 5/8" Dia.	
44	714-0365		#6 Hi-Pro Key 5/32 x 5/8 Dia.						
45	742-0147		26" Blade		99	12160		Belt Keeper Ass'y.	
46	10769		Blade Adapter Kit		100	712-0267		Hex Nut 5/16-18 Thd.*	
47	736-0217		L-Wash. 3/8" Scr. H.D.		101	736-0119		L-Wash. 5/16" Scr.*	
48	710-0459		Hex Scr. 3/8-24 x 1.50" Lg. H.T.		102	712-0267		Hex Nut 5/16-18 Thd.*	
					103	736-0119		L-Wash. 5/16" Scr.*	
49	710-0117		Hex Scr. 5/16-24 x 1.00" Lg. H.T.		104	10423		Belt Guard—Cup Ass'y.	
					105	714-0129		#4 Hi-Pro Key 3/32 x 5/8" Dia.	
50	736-0119		L-Wash. 5/16" Scr.*						
51	712-0123		Hex Nut 5/16-24 Thd.*		106	726-0141		Adjustment Clamp	
52	712-0267		Hex Nut 5/16-18 Thd.*		107	736-0329		L-Wash. 1/4" Scr.*	
53	736-0119		L-Wash. 5/16" Scr.*		108	712-0138		Hex Nut 1/4-28 Thd.*	
54	741-0919		Ball Bearing		109	710-0559		Hex Scr. 1/4-28 x 1.75" Lg.*	
55	750-0142		Spacer		110	710-0299		Hex Scr. 1/4-28 x 1.00" Lg.*	


*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

(462—Red Flake)

When ordering parts, if color or finish is important use the appropriate color code shown above (e.g. Red Flake Finish—12131 (462).)

136-400A

717-0223 REVERSING TRANSMISSION



Unit requires approximately five (5) ounces of high temperature lubricant.

PARTS LIST FOR REVERSING TRANSMISSION 717-0223

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART	REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART
1	716-0104		E-Ring for .500" Dia. Shaft		13	710-0195		Hex Hd. Cap Scr. 1/4-28 x .62" Lg.*	
2	748-0852		Sprocket—8 Tooth		14	741-0862		Detent Ball	
3	714-0129		#4 Hi-Pro Key 3/32 x 5/8" Dia.		15	732-0863		Detent Spring	
4	711-0854		Output Shaft		16	736-0116		FI-Wash. .635 I.D. x .93 O.D.	
5	714-0126		#9 Hi-Pro Key 3/16 x 3/4" Dia.		17	716-0106		E-Ring for .625" Dia. Shaft	
6	717-0123		Trans. Case—L.H. Comp.		18	716-0865		Snap Ring for .500" Dia. Shaft	
7	748-0855		Flange Bearing		19	748-0866		Pinion Gear	
8	712-0117		Hex Centerlock 1/4-28*		20	748-0867		Bearing .627 I.D.	
9	748-0856		Bevel Gear		21	738-0159		Pinion Shaft	
10	748-0857		Clutch Collar		22	736-0192		FI-Wash. .531 I.D. x .93 O.D.	
11	08583		Shift Yoke Assembly		23	736-0921		Spring L-Wash. 1/2" Scr.*	
12	717-0124		Trans. Case—R.H.—Comp. (With Detent Hole)		24	712-0922		Hex Jam Nut 1/2-20 Thd.*	
					25	737-0120		Grease—High Temp. 450°F. (5 oz.)	
					26	717-0223		Transmission Complete	

*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

PARTS INFORMATION

POWER EQUIPMENT PARTS AND SERVICE

Parts and service for all MTD manufactured power equipment are available through the authorized service firms listed below. All orders should specify the model number of your unit, parts numbers, description of parts and the quantity of each part required.

ALABAMA	BIRMINGHAM	
	Auto Electric & Carburetor Co.	2625 4th Ave. S. 35233
ARKANSAS	NORTH LITTLE ROCK	
	Sutton's Lawn Mower Shop	Rt. 4, Box 368 72117
	FORT SMITH	
	Mity Mite Motors, Inc.	2515 Towson Ave. 72901
CALIFORNIA	SAN BERNARDINO	
	Lawn Mower Supply Co.	25608 E. Baseline 92410
	SAN FRANCISCO	
	J.W. Jewett Co.	981 Folsom St. 94107
	SACRAMENTO	
	Luttig & Severson	2030 28th St. 95818
COLORADO	DENVER	
	South Denver Lawn Equip.	527 West Evans 80223
CONNECTICUT	SUFFIELD	
	The Jones & Ramsey Co.	850 Thompsonville Rd. 06078
FLORIDA	JACKSONVILLE	
	Radco Distributors	2403 Market St. 32206
	CORAL GABLES	
	Moz-All of Florida, Inc.	365 Greco Ave. 33146
GEORGIA	EAST POINT	
	East Point Cycle & Key	2834 Church St. 30344
ILLINOIS	LYONS	
	Keen Edge Co.	8615 Ogden Ave. 60534
INDIANA	ELKHART	
	Parts & Sales Inc.	2101 Industrial Pkwy. ..46514
	CORYDON	
	Brown Equip. Dist., Inc.	110 Beech St.47112
IOWA	DUBUQUE	
	Power Lawn & Garden Equip.	2551 J.F. Kennedy 52001
KANSAS	WICHITA	
	Hixon, Inc.	3030 Mascot 67204
LOUISIANA	NEW ORLEANS	
	Suhren Engine Co.	8330 Earhart Blvd. 70118
MARYLAND	TAKOMA PARK	
	Center Supply Co.	6867 New Hampshire Ave. 20012
MASSACHUSETTS	SPRINGFIELD	
	Morton B. Collins Co.	300 Birnie Ave. 01107
MICHIGAN	MOUNT CLEMENS	
	Power Equipment Dist.	36463 South Gratiot... 48043
	LANSING	
	Lorenz Service Co.	2500 S. Pennsylvania.. 48900
MINNESOTA	MINNETONKA	
	Hance Distributing Inc.	11212 Wayzata Blvd. ..55343
MISSISSIPPI	BILOXI	
	Biloxi Sales & Service, Inc.	506 Caillavet St. 39533
MISSOURI	KANSAS CITY	
	Automotive Equip. Service	3117 Holmes St. 64109
	ST. LOUIS	
	Henzler, Inc.	2015 Lemay Ferry Rd. 63125
NEBRASKA	OMAHA	
	R.P.W., Inc.	7402 "L" St. 68127

BRIGGS & STRATTON, TECUMSEH AND PEERLESS PARTS AND SERVICE

Briggs & Stratton, Tecumseh and Peerless parts and service should be handled by your nearest authorized engine service firm. Check the yellow pages of your telephone directory under the listing *Engines Gasoline*, Briggs & Stratton or Tecumseh Lauson

NEW YORK	CARTHAGE	
	Gamble Dist., Inc.	West End Ave. 13619
	SYRACUSE	
	Kimber's, Inc.	115 N. Geddes St. 13204
	ROCHESTER	
	Henry W. O'Neil & Associates	510 N. Goodman St. ... 14609
NORTH CAROLINA	GREENSBORO	
	Dixie Sales Company	327 Battleground Ave.. 27402
	GOLDSBORO	
	Smith Hardware Co.	515 N. George St. 27530
OHIO	WADSWORTH	
	National Central	687 Seville Rd. 44281
	CLEVELAND	
	Bleckrie, Inc.	7900 Lorain Ave. 44102
	CARROL	
	Stebe's Mid-State Mower Supply Box 366	43112
	WILLARD	
	Sunshine Wholesale Tire Outlet Route 224	44890
	MANSFIELD	
	McClure Lawn & Garden Supply...1114 Lexington Ave. .	44903
OKLAHOMA	MUSKOGEE	
	Victory Motors, Inc.	605 S. Cherokee 74401
	ADA	
	Ada Auto Supply	301 E. 12th St. 74820
OREGON	PORTLAND	
	Kenton Supply Co.	8216 N. Denver Ave. . 97217
PENNSYLVANIA	LANCASTER	
	Raub Supply Co.	James & Mulberry Sts...17604
	PITTSBURGH	
	Bluemont Co.	11125 Frankstown Rd.. 15235
TENNESSEE	KNOXVILLE	
	Master Repair Service	2423 Broadway, N.E. ...37917
	MEMPHIS	
	Memphis Cycle & Supply Co.	421 Monroe Ave.38103
	American Sales & Service, Inc. .	1922 Lynnbrook 38117
TEXAS	DALLAS	
	Marr Brothers, Inc.	423 E. Jefferson 75203
	HOUSTON	
	Bullard Supply Co.	2409 Commerce St. 77003
	SAN ANTONIO	
	Catto & Putty, inc.	P.O. Box 240878206
	FORT WORTH	
	Woodson Sales Corp.	1702 N. Sylvania76111
UTAH	SALT LAKE CITY	
	A-1 Engine & Mower Co.	437 E. 9th St.84111
VERMONT	BURLINGTON	
	Vermont Appliance Co.	44 Lakeside Ave.05401
VIRGINIA	RICHMOND	
	RBI Corp.	963 Myers St. 23260
WASHINGTON	SEATTLE	
	Bailey's Rebuild, Inc.	1325 E. Madison St. ...98102
WEST VIRGINIA	CHARLESTON	
	Young's, Inc.	233 Virginia St., E. ... 25301
WISCONSIN	APPLETON	
	Automotive Supply Co.	123 S. Linwood Ave. ..54911

WARRANTY PARTS AND SERVICE POLICY

The purpose of warranty is to protect the customer from defects in workmanship and materials, defects which are NOT detected at the time of manufacture, it does not provide for the unlimited and unrestricted replacement of parts. Use and maintenance are the responsibility of the customer. The manufacturer cannot assume responsibility for conditions over which it has no control. Simply put, if it's the manufacturer's fault, it's the manufacturer's responsibility; if it's the customer's fault, it's the customer's responsibility.

CLAIMS AGAINST THE MANUFACTURER'S WARRANTY INCLUDES

1. Replacement of Missing Parts on new equipment.
2. Replacement of Defective Parts within the warranty period.
3. Repair of Defects within the warranty period.

All claims MUST be substantiated with the following information:

1. Model Number of unit involved.
2. Date unit was purchased or first put into service.
3. Date of failure.
4. Nature of failure.