OWNER'S MANUAL

- ASSEMBLY
- OPERATION
- MAINTENANCE
- PARTS LIST

138-493A 11#P 138-496A

TOP FLITE MODEL

10 HP TECHTSEH /3 V STRATER

THREE Spd. PEER LESS TRANSPILE

38" CUTTING DECK


TIMES 15" X 6.50" PNEUMATIC

18" × 850"

Important:

Read Safety Rules and Instructions Carefully

38" RIDING MOWERS



LIMITED WARRANTY

For one year from the date of original retail purchase, MTD PRODUCTS INC will either repair or replace, at its option, free of charge, F.O.B. factory or authorized service firm, any part or parts found to be defective in material or workmanship. Transportation charges under this warranty must be paid by the purchaser unless return is requested by MTD PRODUCTS INC.

This warranty will not apply to any part which has become inoperative due to misuse, excessive use, accident, neglect, improper maintenance, alterations, or unless the unit has been operated and maintained in accordance with the instructions furnished. This warranty does not apply to the engine, motor, battery, battery charger or component parts thereof. Please refer to the applicable manufacturer's warranty on these items.

This warranty will not apply where the unit has been used commercially.

Warranty service is available through your local authorized service dealer or distributor. If you do not know the dealer or distributor in your area, please write to the Customer Service Department of MTD.

The return of a complete unit will not be accepted by the factory unless prior written permission has been extended by MTD.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

WARNING TO PURCHASERS OF INTERNAL COMBUSTION ENGINE EQUIPPED MACHINERY OR DEVICES IN THE STATE OF CALIFORNIA

The equipment which you have just purchased does not have a spark arrester. If this equipment is used or any forest covered land, brush covered land, or grass covered unimproved land in the State of California, before using on such land, the California law requires that a spark arrester be provided. In addition, spark arrester is required by law to be in effective working order. The spark arrester must be attached to the exhaust system and comply with Section 4442 of the California Public Resources Code.

IMPORTANT

It is suggested that this manual be read in its entirety before attempting to assemble or operate. Keep this manual in a safe place for future reference and for ordering replacement parts.

This unit is shipped WITHOUT GASOLINE or OIL. After assembly, see operating section of this manual for proper fuel and amount.

Your rotary mower is a precision piece of power equipment, not a plaything. Therefore exercise extreme caution at all times.

SAFE OPERATION PRACTICES FOR RIDING VEHICLES

- Know the controls and how to stop quickly— READ THE OWNER'S MANUAL.
- 2. Do not allow children to operate vehicle. Do not allow adults to operate it without proper instruction. Only persons well acquainted with these rules of safe operation should be allowed to use your mower.
- 3. Do not carry passengers.
- 4. Keep the area of operation clear of all persons, particularly small children and pets. Stop engine when they are in the vicinity of your mower. Although the area of operation should be completely cleared of foreign objects, a small object may have been overlooked and could be accidently thrown by the mower in any direction.
- Clear work area of objects which might be picked up and thrown by the mower in any direction.
- 6. Disengage all attachment clutches and shift into neutral before attempting to start engine.
- 7. Disengage power to attachment(s) and stop engine before leaving operator position.
- Disengage power to attachment(s) and stop engine before making any repairs or adjustments. Disconnect the spark plug wire and keep the wire away from the plug to prevent accidental starting.
- Before attempting to unclog the mower or discharge chute, stop the engine and be sure the blade(s) have stopped completely. Disconnect the spark plug wire and keep the wire away from the plug to prevent accidental starting.
- 10. Disengage power to attachment(s) when transporting or not in use.
- Take all possible precautions when leaving vehicle unattended such as disengaging power-take-off, lowering attachments, shifting into neutral, setting parking brake, stopping engine and removing key.
- 12. Do not stop or start suddenly when going uphill or downhill. Mow up and down face of steep slopes; never across the face.
- Reduce speed on slopes and in sharp turns to prevent tipping or loss of control. Exercise extreme caution when changing direction on slopes.
- Stay alert for holes in terrain and other hidden hazards.
 - Use care when pulling loads or using heavy equipment.
 - A. Use only approved drawbar hitch points.
 - B. Limit loads to those you can safely control.
 - C. Do not turn sharply. Use care when backing.

- D. Use counterweight(s) or wheel weights when suggested in owner's manual.
- Watch out for traffic when crossing or near roadways.
- When using any attachments never direct discharge of material toward bystanders nor allow anyone near vehicle while in operation.
- 18. Handle gasoline with care—it is highly flammable.
 - A. Use approved gasoline container.
 - B. Never remove cap or add gasoline to a running or hot engine or fill fuel tank indoors. Wipe up spilled gasoline.
 - C. Open doors if engine is run in garage—exhaust fumes are dangerous. Do not run engine indoors.
- 19. Keep the vehicle and attachments in good operating condition, and keep safety devices in place. Use guards as instructed in owner's manual.
- Keep all nuts, bolts, and screws tight to be sure the equipment is in safe working condition.
- 21. Never store the equipment with gasoline in the tank inside a building where fumes may reach an open flame or spark. Allow engine to cool before storing in any enclosure.
- 22. To reduce fire hazard keep engine free of grass, leaves or excessive grease.
- 23. The vehicle and attachments should be stopped and inspected for damage after striking a foreign object, and the damage should be repaired before restarting and operating the equipment.
- Do not change the engine governor settings or overspeed the engine.
- 25. When using the vehicle with mower, proceed as follows:
 - (1) Mow only in daylight or in good artificial light.
 - (2) Never make a cutting height adjustment while engine is running if operator must dismount to do so.
 - (3) Shut the engine off and wait until the blade comes to a complete stop before removing the grass catcher.
 - (4) Check blade mounting bolts for proper tightness at frequent intervals.
- 26. Check grass catcher bags frequently for wear or deterioration. For safety protection replace only with new bag meeting original equipment specifications.
- 27. Look behind to make sure the area is clear before placing the transmission in reverse and backing up.

3

INDEX

1 to the dAMeson white	Off-Season Storage
Limited Warranty2	Trouble Shooting Chart
Safe Operation Practices 3	
Index and Assembly 4	Illustrated Parts for Transaxle 18
Battery Information	Parts List for Transaxle
Controls 7	Illustrated Parts for Riders 20, 22, 24, 26
Operating Instructions 9	Parts Lists for Riders 21, 23, 25, 27
Maintenance10	Electrical Diagrams28 & 29
Lubrication	Wiring Diagram
Adjustment12	Parts Information Back Cove
Belt Replacement	



IMPORTANT

After striking a foreign object, stop the engine. Remove wire from spark plug, thoroughly inspect the mower for any damage, and repair the damage before restarting and operating the mower.

The steering wheel and seat, with the necessary hardware, are easily assembled to the machine. The battery must be activated and installed as outlined in this section.

TIRE PRESSURE

FOR SHIPPING PURPOSES, THE TIRES ON YOUR UNIT MAY BE OVER-INFLATED. TIRE PRESSURE SHOULD BE REDUCED BEFORE UNIT IS PUT INTO OPERATION. PRESSURE SHOULD BE APPROXIMATELY 15 P.S.I. EQUAL TIRE PRESSURE SHOULD BE MAINTAINED ON ALL TIRES. MAXIMUM TIRE PRESSURE IS 30 P.S.I.



Installation of tire to rim:

- 1. Lubricate tire beads and rim flanges.
- 2. Do not exceed 30 P.S.I. when seating beads.
- 3. Adjust to recommended pressure after beads are sealed.



Reference to right-hand or left-hand side of machine is from the driver's seat facing forward.




FIGURE 1. HARDWARE SUPPLIED

ASSEMBLY

- Step 1. Remove the lawn mower and all parts from the carton. Make certain that all loose parts and literature have been removed before the carton is discarded.
- Step 2. Place steering wheel over steering shaft.
- Step 3. Secure with Belleville Washer (E) and Hex Nut (F). See figure 2.
- Step 4. Press the cap on the steering wheel by hand. See figure 2.




FIGURE 2. STEERING WHEEL ASSEMBLY

Step 5. Use the hex nut and lockwasher to attach the seat to the seat spring in one of the three adjustment holes. (See figure 3.)




FIGURE 3.



Check ALL nuts and bolts for correct tightness.

BATTERY INFORMATION



- A. Battery acid must be handled with great care as it will blister the skin and damage clothing. It is advisable to wear goggles, rubber gloves, and a protective apron when working with it.
- B. Neutralize acid spilled on clothing with dilute ammonia water or a water solution of baking soda. If acid gets on clothes, dilute it with clean water first, then neutralize.
- C. If for any reason acid should be spattered in the eyes, wash it out immediately with clean cold water. Seek medical aid if discomfort continues.
- D. Since battery acid is corrosive to metals, do not pour into any sink or drain. Rinse empty electrolyte containers and mutilate before discarding.



BATTERIES CONTAIN SULFURIC ACID AND MAY CONTAIN EXPLOSIVE GASES (when electrolyte has been added)

- A. Keep sparks, flame, cigarettes away.
- B. Hydrogen gas is generated during charging and discharging.
- C. Ventilate when charging or using in enclosed space.
- D. When using a charger—to avoid sparks— NEVER connect or disconnect charger clips to battery while charger is turned on.
- E. Always shield eyes, protect skin and clothing when working near batteries.

A. Activating the Battery

- Place the battery to be filled on bench or workbench. NEVER activate battery in unit. Remove vent caps from all cells.
- 2. Fill each cell carefully using battery grade 1.250-1.265 specific gravity. Sulfuric acid to be 3/8" above the top of the separators or to the split ring.
- Allow battery to set for 20 minutes to ½ hour.
 Add additional acid if necessary to bring it up to the proper level.
- 4. Replace the vent caps.

5. The battery can now be charged after the 20 minutes setting period. Battery can be SLOW CHARGED (DO NOT FAST CHARGE) at a maximum bench rate of 4-5 amperes until the specific gravity reading is 1.265-1.275. A charging rate in excess of this will buckle and warp the positive plates and perforate the separators. If electrolyte bubbles violently while charging, reduce charging rate until excessive bubbling action subsides, then continue charging until specific gravity is reached.



After battery has been in service, add only approved water. DO NOT ADD ACID.

B. To Install Battery

To install the battery in this unit, refer to next column.

C. Maintenance

- Check periodically (every two weeks or before and after charging) to be sure electrolyte level is 9/16" above separator plates. Add only distilled water or good quality drinking water. NEVER add additional acid or other chemicals to battery after initial activation.
- The battery should be checked with a hydrometer after every 25 hours of operation. If the specific gravity is less than 1.225 remove battery and recharge.
- Coat the terminals and exposed wiring with a thin coat of grease or petroleum jelly for longer service and protection against electrolyte corrosion.
- 4. The battery should be kept clean. Any deposits of acid should be neutralized with soda and water. Be careful not to get this solution in the cells.

D. Storage

- Charge battery using normal methods. NEVER store discharge battery as it will not recover.
- 2. Store in cold, dry place.
- Recharge battery whenever the specific gravity is less than 1.225 before returning to service or every two months, whichever occurs first.

E. Common Causes for Battery Failure Are:

- 1. Overcharging
- 2. Undercharging

- 3. Lack of water
- Loose hold downs and/or corroded connections
- 5. Excessive loads
- 6. Battery electrolyte substitutes
- 7. Freezing of electrolyte



THESE FAILURES DO NOT CONSTITUTE WARRANTY.

INSTALLING THE BATTERY

- 1. Open the hood of the riding mower.
- 2. Place the battery in the battery case with the terminal to the front. See figure 4.




FIGURE 4.

- 3. Cut the black rubber tubing approximately 4 inches long.
- 4. Push the rubber tubing into the manifold of the battery and place the other end into the drain tube. See figures 4 and 5.



The vented battery allows any gases or liquid from the battery to be carried to the rear of the mower through the drain tube.

- Hook the hold down rods under the battery case and place the hold down over the manifold of the battery as shown in figure 6.
- 6. Secure the hold down with the wing nuts.




FIGURE 5.

 Attach the positive cable (from the starter solenoid) and the small wire (from the ammeter) to the positive battery terminal with the bolt, lockwasher and nut in the assembly pack.




FIGURE 6.

8. Attach the negative cable, grounded, to the negative battery terminal with the bolt, lockwasher and nut in the assembly pack.

CONTROLS

The controls on both models may be considered as the Drive Control and the Cutting Control as follows:

a. Throttle Control The throttle control is used to regulate the engine speed and choke the engine. The engine should be operated from 3/4 to full throttle when operating the cutting deck or snow thrower (optional). See figure 7.




FIGURE 7. CONTROLS

- **b.** Gear Shift Lever. The gear shift lever is used to shift into one of three FORWARD GEARS, NEUTRAL or REVERSE. See figures 7 and 8.
- **c. Brake.** The brake pedal is located on the right hand side of the mower and is operated by depressing it with your right foot. See figure 9.
- d. Brake Lock. The brake lock is located on the right hand side of the mower. To lock the brake, depress the brake pedal and lift up the lock button. The pedal will stay depressed. To release, depress the pedal. See figure 9.
- **e. Clutch Pedal.** The clutch pedal is used to disengage the drive mechanism. Depressing the clutch pedal at any time will reduce mower speed. If depressed all the way, it will stop the mower. See figure 10.
- f. Clutch Lockout. When the clutch pedal is depressed all the way it can be locked by placing the clutch lockout in the START position as shown in figure 8. The clutch lockout must be in this position before the engine will start.
- g. Ammeter. The ammeter registers the rate of battery charge or discharge. The ammeter should register on the plus side (+) when the engine is running in the fast position until the battery is completely charged. With a fully charged battery or with the engine idling the ammeter will not show a charge. See figure 7.

h. Light Switch. Pull the light switch out to turn on the lights. The lights will only operate when the engine is running. See figure 7.




FIGURE 8. SHIFT PATTERN

i. Ignition Switch. The ignition switch is located on the right side of the dashboard.

Electric Start. See figure 7. Turn the key to the START position to start the engine. When the engine is running, let the key return to the ON position. To stop the engine, turn the key to the left to the OFF position and remove it to prevent accidental starting.



The engine will not start unless the clutch lockout is in the START position and the lift lever is in the DIS-ENGAGED position




FIGURE 9. RIGHT HAND CONTROLS

j. Lift and Disengagement Lever. It is used to raise the cutting deck. Pulling it all the way back and locking it disengages the blades. The engine will not start unless the lift and disengagement lever is in the disengaged position. See figure 9.

k. Cutting Controls. The cutting controls consist of the height of cut stop and the wheel height adjusters.

Height of Cut Stop. See figure 11. Lift the stop and set it at the desired cutting height.




FIGURE 10. LEFT HAND CONTROLS




FIGURE 11. HEIGHT OF CUT SETTINGS

Wheel Height Adjuster. See figure 12. Move the lever towards the wheel and set it in the desired cutting height.

The cutting height of the mower can be set in two different ways: FULL FLOAT position where the deck follows the contour of the ground, and the SUSPENDED position where the deck hangs from the frame of the rider. The suspended position is normally used for cutting rough uneven ground.

To set the cutting deck in the full float position, set the wheel height adjusters in the desired cutting height as indicated in figure 12. Set height of cut stop in the $1\frac{1}{2}$ position. See figure 11.

To set the cutting deck in the suspended position, set the height of cut stop in the desired cutting height and then set the deck wheel so they just clear the ground.




FIGURE 12. WHEEL HEIGHT ADJUSTER

OPERATING INSTRUCTIONS

STARTING THE ENGINE

Be sure to follow the instructions for the oil and gasoline as described in the engine section of this manual.

Step 1. Be sure the fuel shut-off valve is open. See figure 13.




FIGURE 13. FUEL SHUT-OFF VALVE

- Step 2. Place the clutch lockout in the START position. See figure 10.
- Step 3. Place the lift and disengagement lever in the DISENGAGED position. See figure 9.
- Step 4. Set the throttle control in the CHOKE position. See figure 7.



NOTE

This unit is equipped with a brake indicator light which is located on the dash panel. Whenever the starter key is on and the brake pedal is depressed, it will light.



CAUTION

This light indicates that the brake is engaged. Operating the unit with the brake engaged will result in rapid brake wear and premature brake failure.

Electric Start

See figures 14 and 15. Turn the ignition key to the START position. When the engine is running, let the key return to the ON position.




FIGURE 14. STARTER SWITCH




FIGURE 15. DASH PANEL LABEL



A brief break-in period is essential to ensure maximum engine and mower life. This consists of running the engine at half speed for a period of time required to use one tank of gasoline. It is also recommended to change crankcase oil after the first 2 hours of operation.



Parking brake MUST be disengaged before unit is put into motion.



Unit is equipped with separate brake and clutch pedals. To efficiently stop, it is necessary to disengage clutch when applying brakes.

STOPPING THE ENGINE

Turn the ignition key to the left to the OFF position and remove the key to prevent accidental starting.

OPERATING THE MOWER

- Step 1. Set the desired cutting height.
- Step 2. Start the engine as outlined above.
- Step 3. Select gear and shift.



DO NOT force the gear shift lever! If the lever cannot be moved from NEUTRAL to one of the drive positions, release the clutch pedal slowly, depress it again, and then move the gear shift lever as required.

- Step 4. Once the machine is in motion, remove foot from the pedal. The mower will now move ahead or to the rear, and the use of the steering wheel will provide directional control.
- Step 5. The mower is brought to a stop by pressing your right foot against the brake pedal and your left foot against the clutch pedal. The drive belt will be disengaged and the brake will be applied.



Gear changing should be done only after the mower has been brought to a full stop. If the mower is not to be used for a long period, place the gear shift lever in NEUTRAL and stop the engine. DO NOT leave the machine on an incline.

OPERATING THE CUTTER BLADE

The cutting blades may be engaged while the mower is moving or standing still. DO NOT engage the cutting blades abruptly as the sudden belt tension on the pulley may cause the engine to stall.



When the blade drive is engaged, keep feet and hands away from the discharge opening and from the blade.

To stop the blades, move the lift and disengagement lever (figure 9) into the DISEN-GAGED position. This raises the deck and disengages the blades.



When the machine is used for other than mowing operations the blade drive should be disengaged.

MAINTENANCE

CRANKCASE OIL

To ensure maximum engine performance, perform the following periodic maintenance:

Oil Check

Check the oil level in the crankcase before each use of the machine and after every five hours of operation. Oil should be kept between the add and full marks on the dipstick.

After the first five hours of operating a new engine, drain the oil (See figure 16) from the crankcase while engine is still hot and refill crankcase with new oil; thereafter change the oil every 25 hours of operation. This procedure ensures for minimum wear of engine parts and provides for virtually trouble-free operation. To change the oil, proceed as follows:

Step 1. With the machine on level ground, place a suitable metal container under the oil drain plug, then remove the drain plug. See figure 14.




FIGURE 16. OIL DRAIN

- Step 2. After the oil has been drained completely from the crankcase, replace the drain plug and tighten.
- Step 3. Refill crankcase with 21/4 pints of good quality, type MS, Engine oil into the crankcase. Summer use SAE 30; Winter (Below 40°F.) use SAE 5W-20 or SAE 10W. (Use Wizard 4 Cycle Power Mower Oil Stock No. 78-2050).*

Lubricate the wheel bearings (2 per wheel) and the upper and lower spindle bearings with SAE 30 oil once a season. See figure 17.




FIGURE 17. WHEEL AND SPINDLE BEARINGS

LUBRICATION

AIR CLEANER

Under normal operating conditions, the air cleaner, located on top of the carburetor, must be serviced after every ten hours of use. Under

extremely dusty operating conditions the air cleaner must be serviced after every hour of operation. Refer to figure 18.

When assembling the air cleaner, make certain the lip of the foam element extends over edge of the air cleaner body. The foam element will form a protective seal.

- Step 1. Remove two screws and lift off complete air cleaner assembly.
- Step 2. Remove screen and spacers from foam element.
- Step 3. Remove foam element from air cleaner body.
- Step 4. a. Wash foam element in kerosene or liquid detergent and water to remove dirt.
 - b. Wrap foam in cloth and squeeze dry.
 - c. Saturate foam in SAE 30 engine oil, then squeeze out excess oil.
 - d. Assemble parts, fasten to carburetor with screw.




FIGURE 18. AIR CLEANER

CLEANING ENGINE AND BLADE HOUSING

Any fuel or oil spilled on the machine should be wiped off promptly. Grass, leaves, and other dirt must not be left to accumulate around the cooling fins of the engine or on any part of the machine. Clean the underside of the blade housing after each mowing.

BELTS

Check that belts are free of oil or dirt. Wipe the belts periodically with a clean rag.



Belt tension is automatically maintained by the spring on the variable speed bracket on the drive belts and the belt tension on the deck belt is maintained by the two deck springs.

^{*}Obtain from your nearest Western Auto Store.

SPARK PLUG

The spark plug gap should be cleaned and reset to a 0.030-inch clearance every 25 hours of engine operation. (See figure 19.) Spark plug replacement is recommended at the start of each mowing season; check engine parts list for correct plug type.



Whenever the spark plug is removed for cleaning, it is advisable to replace the spark plug gasket with a new gasket.




FIGURE 19. SPARK PLUG CLEARANCE




FIGURE 20. BLADE REMOVAL

REPLACING BLADE



Before beginning work on the cutter blade, remove the spark plug from the cylinder. The adapter can be removed from the blade by removing the two adapter bolts, lockwashers and nuts.

Removing and Sharpening Blades. Remove the center bolt and lockwasher. See figure 20. Pull the blade and blade adapter from the blade spindle.

WHEEL ADJUSTMENT

The caster (forward slant of the king pin) and the camber (tilt of the wheels out at the top) requires no adjustment. Automotive steering principals have been used to determine the caster and camber on the rider. The front wheels should toe-in 1/8 inch.

To adjust the toe-in follow these steps.

- Step 1. Remove the elastic locknut and drop the tie rod end from the wheel bracket. See figure 21.
- Step 2. Loosen the hex jam nut on the rod.
- Step 3. Adjust the tie rod assembly for correct toe-in.




FIGURE 21. TIE ROD END

ADJUSTMENT

Dimension "B" should be approximately 1/8" less than dimension "A".

- A.) To increase dimension "B", screw the rod into tie rod end.
- B.) To decrease dimension "B", unscrew tie rod from tie rod end.
- C.) Reassemble the rod. Check dimensions. Readjust if necessary.




FIGURE 22. TOE-IN DIAGRAM



To insure safe operation of your unit ALL nuts and bolts must be checked periodically for correct tightness.




FIGURE 23. CARBURETOR ADJUSTMENT

ADJUSTING CARBURETOR CHOKE

Proper choke operation is dependent upon proper adjustment of remote controls on the powered equipment.

To Check Operation of Choke-A-Matic Controls:

Move control lever to CHOKE position. (See figure 7.) The carburetor choke should be closed.



The air cleaner can be removed to check the operation of the choke.

To Adjust:

Place control lever on equipment in FAST (high speed) position. Loosen control casing clamp screw B. Move control casing A and wire until lever D touches choke operating link at C. Tighten casing clamp screw B. See figure 24.




FIGURE 24. CHOKE ADJUSTMENT

BRAKE ADJUSTMENT

- Move brake pedal forward by hand until pressure or resistance is noted. This is the point where the brake pedal spring begins to stretch.
- 2. If adjustment is correct, parking brake lock will have moved approximately 1/4". See figure 25.




FIGURE 25. PARKING BRAKE LOCK

3. If adjustment is incorrect, tighten or loosen brake adjusting nut until correct dimension is obtained. See figure 26. Over tightening will reduce effective braking action. Lock brake adjustment with brake adjustment locknut. Periodic adjustment is necessary to maintain effective brake operation.




FIGURE 26. BRAKE ADJUSTMENT NUT

PREPARING FOR BELT REMOVAL

- To prevent gasoline from leaking from the engine, remove the fuel tank cap, place a piece of thin plastic over the neck of the fuel tank and screw on the cap.
- 2. Disconnect the spark plug wire and ground it against the engine.
- 3. Remove the battery to prevent acid from leaking.



Disconnect the negative terminal first and connect last when installing the battery.

MOWING UNIT BELT REPLACEMENT

- Step 1. Place the lift lever in the disengaged position. See figure 9.
- Step 2. Remove the belt keeper and large bolt on the engine pulley. See figure 27.
- Step 3. Unhook the belt from the engine pulley. See figure 28.
- Step 4. Place the lift lever in the engaged position. See figure 9.




FIGURE 27. BELT KEEPER




FIGURE 28. REMOVING MOWER BELT

Step 5. Unhook the tension springs on both sides of the deck. See figure 29.




FIGURE 29. REMOVING TENSION SPRINGS

- Step 6. Remove the front four deck links from the cutting deck. See figure 30.
- Step 7. Remove the belt guards from both deck pulleys. See figure 30.
- Step 8. Remove and replace the belt and reassemble.




FIGURE 30. DECK LINKS

TRANSMISSION BELTS REMOVAL

- Step 1. Place the lift lever in the disengaged position. See figure 9.
- Step 2. Remove the belt keeper and large bolt on the engine pulley. See figure 27.
- Step 3. Unhook the belt from the engine pulley. See figure 28.
- Step 4. Place the lift lever in the engaged position. See figure 9.
- Step 5. Unhook the tension springs on both sides of the deck. See figure 29.
- Step 6. Remove the front four deck links from the cutting deck. See figure 30.
- Step 7. Tip the deck down as shown in figure 30.



NOTE

Leave the belt attached to the deck pulleys unless you want to replace it.



NOTE

By working between the frame and the deck, it is possible to remove and replace the deck belt without removing the deck, however, the working space is limited.

- Step 9. Removing the transmission belt. See figure 30.
 - a. Remove the entire belt guard from the engine pulley by removing the two front engine bolts. See figure 29.




FIGURE 31. BELT GUARD REMOVAL

- b. Remove the transmission pulley by removing the hex nut and washer. See figure 30.
- c. Remove the bolt and nut from the steering rack and remove the belt.
- d. Reassemble in reverse order with the new belt.




FIGURE 32. BOTTOM VIEW

OFF-SEASON STORAGE

If the machine is to be inoperative for a period longer than 30 days, the following precautions are recommended:

Step 1. Working outdoors, drain all fuel from the fuel tank. Use a clean dry cloth to absorb the small amount of fuel remaining in the tank, then run the engine until all fuel in carburetor is exhausted.




Do not drain fuel while smoking, or if near an open fire.

- Step 2. Drain all the oil from the crankcase (this should be done after the engine has been operated and is still warm) and refill the crankcase with clean new oil.
- Step 3. Disconnect the spark plug wire and remove the spark plug from the cylinder. Pour about six drops of engine oil into the cylinder, and then pull the recoil starter several times to spread the oil on the cylinder wall. Replace the spark plug, but DO NOT connect the wire.
- Step 4. Clean the engine and the entire mower thoroughly.
- Step 5. Lubricate all lubrication points indicated in figure 15; then wipe the entire machine with an oiled rag in order to protect the surfaces.

TROUBLE SHOOTING CHART

		SHOOTING CHART
TROUBLE	LOOK FOR	REMEDY
Engine fails to start.	Safety System	A. Check for a blown fuse in the wire leading from the positive terminal of the battery.
		B. Before checking the safety system further, be sure the clutch control and the blade control are disengaged; only the starting system is being checked. Therefore remove the spark plug lead and ground it to prevent the engine from starting.
		C. Attach a wire (minimum 18 gauge) to the positive terminal of the battery and touch the other end to the small terminal (coil primary) of the solenoid. If the engine cranks, the problem is in the safety system.
		D. Check for continuity from the battery to the solenoid NOTE: The positive terminal of the battery should have a large cable (#8 gauge) and a small wire (#18 gauge) attached to it.
		E. Check all wires and cable for tightness.
		F. Use a #8 gauge wire and jump between the two large terminals of the solenoid. If the unit starts, replace the solenoid.
		G. If the unit fails to start after following the above procedure the problem is probably in the starting motor of the engine.
	Blocked fuel line	Clean fuel line; check fuel supply. Also check fuel shut-off
· .	or empty gas tank	valve.
	Defective spark plug	Spark plug lead wire disconnected. Faulty spark plug—spark should jump gap between control electrode and side electrode. If spark does not jump, replace spark plug.
·		NOTE: Use insulated pliers to hold the spark plug wire.
	Throttle setting	Throttle control lever not in the starting position.
	Loose connections	Spark plug wire loose.
Hard starting or loss of power.	Dirty air cleaner	Remove air cleaner and clean as outlined on page 17 of this manual.
	Carburetor impro- perly adjusted	Review paragraph Carburetor Adjustment.
Excessive vibration.	Bent or damaged blade spindle	Stop engine immediately; tighten all bolts and make all necessary repairs. If vibration continues, have the unit serviced by a competent repairman.
Unit fails to discharge grass.	Discharge chute clogged	Clean discharge chute and inside of deck.
	Foreign object lodged in deck	Remove object from deck. See CAUTION following step 1 in paragraph Operation .
	Obstructions in air	Remove any obstruction from air passages in shroud.
Engine overheats.	passages	
Engine overheats.	Grass and dirt in engine shroud	Clean cooling fins.

17



MUST ORDER FROM PEEPLESS

PARTS LIST FOR TRANSAXLE MODEL NO. 654


		PARIS LIST FOR TRAN	SAXL	E MODEL NO.	654
REF NO	NO.	DESCRIPTION	REF NO.		DESCRIPTION
1 1	PE-770063	Case Ass'y. Transaxle (Incl.	43,	PE-530105	Bearing, Needle
1 -		Nos. 2, 3 & 5)	431	3 PE-788042	Seal, Oil
2		Bearing, Needle	44	PE-778024	Gear (16 teeth)
3	PE-780059	Bearing, Bronze	45	PE-778057	Gear, Bevel (33 teeth)
4		Bearing, Bronze	46	PE-776138	Shaft, Shifter & Brake
5	PE-780061	Bearing, Bronze	47	PE-778058	Gear, Shifting (2nd & 3rd)
6	PE-786033	Plate Ass'y., Center (Incl.	48	PE-778059	Gear, Shifting (1st & Rev.)
l _		Nos. 4 & 7)	49	PE-778060	Gear, Spur (12 teeth)
7		Bearing, Bronze	50	PE-778061	Gear, Countershaft Drive
8	PE-772042	Cover Ass'y., Transaxle			(39 teeth)
	DE 700000	[(Incl. Nos. 3 & 9)	51	PE-778062	Gear, Countershaft (34
9	PE-780063	Bearing, Needle	İ		teeth)
10		Gear Ass'y., Differential (Incl. No. 11)	52	PE-778063	Gear, Countershaft (25 teeth)
11	PE-780064	Bearing, Bronze	53	PE-792034A	Key, Countershaft
12	PE-774340	Axle, Left Hand	54	PE-778064	Idler, Reverse
13	PE-774341	Axle, Right Hand	55	PE-776057	Shaft, Reverse Idler
14	PE-778067	Gear, Bevel	56	PE-786036	Spacer, Reverse Idler
15	PE-778068	Pinion, Bevel	57	PE-784087	Stop, Shifter
16	PE-786034	Pin, Drive	58	PE-788033	Gasket, Case & Cover
17	PE-780065	Washer, Thrust	59	PE-788003	Gasket, Shift Lever Hsg.
18	PE-780001	Washer, Thrust	60	PE-780093	Bearing, Ball
19	PE-788038	Ring, Snap	63	PE-780071	Bearing, Thrust
20	PE-792040	Pin, Roll	64	PE-780072	Washer, Thrust
21	PE-786035	Sleeve Ass'y., Countershaft	65	PE-780073	Washer, Thrust
1 00	DE 700000	_ (Incl. No. 22)	66	PE-792035	Ring, Snap
22	PE-780066	Bearing, Bronze	67	PE-786026	Pin, Dowel
23	PE-776090	Shaft, Idler	68	PE-788043	Seal, Oil
25	PE-784079	Rod Ass'y., Shift (1st &	69	PE-788009	Seal, Oil
1		Rev.) (Incl. Nos. 26 thru	70	PE-788035	Seal, Oil
200	DE 704004	30)	71	PE-792036	Scr., Socket Hd. Cap, 1/4-20
26	PE-784004	Fork, Shift	1		x 11/4
27	PE-784083	Rod, Shift	72	PE-792051	Scr., Socket Hd. Cap, 1/4-20
28 29	PE-792003	Spring			x 1 3/4
30	PE-792004	Ball, Steel	73	PE-792037	Scr., Hex Hd., 5/16-18 x 1
31	PE-792017	Ring, Snap	74	PE-792029	Lockwasher, 5/16"
31	PE-784084	Rod Ass'y., Shift (2nd & 3rd)	75	PE-792039	Plug, Pipe 1/8"
		(Incl. Nos. 26, 28, 29, 30,	76	PE-776155	Shaft, Input
32	PE-784085	32) Rod, Shift	77	PE-778077	Pinion, Input
33	PE-784244	Lover & Hag Assiv Chiff	78	PE-788040	Ring, Retaining
33	1 L-104244	Lever & Hsg. Ass'y., Shift (Incl. Nos. 34 thru 39)	79	PE-790006	Pad, Brake
34	PE-784088		80	PE-790007	Plate, Brake Pad
35	PE-784094	Housing, Shift Lever Keeper, Shift lever	81	PE-790005	Holder, Brake Pad
36	PE-3396P1	Lever, Shift	82	PE-790004	Lever, Brake
37	PE-792016	Ring, Snap	83	PE-792076	Washer, Flat
38	PE-792001		84	PE-792075	Nut, Lock
39	PE-792049	Ring, Quad Pin, Drive	85	PE-792073	Scr., Hex Hd. Cap, 1/4-20 x
40	PE-776154	Shaft & Gear Ass'y., Input	05 4	DE 700005	11/4 thd. forming
"	. = 1.0104	(Incl. Nos. 76, 77 & 78)	ACO	PE-792085	Scr., Hex Hd. Cap, 1/4-20 x
41	PE-786057	Block, Riser	96	DE 700000	2½ thd. forming
42	PE-782038A	Hsg. Ass'y., Axle (Incl. #43)	86	PE-790009	Disc, Brake
	PE-782043	Hsg. Ass'y., Axle (Incl. #43)	87 88	PE-792045 PE-786066	Key, Woodruff #61
43	PE-780091	Brg. & Seal Ass'y., Needle	00	-700000	Spacer
1		(See Note 1)			
	L	\/	<u> </u>		.



NOTE

The no. 780091 bearing and seal can be used interchangeably with the separate #530105 bearing and the separate no. 788042 seal.

138-493A 138-496A IF YOU WRITE TO US ABOUT THIS ARTICLE OR IF YOU ORDER REPLACEMENT PARTS AL-WAYS MENTION THIS MODEL & SERIAL NO M O D E L



· Į	REF.	PART COLOR NO. CODE		NEW	REF.		DECODIDATION	NEW
				PART		NO. CODE	DESCRIPTION	PART
ı	1	712-0113	Wing Nut Solid 1/4-20 Thd.		33	11574	Chute Cover Ass'y.	ļ
	2	12614	Battery Hold Down		35	710-0627	Hex Scr. 5/16-24 x .75" Lg.*	
	3	731-0333	Convoluted Conduit		36	736-0242	Bell. Wash345 I.D. x .88	
	4	710-0286	Truss Mach. Scr. 1/4-20 x	-			O.D.	
	_ [700 0000	.50" Lg.		37	734-0601	Rear Wheel Ass'y.—Comp.	
	5	736-0329	L-Wash. 1/4" Scr.*				18.0 x 8.50	
	6	712-0272	Hex Nut 1/4-20 Thd. Sems*		38.	738-0140	Shld. Scr437 Dia. x .180	
	7	710-0258	Hex Scr. 1/4-20 x .62" Lg.*		39	736-0264	FI-Wash344 I.D. x .62 O.D.	
	8	12811	Battery Brkt. Brace		40	712-0267	Hex Nut 5/16-18 Thd.*	1
	9	736-0329	L-Wash. 1/4" Scr.*		41	10349	Deck Link Ass'y.	
	10	712-0287	Hex Nut 1/4-20 Thd.*		42	09721	Pivot Link Ass'y.	
	11	12747	Battery Brkt.		43	09735	Connecting Rod 3/16 x 1 x	
	12	11836 —456	Hood				12.5" Lg.	
	13	725-0222	Head Lamp		44	714-0101	Inter. Cot. Pin ½" Dia.	
	14 15	731-0409	Grille		45	11029	Handle Pivot Brkt.	
	16	735-0156	Headlight Door		46	710-0201	Hex Scr. 3/8-16 x .62" Lg.*	
	17	710-0289 723-0296	Hex Scr. 1/4-20 x .50" Lg.*		47	736-0219	Bell. Wash400 I.D. x 1.13	
	18	736-0329	Hood Latch Ass'y.				O.D.	
	19	712-0287	L-Wash. 1/4" Scr.*		48	748-0201	Spacer .635 I.D. x .88 O.D.	
-	20	11027	Hex Nut 1/4-20 Thd.*				x .57	
	21	726-0121	Handle Stop Brkt. Ass'y.		49	735-0180	Rubber Wash75 I.D. x 1.25	
	22	736-0192	Push Cap ¼" Dia. Black				O.D.	
l	22	730-0192	Fl-Wash531 I.D. x 1.13		50	720-0157	Grip	
	23	714-0101	O.D.		51	749-0212	Lift Handle	
	24	10346 3636	Inter. Cot. Pin ½" Dia.		52	11032	Lift Handle Brkt. Ass'y.	
	25	1 0346 33636	Lock Out Link Ass'y.		53	736-0219	Bell. Wash400 I.D. x 1.13	
	26	10904	Lock Out Link Ass'y.			740 0004	O.D.	
-	27	732-0232	Deck Link Ass'y.		54	710-0201	Hex Scr. 3/8-16 x .62" Lg.*	1
1	28	710-0195	Spring Brkt.	N	55	712-0287	Hex Nut 1/4-20 Thd.*	İ
	29	711-0576	Hex Scr. ¼-28 x .62" Lg.* Pivot Pin		56	736-0329	L-Wash. 1/4" Scr.*	ļ
	30				57	710-0258	Hex Scr. 1/4-20 x .62" Lg.*	İ
	31		Push-on Flange Palnut Adapter Plate Ass'y.		58	711-0222	Battery Hold Down Rod	
	32		Torsion Spring		59	725-0453	Battery 12-Volt Manifold	
Ţ	<u> </u>	. 52 0201	Totalon apring	L			Vented	ŀ

^{*}For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

(456—Radiant Tangerine)

When ordering parts, if color or finish is important use the appropriate color code shown above (e.g. Radiant Tangerine Finish—11836 (456).)




NOTE

This instruction manual covers various models and all specifications shown do not necessarily apply to your model. Specifications subject to change without notice or obligation.

WHEEL CHART


	FRONT WHEEL	REAR WHEEL		
PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	
734-0497 734-0499 734-0498 734-0255	Wheel Ass'y. Comp. Rim Ass'y. Only Tire Only 15 x 6.00 Air Valve	734-0601 734-0603 734-0516 734-0255	Wheel Ass'y. Comp. Rim Ass'y. Only Tire Only 18 x 8.50 Air Valve	



A STATE OF THE PARTY OF THE PAR	REF.	PART NO.	COLOR	DESCRIPTION	NEW PART	REF.		COLOR		NEW PART
	1	731-0220)	Steering Wheel Cap		29	09095	-456	Front Axle Ass'y. R.H.	
	2	712-0158		Hex Cent. L-Nut 5/16-18 Thd.	`,	30	731-0409		Grille—Front	
	3	736-0219	9	Bell. Wash400 I.D. x 1.13	5	31	11836 -		Front Hood	
				O.D.		32	712-028	7	Hex Nut 1/4-20 Thd.*	
	4	731-0356		12.0 inch Steering Wheel		33	736-032	9	Spring L-Wash. 1/4" Scr.*	1
	5	712-0222		Push Nut 5/8" Dia.		34	710-028	6	Truss Mach. Scr. 1/4-20 x .50"	1 1
	6	736-0174	1	Wave Wash660 I.D. x .88					Lg.*	
	7	700 040	-	O.D.		35	712-037	5	Hex Cent. L-Nut 3/8-16 Thd.	1
	7 8	738-0407		Steering Shaft		36	12360		Dash Panel Ass'y.	
	9	757-0264 736-0921		Seat Ass'y. Comp.		37	736-0105		Bell. Wash.	
	10	712-0206		Spring L-Wash. ½" Scr.*	I	38	710-0250		Hex Scr. 3/8-16 x 1.00" Lg.*	
	11	09087 -		Hex Nut ½-13 Thd.*		39	747-0138		Steering Rod	İ
	12	734-0601		Rear Fender		40	717-0294		Steering Ass'y. Breakdown	
	'-	754-0001		Rear Wheel Ass'y. Comp. 18.0 x 8.50	ł	43	748-0228	3	Hex Flange Brg505 I.D.	
		734-0516	;	Rear Wheel Tire Only 18.0 x	-	44	12372		Bronze	
				8.50		45	710-0412	,	Steering Rod Brkt. Hex Scr. 1/4-28 x .75" Lg.*	
		734-0255	;	Air Valve—Tubeless		46	11048	•	Steering Segment]
,	13	734-0603		Rear Wheel Rim Ass'y.	J	47	11074		Steering Segment Steering Housing Ass'y.	1
	14	736-0242		Bell. Wash.	1	48	715-0134		Spring Pin Spir. 3/16" Dia. x	
	15	710-0258		Hex Scr. 1/4-20 x .62" Lg.*	-		,,00,0104		1.50" Lg.	
	16	736-0329		Spring L-Wash. 1/4" Scr. *	İ	49	736-0329		Spring L-Wash. 1/4" Scr.*	
	17	13322		Grille Frame		50	712-0117		Hex Nut 1/4-28 Thd. Lock*	
	18	712-0267		Hex Nut 5/16-18 Thd.*	1	51	710-0412		Hex Scr. 1/4-28 x .75" Lg.*	
	19	736-0119	-	Spring L-Wash. 5/16" Scr. *		52	710-0351		Truss Mach. B-Tapp Scr. #10	
	20	723-0241	1	Foot Pad 15.75" Lg. x 4.0"				1	x .50" La.	
CONTRACTOR OF THE PERSON			- 1	Wide		53	746-0160		Throttle Control—Comp.	
	`21	710-0259	ĺ	Hex Sems Scr. 5/16-18 x .62"	1	54	712-0147		Speed Nut #10-24 U-Type	
	22	00000		Lg.*		55	12360		Dash Panel Ass'y.	
	22 23	09098		Front Axle Ass'y. L.H.	ŀ	56	722-0111		Knob Only—Throttle Control	
	24	723-0156		Ball Joint Ass'y.		57	13466	1	Upper Frame	
	25	711-0169 710-0494		Collar 5/8" I.D.		58	748-0203	- 1	12 Teeth Spur Gear	
	23	710-0494		Sq. Hd. Set Scr. 5/16-18 x .38		60	731-0144		Vinyl Blk. Strip for Dash 12.0'	ľ
	26	711-0613		Tie Rod	1	61	710-0627		Lg.	
		748-0227		Flange Brg. 6.30 I.D.	1	01	, 10-0027		Hex Scr. w/Lock 5/16"-24 x	- 1
		723-0156	- 1:	Ball Joint Ass'y.		62	748-0228	· .	.75" Lg. Hex Flange Brg50 I.D.	ļ
			ľ	,	1	63	750-0151	- 1	Spacer .50" I.D. x .75 O.D. x	
	-				İ	30	700-0101		1.12" Lg.	
į				•		ł			z Ly.	

^{*}For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.


138-493A 138-496A



	0. N 1 712 2 736 3 756 4 714 5 712 6 736 7 710 8 712 9 736 0 134	0. 092 092 026 012 026 011 011 079	1 7 9 7 9 8 8	DESCRIPTION Hex Jam Nut ½-20 Thd.* L-Wash. ½" Scr.* Transmission Split Pulley .50" I.D. #4 Hi-Pro Key 3/32 x 5/8" Dia. Hex Nut 5/16-18 Thd.* L-Wash. 5/16" Scr.* Hex Scr. 5/16-18 x .75" Lg.* Hex Ins. L-Nut 3/8-16 Thd.	NEW PART	REF. NO. 41 42 43 44 45 46	NO. 12160 710-029 750-029 736-01 712-029	98 19	DESCRIPTION Belt Keeper Ass'y. Hex Sems Scr. 5/16-18 x .62" Lg.* Spacer .384 I.D. x .500 O.D. x 1.43" Lg. L-Wash. 5/16" Scr.* Hex Nut 5/16-18 Thd.*	NEW PART
	2 736 756 4 714 5 712 6 736 7 710 8 712 9 736 0 134	092 026 012 026 011 079 016	1 7 9 7 9 8 8	L-Wash. ½" Scr.* Transmission Split Pulley .50" I.D. #4 Hi-Pro Key 3/32 x 5/8" Dia. Hex Nut 5/16-18 Thd.* L-Wash. 5/16" Scr.* Hex Scr. 5/16-18 x .75" Lg.*		42 43 44 45	710-029 750-029 736-01 712-029	98 19	Hex Sems Scr. 5/16-18 x .62" Lg.* Spacer .384 I.D. x .500 O.D. x 1.43" Lg. L-Wash. 5/16" Scr.*	
	2 736 756 4 714 5 712 6 736 7 710 8 712 9 736 0 134	092 026 012 026 011 079 016	1 7 9 7 9 8 8	L-Wash. ½" Scr.* Transmission Split Pulley .50" I.D. #4 Hi-Pro Key 3/32 x 5/8" Dia. Hex Nut 5/16-18 Thd.* L-Wash. 5/16" Scr.* Hex Scr. 5/16-18 x .75" Lg.*		42 43 44 45	710-029 750-029 736-01 712-029	98 19	Hex Sems Scr. 5/16-18 x .62" Lg.* Spacer .384 I.D. x .500 O.D. x 1.43" Lg. L-Wash. 5/16" Scr.*	
	756 4 714 5 712 6 736 7 710 8 712 9 736 0 134	026 012 026 011 011 079 016	7 9 7 9 8 8	Transmission Split Pulley .50" I.D. #4 Hi-Pro Key 3/32 x 5/8" Dia. Hex Nut 5/16-18 Thd.* L-Wash. 5/16" Scr.* Hex Scr. 5/16-18 x .75" Lg.*		43 44 45	750-029 736-01 712-029	98 19	.62" Lg.* Spacer .384 I.D. x .500 O.D. x 1.43" Lg. L-Wash. 5/16" Scr.*	
	714 5 712 6 736 7 710 8 712 9 736 0 134	012 026 011 011 079 016	9 7 9 8 8	.50" I.D. #4 Hi-Pro Key 3/32 x 5/8" Dia. Hex Nut 5/16-18 Thd.* L-Wash. 5/16" Scr.* Hex Scr. 5/16-18 x .75" Lg.*		44 45	736-01 ⁻ 712-02	19	Spacer .384 I.D. x .500 O.D. x 1.43" Lg. L-Wash. 5/16" Scr.*	
	5 712 6 736 7 710 8 712 9 736 0 134	026 011 011 079 016	7 9 8 8	#4 Hi-Pro Key 3/32 x 5/8" Dia. Hex Nut 5/16-18 Thd.* L-Wash. 5/16" Scr.* Hex Scr. 5/16-18 x .75" Lg.*		44 45	736-01 ⁻ 712-02	19	x 1.43" Lg. L-Wash. 5/16" Scr.*	
	5 712 6 736 7 710 8 712 9 736 0 134	026 011 011 079 016	7 9 8 8	Dia. Hex Nut 5/16-18 Thd.* L-Wash. 5/16" Scr.* Hex Scr. 5/16-18 x .75" Lg.*		45	712-02		L-Wash. 5/16" Scr.*	
	6 736 7 710 8 712 9 736 0 134	011 011 079 016	9 8 8	Hex Nut 5/16-18 Thd.* L-Wash. 5/16" Scr.* Hex Scr. 5/16-18 x .75" Lg.*		45	712-02			
	6 736 7 710 8 712 9 736 0 134	011 011 079 016	9 8 8	L-Wash. 5/16" Scr.* Hex Scr. 5/16-18 x .75" Lg.*						
	7 710 8 712 9 736 0 134	011 079 016	8	Hex Scr. 5/16-18 x .75" Lg.*			747-01		Brake Rod .25" Dia. x 22.25"	1
	8 712 9 736 0 134	079 016	8	Hey Ins. L-Nut 3/8-16 Thd			• .	.	Lg.	
	9 736 0 134	016			1	47	736-02	42	Bell. Wash345 l.D. x .88	
	0 134		ગ 1	L-Wash. 3/8" Scr.*					O.D.	
1	1 700	8		Transaxle "U" Brkt.	N	48	710-03	71	Hex Scr. 5/16-18 x .88" Spec.	
1	1 / 32	015	7	Spring .38 O.D. x 3.25" Lg.		49	717-03		Shift Lever for Transaxle	
1				"Ú"-Bolt 5/16-18 Thd.		50	720-01		Gear Shift Knob	
1	3 _			Transaxle Complete		51	13435		Transaxle Support Brkt.	N
1	4 _			Engine	1	52	710-02	58	Hex Scr. ¼-20 x .62" Lg.*	
1	5 710	044	2	Hex Scr. 5/16-18 x 1.50"		53	736-03	29	L-Wash. 1/4" Scr.*	i I
				Lg.*		54	712-02		Hex Nut 1/4-20 Thd.*	1
1	ô -			Part of Engine		55	710-01	94	Hex Scr. 3/8-16 x 3.00" Lg.*	1
1	7 136	6		Steering Support Plate	N	56	11039		Pedal "U"-Brkt. Ass'y.	
1	6 110			Parking Brake Lever Ass'y.		57	710-01	98	Hex Sems Scr. 5/16-18 x	
	7 123			Clutch Pedal Pad					.75" Lg.	1 1
	8 110			Clutch Pedal Ass'y.		58	12378		Brake Pedal Pad	
	9 714		7	Cotter Pin 3/32" Dia. x .75"		59	10410		Spring Brkt.	
				Lg.*		60	761-01	69	Blade Brake Ass'y. 2.60 High	
3	0 747	011	7	Clutch Rod					(Not Shown)	
3				Belt Guard Ass'y.—Engine		61	726-01	21	Push Cap 1/4" Dia. Black	. 1
3	2 124	8		Idler Brkt. Ass'y.		62	12813		Brake Pedal Ass'y.	
	3 712	015	8	Hex Cent. L-Nut 5/16-18		63	732-02	45	Extension Spring .90 O.D.	
				Thd.			700.04		x 3.75" Lg.	
3	4 128	6		Parking Brake—Lever		64	738-01		Shld. Scr437 Dia. x .180	.
				Ass'y. R.H.		65	710-03	22	Hex Sems Scr. 5/16-18 x	İ
3	5 712	037	5	Hex Cent. L-Nut 3/8-16		66	722.044	24	1.00" Lg.*	
				Thd.		66 67	732-019		Spring .75 O.D. x 11.00" Lg.	
3	6 711	063	0	Spacer .380 I.D. x .50 O.D.		68	736-01		L-Wash. 5/16" Scr.*	1
				x .562		69	712-020 712-020		Hex Nut 5/16-18 Thd.*	
3			7	Hex Nut 5/16-18 Thd.*		70	736-01		Hex Nut 5/16-18 Thd.* L-Wash. 5/16" Scr.*	
3			_	Frame Ass'y.		71	710-020		Carr. Bolt 5/16-18 x 1.50"	
3	9 736	010	5	BellWash400 I.D. x .88		′'	110-020	ا عد	Lg.*	
		001	_	O.D.		72	712-026	37	Hex Nut 5/16-18 Thd.*	
4	0 738	U21	5	Shld. Scr489" Dia. x		, _	112-020	-	HOX HUL O/ 10-10 HIQ.	
				3.00" Lg.						

^{*}For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.


138-493A 138-496A



	PARTS LIST FOR WICE			DELO	130-4	33A AND 130-4	20A	
	REF. NO.	PART COLO	DR DESCRIPTION	NEW PART		PART COLOR NO. CODE	DESCRIPTION	NEW PART
	1	756-0251	Deck Pulley 4.75" O.D.		33	10949	Spring Lever Ass'y, w/Knob	
- 1	2	754-0145	"V"-Belt 21/32 x 69" Lg.		34	736-0329	L-Wash. 1/4" Scr.*	
	-	10101.0	(Blade Drive Belt)		35	712-0287	Hex Nut 1/4-20 Thd.*	
	3	754-0226	"V"-Belt ½ x 65" Lg.		36	736-0105	Bell. Wash400 l.D. x .88	
			(Transmission)				O.D.	
	4	756-0302	Two Step Engine Pulley		37	10937	Wheel Pivot Bar	
1	5	711-0572	Step Washer		38	11236	Wheel Brkt. Ass'y.—R.H.	
1	6	736-0169	L-Wash. 3/8" Scr.*				(Deck)	
	7	710-0152	Hex Scr. 3/8-24 x 1.00" Lg.*		39	736-0329	L-Wash. ¼" Scr.*	
	8	12672	Belt Guard—L.H. Deck		40	712-0287	Hex Nut 1/4-20 Thd.*	
İ	9	12405	Deck Spring Brkt.		41	12673	Belt Guard—R.H. (Deck)	
Ì	10	09164	Deck Reinforcement Plate		42	732-0307	Extension Spring	
-	11	13454	38" Deck Ass'y.		43	711-0255	Blade Spindle	
	12	09164	Deck Reinforcement Plate		44	714-0365	#6_Hi-Pro Key 5/32 x 5/8"	
	13	710-0322	Hex Sems Scr. 5/16-18 x				Dia.	
			1.00" Lg.*		45	09321	Spindle Ass'y. Comp.	
	14	710-0289	Hex Scr. 1/4-20 x .50" Lg.*		1 40	00050	(Deck)	
	15	712-0123	Hex Nut 5/16-24 Thd.*		46	08253	Bearing Housing	1 1
	16	736-0119	L-Wash. 5/16" Scr.* 19" Blade		47	741-0919	Ball Brg787 I.D. x 1.85 O.D.	
	17 18	742-0122	Hex Scr. 5/16-24 x 1.00" Lg.		48	08253	Bearing Housing	
	19	710-0117 710-0459	Hex Scr. 3/8-24 x 1.50" Lg.		49	736-0329	L-Wash. 1/4" Scr.*	
	19	710-0459	H.T.		50		Hex Nut 1/4-20 Thd.*	
	20	736-0217	L-Wash. 3/8" Scr. (Heavy		51	09322	Blade Brake Disc	
	20	730-0217	Duty)		55	712-0261	Hex Jam Nut 5/8-11 Thd.	
	21	10769	Blade Adapter Kit			736-0158	L-Wash. 5/8" Scr.*	
	22	710-0289	Hex Scr. 1/4-20 x .50" Lg.*		57	756-0251	Deck Pulley 4.75" O.D.	
	23	711-0571	Pivot Pin	1	58	756-0116	"V"-Belt Idler 3.06" O.D.	
Projections.	24	11399	Adapter Plate Ass'y.	1	59	756-0217	Fl. Idler 2.75" O.D.	
	25	732-0261	Torsion Spring				w/Flanges	
	26	710-0195	Hex Scr. 1/4-28 x .62" Lg.*		60	712-0116	Hex Ins. L-Nut 3/8-24 Thd.	
	27	11633	Chute Cover Ass'y.	1	61	11237	Wheel Brkt. Ass'yL.H.	
	28	726-0106	Push Nut-1/4" Rod				(Deck)	
	29	738-0119	Shld. Scr625" Dia. x 1.75"		62	13453	38" Deck Ass'y. Comp. (For	1 1
			Lg.				Service)	-
	30	734-0796	Wheel Ass'y.—5.0 x 1.25		63	732-0332	Belt Trap	
			Dia. (Deck)		64	736-0287	FI-Wash793 I.D. x 1.2	4
	31	712-0116	Hex Ins. L-Nut 3/8-24 Thd.				x .060	
	32	736-0105	Bell. Wash400 I.D. x .88					
	1		O.D.	Ţ			 	t 1


^{*}For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

138-493A



PARTS LIST FOR ELECTRICAL SYSTEM MODEL 138-493A


Г,	<u>AN I</u>	S LIST FUR E	LECTRICAL SYSTEM MODEL 1	38-49
	REF. NO.	PART NO.	DESCRIPTION	NEW PART
	1 2 3 4 5 6 7 8 9 10 11 12 13 14	725-0201 725-0380 725-0615 725-0222 725-0202 725-0530 725-0422 12356 725-0379 725-0428 725-0453 725-0122 725-0119 725-0268	Ignition Key Ignition Switch Wire Harness Headlight Light Switch Solenoid Electric Wire Warning Light Brkt. Safety Switch—Red, N.C. Indicator Light 12 V Battery (Manifold Type) Electric Wire Ammeter Safety Switch—Black, N.O.	N



18	
	7
1	
16	ll war dewel. Iwar dewel


		Ö		
PA	RTS LIS	T FOR E	LECTRICAL SCHEMATIC	
REF.	PART NO.	COLOR	DESCRIPTION	NEW PART
1	725-022	22	Headlights	
2	725-053	30	Solenoid	
2	725-011	9	Ammeter	i e
5	725-037	9	Safety Switch—Red, w/o Brkt.	
6	12356		Warning Light Brkt.	
6 7	725-042	28	Brake Indicator Light	
8 9	725-036	4	Wiring Harness	
9	725-020	11	Ignition Key	
10	725-026	7	Ignition Switch	
11	725-045	3	Battery	
12	725-020	2	Headlight Switch	
13	725-026	8	Safety Switch—Black w/Brkt.	
14	725-012	:1	Electric Wire	
15	725-012	2	Electric Wire	
16	12614		Battery Hold Down	
17	711-022	2	Hold Down Rods	
18	712-011	3	Wing Nuts	

138-493A 138-496A



PARTS LIST FOR MODELS 138-493A AND 138-496A

FARTS LIST FOR MODELS 138-493A AND 138-490A				
REF. NO.	PART NO.	DESCRIPTION	NEW PART	
1 2 3 4 5 6 7 8 9	725-0201 725-0267 725-0119 725-0202 725-0364 726-0152 725-0268 725-0530 725-0298	Ignition Key Ignition Switch Ammeter Headlight Switch Wire Harness Mtg. Clamp Safety Switch Solenoid Fuse 7½ Amp ¼ Dia. x 1.29 Lg. Safety Switch	5	
11 12	725-0379 725-0428	Safety Switch—Red w/Brk Indicator Light	t.	



REF. NO.	PART NO.	DESCRIPTION	NEW ART
1	731-0333	Convoluted Conduit	
2	726-0154	Push Mtg. Ties 3/8 I.D.	
3	725-0453	Push Mtg. Ties 3/8 I.D. Battery 12 V-Manifold Venter	b
4	725-0503	Battery Cable Harness	
5	725-0121	Electric Wire	
6	726-0152	Mtg. Clamp	

PARTS INFORMATION

POWER EQUIPMENT PARTS AND SERVICE

Parts and service for all MTD manufactured power equipment are available through the authorized service firms listed below. All orders should specify the model number of your unit, parts number, description of parts and the quantity of each part required.

ALABAMA	BIRMINGHAM
Auto Electric & Carburetor	Co 2625 4th Ave. S 35233
ΑΡΚΑΝΚΑΚ	NORTH LITTLE ROCK
Sutton's Lawn Mower Shop	Rt. 4, Box 368 72117
	FORT SMITH
Mity Mite Motors, Inc	2515 Towson Ave 72901
CALIFORNIA	PORTERVILLE 75 North D Street 93257
Billious	75 North D Street 93257
	SAN BERNARDINO
Lawn Mower Supply Co	
LW Jamest Co	SAN FRANCISCO 981 Folsom St 94107
J.W. Jewell Co	CACDAMENTO
Luttia & Severson	SACRAMENTO 2030 28th St 95818
COLORADO	DENVER
South Denver Lawn Equip.	527 West Evans 80223
FLORIDA	JACKSONVILLE
Radco Distributors	JACKSONVILLE 2403 Market St 32206
	CORAL GABLES 365 Greco Ave 33146
Moz-All of Florida, Inc	365 Greco Ave 33146
GEORGIA	EAST POINT 2834 Church St 30344
East Point Cycle & Key	2834 Church St 30344
ILLINOIS	LYONS 8615 Ogden Ave 60534
Keen Edge Co	8615 Ogden Ave 60534
INDIANA	ELKHART2101 Industrial Pkwy 46514
IOWA	DUBUQUE uip 2551 J.F. Kennedy 52001
Subren Engine Co	NEW ORLEANS 8330 Earhart Blvd70118
MARYLAND	TAKOMA PARK
Center Supply Co	TAKOMA PARK 6867 New Hampshire Ave. 20012
MASSACHUSETTS	SPRINGFIELD 300 Birnie Ave 01107
Morton B. Collins Co	300 Birnie Ave 01107
MICHIGAN	MOUNT CLEMENS36463 South Gratiot 48043
Power Equipment Dist	36463 South Gratiot 48043
	LANSING 2500 S. Pennsylvania 48900
Lorenz Service Co	2500 S. Pennsylvania 48900
MINNESOTA	MINNETONKA11212 Wayzata Blvd 55343
AMEGICE DISTIDUTING INC	BILOVI
MISSISSIPPI Rilaxi Sales & Service Inc.	BILOXI 506 Caillavet St 39533
AAISSOLIDI	KANSASCITV
Automotive Equip. Service	e 64109
	ST. LOUIS
Henzler, Inc	ST. LOUIS 2015 Lemay Ferry Rd 63125
NEW JERSEY	BELLMAWR
Lawnmower Parts Inc	717 Creek Rd., P.O. Box 7 . 08030
NEW YORK	CARTHAGE West End Ave 13619
	West End Ave 13619

BRIGGS & STRATTON, TECUMSEH AND PEERLESS PARTS AND SERVICE

Briggs & Stratton, Tecumseh and Peerless parts and service should be handled by your nearest authorized engine service firm. Check the yellow pages of your telephone directory under the listing **Engines—Gasoline**, Briggs & Stratton or Tecumseh Lauson.

NORTH CAROLINA	GREENSBORO
	GOLDSBORO
Smith Hardware Co	515 N. George St 27530
OHIO National Control	WADSWORTH 687 Seville Rd 44281
	CLEVELAND
Bleckrie, Inc	7900 Lorain Ave 44102
Stahe's Mid-State Mower	CARROLL Supply . Box 366
	WILLARD
	Outlet Route 224
OKLAHOMA Victory Motors, Inc	MUSKOGEE 605 S. Cherokee 74401
,	ADA 301 E. 12th St 74820
Ada Auto Supply	301 E, 12th St 74820
OREGON Kenton Supply Co	PORTLAND 8216 N. Denver Ave 97217
PENNSYLVANIA	HARRISBURG 4021 N. 6th St 17110
Eeco Inc	4021 N. 6th St 17110
T	PHILADELPHIA 5222-24 N Fifth St 19120
Thompson Rubber Co	BITTEDLIDEL
Bluemont Co	PITTSBURGH 11125 Frankstown Rd 15235
TENNESSEE	KNOXVILLE 2423 Broadway, N.E 37917
master kepair service	AAEAADLIC
Memphis Cycle & Supply	MEMPHIS Co 421 Monroe Ave
American Sales & Service	e, Inc 1922 Lynnbrook 3811c
TEXAS	DALLAS 423 E. Jefferson 75203
Morr bromers, inc	HOUSTON
Bullard Supply Co	HOUSTON 2409 Commerce St 77003
	SAN ANTONIO P.O. Box 2408 78206
Catto & Putty, Inc	P.O. Box 2408
Woodson Sales Corn	FORT WORTH 1702 N. Sylvania 76111
UTAH	SALT LAKE CITY
A-1 Engine & Mower Co.	SALT LAKE CITY 437 E. 9th St 84111
VERMONT	BURLINGTON 44 Lakeside Ave
Vermont Appliance Co	PICHAOND
RBI Corp.	RICHMOND 963 Myers St
WASHINGTON	SEATTLE
Bailey's Rebuild, Inc	1325 E. Madison St 98102
WEST VIRGINIA	CHARLESTON 233 Virginia St., E 25301
Young's, Inc.	233 Virginia St., E 25301
WISCONSIN Automotive Supply Co	123 S. Linwood Ave 54911
• • •	

WARRANTY PARTS AND SERVICE POLICY

The purpose of warranty is to protect the customer from defects in workmanship and materials, defects which are NOT detected at the time of manufacture. It does not provide for the unlimited and unrestricted replacement of parts. Use and maintenance are the responsibility of the customer. The manufacturer cannot assume responsibility for conditions which it has no control. Simply put, if it's the manufacturer's fault, it's the manufacturer's responsibility; if it's the customer's fault, it's the customer's responsibility.

CLAIMS AGAINST THE MANUFACTURER'S WARRANTY INCLUDES

- 1. Replacement of Missing Parts on new equipment.
- 2. Replacement of Defective Parts within the warranty period.
- 3. Repair of Defects within the warranty period.

All claims MUST be substantiated with the following information:

- 1. Model Number of unit involved.
- 2. Date unit was purchased or first put into service.
- 3. Date of failure.
- 4. Nature of failure.