


PRO-FORM[®] 975s

Model No. PFCCEX97573

Serial No. _____



Serial
Number
Decal

USER'S MANUAL

QUESTIONS?

As a manufacturer, we are committed to providing complete customer satisfaction. If you have questions, or if there are missing or damaged parts, we will guarantee complete satisfaction through direct assistance from our factory.

TO AVOID UNNECESSARY DELAYS, PLEASE CALL DIRECT TO OUR TOLL-FREE CUSTOMER HOT LINE. The trained technicians on our customer hot line will provide immediate assistance, free of charge to you.

CUSTOMER HOT LINE:

1-888-936-4266

Mon.-Fri., 8h00-18h30 EST
Eastern Standard Time (excluding holidays)



Patent Pending

CAUTION

Read all precautions and instructions in this manual before using this equipment. Keep this manual for future reference.



Visit our website at

www.proform.com

*new products, prizes,
fitness tips, and much more!*


TABLE OF CONTENTS

| | |
|-------------------------------------|-----------|
| IMPORTANT PRECAUTIONS | 2 |
| BEFORE YOU BEGIN | 3 |
| ASSEMBLY | 4 |
| HOW TO USE THE RECUMBENT BIKE | 8 |
| HOW TO USE THE PULSE SENSOR | 9 |
| MAINTENANCE AND STORAGE | 12 |
| CONDITIONING GUIDELINES | 13 |
| PART LIST | 16 |
| EXPLODED DRAWING | 17 |
| CUSTOMER RECORD | 18 |
| ORDERING REPLACEMENT PARTS | 19 |
| LIMITED WARRANTY | Back Page |

IMPORTANT PRECAUTIONS

WARNING: To reduce the risk of serious injury, read the following important precautions before using the recumbent bike.

1. Read all instructions in this manual before using the recumbent bike.
2. It is the responsibility of the owner to ensure that all users of the recumbent bike are adequately informed of all precautions. Use the recumbent bike only as described in this manual.
3. Use the recumbent bike indoors on a level surface. Keep the recumbent bike away from moisture and dust. Place a mat under the recumbent bike to protect the floor or carpet.
4. Inspect and tighten all parts regularly. Replace any worn parts immediately.
5. Keep children under the age of 12 and pets away from the recumbent bike at all times.
6. The recumbent bike should not be used by persons weighing more than 250 pounds.
7. Wear appropriate clothing when exercising; do not wear loose clothing that could become caught on the recumbent bike. Always wear athletic shoes when using the recumbent bike.
8. Always keep your back straight when using the recumbent bike. Do not arch your back.
9. If you feel pain or dizziness at any time while exercising, stop immediately and begin cooling down.
10. The recumbent bike is intended for in-home use only. Do not use the recumbent bike in a commercial, rental, or institutional setting.
11. **CAUTION DECAL PLACEMENT:** The decal shown below has been placed on the recumbent bike. If the decal is missing, or if it is not legible, please call our Customer Service Department toll-free at 1-888-936-4266 to order a free replacement decal. Apply the decal in the location shown.



WARNING: Before beginning this or any exercise program, consult your physician. This is especially important for persons over the age of 35 or persons with pre-existing health problems. Read all instructions before using. ICON assumes no responsibility for personal injury or property damage sustained by or through the use of this product.


BEFORE YOU BEGIN

Thank you for selecting the innovative PROFORM® 975s recumbent bike. The recumbent bike offers a unique form of low-impact exercise that offers greater cardiovascular benefits and increased muscle toning. And the recumbent bike features adjustable resistance to let you tailor your exercise to the level that's perfect for you.

For your benefit, read this manual carefully before you use the recumbent bike. If you have additional questions, please call our Customer Service Department toll-free at 1-888-936-4266, Monday

through Friday, 8 a.m. until 6:30 p.m. Eastern Standard Time (excluding holidays). To help us assist you, please mention the product model number and serial number when calling. The model number is PFCCEX97573. The serial number can be found on a decal attached to the recumbent bike (see the front cover of this manual for the location of the decal).

Before reading further, please look at the drawing below and familiarize yourself with the parts that are labeled.












ASSEMBLY

Place all parts of recumbent bike in a cleared area and remove the packing materials. **Do not dispose of the packing materials until assembly is completed.**

Assembly requires the included tools and your own adjustable wrench  and phillips screwdriver .


PART CHART

Use the part drawings below to identify the small parts used in assembly. The number in parenthesis below each drawing refers to the key number of the part. The second number refers to the quantity used in assembly. **Note: Some small parts may have been pre-attached for shipping. If a part is not in the parts bag, check to see if it has been pre-assembled.**


| | | | | |
|--|---|--|---|---|
|  |  |  |  |  |
| M6 Split Washer (67)–4 | M10 Split Washer (26)–3 | M10 Flat Washer (71)–4 | M6 Nylon Locknut (66)–4 | M10 Nylon Locknut (72)–8 |
|  |  |  |  | |
| M4 x 16mm Screw (34)–1 | #8 x 5/8" Screw (22)–4 | M6 x 16mm Hex Head Screw (24)–8 | M6 x 25mm Hex Head Screw (14)–4 | |
|  |  |  | | |
| M6 x 38mm Button Head Bolt (18)–4 | M10 x 25mm Button Head Screw (25)–3 | M10 x 58mm Carriage Bolt (74)–4 | | |
|  | | | | |
| M10 x 105mm Button Head Bolt (70)–4 | | | | |

1. Loosen the Lock Knob (68) on the right side of the Frame (1). Slide the Seat Frame (3) out until it stops. Tighten the Lock Knob.


Identify the Rear Stabilizer (76), which has no wheels. Attach the Rear Stabilizer to the Seat Frame (3) with two M10 x 58mm Carriage Bolts (74) and two M10 Nylon Locknuts (72).



2. Identify the Front Stabilizer (75), which has wheels. Attach the Front Stabilizer to the Frame (1) with two M10 x 58mm Carriage Bolts (74) and two M10 Nylon Locknuts (72).




3. Attach the Upright (2) to the Frame (1) with three M10 x 25mm Button Head Screws (25) and three M10 Split Washers (26). **Be careful not to pinch the Reed Switch Wire (13) or the Resistance Cable (10).**



4. Route both Adapters (73) up through the Upright (2) as shown.

Attach the Handlebar (4) to the Upright (2) with two M6 x 25mm Hex Head Screws (14) and two M6 Split Washers (67), **but do not tighten the Screws yet. Make sure that the Screws are threaded into the indicated holes. Note: Two additional Screws will be attached in step 6.**



5. Connect the Reed Switch Wire (13) and the two Adapters (73) to the corresponding wires on the Console (8).

If your Console (8) has a ground wire, attach it to the Upright (2) with an M4 x 16mm Screw (34).





Next, attach the Console (8) to the Upright (2) with four #8 x 5/8" Screws (22).

Press the Resistance Knob (9) onto the Resistance Control (10). Be sure that the mark on the Knob is correctly aligned.

6. Finish attaching the Handlebar (4) to the Upright (2) with two more M6 x 25mm Hex Head Screws (14) and two more M6 Split Washers (67). **Tighten all four Hex Head Screws.**


7. Attach the Seat Bracket (69) to the Seat Frame (3) with four M10 x 105mm Button Head Bolts (70), four M10 Flat Washers (71), and four M10 Nylon Locknuts (72).

8. Attach the Seat (16) to the Seat Bracket (69) with four M6 x 16mm Hex Head Screws (24).




9. Attach a Seat Handle (17) to the Seat Bracket (69) with two M6 x 38mm Button Head Bolts (18) and two M6 Nylon Locknuts (66).

Attach the other Seat Handle (17) to the Seat Bracket (69) in the same manner.



10. Attach the Backrest (15) to the Seat Bracket (69) with four M6 x 16mm Hex Head Screws (24).




11. Identify the Left Pedal (45) (there is an “L” on the Left Pedal for identification). Using an adjustable wrench, tighten the Left Pedal *counterclockwise* into the left arm of the Crank (29).


Tighten the Right Pedal (not shown) *clockwise* into the right arm of the Crank (29).

Adjust the Left Pedal Strap (27) on the Left Pedal (45) to the desired position. Press the Pedal Strap onto the adjustment tab on the Left Pedal.

Adjust the Pedal Strap on the Right Pedal (not shown) in the same manner.



12. The Console (8) requires either two or three “AA” batteries (not included); alkaline batteries are recommended. Open the battery cover (not shown) on the back of the Console. Press the batteries into the battery clip. **Make sure that the negative (-) ends of the batteries are touching the springs.** Close the battery cover. Note: If the battery clip holds three batteries, you must insert three batteries.




13. **Make sure that all parts are properly tightened before you use the recumbent bike.** Note: There may be some hardware left over after assembly is completed.

HOW TO USE THE RECUMBENT BIKE


HOW TO ADJUST THE POSITION OF THE SEAT FRAME

The Seat Frame (3) can be adjusted to the position that is the most comfortable for you. To adjust the Seat Frame, first loosen the Lock Knob (68) on the right side of the Frame (1). Slide the Seat Frame forward or backward to the desired position. Tighten the Lock Knob.




HOW TO ADJUST THE PEDAL STRAPS

To adjust each Pedal Strap (27, 31 [not shown]), first pull the end of the Pedal Strap off the adjustment tab on the Left Pedal (45). Align a different hole in the Pedal Strap with the adjustment tab. Press the Pedal Strap onto the adjustment tab.



HOW TO ADJUST THE PEDALING RESISTANCE


The pedaling resistance can be adjusted with the Resistance Knob (9) located on the Console (8). To increase the resistance, turn the Resistance Knob clockwise; to decrease the resistance, turn the Resistance Knob counterclockwise.



HOW TO USE THE PULSE SENSOR

The convenient pulse sensor allows you to measure your heart rate periodically. You can measure your heart rate before you begin exercising, during your workout, and again when you finish.

Note: Before you can use the pulse sensor, you must peel the protective vinyl covering off the metal contacts on the front and rear of each pulse grip.



To use the pulse sensor, first make sure that the power is turned on. Stop exercising, rest both feet on the floor, and place your hands on the metal contacts. Your palms must be resting on the inner contacts and your fingers must be touching the outer contacts. Avoid moving your hands. After a moment, the heart indicator in the PULSE display will flash and your heart rate will be shown. For the most accurate heart rate reading, continue to hold the contacts for about 15 seconds.


HAND PULSE SENSOR TROUBLE-SHOOTING

- Avoid moving your hands while using the pulse sensor. Excessive movement may interfere with heart rate readings. If the pulse sensor is not used correct-

ly, the heart indicator will flash repeatedly in the PULSE display but your heart rate will not be shown.

- If an "L" appears in the PULSE display, then the pulse sensor received too little pulse information to accurately calculate your pulse. Let go of the metal contacts; then place your hands on the contacts again. Your palms must be resting on the inner contacts and your fingers must be touching the outer contacts.
- If an "H" appears in the PULSE display, then the pulse sensor received too much pulse information to accurately calculate your pulse. Let go of the metal contacts; then place your hands on the contacts again. Your palms must be resting on the inner contacts and your fingers must be touching the outer contacts.
- Do not hold the metal contacts too tightly; doing so may interfere with heart rate readings.
- Do not move your hands while you hold the metal contacts; your muscle movement may interfere with heart rate readings.
- For the most accurate heart rate reading, wait for about 15 seconds.
- For optimal performance of the pulse sensor, keep the metal contacts clean. The contacts can be cleaned with a soft cloth—never use alcohol, abrasives, or chemicals.

DIAGRAM OF THE CONSOLE




DESCRIPTION OF THE CONSOLE

The innovative console offers a manual mode and three pacer programs. The pacer programs are designed to help you achieve your exercise goals by pacing your exercise. The programs include an 18 MPH/90 RPM program, a 12 MPH/60 RPM program, and a 6 MPH/30 RPM program. The console also features five monitor modes that provide continuous exercise feedback. **Note: On some consoles the programs are listed in MPH and on others in RPM. Both sets of programs are identical.**

HOW THE PACER PROGRAMS OPERATE

When you use a pacer program, an indicator will light on each track of the P.A.C.E.R. display. The outer track shows a target pace; the inner track will show your actual pace. The target pace will



change periodically during the 18 MPH/90 RPM and 12 MPH/60 RPM programs; as the target pace changes, simply adjust your pace to keep both indicators even. **Important: The target pace is a goal pace. Your actual pace may be slower than the target pace, especially during the first few months of your exercise program. Be sure to exercise at a pace that is comfortable for you.**

The graphs on the left side of the console show how the target pace will change during each program (see the drawing above). Each graph is divided into ten columns, and each column represents 1/10 of a mile. The bars in each column show what the target pace will be during that 1/10 of a mile. For example, in the first column of the 12 MPH/60 RPM graph, there is one bar. This shows that during the first 1/10 of a mile in this program, the target pace will be 6 MPH (30 RPM). In the second column, there are two bars, indicating that the pace is now 12 MPH (60 RPM).

DESCRIPTION OF THE MONITOR MODES

The five following monitor modes provide continuous exercise feedback. The modes are described on the next page.


- **SPEED**—This mode shows your pace, in miles per hour.
- **TIME**—This mode counts the length of time you have exercised. Note: If you stop exercising for ten seconds or longer, the time mode will pause.
- **DIST (Distance)** —This mode shows the total number of miles you have cycled, up to 999. The display will then reset to zero and continue counting.
- **LAPS**—This mode shows the number of quarter-mile laps you have completed.
- **CAL (Calories)**—This mode shows the approximate number of calories you have burned.

STEP-BY-STEP CONSOLE OPERATION

Before the console can be operated, batteries must be installed. (See assembly step 12 on page 7 for installation instructions.) Follow the steps below to operate the console.


1 Turn on the power

To turn on the power, press the on/reset button or simply begin exercising. When the power is turned on, the entire display will appear for two seconds. The console will then be ready for use. Note: If batteries were just installed, the power will already be on.




2 Select one of the three pacer programs or the manual mode

When the power is first turned on, the console will be in the manual mode. To select one of the pacer programs, repeatedly press the program button. The program indicator will show which program you have selected. The programs will be selected in the following order: the manual mode, the 6 MPH/30 RPM program, the 12 MPH/60 RPM program, and the 18 MPH/ 90 RPM program. Note: Once you select a pacer program, you can reselect the manual mode by repeatedly pressing the program button.



3 Begin your workout


If you selected the manual mode, one indicator on the inner P.A.C.E.R. track will light. As you exercise, this indicator will move around the quarter-mile track.




If you selected a pacer program, two indicators on the P.A.C.E.R. track will light. The indicator on the inner track will show your actual pace. The indicator on the outer track will move around the track at the programmed pace. As you exercise, adjust your pace so that the indicators on the inner and outer tracks remain even. As the program progresses, the target pace will change periodically; as the target pace changes, you should also adjust your pace. **Important: The target pace is a goal pace. Your actual pace may be slower than the target pace, especially during the first few months of your exercise program. Be sure to exercise at a pace that is comfortable for you.**

4 Follow your progress with the monitor modes

When the power is turned on, the console will scan through the five modes automatically. A flashing mode indicator will show which mode is currently displayed. When the Laps mode is displayed, an “L” will also appear. If desired, the display can be reset by pressing the on/reset button.



The recumbent bike also features an innovative handgrip pulse sensor. The pulse display allows you to monitor your heart rate during your workout. To use the pulse sensor, see page 9.



5 Turn off the power

To turn off the power, simply wait for about six minutes. If the pedals are not moved and the console buttons are not pressed for six minutes, the power will turn off automatically.

MAINTENANCE AND STORAGE


Inspect and tighten all parts of the recumbent bike regularly. The recumbent bike can be cleaned with a soft, damp cloth. To prevent damage to the console, keep liquids away and keep the console out of direct sunlight.

BATTERY REPLACEMENT

If the console does not function properly, the batteries should be replaced. To replace the batteries, refer to assembly step 12 on page 7.

CRANK ADJUSTMENT


If the arms of the Crank (29) become loose, they should be tightened in order to prevent excessive wear. Loosen the crank nut on the left arm of the Crank. Place the end of a standard screw-



driver in one of the slots in the slotted bearing nut. Lightly tap the screwdriver with a hammer to turn the slotted bearing nut counterclockwise until the arms are no longer loose. **Do not overtighten the slotted bearing nut.** When the slotted bearing nut is properly tightened, tighten the crank nut.

HOW TO STORE THE RECUMBENT BIKE

When the recumbent bike is not in use, it can be folded for compact storage. Refer to the drawing at the right. Loosen the Lock Knob (68) on the right side of the Frame (1). Slide the Seat Frame (3) as far into the Frame as it will go. Tighten the Lock Knob. Store the recumbent bike indoors, away from moisture and dust.



CONDITIONING GUIDELINES

The following guidelines will help you to plan your exercise program. Remember that proper nutrition and adequate rest are essential for successful results.

WARNING: Before beginning this or any exercise program, consult your physician. This is especially important for individuals over the age of 35 or individuals with pre-existing health problems.

WHY EXERCISE?

Exercise has proven essential for good health and general well-being. Regular participation in a well-rounded exercise program results in a stronger and more efficient heart, improved respiratory function, increased stamina and endurance, better weight management and body fat control, increased ability to deal with stress, and greater self-esteem and confidence.


EXERCISE INTENSITY

To maximize the benefits of exercising, it is important to exercise with the proper intensity. The proper intensity level can be found by using your heart rate as a guide. For effective aerobic exercise, your heart rate should be maintained at a level between 70% and 85% of your maximum heart rate as you exercise. This is known as your training zone. You can find your training zone in the table below. Training zones are listed according to age and physical condition.

| AGE | TRAINING ZONE (BEATS/MIN.) | |
|-----|----------------------------|-------------|
| | UNCONDITIONED | CONDITIONED |
| 20 | 138–167 | 133–162 |
| 25 | 136–166 | 132–160 |
| 30 | 135–164 | 130–158 |
| 35 | 134–162 | 129–156 |
| 40 | 132–161 | 127–155 |
| 45 | 131–159 | 125–153 |
| 50 | 129–156 | 124–150 |
| 55 | 127–155 | 122–149 |
| 60 | 126–153 | 121–147 |
| 65 | 125–151 | 119–145 |
| 70 | 123–150 | 118–144 |
| 75 | 122–147 | 117–142 |
| 80 | 120–146 | 115–140 |
| 85 | 118–144 | 114–139 |

During the first few months of your exercise program, keep your heart rate near the low end of your training zone as you exercise. After a few months of regular exercise, your heart rate can be increased gradually until it is near the middle of your training zone as you exercise.

To measure your heart rate, use the pulse sensor in the handlebar. You can also measure your pulse by placing two fingers on your wrist. Stop exercising and take a six-second heartbeat count. Multiply the result by ten to find your heart rate. (A six-second count is used because your heart rate drops quickly when you stop exercising.) If your heart rate is too high, decrease the intensity of your exercise. If your heart rate is too low, increase the intensity of your exercise.



WORKOUT GUIDELINES

A well-rounded workout includes three important parts:

A warm-up, lasting 5 to 10 minutes. Begin with slow, controlled stretches, and progress to more rhythmic stretches. This will increase the body temperature, heart rate, and circulation in preparation for strenuous exercise.

A training zone exercise, including 20 to 30 minutes of exercising with your heart rate in your training zone.

A cool-down, consisting of 5 to 10 minutes of stretching. Thorough stretching offsets muscle contractions and other problems caused when you stop exercising suddenly. Stretching for increased flexibility is often most effective during this phase. This phase should leave you relaxed and comfortably tired.

To maintain or improve your condition, complete three workouts each week, with at least one day of rest between workouts. After a few months of regular exercise, you may complete up to five workouts each week, if desired. Find the best time of day for your workouts, and then stick with it.

Remember, the key to success is to make exercise a regular and enjoyable part of your everyday life.

SUGGESTED STRETCHES

The correct form for several basic stretches is shown below. Move slowly as you stretch—never bounce.

1. Toe Touch Stretch

Stand with your knees bent slightly and slowly bend forward from your hips. Allow your back and shoulders to relax as you reach down toward your toes as far as possible. Hold for 15 counts, then relax. Repeat 3 times.

Stretches: Hamstrings, back of knees and back

2. Hamstring Stretch

Sit with one leg extended. Bring the sole of the opposite foot toward you and rest it against the inner thigh of your extended leg. Reach toward your toes as far as possible. Hold for 15 counts, then relax. Repeat 3 times for each leg.

Stretches: Hamstrings, lower back and groin

3. Calf/Achilles Stretch

With one leg in front of the other, reach forward and place your hands against a wall. Keep your back leg straight and your back foot flat on the floor. Bend your front leg, lean forward and move your hips toward the wall. Hold for 15 counts, then relax. Repeat 3 times for each leg. To cause further stretching of the achilles tendons, bend your back leg as well.

Stretches: Calves, achilles tendons and ankles

4. Quadriceps Stretch


With one hand against a wall for balance, reach back and grasp one foot with your other hand. Bring your heel as close to your buttocks as possible. Hold for 15 counts, then relax. Repeat 3 times for each leg.

Stretches: Quadriceps and hip muscles

5. Inner Thigh Stretch

Sit with the soles of your feet together and your knees outward. Pull your feet toward your groin area as far as possible. Hold for 15 counts, then relax. Repeat 3 times.

Stretches: Quadriceps and hip muscles



NOTES

PART LIST—Model No. PFCCEX97573


R0500A

| Key No. | Qty. | Description | Key No. | Qty. | Description |
|---------|------|------------------------------|---------|------|------------------------------|
| 1 | 1 | Frame | 41 | 2 | Extension Wire |
| 2 | 1 | Upright | 42 | 1 | Flywheel |
| 3 | 1 | Seat Frame | 43 | 1 | 10mm x 13mm Spacer |
| 4 | 1 | Handlebar | 44 | 1 | Flywheel Axle |
| 5 | 2 | Pulse Grip | 45 | 1 | Left Pedal |
| 6 | 1 | Left Side Shield | 46 | 2 | M10 x 52mm Button Head Screw |
| 7 | 1 | Right Side Shield | 47 | 2 | Wheel |
| 8 | 1 | Console | 48 | 5 | 2" x 3" Endcap |
| 9 | 1 | Resistance Knob | 49 | 1 | 1 1/2" x 3" Endcap |
| 10 | 1 | Resistance Cable/Control | 50 | 1 | Cable Clamp |
| 11 | 4 | M5 x 30mm Screw | 51 | 1 | M6 x 56mm Bolt |
| 12 | 4 | M5 Nut | 52 | 2 | M8 Split Washer |
| 13 | 1 | Reed Switch/Wire | 53 | 4 | #8 Flat Washer |
| 14 | 4 | M6 x 25mm Hex Head Screw | 54 | 1 | Clamp Bolt |
| 15 | 1 | Backrest | 55 | 1 | Clamp Nut |
| 16 | 1 | Seat | 56 | 1 | Resistance Hook |
| 17 | 2 | Seat Handle | 57 | 1 | Resistance Spring |
| 18 | 4 | M6 x 38mm Button Head Bolt | 58 | 1 | Magnet Bracket |
| 19 | 2 | Foam Handle Grip | 59 | 1 | M8 x 65mm Hex Head Bolt |
| 20 | 1 | 1" x 3" Endcap | 60 | 1 | M8 Nylon Locknut |
| 21 | 6 | Tree Fastener | 61 | 1 | Drive Belt |
| 22 | 19 | #8 x 5/8" Screw | 62 | 2 | 1 1/4" Round Endcap |
| 23 | 2 | #8 x 3/8" Screw | 63 | 1 | 2" x 4" Endcap |
| 24 | 8 | M6 x 16mm Hex Head Screw | 64 | 1 | Frame Bushing |
| 25 | 3 | M10 x 25mm Button Head Screw | 65 | 1 | Seat Frame Bushing |
| 26 | 3 | M10 Split Washer | 66 | 4 | M6 Nylon Locknut |
| 27 | 1 | Left Pedal Strap | 67 | 4 | M6 Split Washer |
| 28 | 1 | Right Pedal | 68 | 1 | Lock Knob |
| 29 | 1 | Crank/Pulley | 69 | 1 | Seat Bracket |
| 30 | 1 | Bearing Assembly | 70 | 4 | M10 x 105mm Button Head Bolt |
| 31 | 1 | Right Pedal Strap | 71 | 4 | M10 Flat Washer |
| 32 | 1 | Magnet | 72 | 10 | M10 Nylon Locknut |
| 33 | 2 | M4 x 32mm Screw | 73 | 2 | Adapter |
| 34 | 1 | M4 x 16mm Screw | 74 | 4 | M10 x 58mm Carriage Bolt |
| 35 | 4 | Rubber Bumper | 75 | 1 | Front Stabilizer |
| 36 | 2 | M8 Flanged Hex Nut | 76 | 1 | Rear Stabilizer |
| 37 | 2 | M6 Eyebolt | # | 1 | User's Manual |
| 38 | 2 | Adjustment Bracket | # | 1 | 4mm Allen Wrench |
| 39 | 4 | M6 Nut | # | 1 | 5.5mm Allen Wrench |
| 40 | 2 | M10 Washer | | | |

Note: “#” indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover of this manual for information about ordering replacement parts.

EXPLODED DRAWING—Model No. PFCCEX97573

R0500A



CUSTOMER RECORD

Model No.: _____ Serial No.: _____

Retailer Name: _____ Purchase Date: _____

Retailer Address: _____

ORDERING REPLACEMENT PARTS

To order replacement parts, call our Customer Service Department toll-free at 1-888-936-4266, Monday through Friday, 8 a.m. until 6:30 p.m. Eastern Standard Time (excluding holidays). To help us assist you, please be prepared to give the following information:

- The MODEL NUMBER of the product (PFCCEX97573)
- The NAME of the product (PROFORM® 975s recumbent bike)
- The SERIAL NUMBER of the product (see the front cover of this manual)
- The KEY NUMBER and DESCRIPTION of the part(s) (see the PART LIST on page 16 of this manual).

**PLACE
STAMP
HERE**

ICON of Canada Inc.
900 de l'Industrie
St-Jérôme, Québec
Canada, J7Y 4B8

LIMITED WARRANTY

ICON OF CANADA INC., (ICON), warrants this product to be free from defects in workmanship and material, under normal use and service conditions, for a period of ninety (90) days from the date of purchase. This warranty extends only to the original purchaser. ICON's obligation under this warranty is limited to replacing or repairing, at ICON's option, the product at one of its authorized service centers. All products for which warranty claim is made must be received by ICON at one of its authorized service centers with all freight and other transportation charges prepaid, accompanied by sufficient proof of purchase. All returns must be pre-authorized by ICON. This warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage or repairs not provided by an ICON authorized service center, to products used for commercial or rental purposes, or to products used as store display models. No other warranty beyond that specifically set forth above is authorized by ICON.

ICON is not responsible or liable for indirect, special or consequential damages arising out of or in connection with the use or performance of the product or damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyment or use, costs of removal, installation or other consequential damages of whatsoever nature. Some provinces do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, the above limitation may not apply to you. The warranty extended hereunder is in lieu of any and all other warranties and any implied warranties of merchantability or fitness for a particular purpose is limited in its scope and duration to the terms set forth herein. Some provinces do not allow limitations on how long an implied warranty lasts. Accordingly, the above limitation may not apply to you.

This warranty gives you specific legal rights. You may also have other rights which vary from province to province or so specified by the retailer of your equipment.

ICON OF CANADA, 900 de l'Industrie, St. Jérôme, QC J7Y 4B8

PROFORM® is a registered trademark of ICON Health & Fitness, Inc.

| | | | |
|--|--|--|----------------------|
|  WEIDER PRO-FORM WESLO | | PRODUCT WARRANTY REGISTRATION | |
| IMPORTANT: MAIL WITHIN 14 DAYS OF PURCHASE | | | |
| NAME: _____ | | PHONE: _____ | |
| ADDRESS: _____ | | | |
| COUNTY: _____ | | POSTCODE: _____ | |
| MODEL NO. _____ | | SERIAL NO. _____ | PURCHASE DATE: _____ |
| RETAILER NAME: _____ | | RETAILER ADDRESS: _____ | |
| 1) Primary user(s) of product: <input type="checkbox"/> Male <input type="checkbox"/> Female <input type="checkbox"/> Family | | 8) Did you consider purchasing fitness equipment from another manufacturer? <input type="checkbox"/> No <input type="checkbox"/> Yes What other Manufacturer? _____ | |
| 2) Age of primary user: <input type="checkbox"/> 0-24 <input type="checkbox"/> 35-44 <input type="checkbox"/> 55-64 <input type="checkbox"/> 25-34 <input type="checkbox"/> 45-54 <input type="checkbox"/> 65 and over | | 9) Based on your impression of what you have purchased, would you buy another ICON product? <input type="checkbox"/> Yes <input type="checkbox"/> No <input type="checkbox"/> No Opinion If not, what other brand name equipment would you purchase? _____ | |
| 3) Annual household income: <input type="checkbox"/> 0-9,999 <input type="checkbox"/> 15,000-19,999 <input type="checkbox"/> 10,000-14,999 <input type="checkbox"/> 20,000+ | | 10) What other type of exercise equipment do you own? <input type="checkbox"/> Bicycle <input type="checkbox"/> Exercise Cycle <input type="checkbox"/> Treadmill <input type="checkbox"/> Home Gym <input type="checkbox"/> Weight Bench <input type="checkbox"/> Stepper <input type="checkbox"/> Cardio Glide <input type="checkbox"/> Other | |
| 4) How many times a week do you exercise? <input type="checkbox"/> Less than 3 times <input type="checkbox"/> 3 times or more | | 11) Which type of magazines do you read regularly? <input type="checkbox"/> Sports <input type="checkbox"/> Fitness <input type="checkbox"/> Motoring <input type="checkbox"/> Business <input type="checkbox"/> Computer <input type="checkbox"/> General | |
| 5) Have you ever purchased an ICON product before? <input type="checkbox"/> Yes <input type="checkbox"/> No | | 12) Do you wish to be sent further bulletins about ICON products? <input type="checkbox"/> Yes <input type="checkbox"/> No | |
| 6) Where did you first see or hear about ICON products? <input type="checkbox"/> Magazine <input type="checkbox"/> Friend/relative <input type="checkbox"/> Newspaper Ad <input type="checkbox"/> Store <input type="checkbox"/> Other | | THANK YOU FOR YOUR TIME | |
| 7) What was the primary reason for purchasing this ICON product? <input type="checkbox"/> Store Employee <input type="checkbox"/> Television Ads <input type="checkbox"/> Colour <input type="checkbox"/> Electronic Features <input type="checkbox"/> Magazine Ads <input type="checkbox"/> Price <input type="checkbox"/> Product Design <input type="checkbox"/> Product Innovation <input type="checkbox"/> Other Features | | © 1999 ICON of Canada, Inc. Printed in China | |