


Forno **Micro+Grill S1000**



cod. 7151 000

Microwave Oven

INSTRUCTION MANUAL

MODEL: AG925BBD

Read these instructions carefully before using your microwave oven, and keep it carefully.

If you follow the instructions, your oven will provide you with many years of good service.

SAVE THESE INSTRUCTIONS CAREFULLY PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- (a) Do not attempt to operate this oven with the door open since this can result in harmful exposure to microwave energy. It is important not to break or tamper with the safety interlocks.
- (b) Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- (c) **WARNING:** If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person.

ADDENDUM

If the apparatus is not maintained in a good state of cleanliness, its surface could be degraded and affect the lifespan of the apparatus and lead to a dangerous situation.

Specifications

Model:	AG925BBD
Rated Voltage:	230 V~50 Hz
Rated Input Power (Microwave):	1450 W
Rated Output Power (Microwave):	900 W
Rated Output Power (Grill):	1000 W
Oven Capacity:	25 L
Turntable Diameter:	315 mm
External Dimensions: (LxWxH):	513x380x346 mm
Peso netto:	approx. 18.5 kg circa

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, injury to persons or exposure to excessive microwave oven energy when using your appliance, follow basic precautions, including the following:

- 1 Warning: Liquids and other foods must not be heated in sealed containers since they are liable to explode.
- 2 Warning: It is hazardous for anyone other than a competent person to remove a cover which gives protection against exposure to microwave energy.
- 3 Warning: Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understand the hazards of improper use.
- 4 Warning: When the appliance is operated in the combination mode, children should only use the oven under adult supervision due to the temperatures generated. (only for grill series)
- 5 Only use utensils suitable for use in microwave ovens.
- 6 The oven should be cleaned regularly and any food deposits should be removed.
- 7 Read and follow the specific: "PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY".
- 8 When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition.
- 9 If smoke is observed, switch off or unplug the appliance and keep the door closed in order to stifle any flames.
- 10 Do not overcook food.
- 11 Do not use the oven cavity for storage purposes. Do not store items, such as bread, cookies, etc. inside the oven.
- 12 Remove wire twist-ties and metal handles from paper or plastic containers/bags before placing them in the oven.
- 13 Install or locate this oven only in accordance with the installation instructions provided.
- 14 Eggs in the shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended.
- 15 Use this appliance only for its intended uses as described in manual. Do not use corrosive chemicals or vapors in this appliance. This oven is especially designed to heat. It is not

designed for industrial or laboratory use.

- 16 If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 17 Do not store or use this appliance outdoors.
- 18 Do not use this oven near water, in a wet basement or near a swimming pool.
- 19 The temperature of accessible surfaces may be high when the appliance is operating.
Keep cord away from heated surface, and do not cover any events on the oven.
- 20 Do not let cord hang over edge of table or counter.
- 21 Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation.
- 22 The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns.
- 23 Microwave heating of beverages can result in delayed eruptive boiling, therefore take care when handling the container.
- 24 Steam cleaner is not to be used.
- 25 During use the appliance becomes hot. Care should be taken to avoid touching heating elements inside the oven.
- 26 Accessible parts may become hot during use. Young children should be kept away.
- 27 Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering.
- 28 This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capacities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 29 Children should be supervised to ensure that they do not play with the appliance.

To reduce the risk of injury to persons

Grounding installation DANGER

Electric Shock Hazard Touching some of the internal components can cause serious personal injury or death. Do not disassemble this appliance.

WARNING

Electric Shock Hazard Improper use of the grounding can result in electric shock. Do not plug into an outlet until appliance is properly installed and grounded.

CLEANING

Be sure to unplug the appliance from the power supply.

- 1 Clean the inside of the oven after using with a slightly damp cloth.
- 2 Clean the accessories in the usual way in soapy water.
- 3 The door frame and seal and neighbouring parts must be cleaned carefully with a damp cloth when they are dirty.

Two-round-pin plug



This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This appliance is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

Consult a qualified electrician or serviceman if the grounding instructions are not completely understood or if doubt exists as to whether the appliance is properly grounded. If it is necessary to use an extension cord, use only a 3-wire extension cord.

- 1 A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
- 2 If a long cord set or extension cord is used: 1) The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance. 2) The extension cord must be a grounding type 3-wire cord. 3) The long cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled on by children or tripped over unintentionally.

UTENSILS

See the instructions on “Materials you can use in microwave oven or to be avoided in microwave oven.”

CAUTION

Personal Injury Hazard

It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy. There may be certain non-metallic utensils that are not safe to use for microwaving. If in doubt, you can test the utensil in question following the procedure below.

Utensil Test:

- 1 Fill a microwave-safe container with 1 cup of cold water (250ml) along with the utensil in question.
- 2 Cook on maximum power for 1 minute.
- 3 Carefully feel the utensil. If the empty utensil is warm, do not use it for microwave cooking.
- 4 Do not exceed 1 minute cooking time.

Materials you can use in microwave oven

Utensils Remarks

Aluminum foil: shielding only.

Small smooth pieces can be used to cover thin parts of meat or poultry to prevent overcooking. Arcing can occur if foil is too close to oven walls. The foil should be at least 1 inch (2.5cm) away from oven walls.

Browning dish.

Follow manufacturer's instructions. The bottom of browning dish must be at least 3/16 inch

(5mm) above the turntable. Incorrect usage may cause the turntable to break.

Dinnerware Microwave-safe only.

Follow manufacturer's instructions. Do not use cracked or chipped dishes.

Glass jars.

Always remove lid. Use only to heat food until just warm. Most glass jars are not heat resistant and may break.

Glassware Heat-resistant oven glassware only.

Make sure there is no metallic trim. Do not use cracked or chipped dishes.

Oven cooking Follow manufacturer's instructions. Do not close with metal tie. Make bags slits to allow steam to escape.

Paper plates.

use for short-term cooking/warming only. Do not leave oven unattended and cups while cooking.

Paper towels.

Use to cover food for reheating and absorbing fat. Use with supervision for a short-term cooking only.

Parchment.

Use as a cover to prevent splattering or a wrap for steaming.

Paper Plastic.

Microwave-safe only. Follow the manufacturer's instructions. Should be labeled "Microwave Safe". Some plastic containers soften, as the food inside gets hot. "Boiling bags" and tightly closed plastic bags should be slit, pierced or vented as directed by package.

Plastic wrap Microwave-safe only. Use to cover food during cooking to retain moisture. Do not allow plastic wrap to touch food. Thermometers Microwave-safe only (meat and candy thermometers).

Wax paper.

Use as a cover to prevent splattering and retain moisture.

Materials to be avoided in microwave oven

Utensils Remarks

Aluminum tray May cause arcing. Transfer food into microwave-safe dish.

Food carton with May cause arcing. Transfer food into microwave-safe dish.

Metal handle.

Metal or metal-Metal shields the food from microwave energy. Metal trim may trimmed utensils cause arcing.

Metal twist ties.

May cause arcing and could cause a fire in the oven.

Paper bags.

May cause a fire in the oven.

Plastic foam.

Plastic foam may melt or contaminate the liquid inside when exposed to high temperature.


Wood.

Wood will dry out when used in the microwave oven and may split or crack.

SETTING UP YOUR OVEN

Names of Oven Parts and Accessories

Remove the oven and all materials from the carton and oven cavity. Your oven comes with the following accessories:




- A** Control panel
- B** Turntable shaft
- C** Turntable ring assembly
- D** Glass tray
- E** Observation window
- F** Door assembly
- G** safety interlock system

1 Instruction manual

1 Grill Rack
(Only for Grill series)

Turtable Installation



- a. Never place the glass tray upside down. The glass tray should never be restricted.
- b. Both glass tray and turntable ring assembly must always be used during cooking.
- c. All food and containers of food are always placed on the glass tray for cooking.
- d. If glass tray or turntable ring assembly cracks or Turntable shaft breaks, contact your nearest authorized service center.

Installation and connection

1. This appliance is only intended for domestic use.
2. This oven is intended for built-in use only. It is not intended for counter-top use or for use inside a cupboard.
3. Please observe the special installation instructions.
4. The appliance can be installed in a 60cm wide wall-mounted cupboard (at least 55cm deep and 85cm off the floor).
5. The appliance is fitted with a plug and must only be connected to a properly installed earthed socket.
6. The mains voltage must correspond to the voltage specified on the rating plate.
7. The socket must be installed and connecting cable must only be replaced by a qualified electrician. If the plug is no longer accessible following installation, an all-pole disconnecting device must be present on the installation side with a contact gap of at least 3mm.
8. Adapters, multi-way strips and extension leads must not be used. Overloading can result in a risk of fire.




The accessible surface may be hot during operation.

Installation Instructions

Please Read the Manual Carefully Before Installation

SCREW 

TRIM-KIT PLASTIC COVER 





Please Note Electrical connection

The oven is fitted with a plug and must be only connected to a properly installed earthed socket. In accordance with the appropriate regulations, the socket must only be installed and the connecting cable must only be replaced by a qualified electrician.


If the plug is no longer accessible following installation and all-pole isolating switch must be present on the installation side with a contact gap of at least 3mm.

A. Built-in furniture



The built-in cabinet shall not have a rear wall behind the appliance. Minimum installation height is 85cm. Do not cover ventilation slots and air intake points.



B. Install the Oven



- 1 • Do not trap or kink the power cord.
 - Make sure that the oven is installed in the center of the cabinet.



2 Open the door; fix the oven to the cabinet with SCREW at the INSTALLATION HOLE of TRIM KIT. Then fix the TRIM-KIT PLASTIC COVER to the INSTALLATION HOLE.

Operation Instructions

1. Clock Setting

When the microwave oven is electrified, the LED will display "0:00", buzzer will ring once.

1) Press "CLOCK", the hour figures will flash.



2) Turn " " to adjust the hour figures, the input time should be within 0--23.

3) Press "CLOCK", the minute figures will flash.



4) Turn " " to adjust the minute figures, the input time should be within 0--59.

5) Press "CLOCK" to finish clock setting. ":" will flash, and the time will light.

Note:

1) If the clock is not set, it would not function when powered.

2) During the process of clock setting, if you press "STOP/CLEAR", the oven will go back to the previous status automatically.

2. Microwave Cooking.

Press "MICRO./GRILL/COMBI." the LED will display "P100. Press "MICRO./GRILL/COMBI." "



for times or turn " " to choose the power you want, and "P100", "P80" "P50", "P30" or "P10" will display for each added press. Then press "START" to confirm, and turn



" " to set cooking time from 0:05 to 95:00. Press "START" again to start cooking.

Example: If you want to use 80% microwave power to cook for 20 minutes, you can operate the oven as the following steps.

1) Press "MICRO./GRILL/COMBI." once, the screen display "P100".

2) Press "MICRO./GRILL/COMBI." once again or turn " " to choose 80% microwave power.

3) Press "START" to confirm, and the screen displays "P 80".

4) Turn " " to adjust the cooking time until the oven displays "20:00".

- 5) Press “ START “ to start cooking . Note: the step quantities for the adjustment time of the coding switch are as follow: 0---1 min: 5 seconds 1---5 min: 10 seconds 5---10 min: 30 seconds 10---30 min: 1 minute 30---95 min: 5 minutes

Order	Display “MICRO./GRILL/COMBI.” Pad instructions	Microwave Power	Grill Power
1	P100	100%	
2	P80	80%	
3	P50	50%	
4	P30	30%	
5	P10	10%	
6	G	0%	100%
7	C-1	55%	45%
8	C-2	36%	64%

3. Grill or Combi.

Cooking Press “ MICRO./GRILL/COMBI. “ once, the LED will display “P100”,and press

“ MICRO./GRILL/COMBI. “for times or turn the  “ to choose the power you want, and “G”, “C-1” or “C-2” will display for each added press. Then press “START “ to confirm, and turn  “ to set cooking time from 0:05 to 95:00. Press “ START “ again to start cooking.

Example: If you want to use 55% microwave power and 45% grill power(C-1) to cook for 10 minutes, you can operate the oven as the following steps.

- 1) Press “ MICRO./GRILL/COMBI. “ once, the screen display “P100”.
- 2) Press “ MICRO./GRILL/COMBI. “ once again or turn  “ to choose combi. 1 mode.
- 3) Press “START “ to confirm, and the screen displays “C-1”.
- 4) Turn  “ to adjust the cooking time until the oven displays “10:00”.
- 5) Press “ START “ to start cooking .

Note: If half the grill time passes, the oven sounds twice, and this is normal. In order to have a better effect of grilling food, you should turn the food over, close the door, and then if no operation the oven will continue cooking.

4. Kitchen Timer

- 1) Press “ KITCHEN TIMER “, LED will display 0:00, clock indicator will be lighted.
- 2) Turn  “ to enter the timer time.(the maximum cooking time is 95 minutes).
- 3) Press “ START “ to confirm setting.
- 4) When the kitchen time is reached, clock indicator will go out. The buzzer will ring 5 times. If the clock be set (12-hour system), LED will display the current time.

Note: The kitchen Time is differ from 12-hour system, Kitchen Timer is a timer.

5. Speedy Cooking

- 1) In waiting state, Press " START " to start cooking with 100% power for 30 seconds, each added press will increase 30 seconds cooking time up to 95 minutes.
- 2) In microwave cooking or time defrost state, each press of " START " can increase 30 seconds cooking time.
- 3) Under the state of auto menu and weight defrost, cooking time cannot be increased by pressing " START".

6. Defrost By Weight

- 1) Press " WEIGHT DEFROST " once, and the oven will display "dEF1".
- 2) Turn " " to select the weight of food from 100 to 2000 g.
- 3) Press " START " to start defrosting.

7. Defrost By Time

- 1) Press " TIME DEFROST " once, and the oven will display "dEF2".
- 2) Turn " " to select the defrost time. The MAX.time is 95 minutes.
- 3) Press " START " to start defrosting. The defrost power is P30. It cannot change.

8. Auto Reheat

- 1) Press " AUTO REHEAT " once, and the LED will display "200".
- 2) Press " AUTO REHEAT " more times or turn " " to choose the weight of food, and "400" or "600" g will be selected.
- 3) Press " START " to start cooking.

9. Auto Menu

- 1) Press "AUTO MENU" several times or turn " " to choose the menu, and "A-1" to "A-8" will display, which means pizza, chicken pieces,meat, vegetable, fish, pasta, soup and potato.
- 2) Press " START " to confirm.
- 3) Turn " " to choose the default weight as the menu chart.
- 4) Press " START " to start cooking.

Example: If you want to use "Auto Menu" to cook fish for 350g.

- 1) Press "AUTO MENU" several times till "A-5" display.
- 2) Press " START " to confirm.
- 3) Turn " " to select the weight of fish till "350" display.
- 4) Press " START " to start cooking.

The menu chart:

Menu	Weight	Display
A-1 Pizza	200 g	200
	400 g	400
A-2 Chicken Pieces	200 g	200
	400 g	400
	600 g	600
	800g	800
A-3 Meat	250 g	250
	350 g	350
	450 g	450
A-4 Vegetable	200 g	200
	300 g	300
	400 g	400
A-5 Fish	250 g	250
	350 g	350
	450 g	450
A-6 Pasta	50g(with 450 ml cold water)	50
	100g(with 800 ml cold water)	100
A-7 Soup	200 ml	200
	400 ml	400
A-8 Potato	200 g	200
	400 g	400
	600 g	600

10. Program set in Advance

- 1) Set the clock first. (Consult the instruction of clock setting.)
- 2) Input the cooking program. Two stages can be set at most. Defrost should not be set as the cooking program.

Example: If you want to cook food with 80% microwave power for 7 minutes.

a. Press "MICRO./GRILL/COMBI." twice, the screen display "P80".

b. Press  "START" to confirm.

c. Turn  " to adjust the cooking time till the oven displays "7:00".

d. Please do not press "START" to start cooking. Do as following.

3) Press "PRE-SET", the hour figures will flash.

4) Turn  " to adjust the hour figures, the input time should be within 0--23.

5) Press "PRE-SET", the minute figures will flash.

6) Turn  " to adjust the minute figures, the input time should be within 0--59.

7) Press "START" to finish setting. If the door is closed, buzzer will ring twice when the time arrives, then cooking will start automatically.

11. Multi-section cooking

At most 2 sections can be set for cooking. In multi-section cooking, if one section is defrosting, then defrosting shall be placed in the first section. Example: If you want to defrost food for 5 minutes and then cook with 80% microwave power for 7 minutes, operate it as the following:

- 1) Press "TIME DEFROST" once, and the oven will display "dEF2".
- 2) Turn " to select the defrost time till "5:00" display.
- 3) Press "MICRO./GRILL/COMBI." once, the screen display "P100".
- 4) Press "MICRO./GRILL/COMBI." once again or turn " to choose 80% microwave power.
- 5) Press "START" to confirm, and the screen displays "P 80".
- 6) Turn " to adjust the cooking time till the oven displays "7:00".
- 7) Press "START" to start cooking, and buzzer will sound once for the first section, defrosting time counts down; buzzer will sound once again entering the second cooking. when cooking finish, buzzer sounds five times.

12. Inquiring Function

- 1) In states of microwave, grill or combination cooking, press "MICRO./GRILL/COMBI.", the current power will be displayed for 3 seconds. After 3 seconds, the oven will turn back to the former state.
- 2) In cooking state, press "CLOCK" to inquire the time and the time will display for 3 seconds.
- 3) In preset state, press "PRE-SET" to inquire the preset time, and the preset time will display for 3 seconds.

13. Lock-out Function for Children Lock:

In waiting state, press "STOP/CLEAR" for 3 seconds, there will be a long beep denoting entering the children-lock state and the locked indicator will display. The current time will display if the time has been set, otherwise, the LED will display "

Lock quitting: In locked state, press "STOP/CLEAR" for 3 seconds, there will be a long "beep" denoting that the lock is released.

Trouble shooting

Normal	
Microwave oven interfering TV reception	Radio and TV reception may be interfered when microwave oven operating. It is similar to the interference of small electrical appliances, like mixer, vacuum cleaner, and electric fan. It is normal.
Dim oven light	In low power microwave cooking, oven light may become dim. It is normal.
Steam accumulating on door, hot air out of vents	In cooking, steam may come out of food. Most will get out from vents. But some may accumulate on cool place like oven door. It is normal.
Oven started accidentally with no food in.	It is forbidden to run the unit without any food inside. It is very dangerous.

Trouble	Possible Cause	Remedy
Oven can not be started.	(1) Power cord not plugged in tightly.	Unplug. Then plug again after 10 seconds.
	(2) Fuse blowing or circuit breaker works.	Replace fuse or reset circuit breaker (repaired by professional personnel of our company)
	(3) Trouble with outlet.	Test outlet with other electrical appliances.
Oven does not heat.	(4) Door not closed well.	Close door well.
Glass turntable makes noise when microwave oven operates	(5) Dirty roller rest and oven bottom.	Refer to "Maintenance of Microwave" to clean dirty parts.



It is forbidden to run the unit without any food inside. It is very dangerous. According to Waste of Electrical and Electronic Equipment (WEEE) directive, WEEE should be separately collected and treated. If at any time in future you need to dispose of this product please do NOT dispose of this product with household waste. Please send this product to WEEE collecting points where available.

Foster S.p.A.

via M.S. Ottone, 18/20 – 42041 Brescello (RE) – Italy

www.fosterspa.com - info@fosterspa.com

Servizio post-vendita: tel. +39 0522-684450, fax +39 0522-686019, service@fosterspa.com

Servizio ricambi: tel. + 39 0522-684300, fax + 39 0522-684300