


SAMSUNG

MICROWAVE OVEN

CE101K/CE102KT/CE103KB


Owner's Instructions




Code No. : DE68-62042A

Quick Look-up Guide


GB




Place the food in the oven.
Press the MICROWAVE button.
Select the cooking time by pressing the 10 min, 1 min or 10 s buttons as required.



Place the frozen food in the oven.
Select the food category by pressing the AUTO DEFROST button one or more times.




Leave the food in the oven.
Press MORE (▲) one or more times for each extra minute that you wish to add.




Press the POWER LEVEL button until the appropriate power level is displayed.

Result: Cooking starts and at the end the oven beeps four times.



Select the weight by pressing the 1 kg and 0.1 kg buttons as required.
Increase or decrease the time, as required, by pressing MIN+ (▲) or MIN- (▼).



Press START.



You have just purchased a SAMSUNG microwave oven.

Your Owner's Instructions contain much valuable information on cooking with your microwave oven. Take the time to read them as they will help you take full advantage of the microwave oven features.

Contents

- ◆ QUICK LOOK-UP GUIDE 2
- ◆ USING THIS INSTRUCTIONS BOOKLET 5
- ◆ INSTALLING AND PREPARING YOUR MICROWAVE OVEN
 - Safety Precautions 6
 - Accessories 8
 - Installing Your Microwave Oven 9
 - Setting the Time 9
 - How a Microwave Oven Works 10
 - Checking that Your Oven is Operating Correctly 10
 - What to Do if You are in Doubt or Have a Problem 11
- ◆ COOKING WITH YOUR MICROWAVE OVEN
 - Cooking/Reheating 12
 - Power Levels and Time Variations 12
 - Stopping the Cooking 13
 - Adjusting the Cooking Time 13
 - Using the Instant Cook Feature 14
 - Using the Auto Cook Feature 16
 - Using a Crusty Plate (CE102KT only) 18
- ◆ DEFROSTING
 - Using the Auto Defrost Feature 19
 - Setting a Standing Time 21
 - Multistage Cooking 21
- ◆ TRADITIONAL COOKING METHODS
 - Choosing the Heating Element Position 22
 - Choosing the Accessories 22
 - Preheating the Oven 23
 - Cooking by Convection 23
 - Grilling 24
 - Spit-Roasting (CE103KB only) 25
 - Using the Vertical mult - spit (CE103KB only) 26

Contents

- ◆ COMBINED COOKING
 - Combining Microwaves and Convection 27
 - Combining Microwaves and the Grill 28
- ◆ FEATURES COMMON TO ALL TYPES OF COOKING
 - Using the Memory Cook Feature..... 29
 - Using the Demonstration mode 29
 - Safety-locking Your Microwave Oven..... 30
 - Switching the Beeper Off..... 31
- ◆ RECOMMENDATIONS FOR USE
 - Cookware Guide..... 32
 - Cleaning Your Microwave Oven 33
 - Storing and Repairing Your Microwave Oven 33
 - Technical Specifications 34
 - Oven 35
 - Control Panel (CE101K/CE103KB only)..... 36
 - Control Panel (CE102KT only) 37

You have just purchased a SAMSUNG microwave oven. Your Owner's Instructions contain much valuable information on cooking with your microwave oven:

- ◆ *Safety precautions*
- ◆ *Suitable accessories and cookware*
- ◆ *Useful cooking tips*

Inside the cover you will find a quick look-up guide explaining three basic cooking operations:

- ◆ *Cooking a dish (microwave)*
- ◆ *Defrosting a dish*
- ◆ *Adding an extra minute, if the dish is not cooked or reheated enough*

At the end of the booklet you will find illustrations of the oven, and more importantly the control panel, so that you can find the buttons more easily.

The illustrations in the step-by-step procedures use four different symbols.



Press



Push



Important



Note

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

Failure to observe the following safety precautions may result in harmful exposure to microwave energy.

- (a) Under no circumstances should any attempt be made to operate the oven with the door open or to tamper with the safety interlocks (door latches) or to insert anything into the safety interlock holes.
- (b) Do not place any object between the oven door and front face, or allow food or cleaner residues to accumulate on sealing surfaces. Ensure that the door and door sealing surfaces are kept clean by wiping after use with first a damp cloth and then a final wipe with a soft dry cloth.
- (c) Do not operate the oven if it is damaged until it has been repaired by a qualified microwave service technician trained by the manufacturer.

It is particularly important that the oven door closes properly and that there is no damage to the :

- (1) Door, Door seals and sealing surfaces
 - (2) Door hinges (broken or loose)
 - (3) Power cable
- (d) The oven should not be adjusted or repaired by anyone other than a properly qualified microwave service technician trained by the manufacturer.

Before cooking food or liquids in your microwave oven, please check that the following safety precautions are taken.

DO NOT use any metallic cookware in the microwave oven:

- ◆ Metallic containers
- ◆ Dinnerware with gold or silver trimmings
- ◆ Skewers, forks, etc.

Reason: Electric arcing or sparking may occur and may damage the oven.

DO NOT heat:

- ◆ Airtight or vacuum-sealed bottles, jars, containers

Example: Baby food jars

- ◆ Airtight food

Example: Eggs, nuts in shells, tomatoes

Reason: The increase in pressure may cause them to explode.

Tip: Remove lids and pierce skins, bags, etc.

DO NOT operate the microwave oven when it is empty.

Reason: The oven walls may be damaged.

Tip: Leave a glass of water inside the oven at all times. The water will absorb the microwaves if you accidentally set the oven going when it is empty.

DO NOT cover the side or rear ventilation slots with cloths or paper.

Reason: The cloths or paper may catch fire as hot air is evacuated from the oven.

ALWAYS use oven gloves when removing a dish from the oven.

Reason: Some dishes absorb microwaves and heat is always transferred from the food to the dish. The dishes are therefore hot.

DO NOT touch heating elements or interior oven walls.

Reason: These walls may be hot enough to skin burn even after cooking is finished, although they do not appear to be so. Keep away from hot spot. Do not allow inflammable materials to come into contact with any interior area of the oven. Let the oven cool down first.

- ◆ To reduce the risk of fire in the oven cavity.
 - Do not store flammable materials in the oven.
 - Remove wire twist ties from paper or plastic bags.
 - Do not use your microwave oven to dry newspapers.
 - If smoke is observed, keep the oven door closed and switch off or disconnect the oven from the power supply.

Take particular care when heating liquids and baby foods.

- ◆ ALWAYS allow a standing time of at least 20 seconds after the oven has been switched off to allow the temperature to equalize.
- ◆ Stir during heating if necessary and ALWAYS stir after heating.
- ◆ To prevent eruptive boiling and possible scalding, you should stir before, during, and after heating. In the event of scalding, follow these FIRST AID instructions :
Immerse hand in cold water for at least 10 minutes. Cover with clean, dry dressing. Do not apply any creams, oils or lotions.
- ◆ NEVER fill the container to the top and choose a container that is wider at the top than at the bottom to prevent the liquid from boiling over. Bottles with narrow necks may also explode if overheated.
- ◆ ALWAYS check the temperature of baby food or milk before giving it to the baby.
- ◆ NEVER heat a baby's bottle with the teat on, as the bottle may explode if overheated.

Be careful not to damage the power cable.

- ◆ Do not immerse power cable or plug in water and keep power cable away from heated surfaces.
- ◆ Do not operate this appliance if it has a damaged power cable or plug.

Stand at arm's length from the oven when opening the door.

Reason: The hot air or steam released may cause scalding.

IMPORTANT SAFETY INSTRUCTIONS









During cooking, you should look into the oven from time to time when food is being heated or cooked in disposable containers of plastic paper or other combustible material.

IMPORTANT:

Young children should NEVER be allowed to use or play with the microwave oven.

Nor should they be left unattended near the microwave oven when it is in use.

Items of interest to children should not be stored or hidden just above the oven.



Depending on the model that you have purchased, you are supplied with several accessories that can be used in a variety of ways.

1 Coupler, to be placed correctly over the motor shaft in the base of the oven.

Purpose: The coupler rotates the glass plate.

2 Roller ring, to be placed in the centre of the oven.

Purpose: The roller ring supports the glass plate.

3 Glass plate, to be placed on the roller ring with the centre fitting on to the coupler.

Purpose: The glass plate serves as the main cooking surface; it can be easily removed for cleaning.

4 Convection tray, to be placed on the glass plate.

Purpose: The convection tray is used for the traditional (convection or grill) or combination (microwave + convection or grill) cooking modes.

5 Metal racks (High rack, Low rack), to be placed on the convection tray.

Purpose: The metal racks can be used to cook two dishes at the same time. A small dish may be placed on the glass plate and a second dish on the rack. The metal racks can be used in grill, convection and combination cooking.

6,7,8 Roasting spit, Coupler Barbecue and Skewer, to be placed in the glass bowl (CE103KB only).

Purpose: The roasting spit is a convenient way of barbecuing a chicken, as the meat does not have to be turned over. It can be used for grill combination cooking.

9 Glass bowl, to be placed on the convection tray (CE103KB only).

Purpose: Roasting stand is placed on the glass bowl.

10 Crusty plate, to be placed on the glass plate (CE102KT only).


Purpose: The crusty plate is used to brown food better in the microwave or grill combination cooking modes and keep pastry and pizza dough crisp.



DO NOT operate the microwave oven without the coupler, roller ring and glass plate.

How a Microwave Oven Works

GB



Microwaves are high-frequency electromagnetic waves; the energy released enables food to be cooked or reheated without changing either the form or the colour.

You can use your microwave oven to:

- ◆ Defrost
- ◆ Reheat
- ◆ Cook

Cooking Principle



- 1 The microwaves generated by the magnetron are distributed uniformly as the food rotates on the glass plate. The food is thus cooked evenly.
- 2 The microwaves are absorbed by the food up to a depth of about 1 inch (2.5 cm). Cooking then continues as the heat is dissipated within the food.
- 3 Cooking times vary according to the recipient used and the properties of the food:
 - ◆ Quantity and density
 - ◆ Water content
 - ◆ Initial temperature (refrigerated or not)



As the centre of the food is cooked by heat dissipation, cooking continues even when you have taken the food out of the oven. Standing times specified in recipes and in this booklet must therefore be respected to ensure:

- ◆ Even cooking of the food right to the centre
- ◆ The same temperature throughout the food

Checking that Your Oven is Operating Correctly



The following simple procedure enables you to check that your oven is working correctly at all times. If you are in doubt, refer to the section entitled "What to Do if You are in Doubt or Have a Problem" on the next page.



- ◆ The oven must be plugged into an appropriate wall socket.
- ◆ The glass plate must be in position in the oven.
- ◆ If a power level other than the maximum (100% - 900 W) is used, the water takes longer to boil.

- 1 Open the oven door by pushing the large button in the bottom right-hand corner of the control panel. Place a glass of water on the glass plate. Close the door.
- 2 Press the MICROWAVE button and set the time to 4 to 5 minutes, by pressing the 1 min button the appropriate number of times.
- 3 Press START.
Result: The oven heats the water for 4 to 5 minutes. The water should then be boiling.

Becoming familiar with a new appliance always takes a little time. If you have any of the problems listed below, try the solutions given. They may save you the time and inconvenience of an unnecessary service call.

Problem	Checks/Explanation/Solution
<ul style="list-style-type: none"> ◆ Condensation inside the oven ◆ Air flow around the door and outer casing ◆ Light reflection around the door and outer casing ◆ Steam escaping from around the door or vents 	This is normal.
The food is not cooked at all	<ul style="list-style-type: none"> ◆ Have you set the timer correctly and pressed the START button? ◆ Is the door closed? ◆ Have you overloaded the electric circuit and caused a fuse to blow or a breaker to be triggered.
The food is either overcooked or undercooked	<ul style="list-style-type: none"> ◆ Was the appropriate cooking length set for the type of food? ◆ Was an appropriate power level chosen?
Sparking and cracking occur inside the oven (arcing)	<ul style="list-style-type: none"> ◆ Have you used a dish with metal trimmings? ◆ Have you left a fork or other metal utensil inside the oven? ◆ Is aluminium foil too close to the inside walls?
The oven causes interference with radios or televisions	<ul style="list-style-type: none"> ◆ Slight interference may be observed on televisions or radios when the oven is operating. This is normal. <u>Solution:</u> Install the oven away from televisions, radios and aerials. ◆ If interference is detected by the oven's microprocessor, the display may be reset. <u>Solution:</u> Disconnect the power plug and reconnect it. Reset the time.




If the above guidelines do not enable you to solve the problem, take a note of:

- ◆ **The model and serial numbers, normally printed on the rear of the oven**
- ◆ **Your warranty details**
- ◆ **A clear description of the problem**

Then contact your local dealer or SAMSUNG after-sales service.

Cooking/Reheating

GB



The following procedure explains how to cook or reheat food.






ALWAYS check your cooking settings before leaving the oven unattended.

- 1 Open the oven door by pushing the large button in the bottom right-hand corner of the control panel. Place the food in the centre of the glass plate. Close the door.



Never switch the microwave oven on when it is empty.

- 2 Press the MICROWAVE button.
Result: The following indications are displayed:
 (microwave mode)
 (one-stage cooking)
 (maximum cooking power)
- 3 Select the appropriate power level by pressing the POWER LEVEL button until the corresponding percentage is displayed. Refer to the power level table below for further details.

- 4 Set the cooking time by pressing the 10 min, 1 min and 10 s buttons.
Example: For a cooking time of 3 minutes, 30 seconds, press 1 min three times, followed by 10 s three times.
Result: The cooking time is displayed.

- 5 Press the START button.
Result: The oven light comes on and the turntable starts rotating. Cooking starts and when it has finished:
 - ◆ The oven beeps four times
 - ◆ The current time is displayed again



If you wish to heat a dish for a short period of time at maximum power (100%), you can also simply press the MORE (▲) button once for each minute of cooking time. The oven starts immediately. Microwave mode can be programmed to cook food in up to two stages.

Power Levels and Time Variations

The power level function enables you to adapt the amount of energy dissipated and thus the time required to cook or reheat your food, according to its type and quantity. You can choose between ten power levels.

Power Level	Percentage	Output	Power Level	Percentage	Output
HIGH	100%	900 W	MEDIUM	50%	450 W
SAUTÉ	90%	810 W	MEDIUM LOW	40%	360 W
REHEAT	80%	720 W	DEFROST	30%	270 W
MEDIUM HIGH	70%	630 W	LOW	20%	180 W
SIMMER	60%	540 W	WARM	10%	90 W


The cooking times given in recipes and in this booklet correspond to the specific power level indicated.

If you select a...	Then the cooking time must be...
Higher power level	Decreased
Lower power level	Increased


Stopping the Cooking

You can stop cooking at any time so that you can:

- ◆ Check the food
- ◆ Turn the food over or stir it
- ◆ Leave it to stand




To stop the cooking...	Then...
Temporarily	Open the door. <u>Result:</u> Cooking stops. To resume cooking, close the door again and press START.
Completely	Press the Stop button. <u>Result:</u> Cooking stops. If you wish to cancel the cooking settings, press the Stop button again.



Adjusting the Cooking Time

Like traditional cooking, you may find that, depending on the food's characteristics or your tastes, you have to adjust the cooking times slightly. You can:


- ◆ Check how cooking is progressing at any time simply by opening the door
- ◆ Increase or decrease the remaining cooking time



To...	Then press...
Increase the cooking time	MORE (▲) once for each minute to be added to the cooking time
Decrease the cooking time	LESS (▼) once for each minute to be subtracted from the cooking time

Using the Instant Cook Feature

GB



With the Instant Cook feature, the cooking time is set automatically and you do not have to press START.

You can adjust the number of servings by pressing the appropriate Instant Cook button the required number of times.

- 1 Open the oven door by pushing the large button in the bottom right-hand corner of the control panel.
- 2 Place the food in the centre of the glass plate.
- 3 Close the door.
- 4 Select the serving type and number by pressing the appropriate Instant Cook button one or more times:

DRINKS

QUICHE

RICE/PASTA

GRATIN

BURGER/FISHFINGER
(CE101K/CE103KB only)

BAKED POTATOES

Example: Press the DRINKS button three times to reheat three cups of coffee.

Result: Cooking starts after about two seconds. When it has finished:
◆ The oven beeps four times
◆ The current time is displayed again

Using the Instant Cook Feature (continued)





GB

Here are a few tips and recommendations to be followed when cooking or reheating food with the Instant Cook Feature.

Serving Type	Serving Size	Standing Time	Recommendations
Drinks			
Coffee, tea, milk, water	150 ml	-	Take the coffee, tea, milk or water with room temperature or out of the refrigerator and pour it into heat-resistant container.
	300 ml		
	450 ml		
	600 ml		
Quiche			
	600 - 700 g	-	Put the batter and all ingredients in a glass baking container. Put the container on the convection tray on the glass plate.
	750 - 850 g		
	900 - 1000 g		
	1100 - 1200 g		
Rice/Pasta			
Rice	250 g	5 - 10 mins.	Put rice in a bowl, add 500ml cold water and stir. Cook uncovered. Stir before standing and cover during standing. Stir before serving.
	500 g	5 - 10 mins.	
Pasta	250 g	5 mins.	Put pasta in a bowl, add 1000ml boiling water and stir. Cook uncovered. Stir before standing and cover during standing. Put pasta in a bowl, add 1750ml boiling water and stir. Cook uncovered. Stir before standing and cover during standing.
	500 g	5 mins.	
Gratin			
(CE101K/CE103KB)	500 g	-	Put the container with your gratin on the low rack if the volume is higher, or on the high rack if the volume is lower, in order to get the best browning. This program is suitable for all kind of cooked dishes on which you want to put some cheese and get a brown top.(like potato/vegetable gratin)
	750 g		
Burgers/Fishfingers			
(CE101K/CE103KB)	110 - 225 g	-	Place the frozen burgers or fishfingers on aluminium foil on the high rack. Turn them over when the oven beeps.
	225 - 450 g		
Baked Potatoes			
(CE101K/CE103KB)	2 x 175 - 225 g	-	Take potatoes of a similar size. Wash and pierce the skin in several places with a fork. Arrange 2 potatoes on opposite sides of the high rack and 4 or 6 ones in a circle for a better result. Turn over when beep sounds.
	4 x 175 - 225 g		
	6 x 175 - 225 g		

Using the Auto Cook Feature

GB



The Auto Cook feature has ten pre-programmed cooking times. You do not need to set either the cooking times or the power level.

You can adjust the size of the serving by pressing the Dish button.



Use only recipients that are microwave-safe.

- 1 Open the oven door by pushing the large button in the bottom right-hand corner of the control panel.
- 2 Place the food in the centre of the glass plate.
- 3 Close the door.
- 4 Select the type of food that you are cooking by pressing the AUTO COOK button one or more times. Refer to the table on the following page for a description of the various pre-programmed settings.
- 5 Select the size of the serving by pressing the Dish button one or more times.
- 6 Increase or decrease the cooking time, if necessary, by pressing the MORE (▲) or LESS (▼) buttons respectively.
- 7 Press START.

Result: The food is cooked according to the pre-programmed setting selected.



The first number in the code corresponds to the type of dish and the second to the serving size.

Example: To cook 400 - 450 g of tinned food (code 2 - 2), press:

- ◆ AUTO COOK twice
- ◆ Dish twice

Using the Auto Cook Feature (continued)





Here are a few tips and recommendations to be followed when cooking or reheating food with the Auto Cook feature.

Code	Food	Serving Size	Standing Time	Recommendations
1 - 1 - 2	Plated meal	300 - 400 g 450 - 550 g	2 mins.	Take the dish out of the refrigerator and cover it with microwave cling film. This programme is for meals with meat pieces in sauce/gravy and cooked vegetables with a side-dish such as mashed potatoes or noodles.
2 - 1 - 2	Canned food	200 - 250 g 400 - 450 g	1 - 2 mins.	Take the food out of the can and place it in a deep soup plate or ceramic bowl with a lid. This programme is for canned foods such as pasta in tomato sauce, ravioli, baked beans and vegetables e.g. sweet corn, etc.
3 - 1 - 2	Casserole/stew	400 - 500 g 700 - 800 g	2 mins.	Place the food in a deep soup plate or a ceramic bowl with a lid. Stir before leaving to stand.
4 - 1 - 2	Soup/sauce	200 - 250 g 400 - 500 g	1 - 2 mins.	Pour the soup or sauce into a deep soup plate or ceramic bowl. Cover with a lid during reheating and stir before leaving to stand.
5 - 1 - 2 - 3	Boiled potatoes	400 - 500 g 550 - 650 g 700 - 800 g	3 mins. 4 mins. 5 mins.	Take potatoes which are having a similar size. Wash and peel them, and put them in a glass bowl and add 150 - 200 ml of water. Cover with a lid during cooking and standing.
6 - 1 - 2 - 3	Fresh vegetables	200 - 250 g 400 - 500 g 600 - 700 g	2 mins.	Place the vegetables in a glass bowl and add 45 - 60 ml of water. Cover with a lid during cooking. Stir before leaving to stand, still covered with a lid. This programme is especially suitable for firmer vegetables like broccoli, cauliflower, carrots etc.
7 - 1 - 2 - 3	Fish	200 g 400 g 600 g	2 mins.	Arrange the fish in a glass plate and cover with microwave cling film. This programme for fresh fish is for whole fish or fish fillets of trout, plaice, salmon and cod.
8 - 1 - 2 - 3	Roast beef	1000 g 1500 g 2000 g	5 - 10 mins.	Brush the beef with oil and put it on the roasting rack. Turn the meat over when the oven beeps.
9 - 1 - 2 - 3	Roast pork	1000 g 1500 g 2000 g	5 - 10 mins.	Brush the pork with oil and put it on the roasting rack. Turn the meat over when the oven beeps.
10 - 1 - 2 - 3	Roast chicken	700 g 1000 g 1500 g	5 - 10 mins.	Brush the chicken with oil and put it on the roasting rack. Turn the meat over when the oven beeps.

Using a Crusty Plate

**CE102KT
only**

GB



Normally when cooking food, such as pizzas or pies, on a grill or in a microwave oven, the dough or pastry becomes soggy. This can be avoided by using a crusty plate; as a high temperature is reached quickly, the crust turns crisp and brown.

The crusty plate can also be used for bacon, eggs, sausages, etc.

➤ Before using the crusty plate, preheat it by selecting the combination mode for 3 to 5 minutes:

- ◆ Combination of convection (250°C) and microwaves (70% power level)
- or
- ◆ Combination of grill and microwaves (70% power level)

See pages 27 and 28 respectively.

- 1 Preheat the crusty plate, as described above.
 - ☞ Use oven gloves at all times as the crusty plate will become very hot.
- 2 Brush the plate with oil if you are cooking food, such as bacon and eggs, in order to brown the food nicely.
- 3 Place the food on the crusty plate.
 - ☞ Do not place any recipients on the crusty plate that are not heat-resistant (plastic bowls for example).
- 4 Place the crusty plate on the glass plate in the microwave oven.
 - ☞ Never place the crusty plate in the oven without the glass plate.
- 5 Select the appropriate Crusty Reheat programme, by pressing the Crusty Reheat button one or more times. Refer to the table below.
- 6 Select the serving size by pressing the Dish button one or more times.
- 7 Increase or decrease the cooking time, if necessary, by pressing the MORE (▲) or LESS (▼) buttons respectively.
- 8 Press START.

Result: The food is cooked according to the programme selected.

Code	Food	Serving Size	Preheating Time	Standing Time	Recommendations
C1 - 1 - 2	Pizza (frozen and ready to heat)	300 - 350 g 375 - 450 g	3 mins.	-	Preheat the crusty plate using the grill + microwave combination mode. Place the pizza on the crusty plate on the glass plate.
C2 - 1 - 2	Oven Chips (frozen and suitable for heating in an oven)	250 g 500 g	4 mins.	-	Preheat the crusty plate using the convection + microwave combination mode. Place the chips on the crusty plate on the low rack.
C3 - 1 - 2	Pie/Quiche (chilled and ready to heat)	160 - 210 g 340 - 550 g	3 mins.	2 mins.	Preheat the crusty plate using the grill + microwave combination mode. Place the pie or quiche on the crusty plate on the glass plate.

Using a Crusty Plate (continued)

How to clean the crusty plate

The best way to clean the crusty plate is to wash it with hot water and detergent and rinse off with clean water. Do not use a scrubbing brush or a hard sponge otherwise the top layer will be damaged.

- As the crusty plate has a Teflon layer, if you use it incorrectly, it can be damaged.
- ◆ Never cut the food on the plate. Remove the food from the plate prior to cutting.
- ◆ Turn the food over preferably with a plastic or wooden spatula.

Using the Auto Defrost Feature

The Auto Defrost feature enables you to defrost meat, poultry or fish. The defrost time and power level are set automatically. You simply select the programme and the weight.




Use only recipients that are microwave-safe.

- 1 Open the oven door by pushing the large button in the bottom right-hand corner of the control panel. Place the frozen food in the centre of the glass plate. Close the door.
- 2 Press the AUTO DEFROST button.
Result: The following indications are displayed:
 - (Auto Defrost mode)
 - | (code number)
 - 0.0 (weight)
- 3 Press the AUTO DEFROST button one or more times according to the type of food to be defrosted. Refer to the table on the following page for further details.
- 4 Select the food weight by pressing the 1 kg and 0.1 kg buttons.
- 5 Increase or decrease the defrost time, if necessary, by pressing the MORE (▲) or LESS (▼) buttons respectively.
- 6 Press START.
Result:
 - ◆ Defrosting begins.
 - ◆ The oven beeps half way through defrosting to remind you to turn the food over.
- 7 Press START again to finish defrosting.



You can also defrost food manually. To do so, select the microwave cooking/reheating function with a power level of 30%. Refer to the section entitled "Cooking/Reheating" on page 12 for further details.



Using the Auto Defrost Feature (continued)

GB


The following table presents the various Auto Defrost programmes, the weights, standing times and any appropriate recommendations.

Code	Food	Serving Size	Standing Time	Recommendations
1	Meat	0.2 - 2.0 kg	20 - 30 mins.	Shield the edges with aluminium foil. Turn the meat over when the oven beeps. This programme is well-suited to beef, pork, steaks, pork chops and minced meat.
2	Poultry	0.2 - 2.0 kg	20 - 30 mins.	Shield the leg and wing tips with aluminium foil. Turn the poultry over when the oven beeps. You can defrost either whole chickens or chicken portions.
3	Fish	0.2 - 2.0 kg	20 - 30 mins.	Shield the whole tail of the fish with aluminium foil. Turn the fish over when the oven beeps. This programme is well-suited to trout, plaice, salmon and cod, whether whole or in fillets.
4	Fruit	0.2 - 0.5 kg	5 - 10 mins.	Spread the fruit out in a glass bowl. Cover during defrosting and standing. Stir carefully before leaving to stand. This programme is well-suited to soft fruit, such as raspberries, strawberries and blackberries. You can also defrost other fruit, such as apple slices or cherries.
5	Bread	120 - 750 g	5 - 10 mins.	Put the bread rolls, baguette, bread slices or whole loaves on kitchen paper on the glass plate.

Setting a Standing Time

The Hold Timer can be used to set a standing time automatically (without microwave cooking). You do not need to watch the clock; the oven will beep when the standing time is over.

- 1 Press the HOLD TIMER button.
- 2 Select the standing time by pressing the 10 min, 1 min and 10 s buttons.
- 3 Press START.
Result: The oven beeps when the standing time is over.



Multistage Cooking

Your microwave oven can be programmed to cook food in up to four stages.




Example: You wish to defrost food and cook it without having to reset the oven after each stage. You can thus defrost and cook a 1.8 kg chicken in four stages:

- ◆ Defrosting
- ◆ Standing for 1 minute
- ◆ Grill for 15 minutes
- ◆ Combined convection and microwave cooking at 200°C for 30 minutes





The first two stages must be defrosting and a standing time. The combination, convection, and grill modes can only be used once each in the remaining two stages; microwaves can however be used twice at two different power levels. The convection tray should be used, when grill, convection, and combination cooking are required.

- 1 Press the AUTO DEFROST button and set the weight by pressing the 1 kg and 0.1 kg buttons the appropriate number of times (1.8 kg in the example).
- 2 Press HOLD TIMER and set the standing time by pressing the 1 min button the appropriate number of times (1 minute in the example).
- 3 Press GRILL and set the cooking time by pressing the 10 min and 1 min buttons the appropriate number of times (15 minutes in the example).
- 4 Set the convection temperature by pressing the MW+OVEN button the appropriate number of times (200°C in the example).
- 5 Set the microwave power level by the pressing POWER LEVEL the appropriate number of times (70% in the example)
- 6 Set the combined mode cooking time by pressing the 10 min and 1 min buttons (30 minutes in the example).
- 7 Press START.
Result: Cooking starts and when it has finished:
 - ◆ The oven beeps four times
 - ◆ The current time is displayed again



Choosing the Heating Element Position

GB



The heating element is used when cooking food by convection, grilling or spit roasting. It can be placed in one of two positions:


- ◆ **Horizontal position for convection cooking and grilling**
- ◆ **Vertical position for spit roasting only**



Only change the position of the heating element when it is cold and do not apply excessive force when placing it in the vertical position.

To set the heating element to the...	Then...
Vertical position (spit roasting only)	<ul style="list-style-type: none"> ◆ Pull down on the heating element ◆ Push it towards the back of the oven until it is parallel with the back wall
Horizontal position (convection cooking and grilling)	<ul style="list-style-type: none"> ◆ Pull the heating element towards you ◆ Push it upwards until it is parallel with the roof of the oven

Choosing the Accessories



Traditional convection cooking does not require any special cookware. You should, however, use only cookware that you would use in your normal oven.

Microwave-safe recipients are not usually suitable for convection cooking; do not use plastic containers, dishes, paper cups, towels, etc.

If you wish to select a combined cooking mode (microwave and grill or convection), use only recipients that are microwave-safe and oven-proof. Metallic cookware or utensils may damage your oven.



For further details on suitable cookware and utensils, refer to the Cookware Guide on page 32.



Preheating the Oven

For convection cooking, it is recommended that you preheat the oven to the appropriate temperature before placing the food in the oven.



The maximum preheating time is 60 minutes. When the oven reaches the requested temperature, it is maintained for approximately 10 minutes; it is then switched off automatically.

- 1 Check that the heating element is in the correct position for the type of cooking that you require; refer, if necessary, to page 22 for further details.
- 2 Open the door and place the convection tray.
- 3 Press the OVEN/°C button.

Result: The following indications are displayed:


 (convection mode)
 (one-stage cooking)
 250°C (temperature)
- 4 Press the OVEN/°C button one or more times to set the temperature.
- 5 Press the START button.

Result: The oven is preheated to the requested temperature.





Cooking by Convection

The convection mode enables you to cook food in the same way as in a traditional oven. Microwaves are not used. You can set the temperature, as required, in a range varying from 40°C to 250°C in eight preset levels. The maximum cooking time is 60 minutes.

-  ♦ If you wish to preheat the oven, see above.
- ♦ Always use oven gloves when touching the recipients in the oven, as they will be very hot.
- ♦ You can get better cooking and browning, if you use the low rack.


- 1 Check that the heating element is in the horizontal position and that the convection tray is in position.
- 2 Open the door and place the recipient on the convection tray.
- 3 Press the OVEN/°C button.

Result: The following indications are displayed:

 (convection mode)
 (one-stage cooking)
 250°C (temperature)
- 4 Press the OVEN/°C button one or more times to set the temperature.
- 5 Set the cooking time by pressing the 10 min and 1 min buttons.
- 6 Press the START button.

Result: Cooking starts and when it has finished:


 - ♦ The oven beeps four times
 - ♦ The current time is displayed again



Temperature Settings		
250° C	220° C	200° C
180° C	160° C	140° C
100° C	40° C	


Grilling

GB



The grill enables you to heat and brown food quickly, without using microwaves.

- ◆ Always use oven gloves when touching the recipients in the oven, as they will be very hot.
- ◆ You can get better cooking and grilling, if you use the high rack.




1 Check that the heating element is in the horizontal position, unless you are using the roasting spit, and that the appropriate rack is in position.

2 Open the door and place the food on the rack.

3 Press the GRILL button.

Result: The following indications are displayed:

 (grill mode)
| (one-stage cooking)



4 Set the grilling time by pressing the 10 min, 1 min and 10 s buttons.

 The maximum grilling time is 60 minutes.

5 Press the START button.

Result: Grilling starts and when it has finished:


- ◆ The oven beeps four times
- ◆ The current time is displayed again



The roasting spit is useful for barbecue cooking, as you do not need to turn the meat over. It can be used for combined microwave and grill cooking.



- ◆ Make sure that the weight of the meat is evenly distributed on the spit and the spit rotates freely.
- ◆ Always use oven gloves when touching the recipients in the oven, as they will be very hot.



1 Make sure that the heating element is in the vertical position; refer to page 22 for further details.

2 Push the roasting spit through the centre of the meat.
Example: Push the spit between the backbone and breast of a chicken.

3 Place the spit on its stand and place the stand onto the glass bowl and the glass bowl onto the convection tray.

4 To help brown the meat, brush it with cooking oil.

5 Place the oven-proof convection tray on the glass plate in the oven.

6 Select combined microwave and grill, power level and time.


For...	Refer to page...
Combined microwave and grill	28

7 Press START.

Result: Cooking starts and the spit rotates. When it has finished:

- ◆ The oven beeps four times
- ◆ The current time is displayed again


8 When the meat has been fully cooked, carefully remove the spit, using oven gloves to protect your hands.




Using The Vertical Multi-spit

**CE103KB
only**


GB




Coupler Barbecue, Skewer,



Multi-Spit



Roasting-Spit



Glass Bowl

MULTI-SPIT FOR KEBAB

With the multi-spit with 6 kebab skewers you can easily barbecue meat, poultry, fish, vegetables (like onions, peppers or courgettes) and fruit which are all cut into pieces.

You can prepare the above food with the kebab skewers by using grill or combination mode.

USE OF THE MULTI-SPIT WITH KEBAB SKEWERS

1. For preparing kebab with the multi-spit take roasting-spit with the 6 skewers.
2. Put the same amount of food each skewer.
3. Place the roasting-spit into the glass bowl and insert the multi-spit into it.
4. Put the glass bowl with the multi-spit in the centre of the glass plate.

➤ Make sure that the grill heating element is in the right position at the back wall of the cavity and not at the top before starting the grilling process.

REMOVING THE MULTI-SPIT FROM THE OVEN AFTER GRILLING

1. Use oven gloves for taking for glass bowl with the multi-spit out of the oven, because it will be very hot.
2. Take out multi-spit out of the spit stand by using oven gloves as well.
3. Take out carefully the skewers and use a fork for removing the food pieces from the skewers.

➤ The multi-spit is not suitable for cleaning in the dishwasher. Therefore clean it with warm water and washing up liquid by hand. Remove the vertical multi-spit from the oven, as long as you do not need it or you do not operate the microwave oven.