

INSTRUCTIONS



P660 MIXER

P660 MIXERS

ML - 104605



EXECUTIVE OFFICES
701 RIDGE AVENUE
TROY, OHIO 45374-0001

Installation, Operation, and Care of P660 MIXERS

SAVE THESE INSTRUCTIONS

GENERAL

The P660 model mixer is a heavy duty 60 quart mixer which is designed primarily for preparing dough, batter, and pastry. It has a single speed transmission and features a 2½ horsepower Hobart-built motor, a #12 attachment hub, and an electro-mechanical timer as standard equipment.

A 60 quart stainless steel mixer bowl and a 60 quart burnished aluminum ED style dough arm are furnished with each mixer.

Bowl Guard is standard equipment on all P660 models.

These mixers can be ordered with deluxe finish, which includes a chrome plated transmission case, base, bowl support, and pedestal.



Model P660 Mixer

Shipping Weight: 399 kg (880 lb)
Net Weight: 387 kg (853 lb)

INSTALLATION

UNPACKING

Immediately after unpacking the mixer, check for possible shipping damage. If this machine is found to be damaged after unpacking, save the packaging material and contact the carrier within 15 days of delivery.

Prior to installation, test the electrical service to assure that it agrees with the specifications on the machine data plate.

LOCATION

Place the mixer in its operating location. There should be adequate space around the mixer for the user to operate the controls and install and remove bowls. The area above the mixer should allow the top cover to be removed for routine maintenance and servicing.

Holes are provided in the base for permanent bolting to the floor, although this is not necessary in normal installations. Four plastic plugs are supplied with the mixer to plug these holes if they are not used.

Once located, the mixer must be leveled.

Remove the top cover screws and the top cover.

Place a level on the machined surface of the transmission case (Fig. 1) and slide shims under the legs (base) of the mixer as required to level it front-to-back and side-to-side.

Do not replace the top cover until installation is completed.




Fig. 1

Check Lubrication Before Use

This mixer is shipped with oil in the transmission and planetary. Check oil levels before starting mixer. Refer to LUBRICATION, pages 8 – 9, for applicable lubrication procedures.

INSTALLATION CODES AND STANDARDS

The installation of this appliance must be carried out by a licensed installer and in accordance with the applicable regulations, standards, codes of practice and related publications of the country of destination.

ELECTRICAL CONNECTIONS

WARNING: ELECTRICAL AND GROUNDING CONNECTIONS MUST COMPLY WITH THE APPLICABLE PORTIONS OF RELEVANT ELECTRICAL CODES.

WARNING: DISCONNECT ELECTRICAL POWER SUPPLY AND PLACE A TAG AT THE DISCONNECT SWITCH INDICATING THAT YOU ARE WORKING ON THE CIRCUIT.

ELECTRICAL DATA

Model	Volts / Hz / Ph	Rated Amps
P660	400 / 50 / 3	4

A 26.7 mm hole for installation of electrical conduit is located at the top of the pedestal. Make electrical connections per the wiring diagram located on the inside of the Top Cover.

Check Rotation

Three-phase machines must be connected so the planetary rotates in the direction of the arrow on the Drip Cup. To check rotation:

Set the gear shift lever on 1.

Apply power to the mixer and set the Electro-Mechanical Timer on HOLD. With the Bowl Support all the way up, momentarily run the machine by pushing the START and then STOP buttons.

If rotation is incorrect, DISCONNECT ELECTRICAL POWER SUPPLY and interchange any two of the incoming power supply leads.

OPERATION

WARNING: MOVING BEATER IN BOWL, KEEP HANDS, CLOTHING, AND UTENSILS OUT WHILE IN OPERATION, DO NOT USE WITHOUT INTERLOCKED GUARD.

The P660 mixer is equipped with an Electro-Mechanical Timer Control (described at the bottom of this page). Also, become familiar with the other operating parts (Fig. 2) and their functions, which are referenced throughout the OPERATION section (pages 5 – 8).

The Bowl Guard must be in position or the mixer will not operate. Refer to page 7.

If the Bowl Support is not all the way up, the mixer will not operate unless the START button is held in.




Fig. 2

ELECTRO-MECHANICAL TIMER CONTROLS

The START button is used to start the mixer.

The STOP button is used to stop the mixer.

The TIMER is used in conjunction with the START button for timed mixing operations and will stop the mixer when a preset time has elapsed.




Fig. 3

BOWL LIFT

The Handwheel is used to raise and lower the bowl on mixers with the standard bowl lift. Turn the Handwheel clockwise to raise the bowl or counterclockwise to lower it.

MIXING

This section explains operation of the mixer and how to install bowls and agitators.

Bowl

New mixer bowls and agitators (beaters, whips, and dough arms) should be thoroughly washed with hot water and a mild soap solution, rinsed with either a mild soda or vinegar solution, and thoroughly rinsed with clear water BEFORE being used.

The bowl must be installed before the agitator.

To install the bowl, fully lower the bowl support. Position the bowl so the alignment bracket on the back of the bowl is under the retainer on the bowl support and the alignment pins on the front of the bowl support fit in the holes in the bowl. Lock the bowl in place by rotating the bowl clamps over the ears of the bowl.

If a bowl adapter is required, install it on the bowl support as you would the bowl and then install the bowl on the adapter.

Agitator

To install an agitator, the bowl must be installed and fully lowered. Place the agitator in the bowl, push it up on the agitator shaft, and turn it clockwise to seat the shaft pin in the slot of the agitator shank.

To Raise the Bowl While Mixing

To raise the bowl while the agitator is mixing the product (when required by recipe or when using the Bowl Scraper Attachment): Load ingredients. Close Wire Cage Assembly. To begin mixing, press and hold the Start button; then raise the bowl.

Bowl Guard (Fig. 3)

The Wire Cage Assembly on the Bowl Guard can be rotated out-of-the-way to add ingredients or access the bowl and agitator.

To rotate the Wire Cage Assembly to the rear . . .

Push the Latch in to release the Centering Pin from the Centering Ramp. Note how the grooves on the nylon Retainers allow the Wire Cage to ride around the circular Ridge of the planetary Drip Cup. The Wire Cage can rotate 360°; left or right. When the Wire Cage returns to the front and center position, the Centering Pin is captured and held by the Centering Ramp, restricting rotation of the Wire Cage until the Latch is pressed again.

The Wire Cage must be in the front-center position for the mixer to operate.

To remove the Wire Cage Assembly for cleaning . . .

Lower the Bowl. Rotate the Wire Cage to the rear. Remove both Agitator and Bowl. Return the Wire Cage to the front.

While holding the Wire Cage securely with both hands, use your thumb to push down on the Black Release Knob. Lower and remove the Wire Cage. Wash it in a sink or dishwasher; rinse with clear water; and dry with a clean cloth.

The stainless steel Splash Guard can be wiped-off or washed easily with a cloth or sponge and warm soapy water. Rinse with clear water. Dry with a clean cloth.

To reinstall the Wire Cage Assembly . . .

Hold the Wire Cage so its top ring is positioned around the planetary Drip Cup with the grooves in both nylon Rear Retainers straddling the Ridge on the Drip Cup. Push-in the Front-Center Retainer until it stays in and so that its grooves also straddle the Ridge on the Drip Cup. The Wire Cage is properly assembled when all three Retainers straddle the Ridge on the Drip Cup in the three opposed locations.

Rotate the Wire Cage out-of-the-way to install or remove the Agitator and Bowl or to add ingredients.

Return the Wire Cage to its front and center position to operate the mixer.




Fig. 3

Mixer Speed

On P660 mixers equipped with single-speed gearing, all work is performed at that speed.

Bowl Scraper Attachment

The Mixer Bowl Scraper Attachment (when ordered) is provided with a separate instruction manual covering its installation, operation, use and care.

CLEANING

WARNING: DISCONNECT ELECTRICAL POWER SUPPLY AND PLACE A TAG AT THE DISCONNECT SWITCH INDICATING THAT YOU ARE WORKING ON THE CIRCUIT BEFORE BEGINNING ANY CLEANING PROCEDURE.

A flat scraper and a brush are furnished to aid in cleaning bowls and agitators.

The mixer should be thoroughly cleaned daily. DO NOT use a hose to clean the mixer — it should be washed with a clean damp cloth. The base allows ample room for cleaning under the mixer. The apron may be removed by loosening the thumb screws. Behind this apron is an access cover which may be removed for cleaning.

The Drip Cup-Splash Guard (which is secured by three screws) should be removed periodically and wiped clean.

For cleaning the Bowl Guard (including both Wire Cage Assembly and Splash Guard), refer to page 7.

MAINTENANCE

WARNING: DISCONNECT ELECTRICAL POWER SUPPLY AND PLACE A TAG AT THE DISCONNECT SWITCH INDICATING THAT YOU ARE WORKING ON THE CIRCUIT BEFORE BEGINNING ANY MAINTENANCE PROCEDURE.

LUBRICATION

Planetary

The planetary oil should be checked periodically. To check, DISCONNECT ELECTRICAL POWER SUPPLY and remove the Drip Cup-Splash Guard, which is secured by three screws. Remove the fill plug (Fig. 4). Oil should be even with the bottom of the fill plug hole. If it is not, slowly add the recommended planetary lubricant until it is. Replace the fill plug and the Drip Cup-Splash Guard.

A drain plug (Fig. 4) is located on the bottom of the planetary. Should draining become necessary, remove the Drip Cup-Splash Guard and place a suitable catch pan under the drain plug. Remove the drain plug, allow the oil to completely drain, and replace the drain plug. Remove the fill plug and pour in 177 ml (6 fluid ounces) of the recommended planetary lubricant: Exxon Spartan EP-150. Replace the Fill Plug and the Drip Cup-Splash Guard. Contact your local Hobart service office for the recommended planetary lubricant.

Planetary Seal

Occasionally, the planetary seal (Fig. 4) may become dry and begin to squeak. To correct this, work a little lubrication under the lip of the seal.

Transmission

The transmission oil should be even with the line on the Oil Level Gauge when the motor is NOT running. If the oil falls below this line, DISCONNECT ELECTRICAL POWER SUPPLY and remove the Top Cover, which is secured by two screws. Remove the Transmission Fill Plug (Fig. 5) and add a small amount of the recommended transmission oil until it returns to the proper level. DO NOT overfill the transmission as leakage may result. Contact your local Hobart service office for the recommended transmission oil: Mobilgear 634 (quantity 3785 ml = 128 fluid ounces).

Bowl Lift

The slideways and lift screw (Fig. 4) should be lubricated approximately twice a year. To reach these areas, fully lower the bowl support and remove the apron, which is secured by four thumb screws. Wipe a thin coat of Lubriplate 630AA (supplied) on the bowl clamp area of the bowl supports, each slideway, and the lift screw. Replace the apron.

On units with a manual bowl lift, the handwheel gearing should be lubricated periodically. To do this, DISCONNECT ELECTRICAL POWER SUPPLY and remove the top cover, which is secured by two screws. Wipe a coat of Lubriplate 630AA on the gear teeth and replace the top cover.




Fig. 4




Fig. 5

ADJUSTMENTS

Agitator Clearance

The agitator clearance should be checked with each bowl change. The agitator must not touch the bowl and the maximum clearance between the bottom of the bowl and the E or ED Dough Arm is 8mm ($\frac{5}{16}$ ").

Install a Bowl and Agitator. If the Bowl and Agitator come into contact before the Bowl Support reaches its stop, adjust the Stop Screw upwards following the procedure below.

To Measure the Clearance . . .

Pour enough flour in the bowl to cover the bottom of the bowl where the agitator travels. With the bowl fully raised, briefly run the mixer.

Turn off the mixer, DISCONNECT ELECTRICAL POWER SUPPLY, and measure the depth of flour where the agitator has traced a path. This measurement should be taken at several points around the bowl to assure accuracy.

To Adjust the Bowl / Agitator Clearance . . .

- Remove the Apron (which is secured by 4 thumbscrews).
- Loosen the bottom Locking Nut and turn the Stop Screw counterclockwise to increase the clearance or clockwise to decrease the clearance.
- Tighten the Locking Nut while holding the Stop Screw.

Bowl Clamps

The height of the bowl clamp is controlled by a spring washer and lock nut, which are located on the bottom of the bowl support. Turning the lock nut clockwise will loosen the clamp, turning counterclockwise will tighten it. If repeated adjustments are necessary, additional service is indicated. Contact your local Hobart service office.

TROUBLESHOOTING

SYMPTOMS	POSSIBLE CAUSES
Mixer will not start.	<ol style="list-style-type: none">1. Circuit protector in open position — check fuse or disconnect switch.2. Mixer or attachment overloaded.3. Bowl not all the way up.4. Wire Cage Assembly is not in the front-center position.
Agitator touches bowl.	<ol style="list-style-type: none">1. Bowl clamp(s) not closed.2. Improper agitator clearance — see MAINTENANCE for adjustment procedure.3. Bowl clamp(s) improperly adjusted — see MAINTENANCE for adjustment procedure.
Planetary seal squeaks.	<ol style="list-style-type: none">1. Seal requires occasional lubrication — see MAINTENANCE.

SERVICE

If service is needed on this equipment, contact your local Hobart service office.

Our Hobart trained service technicians strategically located at the many Hobart branches are prepared to give you fast, efficient and reliable service. Protect your investment by having a Hobart inspection contract which assures the continued, efficient operation of your Hobart machines, spares and accessories.

For further details, contact your local regional office:

London & Home Counties	01234 841220
Scotland & N. Ireland	0141 7743456
Midland & Wales	0121 7898228
Southern	01454 616048
Northern	0113 2759727

The Hobart Manufacturing Company Limited
Hobart House
51 The Bourne
Southgate
London N14 6RT

Telephone: 0181 920 2800

Fax: 0181 886 0450

