

RCA

U
S
E
R
M
A
N
U
A
L



IMPORTADOR
Comercializadora Thomson de México, S.A. de C.V.
Miguel de Cervantes Saavedra 57
Col. Ampliación Granada
C.P. 11529 Mexico D.F.
Telefono: (55)25 81 53 20
RFC: CTM-980723-KS5

0151

EXPORTER
Thomson multimedia Inc.
P.O. Box 1976, Indianapolis, IN 46206-1976
© 2002 Thomson multimedia Inc.
Trademark(s) © Registered
Marca(s) Registrada(s)
Marque(s) © Déposé(e)
55355710 (Rev.1) (EN/F/E)
www.rca.com
www.rca.com/LatinAmerica
Printed in China/Impreso en China

RD1080

It is important to read this instruction book prior to using your new product for the first time.
Es importante leer este manual antes de usar por vez primera su equipo.

FCC Information

FCC Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

In accordance with FCC requirements, changes or modifications not expressly approved by Thomson multimedia Inc. could void the user's authority to operate this product.

This device generates and uses radio frequency (RF) energy, and if not installed and used properly, this equipment may cause interference to radio and television reception.

If this equipment does cause interference to radio or television reception (which you can determine by unplugging the unit), try to correct the interference by one or more of the following measures:

- Re-orient the receiving antenna (that is, the antenna for the radio or television that is "receiving" the interference).
- Move the unit away from the equipment that is receiving interference.
- Plug the unit into a different wall outlet so that the unit and the equipment receiving interference are on different branch circuits.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, DC 20402. Please specify stock number 004-000-00345-4 when ordering copies.

This product complies with DHHS Rules 21 CFR Subchapter J. Applicable at the date of manufacture.

RCA RD1080



Tested to Comply
With FCC Standards

FOR HOME OR OFFICE USE

This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la class B est conforme à la norme du NMB-003 du Canada

For Your Records

In the event that service should be required, you may need both the model number and the serial number. In the space below, record the date and place of purchase, and the serial number:

Model No.
Date of Purchase
Place of Purchase
Serial No.

Service Information

This product should be serviced only by those specially trained in appropriate servicing techniques. For instructions on how to obtain service, refer to the warranty included in this Guide.

Important Information

Warning

- Do not play your headset at a high volume. Hearing experts warn against extended high-volume play.
- If you experience a ringing in your ears, reduce volume or discontinue use.
- You should use extreme caution or temporarily discontinue use in potentially hazardous situations.

Even if your headset is an open-air type designed to let you hear outside sounds, don't turn up the volume so high that you are unable to hear what is around you.

Caution While Driving: Use of headphones while operating an automobile or moving vehicle is not recommended and is unlawful in some states and areas. Be careful and attentive on the road. Stop operation of the unit if you find it disruptive or distracting while driving.

Precautions for the Unit

- Do not use the unit immediately after transportation from a cold place to a warm place; condensation problem may result.
- Avoid shock to the unit especially during recording. Recorded data may be damaged.
- Do not store the unit near fire, places with high temperature or in direct sunlight.
- Do not operate or store unit in places with frequent static electricity or electrical noise (e.g. speaker, TV set).
- Clean the unit with a soft cloth or a damp chamois leather. Never use solvents.
- The unit must only be opened by qualified personnel.

Warning: Use of this product is for your personal use only. Copying CDs or downloading music files for sale or other business purposes is a violation of copyright law. It is also a violation of copyright law to download files without permission of the copyright owner.

EN

Important Information

Care of Memory Card (Not Included)

- Do not touch the golden electrodes. Use a soft dry cloth to clean any dirt.
- Do not bend Memory Cards.
- Do not operate or store MultiMediaCards in places with frequent static electricity or electrical noise (e.g. speaker, TV set). Recorded data may be damaged.
- It is normal for Memory Card to get warm after being used for a long time.
- Always put it in storage case after removing from the unit.
- Do not store Memory Card near fire, places with high temperature/ humidity or in direct sunlight.

Power supply

- Battery power: AAA (LR03) x 2.

Battery Precautions

- When storing the unit, be sure to remove the batteries because they may leak and damage the unit.
- Batteries may leak electrolyte if inserted incorrectly, if disposed of in fire, or if an attempt is made to charge a battery not intended to be recharged.
- Never mix new batteries with old ones. Do not mix battery types.
- Discard leaky batteries immediately. Leaking batteries may cause skin burns or other personal injury.
- Do not charge batteries which are not intended to be recharged.
- Dispose of batteries, according to federal, state and local regulations.

The descriptions and characteristics given in this document are given as a general indication and not as a guarantee. In order to provide the highest quality product possible, we reserve the right to make any improvement or modification without prior notice. The English version serves as the final reference on all product and operational details should any discrepancies arise in other languages.

Table of Content

FCC Information

Important Information

Before You Begin1

1. Unpacking the player and accessories1
2. What's so special about this MP3 player1
3. Insert batteries into the player2
4. Inserting a MultiMediaCard (optional)2
5. Using Headphones3
6. Connecting the Iyra Player to your Computer3

General Controls4

Radio controls5

Digital music Operation6

- Playback6
- Stop Playback6
- Skip / Search6

Advanced Operation7

- DSP7
- Play Modes7
- Programming Tracks7
- Editing Program7
- Key Lock8
- File Download8
- Adjust volume Level8

Troubleshooting Tips9

Warranty

EN

Before you Begin


1. Unpack the player and accessories

When you unpack your new player, be sure you have removed all the accessories and information papers. The items shown below are packed with your player.

1. The Player
2. Batteries
3. Software CD
4. Digital X-Phone
5. Connection Cable
6. Neck Strap
7. Carry Case

2. What's so special about this MP3 player?

This player is meant to play MP3 and Windows Media™ audio files encoded on a memory card or recorded in the built-in flash memory. To do so, you need the use of a Windows computer with USB port, connection cable (included) and a music management software (MusicMatch Jukebox).




Compressed music internet sites
www.thomson-lyra.com, www.lyrazone.com
www.musicmatch.com, www.emusic.com

1

Before You Begin

3. Insert batteries into the player

- A. To insert batteries, lift open the battery compartment door.



- B. Insert 2 "AAA"(LR03) batteries with polarities corresponding to indications on the compartment. (Refer to "More information" for battery precautions.)

- C. Close the door to the battery compartment

Note: Refer to the power level indicator on display for battery level. Replace with new batteries when the indicator is empty.


EN

4. Inserting a SD card / MultiMediaCard (Optional)

The player has built-in flash memory. To extend the playtime, you can use the optional Memory Card slot.

- A. Insert a Memory Card into the card slot when the player is off as the diagram shows:

- B. To remove card, push the Memory Card to eject.



Caution: Do not remove Memory Card during playback or when power is on. It may stop unit from playing immediately.

2

Before You Begin

5. Using Headphones

Insert phone jack into **PHONES** on the side of player for listening.




Note: Have a Blast- Just Not in Your Eardrums. Make sure you turn down the volume on the unit before you put on headphones. Increase the volume to the desired level only after headphones are in place.




6. Connecting the Lyra Player to your Computer

1. Lift the rubber cover on the player.
2. Insert the smaller end of the connection cable into the socket tightly.
3. Insert the opposite end of the connecting cable to the USB socket on the back of the computer.



Note: Refer to the Software Instruction manual for procedures in setting up USB drivers and transferring files to the player.

General Controls



1. **DISPLAY**
2. **STOP** - Stops playback and turn unit off .
3. **LAST** - Skips back to last track. Press and hold to search backward through the track.
4. **NEXT** - Skips to next track. Press and hold to search forward through the tracks.
5. **PLAY** - Turns unit on, start playback and pause, mute operation in Radio mode.
6. **DSP** - Selects among DSP modes. (Flat, Bass, Pop, Rock, Jazz, Tone)
7. **MODE** - Selects between repeat one, repeat all, random playback, random shuffle, program and program repeat all modes.
8. **RADIO** - Selects radio mode.
9. **MUSIC** - Selects Digital music playback mode.
10. **ENTER** - Presses to confirm selection.
11. **USB** - Connects USB cable.
12. **MEMORY CARD** - Slot for inserting Memory Card.
13. **PHONES** - Inserts headphones
14. **VOLUME** - Adjusts sound volume.

Radio Controls

Listening to the radio(FM only)

Manual search

1. Press **PLAY** to turn on the unit.
2. Push the **ENTER** knob upward to enter radio mode.
3. You may tune up or tune down the frequency by pushing the **ENTER** knob to the left/right.

Auto search / Preset a station

1. In radio mode, keep pushing the **ENTER** knob to the left/right for 2 seconds, the unit will start searching for a station.
2. The unit will stop searching when a station is found.
3. You may save the station by pressing **ENTER**, then push the **ENTER** knob to the left/right to select the location you want to store the station in (0-9).
4. Press **ENTER** to confirm. A preset station is stored.

Select a preset station

1. In radio mode, press **MODE** button.
2. You may recall your previously saved preset station (0-9)
3. Push the **ENTER** knob to the left/right to select your desired preset station.
4. Press **ENTER** to confirm selection.

5

Mono / Stereo selection

1. In radio mode, press DSP button to toggle between ST / Mono.

Adjust Volume Level

- Press + or - to adjust sound volume. Refer to the volume level on display for sound level.

Digital music Operation

Playback

1. In OFF mode, press **PLAY** to turn the unit on.
2. Select music by pushing the **ENTER** key downward, then the total number of tracks will show on display. Playback then starts automatically from the first track.
3. You can press **PLAY** button during playback to pause and press again to resume playback.
4. During playback, you can press **ENTER** to display complete song title and artist information.

Stop Playback

1. During playback, press **STOP** to stop playback (Stop mode) with total number of tracks will show on display.
2. Press **STOP** again to exit to the WELCOME screen. (The unit will turn itself off automatically after idle for about 1 minute.)

Skip / Search (Scan)

1. In stop mode, push **⏪** or **⏩** to select desired tracks.
2. Push **⏩** once to skip to next track. Push and hold for quick forward scan of playing track.
3. Push **⏪** once to return to previous track. Push and hold for quick backward scan of playing track.

EN

6

Advanced Operation

DSP

• In Music mode, press **DSP** button repeatedly to select among the DSP modes:

```

FLAT > BASS > POP
  ^           v
TONE > JAZZ > ROCK
  
```

• In TONE mode, you may further adjust BASS and TREBLE level.

Play modes

• In music mode, press **MODE** button repeatedly during playback for the following playback modes:

Off (Normal playback) > Repeat One > Repeat All > Shuffle > Repeat Shuffle > All Program > Repeat program > Normal.

Note: Pprogram and Repeat program only appears if there are programmed tracks.

Programming Tracks

1. Press **ENTER** in stop mode to enter program mode. You will see 'P' icon flashes on display, flashing '--' for track selection and 'P01' for program list position.
2. Press **⏪** or **⏩** to select a track. Selected track number will flash.
3. Press **ENTER** key upward/downward to skip to the previous / next programming position.
4. Press **ENTER** to confirm selection.
5. Repeat steps 2-4 for further selections. *Maximum 20 selections can be made.*
6. Press **STOP** to exit programming mode or unit returns to stop mode automatically after 30 seconds if no keys are activated.

Note: The player will enter Intro Play mode and play the beginning of each track as you scroll through tracks for programming .

Editing program

Overwriting Programmed Tracks

1. In stop mode, press **ENTER** to enter programming mode.
2. Push **△** or **▽** to select the programmed track you want to overwrite.
3. Push **⏪** or **⏩** to select the new track you want to store.
4. Press **ENTER** to confirm selection.
5. Repeat steps 2 to 4 to overwrite additional programmed tracks.

Advanced Operation

Key Lock

To avoid accidental key activation, press and hold the **MODE** button to lock keys. "Locked" can be seen on display. press and hold the **MODE** button again to unlock keys.

File Download

This unit can be connected to the computer. Please see Software Instruction Manual for instructions to install USB driver , music management software and to transfer tracks to player and/or memory card.

Adjust Volume Level

Press + or - to adjust sound volume. Refer to the volume level on display for sound level.

Troubleshooting Tips

The player does not turn on when **PLAY** button pressed.

- Batteries may be inserted incorrectly.
- Batteries may be empty.

Skipping tracks or bad sound quality?

- Repeat, random or program function may be activated.
- There may be strong magnetic fields (e.g. too close to TV) near the unit.
- Low Battery level. Replace with new ones.

Cannot perform playback?

- **LOCK** function may be activated.
- There may be no MP3 tracks in the card or internal memory.
- Memory Card may be damaged.

Cannot play tracks on the player?

- Track encoded bit rate may not be between 32 to 320kbps for MP3 or between 48kbps to 128kbps for Windows Media Audio.

Note: For better result, we recommend a constant encoded bit rate from 32 to 320kbps for MP3 and 48kbps to 128kbps for Windows Media audio. Nevertheless, your unit may play tracks encoded in variable bit rate (VBR).

USB display does not appear when connected to computer.

- Check connection between your unit and the computer. (Refer to Software Instruction Manual)
- Check if USB drivers are properly installed (Refer to Software Instruction Manual)

The player does not respond to key operations?

- Turn the player off by removing the batteries. Reinsert the batteries properly and turn the player on again to resume normal operations.

US Limited Warranty

EN

What your warranty covers:

- Defects in materials or workmanship.

For how long after your purchase:

- One year from date of purchase.
The warranty period for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first.

What we will do:

- Provide you with a new, or at our option, a refurbished unit. The exchange unit is under warranty for the remainder of the original product's warranty period.
- Proof of purchase in the form of a bill of sale or receipted invoice which is evidence that the product is within the warranty period must be presented to obtain warranty service. For rental firms, proof of first rental is also required.

How to make a warranty claim:

- Properly pack your unit. Include any cables, etc., which were originally provided with the product. We recommend using the original carton and packing materials.
- Include evidence of purchase date such as the bill of sale. Also print your name and address and a description of the defect. Send via standard UPS or its equivalent to:

Thomson multimedia Inc.
Product Exchange Center
11721 B Alameda Avenue
Socorro, Texas 79927

- Insure your shipment for loss or damage. Thomson accepts no liability in case of damage or loss en route to Thomson.
- Pay any charges billed to you by the Exchange Center for service not covered by the warranty.
- A new or refurbished unit will be shipped to you freight prepaid.

What your warranty does not cover:

- Customer instruction. (Your Owner's Manual provides information regarding operating Instructions and user controls. For additional information, ask your dealer.)
- Installation and set-up service adjustments.
- Batteries.
- Damage from misuse or neglect.
- Products which have been modified or incorporated into other products.
- Products purchased or serviced outside the USA.
- Acts of nature, such as but not limited to lightning damage.

US Limited Warranty

Product Registration:

- Please complete and mail the Product registration Card packed with your unit. It will make it easier to contact you should it ever be necessary. The return of the card is not required for warranty coverage.

Limitation of Warranty:

- **THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY THOMSON MULTIMEDIA INC., ITS AGENTS OR EMPLOYEES SHALL CREATE A WARRANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.**
- **REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. THOMSON MULTIMEDIA INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF INDIANA. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.**

How state law relates to this warranty:

- Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.
- This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

If you purchased your product outside the USA:

- This warranty does not apply. Contact your dealer for warranty information.

Canadian Limited Warranty

EN

Thomson multimedia Ltd. warrants to the purchaser or gift recipient that if any manufacturing defect becomes apparent in this product within 1 year from the original date of purchase, it will be replaced free of charge, including return transportation.

This warranty does not include damage to the product resulting from accidents, misuse or leaking batteries.

Should your product not perform properly during the warranty period, either:

1. Return it to the selling dealer with proof of purchase for replacement,
OR

2. Remove the batteries (where applicable), and pack product complete with accessories in the original carton (or equivalent).

— Mail prepaid (with proof of purchase) and insured to:

Thomson multimedia Ltd.
6200 Edwards Blvd.,
Mississauga, Ontario,
L5T 2V7
Canada

The provisions of this written warranty are in addition to and not a modification of or subtraction from the statutory warranties and other rights and remedies contained in any applicable legislation, and to the extent that any such provisions purport to disclaim, exclude or limit any such statutory warranties and other rights and remedies, such provisions shall be deemed to be amended to the extent necessary to comply therewith.

If you are unable to find a qualified servicer for out of warranty service, you may write to: Thomson multimedia Ltd.

P.O. Box 0944

Indianapolis, Indiana, U.S.A., 46206-0944

Attach your sales receipt to this booklet for future reference. This information is required if service is needed during the warranty period.

PURCHASE DATE

NAME OF STORE

