


PWR-AVIS User Manual



12249-B

COPYRIGHT

© 1999, ADC Telecommunications, Inc.
All Rights Reserved
Printed in the U.S.A.

REVISION HISTORY

ISSUE	DATE	REASON FOR CHANGE
1	04/99	Original.

TRADEMARK INFORMATION

ADC and ADC Telecommunications are registered trademarks of ADC Telecommunications, Inc.

DISCLAIMER OF LIABILITY

Contents herein are current as of the date of publication. ADC reserves the right to change the contents without prior notice. **In no event shall ADC be liable for any damages resulting from loss of data, loss of use, or loss of profits and ADC further disclaims any and all liability for indirect, incidental, special, consequential or other similar damages. This disclaimer of liability applies to all products, publications and services during and after the warranty period.**

This publication may be verified at any time by contacting ADC's Technical Assistance Center at 1-800-366-3891, extension 3475 (in U.S.A. or Canada) or 612-946-3000 (outside U.S.A. and Canada), or by writing to ADC Telecommunications, Inc., Attn: Technical Assistance Center, Mail Station #71, P.O. Box 1101, Minneapolis, MN 55440-1101, U.S.A.



ADC Telecommunications, Inc.
P.O. Box 1101, Minneapolis, Minnesota 55440-1101
In U.S.A. and Canada: 1-800-366-3891
Outside U.S.A. and Canada: (612) 938-8080
Fax: (612) 946-3292

TABLE OF CONTENTS

Content	Page
ABOUT THIS MANUAL	v
ADMONISHMENTS	v
GENERAL SAFETY PRECAUTIONS	v
1 GENERAL	1
2 DESCRIPTION	3
2.1 Physical Description	3
2.2 Functional Description	4
2.3 Technical	10
3 INSTALLATION	12
3.1 Chassis Installation	12
3.2 Cabling	14
4 OPERATION	16
4.1 Passive Jack Access Card	16
4.2 Active Jack Access Card With Unity Gain	21
4.3 Amplifier Jack Access Card	27
5 CUSTOMER INFORMATION AND ASSISTANCE	28

ABOUT THIS MANUAL

This manual describes the ADC PWR-AVIS system. The manual provides a product description, installation instructions and operational information.

ADMONISHMENTS

Important safety admonishments are used throughout this manual to warn of possible hazards to persons or equipment. An admonishment identifies a possible hazard and then explains what may happen if the hazard is not avoided. The admonishments — in the form of Dangers, Warnings, and Cautions — must be followed at all times. These warnings are flagged by use of the triangular alert icon (seen below), and are listed in descending order of severity of injury or damage and likelihood of occurrence.



Danger: *Danger is used to indicate the presence of a hazard that **will** cause severe personal injury, death, or substantial property damage if the hazard is not avoided.*



Warning: *Warning is used to indicate the presence of a hazard that **can** cause severe personal injury, death, or substantial property damage if the hazard is not avoided.*



Caution: *Caution is used to indicate the presence of a hazard that **will** or **can** cause minor personal injury or property damage if the hazard is not avoided.*

GENERAL SAFETY PRECAUTIONS

Shown here is the general admonishment that applies throughout the procedures in this manual.



Warning: *Warning is used to indicate the presence of a hazard that **can** cause severe personal injury, death, or substantial property damage if the hazard is not avoided.*

PWR-AVIS USER MANUAL

1 GENERAL

This manual describes the features, functions, and installation of the ADC Power Analog Video Interface System (PWR-AVIS) which is available with single or dual (redundant) power supplies.

PWR-AVIS provides centralized access for testing, monitoring, patching, or amplification of digital, analog video, or baseband signals. Circuits are accessed via little coaxial jacks (LCJ) mounted on jack access cards. A variety of active and passive jack access cards provide various amplification and monitoring levels. The jack access card mates with a rear interface unit (RIU) that is mounted in the chassis. A rear interface unit provides the interface for permanent coaxial connections (F or BNC) to network elements (NE) (see [Figure 1](#)).

► **Note** Jack access cards are used in the RIU only for testing or troubleshooting functions. The number of access cards required in an office must be determined and ordered by the user based on expected provisioning and maintenance activity.

The PWR-AVIS chassis contains one or two power supplies (depending upon configuration) and wiring for powering amplifier and active jack access cards.




Figure 1. Jack Access Card and Rear Interface Unit

2 DESCRIPTION

2.1 Physical Description

2.1.1 Chassis

The PWR-AVIS chassis are 3.5 inches (8.9 cm) high and mount in either 19- or 23-inch (48.3 or 58.4 cm) equipment racks. Reversible mounting brackets are provided for accommodating either rack type. The protective front cover slides into the chassis when circuit access is required. Hinged plates on the chassis mounting brackets provide an area for recording circuit identification.

The PWR-AVIS chassis contains 17 RIUs (one for test) in which LCJ jack access cards or amplifier cards are installed. Two slots are located at the front of the chassis for installing one or two (depending upon configuration) power supply module(s). Office power connections for the power supply module(s) are made, as required, via two sets of -48V and RET terminals at the rear of the chassis. An AC to -48VDC power adapter (PWR-AVIS-110-ST) may be used when a -48VDC power source is not available. A cable management tray at the rear of the chassis supports the IN and OUT cables from the Network Elements.




Figure 3. PWR-AVIS Chassis

2.1.2 Power Supply Module

The power supply modules slide into slots labeled PWR 1 and PWR 2 at the front of the chassis (see [Figure 4](#)). This DC to DC converter provides the necessary $\pm 5V$ power for the chassis. A green LED at the front of the power supply module, when lit, indicates that the power supply module is functioning properly.

- **Note:** If using the single power supply option, the module should only be inserted into the PWR 1 slot.




Figure 4. Power Supply Module

2.2 Functional Description

PWR-AVIS provides a central jack access point between network elements (NE). See [Figure 5](#) on the next page. The jack access cards provide access to circuits for monitoring and maintenance functions. (The jack circuitry automatically provides 75-ohm termination.) The jacks also provide patching functions to bypass defective equipment and/or isolate problems in circuit links. The monitor jack is non-switching. Patching into this jack does not break the circuit and allows non-intrusive access. The unity gain (baseband video) card provides a 0 dB level at the monitor jack. The IN and OUT jacks incorporate a “make before break” switching design and self-terminate into 75-ohms to ensure high service performance without interruption. The IN switching jack provides access to the input signal of an NE. Patching into the jack opens the circuit and signals can be inserted for testing or patching to bypass defective equipment. The OUT switching jack provides access to the output signal of an NE. Patching into the jacks opens the circuit and signals can then be extended for testing or bypass functions. When patching arrangements do not extend the NE output signal, it is recommended that an external 75-ohm termination plug be inserted into the OUT switching jack. This provides greater signal isolation and reduces cross-talk level. The amplifier cards, which do not have jacks for circuit access, provide fixed gain amplification of an incoming signal by 0, 10 or 20 dB respectively for return path applications.






Figure 5. Access Jack, Amp Cards and RIU Schematic

2.2.1 Powering Options

2.2.1.1 Single (Non-Redundant) Powering

The single or non-redundant powering option provides one power supply module for powering the RIUs. [Figure 6](#) shows an example of this configuration.




Figure 6. PWR-AVIS With Single Power Supply Module

2.2.1.2 Dual (Redundant) Powering

The dual or redundant powering option provides two power supply modules for powering the RIUs. [Figure 7](#) shows an example of this configuration.




Figure 7. PWR-AVIS With Dual (Redundant) Power Supply Modules

- **Note:** PWR-AVIS units configured with the single powering option can be upgraded to redundant power by ordering an additional power supply module (PWR-AVIS-PSC).

The PWR-AVIS provides two sets of screw terminal contacts (see [Figure 8](#)) at the rear of the chassis for connecting to a -48V office power supply. Alternately, a 110-48V (PWR-AVIS-110-ST) converter (purchased separately) can be attached to either set of contacts.


2.2.2 Alarms

As shown in [Figure 8](#), PWR-AVIS incorporates two pair of screw terminal alarm contacts (PS1-A and B, and PS2-A and B) located at the rear of the chassis. The contacts may be used as an interface to any existing customer-supplied alarm system. Both A and B contacts perform the same function and can be used with two independent types of warning signals, either audible or visual. If the power supply voltage drops below a normal operating threshold of 3.5VDC, failure is detected and alarm(s) are triggered. The alarm contacts are normally open and will close when a failure occurs.

2.2.3 Single/Dual Powering and Alarms

When PWR-AVIS is configured with a single power supply, only the PS1 alarms should be used. If the power supply fails in this configuration continuity will occur between the PS1 alarm terminals and all RIUs will lose power.

When PWR-AVIS is configured with two power supplies, it normally operates using the primary power supply. If the primary power supply fails, its alarms will activate and the secondary power supply will seamlessly begin to provide power to the chassis. When the primary power supply begins to operate properly (after replacement or maintenance), its alarm will deactivate and it will seamlessly override the secondary power supply. In all cases (except where both power supplies fail) all RIUs will continue to be supplied with power.



12247-B

Figure 8. Power and Alarm Contacts

2.2.4 Rear Interface Units

The RIU, mounted in the rear of the chassis, provides the interface for the coaxial cable and the jack access card which is plugged into the RIU from the front of the chassis. The interface connectors accept coaxial cable terminated with F or BNC connectors. See [Figure 9](#). The RIU is factory wired with ± 5 V and ground for powering the jack access card when it is plugged into the RIU. The ± 5 V is passed to the jack access card through pins while the ground is connected through the RIU and card bodies.




Figure 9. RIU and Jack Access Card

2.2.5 AVIS Jack Access and Amplifier Cards

There are three basic card circuit configurations available:

- A passive (-20 dB) card with Monitor, IN and OUT little coax jacks for full jack access.
- An active (0 dB baseband video) card with Monitor, IN and OUT little coax jacks for full jack access.
- Active (0, +10 and +20 dB gain amplifier) cards without access jacks.

PWR-AVIS Cards, except for the 0,10 and 20 dB active (amplifier) cards, provide the means to access circuits for monitoring and maintenance functions or to amplify an incoming signal. See [Figure 10](#). The monitor network circuitry for the active and passive cards provides access to the signal at 0 or -20 dB level respectively. The active card provides a 0 dB unity gain signal with respect to the output signal. The active amplifier cards provide fixed gain of 0, 10 and 20 dB respectively and are for return path application with bandwidth of 5 MHz to 200 MHz. Power (± 5 V) and ground for active cards is automatically transferred from the RIU when the card is plugged in. The cards with jack circuitry automatically provide 75-ohm circuit termination.




Figure 10. Passive and Active Jack Access Cards

2.2.6 Cable Type

The PWR-AVIS jacks are designed to accept patch cords made up of 735A type mini coaxial cable equipped with little coax plugs (LCP). Equipment (IN and OUT) cable is dependent upon service or bandwidth of the associated equipment. Video equipment requires 734S1 or equivalent cable, equipment operating at intermediate frequencies (IF) and radio frequencies (RF) require HEC-2 or equivalent type cable. All cables should be 75-ohm coaxial with tinned copper shield. The recommended maximum length of cable between NEs is shown in [Table 1](#). Cables are available with F or BNC connectors factory pre-terminated on one end and a stub end on the opposite end. The stub end can then be field connectorized using the appropriate connector to fit the NE Interface. This method of cabling provides exact length cables and minimizes storage congestion. If the use of pre-terminated cables is not desired, connector kits with installation procedures are available from ADC for field termination.

Table 1. Recommended Cable Type and Maximum Length Between Network Elements

CIRCUIT USE	CABLE TYPE	BANDWIDTH	MAX. CABLE LENGTH
Intermediate Frequencies	HEC-2 or equivalent	0–300 MHz	200 feet (61.0 meter)
Radio Frequencies	HEC-2 or equivalent	0–300 MHz	200 feet (61.0 meter)
Baseband Video	734S1 or equivalent	0–6 MHz	200 feet (61.0 meter)

2.3 Technical Description

Table 2. PWR AVIS Technical Specifications

PARAMETER	SPECIFICATION
Dimensions (Chassis)	
Height	3.5 inches (8.9 cm)
Width	19.0 or 23.0 inches (48.3 or 58.4 cm)
Depth	10.0 inches (25.4 cm) Can be recessed 2.0 inches (5.1 cm)
Operating Voltage (Powered Chassis)	
48 VDC	± 20%
120/240 VAC	± 20%, 47–63 Hz
Power Consumption	4 Watts, Max.
RIU Interface Connectors	BNC or F- type
Access Jack Interface	LCJ (0.177 inch diameter)
Electrical Performance (Passive –20dB Access Card)	
Bandwidth	0 to 300 MHz
Impedance	75 ohm nominal
Insertion Loss RIU RIU and LCJ	0.33 dB nominal – 0.40 dB maximum 0.50 dB nominal – 0.75 dB maximum
Monitor Level	21.5 ± 1.5 dB below signal level (1 MHz to 300 MHz)
Return Loss RIU RIU and LCJ	–40 dB minimum –25 dB minimum
Contact Resistance	Less than 30 milliohms
Electrical Performance (0 dB Baseband Video Card)	
Bandwidth	15 Hz – 6 MHz
Impedance	75 ohm nominal
Crosstalk	Greater than –70 dB isolation adjacent channels, 15 Hz to 6MHz
Monitor Short Circuit	1 hour
Monitor Level In IRE In dB	± 1.5 IRE 0 dB ± 62 mdB
Return Loss	Greater than –35 dB, 15 Hz to 6 MHz
Signal to Noise Ratio	70 dB
Diff Gain	0.20%
Diff Phase	0.2 degrees
Chroma-Luma Delay	± 10 ns
Chroma-Luma Gain	± 100 mdB
Gain Frequency	58 IRE

(continued)

Table 2. PWR AVIS Technical Specifications, continued

PARAMETER	SPECIFICATION
Electrical Performance (Amplifier Card)	
Gain 0 dB amp card 10 dB amp card 20 dB amp card	0±1 dB, 5 – 100 MHz 10±1 dB, 5 – 100 MHz 20±1 dB, 5 – 50 MHz
Reverse Isolation	<-50 dB, 5-50 MHz <-40 dB, 50-100 MHz
Impedance	75 ohms nominal
Return Loss Input Output	<-30 dB, 5-50 MHz <-20 dB, 50-100 MHz <-20 dB, 5-50 MHz <-15 dB, 50-100 MHz
Noise Figure 0 dB 10 dB 20 dB	25 dB Typical 18 dB Typical 17 dB Typical
CSO (typical) 6 channels, T7-T12, @ 30 dBmV per channel output 0 dB 10 dB 20 dB	-60 dBc Typical -60 dBc Typical -50 dBc Typical
CTB (typical) 6 channels, T7-T12, @ 30 dBmV per channel output 0 dB 10 dB 20 dB	-70 dBc Typical -70 dBc Typical -70 dBc Typical
Alarm Contacts	Normally open
Environmental	
Operating Temperature	32–122 F (0–50 C)
Humidity Range	20–90% non-condensing

3 INSTALLATION



Danger: To avoid the possibility of severe and potentially fatal electric shock, never install electrical equipment in a wet location or during a lightning storm.



Caution: Always wear an anti-static discharge wrist strap to prevent static electric discharge damage to the Jack Access Card electronic circuitry.

The PWR-AVIS chassis mounts in a 19- or 23-inch (48.3 or 58.4 cm) equipment rack. The chassis can be mounted flush with the rack, or extended 2.0 inches (5.0 cm) out in front of the rack. Mounting screws, reversible mounting brackets, designation labels and cable management tray are shipped with the chassis.

The cable type used for the NE IN and OUT circuits is dependent upon application, type of service and equipment. All cables should be 75 ohm coaxial with tinned copper shield. The recommended maximum lengths are from NE to NE. See [Figure 11](#).




Figure 11. Recommended Maximum Cable Lengths

3.1 Chassis Installation



Danger: To avoid the possibility of severe and potentially fatal electric shock, use extreme care when working at the back of the chassis with the power terminations.

1. Determine rack location, mounting space width and recess position. See [Figure 12](#).
2. Attach the mounting brackets to the chassis accordingly.
3. Position the chassis into the rack location and secure it in place with four mounting screws (provided), two on each side.
4. Connect the chassis ground terminal at the rear of the chassis to the office frame ground. See [Figure 13](#).
5. Attach the cable management tray to the rear of the chassis. See [Figure 12](#).

6. Attach the designation label to the inside of the chassis front door.
 7. Attach power wires, -48V and return. A second set of terminals (-48V (2) and RET (2)) is provided if a backup power source is desired. See [Figure 14](#).
 8. Attach wires from pre-existing alarm system (if any) to the alarm contacts on the power supply unit.
- **Note:** Use only the PS1 alarms if the chassis is configured with one power supply. Use PS1 and PS2 alarms if the chassis is configured with dual (redundant) power supplies.




Figure 12. PWR-AVIS Chassis with Mounting Positions




Figure 13. Chassis Ground Terminal




Figure 14. Office Power Connection

3.2 Cabling

Run and Cable the chassis as follows:

1. Obtain NE circuit IN and OUT assignments from local support staff.
2. Label all IN and OUT cables to identify NE associated with each card IN and OUT jack. Ensure that the NE OUT cable terminates to the RIU OUT and the NE IN terminates to the RIU IN.
3. Route the cables from the NE to the rear of the chassis.

Route circuits 1 through 10 on the right side of the rack, as viewed from the rear. Route circuits 11 through 16 on the left side of the rack. See [Figure 15](#).




Figure 15. AVIS Chassis Cable Routing

4. Dress each coaxial cable across the rear cable management tray. Follow local practice regarding the use of lacing cord or tie wraps for securing the cables to the tray.
5. Measure the length of cable from the cable management tray to the designated RIU, allowing slack for tension relief. Cut, strip, and terminate each coaxial cable with an appropriate F or BNC coaxial connector. Instructions for terminating coaxial connectors are included with the connectors.
6. Record the NE assignment on the designation label located on the inside front door of the chassis.

4 OPERATION


This section provides operational procedures for the ADC Power Analog Video Interface System.

The following figures depict typical interconnect, cross-connect, and testing set-up configurations for the passive jack access cards, active jack access cards, and amplifier cards.




Caution: Always wear an anti-static discharge wrist strap to prevent static electric discharge damage to the Jack Access Card electronic circuitry.

4.1 Passive Jack Access Card




6412-A

Figure 16. Typical Interconnect Application




6413-A

Figure 17. Typical Cross-Connect Application




6414-A

Figure 18. Cross-Connect Application for Local Commercial Insertion



6415-A

Figure 19. Intrusive Test of Transport Feed



6416-A

Figure 20. Insertion of VITS Test Signal




Figure 21. Bypass Failed Video Transport System




Figure 22. Intrusive Insertion of Test Signal




Figure 23. Non-Intrusive Video Test Access

4.2 Active Jack Access Card With Unity Gain




Figure 24. Typical Interconnect Application





Figure 25. Typical Cross-Connect Application



10222-A

Figure 26. Cross-Connect Application for Local Commercial Insertion




Figure 27. Non-Intrusive Insertion of Video Test Signal with Unity Gain Jack Access Card




Figure 28. Non-Intrusive Test of Transport Feed




Figure 29. Insertion of Test Signal




Figure 30. Bypass Failed Video System






Figure 31. Intrusive Insertion of Test Signal



10227-A

Figure 32. Non-Intrusive Insertion of Video Test Signal



10228-A

Figure 33. Temporary Same Video Signal Distribution to Second Location

4.3 Amplifier Jack Access Card




Figure 34. Typical Interconnect with Gain Application

5 CUSTOMER INFORMATION AND ASSISTANCE

For customers wanting information on ADC products or help in using them, ADC offers the services listed below. To obtain any of these services by telephone, first dial the central ADC telephone number, then dial the extension provided below.

The central number for calls originating in the U.S.A. or Canada is **1-800-366-3891**. For calls originating outside the U.S.A. or Canada, dial country code "1" then dial **612-946-3000**.

Sales Assistance Extension 3000	<ul style="list-style-type: none"> • Quotation Proposals • Ordering and Delivery • General Product Information
Systems Integration Extension 3000	<ul style="list-style-type: none"> • Complete Solutions (from Concept to Installation) • Network Design and Integration Testing • System Turn-Up and Testing • Network Monitoring (Upstream or Downstream) • Power Monitoring and Remote Surveillance • Service/Maintenance Agreements • Systems Operation
BCG Technical Assistance Center Extension 3475 E-Mail: technical@adc.com	<ul style="list-style-type: none"> • Technical Information • System/Network Configuration • Product Specification and Application • Training (Product-Specific) • Installation and Operation Assistance • Troubleshooting and Repair
Product Return Department Extension 3748 E-Mail: repair&return@adc.com	<ul style="list-style-type: none"> • ADC Return Authorization number and instructions must be obtained before returning products.

Product information may also be obtained using the ADC web site at **www.adc.com** or by writing ADC Telecommunications, Inc., P.O. Box 1101, Minneapolis, MN 55440-1101, U.S.A.

Contents herein are current as of the date of publication. ADC reserves the right to change the contents without prior notice. **In no event shall ADC be liable for any damages resulting from loss of data, loss of use, or loss of profits and ADC further disclaims any and all liability for indirect, incidental, special, consequential or other similar damages. This disclaimer of liability applies to all products, publications and services during and after the warranty period.**

This publication may be verified at any time by contacting ADC's Technical Assistance Center at 1-800-366-3891, extension 3475 (in U.S.A. or Canada) or 612-946-3000 (outside U.S.A. and Canada), or by writing to ADC Telecommunications, Inc., Attn: Technical Assistance Center, Mail Station #71, P.O. Box 1101, Minneapolis, MN 55440-1101, U.S.A.



© 1999, ADC Telecommunications, Inc.
 All Rights Reserved
 Printed in U.S.A.



www.adc.com