

Quick Installation Guide NAS 3.0 Adapter (NAS30U2)

www.addonics.com

v5.1.11

Technical Support

If you need any assistance to get your unit functioning properly, please have your product information ready and contact Addonics Technical Support at:

Hours: 8:30 am - 6:00 pm PST Phone: 408-453-6212 Email: http://www.addonics.com/support/query/

For more detailed information on setting up the NAS30U2 adapter, refer to the User Manual located on the CD that came with the device.

The NAS 3.0 adapter is a flexible, economical and powerful unit for your Network. Follow the instructions to help you connect, setup and configure it.

Note: Any external USB storage device that you connect to the NAS 3.0 adapter is required to be pre-formatted with either NTFS, FAT32 or FAT64. When the external USB storage device is connected to the NAS 3.0 adapter , the adapter creates a configuration file and a default Public folder.

If you are connecting an external USB drive with data on it, all the data will remain on the drive but the NAS cannot see those data unless transferred to the Public folder.

Network Environment

There are 3 different setup conditions you can choose:

A. Setup NAS30U2 as a DHCP Client:


If the NAS30U2 is connected to a LAN network with an active DHCP server, it will obtain an IP address from DHCP server automatically.

B. Setup NAS30U2 as DHCP Server:


If your LAN network does not have an active DHCP server, the NAS30U2 will immediately act as DHCP server and assign itself an IP address for installation.

C. Setup NAS30U2 in Static IP environment:

You first need to configure the IP address for NAS30U2 to operate in the static IP environment. For Configuring details, please refer to "LAN Config" setup page.



I. NAS30U2 Hardware Installation



- 2. Connect LAN cable via LAN switch and Router.
- 3. Connect 5V power adapter to power up the NAS adapter

NAS30U2 connected directly to a computer's NIC card

If you connect the NAS30U2 to a computer directly, it will act as a DHCP server, assigning itself an IP address automatically and will also assign an IP address to the computer's network card. This configuration will not enable you to see the drive on the network.

NAS30U2 connected to a Router or Switch

When the NAS30U2 is connected to a LAN network with an active DHCP server, it will obtain an IP address from DHCP server automatically. Or if your LAN network does not have an active DHCP server, NAS30U2 will immediately act as DHCP server and assign itself an IP address for installation

II. Search NAS30U2 using SDisk Utility

1. Browse the CD enclosed in the product package. Copy and paste "SDisk Utility" in to your computer then double click the icon to start search.

Note: "SDisk utility" was written with JAVA script, please make sure your computer has installed JAVA before, if not please install the JAVA JRE from the CD drive.



2. When NAS30U2 has been found, click "Connect" to enter web GUI utility.

🍰 S	earch Disk						
IP:	192.168.1.158	•	Name:	STORAGE-06E1	10	Эroup Name:	WORKGROUP
				Search Next	Conne	ct	

Open NAS30U2 web GUI by using web browser.

- 1. Open web browser and type default host name "storage" in the search bar.
- 2. Default login is "admin" for both User name and password. Click "OK" to enter configurations.

storage	? 🛛
	Gr.
NET Disk	
USER name	🔮 admin 🛛 💌
Password	admin
	ÓK Cancél

Identification

You can change and modify your host, group name and password from this page. Click "Apply" to save the setting.

Host name: This is used to identify your device on the network. If you prefer a different name, type in the new name and click "Apply" to save setting.

Group Name: This should be the same as your workgroup. In general, the default "WORKGROUP" will be OK. But if your workstation belongs to different workgroup, type in the correct group name to modify.

For Window OS, right click on "My computer" and choose "Properties", go to the computer name tab to see your current workgroup.

If using a Mac OS system, to join a Windows workgroup, open the directory access utility (under Applications-> utilities). Select SMB and click configure to modify the settings (administrator access required to access this option.)

Note: We strongly suggest you to change the password as soon as you logged in, to prevent unauthorized access.

LAN Configuration

By default, "LAN Config" is set to "Automatic IP". This will allow the NAS30U2 to obtain its IP address automatically. If you prefer setting it manually, select the static IP option, enter your own value and click "Apply" to confirm the new setting.

• = = 11 = .		تحصيرا انصبيت المصينة فمصياره	
System ——	LAN Config		
tatus	Automatic IP	Static IP as below	
dministration	IP Address	192.168.1.100	
me Setting	Subnet Mask	255.255.255.0	
AN Config	Gateway	192.168.1.1	
aintenance	Primary DNS	192.168.1.1	
Server	Secondary DNS	68.94.156.1	Apply
le Server	DUCB Config		
ebDAV Server	DHCP Config –	Disable	
edia Server	DHCP Server		
rinter Server	DICF Server	© Enable	Apply
2P Server	- MAC Address -		
	MAC Address	00:B3:F4:00:1D:60	

To access File Server's PUBLIC folder of NAS30U2 in Windows


Click on the Windows icon located on the bottom left corner of the screen, on the "Search programs and files" \\ followed by the IP address of the NAS3.0 adapter. Eg:\\192.168.1.121 and press Enter key to continue.

[₩ \\192.168.1.186
₽ See more results
\\192.168.1.186 × Shut down >
🚱 é 🖻 🛛

Type "Guest" as username. Leave password empty. Click on OK. This will direct you to the Public folder on the NAS drive.

Windows Security		x
	ork Password sword to connect to: 192.168.1.186	
	User name Password Domain: BEN-PC Remember my credentials	
😣 Log	on failure: unknown user name or bad password.	
	OK	

Now you have set up the folder that you wish to share on your NAS . This folder can be access from other computer on your local network.



To list the NAS drive in Network Places

Go to Network Places in Windows XP, under Network Tasks, click on the "Set up a home or small office network". Follow the wizard and once completed, reboot your system.

For Vista and Windows 7, enable file sharing when accessing the NAS over the network.

To access Samba PUBLIC folder of NAS30U2 in Ubuntu 8.04

First, using the console get the prerequisites for the samba file system: \$ sudo aptitude install samba smbfs \$ mkdir /mnt/NAS \$ sudo mount.cifs //NAS_IP_address/Public /mnt/NAS -o username=Guest

To access Samba PUBLIC folder of NAS30U2 in Mac OS X

- 1. Start at the "Go" drop down menu at the top of your screen, then click "Connect to server".
- 2. Type into the "Server Address" field 'smb://' followed by the IP address of the NAS30U2 you want to connect.
- 3. Click the "Connect" button in the bottom right corner of the window.
- 4. Enter in a username and password. Click the "OK" button in the bottom right hand corner of the window to finish.

Note: The workgroup name needs to be the workgroup the PC belongs to. If you don't know the workgroup that the PC belongs to you can find out by right clicking on the "My Computer" desktop icon on the PC, selecting "Properties" and then selecting the "Computer Name" tab. The work group name is about half way down the window.

5. Select the "share" you are after. This simply refers to a particular group of shared files. Click "OK".

CONTACT US

www.addonics.com

Phone:	408-573-8580
Fax:	408-573-8588
Email:	http://www.addonics.com/sales/query/