

 **Intelligent Technologies****DeviceNet Starter Network Adapter Product  
(D77B-DSNAP)****Installation and User Manual**

September 2002

**Important Notice – Please Read**

The product discussed in this literature is subject to terms and conditions outlined in appropriate Eaton's Cutler-Hammer selling policies. The sole source governing the rights and remedies of any purchaser of this equipment is the relevant Eaton's Cutler-Hammer selling policy.

NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, OR WARRANTIES ARISING FROM COURSE OF DEALING OR USAGE OF TRADE, ARE MADE REGARDING THE INFORMATION, RECOMMENDATIONS AND DESCRIPTIONS CONTAINED HEREIN. In no event will Eaton's Cutler-Hammer be responsible to the purchaser or user in contract, in tort (including negligence), strict liability or otherwise for any special, indirect, incidental or consequential damage or loss whatsoever, including but not limited to damage or loss of use of equipment, plant or power system, cost of capital, loss of power, additional expenses in the use of existing power facilities, or claims against the purchaser or user by its customers resulting from the use of the information, recommendations and descriptions contained herein.

Cover Photo: *IT.* D77B-DSNAP

## Table of Contents

<b>PRODUCT OVERVIEW</b>	
Description . . . . .	1
Features and Benefits . . . . .	2
Safety . . . . .	3
Environmental Ratings . . . . .	4
Approvals/Certifications . . . . .	4
Catalog Numbering System . . . . .	4
<b>PHYSICAL FEATURES</b>	
Physical Description . . . . .	5
Dimensions . . . . .	5
Power Source . . . . .	6
<b>INSTALLATION</b>	
Mount the D77B-DSNAP to the Starter . . . . .	7
Connect the Starter Terminal Adapter to the Starter . . . . .	9
Connect the D77B-DSNAP to DeviceNet . . . . .	10
Set the DeviceNet MAC ID and Baud Rate . . . . .	11
<b>OPERATION</b>	
“Out of Box” Operation . . . . .	12
Quick Start . . . . .	12
FVNR Motor Controller . . . . .	12
FVR Motor Controller . . . . .	14
S751 Motor Controller . . . . .	15
Safe State Behavior . . . . .	17
Input and Output Assemblies . . . . .	17
Input Assembly Data Definition . . . . .	18
Output Assembly Data Definition . . . . .	18
Typical Application . . . . .	19
Features . . . . .	19
DeviceNet Status LED . . . . .	20
Functional Description . . . . .	21
<b>CONFIGURATION</b>	
Using CH Studio . . . . .	22
General Properties . . . . .	23
Configuring Enhanced Features . . . . .	24
Monitor the D77B-DSNAP . . . . .	25
Change the I/O Assemblies of the D77B-DSNAP . . . . .	26
Using a Generic DeviceNet Tool . . . . .	27
Autoconfiguring the D77B-DSNAP for the Starter . . . . .	27
<b>TROUBLESHOOTING AND MAINTENANCE</b>	
Renewal Parts . . . . .	28
Troubleshooting . . . . .	29
<b>APPENDIX A: SUPPORTED DEVICENET OBJECTS</b>	
DeviceNet Objects . . . . .	30
DeviceNet I/O Assemblies . . . . .	39
DeviceNet Input Assemblies . . . . .	40
DeviceNet Output Assemblies . . . . .	42
<b>IT. PUBLICATIONS AND SUPPORT</b>	43

September 2002

**List of Figures**

Figure 1: D77B-DSNAP Features .....	5
Figure 2: D77B-DSNAP Dimensions, mm [in].....	5
Figure 3: Starter Terminal Adapter Connection .....	6
Figure 4: D77B-DSNAP Alignment and Mounting .....	8
Figure 5: D77B-DSNAP Removal .....	8
Figure 6: Connecting Starter Terminal Adapter .....	9
Figure 7: Jumper Installation .....	9
Figure 8: DIP Switch Setting Example .....	11
Figure 9: D77B-DSNAP-X1 on FVNR <i>IT</i> . Starter .....	13
Figure 10: D77B-DSNAP-X2 on FVR <i>IT</i> . Starter.....	14
Figure 11: D77B-DSNAP-X1 on S751 <i>IT</i> . Soft Starter .....	16
Figure 12: Typical D77B-DSNAP Application .....	19

**List of Tables**

Table 1: D77B-DSNAP Electromechanical Starter Connectivity Table.....	1
Table 2: D77B-DSNAP S751 Connectivity Table .....	1
Table 3: Environmental Ratings .....	4
Table 4: Approvals/Certifications .....	4
Table 5: Catalog Numbers.....	4
Table 6: Power Requirements.....	6
Table 7: Starter Size/Available Auxiliary Locations on Mounted D77B-DSNAP. .	7
Table 8: DeviceNet Connection.....	10
Table 9: Baud Rate Configuration Switches .....	11
Table 10: Input Assembly for Non-reversing Starter (E101, N101) .....	13
Table 11: Output Assembly for Non-reversing Starter (E101, N101) and S751 Soft Start.....	14
Table 12: Input Assembly for Reversing Starter (E501, N501).....	15
Table 13: Output Assembly for Reversing Starter (E501, N501) .....	15
Table 14: Input Assembly for S751 Soft Start .....	16
Table 15: Output Assembly for S751 Soft Start .....	17
Table 16: Allowable DeviceNet I/O Assemblies.....	17
Table 17: Input Assembly Data Definitions .....	18
Table 18: Output Assembly Data Definitions.....	18
Table 19: Standard Protective Features.....	19
Table 20: Enhanced Features .....	20
Table 21: Combined MS/NS LED .....	20
Table 22: Truth Table .....	21
Table 23: D77B-DSNAP Renewal Parts .....	28
Table 24: Troubleshooting .....	29
Table 25: Supported Objects.....	30
Table 26: DeviceNet Object Common Services.....	30
Table 27: Identity Object 0x01.....	31
Table 28: DeviceNet Object 0x03 — Instance 1 .....	31
Table 29: Connection Object 0x05 — Instance 1 (Explicit Connection).....	32
Table 30: Connection Object 0x05 — Instance 2 (I/O Message).....	32
Table 31: Discrete Input Object 0x08 .....	33
Table 32: Motor Data Object 0x28 — Instance 1 .....	34
Table 33: Control Supervisor Object 0x29 — Instance 1 .....	35
Table 34: Overload Object 0x2C — Instance 1.....	37
Table 35: Soft Start Object 0x2D — Instance 1 .....	38
Table 36: Allowable DeviceNet I/O Assemblies.....	39
Table 37: Reading Current Input Assembly.....	39
Table 38: Setting Input Assembly.....	39
Table 39: Reading Current Output Assembly .....	39

Table 40: Setting Output Assembly . . . . .	39
Table 41: Assembly 52 (0x34) — Basic Motor Starter . . . . .	40
Table 42: Assembly 53 (0x35) — Extended Motor Starter 1 . . . . .	40
Table 43: Assembly 54 (0x36) — Extended Motor Starter 2 . . . . .	40
Table 44: Assembly 60 (0x3C) — Basic Soft Start Input . . . . .	40
Table 45: Assembly 102 (0x66) — D77B-DSNAP Motor Starter . . . . .	40
Table 46: Assembly 103 (0x67) — D77B-DSNAP Extended Motor Starter. . . . .	40
Table 47: Assembly 105 (0x69) — D77B-DSNAP Abbreviated Motor Starter 1. . .	41
Table 48: Assembly 106 (0x6A) — D77B-DSNAP Abbreviated Motor Starter 2 . .	41
Table 49: Assembly 108 (0x6C) — D77B-DSNAP Motor Starter with Fault Code .	41
Table 50: Assembly 109 (0x6D) — D77B-DSNAP Expanded Motor Starter with Fault Code . . . . .	41
Table 51: Assembly 114 (0x72) — Complete Status Assembly . . . . .	41
Table 52: Input Definitions . . . . .	42
Table 53: Assembly 3 (0x03) — Basic Motor Starter . . . . .	42
Table 54: Assembly 5 (0x05) — Extended Motor Starter . . . . .	42
Table 55: Output Definitions . . . . .	42
Table 56: <i>IT</i> Publications . . . . .	43

September 2002

## Product Overview

### Description

Cutler-Hammer Intelligent Technologies (*IT.*) D77B-DSNAP (**DeviceNet Starter Network Adapter Product**) by Eaton Corporation is the result of a substantive engineering and marketing effort, involving extensive customer input. This product has greatly increased functionality of the *IT.* Electromechanical Starter with the addition of enhanced features. This front-mount device is a single DeviceNet node providing control and monitoring of an *IT.* Electromechanical Starter application.

The D77B-DSNAP provides a communication interface to the following *IT.* Electromechanical Starters.

**Table 1: D77B-DSNAP Electromechanical Starter Connectivity Table**

IEC E101, FVNR E501, FVR	NEMA N101, FVNR N501, FVR	Frame Width
B	00	45 mm
	0	
C	1	54 mm
D	2	76 mm
E	3	105 mm
	4	
F	5	140 mm

**Table 2: D77B-DSNAP S751 Connectivity Table**

S751 Soft Start
All

This manual specifically addresses the DeviceNet Starter Network Adapter Product (D77B-DSNAP). The D77B-DSNAP provides connectivity to DeviceNet supporting Group 2 slave, I/O poll and explicit messaging.

For further information on the *IT.* family of devices, visit our Web site at: [www.cutler-hammer.eaton.com/it](http://www.cutler-hammer.eaton.com/it)

---

### Notice

---

The D77B-DSNAP can only be applied with the *IT.* family of starters.

## Features and Benefits

The *IT.* D77B-DSNAP includes the following significant features:

- Communication to DeviceNet consuming one DeviceNet MAC ID
- Control of non-reversing and reversing *IT.* Starters and S751 Soft Start
- Monitoring of non-reversing and reversing *IT.* Starters and S751 Soft Start
- Easy direct mounting to the front of *IT.* Starters and S751 Soft Start
- Optional ground fault detector
- No special software application required for normal setup. MAC ID and baud rate are set with DIP switches
- Warning levels that are user-settable

September 2002

## Safety

The following safety statements relate to the installation, setup and operation of the Eaton's Cutler-Hammer *IT.* D77B-DSNAP and Starter.

---

### Notice

---

Make sure you read and understand the installation procedures in this manual before you attempt to set up or operate the equipment.

---

### WARNING

---

This instruction manual should be used for proper installation, setup and operation of the *IT.* D77B-DSNAP. Improperly installing and maintaining this product can result in serious personal injury or property damage. Before attempting installation, setup or operation, read and understand this entire manual.

---

### WARNING

---

Hazardous voltage can cause electric shock and burns. Always disconnect power before proceeding with any work on this product.

---

### WARNING

---

Only apply 24V DC to the Terminal Adapter power terminals. Use of any other voltage may result in personal injury, property damage and damage to the *IT.* D77B-DSNAP.

---

### WARNING

---

To provide continued protection against fire or shock hazard, the complete *IT.* D77B-DSNAP must be replaced if it becomes inoperative.

## Environmental Ratings

The following environmental ratings apply to the D77B-DSNAP.

**Table 3: Environmental Ratings**

Category	Description	Specification
Transportation/ Storage	Temperature	-50°C to 80°C [-58°F to 176°F]
	Humidity	5 – 95% non-condensing
Operating	Temperature	0°C to 60°C [32°F to 140°F]
	Humidity	5 – 95% non-condensing
	Altitude	Above 2000 meters [6600 feet] consult factory
	Shock (IEC 68-2-27)	15G in any direction for 11 milliseconds
	Vibration (IEC 68-2-6)	5 – 150 Hz, 5G, 0.7 mm maximum peak-to-peak

## Approvals/Certifications

The following approvals and certifications apply to the D77B-DSNAP.

**Table 4: Approvals/Certifications**

Standard	Approval/Certification
Agency Certifications	UL 508 CE (Low Voltage Directive) CSA C22.2 No. 14 ODVA Group 2 slave no UCMM
Radiated and Conducted Emissions	EN 5011 Class A

### Electrical/EMC

ESD Immunity (IEC 61000-4-2)	±8 kV air, ±4 kV contact
Radiated Immunity (IEC 61000-4-3)	10 V/m 80 – 1000 MHz, 80% amplitude modulation @ 1 kHz
Fast Transient (IEC 61000-4-4)	±2 kV supply and control ±1 kV communications
Surge (IEC 61000-4-5)	±1 kV line-to-line ±2 kV line-to-ground
RF Conducted (IEC 61000-4-6)	10V, 0.15 – 80 MHz
Magnetic Field (IEC 61000-4-8)	30 A/m, 50 Hz
Voltage Dips (IEC 61000-4-11)	30% dip @ 10 ms 60% dip @ 100 ms >95% interrupt @ 5 ms
Protection Degree (IEC 60947-1)	IP20

## Catalog Numbering System

The D77B-DSNAP can be ordered as an assembly or as individual components. The assembly includes all components for normal operation.

**Table 5: Catalog Numbers**


Description	Catalog Number
SNAP Jumper to terminal adapter	D77B-RJJ1
D77B-DSNAP Assembly of terminal adapter, jumper and D77B-DSNAP	D77B-DSNAP-X1
D77B-DSNAP Assembly of terminal adapter, jumper, D77B-DSNAP and second contactor sensor	D77B-DSNAP-X2
DeviceNet Start Network Adapter Product	D77B-DSNAP
SNAP Terminal Adapter for FVR and FVNR starters and S751 Soft Start	D77B-TC8
Second contactor sensor for FVR starters and contactors	D77B-A2
Ground Fault Detector for 45 mm and 54 mm frame starters	D77B-GF1
Ground Fault Detector for 76 mm and 105 mm starters	D77B-GF2
Ground Fault Detector for 140 mm starters	D77B-GF3

September 2002

## Physical Features

### Physical Description


Figure 1 illustrates the front and back of the IT. D77B-DSNAP and its various features.



**Figure 1: D77B-DSNAP Features**

### Dimensions

Figure 2 illustrates the dimensions of the IT. D77B-DSNAP.



**Figure 2: D77B-DSNAP Dimensions, mm [in]**

## Power Source

The *IT* D77B-DSNAP is designed for use with 24V DC power. The D77B-DSNAP uses power from two sources, the DeviceNet subnet and the Eaton's Cutler-Hammer *IT* Starter. This allows the D77B-DSNAP to indicate to the user that the *IT* Starter does not have 24V DC power, signaling a fault or an E-Stop.

Power for DeviceNet communication CPU comes from DeviceNet, as illustrated in **Table 6**. Some power is required from the starter for communication to be present between the *IT* Starters and the D77B-DSNAP.


The power for the *IT* Starter must be connected to the Starter Terminal Adapter.

**Table 6: Power Requirements**

Current Source	Load
DeviceNet	90 mA
<i>IT</i> Starter	Less than 1 mA

When a power supply is chosen for the starter(s), size it for the load of the starter(s) and the D77B-DSNAP using the appropriate *IT* contactor and starter user manual.

The power for Eaton's Cutler-Hammer *IT* Starter must be connected to the *IT* Starter terminal, as illustrated in **Figure 3**.



**Figure 3: Starter Terminal Adapter Connection**

### **CAUTION**

Only apply 24V DC to the D77B-DSNAP. Use of any other voltage may result in personal injury, property damage and damage to the D77B-DSNAP.

September 2002

**Installation**

**Mount the D77B-DSNAP to the Starter**

The *IT.* D77B-DSNAP is designed to be installed in the auxiliary contact locations of the *IT.* family of starters. On all starters, one or more auxiliaries can be used along with the D77B-DSNAP. The following table lists starters and indicates the number of available auxiliary locations for each.

**Table 7: Starter Size/Available Auxiliary Locations on Mounted D77B-DSNAP**


Starter Frame Size (mm)	Number of Available Auxiliary Locations with Center Mounted D77B-DSNAP
45	1 single Auxiliary
54	1 single or 1 dual Auxiliary
76	2 single or 2 dual Auxiliary
105	2 single or 2 dual Auxiliary
140	2 single or 2 dual Auxiliary

Use the following steps and illustration in **Figure 4** to mount the D77B-DSNAP:

1. Align and insert both the D77B-DSNAP feet into the auxiliary starter contact mounting slots on the starter, as illustrated in **Figure 4**.

**Recommendation:** Use the middle auxiliary contact mounting slot on the starter contact block when mounting the D77B-DSNAP.


2. Slide the D77B-DSNAP down until a “click” is heard. This ensures that the D77B-DSNAP is mounted securely to the starter.



**Figure 4: D77B-DSNAP Alignment and Mounting**

Use the following steps and illustration in **Figure 5** to remove the D77B-DSNAP:

1. Press the push tab protruding from the D77B-DSNAP front, **Figure 1** on **Page 5**.
2. Slide the D77B-DSNAP up.
3. Pull the D77B-DSNAP away from the starter contact block.




**Figure 5: D77B-DSNAP Removal**

September 2002


### Connect the Starter Terminal Adapter to the Starter

Loosen the screws on the removable terminal block of the starter and insert the Starter Terminal Adapter into the removable terminal block. Tighten the screws on the terminal block (4.5 in-lb or 0.5 Nm) securing the Starter Terminal Adapter into the removable terminal block. Install the removable terminal block into the starter.



**Figure 6: Connecting Starter Terminal Adapter**

Insert one end of the Starter Adapter Jumper (Catalog Number D77B-RJJ1) into J1 on the Starter Terminal Adapter and the other end into or on the D77B-DSNAP.



**Figure 7: Jumper Installation**

## Connect the D77B-DSNAP to DeviceNet

Connect the DeviceNet cable to the 5-position DeviceNet Connector located at the top of the D77B-DSNAP.

- The 5-position DeviceNet Connector has screws for positive retention that need to be loosened to remove the terminal block.
- The D77B-DSNAP will work with thick and thin media.
- The DeviceNet cable is color-coded and matches the colors on the DeviceNet connector.
- Use only one wire per terminal.
- Tighten the screws to 0.5 Nm (4.5 lb-in).

For further information on DeviceNet wiring practices and power considerations, refer to the *DeviceNet Installation Planning Guide*, Publication Number SA-370.

**Table 8: DeviceNet Connection**

Connector Legend	DeviceNet Wire	Signal
V+	Red	+24V DC
CH	White	CAN High
D	Shield	Shield
CL	Blue	CAN Low
V-	Black	Signal Common

September 2002

### Set the DeviceNet MAC ID and Baud Rate

The MAC ID and baud can only be set using the DIP switches on the front of the D77B-DSNAP. A software tool (such as CH Studio) can view the settings for the D77B-DSNAP MAC ID and baud rate, but cannot be used to modify them.


Refer to the following instructions, figure and table when setting the MAC ID and baud rate.

- Moving a DIP switch to the right is ON and moving the switch to the left is OFF. The MAC ID is in binary with the major units numbered to the right of the switch on the side label. Adding up the major units set to ON determines the MAC ID of the D77B-DSNAP.

**Example:** To set the MAC ID to 25, start from the top (or 32) and set the switches to OFF, ON, ON, OFF, OFF, ON (16+8+1=25).

- The baud rate is set using the configuration switches B0 and B1.

Most significant bit to be at top or left end of switch block.



**Figure 8: DIP Switch Setting Example**

**Table 9: Baud Rate Configuration Switches**

B1	B0	Baud
OFF	OFF	125K
OFF	ON	250K
ON	OFF	500K
ON	ON	Not Allowed

## Operation

This section provides details about the following features and functions of D77B-DSNAP operation:

- “Out of box” operation
- Quick Start
- Typical application
- Enhanced features
- DeviceNet input/output assemblies
- DeviceNet Status LED
- Functional Description

### “Out of Box” Operation

**Note:** Before applying power to the D77B-DSNAP for the first time, make sure it is properly mounted on the starter and that all connections are made (DeviceNet, terminal adapter and auxiliary connector).

When the D77B-DSNAP is properly installed, and has a properly set baud and MAC ID, per the “Installation” section on **Page 11**, the following tables in the Quick Start section indicate the information to expect for I/O assemblies on DeviceNet.

### Quick Start

This part of the section provides the information necessary to install and operate the D77B-DSNAP on a Full Voltage Non-reversing (FVNR) *IT*. Starter, Full Voltage Reversing (FVR) *IT*. Starter and an S751 Soft Start motor controller. Detailed information is available in Appendix A for setup of enhanced parameters and extended Input and Output data (assemblies).

#### ***FVNR Motor Controller***

First, follow the instructions on how to mount the D77B-DSNAP as outlined in **Mount the D77B-DSNAP to the Starter** on **Page 7**.

Second, follow the instruction on how to connect the Starter Terminal Adapter to the starter as outlined in **Connect the Starter Terminal Adapter to the Starter** on **Page 9**.

September 2002




Figure 9: D77B-DSNAP-X1 on FVNR IT Starter

Third, follow the instructions on how to set the MAC ID and Baud Rate as outlined in **Set the DeviceNet MAC ID and Baud Rate** on **Page 11**.

Fourth, follow the instructions on how to wire the D77B-DSNAP to DeviceNet as outlined in **Connect the D77B-DSNAP to DeviceNet** on **Page 10**.

The D77B-DSNAP will auto configure to the FVNR IT Starter when the D77B-DSNAP and the IT Starter are first powered (together). After the auto configuration is complete, the D77B-DSNAP is “married” to that specific size, type and overload range of IT Starter. Any attempt to install an already “married” D77B-DSNAP onto another IT Starter without first performing a reset (Appendix A, **Page 30**) will result in the D77B-DSNAP entering a recoverable fault state (flashing red MS/NS LED); the D77B-DSNAP will not operate the IT Starter.

**Default Input Assembly**

The out of box input assembly (data mapped to the input registers within the system controller) is the following:

**Table 10: Input Assembly for Non-reversing Starter (E101, N101)**

Assembly 105 (0x69) – Input (Producing) – D77B-DSNAP Abbreviated Motor Starter 1								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	At Reference	Reserved	CtrlFrom Net	Ready	Reserved	Running1	Warning	Fault
1	% Thermal Capacity							
2	% FLA							
3	Fault Code (Low byte only)							

### Default Output Assembly

The out of box output assembly (data mapped to the output registers within the system controller) is the following:

**Table 11: Output Assembly for Non-reversing Starter (E101, N101) and S751 Soft Start**

Instance 3: Basic Motor Starter								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved	Reserved	Reserved	Reserved	Reserved	FaultReset	Reserved	Run1


### FVR Motor Controller

First, follow the instructions on how to mount the D77B-DSNAP as outlined in **Mount the D77B-DNSAP to the Starter on Page 7**.

**Note:** The 45 mm and 54 mm frame *IT* Starters will require the user to depress the cross over cover locking tab while installing the D77B-DNSAP. Simply depress the tab while inserting the D77B-DSNAP feet into the slot on the *IT* Starter to ease installation.

Second, follow the instruction on how to connect the Starter Terminal Adapter to the starter as outlined in **Connect the Starter Terminal Adapter to the Starter on Page 9**.

Third, the secondary contactor sensor (D77B-A2) needs to be installed. Install the secondary contactor sensor on the second contactor just as you would install an auxiliary (align the feet and slide towards the bottom). Using a screwdriver, pry up the connector access breakout (Figure 1, Page 5) and remove the breakout. Insert the green connector that is connected via a wire to the second contactor sensor into the breakout making sure to take notice of the alignment tabs for proper orientation.



**Figure 10: D77B-DSNAP-X2 on FVR *IT* Starter**

September 2002

Fourth, follow the instructions on how to set the MAC ID and Baud Rate as outlined in **Set the DeviceNet MAC ID and Baud Rate on Page 11.**

Fifth, follow the instructions on how to wire the D77B-DSNAP to DeviceNet as outlined in **Connect the D77B-DSNAP to DeviceNet on Page 10.**

The D77B-DSNAP will auto configure to the FVR *IT.* Starter when the D77B-DSNAP and the *IT.* Starter are first powered (together). It is important that the second contactor sensor is installed on the second contactor and that the green connector is installed into the breakout. If this is not performed, the auto configuration will set the D77B-DSNAP up for an FRNR *IT.* Starter. After the auto configuration is complete, the D77B-DSNAP is “married” to that specific size, type and overload range of *IT.* Starter. Any attempt to install an already “married” D77B-DSNAP onto another *IT.* Starter without first performing a reset (Appendix A, **Page 30**) will result in the D77B-DSNAP entering a recoverable fault state (flashing red MS/NS LED); the D77B-DSNAP will not operate the *IT.* Starter.

**Default Input Assembly**

The out of box input assembly (data mapped to the input registers within the system controller) is the following:

**Table 12: Input Assembly for Reversing Starter (E501, N501)**

Assembly 106 (0x6A) – Input (Producing) – D77B-DSNAP Abbreviated Motor Starter 2								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	At Reference	Reserved	CtrlFrom Net	Ready	Running2	Running1	Warning	Fault
1	% Thermal Capacity							
2	% FLA							
3	Fault Code (Low byte only)							

**Default Output Assembly**

The out of box output assembly (data mapped to the output registers within the system controller) is the following:


**Table 13: Output Assembly for Reversing Starter (E501, N501)**

Instance 5: Extended Motor Starter								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved	Reserved	Reserved	Reserved	Reserved	FaultReset	Run2	Run1

**S751 Motor Controller**

First, follow the instructions on how to mount the D77B-DSNAP as outlined in **Mount the D77B-DNSAP to the Starter on Page 7** (mounts in the same position as an FVNR starter).

Second, follow the instruction on how to connect the Starter Terminal Adapter to the starter as outlined in **Connect the Starter Terminal Adapter to the Starter on Page 9.**



**Figure 11: D77B-DSNAP-X1 on S751 IT. Soft Starter**

Third, follow the instructions on how to set the MAC ID and Baud Rate as outlined in **Set the DeviceNet MAC ID and Baud Rate on Page 11.**

Fourth, follow the instructions on how to wire the D77B-DSNAP to DeviceNet as outlined in **Connect the D77B-DSNAP to DeviceNet on Page 10.**

The D77B-DSNAP will auto configure to the S751 Starter when the D77B-DSNAP and the *IT.* Starter are first powered (together). After the auto configuration is complete, the D77B-DSNAP is “married” to that specific size, and overload range of S751. Any attempt to install an already “married” D77B-DSNAP onto another S751 without first performing a reset (Appendix, **Page 30**) will result in the D77B-DSNAP entering a recoverable fault state (flashing red MS/NS LED); the D77B-DSNAP will not operate the *IT.* Starter.

**Default Input Assembly**

The out of box input assembly (data mapped to the input registers within the system controller) is the following:

**Table 14: Input Assembly for S751 Soft Start**

Assembly 105 (0x69) – Input (Producing) – D77B-DSNAP Abbreviated Motor Starter 1								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	At Reference	Reserved	CtrlFrom Net	Ready	Reserved	Running1	Warning	Fault
1	% Thermal Capacity							
2	% FLA							
3	Fault Code (Low byte only)							

September 2002

### Default Output Assembly

The out of box output assembly (data mapped to the output registers within the system controller) is the following:

**Table 15: Output Assembly for S751 Soft Start**

Instance 5: Extended Motor Starter								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved	Reserved	Reserved	Reserved	Reserved	FaultReset	Run2	Run1

### Safe State Behavior

The safe state behavior of the D77B-DSNAP is factory set to Fault and Stop. Refer to **Page 35, Table 33** Control Supervisor Object (0x29) Instance 0x01 (16 Dec.) for more information. Safe State is defined as the state in which the D77B-DSNAP will place the motor controller when a communication loss is detected. The D77B-DSNAP will be in a safe state when the unit is powered but does not have a valid I/O connection established.

#### **WARNING**

If the Safe State value is set to Run1 or Run2, **any time** the D77B-DSNAP is powered **and does not** have a valid I/O connection, the motor controller will be commanded to the Safe State value. This includes first powering up the DeviceNet system (D77B-DSNAP) and not having the controller on-line.

### Input and Output Assemblies

An I/O assembly is an ordered collection of data that the system controller exchanges with the D77B-DSNAP for monitoring and control. The input assembly is the data that is sent from the D77B-DSNAP to the system controller for monitoring of the D77B-DSNAP. The output assembly is the data that is sent from the system controller to the D77B-DSNAP for control of the D77B-DSNAP.

The D77B-DSNAP offers a variety of input and output assemblies, as indicated in the following table. The tables in this part of the section provide data definitions and details on these assemblies.

**Table 16: Allowable DeviceNet I/O Assemblies**

Motor Controller	Allowable Input Assemblies	Allowable Output Assemblies
Non-reversing (E101, N101)	52, 53, 102, 105*, 108, 114	3*
Reversing (E501, N501)	52, 53, 54, 102, 103, 105, 106*, 108, 109, 114	5*
Soft Start (S751)	52, 53, 60, 102, 105*, 108, 114	3*

\* Indicates the default

Use a DeviceNet configuration tool to select the assemblies of the D77B-DSNAP. The CH Studio configuration tool provides the means to configure the assemblies quickly and easily, as described in the "Configuration" section of this manual. When using a generic DeviceNet tool, use the tables within this section to set up the assemblies. An EDS is available on Eaton's Cutler-Hammer Web site ([www.cutler-hammer.eaton.com/it](http://www.cutler-hammer.eaton.com/it)).

Refer to Appendix A on **Page 39** for all input and output assembly information.

**Input Assembly Data Definition**

Use the following tables when setting up the D77B-DSNAP input assemblies.

**Table 17: Input Assembly Data Definitions**

Data	Description
Fault/Trip	The motor controller is faulted or tripped <b>Note:</b> A "Faulted" M.C. may still respond to a Run1 or Run2 command
Warning	The motor controller has a warning of an impending trip
Running 1	Primary contactor is being commanded to run
Running 2	Secondary contactor is being commanded to run
Ready	The motor controller is configured and communicating with starter
CtrlFrom Net	The motor controller is controlled from DeviceNet
At Reference	This states that the motor controller is in the state that it is commanded to be in, or that the S751 is in bypass. For FVR applications, a D77B-AC2 is required for this bit to be active while in reverse.
% Thermal Capacity	% thermal capacity of the motor from 0 to 100%
Average Current	Average RMS current of the motor
% FLA	The ratio of the running current divided by the FLA setting on the overload
Fault Codes and Warning Codes	Code for the fault of the motor controller. Valid fault and warning codes are:  0 = No Fault 10 = Test 20 = Current Trip 21 = Thermal Overload 22 = Phase Loss 26 = Phase Imbalance 27 = Ground Fault 41 = Control Undervoltage 62 = Memory Fault 63 = Hardware Link Fault (Not Communicating with Starter) 64 = No Device Power 71 = Fail to Close Primary Contactor 72 = Fail to Open Primary Contactor 101 = Invalid Attached Device Version 102 = SCR Over Temperature 103 = Watchdog 104 = SNAP Protocol Failure to Connect 105 = SNAP Protocol Fault 106 = Temperature Sensor Fault 171 = Fail to Close Second Contactor 172 = Fail to Open Second Contactor 173 = Invalid Action Attempted

**Output Assembly Data Definition**

Use the following table when setting up the D77B-DSNAP output assemblies.


**Table 18: Output Assembly Data Definitions**

Data	Description
Run 1	Energize the primary contactor/Soft Starter
Run 2	Energize the secondary contactor
Fault Reset	Reset the fault

September 2002

## Typical Application

The following figure illustrates a typical D77B-DSNAP application, where a single D77B-DSNAP is connected to a single motor controller and where the motor controllers are distributed throughout the DeviceNet subnet. The subnet is then being controlled by a PC or PLC, which scans the D77B-DSNAP for control and monitoring information.



**Figure 12: Typical D77B-DSNAP Application**

**Note:** Such an application typically has more devices on DeviceNet than are shown in this illustration, such as drives, I/O and user interface units.

## Features

**Table 19: Standard Protective Features**

Trip	Definition
Phase Current Unbalance/Phase Loss	A phase current unbalance trip will occur if one or two of the line currents are 40 – 60% or less of the remaining line(s) for longer than 10 seconds. A phase loss trip will occur with a load current of at least 75% of the minimum FLA if one of the two input line voltages is lost, with the line current going to zero for longer than 10 seconds.
Thermal Overload	While the motor is running and depending on the FLA and trip class settings, when the FLA is exceeded for a period of time (depending on the trip class setting), a thermal overload trip will occur. For more information on this feature, see the <i>Contactors and Starter User Manual</i> (Publication No. 49400).

**Note:** The threshold values for Thermal Overload and Phase Current Unbalance can not be modified.

**Table 20: Enhanced Features**

Fault	Definition
Ground Fault	With the addition of a Ground Fault module, the D77B-DSNAP will trip when the module detects a ground fault. The level of the trip is adjusted on the Ground Fault Module. The Ground Fault Module is connected to the D77B-DSNAP through the Auxiliary opening on the front of the D77B-DSNAP.
Underload Warning	While the motor is running, a warning will be activated when the current falls below a user-settable % of overload's FLA pot setting.
Current Threshold - Warning	While the motor is running, a warning will be activated when the current rises above a user-settable % of overload's FLA pot setting.
SCR Over Temperature	To protect the SCRs from premature damage, a temperature sensor monitors the SCR temperature. If the monitored temperature is too high, the S751 will trip on SCR overtemperature.
Contactors Dropout	The contactor dropped out when it was commanded to be energized.

## DeviceNet Status LED

The combined module status/network status (MS/NS) LED is located on the lower right of the D77B-DSNAP as pictured in **Figure 1: D77B-DSNAP Features**.

The following table describes the state of the MS/NS LED.

**Table 21: Combined MS/NS LED**

State	LED
Non-existent	OFF
Standby	Flashing Green
Operational	Not connected: Flashing Green
Operational	Connected: Green
Recoverable Fault	Flashing Red
Unrecoverable Fault	Red
Initializing	Red/Green Flash

September 2002

**Functional Description**

**Table 22: Truth Table**

Old State	Fieldbus Inputs			Event	New State	Action
	Run 1	Run 2	Reset			
FAULTED	–	–	1	RESET	OFF	FAULT = 0
OFF	0	0	–	NONE	OFF	NONE
OFF	1	0	–	RUN 1	RUNNING 1	RUNNING 1 = 1
OFF	0	1	–	RUN 2	RUNNING 2	RUNNING 2 = 1
OFF	1	1	–	RUN 1/RUN 2	OFF	NONE
RUNNING 1	1	1	–	RUN 2	RUNNING 1	NONE
RUNNING 2	1	1	–	RUN 1	RUNNING 2	NONE
RUNNING 1	1	0	–	FAULT	FAULTED	RUNNING 1 = 0 FAULT = 1
RUNNING 2	0	1	–	FAULT	FAULTED	RUNNING 2 = 0 FAULT = 1
RUNNING 1	1	0	–	WARNING	RUNNING 1	WARNING = 1
RUNNING 2	0	1	–	WARNING	RUNNING 2	WARNING = 1

– = state not important

1 = state true (energized)

0 = state false (de-energized)

WARNING = any warning in **Table 17**

RUNNING 1 = Run/FWD/SLOW

RUNNING 2 = REV/FAST

FAULT = any fault in **Table 17**

## Configuration

The only configuration that is necessary for normal operation of the D77B-DSNAP is setting the MAC ID and baud rate, as described in the “Installation” section, **Page 11**. However, the D77B-DSNAP offers a variety of enhanced features. When these features are required, use the CH Studio software suite or a generic DeviceNet tool to perform the configuration.

This section includes the following configuration procedures, and related instructions and information:

- Using CH Studio
  - View D77B-DSNAP General Properties
  - Configure Enhanced Features
  - Monitor the D77B-DSNAP Status
  - Change the I/O Assemblies
- Using a generic DeviceNet tool

### Using CH Studio

The CH Studio software application is designed for programming and configuring industrial automation systems. The application simplifies the monitoring and configuration of entire networks as well as the enhanced features of individual *IT* communicating devices within those networks.

CH Studio takes advantage of the Windows graphical interface to present a suite of tools that is easy to learn and efficient to use, while meeting the requirements for developing complex network configurations.


CH Studio performs the following configuration functions for DeviceNet networks:

- Discover network devices
- Display device properties
- Monitor and configure network devices
- Save existing network configurations
- Configure networks off-line
- Configure devices off-line

September 2002


**General Properties**

The general properties of the D77B-DSNAP are located in the General Tab of the Property Pages for the device. The general properties include the firmware version, serial number, status and much more.



### Configuring Enhanced Features


The enhanced features of the D77B-DSNAP are configured using the Property Window and the Property Pages. A complete list of all the features and settable attributes are available in the Property Window.



September 2002


***Monitor the D77B-DSNAP***

The running values of the D77B-DSNAP (current, thermal capacity and 24V DC control voltage) can be monitored from the Monitor Tab of the Property Pages. Switching to the Status Tab, all operational status can be monitored.



**Change the I/O Assemblies of the D77B-DSNAP**

All of the I/O assemblies are viewable and settable from the I/O Info Tab of the Property Pages. The assembly can be changed by simply selecting on the new assembly and pressing Apply in the lower right of the page. After the new assembly is chosen, a representation of the data format and structure for the new I/O assembly is created.



September 2002

## Using a Generic DeviceNet Tool

When configuring the D77B-DSNAP with a DeviceNet management tool other than CH Studio, refer to the tables in Appendix A: Supported DeviceNet Objects for the definitions of individual attributes. In addition, an Electronic Data Sheet (EDS) file is available at the Web site [www.cutler-hammer.eaton.com/it](http://www.cutler-hammer.eaton.com/it) for use with tools that can use an EDS file.

Follow these steps to configure a D77B-DSNAP through a generic DeviceNet tool:

1. Search for EDS and download the D77B-DSNAP EDS file from the Cutler-Hammer Web site:  
[www.cutler-hammer.eaton.com/it](http://www.cutler-hammer.eaton.com/it)

**Note:** There are multiple EDS files for the D77B-DSNAP, depending on whether it is used with an FVR, FVNR or S751 configuration.

2. Open/start the tool.
3. Load the EDS file into the tool.
4. Go on-line and connect to the D77B-DSNAP you wish to configure.
5. Open the EDS for the D77B-DSNAP and edit the attributes. For a full list of attributes and definitions, see Appendix A: Supported DeviceNet Objects.
6. Send the changed attributes to the D77B-DSNAP.
7. Close the tool.

## Autoconfiguring the D77B-DSNAP for the Starter

1. Verify the D77B-RJJ1 is installed between J1 on the D77B-DSNAP and J1 on the Starter Terminal Adapter.
2. Connect the "out-of-box" D77B-DSNAP to a powered DeviceNet network.
3. Apply power to the starter terminal adapter, the MS/NS LED should change from blinking red to blinking green.
4. If possible verify that the configuration has occurred by reading the device type from the Identity Object (instance 1 attribute 2)  
0x000C — Configuration has not occurred  
0x0016 — Starter  
0x0017 — S751 Soft Start

**Note:** It can take as long as 15 seconds for the autoconfiguration to be performed on an S751 and 7 seconds for an *IT* Starter.

**Note:** The autoconfiguration is a one-time event. To autoconfigure the D77B-DSNAP for another motor controller, an out-of-box reset must be performed. Using a DeviceNet configuration tool, perform a reset to the Identity Object, instance 1 data = 1.

## Troubleshooting and Maintenance

### Renewal Parts

The following table lists the renewal parts for the *IT* D77B-DSNAP.

**Table 23: D77B-DSNAP Renewal Parts**

Description	Catalog Number
SNAP Jumper to terminal adapter	D77B-RJJ1
D77B-DSNAP Assembly of terminal adapter, jumper and D77B-DSNAP	D77B-DSNAP-X1
D77B-DSNAP Assembly of terminal adapter, jumper, D77B-DSNAP and second contactor sensor	D77B-DSNAP-X2
DeviceNet Start Network Adapter Product	D77B-DSNAP
SNAP Terminal Adapter for FVR and FVNR starters and S751 Soft Start	D77B-TC8
Second contactor sensor for FVR starters and contactors	D77B-A2
Ground Fault Detector for 45 mm and 54 mm frame starters	D77B-GF1
Ground Fault Detector for 76 mm and 105 mm starters	D77B-GF2
Ground Fault Detector for 140 mm starters	D77B-GF3

September 2002

**Troubleshooting**

**Table 24: Troubleshooting**

Observation	Possible Cause	Corrective Action
MS/NS LED flashing red after power-up	D77B-DSNAP is not communicating to the <i>IT</i> Starter	Check the D77B-RJJ1 jumper between the D77B-DSNAP and the D77B-TC8 terminal adapter. Also check that the terminal adapter is properly secured and plugged into the <i>IT</i> Starter.
	The D77B-DSNAP was configured or "married" to another <i>IT</i> Starter	Perform a reset (Appendix A <b>Page 30</b> ) to re-marry the D77B-DSNAP to the <i>IT</i> Starter.
	The D77B-DSNAP is powered but the <i>IT</i> Starter is not	Power the <i>IT</i> Starter.
The MS/NS LED starts flashing green and then turns to a flashing red after power-up	D77B-DSNAP is not communicating to the <i>IT</i> Starter	Check the D77B-RJJ1 jumper between the D77B-DSNAP and the D77B-TC8 terminal adapter. Also check that the terminal adapter is properly secured and plugged into the <i>IT</i> Starter.
<i>IT</i> Starter will not energize	<i>IT</i> Starter is not powered	Verify that the <i>IT</i> Starter has 24V DC on the + and - of the terminal block, the Power LED should be green on the D77B-TC8 terminal adapter.
	<i>IT</i> Starter may be tripped	Reset the trip.
	Improper bit set in output assembly	Check the output assembly data position and verify with the control logic.
Second Contactor will not energize	During the "marriage" the wrong configuration was detected	Verify that the product code ( <b>Table 27</b> instance 3) is 0x1102 (4354 dec.). If the product code is not correct, verify that the second contact sensor is installed and wired, that the <i>IT</i> Starter is powered and perform a Reset to Out of Box (Appendix A, <b>Page 30</b> ).
	Improper bit set in output assembly	Check the output assembly data position and verify with the control logic. Verify the correct output assembly is being used.
	Mechanical interlock is jammed	
	The primary contactor is already energized	Only one contactor can be energized at a time.
A "failed to close" fault is generated when the second contactor is energized	The wiring between the D77B-A2 and the D77B-DSNAP is faulty.	Verify all connections on the D77B-A2 and the D77B-DSNAP. Verify that the D77B-A2 is properly connected to the second contactor.

## Appendix A: Supported DeviceNet Objects

### DeviceNet Objects

**Table 25: Supported Objects**

Object	Object ID	Page
Identity	0x01	Page 31
DeviceNet	0x03	Page 31
DeviceNet Connection	0x05	Page 32
Discrete Input Point	0x08	Page 33
Motor Data	0x28	Page 34
Motor Control Supervisor	0x29	Page 35
Overload	0x2C	Page 37
Soft Start	0x2D	Page 38
Supported DeviceNet I/O Assemblies		Page 39

**Table 26: DeviceNet Object Common Services**

Service Code	Service Name
0x0E	Get_Attribute_Single
0x10	Set_Attribute_Single
0x17	Nop
0x18	Get_Member
0x4B	Allocate_Master/Slave_Connection_Set
0x4C	Release_Master/Slave_Connection_Set
0x05	Reset

#### Reset to Out of Box

Service = Reset (0x05)

Class = Identity (0x01)

Instance = 0x01

Data = 01

September 2002

**Table 27: Identity Object 0x01**

Attribute	Access	Data Type	Name	Value
<b>Instance 1</b>				
01	Get	UINT	Vendor Id	68 [0x44] = Cutler-Hammer
02	Get	UINT	Device Type	12 [0x0C] = Communication Adapter 22 [0x16] = Motor Starter 23 [0x17] = Soft Starter
03	Get	UINT	Product Code	4353 [0x1101] DSNAP, FVNR or S751 4354 [0x1102] DSNAP, FVR or two speed
04	Get	ARRAY	Revision	Byte 0 = Major Revision Byte 1 = Minor Revision
06	Get	UDINT	Serial Number	Serial Number of D77B-DSNAP
09	Get	UINT	Configuration Consistency Value	CRC on configuration values
176	Set	SHORT STRING	User Label or Tag Name	A user established ASCII string of 16 characters or less
177	Get	USINT	Fault Value	Same as Attribute 13 of the Control Supervisor (0x29) Object — Instance 1

**Instance 2 (Overload)/Instance 3 (S751)**

03	Get	UINT	Product Code	XY 11
				X (Motor Controller)
				3 = <i>IT.</i> Starter 6 = S751
				1 = 27 mm 2 = 45 mm 3 = 54 mm 4 = 76 mm 5 = 105 mm 6 = 140 mm
04	Get	ARRAY	Revision	Byte 0 = Major Revision Byte 1 = Minor Revision
06	Get	UDINT	Serial Number	Serial Number of connected device

**Table 28: DeviceNet Object 0x03 — Instance 1**

Attribute	Access	Data Type	Name	Value
1	Get	USINT	MAC ID	0 – 63
2	Get	USINT	Baud Rate	0 = 125K 1 = 250K 2 = 500K
3	Get	BOOL	BOI	
4	Get	USINT	Bus Off Counter	0 – 255
8	Get	USINT	MAC ID Switch	
9	Get	USINT	Baud Rate Switch	

**Table 29: Connection Object 0x05 — Instance 1 (Explicit Connection)**

Attribute	Access	Data Type	Name	Value
1	Get	USINT	State	0 = nonexistent 1 = configured 3 = established 4 = timed out
2	Get	USINT	Instance Type	0 = Explicit
3	Get	BYTE	Transport Class Trigger	131 [0x83]
4	Get	UINT	Produced Connection Id	10[MAC ID]011
5	Get	UINT	Consumed Connection Id	10[MAC ID]100
6	Get	BYTE	Initial Comm Characteristics	33 [0x21]
7	Get	UINT	Produced Connection Size	37
8	Get	UINT	Consumed Connection Size	37
9	Get/Set	UINT	Expected Packet Rate	Timer Resolution of 10 mSec.
12	Get	USINT	Watchdog Timeout Action	1 = Auto Delete

**Table 30: Connection Object 0x05 — Instance 2 (I/O Message)**

Attribute	Access	Data Type	Name	Value
1	Get	USINT	State	0 = nonexistent 1 = configured 3 = established 4 = timed out
2	Get	USINT	Instance Type	1 = I/O Message
3	Get	BYTE	Transport Class Trigger	131 [0x83]
4	Get	UINT	Produced Connection Id	01111[MAC ID]
5	Get	UINT	Consumed Connection Id	10[MAC ID]101
6	Get	BYTE	Initial Comm Characteristics	1 [0x01]
7	Get	UINT	Produced Connection Size	1 – 7
8	Get	UINT	Consumed Connection Size	1
9	Get	UINT	Expected Packet Rate	Timer Resolution of 10 mSec.
12	Get	USINT	Watchdog Timeout Action	1 = Auto Delete
14	Get/Set	EPATH	Produced Connection Path	20 04 24 XX 30 03 XX = Instance
16	Get/Set	EPATH	Consumed Connection Path	20 04 24 XX 30 03 XX = Instance
100	Get/Set	USINT	Production ID (Input Assembly)	See DeviceNet I/O Assemblies, <b>Page 39</b>
101	Get/Set	USINT	Consumption ID (Output Assembly)	See DeviceNet I/O Assemblies, <b>Page 39</b>

September 2002

**Table 31: Discrete Input Object 0x08**

Attribute	Access	Data Type	Name	Value
<b>Instance 1 (Primary Contact Block Detect)</b>				
3	Get	BOOL	Data	0 = Off 1 = On
<b>Instance 2 (Secondary Contact Block Detect)</b>				
3	Get	BOOL	Data	0 = Off 1 = On
<b>Instance 3 (Ground Fault Detect)</b>				
3	Get	BOOL	Data	0 = Off 1 = On

**Table 32: Motor Data Object 0x28 — Instance 1**

Attr ID	Access Rule	DeviceNet Data Type	Name	Value
03	Set	USINT	MotorType	0 = Non-standard motor 3 = PM Synchronous Motor 6 = Wound Rotor Induction Motor 7 = Squirrel Cage Induction Motor
04	Set	SHORT STRING	CatNumber	Manufacturer's Motor Catalog Number (Nameplate number) 32 characters max
05	Set	SHORT STRING	Manufacturer	Manufacturer's Name 32 characters max
06	Set	UINT	RatedCurrent	Rated Stator Current Units: [100mA]
07	Set	UINT	RatedVoltage	Rated Base Voltage Units: [V]
08	Set	UDINT	RatedPower	Rated Power at Rated Freq Units: [W]
09	Set	UINT	RatedFreq	Rated Electrical Frequency Units: [Hz]
10	Set	UINT	RatedTemp	Rated Winding Temperature Units: [degrees C]
11	Set	UINT	MaxSpeed	Maximum allowed motor speed Units: [RPM]
12	Set	UINT	PoleCount	Number of poles in the motor
13	Set	UDINT	TorqConstant	Motor torque constant Units: [0.001 x Nm/A]
14	Set	UDINT	Inertia	Rotor Inertia Units: [ $10^{-6}$ x kg.m <sup>2</sup> ]
15	Set	UINT	BaseSpeed	Nominal speed at rated frequency from nameplate Units: [RPM]
19	Set	USINT	ServiceFactor	Units: [%] Range: 0 .. 255

**Note:** Attribute ID's 06 – 19 only available when attribute ID 03 is 3, 6 or 7.

September 2002

**Table 33: Control Supervisor Object 0x29 — Instance 1**

Attribute	Access	Data Type	Name	Value
3	Set	BOOL	Run 1	0 = False
4	Set	BOOL	Run 2	0 = False
5	Set	BOOL	Net Control	0 = Local Control 1 = Network Control
7	Get	BOOL	Running 1	0 = Other State 1 = Enabled and Run 1
8	Get	BOOL	Running 2	0 = Other State 1 = Enabled and Run 2
9	Get	BOOL	Ready	0 = Other State 1 = Ready or Enabled or Stopping
10	Get	BOOL	Faulted	0 = No Faults 1 = Fault Occurred
11	Get	BOOL	Warning	0 = No Warning 1 = Warning
12	Set	BOOL	Fault Reset	0 > 1 = Fault Reset 0 = No Action
13	Get	UINT	Fault Code	0 = No Fault 10 = Test 20 = Current Trip 21 = Thermal Overload 22 = Phase Loss 26 = Phase Imbalance 27 = Ground Fault 41 = Control Undervoltage 62 = Memory Fault 63 = Hardware Link Fault 64 = No Device Power 71 = Fail to Close Primary Contactor 72 = Fail to Open Primary Contactor 101 = Invalid Attached Device Version 102 = SCR Overt Temperature 103 = Watchdog 104 = SNAP Protocol Failure to Connect 105 = SNAP Protocol fault 106 = Temperature Sensor Fault 171 = Fail to Close Second Contactor 172 = Fail to Open Second Contactor 173 = Invalid Action Attempted
14	Get	UINT	Warning Code	0 = No Warning 29 = Underload 41 = Control Undervoltage 71 = Fail to Close Primary Contactor 72 = Fail to Open Primary Contactor 104 = SNAP Protocol Failure to Connect 171 = Fail to Close Second Contactor 172 = Fail to Open Second Contactor

**Table 32: Control Supervisor Object 0x29 — Instance 1 (Continued)**

Attribute	Access	Data Type	Name	Value
16	Set	USINT	DeviceNet Fault Mode (See Warning)	0 = Fault + Stop 1 = Hold Last State 3 = Run 1 4 = Run 2
22	Get/Set	UDINT	Cycle Count	Number of times the motor has been started
101	Get	DWORD	Local Signals	Byte0 (Consuming Assemble Data) Bit 0 = Run1 Bit 1 = Run2 Bit 3 = Fault Reset Bit 5 = Control From Net Byte1 (N/A) Byte2 (Motor Control Status) Bit 0 = Run1 Bit 1 = Run2 Bit 2 = Reset Bit 3 = Permissive Bit 4 = Ready Bit 5 = Net Control Bit 6 = Disconnect Handle Bit 7 = At Reference Byte3 (N/A)
110	Get/Set	USINT	Number of Contactors	1 = 1 Contactor (FVNR) 2 = 2 Contactor (FVR)
111	Get/Set	BOOL	Communication Valid	0 = Starter Communication Fault 1 = Valid Starter Communication
114	Get/Set	BOOL	Net Select	0 = Control is Local 1 = Control is From Network
115	Get/Set	BOOL	CB Sensor	0 = Disable Crossbar Sensor detect 1 = Enable Crossbar Sensor detect

---

 **WARNING**

---

If the DeviceNet Fault Mode value is set to Run1 or Run2, **any time** the D77B-DSNAP is powered **and does not** have a valid I/O connection, the motor controller will be commanded to the DeviceNet Fault Mode value. This includes first powering up the DeviceNet system (D77B-DSNAP) and not having the controller on-line.

September 2002

**Table 34: Overload Object 0x2C — Instance 1**

Attribute	Access	Data Type	Name	Value
3	Get	INT	Trip Class Setting	Setting of the overloads FLA attribute = (INT)*(0.1 Amps)/2^CS
4	Get	USINT	Trip Class	0 – 200
5	Get	INT	Average of 3 Phase Current	Average Current of 3 Phase (RMS) = (INT)*(0.1 Amps)/2^CS
7	Get	USINT	%Thermal Capacity	0 – 100%
12	Get	SINT	Current Scale (CS)	Current Scaling Factor Scaled Current = (INT)*(0.1 Amps)/2^CS
103	Get/Set	BOOL	Ground Fault Enable	0 = Disabled (default) 1 = Enabled
105	Get/Set	USINT	Ground Fault Time	Length of time the ground fault must be true for a trip 0 – 255 seconds default = 1 second
106	Get/Set	USINT	Ground Fault Delay	Length of time to delay tripping on a ground fault from motor controller start 0 – 255 seconds default = seconds
107	Get	BOOL	Ground Fault	0 = No ground fault 1 = Ground fault
108	Get	BOOL	Current Threshold Enable	0 = Disabled (default) 1 = Enabled
109	Get/Set	USINT	Current Threshold Percent	% of FLA setting to set current threshold 0 – 255%
110	Get	BOOL	Current Threshold Warning	0 = No Warning (default) 1 = Warning
111	Get/Set	BOOL	Underload Enable	0 = Disabled (default) 1 = Enabled
112	Get/Set	USINT	Underload Percent	% of FLA setting to set underload 0 – 255%
113	Get	BOOL	Underload Warning	0 = No Warning (default) 1 = Warning
114	Get	UINT	Starter 24V DC Value	Value of 24V DC connected to the starter 235 = 23.5V DC
115	Get	BYTE	Overload Status Bits	0 = Current Trip 1 = Phase Loss 2 = Phase Imbalance 3 = Receiving Run1 4 = Receiving Run2 5 = Ground Fault 6 = Test 7 = Thermal Overload
116	Get	BOOL	Impending Trip Warning	0 = current < 115% FLA 1 = current > 115% FLA
117	Get	USINT	%FLA	% Running Current divided by the FLA setting on the overload (0 – 255%)
121	Get	UDINT	Max FLA	Amps 256

**Table 35: Soft Start Object 0x2D — Instance 1**

Attribute	Access	Data Type	Name	Value
3	Get	BOOL	AtReference	Starting/stopping output voltage reference status 0 = Not At Reference 1 = Output At Voltage Reference
4	Get	USINT	StartMode	1 = Voltage Ramp No Current Limit The DSNAP will always return the value 1 when accessing this attribute.
5	Get	USINT	StopMode	1 = Ramp Down The DSNAP will always return the value 1 when accessing this attribute.
7	Get	UINT	RampTime1	Tenths of Seconds
16	Get	UINT	DecelTime	Tenths of Seconds
100	Get	USINT	Start Torque	Starting Torque Pot reading
101	Get	WORD	Status Bits	Status bits

September 2002

## DeviceNet I/O Assemblies

The changing of the I/O assemblies from the default to other assemblies using CHStudio is performed in a graphical user environment. When using a generic DeviceNet Management tool that accepts EDS files, the EDS file will aid in simply choosing the I/O assemblies that are allowed and available.

**Table 36: Allowable DeviceNet I/O Assemblies**

Motor Controller	Allowable Input Assemblies (Dec.)	Allowable Output Assemblies (Dec.)
Non-reversing (E101, N010)	52, 53, 102, 105*, 108, 114	3*
Reversing (E501, N501)	52, 53, 54, 102, 103, 105, 106*, 108, 109, 114	5*
S751 Soft Start	52, 53, 60, 102, 105*, 108, 114	3*

\*Indicates the default

For users that have a generic DeviceNet Management tool that does not accept EDS files, follow the simple example below to aid in changing I/O assemblies using explicit messaging.

To read what the current Input assembly is, perform an explicit message of the following:

**Table 37: Reading Current Input Assembly**

Service	Class (HEX)	Instance (HEX)	Attribute (HEX)	Data (HEX)
Get Single	0x05 (Connection)	0x02 (Polled I/O)	0x64 (Production ID) (100 Dec.)	<b>0x34</b> (34 = Basic Motor Starter)

To set the Input assembly, perform an explicit message of the following:

**Table 38: Setting Input Assembly**

Service	Class (HEX)	Instance (HEX)	Attribute (HEX)	Data (HEX)
Set Single	0x05 (Connection)	0x02 (Polled I/O)	0x64 (Production ID) (100 Dec.)	<b>0xXX</b> (XX = the input assembly in HEX. Example: 0x69 is D77B-DSNAP Abbreviated Motor Starter 1)

To read what the current Output assembly is, perform an explicit message of the following:

**Table 39: Reading Current Output Assembly**

Service	Class (HEX)	Instance (HEX)	Attribute (HEX)	Data (HEX)
Get Single	0x05 (Connection)	0x02 (Polled I/O)	0x65 (Consumption ID) (101 Dec.)	<b>0x03</b> (3 = Basic Motor Starter)

To set the Output assembly, perform an explicit message of the following:

**Table 40: Setting Output Assembly**

Service	Class (HEX)	Instance (HEX)	Attribute (HEX)	Data (HEX)
Set Single	0x05 (Connection)	0x02 (Polled I/O)	0x65 (Consumption ID) (101 Dec.)	<b>0xXX</b> (XX = the output assembly in HEX. Example: 0x05 (5 Dec.) is Extended Motor Starter )

**DeviceNet Input Assemblies****Table 41: Assembly 52 (0x34) — Basic Motor Starter**

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Reserved	Reserved	Reserved	Reserved	Reserved	Running1	Reserved	Fault

**Table 42: Assembly 53 (0x35) — Extended Motor Starter 1**

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Reserved	Reserved	CtrlFrom Net	Ready	Reserved	Running1	Warning	Fault

**Table 43: Assembly 54 (0x36) — Extended Motor Starter 2**

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Reserved	Reserved	CtrlFrom Net	Ready	Running2	Running1	Warning	Fault

**Table 44: Assembly 60 (0x3C) — Basic Soft Start Input**

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
At Reference	Reserved	Reserved	Reserved	Reserved	Running1	Reserved	Fault

**Table 45: Assembly 102 (0x66) — D77B-DSNAP Motor Starter**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	At Reference	Reserved	CtrlFrom Net	Ready	Running2	Running1	Warn	Fault
1	% Thermal Capacity							
2	Average Current (Low byte)							
3	Average Current (High byte)							
4	% FLA							

**Table 46: Assembly 103 (0x67) — D77B-DSNAP Extended Motor Starter**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	At Reference	Reserved	CtrlFrom Net	Ready	Running2	Running1	Warn	Fault
1	% Thermal Capacity							
2	Average Current (Low byte)							
3	Average Current (High byte)							
4	% FLA							

September 2002

**Table 47: Assembly 105 (0x69) — D77B-DSNAP Abbreviated Motor Starter 1**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	At Reference	Reserved	CtrlFrom Net	Ready	Reserved	Running1	Warn	Fault
1	% Thermal Capacity							
2	% FLA							
3	Fault Code (Low byte only)							

**Table 48: Assembly 106 (0x6A) — D77B-DSNAP Abbreviated Motor Starter 2**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	At Reference	Reserved	CtrlFrom Net	Ready	Running2	Running1	Warn	Fault
1	% Thermal Capacity							
2	% FLA							
3	Last Fault Code (Low byte only)							

**Table 49: Assembly 108 (0x6C) — D77B-DSNAP Motor Starter with Fault Code**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	At Reference	Reserved	CtrlFrom Net	Ready	Reserved	Running1	Warn	Fault
1	% Thermal Capacity							
2	Average Current (Low byte)							
3	Average Current (High byte)							
4	Last Fault Code (Low byte)							
5	Last Fault Code (High byte)							

**Table 50: Assembly 109 (0x6D) — D77B-DSNAP Expanded Motor Starter with Fault Code**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	At Reference	Reserved	CtrlFrom Net	Ready	Running2	Running1	Warn	Fault
1	% Thermal Capacity							
2	Average Current (Low byte)							
3	Average Current (High byte)							
4	Last Fault Code (Low byte)							
5	Last Fault Code (High byte)							

**Table 51: Assembly 114 (0x72) — D77B-DSNAP Complete Status Assembly**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	At Reference	Reserved	Ctrl From Net	Ready	Running2	Running1	Warning	Fault

**Table 52: Input Definitions**

Data	Description																								
Fault/Trip	The motor controller is faulted or tripped <b>Note:</b> A "Faulted" M.C. may still respond to a Run1 or Run2 command																								
Warning	The motor controller has a warning of an impending trip																								
Running 1	Primary contactor is being commanded to run																								
Running 2	Secondary contactor is being commanded to run																								
Ready	The motor controller is configured and communicating with starter																								
CtrlFrom Net	The motor controller is controlled from DeviceNet																								
At Reference	This states that the motor controller is in the state that it is commanded to be in, or that the S751 is in bypass. For FVR applications, a D77B-AC2 is required for this bit to be active while in reverse.																								
% Thermal Capacity	% thermal capacity of the motor from 0 to 100%																								
Average Current	Average RMS current of the motor																								
% FLA	The ratio of the running current divided by the FLA setting on the overload																								
Fault Codes and Warning Codes	Code for the fault of the motor controller. Valid fault and warning codes are: <table style="width: 100%; border: none;"> <tr> <td style="width: 50%;">0 = No Fault</td> <td style="width: 50%;">64 = No Device Power</td> </tr> <tr> <td>10 = Test</td> <td>71 = Fail to Close Primary Contactor</td> </tr> <tr> <td>20 = Current Trip</td> <td>72 = Fail to Open Primary Contactor</td> </tr> <tr> <td>21 = Thermal Overload</td> <td>101 = Invalid Attached Device Version</td> </tr> <tr> <td>22 = Phase Loss</td> <td>102 = SCR Over Temperature</td> </tr> <tr> <td>26 = Phase Imbalance</td> <td>103 = Watchdog</td> </tr> <tr> <td>27 = Ground Fault</td> <td>104 = SNAP Protocol Failure to Connect</td> </tr> <tr> <td>41 = Control Undervoltage</td> <td>105 = SNAP Protocol Fault</td> </tr> <tr> <td>62 = Memory Fault</td> <td>106 = Temperature Sensor Fault</td> </tr> <tr> <td>63 = Hardware Link Fault (Not Communicating with Starter)</td> <td>171 = Fail to Close Second Contactor</td> </tr> <tr> <td></td> <td>172 = Fail to Open Second Contactor</td> </tr> <tr> <td></td> <td>173 = Invalid Action Attempted</td> </tr> </table>	0 = No Fault	64 = No Device Power	10 = Test	71 = Fail to Close Primary Contactor	20 = Current Trip	72 = Fail to Open Primary Contactor	21 = Thermal Overload	101 = Invalid Attached Device Version	22 = Phase Loss	102 = SCR Over Temperature	26 = Phase Imbalance	103 = Watchdog	27 = Ground Fault	104 = SNAP Protocol Failure to Connect	41 = Control Undervoltage	105 = SNAP Protocol Fault	62 = Memory Fault	106 = Temperature Sensor Fault	63 = Hardware Link Fault (Not Communicating with Starter)	171 = Fail to Close Second Contactor		172 = Fail to Open Second Contactor		173 = Invalid Action Attempted
0 = No Fault	64 = No Device Power																								
10 = Test	71 = Fail to Close Primary Contactor																								
20 = Current Trip	72 = Fail to Open Primary Contactor																								
21 = Thermal Overload	101 = Invalid Attached Device Version																								
22 = Phase Loss	102 = SCR Over Temperature																								
26 = Phase Imbalance	103 = Watchdog																								
27 = Ground Fault	104 = SNAP Protocol Failure to Connect																								
41 = Control Undervoltage	105 = SNAP Protocol Fault																								
62 = Memory Fault	106 = Temperature Sensor Fault																								
63 = Hardware Link Fault (Not Communicating with Starter)	171 = Fail to Close Second Contactor																								
	172 = Fail to Open Second Contactor																								
	173 = Invalid Action Attempted																								

**DeviceNet Output Assemblies****Table 53: Assembly 3 (0x03) — Basic Motor Starter**

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Reserved	Reserved	Reserved	Reserved	Reserved	Fault Reset	Reserved	Run1

**Table 54: Assembly 5 (0x05) — Extended Motor Starter**

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Reserved	Reserved	Reserved	Reserved	Reserved	Fault Reset	Run2	Run1

**Table 55: Output Definitions**

Data	Description
Run 1	Energize the primary contactor
Run 2	Energize the secondary contactor
Fault Reset	Reset the fault

September 2002

## IT. Publications and Support

**Table 56: IT. Publications**

Publication	Description
MN05002001E	<i>IT.</i> D77A I/O Module Products Installation and Users Manual
MN05001002E	<i>IT.</i> QCPort System Install and Planning Guide
MN05001001E	<i>IT.</i> QCPort Starter Network Adapter Product (QSNAP) Installation and Users Manual
MN05004001E	<i>IT.</i> DeviceNet Starter Network Adapter Product (D77B-DSNAP) Installation and Users Manual
MN05004002E	<i>IT.</i> DeviceNet Adapter Installation and User Manual
Pub 49907	Intelligent Technologies S751 Soft Starter User Manual
MN03403002E	IEC Contactor and Starter User Manual
MN03305001E	NEMA Contactor and Starter User Manual

For copies of these and other publications contact the Literature Fulfillment Center at 1-800-957-7050.



September 2002

## **Eaton's Cutler-Hammer Aftermarket Services**

- Technical/telephone support
- Resident service engineers in major trading centers
- Factory repair services
- Warranty administration
- Equipment modification and upgrading services
- Training seminars

**For additional information on this product, please call our Customer Support Center at:**

**1-800-356-1243**

**For service or start-up assistance 24 hours/day, 7 days/week, please call:**

**1-800-498-2678**

### **A response network that gives new meaning to customer service**

- Personalized
- Comprehensive
- Professional

Eaton Corporation  
Cutler-Hammer business unit  
1000 Cherrington Parkway  
Moon Township, PA 15108-4312  
USA  
tel: 1-800-525-2000  
[www.cutler-hammer.eaton.com](http://www.cutler-hammer.eaton.com)

**EAT•N** | **Cutler-Hammer**

© 2002 Eaton Corporation  
All Rights Reserved  
Publication No. MN05004001E  
September 2002  
Printed in USA