



# **QLogic 3000 and 3100 Series Intelligent Ethernet Adapters Users Guide**

Information furnished in this manual is believed to be accurate and reliable. However, QLogic Corporation assumes no responsibility for its use, nor for any infringements of patents or other rights of third parties which may result from its use. QLogic Corporation reserves the right to change product specifications at any time without notice. Applications described in this document for any of these products are for illustrative purposes only. QLogic Corporation makes no representation nor warranty that such applications are suitable for the specified use without further testing or modification. QLogic Corporation assumes no responsibility for any errors that may appear in this document.

<b>Document Revision History</b>	
Version 4.0, 1/07/09	
Version 4.1, 1/27/09	
Version 4.2, 3/23/09	
Version 4.3, 4/09/09	
Version 4.4, 4/20/09	
Version 4.5, 4/30/09	
Rev. A, Version 4.6, 6/15/09	
Rev. B, Version 4.7, 2/26/10	
<b>Changes</b>	<b>Sections Affected</b>
Updated with new release information	All

# Table of Contents

## Preface

Intended Audience . . . . .	ix
Related Materials . . . . .	ix
Documentation Conventions . . . . .	ix
Technical Support . . . . .	x
Availability . . . . .	x
Training . . . . .	xi
Contact Information . . . . .	xi
Knowledge Database . . . . .	xi

## 1 Overview

Obtaining the Latest Software Release Information . . . . .	1-1
QLogic 3000 and 3100 Series Intelligent Ethernet Adapters . . . . .	1-1
Application Notes . . . . .	1-2

## 2 System Requirements

Hardware Requirements . . . . .	2-1
Cable Specifications . . . . .	2-1
SFP+ Optical Module Requirements . . . . .	2-2
Supported QLogic Adapters . . . . .	2-2

## 3 Quick Start

QLogic Adapter Installation and Verification . . . . .	3-1
Pre-installation Checklist . . . . .	3-1
QLogic Adapter Installation . . . . .	3-1
Verify the QLogic Adapter Installation . . . . .	3-2
Linux . . . . .	3-2
Windows Server <sup>®</sup> . . . . .	3-2
Windows Server Driver Installation . . . . .	3-2
Pre-installation Checklist . . . . .	3-2
Windows Server 2003 . . . . .	3-3
Windows Server 2008 and 2008 R2 . . . . .	3-3

---

	Linux Driver Installation . . . . .	3-4
	Pre-installation Checklist . . . . .	3-4
	Verify and Remove Existing QLogic Adapter Driver and Tools Package . . . . .	3-4
	Install the Driver (RPM) . . . . .	3-4
	Red Hat® . . . . .	3-4
	SUSE® . . . . .	3-5
	QLogic Adapter Configuration . . . . .	3-6
<b>4</b>	<b>Hardware Installation</b>	
	QLE3044 Installation . . . . .	4-1
	Ethernet Port Mapping . . . . .	4-2
	QLE3044 Status LEDs . . . . .	4-2
	QLE3044 Bracket Removal and Replacement . . . . .	4-3
	QLE3142 Installation . . . . .	4-4
	QLE3142 Status LEDs . . . . .	4-5
	QLE3142 Bracket Removal and Replacement . . . . .	4-5
<b>5</b>	<b>Windows Server 2003 Driver Installation</b>	
	Driver Checklist . . . . .	5-1
	Firmware ROM Image Location . . . . .	5-1
	Windows Server NIC Driver Installation and Verification . . . . .	5-2
	Windows Server 2003 NIC Driver Installation . . . . .	5-2
	Windows Server 2003 NIC Driver Installation Verification . . . . .	5-5
	Uninstall the NIC Driver . . . . .	5-6
<b>6</b>	<b>Windows Server 2008 and 2008 R2 Driver Installation</b>	
	Driver Checklist . . . . .	6-1
	Firmware ROM Image Location . . . . .	6-1
	Windows Server 2008 NIC Driver Installation and Verification . . . . .	6-2
	Windows Server 2008 NIC Driver Installation . . . . .	6-2
	Windows Server 2008 NIC Driver Installation Verification . . . . .	6-5
	Windows Server 2008 and 2008 R2 Teaming Driver Installation and Configuration . . . . .	6-6
	Windows Server 2008 and 2008 R2 Teaming Driver Installation . . . . .	6-6
	Windows Server 2008 and 2008 R2 Teaming Driver Configuration . . . . .	6-8
	Windows Server 2008 NIC Driver Uninstall (Previous Version) . . . . .	6-12
	Windows Server 2008 NIC and Teaming Driver Uninstall . . . . .	6-13
<b>7</b>	<b>Windows Server 2003, 2008, and 2008 R2 Driver Configuration</b>	
	NIC Driver Properties and Configuration . . . . .	7-1
	QLogic Adapter Configuration . . . . .	7-9

QLogic Adapter Diagnostic Tests .....	7-11
Windows Server 2003 Performance .....	7-13
Performance Testing the QLogic Adapter with <code>ntttcp</code> .....	7-13
<code>ntttcp</code> Overview .....	7-14
<code>ntttcps</code> and <code>ntttcpr</code> Command Line Options .....	7-15
<code>Tcp1323Opts</code> Parameter .....	7-16
Modifying the <code>Tcp1323Opts</code> Parameter .....	7-17
Creating the <code>Tcp1323Opts</code> Parameter .....	7-18
Setting the <code>TcpWindowSize</code> Parameter .....	7-20

## 8 Linux Driver Installation and Configuration

Linux Driver Checklist .....	8-1
Locate the Firmware ROM Image .....	8-1
Locate the Driver File .....	8-2
Verify the Firmware Version .....	8-2
Verify the Driver Version and Module Information .....	8-2
Locate the QLogic Tools .....	8-2
Build the Linux Driver Source Code .....	8-2
Enable the Inbox Kernel GPL and Commercial Drivers .....	8-2
Check for MSI-X Support .....	8-3
Inbox Kernel GPL Driver and Blacklisting .....	8-4
Preparing for QLogic Adapter Driver Installation .....	8-5
QLogic Adapter Driver Installation (RPM Format) .....	8-5
Install the Linux Driver Source in RPM Format .....	8-5
Create the Binary .....	8-5
Install the Binary .....	8-5
Install the QLogic Tools .....	8-6
Linux QLogic Adapter Driver Options .....	8-6
<code>Ethtool</code> Utility .....	8-7
Configure the QLogic Adapter on Linux .....	8-8
Uninstall the Commercial GPL Driver and Tools Package .....	8-8
Diagnostic Tests for the QLogic Adapter .....	8-8
Linux Performance Tuning .....	8-9
Performance Tools .....	8-9
Using the <code>iperf</code> Tool .....	8-9
Optimization .....	8-10

---

<b>9</b>	<b>Linux Configuration for Bonding Mode and Virtual LAN (VLAN)</b>	
	Linux Bonding Mode . . . . .	9-1
	Active-Backup or Mode=1 . . . . .	9-2
	Round-Robin or Mode=0 . . . . .	9-3
	Bonding Driver Options . . . . .	9-4
	Bonding Driver Parameters . . . . .	9-4
	arp_interval . . . . .	9-5
	arp_ip_target . . . . .	9-5
	downdelay . . . . .	9-5
	lacp_rate . . . . .	9-5
	QLogic Adapter Bonding Modes Under Linux . . . . .	9-5
	Configuring Virtual LAN (VLAN) Under Linux. . . . .	9-7
<b>10</b>	<b>Firmware Management</b>	
	Windows Server Dynamic Firmware Download . . . . .	10-1
	Linux Dynamic Firmware Download. . . . .	10-1
<b>11</b>	<b>Troubleshooting Guidelines</b>	
	Unable to Boot the Host System with the QLogic Adapter Installed . . . . .	11-1
	Unable to Send/Receive Network Traffic Using the QLogic Adapter . . . . .	11-1
	Additional Configuration for Windows Server 2008 Teaming . . . . .	11-2
	Troubleshooting Tools . . . . .	11-2
	Windows Server Tools . . . . .	11-3
	Linux Tools. . . . .	11-3
	Check for System Errors . . . . .	11-4
	Linux . . . . .	11-4
	Windows Server . . . . .	11-4
	Caveats . . . . .	11-4
	MSI-X Interrupts for Linux . . . . .	11-4
	PCI Express Slot . . . . .	11-5
<b>A</b>	<b>Diagnostic Utility Commands</b>	
<b>B</b>	<b>Flash Update</b>	
	Flash Update and Tool Guidelines . . . . .	B-1
	Flash Update Options. . . . .	B-1
	nxflash Command . . . . .	B-1
	Windows Server . . . . .	B-2
	Linux . . . . .	B-2

NX Live CD . . . . .	B-2
NX Live USB . . . . .	B-2
NX Live Menu Options. . . . .	B-3
QLogic Adapter Flash Update—Windows Server . . . . .	B-3
Using the Flash Utility . . . . .	B-4
Flash Update Procedure . . . . .	B-5
Updating the Flash on Multiple Standalone QLogic Adapters . . . . .	B-7
QLogic Adapter Flash Update—Linux . . . . .	B-8
Using the Flash Utility . . . . .	B-8
Flash Update Procedure . . . . .	B-10

## Glossary

## Index

### List of Figures

Figure		Page
4-1	QLE3044 Port Assignments . . . . .	4-1
4-2	QLE3044 Status LEDs—Front View . . . . .	4-2
4-3	QLE3044 Bracket Removal . . . . .	4-3
4-4	QLE3044 Bracket Replacement. . . . .	4-3
4-5	QLE3142 Installation and Removal . . . . .	4-4
4-6	QLE3142 Status LEDs—Side View . . . . .	4-5
4-7	QLE3142 Bracket Removal . . . . .	4-5
4-8	QLE3142 Bracket Replacement. . . . .	4-6
5-1	Windows Server 2003—Found New Hardware Wizard Dialog Box. . . . .	5-2
5-2	Windows Server 2003—NIC Driver Location Information . . . . .	5-3
5-3	Windows Server 2003—Select NIC Driver Location . . . . .	5-3
5-4	Windows Server 2003—Browse for Folder . . . . .	5-4
5-5	Windows Server 2003—Software Installation Progress. . . . .	5-4
5-6	Windows Server 2003—Software Installation Complete . . . . .	5-5
5-7	NIC Driver Installation Verification . . . . .	5-5
6-1	Windows Server 2008—Setup Wizard. . . . .	6-2
6-2	Windows Server 2008—License Agreement . . . . .	6-3
6-3	Windows Server 2008 — Installation Options . . . . .	6-3
6-4	Windows Server 2008—Select Installation Folder. . . . .	6-4
6-5	Windows Server 2008—Confirm Installation . . . . .	6-4
6-6	Windows Server 2008—Installation Complete. . . . .	6-5
6-7	NIC Driver Installation Verification . . . . .	6-5
6-8	Windows Server 2008—Installation Options . . . . .	6-6
6-9	Windows Server 2008—Advanced Network Config Service Setup Wizard . . . . .	6-7
6-10	Windows Server 2008 Teaming—Select Network Configuration Service . . . . .	6-8
6-11	Windows Server 2008 Teaming—Network Configuration Service Window . . . . .	6-9
6-12	Windows Server 2008 Teaming—Creating a Team . . . . .	6-10

6-13	Windows Server 2008 Teaming—Create Team Window . . . . .	6-11
6-14	Windows Server 2008 Teaming—Create Team Progress Bar . . . . .	6-11
6-15	Windows Server 2008 Teaming—Team Management Window . . . . .	6-12
6-16	Windows Server 2008 Teaming Uninstall Procedure . . . . .	6-13
7-1	Adapter Properties—General Tab . . . . .	7-2
7-2	Network Connections Window . . . . .	7-9
7-3	Local Area Connection Properties Dialog Box . . . . .	7-10
7-4	Internet Protocol (TCP/IP) Properties Dialog Box . . . . .	7-11
7-5	Adapter Properties—Diagnostics Tab . . . . .	7-12
7-6	Run Dialog Box . . . . .	7-14
7-7	Location of <code>ntttcp</code> . . . . .	7-14
7-8	Run Window . . . . .	7-17
7-9	Registry Editor—HKEY_LOCAL_MACHINE Directory . . . . .	7-17
7-10	Registry Editor—Parameter Directory . . . . .	7-19
7-11	New Key—DWORD . . . . .	7-19
7-12	Creating <code>Tcp1323Opts</code> . . . . .	7-19
7-13	Edit DWORD Value Window— <code>Tcp1323Opts</code> Parameter . . . . .	7-20
7-14	Modifying the <code>TcpWindowSize</code> Parameter . . . . .	7-21
7-15	Edit DWORD Value Window — <code>TcpWindowSize</code> Parameter . . . . .	7-21

### List of Tables

Table		Page
1-1	QLogic 3000 and 3100 Series Intelligent Ethernet Adapters . . . . .	1-1
2-1	Cable Specifications—Optical . . . . .	2-1
2-2	Cable Specifications—Copper . . . . .	2-2
4-1	Mapping of Port Number, PCI Function, and Ethernet Interface . . . . .	4-2
4-2	QLE3044 LED Definitions . . . . .	4-2
7-1	Advanced Properties Parameters . . . . .	7-3
7-2	<code>ntttcps</code> and <code>ntttcpr</code> Command Line Options . . . . .	7-15
7-3	<code>Tcp1323Opts</code> . . . . .	7-16
7-4	Range . . . . .	7-17
8-1	<code>modprobe</code> Command Optional Parameters . . . . .	8-7
9-1	Bonding Modes . . . . .	9-6
11-1	Troubleshooting Tools in Windows Server . . . . .	11-3
11-2	Troubleshooting Tools in Linux . . . . .	11-3
11-3	QLogic Adapter Device IDs . . . . .	11-5
A-1	Diagnostic Utility Commands . . . . .	A-1
B-1	Flash Utility Commands—Windows Server . . . . .	B-4
B-2	Flash Utility Commands—Linux . . . . .	B-8



# Preface

## Intended Audience

This guide is for system administrators and end-users of the QLogic 3000 and 3100 Series Intelligent Ethernet adapters.

## Related Materials

- Linux<sup>®</sup> man page `% man nx_nic`
- `nxudiag` utility help (diagnostics)
  - `nxudiag -h` or `nxudiag --help` (Windows<sup>®</sup>)
  - `%. /nxudiag -h` or `nxudiag --help` (Linux<sup>®</sup>)
- Check the QLogic Web site for updates.

## Documentation Conventions

This guide uses the following documentation conventions:

- **NOTE:** provides additional information.
- Text in **blue** font indicates a hyperlink (jump) to a figure, table, or section in this guide, and links to Web sites are shown in underlined blue. For example:
  - [Table 9-2](#) lists problems related to the installation.
  - See “[Installation Checklist](#)” on page 3-6.
  - For more information, visit [www.qlogic.com](http://www.qlogic.com).
- Text in **bold** font indicates user interface elements such as a menu items, buttons, check boxes, or column headings. For example:
  - Click the **Start** button, point to **Programs**, point to **Accessories**, and then click **Command Prompt**.
  - The Adapter Properties window opens with the **General** tab in front.

- Text in `Courier` font indicates a file name, directory path, command, or screen text. For example:
  - `nx3fwct.bin`
  - `C:\WINDOWS\system32\drivers`
- Text in **Courier** font indicates a command to enter that performs a specific task. For example:
  - `rpm -iv nx_nic-[version].src.rpm`The italic text (*version*) indicates a variable.
- A percent sign (%) is the cursor prompt when executing Linux commands.
- The term <current release> refers to the current release of the software, For example, release 4.0.305.
- Key names and key strokes are indicated with UPPERCASE:
  - Press CTRL+P.
  - Press the UP ARROW key.
- Text in *italics* indicates terms, emphasis, variables, or document titles. For example:
  - For a complete listing of license agreements, refer to the *QLogic Software End User License Agreement*.
  - What are *shortcut keys*?
  - `/lib/modules/<kernel-version>/kernel/net/netxen`

## Technical Support

Customers should contact their authorized maintenance provider for technical support of their QLogic products. QLogic-direct customers may contact QLogic Technical Support; others will be redirected to their authorized maintenance provider.

Visit the QLogic support Web site listed in [Contact Information](#) for the latest firmware and software updates.

## Availability

QLogic Technical Support for products under warranty is available during local standard working hours excluding QLogic Observed Holidays.

## Training

QLogic offers training for technical professionals for all iSCSI, InfiniBand, Fibre Channel, and Intelligent Ethernet products. From the main QLogic Web page at [www.qlogic.com](http://www.qlogic.com), click the **Education and Resources** tab at the top, then click the **Education & Training** tab on the left. The QLogic Global Training Portal offers online courses, certification exams, and scheduling of in-person training.

Technical Certification courses include installation, maintenance and troubleshooting QLogic SAN products. Upon demonstrating knowledge using live equipment, QLogic awards a certificate identifying the student as a Certified Professional. The training professionals at QLogic may be reached by e-mail at [training@qlogic.com](mailto:training@qlogic.com).

## Contact Information

Please feel free to contact your QLogic approved reseller or QLogic Technical Support at any phase of integration for assistance. QLogic Technical Support can be reached by the following methods:

**Web** <http://support.qlogic.com>

**Email** [support@qlogic.com](mailto:support@qlogic.com)

The QLogic knowledge database contains troubleshooting information for the QLogic adapters. Access the data base from the QLogic Support Web page, <http://support.qlogic.com>. Use the Support Center search engine to look for specific troubleshooting information.

## Knowledge Database

The QLogic knowledge database is an extensive collection of QLogic product information that you can search for specific solutions. We are constantly adding to the collection of information in our database to provide answers to your most urgent questions. Access the database from the QLogic Support Center: <http://support.qlogic.com>.



# 1 Overview

This guide describes the system requirements, installation, and setup required for the QLogic 3000 and 3100 Series Intelligent Ethernet adapters listed in [Table 1-1](#).

## Obtaining the Latest Software Release Information

To download the latest version of the drivers for this product, see the QLogic Web site Downloads section:

[http://driverdownloads.qlogic.com/QLogicDriverDownloads\\_UI/default.aspx](http://driverdownloads.qlogic.com/QLogicDriverDownloads_UI/default.aspx).

## QLogic 3000 and 3100 Series Intelligent Ethernet Adapters

The products in [Table 1-1](#) are supported in this document.

**Table 1-1. QLogic 3000 and 3100 Series Intelligent Ethernet Adapters**

Product	Product Definition	Transfer Medium
QLE3044-RJ	Quad-port 1GbE Intelligent Ethernet Adapter	Copper
QLE3142-CU	Dual-port 10GbE Intelligent Ethernet Adapter	Twinax
QLE3142-SR	Dual-port 10GbE Intelligent Ethernet Adapter (short range fiber)	Optical
QLE3142-LR	Dual-port 10GbE Intelligent Ethernet Adapter (long range fiber)	Optical

Table Notes

For OEM-branded QLogic 3000 and 3100 Series Intelligent Ethernet adapters, see the QLogic Web site.

These products are collectively referred to as the *QLogic adapter* unless otherwise noted.

The QLogic adapters are compatible with Windows, Linux, and other operating systems (OSs).

---

## Application Notes

For information about Linux PXE and iSCSI boot, see the following applications notes, available upon request from QLogic:

- *Setting up Linux PXE on Server and Client Systems*, part number FE0051401-00
- *iSCSI Boot Setup*, part number IS0051404-00

# 2 System Requirements

Before installing the QLogic adapter, make sure your system meets the requirements listed in this section:

- “Hardware Requirements” on page 2-1
- “Supported QLogic Adapters” on page 2-2

## Hardware Requirements

### Cable Specifications

Make sure the cables you are using meet the specifications listed in [Tables 2-1](#) and [2-2](#).

**Table 2-1. Cable Specifications—Optical**

Product	Core Diameter (μm)	Optical Mode	Wavelength (nm)	Bandwidth (MHz)	Distance (m)
QLE3142-SR	50	OM2	850	400	66
				500	82
	OM3	2,000		300	
	62.5	OM1		160	26
				200	33
QLE3142-LR	9	N/A	1310	N/A	10,000
	10	N/A		N/A	10,000

**Table 2-2. Cable Specifications—Copper**

Product	Cable Type	Network Type	Cable Length (meters)
QLE3044-RJ	Cat5	LAN	100
QLE3142-CU	Copper direct attach twinax	LAN	10

## SFP+ Optical Module Requirements

Use only the optical modules validated and shipped with the QLogic adapter.

## Supported QLogic Adapters

Make sure you have one of the adapters listed in [Table 1-1](#).



# 3 Quick Start

This section provides instructions for advanced users who are already familiar with hardware and software installation procedures. See the appropriate section, as applicable:

- [“QLogic Adapter Installation and Verification” on page 3-1](#)
- [“Windows Server Driver Installation” on page 3-2](#)
- [“Linux Driver Installation” on page 3-4](#)

## QLogic Adapter Installation and Verification

The following sections provide high-level instructions for installing the QLogic adapter. For more detailed instructions, see [“Hardware Installation” on page 4-1](#).

### Pre-installation Checklist

Before installing the QLogic adapter:

1. Verify that the system meets the requirements specified in [“System Requirements” on page 2-1](#).
2. Power down the system.

### QLogic Adapter Installation

To install the QLogic adapter:

1. Insert the QLogic adapter into an available PCI Express<sup>®</sup> slot.
2. Connect the appropriate cables to the QLogic adapter.
3. Power up the system.

For more information on the QLogic adapter installation, refer to [“Hardware Installation” on page 4-1](#).

## Verify the QLogic Adapter Installation

To verify that the QLogic adapter has been installed correctly, perform the steps in the appropriate section.

### Linux

On Linux systems, execute the following command:

```
# lspci -vvv -d 4040:
```

### Windows Server®

On Windows Server systems, perform the following steps:

1. Do one of the following:
  - For Windows 2003, right-click **My Computer**, and then click **Manage**. The Computer Management window opens.
  - For Windows Server 2008, right-click **Computer**, then click **Manage**. The Server Manager window opens.
2. Do one of the following:
  - For Windows Server 2003, select **Computer Management**, select **System Tools**, and then select **Device Manager**.
  - For Windows Server 2008, select **Server Manager**, select **Diagnostics**, then select **Device Manager**.
3. Check under **Other devices** for an Unknown Device. The QLogic adapter will be listed as an Unknown Device. It will have a yellow question mark next to it prior to having the QLogic adapter driver installed.
4. Right-click the device and select **Properties** from the shortcut menu.
5. Click the **Details** tab. Look for `VEN_4040` as part of the string. This text indicates that the QLogic adapter is installed correctly.

## Windows Server Driver Installation

### Pre-installation Checklist

1. Download the driver package from the QLogic Web site, [http://driverdownloads.qlogic.com/QLogicDriverDownloads\\_UI/default.aspx](http://driverdownloads.qlogic.com/QLogicDriverDownloads_UI/default.aspx).
2. Extract the driver package.

For more information, see the Driver Checklist in the section that corresponds to your OS.

## Windows Server 2003

To install the QLogic adapter driver:

1. From the Windows desktop, right-click **My Computer**. On the shortcut menu, select **Manage**. The Computer Management window opens.
2. Select **Computer Management**, select **System Tools**, and then select **Device Manager**.
3. Right-click the server's host name and select **Scan for hardware changes**.
4. When prompted to connect to Windows Update, Click **No, not at this time**, and then click **Next**.
5. Click **Install from a list or specific location**, then click **Next**.
6. Select **Search for the best driver in these locations**. Deselect the **Search removable media** option. Select **Include this location in the search**.
7. Click **Browse**, and then provide the path to the directory where the driver is located.
8. Locate the following files in the driver directory:  

```
nx3fwct.bin  
nx3fwmn.bin  
nxnd5x86.sys (Windows 2003, 32 bit) or  
nxnd5x64.sys (Windows 2003, 64 bit)
```

Click **OK** in the Browse for Folder window.
9. Click the **Next** button in the Hardware Update Wizard window.

For more details on the Windows Server 2003 driver installation, refer to [“Windows Server 2003 NIC Driver Installation” on page 5-2](#).

To configure the QLogic adapter:

1. Click the **Start** button, and then select **Network Connections**.
2. Verify that QLogic adapter icon says **Connected**.
3. Assign an IP address to the network interface.

## Windows Server 2008 and 2008 R2

To install the QLogic adapter driver:

1. Open a Windows Explorer window.
2. Navigate to the `Install_Packages` directory from the release extracted from the QLogic driver package.
3. Double-click the respective MSI package required for Windows Server 2008.

4. Follow the instructions on the screen to complete the installation.

For more details on the Windows Server 2008 driver installation, refer to “[Windows Server 2008 NIC Driver Installation](#)” on page 6-2.

To configure the QLogic adapter:

1. Click the **Start** button, and then select **Network Connections**.
2. Verify that QLogic adapter icon says **Connected**.
3. Assign an IP address to the network interface.

## Linux Driver Installation

### Pre-installation Checklist

Download the driver package from the QLogic Web site, [http://driverdownloads.qlogic.com/QLogicDriverDownloads\\_UI/default.aspx](http://driverdownloads.qlogic.com/QLogicDriverDownloads_UI/default.aspx).

See “[Linux Driver Checklist](#)” on page 8-1 for more information.

### Verify and Remove Existing QLogic Adapter Driver and Tools Package

If you have a previous version of the QLogic adapter driver, perform the following steps to remove the driver and tools package:

1. Type:  

```
rpm -qa | grep nx_
```
2. Type:  

```
ifconfig eth[n] down
```
3. Type:  

```
rmmmod nx_nic.ko
```
4. Type:  

```
rpm -e nx_nic-[version]
```
5. Type:  

```
rpm -e nx_tools-[version]
```

### Install the Driver (RPM)

#### Red Hat®

To install the driver on a Red Hat system:

1. Type the following command to extract the driver:  

```
tar -zxvf qle30xx_qle31xx-src-[version].tar.gz
```

2. Type the following command to install the RPM source:

```
rpm -iv nx_nic-[version].src.rpm
```

3. Type the following command to build the binary RPM:

```
rpmbuild -bb /usr/src/redhat/SPECS/nx_nic-[version].spec
```

4. Type the following command to install the binary RPM:

```
rpm -ivh /usr/src/redhat/RPMS/[arch]/nx_nic-[version].[arch].rpm
```

The `[arch]` variable designates the system architecture. Some `[arch]` variables are `i386`, `i586`, `i686`, `x86_64`, depending on the system.

5. Type the following command to install the tools RPM:

```
rpm -ivh nx_tools-[version].rpm
```

6. Type the following command to load the driver:

```
modprobe -v nx_nic
```

## SUSE®

To install the driver on a SUSE system:

1. Type the following command to extract the driver:

```
tar -zxvf qle30xx_qle31xx-src-[version].tar.gz
```

2. Type the following command to install the RPM source:

```
rpm -iv nx_nic-[version].src.rpm
```

3. Type the following command to build the binary RPM:

```
rpmbuild -bb /usr/src/packages/SPECS/nx_nic-[version].spec
```

4. Type the following command to install the binary RPM:

```
rpm -ivh /usr/src/packages/RPMS/[arch]2/nx_nic-[version].[arch].rpm
```

The `[arch]` variable designates the system architecture. Some `[arch]` variables are `i386`, `i586`, `i686`, `x86_64`, depending on the system.

5. Type the following command to install the tools RPM:

```
rpm -ivh nx_tools-[version].rpm
```

6. Type the following commands to load the driver:

```
modprobe firmware_class  
modprobe -v nx_nic
```

---

## QLogic Adapter Configuration

To configure the QLogic adapter:

1. Type the following command to identify the Ethernet interface:

```
cat /proc/net/nx_nic/dev0/stats
```

2. Type the following command to assign an IP address:

```
ifconfig eth[n] [ip address]
```

# 4 Hardware Installation


This section provides installation instructions for the QLogic adapters. Please follow all applicable ESD precautions when handling the QLogic adapter.

## QLE3044 Installation

To install the QLE3044:

1. Verify that the system is powered off and unplug the power cord.
2. Remove the system cover.
3. Locate an empty x4 or higher PCIe<sup>®</sup> slot.
4. Insert the QLE3044 into the PCIe slot. Apply uniform pressure on top of the QLE3044 until it is firmly seated in the PCIe bus connector.
5. Secure the bracket to the chassis and replace the cover.
6. Connect the appropriate cables to the QLE3044.
7. Plug in the power cord and power up the system.

The QLE3044 contains four ports that are organized as shown in [Figure 4-1](#). Note that the portion of the bracket covering the four RJ45 jacks is not shown.



**Figure 4-1. QLE3044 Port Assignments**

## Ethernet Port Mapping


The mapping of port numbers on the QLE3044 is shown in [Table 4-1](#).

**Table 4-1. Mapping of Port Number, PCI Function, and Ethernet Interface**

Port Number	PCI Function	Ethernet Interface
1	0	Ethernet interface numbers are dynamically allocated by the host. As such, any eth[n] interface can be connected to any port.
2	1	
3	2	
4	3	

## QLE3044 Status LEDs

The QLE3044 has two status LEDs per port. These LEDs are located on the port itself, as shown in [Figure 4-2](#). When viewing the QLE3044 from the front, the bi-color green/orange link LED is on the left, and the green activity LED is on the right.



**Figure 4-2. QLE3044 Status LEDs—Front View**

The bi-color link LED indicates the speed of the connection as shown in [Table 4-2](#).

**Table 4-2. QLE3044 LED Definitions**

Speed	Green/Orange Bi-Color Link LED	Green Activity LED
10Mbps	Off	During power-up, the activity LED is on continuously (solid). The LED blinks during normal operation when there is activity on the port for any of the speed settings.
100Mbps	Green On	
1000Mbps	Orange On	




## QLE3044 Bracket Removal and Replacement

Depending on the type of system, installation of the QLE3044 requires either a long bracket or a short bracket. QLogic provides both of these brackets with the product. The brackets for the QLE3044 are different from previous brackets in that they slide over the top of the four RJ45 Ethernet jacks.


To remove and replace the bracket:

1. Remove the screw at the top of the QLE3044 that holds the bracket in place.
2. Slide the bracket upward towards the top of the QLE3044 until it clears all of the Ethernet jacks. (The bracket covers the top of the RJ45 Ethernet jacks.)
3. To replace with a different bracket, reverse the process, sliding the new bracket over the Ethernet jacks. Then fasten the bracket in place with the screw.

The removal and replacement process is illustrated in [Figure 4-3](#) and [Figure 4-4](#), respectively.



**Figure 4-3. QLE3044 Bracket Removal**




**Figure 4-4. QLE3044 Bracket Replacement**

## QLE3142 Installation

To install the QLE3142:

1. Verify that the system is powered down and unplug the power cord.
2. Remove the system cover.
3. Locate an empty PCIe x8 slot.
4. Remove the SFP+ optical modules from the QLE3142 if they are already inserted (see [Figure 4-5](#)).



**Figure 4-5. QLE3142 Installation and Removal**


5. Insert the QLE3142 into the PCIe x8 slot. Apply uniform pressure on top of the QLE3142 until it is firmly seated in the bus connector.
6. Connect the SFP+ module or copper direct-attach twinax cable. Listen for an audible clicking sound when the optical module is inserted into the housing (see [Figure 4-5](#)).
7. Secure the bracket to the chassis and replace the cover.
8. Connect the appropriate cables to the QLE3142.
9. Plug in the power cord and power up the system.

**NOTE:**

The optical module must be seated correctly in the housing to ensure proper operation.

## QLE3142 Status LEDs

The QLE3142 has two status LEDs per port, one for link status and one for activity. These LEDs are located next to the ports as shown in [Figure 4-6](#). Both SFP+ ports operate at 10Gbps.




**Figure 4-6. QLE3142 Status LEDs—Side View**

## QLE3142 Bracket Removal and Replacement

Depending on the type of system, installation of the QLE3142 requires either a long bracket or a short bracket. QLogic provides both of these brackets with the product.


To remove and replace the bracket:

1. Remove the SFP+ optical modules from their housing (see [Figure 4-7](#)).



**Figure 4-7. QLE3142 Bracket Removal**

2. Remove the two screws at the top and bottom of the QLE3142 that hold the bracket in place.
3. Gently pull the bracket away from the QLE3142 until it disconnects from the optical module housings.
4. To replace with a different bracket, reverse the process, sliding the new bracket over the module housings (see [Figure 4-8](#)). Note that the screw mounting tabs on the bracket go on the solder side of the QLE3142. Fasten the bracket in place with the two screws.



**Figure 4-8. QLE3142 Bracket Replacement**

# 5 Windows Server 2003 Driver Installation

This section describes the installation and configuration procedure for the QLogic adapter NIC driver on a Windows Server 2003 operating system (OS).

For Windows Server 2008 driver installation instructions, see [Section 6](#).

For Linux driver installation instructions, see [Section 8](#).

## Driver Checklist

Before installing the QLogic adapter NIC driver on a Windows Server 2003 OS:

1. Download the driver package from the QLogic Web site, [http://driverdownloads.qlogic.com/QLogicDriverDownloads\\_UI/default.aspx](http://driverdownloads.qlogic.com/QLogicDriverDownloads_UI/default.aspx)
2. Make sure your system complies with the system requirements (see [“System Requirements” on page 2-1](#)).
3. For existing installations:
  - a. Uninstall the old NIC driver and utilities (see [“Uninstall the NIC Driver” on page 5-6](#)).
  - b. Install the new NIC driver (see [“Windows Server NIC Driver Installation and Verification” on page 5-2](#)).
  - c. Update the Flash (contact Technical Support to see if this step is required).

## Firmware ROM Image Location

The firmware ROM image files (`nx3fwct.bin` and `nx3fwmn.bin`) are in the `C:\WINDOWS\system32\drivers` directory.

A user interface and a command line interface (CLI) are provided for communicating with the Flash utility.

## Windows Server NIC Driver Installation and Verification

The following subsections describe the installation and verification procedures for Windows Server 2003.

### Windows Server 2003 NIC Driver Installation

The following procedure is for a new NIC driver installation.


1. Extract the QLogic adapter NIC driver release package to a directory on the host.

After the server system is powered up, Windows detects the QLogic adapter, and the Found New Hardware Wizard dialog box opens (Figure 5-1).



**Figure 5-1. Windows Server 2003—Found New Hardware Wizard Dialog Box**


2. Click **No, not at this time**, and then click **Next**. The wizard opens another dialog box prompting for NIC driver location information (Figure 5-2).



**Figure 5-2. Windows Server 2003—NIC Driver Location Information**

3. Click **Install from a list or specific location (Advanced)**, and then click **Next**.


A dialog box opens, prompting for more information about the NIC driver location (Figure 5-3).



**Figure 5-3. Windows Server 2003—Select NIC Driver Location**

4. Click **Search for the best driver in these locations**, and then select the **Include this location in the search** check box.
5. Do one of the following:
  - Type the appropriate path to the QLogic adapter NIC driver directory in the accompanying field, and then click **Next**.

- If the exact directory path is not known, click **Browse**. The Browse for Folder dialog box opens (Figure 5-4).




**Figure 5-4. Windows Server 2003—Browse for Folder**

- Select the QLogic adapter NIC driver directory.
- Select the appropriate directory (x86 or x64), and then click **OK**.

The QLogic adapter supports both 32-bit and 64-bit OSs. The x86 directory contains the 32-bit NIC driver. The x64 directory contains the 64-bit NIC driver.

6. Click **Next** in the Hardware Update Wizard dialog box to install the NIC driver.


The 'Please wait while the wizard installs the software' dialog box appears while the NIC driver is being installed (Figure 5-5).



**Figure 5-5. Windows Server 2003—Software Installation Progress**



When the installation completes, the Completing the Hardware Update Wizard dialog box opens (Figure 5-6).




**Figure 5-6. Windows Server 2003—Software Installation Complete**

7. Click **Finish**.

## Windows Server 2003 NIC Driver Installation Verification

To verify that the NIC driver was properly installed:

1. Click the **Start** button, right-click **My Computer**, and then select **Device Manager**. A list of devices appears in right side of the window.
2. Verify that the QLogic adapter is listed under Network Adapters, as shown in Figure 5-7.



**Figure 5-7. NIC Driver Installation Verification**

## Uninstall the NIC Driver

To uninstall the QLogic adapter NIC driver in Windows Server 2003:

1. Right-click **My Computer**, and then click **Manage**.
2. Double-click **Device Manager**. The list of devices in the computer is displayed on the right side of the window.
3. Locate and right-click the QLogic adapter.
4. Click **Uninstall**.
5. Delete the following files from the corresponding directory:

File	Directory
nxcoinst.dll	C:\WINDOWS\system32
nx3fwct.bin	C:\WINDOWS\system32\drivers
nx3fwmn.bin	C:\WINDOWS\system32\drivers
nxnd5x64.sys	C:\WINDOWS\system32\drivers

# 6 Windows Server 2008 and 2008 R2 Driver Installation

This section describes the installation and configuration procedure for the QLogic adapter NIC driver and Teaming driver on Windows Server 2008 and 2008 R2 operating systems (OSs).

For Windows Server 2003 NIC driver installation instructions, see [Section 5](#).

For Linux NIC driver installation instructions, see [Section 8](#).

## Driver Checklist

Before installing the QLogic adapter NIC or Teaming driver on a Windows Server 2008 OS:

1. Download the driver package from the QLogic Web site, <http://driverdownloads.qlogic.com/QLogicDriverDownloads/UI/default.aspx>
2. Make sure your system complies with the system requirements (see “System Requirements” on page 2-1).
3. Uninstall any previous version of the driver (see “Windows Server 2008 NIC Driver Uninstall (Previous Version)” on page 6-12 or “Windows Server 2008 NIC and Teaming Driver Uninstall” on page 6-13).

## Firmware ROM Image Location

The firmware ROM image files (`nx3fwct.bin` and `nx3fwmn.bin`) are in the `C:\WINDOWS\system32\drivers` directory.

A user interface and a command line interface (CLI) are provided for communicating with the Flash utility.


# Windows Server 2008 NIC Driver Installation and Verification

## Windows Server 2008 NIC Driver Installation

To install the NIC driver:

1. Navigate to the `Install_Packages` directory in the new NIC driver package.
2. Extract the driver by running the appropriate self-extracting executable:
  - `q3w32n6[version].exe`
  - `q3wx64n6[version].exe`
  - `q3ws8R2x64n6[version].exe`
3. Double-click one of the following MSI packages, as appropriate:
  - `Qancs_win2k8_x64.msi`
  - `Qancs_win2k8_x86.msi`
  - `Qancs_win2k8_R2_x64.msi`

The Setup Wizard dialog box opens (see [Figure 6-1](#)).



**Figure 6-1. Windows Server 2008—Setup Wizard**


4. Click **Next**.

The License Agreement dialog box opens (see [Figure 6-2](#)).



**Figure 6-2. Windows Server 2008—License Agreement**


5. Read the License Agreement. Click **I Agree**, and then click **Next**. The QLogic Advanced Network Config Service dialog box opens (see [Figure 6-3](#)).



**Figure 6-3. Windows Server 2008 — Installation Options**

6. Do one of the following, and then click **Next**:
  - Click **Typical Installation** to install only the base NIC driver. Teaming support will not be enabled.
  - Click **Complete Installation** if Teaming support is required.


The Select Installation Folder dialog box opens (see [Figure 6-4](#)).



**Figure 6-4. Windows Server 2008—Select Installation Folder**

7. Change the installation folder (if required), and then click **Next**.


The Confirm Installation dialog box opens (see [Figure 6-5](#)).



**Figure 6-5. Windows Server 2008—Confirm Installation**

8. Click **Next** to begin the installation.

At the end of the installation process, the Installation Complete dialog box opens (Figure 6-6).




**Figure 6-6. Windows Server 2008—Installation Complete**

9. Click **Close** to complete the installation.

## Windows Server 2008 NIC Driver Installation Verification

To verify that the NIC driver was properly installed:

1. Click the **Start** button, right-click **My Computer**, and then select **Device Manager**. A list of devices appears in right side of the window.
2. Verify that the QLogic adapter is listed under Network Adapters, as shown in Figure 6-7.




**Figure 6-7. NIC Driver Installation Verification**

## Windows Server 2008 and 2008 R2 Teaming Driver Installation and Configuration

The following subsections describe how to install and configure the Windows Server 2008 intermediate (Teaming) driver.

### Windows Server 2008 and 2008 R2 Teaming Driver Installation

During the Windows Server 2008 NIC driver installation process, you can load both the NIC and Teaming drivers, or only the NIC driver, as shown in [Figure 6-8](#).



**Figure 6-8. Windows Server 2008—Installation Options**

If the **Complete Installation** option (default) shown in [Figure 6-8](#) was selected during the Windows Server 2008 NIC driver installation process, then the Teaming driver has already been installed on the system.



If the base NIC driver was installed the first time the driver package was installed (see the **Typical Installation** option in [Figure 6-3](#)), then you need to re-install the driver to include Teaming:

1. Repeat [Steps 1](#) through [5](#) from “[Windows Server 2008 NIC Driver Installation and Verification](#)” on page 6-2.

The QLogic Advanced Network Config Service dialog box displays ([Figure 6-9](#)).




**Figure 6-9. Windows Server 2008—Advanced Network Config Service Setup Wizard**

2. Click **Repair QLogic Advanced Network Config Service**.
3. Click **Finish**.

## Windows Server 2008 and 2008 R2 Teaming Driver Configuration

After the Teaming driver is installed, the Local Area Connection Properties dialog box includes the **QLogic Advanced Network Configuration Service** option, as shown in [Figure 6-10](#).




**Figure 6-10. Windows Server 2008 Teaming—Select Network Configuration Service**

Follow these steps to configure Teaming for the QLogic adapter:


1. Click the **Start** button, point to **Programs**, point to **QLOGIC Corporation**, and then select **NxTeamingUI**.

The QLogic Advanced Networking Config Service Window opens (see [Figure 6-11](#)).



**Figure 6-11. Windows Server 2008 Teaming—Network Configuration Service Window**

2. Right-click **Teams**, and then click **Create Team** (Figure 6-12).




**Figure 6-12. Windows Server 2008 Teaming—Creating a Team**

**NOTE:**

For more help, see the information in the **Status** box.

After selecting Create Team, the Create Team dialog box opens (Figure 6-12).




**Figure 6-13. Windows Server 2008 Teaming—Create Team Window**

**NOTE:**

For more help, see the information in the **Message** box.


3. Select the check boxes for the QLogic adapter ports to be Teamed, and then click **OK** (Figure 6-13).

A progress bar appears as the Team is being created (Figure 6-14).



**Figure 6-14. Windows Server 2008 Teaming—Create Team Progress Bar**

4. Verify the Team creation. When the Team creation is complete, the **Teaming Management** tab in the QLogic Advanced Network Configuration Service dialog box shows the formed Team (Figure 6-15).



**Figure 6-15. Windows Server 2008 Teaming—Team Management Window**

**NOTE:**

For more help, see the information in the **How-to** box.

## Windows Server 2008 NIC Driver Uninstall (Previous Version)

If your system already has a NIC driver installed, and the version number is earlier than 4.0.517, you must remove this driver before installing the latest NIC driver.

To uninstall the old driver:

1. Right-click **Computer**, and then click **Manage**.
2. Select **Server Manager**, select **Diagnostics**, and then select **Device Manager**.

Under Network adapters, locate the QLogic adapters.

3. Right-click the adapters to be uninstalled, and then select the **Uninstall** option for each device to be uninstalled.
4. Delete one of the following file sets from the corresponding directories:


File	Directory
nxcoinst.dll	C:\WINDOWS\system32
nx3fwct.bin	C:\WINDOWS\system32\drivers
nx3fwmn.bin	C:\WINDOWS\system32\drivers
nxnd6x64.sys	C:\WINDOWS\system32\drivers

File	Directory
nxnd6x86.sys	C:\WINDOWS\system32\drivers

## Windows Server 2008 NIC and Teaming Driver Uninstall

To uninstall the Windows Server 2008 Teaming driver:

1. Click the **Start** button, select **Programs**, select **QLogic Corporation**, and then click **Uninstall QANCS** (see [Figure 6-16](#)).



**Figure 6-16. Windows Server 2008 Teaming Uninstall Procedure**





# 7 Windows Server 2003, 2008, and 2008 R2 Driver Configuration

This section describes how to program your QLogic adapter and maximize its performance in the Windows Server 2003, 2008, and 2008 R2 OSs. Topics include:

- [“NIC Driver Properties and Configuration” on page 7-1](#)
- [“QLogic Adapter Configuration” on page 7-9](#)
- [“QLogic Adapter Diagnostic Tests” on page 7-11](#)
- [“Windows Server 2003 Performance” on page 7-13](#)

## NIC Driver Properties and Configuration


The QLogic adapter NIC driver can be configured through the adapter properties in Device Manager.

To access the Device Manager:

1. Click the **Start** button, right-click **My Computer**, and then click **Device Manager**. A list of devices appears in the right side of the window.
2. Under **Network Adapters**, right-click the QLogic adapter, and then select **Properties**.

The advanced properties window opens.

- The advanced properties window has the following tabs:
- The **General** tab is in front (Figure 7-1).



Windows Server 2003

Windows Server 2008

**Figure 7-1. Adapter Properties—General Tab**

- The **Advanced** tab displays the driver properties.  
[Table 7-1](#) describes the **Advanced** tab selections.

**Table 7-1. Advanced Properties Parameters**

Parameter	Description
Completion Queue Size	<p>This parameter indicates the size of the completion queue.</p> <ul style="list-style-type: none"> <li>■ Registry Key: CompletionQueueSize</li> <li>■ Default: 4 (16,384 entries).</li> <li>■ Values (entries): 0 (1024), 1 (2048), 2 (4096), 3 (8192), 4 (16,384), 5 (32,768)</li> </ul>
Flow Control	<p>This parameter sets flow control parameters. There are four flow control options: 0 (off), 1 (transmit), 2 (receive), and 3 (transmit/receive).</p> <ul style="list-style-type: none"> <li>■ Registry Key: FlowControl</li> <li>■ Default: 3 (Transmit and receive flow control enabled.)</li> <li>■ Values: 0, 1, 2, 3</li> </ul>
Health Monitoring	<p>This parameter maintains the health of the device. Disabling this parameter should be performed under advisement from QLogic.</p> <ul style="list-style-type: none"> <li>■ Registry Key: Watchdog</li> <li>■ Default: Health monitoring enabled.</li> <li>■ Values: Enabled/Disabled</li> </ul>
Interrupt Moderation	<p>This parameter provides interrupt moderation. When this parameter is enabled, interrupts are moderated automatically based on traffic patterns.</p> <ul style="list-style-type: none"> <li>■ Registry Key: InterruptModeration</li> <li>■ Default: Disabled</li> <li>■ Values: Enabled/Disabled</li> </ul>
IPv4 Checksum Offload	<p>This parameter enables/disables the IPv4 checksum offload. There are four flow checksum options: 0 (off), 1 (transmit), 2 (receive), and 3 (transmit/receive).</p> <ul style="list-style-type: none"> <li>■ Registry Key: IPChecksumOffloadv4</li> <li>■ Default: 3 (Transmit and receive checksum enabled)</li> <li>■ Values: 0, 1, 2, 3</li> </ul>

**Table 7-1. Advanced Properties Parameters (Continued)**

Parameter	Description
Large Receive Offload (LRO)	<p>This parameter specifies the large receive offload—enable/disable options.</p> <ul style="list-style-type: none"> <li>■ Registry Key: LRO</li> <li>■ Default: Enabled</li> <li>■ Values: Enabled/Disabled</li> </ul>
Large Send Offload V1 IPv4	<p>This parameter specifies the large send offload—enable/disable options.</p> <ul style="list-style-type: none"> <li>■ Registry Key: LsoV1IPv4</li> <li>■ Default: Enabled</li> <li>■ Values: Enabled/Disabled</li> <li>■ Size of LSO: 64K maximum</li> </ul>
Large Send Offload V2 IPv4 <sup>a</sup>	<p>This parameter specifies the large send offload—enable/disable options.</p> <ul style="list-style-type: none"> <li>■ Registry Key: LsoV2IPv4</li> <li>■ Default: Enabled</li> <li>■ Values: Enabled/Disabled</li> <li>■ Size of LSO: 64K maximum</li> </ul>
Large Send Offload V2 IPv6 <sup>a</sup>	<p>This parameter specifies the large send offload—enable/disable options.</p> <ul style="list-style-type: none"> <li>■ Registry Key: LsoV2IPv6</li> <li>■ Default: Enabled</li> <li>■ Values: Enabled/Disabled</li> <li>■ Size of LSO: 64K maximum</li> </ul>
Locally Administered Address	<p>This is the locally administered address (LAA) that users/administrators can set on this interface to override the permanent address of the QLogic adapter (that may have been Flashed into the hardware).</p> <ul style="list-style-type: none"> <li>■ Registry Key: NetworkAddress</li> <li>■ Format: Hex</li> <li>■ Options: Value. (A value is required—enter the 12 hex bytes of the MAC address to be used, or not present.)</li> </ul>

**Table 7-1. Advanced Properties Parameters (Continued)**

Parameter	Description
Max Ethernet Frame Size	<p>This parameter specifies the Ethernet frame size for packet transmission and receive (it does not include the MAC header).</p> <ul style="list-style-type: none"> <li>■ Reg Key: MaxFrameSize</li> <li>■ Default: 1500 (corresponds to 1514 bytes on the wire plus 4 bytes of CRC)</li> <li>■ Max: 9600</li> <li>■ Min: 64</li> <li>■ Step: 1</li> </ul>
Max Jumbo Buffers	<p>This parameter specifies the maximum number of receive buffers per Jumbo frame.</p> <ul style="list-style-type: none"> <li>■ Reg Key: RxJumboRingSize</li> <li>■ Default: 2 (4096 buffers)</li> <li>■ Values: 0 (1024), 1 (2048), 2 (4096), 3 (8192)</li> </ul>
Max Offload Connections	<p>This parameter specifies the maximum number of offload connections.</p> <ul style="list-style-type: none"> <li>■ Reg Key: MaxOffloadConnections</li> <li>■ Default: 512</li> <li>■ Max: 512</li> <li>■ Min: 0</li> <li>■ Step: 1</li> </ul> <p><b>NOTE:</b> This feature is not supported at the time of publication.</p>
Number of Receive Buffers	<p>This parameter specifies the packet buffers used by the driver for receive operations (DMA memory and indicated to stack). Each buffer is 1536 bytes.</p> <ul style="list-style-type: none"> <li>■ Registry Key: ReceiveBuffers</li> <li>■ Default: 4 (16,384 entries)</li> <li>■ Values (entries): 0 (1024), 1 (2048), 2 (4096), 3 (8192), 4 (16,384), 5 (32,768)</li> </ul>

**Table 7-1. Advanced Properties Parameters (Continued)**

Parameter	Description
Number of Transmit Buffers	<p>This parameter specifies the packet buffers used by the driver for transmit operations (DMA memory and indicated to stack). Each buffer is 1536 bytes.</p> <ul style="list-style-type: none"> <li>■ Registry Key: TransmitBuffers</li> <li>■ Min: 1K</li> <li>■ Max: 2K</li> <li>■ Default: 1024</li> <li>■ Values: 0 (1024), 1 (2048)</li> </ul>
Optimization	<p>This parameter controls optimization and IP forwarding. Enable this function when the QLogic adapter is used for IP forwarding.</p> <ul style="list-style-type: none"> <li>■ Registry Key: Optimization</li> <li>■ Default: Disabled</li> <li>■ Values: Disabled/Enabled</li> </ul>
Priority and VLAN Tag	<p>This parameter controls support for 802.1p/q priority tagging. Enable this parameter to set the virtual LAN (VLAN) ID. There are four options (values).</p> <p>0: Both 802.1p/q priority tagging and VLAN tagging disabled.</p> <p>1: Priority tagging enabled, VLAN tagging disabled.</p> <p>2: VLAN tagging enabled, priority tagging disabled.</p> <p>3: Both 802.1p/q priority tagging and VLAN tagging enabled.</p> <ul style="list-style-type: none"> <li>■ Registry Key: PriorityVLANTag</li> <li>■ Default: 3</li> <li>■ Values: 0, 1, 2, 3</li> </ul>
Receive Side Scaling	<p>This parameter enables/disables the receive side scaling (RSS) feature.</p> <ul style="list-style-type: none"> <li>■ Registry Key: RSS</li> <li>■ Default: Enabled</li> <li>■ Values: Enabled/Disabled</li> </ul>

**Table 7-1. Advanced Properties Parameters (Continued)**

Parameter	Description
Receive Side Scaling Rings	<p>This parameter controls the number of rings used. The total is calculated by <math>1KB \times 2^n</math> with a value of 5 for a maximum of 32KB.</p> <ul style="list-style-type: none"> <li>■ Registry Key: MaxStatusRings</li> <li>■ Default: 2</li> <li>■ Max: 4</li> <li>■ Min: 1</li> <li>■ Step: 1</li> </ul>
TCP Checksum Offload IPv4	<p>This parameter enables/disables the TCP checksum offload for IPv4. There are four TCP checksum options (values):</p> <p>0: Off 1: Transmit 2: Receive 3: Transmit/receive</p> <ul style="list-style-type: none"> <li>■ Registry Key: TCPChecksumOffloadv4</li> <li>■ Default: 3 (Transmit and receive checksum enabled)</li> <li>■ Values: 0, 1, 2, 3</li> </ul>
TCP Checksum Offload IPv6 <sup>a</sup>	<p>This parameter enables/disables the TCP checksum offload for IPv6. There are four TCP checksum options (values):</p> <p>0: Off 1: Transmit 2: Receive 3: Transmit/receive</p> <ul style="list-style-type: none"> <li>■ Registry Key: TCPChecksumOffloadv6</li> <li>■ Default: 3 (Transmit and receive checksum enabled)</li> <li>■ Values: 0, 1, 2, 3</li> </ul>

**Table 7-1. Advanced Properties Parameters (Continued)**

Parameter	Description
UDP Checksum Offload IPv4	<p>This parameter enables/disables the UDP checksum offload. There are four UDP checksum options (values):</p> <ul style="list-style-type: none"> <li>0: Off</li> <li>1: Transmit</li> <li>2: Receive</li> <li>3: Transmit/receive</li> </ul> <ul style="list-style-type: none"> <li>■ Registry Key: UDPChecksumOffloadv4</li> <li>■ Default: 3 (Transmit and receive checksum enabled)</li> <li>■ Values: 0, 1, 2, 3</li> </ul>
UDP Checksum Offload IPv6 <sup>a</sup>	<p>This parameter enables/disables the UDP checksum offload. There are four UDP checksum options (values):</p> <ul style="list-style-type: none"> <li>0: Off</li> <li>1: Transmit</li> <li>2: Receive</li> <li>3: Transmit/receive</li> </ul> <ul style="list-style-type: none"> <li>■ Registry Key: UDPChecksumOffloadv6</li> <li>■ Default: 3 (Transmit and receive checksum enabled)</li> <li>■ Values: 0, 1, 2, 3</li> </ul>
VLAN ID	<p>This parameter sets the VLAN ID for this interface (also exposed through the standard OID).</p> <ul style="list-style-type: none"> <li>■ Registry Key: VlanId</li> <li>■ Default: 0 (no VLAN)</li> <li>■ Max: 4094</li> <li>■ Min: 0</li> <li>■ Step: 1</li> <li>■ Range: 0–4094</li> </ul>

Table Notes

<sup>a</sup> Windows Server 2008 only




- The Information tab contains information about the firmware version, BIOS version, driver version, and other QLogic adapter properties.
- The Diagnostics tab tests the QLogic adapter’s Flash, LED, and other functions.
- The Statistics tab displays information about the QLogic adapter.
- The Flash update tab displays the current firmware version on the QLogic adapter. You can update the firmware (if required).
- The Driver tab displays driver information. From this tab, you can update, uninstall, or restore a previous version of the QLogic adapter driver.
- The Details tab displays detailed information about the QLogic adapter.
- The Resources tab displays the resource settings for the QLogic adapter.

## QLogic Adapter Configuration

To enable the connections to the QLogic adapter:

1. Open the Network Connections window in the Control Panel, or directly from the desktop if the icon exists (Figure 7-2).



**Figure 7-2. Network Connections Window**

If an IP address has not been assigned, the QLogic adapter entry says **Limited or no connectivity**.


If there is a red **X** next to QLogic adapter icon, the link is down. In this case, do the following:

- a. Verify that the card is seated properly in the PCI slot.
- b. Make sure that the network cable is connected properly at both ends.
- c. Make sure that the cable is good.
- d. Assign an IP address to the interface if you have not already.
- e. Verify that the SFP+ module is installed correctly (QLE3142).

See [Section 11](#) for more information.

2. To check the status of the connection, right-click the adapter icon in the Network Connections window, and then select **Properties**.


The Local Area Connection Properties dialog box opens ([Figure 7-3](#)).



**Figure 7-3. Local Area Connection Properties Dialog Box**

3. Assign an IP address manually by selecting the **Internet Protocol (TCP/IP)** entry, and then clicking the **Properties** button.

The Internet Protocol (TCP/IP) Properties dialog box opens (Figure 7-4).



**Figure 7-4. Internet Protocol (TCP/IP) Properties Dialog Box**

4. Assign the appropriate IP, subnet mask, and default gateway values in the Internet Protocol (TCP/IP) Properties dialog box, and then click **OK**.
5. Verify connectivity with another card or switch using the `ping` utility.


## QLogic Adapter Diagnostic Tests

The Windows user diagnostics utility performs different tests using the `nxudiag.exe` command. The syntax for these tests is:

```
nxudiag.exe [command-options-and-arguments]
```

See [Table A-1](#) for a list of Windows diagnostic command options and arguments. The QLogic adapter will be offline at this time.

Alternately, there is a **Diagnostics** tab in the QLogic adapter property sheet that can perform the same tests (Figure 7-5).



Windows Server 2003

Windows Server 2008

**Figure 7-5. Adapter Properties—Diagnostics Tab**

## Windows Server 2003 Performance

This section describes Windows performance tuning.

### **NOTE:**

The tunable performance parameters are system and application specific. Understanding the relationship between the parameter values, target workload, performance applications, operating system, and system configuration provides a better understanding of performance optimization and bottlenecks.

## Performance Testing the QLogic Adapter with `ntttcp`

To enhance Windows Server performance, change these parameters in the order listed.

1. Enable Windows Server scaling (for Windows Server 2003).


Set the `Tcp1323Opts` parameter value to 1. Note that this parameter is not created by default. For more information about modifying a previously created parameter, or creating a new parameter, see [“Tcp1323Opts Parameter” on page 7-16](#).

2. Set the `TcpWindowSize` parameter (for Windows Server 2003).

In the `TcpWindowSize` parameter window, set the value in the **Value Data** box to either **200000** hexadecimal, or **2,097,152** decimal. Be sure to click either **hexadecimal** or **decimal** in the **Base** box depending on the value entered.


If the `TcpWindowSize` parameter does not exist, it can be created using `regedit`. See [“Setting the TcpWindowSize Parameter” on page 7-20](#) for more information.

3. Run `ntttcp`.
  - a. Click the **Start** button, and then click **Run**. The Run dialog box opens.
  - b. Type `cmd` in the **Open:** box, and then click **OK** (Figure 7-6).



**Figure 7-6. Run Dialog Box**

- c. Change the directory path to the location where `ntttcp` was downloaded or copied. An example directory tree is shown in Figure 7-7.



**Figure 7-7. Location of `ntttcp`**

For scripts, see the tools package included with the release.

## **ntttcp Overview**

There are two switches on `ntttcp` that boost performance: `-a` and `-rb`.

`ntttcp` can be run without an optimal value for the `-a` switch and without the `-rb` switch for the QLE3044.

When running `ntttcp` with the QLE3142, and in particular with fewer threads on Windows Server, performance is limited by the receive window and by the outstanding I/O (`-a`) value, regardless of hardware limitations.

For the receive side, the optimal value is 16 for `-a` and 512,000 for `-rb` (or something similar). With these values, a single thread should perform closer to a multi-thread configuration. From a DOS command prompt, type the following command. Note that the command must be executed from the same directory in which the executable files are located.

```
ntttcpr -m 16,0,<rcv ipaddr> -n <# of tcp segs for snd/rcv> -a 16
```

For the transmit side, `-a` should be a value less than eight. The more threads, the lower the value.

**NOTE:**

The send (transmit) and receive side `ntttcp` commands must use the receive side's IP address.

## ntttcps and ntttcpr Command Line Options

The `ntttcps` and `ntttcpr` command line options are listed in [Table 7-2](#).

**Table 7-2. ntttcps and ntttcpr Command Line Options**

Command	Default	Notes
<code>-l &lt;length of buffer&gt;</code>	64K	—
<code>-n &lt;number of buffers&gt;</code>	20K	—
<code>-p &lt;port base&gt;</code>	5001	—
<code>-a &lt;outstanding I/O&gt;</code>	2	—
<code>-x &lt;packet array size&gt;</code>	1	—
<code>-rb &lt;receive buffer size&gt;</code>	64K	—
<code>-sb &lt;send buffer size&gt;</code>	0	—
<code>-i</code>	—	Infinite loop
<code>-f &lt;file name&gt;</code>	output.txt	—
<code>-u</code>	—	UDP send/receive
<code>-w</code>	—	—
<code>-d</code>	—	Verify flag
<code>-t &lt;runtime&gt;</code>	—	Runtime is in seconds.
<code>-v</code>	—	Enable verbose mode.
<code>-6</code>	—	Enable IPv6 mode.

**Table 7-2. *ntttcps* and *ntttcpr* Command Line Options (Continued)**

Command	Default	Notes
-fr	—	Full buffers posted on read operations.
-mb	—	Multiple buffer post mode
-m <mapping>	—	<i>mapping</i> is a session or sessions, processor, receiver, and IP set. The following example sets up four sessions on processor 0 to test a network on 1.2.3.4:  -m 4,0,1.2.3.4

## Tcp1323Opts Parameter

**NOTE:**

This parameter is only for Windows Server 2003.

This parameter determines whether TCP uses the time-stamping and window scaling features described in *RFC 1323, TCP Extensions for High Performance*.

For more efficient use of high bandwidth networks, use a larger TCP window size. The TCP window size field controls the flow of data and is limited to 2 bytes, or a window size of 65,535 bytes.

Since the size field cannot be expanded, a scaling factor is used. The TCP window option increases the maximum window size from 65,535 bytes to 1 gigabyte. The TCP receive window is the amount of data the sending host can send on a connection at one time.

When the value for window size is added to the registry and its size is larger than the default value, Windows attempts to use a scale value that accommodates the new window size.

Tables 7-3 and 7-4 show the four `Tcp1323Opts` settings.

**Table 7-3. *Tcp1323Opts***

Data Type	Range <sup>a</sup>	Value
REG_DWORD	0   1   2   3	1

Table Notes

<sup>a</sup> See Table 7-4



**Table 7-4. Range**


Hex Value	Meaning
0	Timestamps and window scaling are disabled.
1	Window scaling is enabled.
2	Timestamps are enabled.
3	Timestamps and window scaling are enabled.

To modify the scale factor, set `Tcp1323Opts` to 1. Note that this parameter is not created by default. To modify a previously created parameter, see [“Modifying the Tcp1323Opts Parameter” on page 7-17](#). To create a new parameter, see [“Creating the Tcp1323Opts Parameter” on page 7-18](#).

### Modifying the `Tcp1323Opts` Parameter

If the parameter was created previously, it can be modified as follows:


1. Click the **Start** button, and then click **Run**. The Run dialog box opens.
2. Type **regedit** in **Open:** box (Figure 7-8), and then click **OK**.



**Figure 7-8. Run Window**

The Registry Editor window opens.

3. Click the **HKEY\_LOCAL\_MACHINE** directory (Figure 7-9).



**Figure 7-9. Registry Editor—HKEY\_LOCAL\_MACHINE Directory**

4. Navigate to the following directory path from the HKEY\_LOCAL\_MACHINE directory:

```
HKEY_LOCAL_MACHINE
  SYSTEM
    CurrentControlSet
      Services
        Tcpip
          Parameters
```

5. Locate the `Tcp1323Opts` entry and change the value to 1.


### Creating the `Tcp1323Opts` Parameter

If the `Tcp1323Opts` parameter does not exist, it can be created as follows:

1. Click the **Start** button, and then click **Run**. The Run dialog box opens.
2. Type **regedit** in the **Open:** box, and then click **OK** (Figure 7-8).  
The Registry Editor window opens.
3. Click the **HKEY\_LOCAL\_MACHINE** directory (Figure 7-9).
4. Navigate to the following directory path from the HKEY\_LOCAL\_MACHINE directory:


```
HKEY_LOCAL_MACHINE
  SYSTEM
    CurrentControlSet
      Services
        Tcpip
          Parameters
```

The Registry Editor window displays the parameters on the right side (Figure 7-10).




**Figure 7-10. Registry Editor—Parameter Directory**

- Right-click anywhere in the right side of the window and create a new key with a **DWORD** value (Figure 7-11).




**Figure 7-11. New Key—DWORD**

- Rename **New Value #1** to **Tcp1323Opts** (Figure 7-12).



**Figure 7-12. Creating Tcp1323Opts**

7. Right-click **Tcp1323Opts**, and then click **Modify**. In the **Value data** box, type **1** (the default value is 0), and then click **OK**. (Figure 7-13).



**Figure 7-13. Edit DWORD Value Window—*Tcp1323Opts* Parameter**

## Setting the `TcpWindowSize` Parameter

**NOTE:**

This parameter is only for Windows Server 2003.

To set the `TcpWindowSize` parameter:


1. Click the **Start** button, and then click **Run**. The Run dialog box opens.
2. Type **regedit** in the **Open:** box, and then click **OK** (Figure 7-8).
3. Click the **HKEY\_LOCAL\_MACHINE** directory (Figure 7-9).
4. Navigate to the following directory path from the HKEY\_LOCAL\_MACHINE directory:

```
HKEY_LOCAL_MACHINE
  SYSTEM
    CurrentControlSet
      Services
        Tcpip
          Parameters
```

The Registry Editor window displays the parameters on the right side (Figure 7-10).

5. Right-click anywhere in the right side of the window and create a new key with a **DWORD** value (Figure 7-11).
6. Rename **New Value #1** to **TcpWindowSize**.


7. Right-click **TcpWindowSize**, and then click **Modify** (Figure 7-14).



**Figure 7-14. Modifying the *TcpWindowSize* Parameter**

The Edit DWORD Value dialog box opens.

8. Type a the value in the **Value data:** box: either **200000** hexadecimal or **2,097,152** decimal. Be sure to select either the **Hexadecimal** or **Decimal** button in the **Base** section depending on the value entered (Figure 7-15).



**Figure 7-15. Edit DWORD Value Window — *TcpWindowSize* Parameter**

For more information on setting the TCP window size, see “[Tcp1323Opts Parameter](#)” on page 7-16.



# 8 Linux Driver Installation and Configuration

This section describes the Linux driver installation and configuration procedure.

For the Windows Server 2003 driver installation procedure, see [Section 5](#).

For the Windows Server 2008 driver installation procedure, see [Section 6](#).

## Linux Driver Checklist

Before installing and configuring the Linux driver, follow the instructions in these sections:

- [“Locate the Firmware ROM Image” on page 8-1](#)
- [“Locate the Driver File” on page 8-2](#)
- [“Verify the Firmware Version” on page 8-2](#)
- [“Verify the Driver Version and Module Information” on page 8-2](#)
- [“Locate the QLogic Tools” on page 8-2](#)
- [“Build the Linux Driver Source Code” on page 8-2](#)
- [“Enable the Inbox Kernel GPL and Commercial Drivers” on page 8-2](#)
- [“Check for MSI-X Support” on page 8-3](#)

## Locate the Firmware ROM Image

After installing the binary RPM, the firmware ROM image files (`nx3fwct.bin` and `nx3fwmn.bin`) are placed in the `/lib/firmware` directory.

When the driver module is loaded, the firmware files located in the `/lib/firmware` directory are dynamically loaded onto the QLogic adapter.

The dynamically downloaded firmware becomes the active firmware and supersedes the default firmware Flashed on the QLogic adapter.

## Locate the Driver File

The QLogic adapter driver is located at:

- SUSE: `/lib/modules/[kernel version]/update/drivers/net`
- Red Hat 5: `/lib/modules/[kernel version]/update`
- Red Hat 4: `/lib/modules/[kernel version]/kernel/drivers/net`

## Verify the Firmware Version

Type the following commands to view the firmware version, where *n* is the port number:

```
% ethtool -i eth[n]  
% dmesg | grep nx
```

## Verify the Driver Version and Module Information

Type the following commands to view the driver version and module information, where *n* is the port number:

```
% modinfo nx_nic  
% ethtool -i eth[n]
```

## Locate the QLogic Tools

Type the following command to go to the directory where the tools are located:

```
% cd /opt/netxen
```

These tools include:

- `nxflash`
- `nxudiag`
- `phantomcore_P3`
- `[card type]-romimage`

## Build the Linux Driver Source Code

Linux kernel source/headers are required to compile the drivers provided in source code format. Some Linux operating system (OS) distributions may not install the kernel source/headers by default. The headers can be added from the Linux OS Distribution disk using the RPM package manager.

## Enable the Inbox Kernel GPL and Commercial Drivers

The inbox kernel GPL and commercial drivers are included in the Linux kernels available from `kernel.org`.



**NOTE:**

The commercial GPL version of the driver (`nx_nic.ko`) contains the most recent updates.

To determine which driver to use:

1. The driver name is:  
`netxen_nic.ko`
2. Type the following command to identify the `netxen_nic.ko` driver:  
`% lsmod | grep netxen_nic`

**NOTE:**

The `netxen_nic.ko` file is automatically *blacklisted* when the Linux commercial GPL driver RPM is installed.

3. To disable the inbox kernel GPL driver (`netxen_nic.ko`):
  - a. Type the following command to remove the driver from the OS memory:  
`% rmmmod netxen_nic`
  - b. Remove or rename the `netxen_nic.ko` file from the `/lib/modules/<uname -r>/kernel/drivers/net/netxen` directory.

The commercial GPL driver (`nx_nic.ko`) can be enabled after the inbox kernel GPL driver module is disabled.

## Check for MSI-X Support

MSI and MSI-X are supported by the QLogic adapter driver and firmware. Ensure that the OS, kernel, and hardware support MSI-X.

Type the following command to see if MSI-X is supported:

```
% cat /proc/interrupts
```

The output of this command is similar to the following:

```
[root@apps4242 ~]# cat /proc/interrupts
CPU0 CPU1
58: 164 7 PCI-MSI-X eth2
66: 0 0 PCI-MSI-X eth2:1
74: 6 0 PCI-MSI-X eth2:2
82: 0 0 PCI-MSI-X eth2:3
122: 3195 0 PCI-MSI-X eth3
130: 0 0 PCI-MSI-X eth3:1
138: 0 0 PCI-MSI-X eth3:2
146: 0 0 PCI-MSI-X eth3:3
```

**NOTE:**

Some older Linux kernel versions may not support MSI-X.

## Inbox Kernel GPL Driver and Blacklisting

**NOTE:**

There are two drivers for the QLogic adapter:

- `netxen_nic.ko`. This is the in-kernel (inbox) GPL driver. It is released into the Linux upstream kernel and included in major Linux distributions.
- `nx_nic`. This is the commercial GPL driver released by QLogic.

When the QLogic RPM binary package is installed, the inbox kernel GPL driver (`netxen_nic.ko`) is *blacklisted*. Consequently, when the system is powered up, the `netxen_nic.ko` driver will not load. To prevent this from happening, you can execute the RPM `erase` command (`rpm -e nx_nic-[version]`<sup>1</sup>), which will remove the QLogic RPM binary package so that the blacklisting will revert back to the prior setting, and the `netxen_nic.ko` driver will load when the system is powered up.

To check if the inbox kernel GPL driver has been installed on the system, check the `/lib/modules/<kernel-version>/kernel/net/netxen` directory for the `netxen_nic.ko` driver. Remove or rename this file, and then reboot.

Alternately, uninstall the driver by typing the following command before continuing with the driver installation.

```
% rmmmod netxen_nic
```

---

<sup>1</sup> `[version]` refers to the RPM package currently on the system. RPM packages can be located by typing the command: `rpm -qa | grep nx_`.

The following sections describe how to install a new driver.

## Preparing for QLogic Adapter Driver Installation

Check for prior versions of the QLogic adapter driver and tools. Remove the packages from the system to prepare for installing the new release.

Use RPM to check for prior packages. For example, type:

```
% rpm -qa | grep nx_
```

Look for output similar to the following:

```
nx_nic-[prior_version]  
nx_tools-[prior_version]
```

Remove each of the prior packages by typing the following commands:

```
% rpm -e nx_nic-[prior_version]  
% rpm -e nx_tools-[prior_version]
```

## QLogic Adapter Driver Installation (RPM Format)

The following sections describe how to install the Linux driver in RPM format, create the binary, install the binary, and install the QLogic tools.

### Install the Linux Driver Source in RPM Format

To install the Linux driver source in RPM format:

1. Type the following command to extract the driver:

```
tar -zxvf qle30xx_qle31xx-src-[version].tar.gz
```

2. Type the following command to install the Linux driver RPM source:

```
% rpm -iv nx_nic-[version].src.rpm
```

### Create the Binary

Type the following command to create the binary RPM for Red Hat systems:

```
% rpmbuild -bb usr/src/redhat/SPECS/nx_nic-[version].spec
```

Type the following command to create the binary RPM for SUSE systems:

```
% rpmbuild -bb usr/src/packages/SPECS/nx_nic-[version].spec
```

### Install the Binary

Type the following command to install the binary RPM for Red Hat systems:

```
% rpm -i usr/src/redhat/RPMS/[arch]/nx_nic-[version].[arch].rpm
```

Type the following command to install the binary RPM for SUSE systems:

```
% rpm -i usr/src/packages/RPMS/[arch]/nx_nic-[version].[arch].rpm
```

In these commands, the `[arch]` variable designates the system architecture. Some `[arch]` variables include `i386`, `i586`, `i686`, `x86_64`, depending on the system. The installed QLogic driver binary will be located in one of the following directories:

```
/lib/modules/<uname -r>/updates/drivers/net/  
/lib/modules/<uname -r>/kernel/drivers/net
```

## Install the QLogic Tools

To install the QLogic tools:

1. Type the following command to extract the tools:

```
tar -zxvf qle30xx_qle31xx-linux_tools-[version].tar
```

2. Type the following command to install the tools:

```
% rpm -ivh nx_tools-[version].rpm
```

3. Type the following command to go to the directory where the tools are located:

```
% cd /opt/netxen
```

These tools include:

- `nxflash`
- `nxudiag`
- `phantomcore_P3`
- `[card type]-romimage` (`[card type]` refers to the exact ROM image)

The release may contain multiple ROM images.

## Linux QLogic Adapter Driver Options

Type the `modprobe` command to pass optional parameters to the driver, for example:

```
% modprobe -v nx_nic <parameter>
```

The parameters are listed in [Table 8-1](#).

**Table 8-1. modprobe Command Optional Parameters**

Parameter	Description	Default	Range
tx_desc	Sets the size of the command descriptor rings (transmit).	1024	256–1024 (must be power of two)
jumbo_desc_1g	Sets the size of the receive ring for jumbo frames (1GbE ports).	1024 (x86 64-bit) 512 (x86 32-bit)	64–1024 (must be power of two)
jumbo_desc	Sets the size of the receive ring for jumbo frames (10GbE ports).	1024	64–1024 (must be power of two)
rdesc_1g	Sets the size of the receive ring for normal packets (1GbE ports). For firmware version 4.0.xyz, the maximum size is 8192.	8192 (x86 64-bit) 2048 (x86 32-bit)	64–8192 (must be power of two)
rdesc_10g	Sets the size of the receive ring for normal packets (10GbE ports). For firmware version 4.0.xyz, the maximum size is 8192.	8192 (x86 64-bit) 4096 (x86 32-bit)	64–8192 (must be power of two)
use_msi	Enables MSI interrupts.	1	0: Disabled 1: Enabled
use_msi_x	Enables MSIx interrupts. This parameter is available only in kernel versions later than 2.6.8. When this parameter is enabled, it takes precedence over MSI interrupts and the use_msi parameter is ignored.	1	0: Disabled 1: Enabled
rss_enable	Enables receive side scaling. This parameter is available only when MSI-X interrupts are enabled.	1	0: Disabled 1: Enabled

## Ethtool Utility

The `ethtool` utility checks and configures additional driver options. See the `nx_nic` Linux man pages for driver option configuration examples. See the `ethtool` Linux man pages for additional details. Here is an example command:

```
% ethtool -K eth[n] tso off
```

## Configure the QLogic Adapter on Linux

To configure the QLogic adapter:

1. Type one of the following commands to identify the Ethernet interface (eth1, eth2, etc.) and the nx\_nic driver from the command line:

```
% cat /proc/net/nx_nic/dev0/stats | grep eth Of  
% ifconfig -a
```

Look for the interface with a MAC address (HWaddr) prefix of  
00:0E:1E:XX:XX:XX

2. Type the following to commands assign an IP Address and activate the interface:

```
% ifconfig eth[n] down  
% ifconfig eth[n] <IP Address> netmask <Netmask Value> up
```

3. Verify that the network services are running, and then type:

```
% service network restart
```

To verify connectivity, contact a different IP address using the ping command.

## Uninstall the Commercial GPL Driver and Tools Package

Type the following commands to uninstall the commercial GPL driver and tools, which are part of the RPM package:

```
% rpm -qa | grep nx_  
% ifconfig eth[n] down  
% rmmmod nx_nic.ko  
% rpm -e nx_nic-[version]1  
% rpm -e nx_tools-[version]
```

## Diagnostic Tests for the QLogic Adapter

The Linux user diagnostics utility performs various tests using the ./nxudiag -i eth[n] command.

The syntax for these tests is:

```
% ./nxudiag [command-options-and-arguments]
```

See [Table A-1](#) for a list of Linux diagnostic utility commands.

---

<sup>1</sup> [version] refers to the RPM package currently on the system. RPM packages can be located by executing the command: rpm -qa | grep nx\_.

**NOTE:**

While running these tests, the network traffic will be interrupted.

## Linux Performance Tuning

This section describes Linux performance tuning.

**NOTE:**

The tunable performance parameters are system and application specific. Understanding the relationship between the parameter values, target workload, performance applications, operating system, and system configuration provides a better understanding of performance optimization and bottlenecks.

## Performance Tools

Add the following parameters for performance tuning on Linux systems in the `/etc/sysctl.conf` file:

```
net.core.rmem_max = 16777216
net.core.wmem_max = 16777216
net.core.optmem_max = 524287
net.core.netdev_max_backlog = 250000
net.ipv4.tcp_rmem = 4096 87380 16777216
net.ipv4.tcp_wmem = 4096 87380 16777216
net.ipv4.tcp_timestamps = 0
net.ipv4.tcp_sack = 1
net.ipv4.tcp_low_latency = 0
net.ipv4.tcp_window_scaling = 1
net.ipv4.tcp_moderate_rcvbuf = 1
net.ipv4.route.flush = 1
```

**NOTE:**

Various factors including tools, kernel, stacks, and related parameters affect system performance.

### Using the `iperf` Tool

The `iperf` tool measures network performance. The following paragraphs show how to use `iperf`; however, it can be further tuned depending on your system's requirements.

Here is an example of `iperf` from the server side:

```
% iperf -s -w 1M -l 16k
```

Here is an example of `iperf` from the client side:

```
% iperf -c <ipAddr of Server> -w 1M -P12 -l 16k -P<number of threads>
```

## Optimization

Note the following:

- PCIe x8 provides optimal performance for 10GbE.
- MSI and MSI-X interrupts perform better than legacy interrupts.
- Linux kernel version 2.6.15 and higher provide better performance optimization.
- Check CPU utilization on the host for CPU-bound bottlenecks.



# 9 Linux Configuration for Bonding Mode and Virtual LAN (VLAN)

## Linux Bonding Mode

Ensure that the steps required for installing the RPM source, creating the binary, and installing the binary have been performed as described in [“QLogic Adapter Driver Installation \(RPM Format\)”](#) on page 8-5 before setting up Linux bonding mode.

Type the following command to verify that the QLogic adapter driver has been installed:

```
% lsmod | grep nx_nic
```

Type the following command to install the driver (if it has not yet been installed):

```
% modprobe -v nx_nic
```

The steps for setting the Linux bonding mode are as follows. Note that these are example commands. The actual commands may be different depending on the system configuration.

1. 

```
% modprobe bonding mode=1 miimon=100 updelay=50000  
primary=eth16
```
2. 

```
% ifconfig bond0 25.145.1.199 netmask 255.255.255.0  
broadcast 25.145.1.255 up
```
3. 

```
% ifenslave bond0 eth15 eth16
```

Type the following command to bring down the bond:

```
% ifconfig bond0 down
```

### **NOTE:**

These commands and steps have been tested under RHEL5. Other Linux distributions and versions may enable and utilize bonding differently.

After bonding, the MAC addresses for the two ports that were bonded appear to be the same when running the `ifconfig` command. This similarity is due to the formation of a bond to permit traffic to be passed between the ports.

After the bond has been brought down and the bonding driver removed, the QLogic adapter's original MAC addresses will resume on the ports.

## Active-Backup or Mode=1

The active-backup policy allows only one slave in the bond to be active. A different slave becomes active only if the active slave fails.

By setting `mode=1`, when `ifenslave` is executed, the bonding driver calls into the `bond_enslave()` function and sets the slave link modes for the corresponding two Ethernet ports to `BOND_LINK_DOWN`.

When the bond mode is 1 (`BOND_MODE_ACTIVEBACKUP`) and the primary device is indicated, one slave device is configured as the active slave. The `dmesg` command displays the primary port. Here is an example output of the `dmesg` command:

```
bonding: bond0: making interface eth16 the new active one 0 ms
earlier
```

If the active connection goes down, then the slave port becomes the primary port. Type the following command to monitor the bonding process during the switch-over or port priority:

```
% cat /proc/net/bonding/bond0
```

The following message is displayed:

```
MII Status: up (for eth16)
```

The `dmesg` command shows the status of the slave port, for example:

```
bonding: bond0: link status up for interface eth15, enabling it in
50000 ms.
```

Type the following command to check the status of the primary port:

```
% cat /proc/net/bonding/bond0
```

The output for this command is:

```
MII Status: down (for eth16)
```

After 50 seconds, the `dmesg` command will print:

```
bonding: bond0: link status definitely up for interface eth15.
bonding: bond0: making interface eth15 the new active one.
```

Type the following command to check the status of the new primary port:

```
% cat /proc/net/bonding/bond0
```

The output for this command is:

```
MII Status: up (for eth15)
```

## Round-Robin or Mode=0

This mode implements a round-robin scheme between the two Ethernet ports. To set the round-robin mode, type the following command:

```
% modprobe bonding mode=0 miimon=100 updelay=50000 primary=eth16
```

After the command is executed, both links delay for 50 seconds before their states are set to `BOND_LINK_UP`.

Type the following command to check the status of the bonding process:

```
% cat /proc/net/bonding/bond0
```

The output for this command is:

```
Ethernet Channel Bonding Driver: v3.0.1
Bonding Mode: load balancing (round-robin) MII Status: up MII
Polling Interval (ms): 100 Up Delay (ms): 50000 Down Delay (ms): 0
Slave Interface: eth16
MII Status: down <===== down state
Link Failure Count: 0
Permanent HW addr: 00:0e:1e:00:11:d2

Slave Interface: eth15
MII Status: down <===== down state
Link Failure Count: 0
Permanent HW addr: 00:0e:1e:00:11:d3
```

After 50 seconds, type the command again to verify the MII status of the Ethernet ports:

```
% cat /proc/net/bonding/bond0
```

The output for this command is:

```
Ethernet Channel Bonding Driver: v3.0.1 (January 9, 2006)
Bonding Mode: load balancing (round-robin) MII Status: up MII
Polling Interval (ms): 100 Up Delay (ms): 50000 Down Delay (ms): 0
```

```
Slave Interface: eth16
MII Status: up <===== up state
Link Failure Count: 0
Permanent HW addr: 00:0e:1e:00:11:d2
Slave Interface: eth15
MII Status: up <===== up state
Link Failure Count: 0
Permanent HW addr: 00:0e:1e:00:11:d3
```

The `dmesg` command output is:

```
bonding: bond0: link status definitely up for interface eth16.
bonding: bond0: link status definitely up for interface eth15.
```

## Bonding Driver Options

Options for the bonding driver are supplied as parameters to the bonding module at load time. They may be given as command line arguments to the `modprobe` command, but are usually specified in the `/etc/modules.conf` or `/etc/modprobe.conf` configuration file, or in a distribution-specific configuration file (some of which are detailed in the next section).

## Bonding Driver Parameters

The available bonding driver parameters are listed in the following sections. If a parameter is not specified, the default value is used. When initially configuring a bond, QLogic recommends that `tail -f /var/log/messages` be run in a separate window to watch for bonding driver error messages.

It is critical to specify the following parameters; otherwise, serious network degradation will occur during link failures.

- `miimon` or `arp_interval` and
- `arp_ip_target`

Most devices support `miimon`, so it is safe to use.

Options with textual values accept either the text name or, for backward compatibility, the option value. For example, `mode=802.3ad` and `mode=4` set the same mode.

### `arp_interval`

This parameter specifies the ARP link monitoring frequency in milliseconds. When ARP monitoring is used in an etherchannel compatible mode (modes 0 and 2), the switch must be configured in a mode that evenly distributes packets across all links.

When the switch is configured to distribute the packets in an XOR fashion, all replies from the ARP targets are received on the same link, which could cause the other team members to fail. ARP monitoring should not be used with `miimon`. A value of 0 disables ARP monitoring. The default value is 0.

### `arp_ip_target`

This parameter specifies the IP addresses to use as ARP monitoring peers when `arp_interval` is greater than 0. These are the targets of the ARP request sent to determine the health of the link to the targets.

Specify these values in `ddd.ddd.ddd.ddd` format. Multiple IP addresses must be separated by a comma. At least one IP address must be given for ARP monitoring to function. The maximum number of targets that can be specified is 16. The default value is no IP addresses.

### `downdelay`

This parameter specifies the time, in milliseconds, to wait before disabling a slave after a link failure has been detected. This option is valid only for the `miimon` link monitor. The `downdelay` value must be a multiple of the `miimon` value; otherwise, the value will be rounded down to the nearest multiple. The default value is 0.

### `lACP_rate`

This parameter specifies the rate at which the link partner transmits LACPDU packets in 802.3ad mode. Possible values are:

- Slow or 0: Request partner to transmit LACPDUs every 30 seconds (default).
- Fast or 1: Request partner to transmit LACPDUs every 1 second.

## QLogic Adapter Bonding Modes Under Linux

There are several modes that can be used for bonding the QLogic adapter under Linux. Note that there are variations in support and usage with respect to the hardware and Linux distributions, and that not all the modes work for a given system and network topology.

The bonding modes are described in [Table 9-1](#).

**Table 9-1. Bonding Modes**

Mode Number	Mode Name	Description
0	balance-rr	This mode uses a round-robin policy; it transmits packets in sequential order, from the first available slave through the last. This mode provides load balancing and fault tolerance.
1	active-backup	In this mode, one slave interface is active at all times. If one interface fails, another interface takes over the MAC address and becomes the active interface. This mode provides only fault tolerance. This mode does not require special switch support.
2	balance-xor	In this mode, transmissions are balanced across the slave interfaces based on ((source MAC) XOR (dest MAC)) modulo slave count. The same slave is selected for each destination MAC. This mode provides load balancing and fault tolerance.
3	broadcast	This mode transmits everything on all slave interfaces. This mode provides fault tolerance.
4	802.3a	This mode provides standard IEEE 802.3ad dynamic link aggregation. It requires 802.3ad support in the switch, and driver support for retrieving the speed and duplex of each slave.
5	balance-tlb	This mode provides adaptive transmit load balancing. Incoming traffic is received only on the active slave. Outgoing traffic is distributed according to the current load on each slave. This mode does not require special switch support.
6	balance-alb	This mode provides adaptive load balancing through ARP negotiation; both transmit load balancing (TLB) and receive load balancing are supported for IPv4. This mode does not require special switch support, but does require the ability to change the MAC address of a device while it is open.

## Configuring Virtual LAN (VLAN) Under Linux

To configure the VLAN function:

1. Type the following command to see if the `8021q.ko` driver has been loaded:

```
% lsmod | grep 8021q
```

Type the following command if the driver has not been loaded:

```
% modprobe -v 8021q
```

The `vconfig add` command creates a VLAN device on `eth0` and will, in turn, create an `eth0.5` interface.

2. Type the following command for `eth0` to add VLAN ID 5:

```
% vconfig add eth0 5
```

3. Type the `ifconfig` command to assign an IP address to the VLAN interface:

```
% ifconfig eth0.5 192.168.1.100 netmask 255.255.255.0  
broadcast 192.168.1.255 up
```

4. Type the following command to get detailed information about the VLAN interface:

```
% cat /proc/net/vlan/eth0.5
```

Repeat [Steps 2](#) and [3](#) if more than one VLAN is required.

Type the following commands to delete a VLAN interface:

```
% ifconfig eth0.5 down
```

```
% vconfig rem eth0.5
```





# 10 Firmware Management

This section describes the firmware download process. When the driver package is installed, the firmware files are installed onto the host operating system (OS).

The dynamic firmware download takes place when the driver module is loaded. As the driver module is loaded, the firmware file downloaded from the host OS becomes the active firmware version on the QLogic adapter.

## Windows Server Dynamic Firmware Download

During the driver installation process, the firmware ROM image files are placed in the `C:\WINDOWS\system32\drivers` directory.

Type the following command to determine if the firmware loaded successfully in Windows Server. The *n* in "Local Area Connection *n*" refers to the port being Flashed.

```
nxflash.exe -i "Local Area Connection n" --info (The quotation marks are required.)
```

Check for the following entry:

```
Active Firmware version: 4.0.408
```

To determine the port number (*n*), click the **Start** button, right-click **My Network Places**, and then click **Properties**. The Network Connections window opens.

The Network Connections window lists all of the ports and the type of device to which they are connected.

## Linux Dynamic Firmware Download

After the installation of the driver RPM, the firmware ROM image files are placed in the `/lib/firmware` directory.

When the driver is installed, the firmware file located in the `/lib/firmware` directory is dynamically loaded onto the QLogic adapter.

Type the following command to determine if the firmware has loaded successfully. The [*n*] refers to the port number.

```
ethtool -i eth[n]
```

Check for the following entry:

Active Firmware version: 4.0.408

# 11 Troubleshooting Guidelines

## Unable to Boot the Host System with the QLogic Adapter Installed

If the system does not boot after installing the QLogic adapter:

1. Remove the QLogic adapter and power up the system. Does the system boot without the QLogic adapter? If so, power down the system, insert the QLogic adapter into a different PCIe slot, and power up the system.
2. Ensure that the system BIOS configuration is up-to-date during the system boot up process.
3. Ensure that the recommended minimum memory is installed on the host system.
4. Note any error messages that appear during the operating system (OS) boot sequence.
5. Check for system error messages.
  - Windows event viewer
  - `% dmesg` (display system messages on Linux)

## Unable to Send/Receive Network Traffic Using the QLogic Adapter

If network traffic cannot be sent/received with the QLogic adapter:

1. Ensure that the network cable is plugged in properly.
2. Ensure that the SFP+ module is installed correctly (see [“QLE3142 Installation” on page 4-4](#)).
3. Ensure that the client machine is configured correctly and able to communicate with other machines.

4. Type `lspci -v` and look for vendor ID 4040.
  - a. Check to see if the QLogic adapter is visible on the PCI bus.
  - b. Check to see if the QLogic adapter is plugged into the appropriate PCIe slot.
5. Check if the driver is loaded correctly and the card is initialized.
  - Windows event viewer
  - `dmesg` (display system messages on Linux)
6. Check the network configuration.
  - a. Check for a valid IP address and subnet.
  - b. Check for duplicate IP address and subnet numbers.
  - c. Check the gateway address and network path (if connected through a gateway).
  - d. Check the QLogic adapter MAC address values.
  - e. Verify the network link status as seen by the host OS.
  - f. Check for LED activity (using `ping`).
  - g. Analyze the transmit and receive packets for the QLogic adapter using network monitoring tools.
  - h. Verify the ARP entry and response.

If none of the previous steps resolve the problem, run the QLogic user diagnostics.

## Additional Configuration for Windows Server 2008 Teaming

*How-to* tips can be found at the bottom of the **Teaming Management tab** in the QLogic Advanced Network Config Service window (see [Figure 6-15](#)).

## Troubleshooting Tools

The following sections explain how to use the Windows and Linux tools to help solve potential problems.

## Windows Server Tools

The troubleshooting tools available in Windows Server are described in [Table 11-1](#).

**Table 11-1. Troubleshooting Tools in Windows Server**

Tool	What it Provides
systeminfo	The <code>systeminfo</code> tool provides detailed information about the operating system version, CPU, system manufacturer and model, memory configuration, hot fixes, and network cards.
Device manager	The device manager shows the hardware configured on the system.
Driver tab	The driver tab displays device status, QLogic adapter information, debug counters for gathering support log details, diagnostics test cases, statistics, driver version, and resources.
ipconfig	The <code>ipconfig</code> tool shows IP network settings; it also releases and renews by adapter or connection.
%systemRoot%\windows\inf\QLsetup.log	This log contains messages from the installer program (MSI); these messages indicate if the installation was successful.
Windows event log	The Windows event log is the main source of information for device driver problems and events. The QLogic adapter's device drivers indicate status by logging events in the system event log.

## Linux Tools

The troubleshooting tools available in Linux are described in [Table 11-2](#).

**Table 11-2. Troubleshooting Tools in Linux**

Tool	What is Provides
nxdebug1	Linux script does not require the <code>nx_nic</code> driver to be loaded. This tool gathers information on the kernel, any GPL or <code>nx_nic</code> driver loaded, RPM packages, processor, memory, interrupts, PCI bus, <code>dmesg</code> (last 50 messages), and network configuration.
nxdebug2	Linux script does require the <code>nx_nic</code> driver to be loaded. This tool gathers kernel configuration, <code>nx_nic</code> device stats, multicast settings, <code>nx_nic</code> driver messages from the <code>/var/log/messages</code> file, <code>modprobe</code> info, SLAB information, buddy information, I/O memory information, <code>sysctl</code> information, the complete <code>dmesg</code> log, <code>ethtool</code> details on the <code>nx_nic</code> interface, and specific <code>nx_nic</code> status.

## Check for System Errors

### Linux

To check for system errors in Linux.

- Check for error messages from the kernel using the following commands:

```
% dmesg
% cat /var/log/messages
```

- Check routing table, gateway, and IP address conflicts for all interfaces using the following command:

```
% route
```

- Check network interface transmit and receive counts during pings using the following command:

```
% ifconfig <network interface>
```

- Use the `wireshark`, `ethereal`, `tethereal`, or `tcpdump` utility to capture packets.

### Windows Server

To check for system errors in Windows Server:

- Use the `wireshark` or `ethereal` utilities to capture packets.
- Check for system error messages using the Windows event viewer.

## Caveats

### MSI-X Interrupts for Linux

Newer Linux OS distributions or kernel versions support MSI-X interrupts; some older versions do not support MSI-X. If MSI-X is not available on the OS, then use MSI or legacy mode in the OS.

Type the following command on the Linux host to check that PCI-MSI-X or PCI-MSI is enabled for the Ethernet interface:

```
% cat /proc/interrupts
```

Determine if the installed Linux kernel has the MSI configuration option enabled (earlier versions of the kernel may require an MSI patch).

Type the following command from the directory `/usr/src/kernels/<kernel version>` and verify that the MSI configuration option is supported/enabled:

```
% make menuconfig
```

## PCI Express Slot

The QLogic adapter can be located on the PCI Express bus using the following Linux procedures.

- Determine the vendor and device ID.** To check if the PCIe slot has a x8 link for optimal PCIe performance, first determine the PCI vendor ID and device ID code by typing the following command:

```
% lspci -n
```

You should see a message similar to:

```
06:00.0 0200: 4040:0100 (rev 42)
```

The QLogic vendor ID is 0x4040. A list of QLogic adapter device IDs is listed in [Table 11-3](#).

**Table 11-3. QLogic Adapter Device IDs**

Product	Device ID	Description
QLE3044	0124	Quad-port 1GbE copper interface
QLE3142-CU	0126	Dual-port 10GbE with twinax interface
QLE3142-SR	0126	Dual-port 10GbE with short-range fiber interface
QLE3142-LR	0126	Dual-port 10GbE with long-range fiber interface

- Determine the interface attributes.** To determine the attributes of the interface, type the following command:

```
% lspci -n -d 4040:0100 -vvv | grep -i width
```

You should see a message similar to:

```
Link: Supported Speed 2.5 Gb/s, Width x8, ASPM L0s, Port 0
Link: Speed 2.5Gb/s, Width x8
```

- Determine the width parameters.** Check if the `lspci` output “negotiated width” (the second width in the output) reflects the actual “supported width”. In an system with a QLE3044, for example, type the following command to determine if these two widths are the same:

```
% lspci -xxx -vvv -d 4040:0100
```

In the previous command, 4040 indicates the QLogic vendor ID and 0124 indicates a QLE3044. The device ID is 0126.

Examine the following hex output:

```
..... 82 04 00 00 01 00 82
        ↑           ↑
Supported Negotiated
link width link width
```

From the `lspci` hex output:

```
c0: 10 00 02 00 02 80 00 00 00 10 0b 00 82 04 00 00
                                     ↑
                                     ||_____ capability. "82 04" = x8 PCIe Gen2
```

Note that some PCIe chip sets with a x16 link may not support a PCI Express x8 link width. A link is required to support only its maximum width and x1. Check the motherboard specification to determine if its PCIe x16 slot can autonegotiate to x8.

On some motherboards, the PCIe slots are all the same physical size required by a x16 slot, but electrically they are different widths. Check the motherboard specification for the supported width of each of the PCIe slots.



# A Diagnostic Utility Commands

Table A-1 lists user-level diagnostic utility commands for the Linux and Windows Server OSs.

**Table A-1. Diagnostic Utility Commands**

Command	Description
-i --interface	This command specifies the interface type (Local Area Connection 1, Local Area Connection 2, etc.).
-a --all	This command performs all tests, regardless of the default.
-D --default	This command performs only the default test.
-R --CRegs	This command tests all control registers (default).
-F -FLASH	This command tests the Flash (default).
-I --IRQS	This command tests the interrupt mechanism (default).
-L --IntLB	This command performs an internal loopback test (default).
-H --Hw	This command performs a hardware test (default).
-S --LinkST	This command tests the link status (default).
-l --LED	This command tests the LEDs (default).

**Table A-1. Diagnostic Utility Commands (Continued)**

Command	Description
-nR --noCRegs	This command disables control register testing (use with -D or -a).
-nF --noFLASH	This command disables Flash testing (use with -D or -a).
-nI --noIRQS	This command disables interrupt testing (use with -D or -a).
-nL --noIntLB	This command disables internal loopback testing (use with -D or -a).
-nH --noHw	This command disables hardware testing (use with -D or -a).
-nS --noLinkSt	This command disables link status testing (use with -D or -a).
-nL --noLED	This command disables LED status testing (use with -D or -a).
-E --ExtLB	This command performs an external full-duplex loopback test.
-h --help	This command prints the help message.
-v --version	This command displays version information.
-C --Cmdif	This command performs an interface status test. <b>NOTE:</b> This command is valid only in Linux.

# B Flash Update

Under rare circumstances, it may be necessary update the Flash on the QLogic adapter. Contact Technical Support to see if a Flash update is required. If so, follow the instructions in this appendix.

## Flash Update and Tool Guidelines

Consider the following before updating the Flash:

- The update process should not be interrupted (do not reboot or stop the update process).
- A backup image of the existing Flash will be created at the start of the Flash update process. The Flash utility will use the backup image to recover if required.
- The Flash tool will not start the Flash update process if the QLogic adapter driver is not loaded.
- The Flash tool auto-identifies the appropriate Flash image for the QLogic adapter.

## Flash Update Options

Options for updating the Flash are as follows. Do use these options unless specified by Technical Support.

- [“nxflash Command” on page B-1](#)
- [“NX Live CD” on page B-2](#)
- [“NX Live USB” on page B-2](#)

### **nxflash Command**

Run the appropriate command from Linux or Windows Server, as described in the following paragraphs.

## Windows Server

Type the following command, where “Local Area Connection *n*” specifies the adapter being Flashed:

```
nxflash -i "Local Area Connection n" --all (the quotes are required)
```

You are prompted to answer Y(es) or N(o) to allow the upgrading of the Flash to continue. Press the **Y** key to continue.

See “QLogic Adapter Flash Update—Windows Server” on page B-3 for more information.

## Linux

Type the following command, where [*n*] indicates the port number of the QLogic adapter (0, 1, 2, etc.):

```
./nxflash -i [n] --all
```

See “QLogic Adapter Flash Update—Linux” on page B-8 for more information.

## NX Live CD

To install the NX Live CD:

1. Download the QLogic Live ISO image file from the QLogic Web site, [www.qlogic.com](http://www.qlogic.com).
2. Burn the ISO image onto a CD writable media (make sure your system has a CD burner).
3. Insert the NX Live CD into the system that contains the QLogic adapter.
4. Change any BIOS settings to permit the CD to boot before the other devices on the system.
5. Boot the system from the CD.
6. Use the menu options (see “NX Live Menu Options” on page B-3) to show current board information, update the firmware, or reboot the system (remember to remove the NX Live CD if you need to revert back to the operating system (OS) on the hard disk).

Refer to the support page on the on QLogic Web site for more information on downloading the NX Live CD.

## NX Live USB

To install the NX Live USB:

1. Download the NX Live USB zip image file from the QLogic Web site, [www.qlogic.com](http://www.qlogic.com).
2. Insert a USB Flash device in a USB slot.

3. Format the USB Flash device to a FAT file system (if required):
  - a. Right-click the **Start** button, and then click **Explore**.
  - b. Right-click the USB Flash drive, and then click **Format**.
  - c. Format the USB Flash drive to a FAT file system.
4. Unzip the NX Live USB file into its own directory.
  - a. Right-click the file, click **Open With**, and then click **Compressed (zipped) Folders**.
  - b. Copy the two folders `boot` and `slax` onto the USB Flash drive.
5. Click the **Start** button, and then click **Run**.
6. Type `cmd` in the **Open:** box, and then click **OK**.
7. Change to the drive letter assigned for the USB Flash drive, for example:  
`C:\Documents and Settings>F:`
8. Change the directory to the `boot` folder on the USB Flash drive.
9. Execute the `bootinst.bat` file. Press the ENTER key twice to complete the process of making the USB Flash drive bootable.
10. Insert the NX Live USB Flash drive into the server with the QLogic adapter.
11. Change any BIOS settings to permit the USB Flash drive to boot before the other devices on the system.
12. Use the menu options (see [NX Live Menu Options](#)) to show current board information, update the firmware, or reboot the system (remember to remove the NX Live USB if you need to revert back to the OS on the hard disk).

## NX Live Menu Options

Here is an example of the NX Live menu options:

```
NX Live Firmware Update
Menu Options:
1. Show adapter information
2. Update to latest firmware on adapter
3. Reboot system if firmware has been updated
Enter here:
```

## QLogic Adapter Flash Update—Windows Server

This section provides information on how to perform a Flash update in Windows Server 2003, 2008, and 2008 R2. Note that the QLogic adapter is shipped with a default Flash version.

## Using the Flash Utility

When invoking the `nxflash.exe` utility, use the following syntax:

```
nxflash -i "Local Area Connection n" --all
```

In this command, the `-i` indicates the interface command and the "Local Area Connection *n*" specifies the adapter being Flashed. (The quotation marks are required.)

To determine the adapter number:

1. Click the **Start** button, and then right-click **My Network Places**.
2. Click **Properties**. The Network Connections window opens.

The Network Connections window lists all of the adapters and the type of device to which they are connected.

Along with the interface (`-i` in the `nxflash` command syntax), additional commands are listed in [Table B-1](#).

**Table B-1. Flash Utility Commands—Windows Server**

Command	Definition	Description
<code>-i</code> <code>--interface</code>	Interface	This command specifies the interface type (Local Area Connection 1, Local Area Connection 2, etc.).
<code>--info</code>	Information	This command displays adapter information such as adapter type, chip revision, serial ID, firmware version, BIOS version, MAC address, etc.
<code>-a</code> <code>--all</code>	Flash update	This command performs a complete update of the BIOS and the firmware.
<code>-a &lt;image file&gt;</code> <code>--all &lt;image file&gt;</code>	Flash update	This command performs a complete update of the BIOS and the firmware using a user-renamed ROM image.
<code>-r &lt;backup file&gt;</code> <code>--restore &lt;backup file&gt;</code>	Restore	When an update is performed, the previous Flash version is stored to a file in the current working directory. Executing this command restores the specified backup Flash version to the QLogic adapter. Here is an example of a backup file name:  <code>flashbackup_[serial number]_[version]_[date-time]</code>
<code>--pxe-on</code>	PXE	This command enables PXE (default).

**Table B-1. Flash Utility Commands—Windows Server (Continued)**

Command	Definition	Description
<code>--pxe-off</code>	PXE	This command disables PXE.
<code>--wol-on</code>	WOL	This command enables wake on LAN.
<code>--wol-off</code>	WOL	This command disables wake on LAN (default).
<code>-d name.xml</code>	Create XML	This command creates an XML file that contains QLogic adapter/firmware information. For Windows Server, the XML file will be in the current directory.
<code>-h</code> <code>--help</code>	Help	This command displays the help menu.
<code>-v</code> <code>--version</code>	Version	This command displays the version information.

## Flash Update Procedure

To update the Windows Server 2003, 2008, and 2008 R2 OS Flash:

1. Click the **Start** button, and then click **Run**. The Run dialog box opens.
2. Type **cmd** in the **Open:** box, and then click **OK**.
3. Go to the `utils` directory in the driver package provided.

The following binaries must be in the same directory from where the Flash command will be executed:

```
nxflash.exe
[card type]-romimage
```

The release may contain multiple ROM images. The `[card type]` variable in the previous command refers to the exact ROM image.

Note that the `nxflash` utility and ROM image files must be in the same directory from where the `nxflash` command is executed.

4. Type the following command, where `n` is the number of the port being Flashed:

```
nxflash.exe -i "Local Area Connection n" --all (The quotation marks are required.)
```

Writing the Flash takes a few minutes. Do not interrupt or reboot the system during this time.

Here is an example of the Windows Server `nxflash --all` output for local area connection 8:

```
C:\netxen\4.0.223\utils>nxflash -i "Local Area Connection 8"
--all
NETXEN Port is Port 0
Verifying flash...Done.
0/9 - Init
*** Currently in flash ***
Board Type      : Quad Gig LP
Firmware Version : 4.0.222
MAC Address 0   : 00:0E:1E:00:7F:24
MAC Address 1   : 00:0E:1E:00:7F:25
MAC Address 2   : 00:0E:1E:00:7F:26
MAC Address 3   : 00:0E:1E:00:7F:27
Serial Number   : QG88BK0130
NIC binary romimage found in C:\netxen\4.0.223\utils
Rom Image      :
C:\netxen\4.0.223\utils\lp_qg_cut_thru_b1_romimage
1/9 - Extracting Romimage
Firmware version From Board: 4.0.222
Firmware version From Romimage: 4.0.223
WARNING: This operation will take the NIC off line.
Do you wish to upgrade? (Y/N) y
```

5. Reboot the system.
6. Type the following command to verify that the Flash has been updated (*n* is the number of the port being Flashed):

**`nxflash.exe -i "Local Area Connection n" --info`** (The quotation marks are required.)



Here is an example of a Windows Server `nxflash --info` output for local area connection 0:

```
C:\Users\Administrator\Desktop\4.0.223\utils>nxflash.exe -i
"Local Area Connection 0" --info
NETXEN Port is Port 0
Verifying flash...Done.
Board Type                : 0x24 (Quad Gig LP)
Board Chip Rev            : B1
Serial Id                 : QG87BK0092
Efuse ID                  : 0x4e36343633340f08
Firmware version (on Flash) : 4.0.228
Active Firmware version   : 4.0.229
Firmware in               : CUT-THRU mode
Driver version            : 4.0.229
BIOS version              : 2.0.0
MAC Addr 0                : 00:0E:1E:00:79:DC
MAC Addr 1                : 00:0E:1E:00:79:DD
MAC Addr 2                : 00:0E:1E:00:79:DE
MAC Addr 3                : 00:0E:1E:00:79:DF
Subsystem ID              : 0x01244040
PHY Type                  : UNKNOWN PHY
PXE Status                : Disabled
```

## Updating the Flash on Multiple Standalone QLogic Adapters

The Flash can be updated on multiple QLogic adapters on the same host using one of the following procedures.

- To perform updates from the same directory tree, type the following commands sequentially after the Flash update has completed. In these commands, *n* represents two different port numbers, for example, "Local Area Connection 4" and "Local Area Connection 5" (the quotation marks are required).
  - ❑ `nxflash.exe -i "Local Area Connection n" --all` (first QLogic adapter)
  - ❑ `nxflash.exe -i "Local Area Connection n" --all` (second QLogic adapter)

- To perform updates simultaneously from two different directory trees, type the following commands from two separate directory trees. In these commands, *n* represents two different port numbers, for example, “Local Area Connection 4” and “Local Area Connection 5” (the quotation marks are required).
  - ❑ `c:\[version]-a\utils\ nxflash.exe -i "Local Area Connection n" --all` (first QLogic adapter)
  - ❑ `c:\[version]-b\utils\ nxflash.exe -i "Local Area Connection n" --all` (second QLogic adapter)

## QLogic Adapter Flash Update—Linux

This section describes how to perform a Flash update in Linux. Note that the QLogic adapter is shipped with a default Flash version.

### Using the Flash Utility

When invoking the `nxflash` utility, use the following syntax:

```
% ./nxflash -i [n] [command]
```

In this command, the `[n]` indicates the QLogic adapter device number (0, 1, etc.).

Along with the interface type (`-i` in the `nxflash` command syntax), additional commands (`[command]` in the `nxflash` command syntax) are listed in [Table B-2](#).

**Table B-2. Flash Utility Commands—Linux**

Command	Definition	Description
<code>-l</code> <code>--list</code>	List devices	This command shows all QLogic devices installed.
<code>-i</code> <code>--interface</code>	Interface	This command specifies the interface type (0, 1, 2, etc.).
<code>--info</code>	Information	This command displays adapter information such as the adapter type, chip revision, serial ID, firmware version, BIOS version, MAC address, etc.
<code>-a</code> <code>--all</code>	Flash update	This command performs a complete update of the BIOS and the firmware. This command is used when the default ROM image is used.

**Table B-2. Flash Utility Commands—Linux (Continued)**

Command	Definition	Description
-a <image file> --all <image file>	Flash update	This command performs a complete update of the BIOS and the Flash using a user-renamed ROM image.
-r <backup file> --restore <backup file>	Restore	When an update is performed, the previous firmware version is stored to a file in the current working directory. Executing this command restores the specified backup Flash version to the QLogic adapter. Here is an example backup file name:  <i>flashbackup_[serial number]_[version]_[date-time]</i>
--pxe-on	PXE	This command enables PXE.
--pxe-off	PXE	This command disables PXE (default).
--wol-on	WOL	This command enables wake on LAN.
--wol-off	WOL	This command disables wake on LAN (default).
-h --help	Help	This command displays the help menu.
-d name.xml	Create XML	This command creates an XML file containing QLogic adapter firmware information in /tmp.
-v --version	Version	This command displays the version information.

**Table Notes**

The QLogic adapter will be offline during a Flash update.

## Flash Update Procedure

To update the Linux OS Flash:

1. Ensure that the steps required for installing the RPM source, creating the binary, and installing the binary to the file system have been performed. If not, follow the instructions in [“QLogic Adapter Driver Installation \(RPM Format\)” on page 8-5](#) before proceeding. The new driver is now ready to be loaded automatically the next time the system is powered up.
2. Update the Flash.

- a. Type the following command to go to the appropriate directory:

```
% cd/opt/netxen
```

- b. Type the following command to display a list of all the QLogic devices:

```
./nxflash --list
```

Note the function number for the QLogic adapter.

- c. Type the following command to start the Flash update; use the function number from the previous step in the `-i` option:

```
% ./nxflash -i [n] --all
```

The Flash update takes a few minutes to complete and *must not be interrupted*. Note that you only need to update one port on each QLogic adapter; updates do not need to be performed on a per-port basis.

As an example, the `--list` command displays one of the following two devices in an SFP+ installation. For copper -based installations, additional devices will be shown:

```
[0] NetXen Dual Port SFP+ 10GbE Server Adapter [PCI slot 17  
function 0]
```

```
[1] NetXen Dual Port SFP+ 10GbE Server Adapter [PCI slot 17  
function 1]
```

3. Get Flash related information. Use the `--info` option to get information about the Flash by typing:

```
% ./nxflash -i [n] --info
```

Here is an example of a Linux `nxflash` output:

```
# ./nxflash -i 0 --info
NIC driver will be temporarily unloaded
Closing interfaces: eth2 eth3
PCIE Function Number is 0
Verifying flash...Done.
Board Type           : 0x26 (NetXen NX3031 Dual Port SFP+ 10GbE
Server Adapter)
Board Chip Rev       : B1
Serial Id            : SF8DBK0145
Efuse ID             : 0x0000000000000000
Firmware version(on Flash) : 4.0.304
BIOS version         : 2.1.0
MAC Addr 0           : 00:0E:1E:00:7C:A4
MAC Addr 1           : 00:0E:1E:00:7C:A5
Subsystem ID         : 0x01264040
PXE Status           : Enabled
WOL Status           : Disabled
Please wait while NetXen drivers are restored...
```



# Glossary

**dbgview.exe**

Debug viewer for Windows Server

**dmesg**

Linux system messages

**Ethtool utility**

Linux Ethernet tool for card settings; See `man ethtool` in Linux.

**FlexLOM™**

QLogic's FlexLOM feature in the Intelligent Ethernet Adapter enables 1GbE and 10GbE connectivity with the end user's choice of interface on a single device.

**iperf**

Linux performance tool

**iSCSI**

Internet small computer system interface. Protocol that encapsulates data into IP packets to send over Ethernet connections. An alternative to FCIP.

**LED**

Light emitting diode  
Status indicator on a device.

**MSI**

Message signaled interrupt

**MSI-X**

Message signaled interrupt extension

One of two PCI-defined extensions to support message signaled interrupts (MSI), in PCI 2.2 and later and PCI Express. MSIs are an alternative way of generating an interrupt through special messages that allow emulation of a pin assertion or deassertion.

MSI-X (defined in PCI 3.0) allows a device to allocate any number of interrupts between 1 and 2048 and gives each interrupt separate data and address registers. Optional features in MSI (64-bit addressing and interrupt masking) are mandatory with MSI-X.

**netxen\_nic.ko**

In-kernel (inbox) GPL driver. It is released into the Linux upstream kernel and included in major Linux distributions.

**nxflash**

Flash utility

**nx\_nic**

Commercial GPL driver released by QLogic

**nxudiag**

QLogic user diagnostic utility

---

## PCIe and PCI Express

A third-generation input/output (I/O) standard that allows enhanced Ethernet network performance beyond that of the older peripheral component interconnect (PCI) and PCI extended (PCI-X) desktop and server slots.

## PXE

Preboot execution environment

## romimage

QLogic firmware image for a QLogic 3000 or 3100 Series Intelligent Ethernet Adapter

## RPM

Software package file format

## RSS

Receive side scaling

## SFP+

Small form factor pluggable +  
A 1/10Gbps transceiver device (smaller than a gigabit interface converter) that plugs into the Ethernet port.

## VLAN

Virtual logical area network (LAN)  
A group of hosts with a common set of requirements that communicate as if they were attached to the same wire, regardless of their physical location. Although a VLAN has the same attributes as a physical LAN, it allows for end stations to be grouped together even if they are not located on the same LAN segment. VLANs enable network reconfiguration through software, instead of physically relocating devices.



# Index

## Symbols

%systemRoot%\windows\stnf\  
QLsetup.log 11-3

## A

-a A-1, B-4, B-8  
-a <image file> B-4, B-9  
Active-backup mode 9-2  
Adapter properties  
  Advanced tab 7-3  
  Details tab 7-9  
  Diagnostics tab 7-9, 7-12  
  Driver tab 7-9, 11-3  
  Flash update tab 7-9  
  General tab 7-2  
  Information tab 7-9  
  Resources tab 7-9  
  Statistics tab 7-9  
Adapters supported 1-1  
Advanced tab, adapter properties 7-3  
--all A-1, B-4, B-8  
--all <image file> B-4, B-9  
Application notes 1-2  
arp\_interval parameter 9-5  
arp\_ip\_target parameter 9-5  
Audience ix

## B

Binary RPM in Linux 8-5

## Bonding

  driver options 9-4  
  driver parameters 9-4  
  mode 9-1, 9-5

Bracket removal and replacement 4-3, 4-5

## C

-C A-2  
Cable specifications 2-1  
--Cmdif A-2  
Commercial GPL driver 8-4  
  enable 8-2  
  uninstall 8-8  
Configuration, QLogic adapter 7-9, 8-8  
Configuration, Windows Server 2008 Teaming  
  driver 6-8  
Conventions ix  
--CRegs A-1

## D

-D A-1  
-d name.xml B-5, B-9  
dbgview.exe Glossary-1  
--default A-1  
Details tab, adapter properties 7-9  
Device ID 11-5  
Device manager 11-3  
Diagnostics 7-11, 8-8  
Diagnostics tab, adapter properties 7-9, 7-12  
dmesg Glossary-1  
Document conventions ix  
downdelay parameter 9-5

## Driver

see *also* Driver installation, Driver installation verification  
bonding driver options [9-4](#)  
bonding driver parameters [9-4](#)  
configuration, Windows Server 2003, 2008 [7-1](#)  
configuration, Windows Server 2008 Teaming [6-8](#)  
file location, Linux [8-2](#)  
inbox kernel GPL and commercial, enable [8-2](#)  
options [8-6](#)  
tab, adapter properties [7-9](#), [11-3](#)  
version [8-2](#)

## Driver installation

see *also* Inbox kernel GPL driver, Commercial GPL driver  
Linux [3-4](#)  
Linux (RPM format) [8-5](#)  
Linux driver source code, building [8-2](#)  
Windows Server 2003 (NIC) [3-3](#), [5-2](#)  
Windows Server 2008 (NIC) [3-3](#), [6-2](#)  
Windows Server 2008 (Teaming) [6-6](#)

## Driver installation verification

Windows Server 2003 (NIC) [5-5](#)  
Windows Server 2008 (NIC) [6-5](#)

## E

-E [A-2](#)  
Ethool utility [8-7](#), [Glossary-1](#)  
Event log [11-3](#)  
--ExtLB [A-2](#)

## F

-F [A-1](#)

## Firmware

dynamic download [10-1](#)  
ROM image location [5-1](#), [6-1](#), [8-1](#)  
version, Linux [8-2](#), [10-2](#)  
version, Windows Server 2003 and 2008 [10-1](#)

## Flash

--FLASH [A-1](#)  
update tab, adapter properties [7-9](#)  
update, Linux [B-1](#), [B-8](#), [B-10](#)  
update, Windows Server 2003 and 2008 [B-1](#), [B-5](#)  
updating on multiple standalone QLogic adapters [B-7](#)  
utility commands [B-4](#), [B-8](#)

## G

General tab, adapter properties [7-2](#)

## H

-H [A-1](#)  
-h [A-2](#), [B-5](#), [B-9](#)  
Hardware  
installation [3-1](#), [4-1](#), [4-4](#)  
requirements [2-1](#)  
verifying the installation of [3-2](#)  
--help [A-2](#), [B-5](#), [B-9](#)  
Host system cannot boot with QLogic adapter installed [11-1](#)  
--Hw [A-1](#)

## I

-I [A-1](#)  
-i [A-1](#), [B-4](#), [B-8](#)  
Inbox kernel GPL driver, blacklisting [8-4](#)  
Inbox kernel GPL driver, enabling [8-2](#)  
--info [B-4](#), [B-8](#)  
Information tab, adapter properties [7-9](#)

## Installation

see *also* Driver installation, Driver installation verification  
hardware [3-1](#)  
hardware verification of [3-2](#)  
Linux driver [3-4](#)  
Windows Server 2003 NIC driver [3-3](#), [5-2](#)  
Windows Server 2008 NIC driver [3-3](#), [6-2](#)  
Windows Server 2008 Teaming driver [6-6](#)  
`--interface` [A-1](#), [B-4](#), [B-8](#)  
`--IntLB` [A-1](#)  
`ipconfig` [11-3](#)  
`iperf` [8-9](#), [Glossary-1](#)  
`--IRQs` [A-1](#)  
iSCSI [Glossary-1](#)  
iSCSI boot [1-2](#)

## L

`-L` [A-1](#)  
`-l` [A-1](#), [B-8](#)  
`lacp_rate` parameter [9-5](#)  
`--LED` [A-1](#)  
LEDs [4-2](#), [4-5](#), [Glossary-1](#)  
`--LinkST` [A-1](#)  
Linux  
bonding mode [9-1](#)  
driver installation [3-4](#)  
driver installation in RPM format [8-5](#)  
driver options [8-6](#)  
driver source code, building [8-2](#)  
Flash update [B-8](#), [B-10](#)  
MSI-X interrupts for [11-4](#)  
performance tuning [8-9](#)  
PXE [1-2](#)  
system errors, checking for [11-4](#)  
troubleshooting tools [11-3](#)  
VLAN, configuring under [9-7](#)  
`--list` [B-8](#)

## M

Modes, active-backup [9-2](#)  
Modes, round-robin [9-3](#)  
`modprobe` command optional parameters [8-7](#)  
Module information, Linux [8-2](#)  
MSI [Glossary-1](#)  
MSI-X [Glossary-1](#)  
interrupts [11-4](#)  
support [8-3](#)

## N

Network traffic not being sent/received using the QLogic adapter [11-1](#)  
`netxen_nic.ko` [8-4](#), [Glossary-1](#)  
`-nF` [A-2](#)  
`-nH` [A-2](#)  
`-nI` [A-2](#)  
`-nL` [A-2](#)  
`-nl` [A-2](#)  
`--noCRegs` [A-2](#)  
`--noFLASH` [A-2](#)  
`--noHw` [A-2](#)  
`--noIntLB` [A-2](#)  
`--noIRQs` [A-2](#)  
`--noLED` [A-2](#)  
`--noLinkST` [A-2](#)  
`-nR` [A-2](#)  
`-nS` [A-2](#)  
`ntttcp` [7-13](#), [7-14](#)  
`ntttcpr` command line options [7-15](#)  
`ntttcps` command line options [7-15](#)  
NX Live  
CD [B-2](#)  
menu [B-3](#)  
USB [B-2](#)  
`nx_nic` [8-4](#), [Glossary-1](#)  
`nx3fwct.bin` [5-1](#), [6-1](#), [8-1](#)  
`nx3fwmn.bin` [5-1](#), [6-1](#), [8-1](#)  
`nxdebug1` [11-3](#)  
`nxdebug2` [11-3](#)

nxflash [Glossary-1](#)  
command [B-1](#), [B-4](#), [B-8](#)  
nxudiag [Glossary-1](#)

## P

PCI Express [Glossary-2](#)  
PCI Express bus, finding QLogic adapter on  
[11-5](#)  
PCIe [Glossary-2](#)  
Performance tuning [7-13](#), [8-9](#)  
Port mapping [4-2](#)  
PXE [Glossary-2](#)  
`--pxe-off` [B-5](#), [B-9](#)  
`--pxe-on` [B-4](#), [B-9](#)

## Q

QLE3044  
see *also* QLogic adapter  
bracket removal and replacement [4-3](#)  
hardware installation [4-1](#)  
LEDs [4-2](#)  
port mapping [4-2](#)  
QLE3142  
see *also* QLogic adapter  
bracket removal and replacement [4-5](#)  
hardware installation [4-4](#)  
LEDs [4-5](#)  
QLogic adapter  
see *also* QLE3044, QLE3142  
bonding modes [9-5](#)  
configuration, Linux [3-6](#), [8-8](#)  
configuration, Windows Server 2003 and  
2008 [7-9](#)  
device IDs [11-5](#)  
diagnostics [7-11](#), [8-8](#)  
hardware installation [3-1](#)  
PCI Express bus location [11-5](#)  
performance tuning [7-13](#)  
properties [7-2](#)  
supported adapters [1-1](#)  
Quick start instructions [3-1](#)

## R

`-R` [A-1](#)  
`-r <backup file>` [B-4](#), [B-9](#)  
Red Hat driver installation [3-4](#)  
Related materials [ix](#)  
Requirements, hardware [2-1](#)  
Resources tab, adapter properties [7-9](#)  
`--restore <backup file>` [B-4](#), [B-9](#)  
romimage [Glossary-2](#)  
Round-robin mode [9-3](#)  
RPM [Glossary-2](#)  
binary RPM in Linux [8-5](#)  
installing the Linux driver in RPM format [8-5](#)  
RSS [Glossary-2](#)

## S

`-S` [A-1](#)  
SFP+ [Glossary-2](#)  
SFP+ optical module requirements [2-2](#)  
Statistics tab, adapter properties [7-9](#)  
SUSE driver installation [3-5](#)  
System errors, checking for [11-4](#)  
systeminfo [11-3](#)

## T

Tcp1323Opts parameter [7-16](#)  
TcpWindowSize parameter [7-20](#)  
Technical support [x](#)  
Tools  
Linux [8-2](#), [8-6](#)  
troubleshooting [11-3](#)  
uninstall [8-8](#)  
Troubleshooting [x](#), [11-1](#)

## U

### Uninstall

- commercial GPL driver [8-8](#)
- tools [8-8](#)
- Windows Server 2003 NIC driver [5-6](#)
- Windows Server 2008 NIC driver [6-12](#)
- Windows Server 2008 Teaming driver [6-13](#)

## V

- v [A-2](#), [B-5](#), [B-9](#)
- version [A-2](#), [B-5](#), [B-9](#)
- VLAN [Glossary-2](#)
- VLAN configuration [9-7](#)

## W

### Windows Server 2003

- configuring the QLogic adapter in [7-9](#)
- diagnostics [7-11](#)
- driver configuration [7-1](#)
- driver installation overview [3-3](#)
- event log [11-3](#)
- Flash update [B-5](#)
- NIC driver installation [5-2](#)
- NIC driver installation verification [5-5](#)
- performance tuning [7-13](#)
- system errors, checking for [11-4](#)
- troubleshooting tools [11-3](#)
- uninstall NIC driver [5-6](#)

- Windows Server 2008 and 2008 R2
  - configuring the QLogic adapter in [7-9](#)
  - diagnostics [7-11](#)
  - driver configuration [7-1](#)
  - driver installation overview [3-3](#)
  - event log [11-3](#)
  - Flash update [B-5](#)
  - NIC driver installation [6-2](#)
  - NIC driver installation verification [6-5](#)
  - system errors, checking for [11-4](#)
  - Teaming driver configuration [6-8](#)
  - Teaming driver installation [6-6](#)
  - troubleshooting tools [11-3](#)
  - uninstall NIC driver [6-12](#)
  - uninstall Teaming driver [6-13](#)
- wol-off [B-5](#), [B-9](#)
- wol-on [B-5](#), [B-9](#)







**Corporate Headquarters** QLogic Corporation 26650 Aliso Viejo Parkway Aliso Viejo, CA 92656 949.389.6000 [www.qlogic.com](http://www.qlogic.com)

**Europe Headquarters** QLogic (UK) LTD. Quatro House Lyon Way, Frimley Camberley Surrey, GU16 7ER UK +44 (0) 1276 804 670

---

© 2009, 2010 QLogic Corporation. Specifications are subject to change without notice. All rights reserved worldwide. QLogic, the QLogic logo, and FlexLOM are trademarks or registered trademarks of QLogic Corporation. Finisar is a registered trademark of Finisar Corporation. JDS Uniphase is a registered trademark of JDS Uniphase Corporation. Red Hat is a registered trademark of Red Hat, Inc. Windows and Windows Server are registered trademarks of Microsoft Corporation. Linux is a registered trademark of Linus Torvalds. PCI Express and PCIe are registered trademarks of PCI-SIG. SUSE is a registered trademark of Novell, Inc. All other brand and product names are trademarks or registered trademarks of their respective owners. Information supplied by QLogic Corporation is believed to be accurate and reliable. QLogic Corporation assumes no responsibility for any errors in this brochure. QLogic Corporation reserves the right, without notice, to make changes in product design or specifications.