


**Network
Management Card**
User Manual



NMC Transverse - 66074



Environment Sensor - 66846

Network Management Card

User Manual

Table of Contents

1	MGE NETWORK SOLUTION	5
1.1	INTRODUCTION	5
1.1.1	Connecting the UPS / STS to the Network	5
	The Network Management Card:	5
1.1.2	Protecting the computers / servers	6
1.1.3	Monitoring the UPSs over the network	6
1.1.4	Connection	7
1.2	PRESENTATION OF THE NETWORK MANAGEMENT CARDS (NMC)	7
1.3	PRESENTATION OF THE ENVIRONMENT SENSOR SOLUTION	8
1.4	DIRECT SENDING OF E-MAIL	8
1.5	SENDING TEXT MESSAGES (SMS)	8
1.6	COMPATIBILITY WITH THE NETWORK MANAGEMENT SYSTEMS (NMS) – TRAP SENDING	8
1.7	TECHNICAL DATA	9
1.7.1	Configuration	9
1.7.2	Administration	9
1.7.3	Network	9
1.7.4	MIB (Management Information Base)	9
1.7.5	Environment sensor	9
2	INSTALLATION AND CONFIGURATION	11
2.1	INSTALLATION	11
2.1.1	Installing the card in the UPS / STS	11
2.1.2	Connecting the card to the IT network	11
2.1.3	Understanding front panel signals	11
2.2	BASIC CONFIGURATION	11
2.2.1	List of default parameters	11
2.2.2	Adjusting the network parameters	11
2.2.3	Rebooting the card	11
2.2.4	Restoring factory configuration	11
2.2.5	Lost password – restoring the default password	11
2.2.6	Checking that the card is working	11
2.3	ENVIRONMENT SENSOR	11
3	SUPERVISION / ADMINISTRATION VIA A WEB BROWSER	12
3.1	OPTIMISING THE PERFORMANCE OF YOUR BROWSER	12
3.2	UPS / STS	13
3.2.1	“UPS properties” page	13
3.2.2	“STS properties” page	15
3.2.3	About	16
3.2.4	On-line help	17
3.2.5	UPS 3-Phase display	19
3.2.6	STS 3-Phase display	21
3.2.7	UPS Control	22
3.2.8	UPS weekly schedule programming	24
3.2.9	Shutdown parameters	25
3.2.10	Viewing the alarms	26
3.3	Logs	27
3.3.1	UPS Measurements	27
3.3.2	STS Measurements	28

Network Management Card

User Manual

3.3.3	UPS Event log	30
3.3.4	STS Event log	30
3.3.5	System log	32
3.4	NOTIFICATION	34
3.4.1	UPS Email Notification	34
3.4.2	STS Email Notification	36
3.4.3	Email Message Settings	37
3.4.4	Email Example	39
3.5	CONFIGURATION	40
3.5.1	Network Settings	41
3.5.2	System	43
3.5.3	UPS Notified Applications	45
3.5.4	Central Shutdown Configuration	47
3.5.5	STS Notified Applications	48
3.5.6	Access control	50
3.5.7	Time	53
3.6	ENVIRONMENT	54
3.6.1	Characteristics	54
3.6.2	Environment status	55
3.6.3	UPS Environment Settings	57
3.6.4	Log	59
4	SERVERS PROTECTION, UPS ONLY	60
4.1	SET-UP OF THE SHUTDOWN PARAMETERS	60
4.1.1	Shutdown criteria managed by the Management Card	60
4.1.2	Specific set-up for long autonomy installation (> 30 mn)	61
4.2	THE DIFFERENT SERVER AND UPS SHUTDOWN SEQUENCES	62
4.2.1	Extended power outage, shutdown initiated by the Shutdown Timer	62
4.2.2	Extended power outage, shutdown initiated by the "Low battery power" message	63
4.2.3	Extended power outage, shutdown initiated by the Shutdown Timer, but utility restoration before the end of the Shutdown Duration	64
4.2.4	Off/On command	64
5	CONFIGURING A SET OF CARDS WITH MUPGRADE	65
6	CONFIGURATION IN LOCAL MODE AND VIA TELNET OR SSH	65
6.1	CONFIGURATION IN LOCAL MODE	65
6.1.1	Choice 1: SNMP agent configuration menu	66
6.1.2	Choice 2: UPS / STS parameters	67
6.1.3	Choice 3: Access control	67
6.1.4	Choice 4: Restore default configuration	68
6.1.5	Choice 5: Reset the card	68
6.2	CONFIGURATION VIA TELNET	69
6.3	CONFIGURATION VIA SSH	69
6.3.1	PuTTY SSH Client Program	69
7	MAINTENANCE	72
7.1	SOFTWARE UPGRADE	72
7.1.1	Card firmware upgrade using Mupgrade (Windows)	72
7.1.2	Card software upgrade via TFTP (UNIX and Windows)	72
7.1.3	Recovery tool software Msupgrade (Windows) via the serial link	72
8	APPENDICES	73
8.1	TABLES OF ALARMS AND EVENTS	73

Network Management Card

User Manual

8.1.1	UPS Alarm table	73
8.1.2	STS Alarm table	73
8.1.3	UPS event table	74
8.1.4	STS event table	76
8.1.5	System alarm table	78
8.2	GLOSSARY	79

Network Management Card

User Manual


1 MGE Network Solution

1.1 Introduction

- provides information on events concerning the supply of power to the computers connected to your computer network,
- carries out automatic shutdown of computer systems,
- monitors and controls all the UPSs connected to the network.
- monitors all the STS connected to the network,

As illustrated in the picture below, MGE Network Solution provides these 3 main functions:

- **connecting** the UPS / STS to the Network,
- **protecting** the computers powered by UPS,
- **monitoring** the UPSs / STSs over the Network



1.1.1 Connecting the UPS / STS to the Network

This function can be performed either through network Cards inserted in the UPS (**Network Management Card**).

The Network Management Card:

- manages communication with the UPS / STS,

Network Management Card

User Manual

- ▶ periodically accesses the information concerning the UPS / STS,
 - ▶ makes this information available to the connected applications (**Network Shutdown Modules**, Web Browser, Network Management Systems, **Enterprise Power Manager**)
- Operation may be in standard secure mode (the default mode) or in SSL secure mode (Secure Socket Layer SSL).

1.1.2 Protecting the computers / servers

This function is performed by the **Network Shutdown Module** installed on each of the servers to be protected. Note that the Shutdown Module is available on several Operating Systems.

The Network Shutdown module (only available for UPS, not for STS):

- ▶ Continuously waits for information from the Network Management Card connected to the MGE UPSs.
- ▶ warns administrators and users if AC power fails and proceeds with graceful system shutdown before the end of battery backup power is reached.


1.1.3 Monitoring the UPSs over the network

Depending on your needs, you can either use:

- ▶ your Internet browser to monitor each UPS, as Management Card include a Web server.
- ▶ your company's standard Network Management System (HP-Openview, CA Unicenter, HP Insight Manager, IBM Tivoli Netview). To simplify integration of MGE UPSs with these NMS, you can use one of the Network Management System Kits for MGE devices. These kits are available on **Management Pac 2** CD-Rom. (ref 66923)
- ▶ the MGE supervisor " **Enterprise Power Manager** "

Network Management Card

User Manual



1.1.4 Connection

1.1.4.1 How to connect UPS / network :

- ▶ Insert the optional card in the UPS / STS and connect the device to the computer network.
- ▶ Start the MGE UPS / STS, then the computers.

1.1.4.2 Setting up the protection, for UPS only

- ▶ Set up the Network Management Card (see user manual).
- ▶ Install Network Shutdown Module on all machines that are to be protected by the UPS (supplied with UPS battery backup power).

The software components for each platform and the user manuals are supplied free-of-charge on the Solution-Pac 2 CD are available or for download on the www.apc.com Web site.

1.2 Presentation of the Network Management Cards (NMC)

MGE provides one form factors for its **Network Management Cards** :

Network Management Card

User Manual

- ▶ **NMC Transverse** for UPS, in UPS slot, like the MGE Galaxy PW, MGE Galaxy PW 1000, MGE Galaxy 3000, MGE Galaxy 4000 US, MGE Galaxy 5000, MGE Galaxy 5000 US
- ▶ **NMC Transverse** for UPS, *using the **Network Management Link***, like the Comet 3000, Comet S31, MGE Galaxy 6000, MGE Galaxy 9000, EPS 6000 US, EPS 7000 US, EPS 8000 US
- ▶ **NMC Transverse** for STS, in STS slot, like the MGE Epsilon STS and MGE Upsilon STS

The Network Management Cards acquire information on the operation status of the UPS / STS systems and provide remote control of these systems by means of an ETHERNET network from any SNMP administration station or Web browser. They also supply alarms to the Network Shutdown Modules to trigger shutdown or other automatic actions for protected servers.

A simple html browser is used for supervision and configuration.
Network Management Cards are compatible with :

- ▶ [Network Shutdown Modules](#)
- ▶ [Entreprise Power Manager](#)
- ▶ [Management-Pac 2 ?](#)
- ▶ [ISXC](#)

1.3 Presentation of the Environment Sensor solution

The [Environment Sensor](#) solution comprises a box to be connected to the **Card Settings** port of the Network Management Cards:

Environment Sensor enables measurement of temperature and humidity around the UPS, consideration of external alarms via 2 dry contacts and notification of alarms according to pre-programmed thresholds.

1.4 Direct sending of E-mail

When a UPS / STS event occurs, the Network Management Card can directly notify up to 4 intranet or extranet addressees by e-mail (see [Email Notification](#) and [Email Message Settings](#)).

1.5 Sending text messages (SMS)

SMS messages can be sent by specific configuration of the e-mail function via the internet access providers making the e-mail / SMS transfer.

1.6 Compatibility with the Network Management Systems (NMS) – Trap sending

The Network Management Cards are compatible with the major Network Management Systems (IBM Tivoli, CA Unicenter, HP Insight Manager ..). The Management-Pac 2 offering includes the necessary SNMP plug-in to allow an easy integration in the NMS. Events are notified by SNMP trap

- ▶ NMS can subscribe on page "[Notified Application](#)"
- ▶ SNMP sequences are described in chapter "Server protection"

The trap list can be looked over in the document "Agent's MIB description" available on apc.com.

Network Management Card

User Manual

1.7 Technical data

1.7.1 Configuration

The user can configure the card with one of the following means:

- Web browser
- Local serial link
- Telnet console
- BOOTP/DHCP
- Mupgrade

1.7.2 Administration

- Up to 50 workstations protected
- Up to 15 browsers connected at the same time
- E-mail sending configurable according to UPS alarms and transmission of a periodical report
- Measurement of temperature and humidity, adjustable thresholds, possibility of sending e-mails and shutting down the installation
- Control of UPS on/off switching via the HTML interface
- Adjustment and control Power via the HTML interface, sequential starting of the installation and optimisation of backup time by shutting down non-priority systems
- Adjustment of date and time via NTP server - Daylight Saving Time management
- Protection by encrypted password.
- Protection by secured connection SSL and SSH
- Saving of logs in the non-volatile memory
- Automatic language detection according to browser configuration.
- Languages available: English / French / Spanish / German / Italian
- On-line help available for each page
- Card firmware updated via the network
- Card configuration deployment on your installed base through network utility (Mupgrade)

1.7.3 Network

- Fast ETHERNET 10/100 Mbits compatibility with auto-negotiation on the RJ45 outlet
- SNMP trap port modifiable (by default = 162)

1.7.4 MIB (Management Information Base)

- MIB IETF UPS (RFC1628) for UPS
- MIB MGE V1.7 AD, for UPS
- MIB MGE V2.2 AA, for STS

1.7.5 Environment sensor

- Temperature measurement from 0 to 70 °C with +/- 1° C accuracy
- Measurement of humidity from 0 to 100 % with +/- 6 % accuracy
- Min / max time-stamped function for temperature and humidity
- Choice of temperature readings in Celsius or Fahrenheit
- High and low thresholds, hysteresis and offset adjustable via Web interface

Network Management Card

User Manual

- ▶ Possibility of notification of status changes by e-mail, SMS or SNMP traps
- ▶ Position detection of 2 dry contacts (maximum sensor/contact distance: 20 m)
- ▶ Name and status of each configurable contact
- ▶ Recording of events and measurements in the card log
- ▶ Possibility of shutting down the installation in the event of a threshold being exceeded or on opening / closure of a dry contact
- ▶ Connection to the card with straight CAT5 RJ45 network cables (maximum card/sensor distance: 20 m)

Network Management Card

User Manual

2 Installation and Configuration

For the following sections, read the installation manual supplied with the card or available for download on the www.apc.com web site in the “[Download area](#)” section .

2.1 Installation

2.1.1 Installing the card in the UPS / STS

2.1.2 Connecting the card to the IT network

2.1.3 Understanding front panel signals

2.2 Basic configuration

2.2.1 List of default parameters

2.2.2 Adjusting the network parameters

2.2.3 Rebooting the card

2.2.4 Restoring factory configuration

2.2.5 Lost password – restoring the default password

2.2.6 Checking that the card is working

2.3 Environment Sensor

Read the installation manual supplied with the box.

Network Management Card User Manual

3 Supervision / Administration via a Web browser

A JVM (Java Virtual Machine) is required to ensure correct display of information in HTML pages.

- ▶ On a computer equipped with a Web browser (Internet Explorer or Netscape recommended), enter the address initialised previously in the Installation chapter (e.g.: <http://213.30.17.30>.)
- ▶ The “UPS properties” or “STS properties” home page is displayed.

3.1 Optimising the performance of your browser

- ▶ To view status changes on the UPS in real time, the browser must be configured so that it automatically refreshes all the objects on the current page.
Example on IE : **Tools / Internet Options / General / Parameters menu**, tick **Every time this page is visited** and validate.

Network Management Card

User Manual

3.2 UPS / STS

3.2.1 “UPS properties” page

- ▶ This page gives instant access to the essential information about your UPS. This page is automatically refreshed every 10 seconds (by default). To change this value, go to the “[System](#)” page.

3.2.1.1 UPS zone: general information on the UPS.

Indication of the picture and generic name of the UPS range

Computer room: Customised name of your system corresponding to the “upsIdentName” object of the UPS MIB (RFC 1628)

You can change this name on the “[System](#)” page.





	<ul style="list-style-type: none"> • Normal operation
	<ul style="list-style-type: none"> • Alarm present. This icon links directly to the alarm page

3.2.1.2 “UPS status” zone: essential information

- ▶ The various icons showing the status of the UPS are:

Network Management Card

User Manual

• 	• Battery operation
• 	• Load powered by main AC
• 	• Loss of communication with the UPS
• 	• Battery fault

“**Communication**”: indicates the status of the communication between the card and the UPS

“**Power source**”: indicates whether the power comes from the utility or from the UPS battery

“**Batteries**”: indicates whether the battery is being charged or discharged

“**Output load level**”: indicates the power percentage used at UPS output

“**Output**”: indicates if the UPS output is protected, Powered or not Powered

3.2.1.3 “Battery status” zone:

- ▶ “**Bargraph**”: Graph showing the remaining battery charge (in percent).
- ▶ “**Battery charge level**”: Remaining battery charge (in percent).
- ▶ “**Remaining backup time**”: Estimation of the maximum backup time remaining before UPS shutdown.
This time can be modified by the adjustments on the “Shutdown parameters” page
- ▶ “**Last periodical test**”: Result of the last automatic battery test carried out by the UPS
Possible values are:
 - **OK**: the test was completed correctly
 - **NOK**: the battery needs to be checked
 - **Deactivated**: the automatic battery test is not validated on the UPS

Network Management Card

User Manual

3.2.2 “STS properties” page

- ▶ This page gives instant access to the essential information about your STS. This page is automatically refreshed every 10 seconds (by default). To change this value, go to the [“System”](#) page.

3.2.2.1 STS zone: general information on the STS.

Indication of the picture and generic name of the UPS range

Computer room: Customised name of your system corresponding to the “upsIdentName” object of the UPS MIB (RFC 1628)

You can change this name on the [“System”](#) page.

	<ul style="list-style-type: none"> • Normal operation
	<ul style="list-style-type: none"> • Alarm present. This icon links directly to the alarm page

3.2.2.2 “STS status” zone: essential information

- ▶ The various icons showing the status of the UPS are:

	<ul style="list-style-type: none"> • Loss of communication with the STS
--	--

Network Management Card

User Manual

“Communication”: indicates the status of the communication between the card and the STS
“Output”: indicates whether the output is or not powered
“Output load level”: indicates the power percentage used at STS output
“Transfer”: indicates if it is possible to switch from one used source to the other.

3.2.2.3 “Sources status” zone:

- **“Active source”**: indicate which source is currently used.
 Possible values are:
 - 1: for source 1
 - 2 : for source 2
 - **Unknown** : if value unknown (initialization, lost of communication)

- **“Preferred source”**: indicate which source is used, if none source is faulty
 Possible values are:
 - 1: for source 1
 - 2 : for source 2
 - **Unknown** : if value unknown (initialization, lost of communication)

3.2.3 About

The **“About your UPS”** or **“About your STS”** zone provides information on the UPS / STS, in particular, the name range and software version. Are also available, the current NMC firmware release.

About your UPS / STS

GALAXY 5000 60 kVA	
UPS / STS Name :	GALAXY 5000 60 kVA
UPS / STS Firmware revision :	IA.GDENA8S300IC303

Network Management Card	
Firmware revision :	IAb6 (SN 49ej45002)




Network Management Card

User Manual

3.2.4 On-line help

On-line contextual help in English is available at the top of each page by clicking on the **Help** link, which is always located on the top right corner.

The Help page always opens a new window. There is two help pages, dedicated to the device : one help for UPS, other one for STS.



UPS Properties Help







This is the page by default, displaying the fundamentals status of the UPS.

UPS feature identifies the UPS, which is powering the electrical network.

- ▶ **About your UPS:** provides information on the UPS and the Network Management Card

UPS Status

- ▶ **Communication:** indicates the status of the communication between the card and the UPS.
- ▶ **Power source:** indicates either the power comes from the utility or from the UPS battery
- ▶ **Battery:** indicates either the battery is being in charge or in discharge.
- ▶ **Output load level :** indicates the power percentage used at UPS output.

	Utility power present
	UPS is on battery
	Battery fault or unavailable
	Communication loss with the UPS
	Outlet powered - Flashing when an on/off sequence is in progress
	Outlet not powered or not protected

Battery Status:

- ▶ **Battery charge level:** Remaining battery charge (in percent).
- ▶ **Remaining backup time:** Estimation of the remaining battery backup time before UPS shutdown.
- ▶ **Last periodic test:** Result of the last automatic battery test carried out by the UPS.

Refresh : The Web browser refreshes this page according to the period defined by the parameter **Refresh Rate** in the page [System Settings](#).

Note : A Java Virtual machine is required to show properly html pages

UPS

- ▶ [UPS Properties](#)
- ▶ [3-Phase Display](#)
- ▶ [UPS Control](#)
- ▶ [Weekly Schedule](#)
- ▶ [Shutdown](#)
- ▶ [Parameters](#)
- ▶ [Alarm Table](#)

Logs and Notification

- ▶ [Measurements](#)
- ▶ [Event Log](#)
- ▶ [System log](#)
- ▶ [Email Notification](#)
- ▶ [Email Message](#)

Settings

- ▶ [Network](#)
- ▶ [System](#)
- ▶ [Notified Applications](#)
- ▶ [Central](#)
- ▶ [Configuration](#)
- ▶ [Access Control](#)
- ▶ [Time](#)


Environment

- ▶ [Status](#)
- ▶ [Settings](#)
- ▶ [Log](#)

▶ [Web resources](#)

Network Management Card

User Manual



- ▶ **STS**
 - [STS Properties](#)
 - [3-Phase Display](#)
 - [Alarm Table](#)
- ▶ **Logs and Notification**
 - [Measurements](#)
 - [Event Log](#)
 - [System log](#)
 - [Email Notification](#)
 - [Email Message](#)
- ▶ **Settings**
 - [Network](#)
 - [System](#)
 - [Notified Applications](#)
 - [Access Control](#)
 - [Time](#)
- ▶ **Environment**
 - [Status](#)
 - [Settings](#)
 - [Log](#)
- ▶ [Web resources](#)

STS Properties Help

This is the page by default, displaying the fundamentals status of the STS.

STS Status

- ▶ **Communication:** indicates the status of the communication between the card and the STS.
- ▶ **Output :** indicates if the load is powered or not
- ▶ **Output load level :** indicates the power percentage used at STS output.
- ▶ **Transfer:** indicates if possible to supply the load with the other source, in the place of current one.

Sources Status:

- ▶ **Active source:** which source is powering the load .
- ▶ **Prefered source:** the customer prefered source.
- ▶ **About your STS:** provide information on the STS and the Network Management Card.

Refresh : The Web browser refreshes this page according to the period defined by the parameter **Refresh Rate** in the page [System Settings](#).

Network Management Card

User Manual

3.2.5 UPS 3-Phase display

Click **3-phase display** to access to the detailed monitoring page
 This item is added to the menu for all single UPSs having a three-phase output.

- The link on the gauge symbols gives access to the measurement page related to the function.
- Function symbols are outlined in red when an alarm is present.
- The red triangle, linked to the alarm page, appears when an alarm is present, otherwise a green symbol is displayed.

This page is automatically refreshed every 10 seconds (by default).
 To change this value, go to the "[System](#)" page.

3-Phase Display Frequency and power factor

Total	Ph1	Ph2	Ph3
24 kW	5 kW	5 kW	13 kW
26 kVA	5 kVA	5 kVA	15 kVA
50.0 Hz	25 A	25 A	64 A
pf = 0.90	404 V (u12)	404 V (u23)	403 V (u31)
	233 V	233 V	232 V

Labels for the schematic diagram:

- Maintenance position
- Static switch operation
- Normal operation
- Battery

3.2.5.1 Normal input measurements

3-Phase Display

Ph1	Ph2	Ph3
40 A	40 A	40 A
398 V (u12)	398 V (u23)	398 V (u31)

49.9 Hz

Labels for the input measurements:

- Input current
- Input voltage Phase / Phase

Network Management Card

User Manual

3.2.5.2 Battery measurements

3-Phase Display

GALAXY 5000 60 kVA - Battery		Help
Remaining backup time :	11 min 0 sec	Remaining backup time estimated by the UPS
Battery charge level :	75 %	Battery charge level
Battery voltage :	491.0 V	Battery voltage
Battery current :	0 A	Battery current – Negative when discharging
Battery Temperature :	23 °C	Battery temp. – Internal temperature probe

3.2.5.3 By Pass measurements

3-Phase Display

GALAXY 5000 60 kVA - By-pass input				Help
Ph1	Ph2	Ph3		
0 A	0 A	0 A		By Pass current
397 V (U12)	397 V (U23)	397 V (U31)		By Pass voltage Phase / Phase

50.0 Hz

Network Management Card

User Manual

3.2.6 STS 3-Phase display

Click **3-phase display** to access to the detailed monitoring page
 This item is added to the menu for all single UPSs having a three-phase output.

- The link on the gauge symbols gives access to the measurement page related to the function.
- Function symbols are outlined in red when an alarm is present.
- The red triangle, linked to the alarm page, appears when an alarm is present, otherwise a green symbol is displayed.

This page is automatically refreshed every 10 seconds (by default).
 To change this value, go to the "[System](#)" page.

Interface 3-phases

The screenshot shows the 'Interface 3-phases' for an 'Upsilon STS 250 A - Sortie'. It includes a table of phase data, summary statistics, and a circuit diagram with two sources (S1, S2) and an output (OUT).

	Ph1	Ph2	Ph3
Output current	1.7 A	1 A	0.3 A
Output voltage Phase / Phase	401 V (u12)	400.6 V (u23)	400.2 V (u31)

Summary statistics:

- Output active power: 00 kW
- Output apparent power: 00 kVA
- Output frequency: 50 Hz
- Output power factor: pf = 00
- Output crest factor: Crete = 00
- Source1 source2 dephasement: $\phi\% = -0.4^\circ$

Diagram callouts:

- Output active power, Output apparent power, Output frequency:** Point to the summary statistics.
- Output current:** Points to the current values in the table.
- Output voltage Phase / Phase:** Points to the voltage values in the table.
- Output power factor, Output crest factor, Source1 source2 dephasement:** Points to the pf, Crete, and $\phi\%$ values.
- No Alarm – STS OK:** Points to the green 'ok' icon.
- Maintenance position, on Source 2:** Points to the blue switch icon for Source 2.
- Normal position, on Source 2:** Points to the green line for Source 2.
- Maintenance position, on Source 1:** Points to the blue switch icon for Source 1.

Network Management Card

User Manual

3.2.6.1 Source 2 input measurement

Ph1	Ph2	Ph3
00 A	00 A	00 A
403.1 V (u12)	401.8 V (u23)	401.1 V (u31)

50 Hz
00 A(neutral)

Source 1 current
Source 1 voltage Phase / Phase
Source 1 frequency
Source 1 neutral current (if wiring 3 phases + neutral)

3.2.6.2 Source 2 input measurement

Ph1	Ph2	Ph3
1.6 A	0.9 A	0.4 A
406.6 V (u12)	405.5 V (u23)	405.1 V (u31)

50 Hz
2.4 A(neutral)

Source 2 current
Source 2 voltage Phase / Phase
Source 2 frequency
Source 2 neutral current (if wiring 3 phases + neutral)

3.2.7 UPS Control

Click on the **"UPS Control"** section in the menu.

If the UPS is not compatible with this function, a warning message is sent to the user. UPS configuration may also prevent the commands from being properly run. Read the UPS manual for more information.

UPS Control

GALAXY 5000 60 KVA Help

Output	Status	Control	Off Delay	Toggle Duration	On Delay
Master	On	None	0 sec	0 sec	0 sec

Execute Save changes

This page enables triggering of [startup and shutdown sequences](#) for the UPS main output. The status of output is displayed by a symbol associated with the **Off** label (red symbol) or **Powered** (green symbol).

Network Management Card

User Manual

- ▶ The shutdown sequences take into account the time required for the registered servers to shut down without losing data ([see shutdown parameters](#)). Once the sequence has started, the commands are disabled until it ends.
- ▶ After a startup sequence, the commands are disabled for 120 seconds to enable the servers to fully restart

The Check column proposes six different commands, and a command is only actually started after clicking on **'Execute'**:

“Safe power down”: a sequence to switch off output power is launched immediately. The symbol representing the output flashes, indicating that the sequence is in progress. The systems supplied are shut down correctly while the shutdown sequence is running, then the output is cut.

“Safe power down & reboot”: A sequence to switch off then restore output power is launched immediately. The symbol representing the output flashes, indicating that the shutdown sequence is in progress. The powered systems are shut down correctly during the shutdown sequence, then the output is switched off. Finally, the restart sequence is launched at the end of the time delay specified in the **“Toggle duration”** parameter. The output status is updated.

“Immediate On”: a sequence to switch on output power is launched immediately. The output is re-powered and the systems supplied start up again correctly.

“Delayed, safe power down”: this is the same switch off sequence as for the **“ Safe power down ”** command, but postponed by the number of seconds programmed in the **“Off Delay”** parameter.

“Delayed, safe power down & reboot:” this is the same switch off then on sequence as for the **Safe power down & reboot ”** command, but postponed by the number of seconds programmed in the **“ Off Delay ”** parameter.

“Delayed On ”: this is the same switch on sequence as for the **“ Immediate On ”** command, but postponed by the number of seconds programmed in the **“ On Delay ”** parameter.

The **Save** button saves the **Off Delay, Toggle duration** and **On Delay** parameters on the card .

Security: The administrator must click on **Save** and enter his login / password to save modifications or run commands. The login and password by default are: **MGEUPS**.

Network Management Card

User Manual

3.2.8 UPS weekly schedule programming

Click on the **“Weekly schedule”** section of the menu.

If the UPS is not compatible with this function, a warning message is sent to the user. UPS configuration may also prevent the commands from being properly run. Read the UPS manual for more information.

The weekly schedule enables the administrator to optimise power consumption or program a reboot of the protected equipment at a set time.

In a shutdown sequence, the **Network Shutdown Modules** connected to the card are informed and ensure that each machine is shut down correctly before the UPS output is switched off (dependant of the UPS settings and UPS type).

Up to 7 UPS shutdown sequences (dependant of the UPS settings and UPS type) can be programmed in one week, with a minimum shutdown delay of 30 minutes.

Security: the administrator clicks on **“Save”** and enters his/her login / password to save any edits. The login and password by default are: **MGEUPS**.

Weekly Schedule

GALAXY 5000 60 kVA [Help](#)

Day	Shutoff Time	Restart Time
Sunday	-	-
Monday	-	-
Tuesday	-	-
Wednesday	21:30	22:00
Thursday	-	-
Friday	-	-
Saturday	-	00:00 00:30 01:00 01:30 02:00 02:30 03:00 03:30 04:00 04:30

Network Management Card

User Manual

3.2.10 Viewing the alarms

- Click on the “**Alarm table**” section in the menu to view the list of current alarms. The table of managed alarms is included in the [appendix](#).

Note: The alarm number is not related to the SNMP trap number

Alarm Table

GALAXY 5000 60 kVA [Help](#)

Alarm ID	Alarm Time	Alarm Description
30	2010/01/25 16:01:54	Utility Failure
31	2010/01/25 16:02:59	Output On By-pass

Network Management Card

User Manual

3.3 Logs


3.3.1 UPS Measurements

Click on the **“Measurements”** section in the menu.

The following measurements are saved and time-stamped:

- ▶ **“Input voltage”**: Value of the utility voltage supplying your UPS (average of 3 phases for UPS' equipped with a 3-phase input)
- ▶ **“Input frequency”**: Value of the utility frequency feeding your UPS
- ▶ **“Output voltage”**: Value of the output voltage of your UPS (average of the 3 phases for UPS' with a 3-phase output)
- ▶ **“Output load”**: Value of the percentage of load at UPS output (Value of the most loaded phase for 3-phase UPS')
- ▶ **“ Output current Ph x”**: Value of the output current for each phase on three-phase UPSs
- ▶ **“Battery capacity”**: Percentage of charge available in the battery
- ▶ **“Remaining time”**: Estimation of the remaining backup time
- ▶ The save frequency of these values is defined in the **“System”** page (60 seconds by default). Approximately 1000 time-stamps are stored permanently on the card. The oldest time-stamps are automatically deleted.
- ▶ **“Save”** enables all saved values to be opened or saved in CSV format (compatible with Excel type spreadsheets)
- ▶ **“Clear”** enables deletion of all records. The administrator must enter his login / password to validate this action if he has not already done so during the current session.

Measurements index page



GALAXY 5000 60 kVA Help


Save Log Clear Log

- [From 2010/01/25 15:00:00](#)
- [From 2010/01/25 14:56:00 To 2010/01/25 14:59:00](#)

Select the time range to view

Network Management Card

User Manual

GALAXY 5000 60 kVA 

Log Date (yyyy/mm/dd)	Log Time (hh:mm:ss)	Input Voltage (Volt)	Input Frequency (Hertz)	Output Voltage (Volt)	Output Load (%)	Output Current Ph1(A)	Output Current Ph2(A)	Output Current Ph3(A)	Battery Capacity (%)	Remaining Time (min)
2010/01/22	15:00:00	402	50	404	0	0	0	0	75	72
2010/01/22	15:01:00	402	50	404	0	0	0	0	75	72
2010/01/22	15:02:00	403	50	403	0	0	0	0	75	72
2010/01/22	15:03:00	402	50	404	0	0	0	0	75	72
2010/01/22	15:04:00	403	50	404	0	0	0	0	75	72
2010/01/22	15:05:00	401	50	403	0	0	0	0	75	72
2010/01/22	15:06:00	402	50	404	0	0	0	0	75	72
2010/01/22	15:07:00	399	49	404	0	0	0	0	75	72
2010/01/22	15:08:00	399	50	404	44	25	25	64	75	11
2010/01/22	15:09:00	398	50	403	44	25	25	64	75	11
2010/01/22	15:10:00	401	49	404	44	25	25	64	75	11
2010/01/22	15:11:00	402	50	404	44	25	25	64	75	11

3.3.2 STS Measurements

Click on the **“Measurements”** section in the menu.

The following measurements are saved and time-stamped:

- **“Source 1 voltage”**: Value of the utility voltage supplying your STS (value of the first phase)
- **“Source 1 frequency”**: Value of the utility frequency feeding your STS
- **“Source 2 voltage”**: Value of the utility voltage supplying your STS (value of the first phase)
- **“Source 2 frequency”**: Value of the utility frequency feeding your STS
- **“Output voltage”**: Value of the output voltage of your STS (value of the first phase)
- **“Output load”**: Value of the percentage of load at STS output (value of loaded for the 3-phase)
- **“Output current Ph x”**: Value of the output current for each phase on three-phase STSs
- The save frequency of these values is defined in the **“System”** page (60 seconds by default).

Approximately 1000 time-stamps are stored permanently on the card. The oldest time-stamps are automatically deleted.

- **“Save”** enables all saved values to be opened or saved in CSV format (compatible with Excel type spreadsheets)

“Clear” enables deletion of all records. The administrator must enter his login / password to validate this action if he has not already done so during the current session.

Network Management Card

User Manual

Measurements index page

Upsilon STS 250 A [Help](#)

Save Log

Clear Log

- [From 2010/02/08 15:00:00](#)
- [From 2010/02/08 14:30:00 To 2010/02/08 14:59:00](#)
- [From 2010/02/08 14:00:00 To 2010/02/08 14:29:00](#)
- [From 2010/02/08 13:30:00 To 2010/02/08 13:59:00](#)
- [From 2010/02/08 13:00:00 To 2010/02/08 13:29:00](#)

Select the time range to view

Measurements

Upsilon STS 250 A

Log Date (yyyy/mm/dd)	Log Time (hh:mm:ss)	Source 1 voltage (Volt)	Source 1 frequency (Hertz)	Source 2 voltage (Volt)	Source 2 frequency (Hertz)	Output Voltage (Volt)	Output Load (%)	Output Current Ph1(A)	Output Current Ph2(A)	Output Current Ph3(A)
2010/02/08	14:30:00	400	49	404	50	404	0	1	0	0
2010/02/08	14:31:00	403	49	404	49	404	0	1	0	0
2010/02/08	14:32:00	400	49	404	49	404	0	1	1	0
2010/02/08	14:33:00	401	50	404	49	404	0	1	0	0
2010/02/08	14:34:00	402	50	404	49	404	0	1	0	0
2010/02/08	14:35:00	401	49	404	49	404	0	1	0	0
2010/02/08	14:36:00	400	49	405	49	405	0	1	0	0
2010/02/08	14:37:00	402	49	406	49	406	0	1	0	0
2010/02/08	14:38:00	401	50	405	49	405	0	1	0	0
2010/02/08	14:39:00	401	50	406	50	406	0	1	1	0


Network Management Card

User Manual

3.3.3 UPS Event log

Click in the “**Event log**” section of the menu.

- ▶ “**Save Log**” enables all values saved to be opened or saved in CSV format (compatible with Excel type spreadsheets).
- ▶ “**Clear Log**” enables deletion of all records. The administrator must enter his/her login / password to validate this action.



Select the time range to view:

Event Log data



Date (yyyy/mm/dd)	Time (hh:mm:ss)	Event Description
2010/01/25	15:13:24	Output on Bypass
2010/01/25	15:13:29	UPS off sequence completed
2010/01/25	15:13:32	Output switch (Q5N) open
2010/01/25	15:14:39	UPS fault
2010/01/25	15:15:40	Bypass : Return on UPS
2010/01/25	15:15:48	Output switch (Q5N) closed
2010/01/25	15:16:17	UPS OK
2010/01/25	15:34:54	Output on battery

See the table of events generated in the [UPS event table](#).

3.3.4 STS Event log

Click in the “**Event log**” section of the menu.

Network Management Card User Manual

- ▶ **“Save Log”** enables all values saved to be opened or saved in CSV format (compatible with Excel type spreadsheets).
- ▶ **“Clear Log”** enables deletion of all records. The administrator must enter his/her login / password to validate this action.

Event Log index page



- [From 2010/02/08 10:28:08](#)
- [From 2010/02/05 12:49:10 To 2010/02/08 10:28:08](#)
- [From 2010/02/05 11:28:17 To 2010/02/05 11:28:45](#)
- [From 2010/02/04 10:14:52 To 2010/02/04 15:17:23](#)
- [From 2010/02/02 16:55:36 To 2010/02/02 16:56:00](#)
- [From 2010/02/02 16:46:54 To 2010/02/02 16:47:17](#)
- [From 2010/02/02 16:29:42 To 2010/02/02 16:30:05](#)

Select the time range to view:

Network Management Card

User Manual

Event Log data

Upsilon STS 250 A

Date (yyyy/mm/dd)	Time (hh:mm:ss)	Event Description
2010/02/05	12:49:10	Source 1 circuit breaker (Q1) closed
2010/02/05	12:49:10	Source 2 circuit breaker (Q2) closed
2010/02/05	12:49:10	Output circuit breaker (Q3) closed
2010/02/05	12:49:11	Source 1 active
2010/02/05	12:49:33	Source 1 preferred
2010/02/05	12:49:33	Transfer available
2010/02/05	14:55:55	Source 2 active
2010/02/05	14:56:17	Source 1 voltage fault
2010/02/05	14:56:17	Source 1 frequency fault
2010/02/05	14:56:17	Transfer forbidden
2010/02/05	14:56:17	Sources out of synchronization
2010/02/05	14:56:27	Source 1 active
2010/02/05	14:56:50	Transfer available
2010/02/08	10:27:46	Source 2 active
2010/02/08	10:28:08	Source 1 voltage fault
2010/02/08	10:28:08	Transfer forbidden

See the table of events generated in the [STS event table](#).

3.3.5 System log

Click in the **“System log”** section in the menu.

- ▶ **“Save”** enables all values saved to be opened or saved in CSV format (compatible with Excel type spreadsheets).
- ▶ **“Clear”** enables deletion of all records. The administrator must enter his/her login / password to validate this action.

Network Management Card

User Manual

System Log index page

GALAXY 5000 60 kVA [Help](#)

Save Log

Clear Log

- [From 2010/01/25 14:55:36](#)

Select the time range to view:

System Log data

GALAXY 5000 60 kVA

Date (yyyy/mm/dd)	Time (hh:mm:ss)	Event Description
2010/01/25	14:55:31	Agent event log cleared
2010/01/25	14:55:36	Environment log cleared

See the table of events generated in the [System Alarm Table](#).

Network Management Card

User Manual

3.4 Notification

3.4.1 UPS Email Notification

The card offers the possibility of redirecting UPS alarms to an e-mail server. The format of these e-mails is compatible with mobile telephone transfer systems using text messages (SMS).

Email Notification

Evolution 500
[Help](#)

Notified events	Recipient list
Battery operation	
Utility failure <input type="checkbox"/>	admin1@domain.com
Utility restored <input type="checkbox"/>	recipient2@domain.com
UPS Off sequence in progress <input checked="" type="checkbox"/>	recipient3@domain.com
Low battery <input type="checkbox"/>	recipient4@domain.com
UPS alarms	
Battery fault <input type="checkbox"/>	Recipient : <input type="text" value="admin1@domain.com"/>
Battery OK <input type="checkbox"/>	<input type="button" value="Enabled"/> ▾
UPS overload <input type="checkbox"/>	Attached files : <input checked="" type="checkbox"/> Measurements
UPS returns to normal load <input type="checkbox"/>	<input type="checkbox"/> Event log
UPS fault <input checked="" type="checkbox"/>	<input type="checkbox"/> System log
UPS OK <input type="checkbox"/>	<input type="checkbox"/> Environment log
UPS communication failed <input type="checkbox"/>	Periodic report : every <input type="text" value="0"/> day(s) at <input type="text" value="-"/> ▾
UPS communication restored <input type="checkbox"/>	Day of next report : <input type="text" value="-"/> ▾
UPS battery charger is not active <input type="checkbox"/>	<input type="button" value="Test"/> <input type="button" value="Save changes"/>
Output on bypass <input type="checkbox"/>	Email Message Settings
Bypass : Return on UPS <input type="checkbox"/>	Configure SMTP Server on Network Settings
Software alarms	
Firmware upgrade <input type="checkbox"/>	
Environment sensor communication failed <input type="checkbox"/>	
Environment alarms	
Configured on Environment Settings	
Environment sensor notification <input type="checkbox"/>	
<input checked="" type="checkbox"/> Show advanced events <input type="button" value="Set default"/>	

► **Notified events:**

The left side of the page shows the events that can be notified.

By default, only the main events of battery operation and a few UPS alarms are accessible. All the events appear if the **Show advanced events** option is ticked off.

By default, two events are selected for notification. The user can modify this pre-selection by ticking other events or can, on the contrary, restore the initial configuration by clicking on **By default**.

► **Environment alarms:** (accessible when **Show advanced events** option is ticked off)

Network Management Card

User Manual

Environment alarms must be selected to activate e-mail notification of events concerning the Environment Sensor. The detail of notified events is accessed via the [Configure Environment](#) link.

► Recipient List:

On the right side of this page, up to four recipients can be configured to receive e-mails from the card. Each addressee has its own trigger events, selected from the left side of the page, for which an e-mail is sent. The card's log indicates e-mail transmission errors.

Each recipient is configured with the following parameters:

Recipient: this is the e-mail address of the person or department to receive the e-mail. The default value is *recipientx@domain.com*.

Attached files: The files selected (UPS measurements, Event log, System log or Environment measurements) are enclosed with each e-mail sent. The files are sent in CSV format.

Periodic report: In addition to the e-mails sent when events occur, a periodical e-mail containing the 4 log files can be sent to the recipient every x days at the time specified by the user.

To configure the first transmission, specify the day, time and frequency of the next transmission in the **Day of next report** box. After this date, the page will show the date and time of the next transmission. Data are sent in CSV format.

Save: Saves any modifications.

Test: enables an e-mail to be sent to the recipient immediately. This is one way of checking e-mail transmission, particularly access to the SMTP server configured in "Network settings". A transmission report is added to the system log. In the event of failure, the card will repeat the transmission 3 times, at one minute intervals, before producing a transmission report.

The event label in the subject and text of the message is replaced with a test label.

If the user makes any modifications to the page, they must be saved before using the "Test" function.

E-mail message configuration: [see next page](#)

Network settings: enables the name of the SMTP server to be entered. See "[Network settings](#)"

Security: The administrator has to click on **Save** and enter his login/password to save any modifications. The default login and password are: **MGEUPS**

Network Management Card

User Manual

3.4.2 STS Email Notification

The card offers the possibility of redirecting STS alarms to an e-mail server. The format of these e-mails is compatible with mobile telephone transfer systems using text messages (SMS).

Email Notification

Upsilon STS
[Help](#)

Notified events	Recipient list	
STS status		
Communication failure <input type="checkbox"/>	<div style="background-color: #e0e0e0; padding: 2px;">recipient1@domain.com</div> recipient2@domain.com recipient3@domain.com recipient4@domain.com	
Communication restored <input type="checkbox"/>		
STS alarms		
Output circuit breaker (Q3) open <input type="checkbox"/>		
Source 1 bypass (Q1BP) close <input type="checkbox"/>	Recipient: <input type="text" value="recipient1@domain.com"/>	
Source 2 bypass (Q2BP) close <input type="checkbox"/>	<input type="button" value="Disabled"/>	
Output not powered <input checked="" type="checkbox"/>	Attached files: <input type="checkbox"/> Measurements	
Load powered <input type="checkbox"/>	<input type="checkbox"/> Event Log	
No Output overload <input type="checkbox"/>	<input type="checkbox"/> System log	
Output overload <input type="checkbox"/>	<input type="checkbox"/> Environment log	
No Output thermal overload <input type="checkbox"/>	Periodic report: every <input type="text" value="0"/> day(s) at <input type="text" value="-"/>	
Output thermal overload <input type="checkbox"/>	Day of next report: <input type="text" value="-"/>	
No STS general alarm <input type="checkbox"/>	<input type="button" value="Test"/> <input type="button" value="Save changes"/>	
STS general alarm <input checked="" type="checkbox"/>	Email Message Settings	
No STS thermal fault <input type="checkbox"/>	Configure SMTP Server on Network Settings	
STS thermal fault <input type="checkbox"/>		
Software alarms		
Firmware upgrade <input type="checkbox"/>		
Environment sensor communication failed/restored <input type="checkbox"/>		
Environment alarms		
Configured on Environment Settings		
Environment sensor notification <input type="checkbox"/>		
<input type="button" value="Set default"/>		

► **Notified events:**

The left side of the page shows the events that can be notified.

By default, only the events Output not powered and the STS general alarm are selected.

The user can modify this pre-selection by ticking other events or can, on the contrary, restore the initial configuration by clicking on **By default**.

- **Environment alarms** must be selected to activate e-mail notification of events concerning the Environment Sensor. The detail of notified events is accessed via the [Configure Environment](#) link.

► **Other settings:**

See UPS Email notification

Network Management Card

User Manual

3.4.3 Email Message Settings

This page enables customisation of the content of the messages received by recipients of e-mails sent by the card.

Customisation is common to the four recipients that can be notified (see [E-mail notification](#)).

3.4.3.1 UPS Email Message Settings

Email Message Settings

Galaxy PW Single//
[Help](#)

These settings are common for all the recipients, which can be notified by E-mail.

Sender:

Subject:

Schneider Electric
 UPS / STS Name
 UPS / STS Location
 Event message

Message text:

Sender

(32 characters maximum) identifies the source of the message. The default value is *ups@domain.com*. This field is free. However, depending on the type of SMTP server configuration, it is possible that the server checks that the domain name contained in the From address exists, and even that the user in the From address belongs to this domain.

Subject

enables the user to specify the subject of the e-mail to be sent. By entering some free text and selecting from several optional fields, if desired, the message subject is built:

- **UPS / STS name** recalls the name of the UPS, can be selected or not.
- **UPS / STS location** recalls the geographic location of the UPS (see System Settings), can be selected or not.
- **Event message** identifies the event generating the e-mail, can be selected or not.

Network Management Card

User Manual

- **Message text** is a free zone.
The body of the e-mail sent is composed of:
 - **Message text**, which is free text.
 - the date and time of the event, as saved in the log.
 - URL of the card, enabling a direct link with the card to be established.
 - Attachments, as configured for the e-mail recipients .- duplication of the subject, as configured.

3.4.3.2 STS Email Message Settings

Email Message Settings

MGE Upsilon STS 250 A [Help](#)

These settings are common for all the recipients, which can be notified by E-mail.

Sender :

Subject :

UPS / STS Name
 UPS / STS Location
 Event message

Message text :

Detail settings : see UPS Email setting

Network Management Card

User Manual

3.4.4 Email Example



<sts@domain.com>

19/02/2010 17:07

A recipient2@domain.com
cc
Objet Schneider Electric - Check mail

Schneider Electric - Check mail
Date (yyyy/mm/dd):2010/02/19 Time (hh:mm:ss):17:07:37
<http://10.216.134.48>



MEASUREMENTS_2010021917.CSV EVENT_2010021917.CSV SYSTEM_2010021917.CSV ENVIRONMENT_2010021917.CSV

Network Management Card

User Manual

3.5 Configuration

The parameters of this menu can only be modified after entering the “User Name” and “Password”. The following screen is proposed automatically:



User Name and password by default are: MGEUPS

Each field accepts up to 10 characters max.

After entering the login and password, these identifiers remain active as long as the browser is open, so you only have to enter them once.

If the browser is closed, they will have to be re-entered.

Tick the “Save this password in your password list” box if you want to avoid systematic re-entry.

An error in either field results in systematic rejection of the requested action (save, page access, card reboot, etc.). After three unsuccessful attempts, the browser must be rebooted.

These two fields do not travel “decoded” on the IT network, they are encrypted with an MD5 type algorithm, ensuring total confidentiality.

Network Management Card

User Manual

3.5.1 Network Settings

Click on the “**Network**” section in the menu.

This menu enables the administrator to configure the network parameters of the card and authorisation of the remote upgrade of the embedded system.

Network Settings

Upsilon STS		Help
IP Address :	<input type="text" value="123.49.134.84"/>	
Subnet Mask :	<input type="text" value="255.255.254.0"/>	
Gateway Address :	<input type="text" value="123.49.134.1"/>	
<hr/>		
Hostname :	<input type="text" value="ups6F2C"/>	
Domain Name :	<input type="text" value="ups.domain.com"/>	
<hr/>		
Telnet Connection :	<input type="text" value="Enabled"/>	
BootP/DHCP :	<input type="text" value="Enabled"/>	
Network Upgrade :	<input type="text" value="Enabled"/>	
<hr/>		
Primary DNS Server :	<input type="text" value="123.49.129.94"/>	
Secondary DNS Server :	<input type="text" value="123.49.129.95"/>	
<hr/>		
SMTP Server (for Email Notification) :	<input type="text" value="smtpserver.domain.com"/>	
<hr/>		
Authentication :	<input type="checkbox"/>	
<input type="button" value="Save changes"/>		

- **IP address:** The IP address of the card (e.g.: 123.49.134.36).
- **Subnet Mask:** The mask of the sub-network of your network (e.g.: 255.255.254.0).
- **Gateway Address:** Indicate the IP address of the gateway to access the stations located outside the card's sub-network (e.g.: 123.49.134.1).
- **Hostname** must be suited to the card. This is the first part of the full qualified domain name, used by the DNS (name must be compatible with DNS rules)

Network Management Card

User Manual

- ▶ **Domain name** is the domain to which the card belongs. This is the part of the full qualified domain name that follows the host name and is used by the DNS. The default value of the two parameters comprising the full qualified domain name: *ups.domain.com*

- ▶ **TELNET connection:** Authorises (choose enable) remote connection with a terminal to access the maintenance menu.

See "[Configuration in local mode and via Telnet](#)" for more information

- ▶ **BootP/DHCP:** Authorises (choose enable) configuration of network parameters with your BootP/DHCP server when the card is booted

Mode of card operation with server: after any reboot, if this option is enabled, the card tries to recover the network parameters from the server for 10 sec. If no response is received from the server, the card boots with the last saved parameters from the previous start. These parameters are those shown on the page
The default value for this parameter is "Enable"

. **Note:**

The IP address supplied by the DHCP server must be fixed to maintain connection with the clients installed on the stations to be protected.

- ▶ **Network Upgrade:** Authorises (choose enable) remote upgrading of the embedded system on the card using the Mupgrade tool. Read the "[Maintenance](#)" section for more details.

- ▶ **Primary DNS server:** contains the IP address of the main DNS server ensuring conversion of the domain name to IP address.

- ▶ **Secondary DNS server:** contains the IP address of the secondary DNS server ensuring conversion of the domain name to IP address if the primary DNS server is not available.

- ▶ **SMTP server:** contains the name or IP address of the local server with which the card connects to send e-mails.

It may be filled in either as host + domain name (DNS resolution), or directly with the IP address

The default value is *smtpserver.domain.com* . The card uses port 25 to send e-mails.

- ▶ The **Authentication** option must be selected if the SMPT server requires this parameter for query submission (see the RFC 2554 for SMTP authentication) for commercial reasons, access control, etc.
When authentication is selected, the **User** and **Password** parameters must be specified for identification with the local SMTP server.

Default values are *MGEUPS/MGEUPS*.

Note: The card must be rebooted after any changes to these parameters. See "[System](#)"

Security: the administrator must click on **Save** and enter his login/password to save any modifications.

Network Management Card

User Manual

3.5.2 System

Click the “**System**” section in the menu.

This menu enables the customisation of the information on the [UPS properties](#) / [STS properties](#) and [Environment](#) pages.

System Settings

Galaxy PW Single/		Help
UPS / STS Contact :	<input type="text" value="Computer Room Manager"/>	
UPS / STS Location :	<input type="text" value="Computer Room"/>	
History Log Interval (Sec) :	<input type="text" value="60"/>	
Refresh Rate (Sec) :	<input type="text" value="10"/>	
Default Language :	<input type="text" value="English"/> ▾	
Environment Log Interval (Sec) :	<input type="text" value="300"/>	
Environment Refresh Rate (Sec) :	<input type="text" value="60"/>	
Environment Input grace period (Sec) :	<input type="text" value="1"/>	
<input type="button" value="Save changes"/>		
<input type="button" value="Reset Communication"/>		
<input type="checkbox"/> Keep TCP/IP parameters	<input type="button" value="Factory Reset"/>	

- **UPS contact:** This text field is limited to 32 characters. Enter the name of the person responsible for UPS administration at IT network level and/or electrical maintenance. This field does not appear on any other Web page. By default, its value is “Computer Room Manager”.
- **UPS location:** Enter a description (limited to 32 characters) of the location of the UPS in your installation (e.g. Computer room E1-C066). This text is displayed on the home page at the top right, above the name of the UPS. Its value by default is “Computer room”.
- **History Log interval:** [5 to 99999 seconds]. Measurement save period. Default value = 60 sec.
- **Refresh rate:** [5 to 99999 seconds]. Home page and alarms table refresh period. Default value = 10 sec.
- **Default language:** Enables initialisation of the browser language at card connection.

Auto: Automatically displays the Web page texts in the same language as your browser. If the Network Management Card is not able to display the recognised language, the pages will be displayed in English.

Network Management Card

User Manual

Choice of one of the available languages: **English, French, Italian, German, Spanish** changes the language of the html interface pages

▶ **Note:**

Alarm notification remains in English / French (reboot the browser after modification).

SNMP message remain in English.

- ▶ **Environment log interval:** [from 5 to 99999 sec]. Temperature and humidity measurement save period. Default value = 300 sec. (only visible if the sensor is present).
- ▶ **Environment refresh rate:** [from 5 to 99999 sec]. “**Environment status**” page refresh rate. Default value = 60 sec. (only visible if the sensor is present).
- ▶ **Environment input grace period :** [from 0 to 9 sec]. Period during which a status change by one of the inputs is not considered. Default value = 1 sec. (only visible if the sensor is present).
- ▶ **“Reset communication” button:** performs a remote reboot of the card without modifying the configuration. This action is compulsory for consideration of any changes made on [the “Network settings”](#) page. Security of this operation is ensured by requesting Login and Password.
- ▶ **“Factory Reset” button:** enables restoration of the default configuration of all the card’s parameters. The TCP/IP parameters: IP address, subnet mask, gateway and BootP/DHCP value are maintained if the **“Keep TCP/IP parameters”** option is selected. Security of this operation is ensured by requesting Login and Password. Default login and Password are: **MGEUPS**

Note:

If any of these parameters are changed, the card must be rebooted.

Network Management Card

User Manual

3.5.3 UPS Notified Applications

Click the **“Notified Application”** section in the menu.

Security: the administrator has to enter his login/password to view this information.

This menu enables:

- ▶ The addition of the supervision stations receiving traps and configuration of the trap type.
- ▶ To list all the Notified Applications and the main parameters.
- ▶ Simulate events to test notification and shutdown of the Notified Applications.

Up to 50 destinations can be managed by the card.

The card is compatible with the **Network Shutdown Module**

Note: It is not necessary to add the **Network Shutdown Modules** protecting your servers in this list as it is done automatically.

Notified Applications

GALAXY 5000 60 KVA [Help](#)

All	Nr	Hostname or IP Address	Application Name	Output	Configuration	Shutdown Duration (sec)	Shutdown After (min)
<input type="checkbox"/>	1	10.216.134.30	Trap				
<input type="checkbox"/>	2	WXFRAPCMGE0115D	Shutdown Module V3.05	Master	Central	120	

Select the applications to be removed.

Select the applications to be tested.

Select the Network Management System to be modified.

Select an entry in the list to modify the values in the edit zone at the bottom of the page. Note that the Network Shutdown Module must not be manually modified.

The applications in the table appears in the order they have subscribed to the card. Following informations are displayed :

- ▶ **Nr** : is the index where the application is stored into the table.
- ▶ **Hostname or IP Address** : By priority the hostname of the computer is displayed when the IP address can be converted into a hostname with a DNS server or if the application has been entered as a hostname (see page Network Management System settings). Otherwise the IP address is displayed.
- ▶ **Application Name** : sent by the application at subscribe time or manually entered.
- ▶ **Output** : is the number of the output from which the client is powered.
- ▶ **Configuration** : shows where the parameters of Network Shutdown Module comes from : **Local**(coming from the application) or **Central**(coming from the card).
- ▶ The Central Shutdown Configuration is available by clicking on Configuration link.
- ▶ **Shutdown duration** : is the shutdown duration necessary to properly shutdown the computer.

Network Management Card

User Manual

- ▶ **Shutdown after** : is the time available to the user from the Power failure until the launch of the shutoff sequence of the UPS. This parameter is optionnal.

Many actions are available on this page :

- ▶ **Remove** : Depending on the kind of application, the selected ones will definitively disappear from the table as SNMP applications, or they will disappear and automatically re-subscribe as the Network Shutdown Module application.
- ▶ **Utility failure Test** : Two alarms 'Utility failure' and 'Utility restored' spaced of 60 seconds will be sent to the applications selected, making sure that the applications can be reached over the network.
- ▶ **Shutdown Test** : This test simulates a UPS on battery operation, it sends alarms to the selected applications. It enables an easy check to see if the server protection works correctly.- No intervention on the UPS is required.
 - Simulated alarms will be processed by the applications selected only.
 - Warning :This test will generate a REAL shutdown sequence of servers on which Network Shutdown Module is running.


Add NMS allows to add a SNMP trap receiver as a Network Management System.

Modify NMS allows to modify a SNMP trap receiver.

Both buttons makes appear a new window where it is possible to enter the Application name, the Hostname or IP Address, the Trap community and the severity.

Network Management Card

User Manual



Network Management System Settings

GALAXY 5000 60 kVA

Nr : 1

Application Name :

Hostname or IP Address :

Protocol : SNMP V1

Trap Community :

Severity :

- ▶ **Trap community** indicates the name of the SNMP community

For more details, read the MIB description document: available on the www.apc.com site.

3.5.4 Central Shutdown Configuration

Click the **“Notified Application”** section in the menu then in **“Configuration”**.

Network Management Card

User Manual

Central Shutdown Configuration

GALAXY 5000 60 KVA

[Help](#)

This configuration will be used by the Network Shutdown Modules, on next connection.

Shutdown Parameters :

Shutdown After : min **Shutdown Duration :** sec

Broadcast :

Administrators

Users

This page is used to define either the shutdown or the notification settings used by the Network Shutdown Modules that connect to Network Management Card. These settings are used by the Network Shutdown Modules if they are in centralized-configuration mode or if their configuration is not valid.

- ▶ **Shutdown After (time before shutdown)** This is the time in seconds that the system waits following failure of AC power before initiating the system-shutdown procedure. This value must be selected to provide users with enough time to close their applications and disconnect, but within the battery backup time provided by the UPS.
 If another criterion occurs before the end of the shutdown timer, the shutdown procedure is immediately run.
 This parameter is optional, uncheck it to invalidate
- ▶ **Shutdown Duration :** This is the time in seconds required by the system to go through its shutdown procedure.
- ▶ **Broadcast :** Send network notifications to the Administrators and Users groups on events

If you wish to set up a new configuration for the Network Shutdown Modules already set to centralized-configuration mode, proceed as indicated below.

- ▶ Change the Network Shutdown Module parameters in the page “Central Shutdown Configuration”.
- ▶ Click the **Save** button. Open the List of notified applications.

Select the Network Shutdown Modules to receive the new configuration.

Press the button “**Remove**” They reconnect and use the new configuration

3.5.5 STS Notified Applications

Click the “**Notified Application**” section in the menu.


Security: the administrator has to enter his login/password to view this information.

This menu enables:

- ▶ The addition of the supervision stations receiving traps and configuration of the trap type.
 - ▶ To list all the Notified Applications and the main parameters.
 - ▶ Simulate events to test notification and shutdown of the Notified Applications.
- Up to 50 destinations can be managed by the card.

Network Management Card

User Manual



Notified Applications

Upsilon STS [Help](#)

All	Nr	Hostname or IP Address	Application Name
<input type="checkbox"/>	1	10.216.135.194	Gmz computer

Select the applications to be removed.

Select the applications to be tested.

Select the Network Management System to be modified.

Select an entry in the list to modify the values in the edit zone at the bottom of the page. Note that the Network Shutdown Module must not be manually modified. The applications in the table appears in the order they have subscribed to the card. Following informations are displayed :

- **Nr** : is the index where the application is stored into the table.
- **Hostname or IP Address** : By priority the hostname of the computer is displayed when the IP address can be converted into a hostname with a DNS server or if the application has been entered as a hostname (see page Network Management System settings). Otherwise the IP address is displayed.
- **Application Name** : sent by the application at subscribe time or manually entered.

Many actions are available on this page :

- **Remove** : Depending on the kind of application, the selected ones will definitively disappear from the table as SNMP applications, or they will disappear and automatically re-subscribe as the Network Shutdown Module application.
- **STS general alarm Test** : This test simulates alarm 'STS general alarm' , making sure that the applications can be reached over the network.
-


Add NMS allows to add a SNMP trap receiver as a Network Management System.

Modify NMS allows to modify a SNMP trap receiver.

Both buttons makes appear a new window where it is possible to enter the Application name, the Hostname or IP Address, the Trap community and the severity.

Network Management Card

User Manual



Network Management System Settings

Upsilon STS

Nr : 1

Application Name : Gmz computer

Hostname or IP Address : 10.216.135.194

Protocol : SNMP V1

Trap Community : public

Severity : 2 - Severe

Cancel Save changes

▶ **Trap community** indicates the name of the SNMP community

For more details, read the MIB description document: available on the www.apc.com site.

3.5.6 Access control

Click the **“Access control”** section in the menu.

To access this page, the login and password are systematically requested if they have not already been entered.

This menu enables configuration of the different parameters enabling secure access to the card via a browser or SNMP.

Network Management Card

User Manual

Access Control

GALAXY 5000 60 KVA
Help

Enter New Manager Login :

Enter New Password :

Confirm New Password :

SNMP Access Control

Current community Read-Only is :

Change Community Read-Only :

Current community Read/Write is :

Change Community Read/Write :

Change Trap Port Number :

SSL Activation

Authentication for All Html Pages

- **Enter New Manager Login:** Text field limited to 10 characters. Enables secure access and modification of pages. Default value "MGEUPS".
- **Enter New Password:** Text field limited to 10 characters. Enables secure access to the sections of the Configuration menu. Default value "MGEUPS".
- **Confirm New Password:** Text field limited to 10 characters. Must be strictly identical (including upper/lower case) to the field above .
- **SNMP Access Control:** permits to limit or disable SNMP access.
 - **Read / Write:** All SNMP operations are allowed
 - **Read only:** only read operations can be done. . When selecting this mode,
 - **Disable:** Card doesn't manage SNMP
- **Current Community Read-only is:** Enables read-only SNMP access control (GET). Default value "public".

Network Management Card

User Manual

- ▶ **Change Community Read-only:** Text field limited to 31 characters. This field is only validated after clicking on “**Save**”. Default value “public”.
- ▶ **Current Community Read/Write is:** Enables read and write SNMP access control (GET and SET). Default value “public”.
- ▶ **Change Community Read/Write:** Text field limited to 31 characters. This field is only validated after clicking on “**Save**”. Default value “public”.
- ▶ **Change Trap Port Number:** Numeric field limited to 65534. Enables forwarding of traps sent by the card to a port other than the port usually used for SNMP. Default value 162.
- ▶ **SSL Activation:** When selected, access to Web interface is made in secure mode (https). **Telnet access is disabled and the card is accessible in SSH.**

Connections with Network Shutdown Modules stay in standard mode (secure TCP)

SSL Security Implementation

SSL → version 3.0
 Method → TLS_RSA_WITH_RC4_128_MD5
 Auth → RSA
 Key Exchange → RSA
 Encryption → RC4_128
 Digest → MD5

SSH Security Implementation

SSH v1
 Method ==> SSH_CIPHER_3DES
 Encryption ==> Triple_DES in CBC mode
 This change takes effect after a card reboot.

- ▶ **Authentication for all html pages :** Login/password Authentication is required for all pages.

Network Management Card

User Manual

3.5.7 Time

Click the **“Time”** section in the menu.

This menu enables initialisation of the date and time of the card in three different ways.

Setting Time

GALAXY 5000 60 kVA
[Help](#)

Current Date and Time

(yyyy/mm/dd) (hh:mm:ss)

Date: Time:

Setting Time

Set manually

(yyyy/mm/dd) (hh:mm:ss)

Date: Time:

Synchronize with computer time

(yyyy/mm/dd) (hh:mm:ss)

Date: Time:

Synchronize with SNTP Server

Name or IP Address:

Time Zone:

Manual Daylight Saving Time (add 1 Hour)

- ▶ **Synchronise manually:** Enables initialisation of the date and time of the card, with the values entered in the Date and Time fields. Values are updated after clicking the **“Save”** button.
- ▶ **Synchronise with computer time:** Enables the date and time of your PC to be transferred to the card. This transfer is made after clicking on the **“Save”** button. Time is not adjusted regularly, it is set **one time** after clicking the **“Save”** button.
- ▶ **Synchronise with an NTP server:** Enables connection with a time server, either available on the company’s internal network or on the Web. This server communicates GMT time. The IP address of the time server must be entered, and the time zone of your geographic area must then be selected from the

Network Management Card

User Manual

list. Connection is made with the server and the date and time are set after clicking on the “**Save**” button.
Time is updated every hour.

The card uses the NTP protocol (UDP 123 port) and the firewall must be set accordingly, no error message is generated if the time server contact fails

- ▶ **Daylight Saving Time:** Enables corrections due to summer / winter time changes, this option must be supported by the NTP server.

Note 1:

Time drift is related to card electronics. It may be up to a maximum of +/- 2min/month.

3.6 Environment

The environment sensor is an option that enables temperature and humidity to be measured, and indication of the position of two external contacts. It is connected with a standard network cable to the **Card Settings** port of the Network Management Card.

On startup, the card automatically detects sensor presence. The main menu then displays an additional section “**Environment**” with the following elements:

- ▶ **Status**
- ▶ **Configuration**
- ▶ **Log**

Note 1 This function is only accessible with the DA version software (or superior) for the card. This software can be downloaded on the www.apc.com site, from the [download](#) section.

Note 2: To switch the serial port to the configuration mode, just disconnect the sensor cable and reinitialise the card by pressing “Reset”. The reverse operation must be performed to manage the environment sensor once again.

3.6.1 Characteristics

- ▶ Temperature measurement from 0 to 70 °C with +/- 1° C accuracy
- ▶ Humidity measurement from 0 to 100 % with +/- 6 % accuracy
- ▶ Min. / max. time-stamped function for temperature and humidity
- ▶ Choice of displaying temperature in Celsius or Fahrenheit
- ▶ High and low thresholds, hysteresis and offset adjustment via Web interface
- ▶ Possibility of notification of status changes by e-mail, SMS or SNMP trap
- ▶ Position detection of 2 dry contacts (maximum sensor/contact distance: 20m)


Network Management Card

User Manual

- ▶ Name and status of each contact can be configured
- ▶ Recording of events and measurements in the card log
- ▶ Possibility of shutting down the installation safely if one of the thresholds is exceeded or if a dry contact closes
- ▶ Connection to the Network Management Card by CAT5 straight RJ45 network cables (maximum card/sensor distance: 20m)

3.6.2 Environment status

Environment Status



For both measurements, a graduated gauge proposes the following functions:

The cursor indicates the current value.

Two red zones to the left and right represent the high and low thresholds that can be set on the [Environment Settings](#) page.

When the measured value enters one of these zones, a alarm can be notified (see **Notification** parameter in the [Environment Settings](#) page).

Time-stamped minimum and maximum temperatures show the extreme values recorded since the last **Reset Min/Max**, a thin dotted line shows their positions on the gauge.

Min and Max can be forced at any time to the current value by clicking on the **Reset Min/Max** button.

Calibrate: the sensor is calibrated in the factory, but the user can apply an offset to adjust the measurement.

Input # 1 and **Input # 2** show the position of the two contacts acquired by the sensor.

The position is displayed with the parameters entered in the [Environment Settings](#) page.

Network Management Card

User Manual

The last status change of each contact is time-stamped.

The Internet browser updates this page regularly according to the **Environment refresh rate** parameter on the [System settings](#) page.

Network Management Card

User Manual

3.6.3 UPS Environment Settings

3.6.3.1 UPS Environment Settings

Environment Settings

GALAXY 5000 60 kVA [Help](#)

Sensor name:		Environment sensor	Notification	System Shutdown	
Temperature	High threshold:	<input type="text" value="40"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
	<input type="button" value="°C"/> <input type="button" value="°F"/>	Low threshold:	<input type="text" value="5"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
	Hysteresis:	<input type="text" value="2"/>			
Humidity	High threshold:	<input type="text" value="90"/> %	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
	Low threshold:	<input type="text" value="10"/> %	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
	Hysteresis:	<input type="text" value="5"/> %			
Input #1:	<input type="text" value="Input #1"/>	<input type="text" value="closed"/> when closed	<input type="checkbox"/>	<input type="checkbox"/>	
		<input type="text" value="open"/> when open	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Input #2:	<input type="text" value="Input #2"/>	<input type="text" value="closed"/> when closed	<input type="checkbox"/>	<input type="checkbox"/>	
		<input type="text" value="open"/> when open	<input checked="" type="checkbox"/>	<input type="checkbox"/>	

Show advanced parameters

The environment sensor measures temperature, humidity and gives the status of the 2 contacts (used for door, alarms or generator unit).

The temperature and humidity thresholds can be adjusted and can trigger notification and correct shutdown of the protected system.

The **Sensor name** is the function name given to the sensor, usually it enables location of the sensor.

Temperature: choose the temperature unit (°C or °F) from the selection box.

High threshold: if this value is exceeded, a **notification** is sent if this is validated. Default value is 40 °C / 104 °F.

Low threshold: if this value is exceeded, a **notification** is sent if this is validated. Default value is 5 °C / 41 °F.

Hysteresis must be set to prevent multiple notifications if temperature fluctuates around a threshold. Default value is 2 °C / 3.6 °F. (Advanced parameters)

Network Management Card

User Manual

The high alarm cannot be reactivated while temperature remains above the **High threshold – Hysteresis** value.

The low alarm cannot be reactivated while temperature remains below **Low threshold + hysteresis** value.

Humidity

High threshold: if this value is exceeded, a **notification** is sent if enabled. Default value is 90%.

Low threshold: if this value is exceeded, a **notification** is sent if enabled. Default value is 5%.

Hysteresis must be set to prevent multiple notifications if humidity fluctuates around a threshold. Default value is 5%. (Advanced parameters)

The high alarm cannot be reactivated while humidity remains above the **High threshold – Hysteresis** value.

The low alarm cannot be reactivated while humidity remains below **Low threshold + hysteresis** value.

Input No 1 and **Input No 2:** enter an identifier corresponding to the acquired contact (e.g.: rack door, air conditioning, generator unit, etc.). Max. length is 28 characters.

If contact closed and **if contact open:** are the names associated to the two contact positions. (e.g.: "open" and "closed" for a door, "On" and "Off" for a generator).

Each status change triggers a **notification** if enabled.

Notification includes: Log, Notification by e-mail and generation of SNMP Trap. The list of messages is given in the [appendix](#).

System shutdown can be triggered for each notification if this option is enabled. If notification is disabled, the Shutdown option cannot be used. (Advanced parameters)

Security: the administrator has to click on Save and enter his login/password to save any modifications.

3.6.3.2 STS Environment Settings

Network Management Card

User Manual



- ▶ **STS**
 - [STS Properties](#)
 - [3-Phase Display](#)
 - [Alarm Table](#)
- ▶ **Logs and Notification**
 - [Measurements](#)
 - [Event Log](#)
 - [System log](#)
 - [Email Notification](#)
- ▶ **Settings**
 - [Network](#)
 - [System](#)
 - [Notified Applications](#)
 - [Access Control](#)
 - [Time](#)
- ▶ **Environment**
 - [Status](#)
 - [Settings](#)
 - [Log](#)

Environment Settings

MGE Upsilon STS 250 A [Help](#)

Sensor name:		Environment sensor		Notification	
Temperature	High threshold:	<input type="text" value="40"/>		<input type="checkbox"/>	
	°C ▾	Low threshold:	<input type="text" value="5"/>	<input type="checkbox"/>	
		Hysteresis:	<input type="text" value="2"/>		
Humidity	High threshold:	<input type="text" value="90"/>	%	<input type="checkbox"/>	
		Low threshold:	<input type="text" value="5"/>	%	<input type="checkbox"/>
		Hysteresis:	<input type="text" value="5"/>	%	
Input #1:	<input type="text" value="Input #1"/>	<input type="text" value="closed"/>	when closed	<input type="checkbox"/>	
		<input type="text" value="open"/>	when open	<input type="checkbox"/>	
Input #2:	<input type="text" value="Input #2"/>	<input type="text" value="closed"/>	when closed	<input type="checkbox"/>	
		<input type="text" value="open"/>	when open	<input type="checkbox"/>	

Same feature than for UPS, without the system shutdown only available for UPS. For detail see the UPS environment settings.

3.6.4 Log

Environment log

GALAXY 5000 60 kVA

Log Date (yyyy/mm/dd)	Log Time (hh:mm:ss)	Temperature (°C)	Humidity (%)
2010/01/25	16:15:00	21.8	26
2010/01/25	16:20:00	21.8	26
2010/01/25	16:25:00	21.8	26

The environment sensor's two measurements, Temperature and Humidity, are recorded at an interval defined by the **Environment log interval** parameter on the [System settings](#) page.

By default, this period is 300 seconds.

Each measurement is dated and stored in the log of the UPS' communication card.

The size of log files is limited by a time indexing system.

The user can **Save** the log on his workstation at any time, in a CSV format file.

He can also **Clear** the files contained in the card to reset the log.

Network Management Card User Manual

4 Servers protection, UPS only

4.1 Set-up of the shutdown parameters

The Network Shutdown Module, on protected server boot, subscribes itself automatically to Notified Applications list and sends its essential data:

- ▶ **IP address or name of the server on which it is installed**, to be notified by the card of any power events
- ▶ **Time required to shutdown the server** (Shutdown Duration, configurable in the Shutdown Module “set-up” menu):

The card takes into account the longest shutdown time of all the Network Shutdown Modules subscribed to manage UPS shutdown without affecting any of the servers protected.

In case of a major power event, the Shutdown Module receives messages from the card and regularly checks its accessibility. The most important messages can generate actions and are sent back to the administrator and users via the network.

When the server shuts down, the Shutdown Module unsubscribes itself from the Notified Applications.

4.1.1 Shutdown criteria managed by the Management Card

During an extended power failure, three criteria may cause the server shutdown procedure to be initiated. If several criteria are selected, the first criterion encountered will launch the shutdown procedure. At the end of the shutdown procedure, when all servers have been shut down, the UPS may shut down to avoid unnecessary discharge of its batteries, depending on its configuration.

4.1.1.1 Backup time before initiating the shutdown procedure (Shutdown After)

When the UPS switches to battery, the **Network Management Card** starts the Shutdown Timer countdown and launches the system shutdown procedure at the end of the countdown.

This value must be chosen so that users have time to complete their tasks and disconnect, without exceeding battery backup time.

By default, this value is set to 30 minutes. Since GA release, this criterion is not selected in the default configuration

Note 1:

The Network Shutdown Module can also manages its own Shutdown Timer (configurable in the Shutdown Module “set-up” menu)

Note that if this criterion is selected to initiate system shutdown, automatic system reboot when power is restored is not guaranteed (e.g. power restoration if only this system was shut down).

By default, this parameter is not selected.

4.1.1.2 Initiating the shutdown procedure when the battery level is lower than: (if capacity under)

When the card detects that the remaining backup time percentage is less than the configured level, the shutdown sequence is started.

By default, the card uses the value set in the UPS.

Note:

Certain types of UPS only accept pre-defined minimum battery level values. Check the UPS documentation.

Network Management Card

User Manual

4.1.1.3 Shutdown when backup time is less than

When the Network Management Card detects that the percentage of backup time remaining is less than the value set, the shutdown sequence is started.

4.1.1.4 Shutdown duration

Duration required for the systems protected by the Shutdown Modules to shut down (in seconds).

4.1.2 Specific set-up for long autonomy installation (> 30 mn)

For installation where the backup period is longer than 30 minutes, the Network Management Card will initiate automatically a shutdown at the end of the shutdown timer if this parameter is selected on the "Shutdown parameters" page.

Network Management Card

User Manual

4.2 The different server and UPS shutdown sequences

4.2.1 Extended power outage, shutdown initiated by the Shutdown Timer


During battery backup time, the **Shutdown Timer of the Network Management Card** is reached: after a user-defined backup time period, the shutdown of all servers is initiated, followed by the UPS shutdown (depending on its configuration). The UPS restarts when utility power is restored (depending on its configuration).

- ▶ **Shutdown Duration:** Maximum value of shutdown times of the Network Shutdown Modules subscribed to the card and depending on the main UPS output. This value is updated each time a client subscribes/unsubscribes.

Note: During battery operation, these values are not updated.

Shuts down after the ShutDown Timer + Shutdown Duration after having stopped the servers

Restarts when utility power is restored (possibility of programming a restart delay)



Network Management Card


User Manual

4.2.2 Extended power outage, shutdown initiated by the “Low battery power” message

When the “Low battery power” message is displayed, the UPS is shut off after taking into account the shutdown duration of the servers.

“**Low battery power**”: The message appears if either of the two following criteria is checked:

- Low Battery Level
- Minimum remaining backup time (Low Battery Delay)




Network Management Card

User Manual


4.2.3 Extended power outage, shutdown initiated by the Shutdown Timer, but utility restoration before the end of the Shutdown Duration

If utility power is restored before the end of the Shutdown Duration, the UPS is shut off after the Shutdown Duration for a period equal to the forced reboot time delay



4.2.4 Off/On command

Off/On command is sent from the “UPS control” page
 After a power on, controls are disabled during 120 seconds to allow the server to reboot.



Network Management Card

User Manual

5 Configuring a set of cards with Mupgrade

This feature is particularly useful to configure large UPSs / STSs installed base.

The Remote configuration features of Mupgrade allows you to import, modify and export configuration files from and to Network Management Cards.

Configure all your Network Management Cards in four step :

1. Configure a Network Management Card located on the network through the html interface to create a master configuration..
2. Import this configuration from the master card in Mupgrade.
3. Edit and change some parameters , **select the fields which must be overwritten in the destination cards** and save the new configuration in a file.
4. Export the new configuration to other cards which have **same firmware release** as the master card

Read the relevant documentation available for download on the www.apc.com web site.

6 Configuration in local mode and via Telnet or SSH

6.1 Configuration in local mode

- ▶ Use the cable supplied with the card.
- ▶ Connect the card to a computer equipped with a hyper-terminal type emulator. The serial link should be set at 9600 bauds, 8 bits, no parity, 1 stop bit and no flow control.
- ▶ Check that UPS power is on.
- ▶ A few seconds after terminal opening, press the "**Enter**" button. The menu asks you to enter your password (**MGEUPS** by default), and then press "**Enter**".
- ▶ The card will disconnect itself after 3 minutes of inactivity.
- ▶ The menu is in English only.

```

+=====
+
|   [ MGE UPS SYSTEMS SNMP/Web agent Configuration menu ]   |
+=====
+
Enter Password: *****

+=====
+
|   [ MGE UPS SYSTEMS SNMP/Web agent Configuration menu ]   |
+=====
+
1. Agent Configuration
2. UPS/STS Parameters
3. Access Control Table

```

Network Management Card

User Manual

- 4. Reset Configuration To Default
- 5. Reset Agent
- 0. Exit

Please Enter Your Choice =>

6.1.1 Choice 1: SNMP agent configuration menu

The blue lines are those displayed on screen.

```

=====+
|           [ Agent Configuration Menu ]           |
=====+
  
```

SNMP/Web Agent Version : IAb6 (SN 49ej45007)

Indicates the version level of the software and the serial number of the card.

Ethernet address : 00 E0 D8 0D 6F 2A

MAC address of the card.

Agent BIOS Version : 6.16

Version number of the BIOS.

1. IP Address : 123.49.132.74

To change the IP address of the card, press "1" then "**Enter**". Specify an IP address, then press "**Enter**".

2. Gateway Address : 123.49.132.1

Enter the name of the gateway to be used to communicate with other sub-networks.

3. Network Mask : 255.255.254.0

Enter the mask of the sub-network defining the user group to which the card is connected.

4. sysContact : Computer Room Manager

Enter the name of the person responsible for the UPS.

5. sysName : MGEUPS

Enter a string of characters to identify the UPS.

32 characters maximum

6. sysLocation : Computer Room

Enter a string of characters to identify the installation location of the UPS.

32 characters maximum

7. Community Read-Only : public

Enter the name of the read-only community (by default = public)

31 characters maximum

8. Community Read/Write : public

Enter the name of the read/write community. This name is used by the NSM to subscribe to the table of notified Clients. It is recommended to personalise this name.

Value by default "public".

31 characters maximum

9. HTTP Login Username : MGEUPS

Network Management Card

User Manual

Text field limited to 10 characters. Enables secure access to the sections of the Configuration menu. Default value "MGEUPS".

a. Manager Password : *

Text field limited to 10 characters. Enables secure access to the sections of the Configuration menu. Default value "MGEUPS".

b. BOOTP/DHCP Enabled : Enabled

Authorises the configuration of network parameters with your BootP/DHCP as a startup mode (choose enable).

Card operating mode with the server: after all reboots, the card (if this option is enabled), attempts to recover the network parameters from the server for 10 seconds. If no response is obtained from the server, the card boots with the last parameters saved from the previous start.

0. Return to previous menu

Goes back to the previous menu.

6.1.2 Choice 2: UPS / STS parameters

The blue lines are those displayed on screen.

```

+=====+
| [UPS/STS Parameters Menu] |
+=====+
SNMP/Web Agent Version : IAb6 (SN 49ej45007)
Ethernet address : 00 E0 D8 0D 6F 2A
Agent BIOS Version : 6.16
  
```

1. Log Periodicity : 60

Value between 20 and 99999. Enables initialisation of the save frequency of Measurements, Events and System in the Log menu. Default value = 60 sec.

2. Trap Port Number : 162

Numeric field limited to 65534. Enables forwarding of the traps sent by the card to a port other than the one usually used for SNMP. Default value 162

3. System Date (yyyy/mm/dd) : 2010/01/22

Enables adjustment of the date

4. System Time (hh:mm:ss) : 12:43:21

Enables adjustment of the time

0. Return to previous menu

6.1.3 Choice 3: Access control

```

+=====+
| IP Address Community String Access |
+=====+
[1] 0.0.0.0 public NotAccess
  
```

Network Management Card

User Manual

```
[2] 0.0.0.0    public    NotAccess
[3] 0.0.0.0    public    NotAccess
[4] 0.0.0.0    public    NotAccess
```

COMMANDS -

1. Modify - Modify an entry of table
2. Reset - Reset an entry to default from table
0. Return to previous menu

Please Enter Your Choice =>

This menu enables configuration of access to the four supervision stations (identified by the IP address) with read/write community names different to those already defined in the card "1" menu.

First enter the figure corresponding to the command to be carried out, then the number of the target input. The example below shows how to configure the read/write rights for a station (172.17.1.1) with a community name **MyCom**:

Please Enter Your Choice => 1

Entry Number : 1

Enter IP address : [0.0.0.0] 172.172.1.1

Enter Community String : [public] MyCom

Select Access Type -

[NotAccess]

1. Read
2. Read/Write
3. NotAccess

Please Enter Your Choice => 2

```
=====+
| IP Address   Community String   Access           |
=====+
[1] 172.172.1.1    MyCom           Read/Write
```

6.1.4 Choice 4: Restore default configuration

Use this function to restore the card's factory configuration. Reboot the card so that the network parameter changes are taken into account.

6.1.5 Choice 5: Reset the card

Use this function to reboot the card

Network Management Card

User Manual

6.2 Configuration via Telnet

You can access the configuration menu (see “[configuration in local mode](#)” section) from a station equipped with the Telnet protocol.

As soon as the card is accessible on the network, enter the command:

telnet < card IP address > to access the menu.

The password defined by default is MGEUPS.

The card will disconnect automatically after 3 minutes of inactivity.



6.3 Configuration via SSH

You can access the configuration menu (see “[configuration in local mode](#)” section) from a station equipped with the SSH protocol when https option is selected.

when user connect to NMC by SSH, the screen will hold about 10 seconds for process encryption cipher.

Note : SSH connection is allowed, when SSL Activation is checked in the Access Control Page.
In this case, the telnet connection will be not available.

6.3.1 PuTTY SSH Client Program

PuTTY is a free implementation of Telnet and SSH for Win32 and Unix platforms, along with an xterm terminal emulator. You can get the PuTTY by


<http://www.chiark.greenend.org.uk/~sgtatham/putty/>

Here after, we will show you how to set up PuTTY programme for connecting to NMC card by SSH V1 protocol.


Network Management Card

User Manual

Execute PuTTY and select the following options:.



Select SSH :



Network Management Card User Manual

and Clic on « Open » to start connection



```
10.216.132.73 - PuTTY
login as: MGEUPS
Sent username "MGEUPS"
MGEUPS@10.216.132.73's password:
Access denied
MGEUPS@10.216.132.73's password:

+-----+
| [ MGE UPS SYSTEMS SNMP/Web agent Configuration menu ] |
+-----+
1. Agent Configuration
2. UPS/STS Parameters
3. Access Control Table
4. Reset Configuration To Default
5. Reset Agent
0. Exit

Please Enter Your Choice => █
```


Network Management Card User Manual

7 Maintenance

7.1 Software upgrade

7.1.1 Card firmware upgrade using Mupgrade (Windows)

This feature is particularly useful to upgrade a large UPS installed base in one operation.

Read the relevant documentation available for download on the www.apc.com web site.

7.1.2 Card software upgrade via TFTP (UNIX and Windows)

Upgrading is also possible with TFTP command.

Generic command, with default value, is:

```
tftp -i @IP put nmc_fb.bin upgrade@MGEUPS@MGEUPS
```

Where:

-i indicates binary mode

@IP is the address of the NMC card

nmc_fb.bin is the firmware name

Caution the last parameter **upgrade@MGEUPS@MGEUPS**, represent the default value of **upgrade@password@username**. This parameter is build like an unique word, without any blank character inside.

password value defined in the acces control page

username value defined in the acces control page

Check syntax depending of your operating system

7.1.3 Recovery tool software Msupgrade (Windows) via the serial link

Read the relevant documentation available for download on the www.apc.com web site.

Network Management Card

User Manual

8 Appendices

8.1 Tables of alarms and events

8.1.1 UPS Alarm table

English	French
Battery Fault	Défaut batterie
Output On Battery	Sortie alimentée par batterie
Low Battery	Fin d'autonomie
UPS Over Temperature	Défaut température
Output not protected	Sortie non protégée
UPS Overload	Surcharge onduleur
Output On Bypass	Sortie sur Bypass
Charger Fault, Not Charging Battery	Défaut chargeur
Utility failure	Perte secteur
No Battery	Pas de batterie
Replace Battery	Batterie à remplacer
Unavailable Battery	Batterie indisponible
Boost Activated on UPS	Onduleur en mode Boost
Buck Activated on UPS	Onduleur en mode Buck
<Sensor name>: Temperature is above high threshold xx °C	<Sensor name>: La température est au dessus du seuil haut xx °C
"<Sensor name>: Humidity is above high threshold xx %",	<Sensor name>: L'humidité est au dessus du seuil haut xx %",
<Sensor name>: Temperature is below low threshold xx °C	<Sensor name>: La température est en dessous du seuil bas xx °C
<Sensor name>: Humidity is below low threshold xx %	<Sensor name>: L'humidité est en dessous du seuil bas xx %
<Sensor name>: <Input #1 label> <when closed label>	<Sensor name>: <Input #1 label> <when closed label>
<Sensor name>: <Input #1 label> <when open label>	<Sensor name>: <Input #1 label> <when open label>
<Sensor name>: <Input #2 label> <when closed label>	<Sensor name>: <Input #2 label> <when closed label>
<Sensor name>: <Input #2 label> <when open label>	<Sensor name>: <Input #2 label> <when open label>

8.1.2 STS Alarm table

English	French
Source 1 Static Switch fault	Défaut Contacteur Statique source 1
KM1 fault	Défaut Contacteur source 1 (KM1)
Source 2 Static Switch fault	Défaut Contacteur Statique source 2
KM2 fault	Défaut Contacteur source 2 (KM2)
Source 1 voltage fault	Défaut tension source 1
Source 1 frequency fault	Défaut fréquence source 1 hors tolérances
Source 2 voltage fault	Défaut tension source 2
Source 2 frequency fault	Défaut fréquence source 2 hors tolérances
Output not powered	Charge non alimentée
Transfer forbidden	Transfert interdit

Network Management Card

User Manual

Sources out of synchronization	Déphasage sources 1 / 2
Emergency stop activated	Défaut arrêt d'urgence active
Output Thermal overload	Défaut surcharge thermique
Output overload	Défaut surcharge
STS internal fault	Défaut interne
STS general alarm	Défaut Alarme Générale
STS communication failure	Défaut Communication interne
<Sensor name>: Temperature is above high threshold xx °C	<Sensor name>: La température est au dessus du seuil haut xx °C
"<Sensor name>: Humidity is above high threshold xx %",	<Sensor name>: L'humidité est au dessus du seuil haut xx %",
<Sensor name>: Temperature is below low threshold xx °C	<Sensor name>: La température est en dessous du seuil bas xx °C
<Sensor name>: Humidity is below low threshold xx %	<Sensor name>: L'humidité est en dessous du seuil bas xx %
<Sensor name>: <Input #1 label> <when closed label>	<Sensor name>: <Input #1 label> <when closed label>
<Sensor name>: <Input #1 label> <when open label>	<Sensor name>: <Input #1 label> <when open label>
<Sensor name>: <Input #2 label> <when closed label>	<Sensor name>: <Input #2 label> <when closed label>
<Sensor name>: <Input #2 label> <when open label>	<Sensor name>: <Input #2 label> <when open label>

8.1.3 UPS event table

English	French
Battery fault	Défaut batterie
Battery OK	Fin défaut batterie
Replace battery	Batterie à remplacer
Battery replaced	Batterie remplacée
Low battery	Fin d'autonomie
UPS return from low battery	Fin préalarme d'autonomie
UPS battery charger is not active	Chargeur batterie arrêté
UPS battery charger is active	Chargeur batterie en marche
UPS battery entering minimum condition	Batterie en charge minimum
UPS battery exiting from minimum condition	Fin batterie en charge minimum
Output on battery	Sortie alimentée par batterie
Return on UPS	Sortie sur onduleur
Output on Bypass	Sortie sur Bypass
Bypass : Return on UPS	Sortie sur onduleur
UPS bypass unavailable	Bypass indisponible
UPS bypass available	Bypass disponible
Utility failure	Perte secteur
Utility restored	Retour secteur
Boost activated on UPS	Onduleur en mode Boost
Boost de-activated on UPS	Mode Boost désactivé
UPS overload	Surcharge onduleur
UPS return to normal load	Fin de surcharge onduleur
UPS over temperature	Défaut température

Network Management Card

User Manual

UPS return to normal temperature	Fin de défaut température
%s on sequence started	Début séquence de démarrage %s
%s on sequence cancelled	Arrêt séquence de démarrage %s
%s on sequence in progress	Séquence de démarrage %s en cours
%s on sequence completed	Fin séquence de démarrage %s
%s off sequence started	Début séquence d'arrêt %s
%s off sequence cancelled	Arrêt séquence d'arrêt %s
%s off sequence in progress	Séquence d'arrêt %s en cours
%s off sequence completed	Fin séquence d'arrêt %s
%s toggle (off/on) sequence started	Début séquence d'arrêt/marche %s
%s toggle (off/on) sequence cancelled	Arrêt séquence d'arrêt/marche %s
%s toggle (off/on) sequence in progress	Séquence d'arrêt/marche %s en cours
%s toggle (off/on) sequence completed	Fin séquence d'arrêt/marche %s
UPS	onduleur
UPS communication failed	Perte de communication avec l'onduleur
UPS communication restored	Retour de communication avec l'onduleur
Unavailable battery	Batterie indisponible
Battery available	Batterie disponible
UPS waiting for battery charging condition	UPS waiting for battery charging condition
UPS reached battery charging condition	UPS reached battery charging condition
UPS fault	défaut interne
UPS OK	Fin défaut interne
UPS passed battery test	Test batterie terminé
UPS failed battery test	Test batterie en défaut
UPS enter environment external alarm	UPS enter environment external alarm
UPS exit environment external alarm	UPS exit environment external alarm
Buck activated on UPS	Onduleur en mode Buck
Buck de-activated on UPS	Mode Buck désactivé
Normal input switch (Q1) closed	Interrupteur d'entrée (Q1) fermé
Normal input switch (Q1) open	Interrupteur d'entrée (Q1) ouvert
Bypass switch (Q4S) closed	Interrupteur bypass (Q4S) fermé
Battery switch (QF1) closed	Disjoncteur batterie QF1 fermé
Battery switch (QF1) open	Disjoncteur batterie QF1 ouvert
Manual bypass switch (Q3BP) closed	Interrupteur bypass manuel (Q3BP) fermé
Manual bypass switch (Q3BP) open	Interrupteur bypass manuel (Q3BP) ouvert
Output switch (Q5N) closed	Interrupteur de sortie (Q5N) fermé
Output switch (Q5N) open	Interrupteur de sortie (Q5N) ouvert
Output not protected	Sortie non protégée
Output On	Sortie alimentée
<Sensor name>: Temperature is below low threshold %d °C	<Sensor name>: La température est en dessous du seuil bas %d °C
<Sensor name>: Temperature is above high threshold %d °C	<Sensor name>: La température est au dessus du seuil haut %d °C
<Sensor name>: Temperature is in normal range	<Sensor name>: La température est revenue à un niveau normal
<Sensor name>: Humidity is below low threshold %d %	<Sensor name>: L'humidité est en dessous du seuil bas %d %
<Sensor name>: Humidity is above high threshold %d %	<Sensor name>: L'humidité est au dessus du seuil haut %d %

Network Management Card

User Manual

<Sensor name>: Humidity is in normal range	<Sensor name>: L'humidité est revenue à un niveau normal
<Sensor name>: <Input #1 label> <when closed label>	<Sensor name>: <Input #1 label> <when closed label>
<Sensor name>: <Input #1 label> <when open label>	<Sensor name>: <Input #1 label> <when open label>
<Sensor name>: <Input #2 label> <when closed label>	<Sensor name>: <Input #2 label> <when closed label>
<Sensor name>: <Input #2 label> <when open label>	<Sensor name>: <Input #2 label> <when open label>

8.1.4 STS event table

English	French
Source 1 Static Switch fault	Défaut Contacteur Statique source 1
KM1 fault	Défaut Contacteur source 1 (KM1)
Source 2 Static Switch fault	Défaut Contacteur Statique source 2
KM2 fault	Défaut Contacteur source 2 (KM2)
Source 1 voltage fault	Défaut tension source 1
Source 1 frequency fault	Défaut fréquence source 1 hors tolérances
Source 2 voltage fault	Défaut tension source 2
Source 2 frequency fault	Défaut fréquence source 2 hors tolérances
Load not powered	Charge non alimentée
Transfert forbidden	Transfert interdit
Displacement source 1 / source 2	Déphasage sources 1 / 2
EPO present	Défaut arrêt d'urgence activé
Thermal overload	Défaut surcharge thermique
Overload fault	Défaut surcharge
Internal failure	Défaut interne
General alarm	Défaut Alarme Générale
Communication failure	Défaut Communication interne
Source 1 circuit breaker (Q1) closed	Interrupteur Q1 fermé
Source 1 circuit breaker (Q1) open	Interrupteur Q1 ouvert
Source 2 circuit breaker (Q2) closed	Interrupteur Q2fermé
Source 2 circuit breaker (Q2) open	Interrupteur Q2ouvert
Output circuit breaker (Q3) closed	Interrupteur Q3fermé
Output circuit breaker (Q3) open	Interrupteur Q3ouvert
Source 1 bypass switch (Q1BP) closed	Interrupteur Q1BP ferme
Source 1 bypass switch (Q1BP) open	Interrupteur Q1BP ouvert
Source 2 bypass switch (Q2BP) closed	Interrupteur Q2P ferme
Source 2 bypass switch (Q2BP) open	Interrupteur Q2P ouvert
Source 1 active	Source 1 active
Source 2 active	Source 2 active
Source 1 preferred	Source 1 prioritaire
Source 2 preferred	Source 2 prioritaire
Transfer available	Transfert autorisé
<Sensor name>: Temperature is below low threshold %d °C	<Sensor name>: La température est en dessous du seuil bas %d °C
<Sensor name>: Temperature is above high threshold %d °C	<Sensor name>: La température est au dessus du seuil haut %d °C
<Sensor name>: Temperature is in	<Sensor name>: La température est revenue à

Network Management Card

User Manual

normal range	un niveau normal
<Sensor name>: Humidity is below low threshold %d %	<Sensor name>: L'humidité est en dessous du seuil bas %d %
<Sensor name>: Humidity is above high threshold %d %	<Sensor name>: L'humidité est au dessus du seuil haut %d %
<Sensor name>: Humidity is in normal range	<Sensor name>: L'humidité est revenue à un niveau normal
<Sensor name>: <Input #1 label> <when closed label>	<Sensor name>: <Input #1 label> <when closed label>
<Sensor name>: <Input #1 label> <when open label>	<Sensor name>: <Input #1 label> <when open label>
<Sensor name>: <Input #2 label> <when closed label>	<Sensor name>: <Input #2 label> <when closed label>
<Sensor name>: <Input #2 label> <when open label>	<Sensor name>: <Input #2 label> <when open label>

Network Management Card

User Manual

8.1.5 System alarm table

English	French
Cold boot	Démarrage de la carte
Warm boot	Réinitialisation de la carte
Network link up	Carte connectée au réseau
Network link down	Carte déconnectée du réseau
Agent Card Restart	Redémarrage de la carte
Parameters reset to default	Paramètres par défaut reprogrammés
Firmware upgrade with version xx	Carte reprogrammée avec version xx
History log cleared	Historique des mesures effacé
UPS event log cleared	Historique des événements effacé
Agent event log cleared	Historique système effacé
History log interval changed	Période des historiques modifiée
Communication failure	Perte de communication
Communication restored	Retour de communication
Time changed by user	Date et heure réglées manuellement
Time changed by server	Date et heure synchronisées par serveur
Time changed by RTC	Date et heure réglées par RTC
Access to SMTP server failed to mail to recipient	L'accès au serveur SMTP a échoué pendant l'envoi au destinataire de mail
Access to SMTP server succeed to test mail to recipient	L'accès au serveur SMTP a réussi pour le test d'envoi au destinataire de mail
Environment log cleared	Historique des mesures environnement effacé
<Sensor name> communication failed	<Sensor name> communication restored

Network Management Card

User Manual

8.2 Glossary

Bootp:

Protocol based on UDP used to allocate an IP address corresponding to an Ethernet card during the startup phase. Defined by the RCF 951

Community name:

Access key to access SNMP agent information

DHCP Dynamic Host Configuration Protocol

This IETF protocol enables remote, automatic, self-configuration of the IP addresses of a workstation.

DNS Domain Name Service

The DNS protocol ensure correspondence between the name of a machine and its IP address

DST Daylight Saving Time

Extension of the NTP protocol to manage time changes in summer and winter

E-mail

Electronic means of transmitting messages and/or files.

Gateway

Interconnection equipment between networks with different conventions, to enable communication between them

HTML

(HyperText Markup Language) Language used to describe hypertext pages on the web.

HTTPS : is the secure version of HTTP, the communication protocol of the World Wide Web. It was invented by Netscape Communications Corporation to provide authentication and encrypted communication and is used in electronic commerce.

IP

Internet Protocol. Network layer protocol in the TCP/IP stack offering a no-connection inter-network service . The IP protocol offers functions for addressing, service type specification, fragmentation and re-assembling and security. Defined in RFC 791.

MD5

Message Digest 5. Algorithm producing an output message from an input message of arbitrary length, in the form of a replica or many 128 bit message. Intended for digital signature applications requiring large files to be compressed in total security before being coded with a private key, using a public key algorithm, like RSA.

MIB MANAGEMENT INFORMATION BASE

- Group of software commands to control and administrate a device through the network. Each type of device (server, hub, PC, UPS, etc.) has its own MIB
– The IETF has proposed a standard MIB for each group of devices (hubs, for example) to simplify administration if they come from different suppliers

MultiSlot

Expander module for MGEUPS communication card.

Network Management Card

User Manual

NETWORK MANAGEMENT CARD

Communication cards to supervise UPS and communicate with Network Shutdown Module to insure power protection on servers

NMS NETWORK MANAGEMENT STATION (SNMP)

The dedicated PC or workstation is used on the company's networks to administrate all devices connected to the network. Data are transmitted using the SNMP protocol. Popular NMS systems include HP OpenView, IBM Tivoli, CA Unicenter, etc.

NETWORK SHUTDOWN MODULE

Protection software installed on a PC or server to protect it

NTP Network Time Protocol

Protocol to position a set of machines on a network at the same time.

REBOOT –

To restart a system after an interruption.

- To perform an obstacle-free “reboot”, it is essential that the system is correctly and carefully shut down beforehand.
- The reboot is usually automatic if the computer is re-supplied with electricity (from the utility or from the UPS).

RFC

Request for Comments. All documents defining internal Internet operation.

SNMP (SIMPLE NETWORK MANAGEMENT PROTOCOL)

Protocol used to remote-supervise, administrate and control devices connected to a company network.

SMTP (SIMPLE MAIL TRANSFER PROTOCOL)

Enables message transfer between e-mail servers or between the client and its server. It is based on the server's port 25. It is described in RFC 821

SSL (Secure Sockets Layers) is a protocol developed by Netscape Communications Corporation for securing data transmission in commercial transactions on the Internet. Using public-key cryptography, SSL provides server authentication, data encryption, and data integrity for client/server communications

Subnet mask:

Mask of bits used to identify and differentiate the network address and the equipment address in an IP address. Normally, the mask is automatically determined by the class of address, which defines in a unique manner the network part/equipment part division of the IP address.

- Class A: internet address: 255.0.0.0.
- Class B: internet address: 255.255.0.0.
- Class C: internet address: 255.255.255.0.

TCP/IP

Transmission Control Protocol/Internet Protocol. Common name of a series of protocols developed by the DOD in the US to help build Internet networks throughout the world.

Telnet

Internet protocol used for terminal emulation, i.e. enabling a computer to connect with a server as if it was a simple terminal locally connected to this server.

Network Management Card

User Manual

Trap (SNMP)

This term describes an event that affects an MIB variable. Traps are sent to the manager, which is programmed to perform specific tasks upon reception of the traps.