

EZ Card1000

1000 Mbps Gigabit Ethernet PCI Network Card

- ◆ High performance for instant access to network resources
- ◆ 1000BASE-T model for Category 5 UTP
- ◆ Supports PCI 32 and 64-bit bus-master architectures
- ◆ Full-duplex operation for up to 2 Gbps of bandwidth
- ◆ IP, TCP and UDP checksum off-loading capability reduces CPU overhead



EZ Card 1000 User Guide

From SMC's EZ line of feature-rich workgroup LAN solutions

SMC®

Networks

6 Hughes

Irvine, CA 92618

Phone: (949) 707-2400

March 2001

Pub. # 150416-102 R01

Information furnished by SMC Networks, Inc. (SMC) is believed to be accurate and reliable. However, no responsibility is assumed by SMC for its use, nor for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of SMC. SMC reserves the right to change specifications at any time without notice.

Copyright © 2001 by
SMC Networks, Inc.
6 Hughes
Irvine, CA 92618
All rights reserved. Printed in Taiwan

Trademarks:

SMC is a registered trademark; and EZ Card, EtherPower and SuperDisk are trademarks of SMC Networks, Inc. Other product and company names are trademarks or registered trademarks of their respective holders.

Limited Warranty

Limited Warranty Statement: SMC Networks, Inc. ("SMC") warrants its products to be free from defects in workmanship and materials, under normal use and service, for the applicable warranty term. All SMC products carry a standard 90-day limited warranty from the date of purchase from SMC or its Authorized Reseller. SMC may, at its own discretion, repair or replace any product not operating as warranted with a similar or functionally equivalent product, during the applicable warranty term. SMC will endeavor to repair or replace any product returned under warranty within 30 days of receipt of the product.

The standard limited warranty can be upgraded to a Limited Lifetime* warranty by registering new products within 30 days of purchase from SMC or its Authorized Reseller. Registration can be accomplished via the enclosed product registration card or online via the SMC web site. Failure to register will not affect the standard limited warranty. The Limited Lifetime warranty covers a product during the Life of that Product, which is defined as the period of time during which the product is an 'Active' SMC product. A product is considered to be 'Active' while it is listed on the current SMC price list. As new technologies emerge, older technologies become obsolete and SMC will, at its discretion, replace an older product in its product line with one that incorporates these newer technologies. At that point, the obsolete product is discontinued and is no longer an 'Active' SMC product. A list of discontinued products with their respective dates of discontinuance can be found at http://www.smc.com/smc/pages_html/support.html.

All products that are replaced become the property of SMC. Replacement products may be either new or reconditioned. Any replaced or repaired product carries either a 30-day limited warranty or the remainder of the initial warranty, whichever is longer. SMC is not responsible for any custom software or firmware, configuration information, or memory data of Customer contained in, stored on, or integrated with any products returned to SMC pursuant to any warranty. Products returned to SMC should have any customer-installed accessory or add-on components, such as expansion modules, removed prior to returning the product for replacement. SMC is not responsible for these items if they are returned with the product.

Customers must contact SMC for a Return Material Authorization number prior to returning any product to SMC. Proof of purchase may be required. Any product returned to SMC without a valid Return Material Authorization (RMA) number clearly marked on the outside of the package will be returned to customer at customer's expense. For warranty claims within North America, please call our toll-free customer support number at (800) 762-4968. Customers are responsible for all shipping charges from their facility to SMC. SMC is responsible for return shipping charges from SMC to customer.

WARRANTIES EXCLUSIVE: IF AN SMC PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, CUSTOMER'S SOLE REMEDY SHALL BE REPAIR OR REPLACEMENT OF THE PRODUCT IN QUESTION, AT SMC'S OPTION. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, EITHER

LIMITED WARRANTY

IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SMC NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE OR USE OF ITS PRODUCTS. SMC SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.

LIMITATION OF LIABILITY: IN NO EVENT, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), SHALL SMC BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE, LOSS OF BUSINESS, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF ITS PRODUCTS, EVEN IF SMC OR ITS AUTHORIZED RESELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

SOME STATES DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES OR THE LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR CONSUMER PRODUCTS, SO THE ABOVE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, WHICH MAY VARY FROM STATE TO STATE. NOTHING IN THIS WARRANTY SHALL BE TAKEN TO AFFECT YOUR STATUTORY RIGHTS.

* SMC will provide warranty service for one year following discontinuance from the active SMC price list. Under the limited lifetime warranty, internal and external power supplies, fans, and cables are covered by a standard one-year warranty from date of purchase.

SMC Networks, Inc.

SMC Networks, Inc.
6 Hughes
Irvine, CA 92618

COMPLIANCES

FCC - Class B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

EC Conformance Declaration - Class B

SMC contact for these products in Europe is:

SMC Networks Europe,
Edificio Conata II,
Calle Frutuós Gelabert 6-8, 2^a, 4^a,
08970 - Sant Joan Despí,
Barcelona, Spain.

This information technology equipment complies with the requirements of the Low Voltage Directive 73/23/EEC and the EMC Directive 89/336/EEC, and carries the CE Mark accordingly. It conforms to the following specifications:

EMC:	EN55022 (1988)/CISPR-22 (1995)	Class B
	IEC 1000-4-2	4 kV CD, 8 kV AD
	IEC 1000-4-3 (1995)	3 V/m
	IEC 1000-4-4 (1995)	1.0 kV - (power line) 0.5 kV - (signal line)
	IEC 1000-4-6 (1995)	3 Vrms

Industry Canada - Class B

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the interference-causing equipment standard entitled "Digital Apparatus," ICES-003 of the Department of Communications.

Cet appareil numérique respecte les limites de bruits radioélectriques applicables aux appareils numériques de Classe B prescrites dans la norme sur le matériel brouilleur: "Appareils Numériques," NMB-003 édictée par le ministère des Communications.

Japan VCCI Class B

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスB情報技術装置です。この装置は、家庭環境でを使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると受信障害を引き起こすことがあります。

取り扱い説明書に従って正しい取り扱いをして下さい。

Australia AS/NZS 3548 (1995) - Class B



ACN 069 351 613

SMC contact for products in Australia is:

SMC Communications Pty. Ltd.
Suite 18, 12 Tryon Road,
Lindfield NSW2070,
Phone: 61-2-94160437
Fax: 61-2-94160474

TABLE OF CONTENTS

1	Installing The Network Card	1-1
	Introduction	1-1
	Hardware Description	1-2
	LED Indicators	1-3
	Package Contents	1-4
	SuperDisk Contents	1-4
	System Requirements	1-5
	Inserting the Network Card	1-5
	PCI Configuration	1-7
	Connecting Category 5 Cable	1-8
	Cable Testing for Existing Category 5 Cable	1-8
	Adjusting Existing Category 5 Cabling to Run 1000BASE-T	1-8
	Connecting UTP Cable	1-9
2	Installing and Configuring Network Drivers	2-1
	Windows NT 4.0 Installation	2-1
	First-Time Installation	2-1
	Secondary Installation	2-3
	Further Configuration	2-4
	Windows 2000 Installation	2-5
	Novell NetWare Installation	2-6
	NetWare Server 5.0	2-6
	NetWare Server 4.11	2-8
	Linux 2.2.X or Later Installation	2-10
	Manual Loading and Configuration	2-10
	Automatic Installation	2-12
	Windows 98 Installation	2-14
	Other Installations	2-16
	Latest Drivers	2-16
3	Configuring and Testing the Network Card	3-1
	Configuration	3-1
	Network Card Information	3-1
	Auto-Negotiation	3-1

	Network Type	3-2
	Network Address	3-2
	Jumbo Frame Size	3-2
	IEEE Compliance.	3-2
	Receive Buffer	3-3
	Transmit Buffer	3-3
A	Troubleshooting	A-1
	PCI Compatibility	A-1
	Solutions for Common Problems	A-3
	Network Card Installation Problems	A-3
	Network Connection Problems	A-4
B	Cables	B-1
	Cable Specifications	B-1
	Twisted-Pair Cable and Pin Assignments	B-1
	10BASE-T/100BASE-TX Pin Assignments	B-3
	1000BASE-T Pin Assignments	B-3
C	Specifications	C-1
	Software Drivers	C-3
	Index	

CHAPTER 1

INSTALLING THE NETWORK CARD

Introduction

SMC's EZ Card 1000 network interface card is a Gigabit Ethernet card for 32 and 64-bit PCI local bus compliant computers. It operates under the 1000BASE-T specification over Category 5 UTP Cable. This adapter provides up to ten times the bandwidth of Fast Ethernet. A true plug-and-play device, this card is auto-configurable upon power up. Leading-edge ASIC technology and performance-enhancing techniques maximize throughput and minimize CPU utilization. The result is a network card that delivers the performance and reliability demanded by today's high-end servers and workstations.

Hardware Description

The EZ Card 1000 is a Gigabit Ethernet network card designed for 32 and 64-bit PCI-bus computers. The SMC9462TX has a single RJ-45 connector to attach to Category 5 UTP cable and supports 10 Mbps, 100 Mbps and 1000 Mbps Ethernet operations. It also supports full and half duplex and features auto-negotiation.




Figure 1-1. The EZ Card 1000 SMC9462TX

LED Indicators

The EZ Card 1000 network card includes status LED indicators as described in the following figure and table.




Figure 1-2. Status LEDs

LED	Status	Description
Link	On Green	Indicates a valid 1000BASE-T connection on the fiber port.
ACT	Flashing Green	Indicates that the adapter is transmitting or receiving data.
1000	On Green	Indicates that the adapter is operating at 1000 Mbps.
100	On Green	Indicates that the adapter is operating at 100 Mbps.
10	On Green	Indicates that the adapter is operating at 10 Mbps.

Package Contents

After unpacking the EZ Card 1000, check the contents of the box to be sure you have received the following components:

- ◆ EZ Card 1000 network card SMC9462TX
- ◆ SuperDisk™ network drivers diskette
- ◆ This User Guide
- ◆ SMC Warranty Registration Card

Immediately inform your dealer in the event of any incorrect, missing or damaged parts. If possible, please retain the carton and original packing materials in case there is a need to return the product.

Please fill out and return the Warranty Registration Card to SMC or register on SMC's Web site. The EZ Card 1000 is covered by a limited lifetime warranty.

SuperDisk Contents

The SuperDisk contains drivers and other files to make network card configuration, testing, and driver installation easy.

- ◆ RELEASE.TXT—a summary of the contents of the driver diskette.
- ◆ README.TXT—contains basic information and instructions for installing and using the network card.
- ◆ Driver installation “TXT” files—contain installation instructions for a particular driver.

System Requirements

Before you install the EZ Card 1000 card, check your system for the following requirements:

- ◆ A PC and BIOS that support the PCI Local Bus Specification v2.2 or later
- ◆ An available bus-mastering 32-bit or 64-bit PCI slot
- ◆ Category 5 or 5e UTP cable with RJ-45 connectors
- ◆ An IEEE 802.3ab-compliant Gigabit Ethernet device installed in your network

Note: If you are installing in an older PC model (Pentium or earlier), upgrade the BIOS to the latest version.

Inserting the Network Card

WARNINGS:

- This network adapter requires a PC and BIOS that support the PCI Local Bus Specification v2.2 or later. If you are installing in an older PC model, upgrade the BIOS to the latest version
 - Network cards are sensitive to static electricity. To protect the card, avoid touching its electrical components and always touch the metal chassis of your computer before handling the card.
 - Backup your SuperDisk driver diskette and use the copy as the working diskette to protect the original from accidental damage.
1. Switch off the computer, unplug the power cord, and remove the computer's cover.
 2. Select an available 32-bit bus-mastering PCI slot and remove the cover bracket.

- Use a 64-bit PCI slot if your PC supports this standard.
- If using a 32-bit PCI slot, the end of the card's edge connector will be exposed. Be careful that it does not touch any conducting parts on the PC motherboard.

Note: Some PC motherboard designs may not provide adequate space behind all 32 or 64-bit PCI slots to properly install the network card.

3. Install the network card into the slot so that it is firmly seated. Then, screw the card's bracket securely into the PC's chassis.




Figure 1-3. Inserting the Network Card

4. Replace the chassis cover on your PC and power it on.
5. The EZ Card 1000 should be automatically configured by the host computer's BIOS. However, if you have an older computer, you may have to manually configure the computer's BIOS settings.
6. The SMC SuperDisk that accompanies the EZ Card 1000 contains all the network operating system drivers supported by this card. Please read the "RELEASE.TXT" file on the diskette for a list of all drivers. Refer to Chapter 2 in this guide for instructions on installing drivers. Also, a text file is included with each driver to detail the proper installation procedure. Any new or updated drivers can be downloaded from SMC's Web site (see the back cover of this guide).

PCI Configuration

In most cases, your network card is automatically configured when you power-up your computer. In certain computers, however, you must modify PCI settings by running your computer's BIOS Setup program. For more information, refer to "PCI Compatibility" on page A-2.

Connecting Category 5 Cable

To connect to a 1000BASE-T Gigabit Ethernet device, use the RJ-45 connector on the network card and Category 5, 5e or better UTP cable. This connection can be made directly to the device, or indirectly via a wall outlet that has the proper wiring for an RJ-45 connector. Connections can be made for a distance of 100m (328 ft). It is recommended that for all critical connections, or any new cable installations, Category 5e (enhanced Category 5) cable should be used. The Category 5e specification includes test parameters that are only recommendations for Category 5. Therefore, the first step in preparing existing Category 5 cabling for running 1000Base-T is a simple test of the cable installation to be sure that it complies with the IEEE 802.3ab standards.

Cable Testing for Existing Category 5 Cable

Installed Category 5 cabling must pass tests for Attenuation, Near-End Crosstalk (NEXT), and Far-End Crosstalk (FEXT). This cable testing information is specified in the ANSI/TIA/EIA-TSB-67 standard. Additionally, cables must also pass test parameters for Return Loss and Equal-Level Far-End Crosstalk (ELFEXT). These tests are specified in the ANSI/TIA/EIA-TSB-95 Bulletin, "The Additional Transmission Performance Guidelines for 100 Ohm 4-Pair Category 5 Cabling." When testing your cable installation, be sure to include all patch cables between switches and end devices.

Adjusting Existing Category 5 Cabling to Run 1000BASE-T

If your existing Category 5 installation does not meet one of the test parameters for 1000Base-T, there are basically three measures that can be applied to try to correct the problem:

1. Replace any Category 5 patch cables with high-performance Category 5e cables.
2. Reduce the number of connectors used in the link.
3. Reconnect some of the connectors in the link.

Connecting UTP Cable

1. Attach the male RJ-45 connector on one end of a UTP cable to the network card's RJ-45 port.




Figure 1-4. Connecting UTP Cable

2. Attach the male connector on the other end of the UTP cable directly to an Ethernet or Fast Ethernet device.

OR

Attach the male connector on the other end of the UTP cable to a wall outlet with an RJ-45 connector properly wired for 1000BASE-T Ethernet. Wiring from the wall outlet connection is usually routed to a hub or switch through a punch-down block located in a wiring closet.

3. For 1000 Mbps operation, make certain that the device you are connecting to is compliant with IEEE 802.3ab 1000BASE-T.

CHAPTER 2

INSTALLING AND CONFIGURING NETWORK DRIVERS

Windows NT 4.0 Installation

Caution: Prior to installing the driver, make sure you have upgraded to NT Service Pack 4 or later.

First-Time Installation

If you have already installed a network card, configured Windows NT Networking, or configured a network driver, refer to the procedure entitled “Secondary Installation” on page 3. If Windows NT is already installed on your computer, proceed to Step 2. Otherwise, complete a first-time Windows NT installation without the SMC network card installed. Be sure to also install NT Service Pack 4 or later.

1. Shut down your PC, install the SMC network card, and attach the network cable. Restart Windows NT.
2. Double-click on the “My Computer,” “Control Panel,” and “Network” icons. The “Network Configuration” window appears, prompting you to install Windows NT Networking. Select “Yes.” Windows NT invokes the “Network Setup Wizard.” Click on “Next.”
3. When prompted to “Search for a Network Adapter,” click on “Select from List.”

4. When prompted to "Select a Network Adapter," click on "Have Disk." Insert the SuperDisk when prompted and click on "OK."
5. You are presented with the "Select OEM Option" window. Highlight "EZ Card 1000" and click on "OK."
6. When prompted to "Search for an Adapter," click on "Next."
7. Select network protocols when prompted and click "Next."

Note: To complete a TCP/IP installation, you will need to know your IP Address and Subnet Mask. For further information, contact your network administrator or Internet service provider.

8. Click on "Next" and then "Next" again when prompted to "Install Network Components." When prompted for Windows NT installation files, type the path to your Windows NT files on your CD-ROM (e.g., D:\WINNT) or hard drive, and click on "OK."
9. You are presented with the "Network Card Setup" window where you can specify the network card data rate. "AUTONEGOTIATE" is the recommended setting for the EZ Card 1000 network card. Select "Continue" after verifying network card settings.
10. Click on "Next" and then "Next" again when prompted to "Start the Network."
11. Enter the "Workgroup" or "Domain" names (optional) when prompted and click on "Next."
12. Select "Finish" when prompted and click on "Yes" when prompted to reboot. Remove the SuperDisk.

Secondary Installation

Follow this procedure if you have already installed another network card or loaded another driver.

1. Be sure to install Windows NT Service Packet 4 or later if it is not already installed.
2. Install the SMC network card (if not already installed), attach the network cable, and boot Windows NT.
3. Double-click on the “My Computer,” “Control Panel,” and “Network” icons. From the “Network” window, select the Adapter tab.
4. Do not select any of the network cards listed. Select “Add.”
5. You are presented with the “Select Network Adapter” window. Click on “Have Disk.”
6. You are presented with the “Insert Disk” window. Specify the path to the root directory of the SuperDisk (e.g., A:\) and click on “OK.”
7. You are presented with the “Select OEM Option” window. Highlight “EZ Card 1000” and click on “OK.”
8. You are presented with the “Network Card Setup” window where you can specify the network card data rate. “AUTONEGOTIATE” is the recommended setting for the EZ Card 1000 network card. Select “OK” after verifying network card settings.
9. You are presented with the “Network” window where the SMC network card is now listed as an installed adapter. At this point you can select “Close” to exit the Network applet and follow the prompts to restart Windows NT.
10. Select “Yes” when prompted to reboot for the changes to take effect.

Further Configuration

You can modify card settings, install additional protocols and other network components via the Windows NT “Network” applet.

1. Double-click on the “My Computer,” “Control Panel,” and “Network” icons. The “Network” dialog box appears. If the correct network protocols are not installed in the “Protocols” tab list box, click on the “Add” button and follow the on-screen directions to select network protocols.
2. Click on the appropriate tab, “Identification,” “Services” or “Bindings,” to add or modify other network components, as needed.
3. To modify other network card properties, click on the “Adapters” tab and select the EZ Card 1000 in the list box. Then click on the “Properties” button to run the card’s configuration utility. Refer to Chapter 3 for a description of the card’s configuration utility and its options.

Windows 2000 Installation

The EZ Card 1000 driver for Windows 2000 conforms to the Network Driver Interface Specification (NDIS) 5.0 and can be found in the “\Winnt\Win2000” directory on the SMC SuperDisk driver diskette.

1. If Windows 2000 is already installed on your computer, proceed to Step 2. Otherwise, install Windows 2000 without the SMC network card installed.
2. Shut down your PC, install the SMC network card, and attach a network cable.
3. Reboot Windows 2000. Make sure you have your Windows 2000 installation CD available, or that you are aware of the path to the installation files on your hard drive.
4. After you have logged in, a “Welcome to the Found New Hardware Wizard” window will appear if Windows 2000 cannot locate the driver. If this window does not appear, Windows 2000 was able to locate the driver and installation is complete. If the window appears, click on “Next.” Select “Search for a suitable driver” and click on “Next.” Select “Specify location” and then type in “A:\WINNT\WIN2000” and click on “OK.”
5. Follow the remaining Windows 2000 instructions to complete the installation.

Novell NetWare Installation

NetWare Server 5.0

Installing the LAN driver is part of the NetWare installation process. Use the following instructions with those in the NetWare installation manual to install the driver. You will need the SMC SuperDisk during this procedure. Shutdown your computer and install the EZ Card 1000 network card in a PCI slot. Connect the card to the network using UTP cable.

1. Turn your computer on and boot it to the NetWare 5.0 console prompt.
2. At the NetWare console prompt enter the command "load nwconfig" to start the install utility. The Installation Options dialog box is displayed.
3. Select the Driver Options menu item and press enter. The Driver Options dialog box is displayed.
4. Select the Configure Network Drivers menu item and press enter. The Additional Driver Actions dialog box is displayed.
5. Insert the SMC SuperDisk driver diskette into the "A" drive.
6. Select the "Load an additional driver" menu item option and press Enter. The "Select a driver" dialog box is displayed. Press the "Ins" key to Install an unlisted driver. A dialog box indicating the A drive will be scanned for drivers is displayed. Press Enter to continue.
7. Press Enter to select the SMC9462.LAN from the "Select a driver" to install dialog box. A message asking if you want to copy the driver is displayed. Select "Yes" to continue. The device driver is copied.

8. A screen with three dialog boxes is displayed. To change the driver configuration, tab to the “SMC9462_1 Parameters” dialog box and modify the driver parameters. Depending on the network that the card is attached to, the Link, Speed, Duplex Mode, and Phy Type parameters might need to be changed from their default values. If you are not sure what values are required for your network, contact your network administrator.
9. Tab to the “SMC9462_1 Protocols” and select the desired protocols.
10. Tab to the “Board SMC9462_1 Actions” dialog box. Select the “Save Parameters and Load Driver” option and press Enter to continue.
11. Perform protocol specific configuration as required.
12. Select “No” when asked if you want to load additional drivers.
13. On the “Additional Driver Actions” dialog box, select “Return to previous menu” and press Enter to continue.
14. On the “Driver Options” dialog box, select “Return to previous menu” and press Enter to continue.
15. On the “Installation Options” dialog box, select “Exit” to return to the NetWare console prompt.

NetWare Server 4.11

Installing the LAN driver is part of the NetWare installation process. Use the following instructions with those in the NetWare installation manual to install the driver. You will need the SMC SuperDisk during this procedure.

1. Shutdown your computer and install the EZ Card 1000 network card in a PCI slot. Connect the card to the network using UTP cable.
2. Turn your computer on and boot it to the NetWare 4.11 console prompt.
3. At the NetWare console prompt Enter the command “load install” to start the install utility. The Installation Options dialog box is displayed.
4. Select the “Driver Options” menu item and press enter. The “Driver Options” dialog box is displayed.
5. Select the “Configure Network Drivers” menu item and press Enter. The “Additional Driver Actions” dialog box is displayed.
6. Insert the SMC SuperDisk driver diskette into the “A” drive.
7. Select the “Load an additional driver” menu item option and press Enter. The “Select a driver” dialog box is displayed. Press the “Ins” key to install an unlisted driver. A dialog box is displayed indicating that the A drive will be scanned for drivers. Press Enter to continue.
8. Press Enter to select the SMC9462.LAN from the “Select a driver to install” dialog box. A message asking if you want to copy the driver is displayed. Select “Yes” to continue. The device driver is copied.

9. A screen with three dialog boxes is displayed. To change the driver configuration, tab to the “SMC9462_1 Parameters” dialog box and modify the driver parameters. Depending on the network that the card is attached to, the Link, Speed, Duplex Mode, and Phy Type parameters might need to be changed from their default values. If you are not sure what values are required for your network, contact your network administrator.
10. Tab to the “SMC9462_1 Protocols” and select the desired protocols.
11. Tab to the “Board SMC9462_1 Actions” dialog box. Select the “Save Parameters and Load Driver” option and press Enter.
12. Perform protocol specific configuration as required.
13. Select “No” when asked if you want to load additional drivers.
14. On the “Additional Driver Actions” dialog box, select “Return to previous menu” and press Enter to continue.
15. On the “Driver Options” dialog box, select “Return to previous menu” and press Enter to continue.
16. On the “Installation Options” dialog box, select “Exit” to return to the NetWare console prompt.

Linux 2.2.X or Later Installation

This section describes the procedure for manual and automatic loading and configuration of the EZ Card 1000 Unix stream driver for Linux 2.2.X or later. The Linux driver can be found in the “\linux” directory on the SMC SuperDisk driver diskette.

Manual Loading and Configuration

Note: In the following sections that describe the driver configuration it is suggested that these instructions be carried out in a single-user environment.

1. Log into the Unix system as supervisor (root) and enter Maintenance mode. Make sure that the current directory is “/” using the Unix command “pwd.”
2. Use the following steps to uncompress the package file:

```
# cd /tmp (and insert the floppy in the proper drive,  
i.e. a:)  
# mcopy a:/linux/2_2_X/smc9462t.o./temp  
# cd temp
```

Now the installation directory is ready for use.

3. Load the EZ Card 1000 device driver module by simply running the command:

```
# insmod smc9462t.o
```

You can also specify command line parameters for the driver, such as:

```
#insmod MaxTxDesc=150 MaxRxDesc=150 RxBufSize=2048
```

The following command line parameters are supported:

RxBufSize: This is the size of the receive buffer memory space allocated per receive descriptor (the label given to each packet received). The default value is 2048. It should be set at 2048 to ensure good performance when not using jumbo frames. When using jumbo frames it should be set at 4096.

MaxRxDesc: This is the maximum number of receive descriptors that will be allocated. This value should be at least 100. The default value is 200.

MaxTxDesc: This is the maximum number of transmit descriptors that will be allocated. This value should be at least 100. The default value is 200.

<mtu-size>: This is the maximum transmission packet size and can be increased up to 4000 bytes for effective operation. To enable the use of jumbo frames, the mtu size can be increased by using the ifconfig utility, as follows

```
#ifconfig <interface-name> mtu <mtu-size>
```

for example:

```
ifconfig eth0 mtu 3000
```

Assuming the card has been assigned the device name “eth0,” the following command brings the card into an operational state:

```
# ifconfig eth0 up
```

Next the driver must be bound to an active protocol, almost always TCP/IP, using the following command:

```
#ifup eth0
```

Note that this is meaningful only if the system can find a configuration script that contains the necessary network info. A sample is given below.

```
DEVICE=eth0
USERCTL=no
ONBOOT=yes
```

```
BOOTPROTO=none
BROADCAST=207.200.5.255
NETWORK=207.200.5.0
NETMASK=255.255.255.0
IPADDR=207.200.5.2
```

Automatic Installation

This section describes how to install the Linux driver so that it is automatically loaded and configured at boot time. The following description is based on the Red Hat 7.0 distribution, but it can be easily ported to other distributions as well.

Note: Before automatically loading the driver at boot time, ensure that the system will function correctly after the driver has been loaded manually.

1. Log into the Unix system as supervisor (root) and enter Maintenance mode. Make sure that the current directory is “/” using Unix command “pwd.”
2. Use the following steps to uncompress the package file:

```
#cd tmp and insert the floppy in drive a:
#mcopy a:/linux/2_2_X/nic/smc9462t.o ./temp
#cd temp
```

Now the installation directory is ready for use.

3. Copy the lacp.o and the smc9462t.o file to the network modules directory, typically /lib/modules/2.4.X/kernel/drivers/net

```
#cp ./lacp.o /lib/modules/2.2.X/kernel/drivers/net
#cp ./smc9462t.o /lib/modules/2.2.X/kernel/drivers/
net
```

4. Locate the boot module configuration file, most commonly “conf.modules” in the “/etc.” directory. Add the following line:

```
alias ethx smc9462
```


where “ethx” will be “eth0” if you do not have any other adapters, “eth1” if you already have one, and so on. The parameters are the ones discussed in the previous paragraph.

5. Find out where the network configuration scripts are, normally in the “/etc/sysconfig/network-scripts” directory, and create a configuration script (sample discussed above) named “ifcfg-ethx” that contains network information.

```
# cd /etc/sysconfig/network-scripts
# vi ifcfg-ethx (make a configuration script file)
```

6. Reboot the Unix system to initialize the driver function.

```
# reboot
```

Windows 98 Installation

The EZ Card 1000 driver for Windows 98 conforms to the Network Driver Interface Specification (NDIS) 5.0 and can be found in the “\Win98” directory on the SMC SuperDisk driver diskette.

1. If Windows 98 is already installed on your computer, proceed to Step 2. Otherwise, complete a first-time Windows 98 installation without the SMC network card installed.
2. Shut down your PC, install the SMC network card, and attach network cable.
3. Power on your PC and boot into Windows 98.
4. When Windows 98 prompts with “PCI Ethernet Controller” in the “New Hardware Found” dialog box, click the “Next” button.
5. Select “Search for the best driver for your device (Recommended)” in the “Add New Hardware Wizard” dialog box, then click the “Next” button.
6. Insert the EZ Card 1000 Driver Diskette in your floppy drive.
7. Select “Specify a location” and type path “A:\Win98” in the “Add New Hardware Wizard” dialog box, then click the “Next” button.
8. Click the “Next” button in the “Add New Hardware Wizard” dialog box.
9. Windows 98 will prompt with “SMC EZ Card 1000 Adapter” in the “Add New Hardware Wizard” dialog box.
10. Click the “Next” button in the “Add New Hardware Wizard” dialog box, then Windows 98 will copy the driver (smc9462.sys) from “A:\Win98” to the “C:\WINDOWS\SYSTEM” directory and the “SMC9462.INF” file from “A:\Win98” to the “C:\WINDOWS\INF” directory.

11. When Windows prompts with "SMC EZ Card 1000 Adapter" in the "Add New Hardware Wizard" dialog box, click the "Finish" button.
12. Remove the SMC SuperDisk driver diskette from your floppy drive.
13. Restart your computer to initialize the network function.

Note: "C:\WINDOWS" is the directory where your Windows 98 system is located.

Other Installations

Refer to the installation documents on SMC's SuperDisk for instructions on installing drivers for use with other operating systems.

Please note that new releases of SMC drivers and operating systems may result in procedures slightly different than those described in this chapter.

Latest Drivers

The SuperDisk contains the latest drivers available at shipping time. If more recent versions of these drivers are available, you can download them from SMC's Web site. Refer to the back cover of this user guide.

CHAPTER 3

CONFIGURING AND TESTING THE NETWORK CARD

Configuration

This section describes the configuration procedure in a Windows environment. When you install the Windows driver, the configuration utility is also installed. You can run this utility by clicking on the “Properties” button for the card in the “Network” control panel applet. Using this utility you can perform the following procedures:

- ◆ View the adapter’s status.
- ◆ Configure the adapter’s advanced properties, such as link parameters and Jumbo Frame support.

Network Card Information

Select the “Properties” tab in the utility window to view the network card status information and to set a locally administered network address.

Auto-Negotiation

This field lets you set the speed, duplex capabilities and flow control for the adapter. If auto-negotiate is chosen, the adapter compares capabilities with its link partner and chooses settings common to both. The adapter will try to use the settings specified on the configuration page first. If the link partner cannot match these settings, lower settings are tried. If the link partner has a fixed

configuration the switch will sense the link speed but will default to half duplex. If the link partner is configured to full duplex, the adapter will not connect correctly resulting in high error rates and inefficient communication. Therefore, auto-negotiation should be disabled when connecting to a card with fixed configuration.

Network Type

This field is used to select link speed and duplex capabilities of the adapter. When auto-negotiate is disabled, these are the settings of the card. The default value is “Auto.”

Network Address

This field lets you set a local network MAC address to override the permanent MAC address that is stored in EEPROM on the card. This feature is useful if the adapter is being used in a test environment. However, for normal use it is recommended to retain the factory-set “Permanent” MAC address.

Jumbo Frame Size

The adapter can be configured to use Jumbo Frames. This increases the maximum Ethernet frame size to greater than 1514 bytes. Using Jumbo Frames greatly reduces packet processing overhead and can boost throughput by up to 300% for bulk data transfers.

Note: To use Jumbo Frames, both communicating computers must have network cards that support this feature. Also, at full duplex, all switches in the network between the two end computers must be able to accept the extended frame size. With half-duplex connections, all devices in the collision domain need to support Jumbo Frames.

IEEE Compliance.

This option should be set to disabled if the link partner does not comply to the IEEE802.3 specifications for 1000BASE-T network adapters. This is often characterized by an intermittent connection and can occur with older gigabit ethernet hardware.

Receive Buffer

This field lets you set the number of buffers allocated in the memory for use by the adapter while receiving packets. Decreasing the number of buffers reduces the memory requirement of the adapter.

Transmit Buffer

This field lets you set the number of buffers allocated in the memory for use by the adapter while transmitting packets. Decreasing the number of buffers reduces the memory requirement of the adapter.

APPENDIX A

TROUBLESHOOTING

PCI Compatibility

Early PCI BIOS versions do not properly support the PCI specification and may “hang” when a network card driver tries to load. If this occurs, make sure your BIOS correctly supports the PCI Local Bus Specification (v2.2 or later) and upgrade your computer BIOS to the latest version.

Some PCI computers are not self-configuring and require you to perform some or all of the following functions by motherboard jumper changes and/or BIOS Setup program configuration:

- ◆ Verify that the PCI slot is an enabled busmaster slot and not a slave PCI slot. The EZ Card 1000 must be installed in a PCI busmaster slot. In some computers the PCI slot must be configured to enable bus mastering. Refer to your PC's manual and check the PCI BIOS Setup program to be sure the PCI slot is an enabled busmaster slot.
- ◆ In some computers, you may be required to disable Plug 'n Play (PnP) in the BIOS Setup program if resources are not properly assigned between the network card and other installed cards.
- ◆ Some computers may require you to reserve interrupts and memory addresses for installed ISA cards to prevent PCI cards from using the same settings. Refer to your PC's manual and check the PCI BIOS Setup program configuration options for ISA cards.

- ◆ Make sure the PCI slot is configured to support INTA.
- ◆ Ensure that INTA for the slot is assigned to a free interrupt (IRQ) number.
- ◆ Check the BIOS Setup program's PCI parameters for the slot where the EZ Card 1000 network card is installed. Ensure the slot is configured for level-triggered interrupts instead of edge-triggered interrupts. An example of typical PCI parameters follows:

PCI Slot #:	<i>(slot number where the network card is installed)</i>
Master:	Enabled
Slave:	Enabled
Latency Timer:	40 (range is 20 to 255)
Interrupt Type:	Level-Triggered
Interrupt Number:	<i>(choose any number the BIOS Setup supplies that does not conflict with another installed card)</i>

Note that the wording of these parameters varies with different computers, and not all parameters may be configurable.

Always consult your computer manual for information on changing motherboard jumper settings and BIOS Setup program parameters for use with PCI network cards. If you set a motherboard jumper and modify the computer's BIOS Setup, make sure the jumper and BIOS settings match.

Solutions for Common Problems

Problems are often caused by cabling errors, conflicts with other devices installed in the same computer, or software that has been configured incorrectly. If you encounter a problem with the EZ Card 1000 network card, use the following checklists to identify and correct the problem.

Network Card Installation Problems

If your computer cannot find The EZ Card 1000 or the network driver does not install correctly, check the following items before contacting SMC Technical Support.

- ◆ Make sure the card is securely seated in the PCI slot. Check for any hardware problems, such as physical damage to the card's edge connector.
- ◆ Try the card in another PCI busmaster slot. If all fails, test with another EZ Card 1000 card that is known to operate correctly.
- ◆ Check for resource conflict in the PCI configuration. See section "PCI Compatibility" in this chapter.
- ◆ Make sure your computer is using the latest BIOS available.
- ◆ If there are other network cards in the computer, they may be causing conflict. Remove all other cards from the computer and test the EZ Card 1000 separately.
- ◆ Check for a defective computer or PCI bus by trying the network card in another computer that is known to operate correctly.

Network Connection Problems

If your computer cannot find the EZ Card 1000 card or the network driver does not install correctly, check the following items before contacting SMC Technical Support.

- ◆ Make sure the card is securely seated in the PCI slot. Check for any hardware problems, such as physical damage to the card's edge connector.
- ◆ Try the card in another PCI busmaster slot. If all fails, test with another EZ Card 1000 card that is known to operate correctly.
- ◆ Check for resource conflict in the PCI configuration. See section "PCI Compatibility" in this chapter.
- ◆ Make sure your computer is using the latest BIOS available.
- ◆ If there are other network cards in the computer, they may be causing conflict. Remove all other cards from the computer and test the EZ Card 1000 separately.
- ◆ Check for a defective computer or PCI bus by trying the network card in another computer that is known to operate correctly.
- ◆ Make sure your computer is using the latest BIOS available.
- ◆ If you cannot access a Windows or NetWare service on the network, check that you have enabled and configured the service correctly. If you cannot connect to a particular server, ensure that you have access rights and a valid ID and password.
- ◆ If you cannot access the Internet, be sure you have configured your system for TCP/IP.

APPENDIX B

CABLES

Cable Specifications

Cable Types and Specifications			
Cable	Type	Max. Length	Connector
10BASE-T	Cat. 3, 4, 5 100-ohm UTP	100 m (328 ft)	RJ-45
100BASE-TX	Cat. 5 100-ohm UTP	100 m (328 ft)	RJ-45
1000BASE-T	Cat. 5, 5e 100-ohm UTP	100 m (328 ft)	RJ-45

Twisted-Pair Cable and Pin Assignments

Caution: DO NOT plug a phone jack connector into any RJ-45 port. Use only twisted-pair cables with RJ-45 connectors that conform with FCC standards.

For 10BASE-T/100BASE-TX connections, a twisted-pair cable must have two pairs of wires. Each wire pair is identified by two different colors. For example, one wire might be red and the other, red with white stripes. Also, an RJ-45 connector must be attached to both ends of the cable.

For 1000BASE-T connections, a twisted-pair cable must have four pairs of wires and have RJ-45 connectors attached to both ends of the cable.

Caution: Each wire pair must be attached to the RJ-45 connectors in a specific orientation.

Figure B-1 illustrates how the pins on the RJ-45 connector are numbered. Be sure to hold the connectors in the same orientation when attaching the wires to the pins.




Figure B-1. RJ-45 Connector Pin Numbers

10BASE-T/100BASE-TX Pin Assignments

With 10BASE-T/100BASE-TX cable, pins 1 and 2 are used for transmitting data, and pins 3 and 6 for receiving data. The “+” and “-” signs in the tables below are used to represent the polarity of the wires that make up each wire pair.

RJ-45 Pin Assignments	
Pin	Assignment*
1	Tx+
2	Tx-
3	Rx+
6	Rx-

1000BASE-T Pin Assignments

The table below shows the 1000Base-T pinouts for a straight-through cable connection. These ports require that all four pairs of wires be connected. Note that for 1000Base-T operation, all four pairs of wires are used for both transmit and receive.

Connector A		Connector B
1	<- - - - - >	1
2	<- - - - - >	2
3	<- - - - - >	3
6	<- - - - - >	6
4	<- - - - - >	4
5	<- - - - - >	5
7	<- - - - - >	7
8	<- - - - - >	8

CABLES

APPENDIX C

SPECIFICATIONS

Bus Interface

32-bit and 64-bit bus master, PCI

Interrupt

INTA

Network Interface

1000BASE-T:

UTP cable; Category 5, 5e or better

100BASE-TX:

UTP cable; Category 5

10BASE-T:

UTP cable; Category 3, 4, or 5

Data Rate

1000 Mbps, 100 Mbps, 10 Mbps half and full duplex

Cabling

4 pairs of Category 5, 5e or better UTP cable:
maximum 100 m (328 ft)

LED Indicators

1000, 1000, and 10 Mbps link
Activity

Operating Voltage

+5 VDC @ 2.7 A maximum

Size (without bracket)

3.11 x 6.50 in. (7.9 x 16.5 cm)

SPECIFICATIONS

Weight

2.8 oz (80g)

Temperature

Operating 32 to 140 °F (0 to 60 °C)

Storage -40 to 18 °F (-22 to 85 °C)

Humidity

5 to 95% (non-condensing)

Standards

IEEE 802.3ab 1000BASE-T

IEEE 802.3u 100BASE-TX

IEEE 802.3 10BASE-T

IEEE 802.3x Full-Duplex flow control

PCI v2.2

Compliances

CE Mark

Emissions

FCC Class B

VCCI Class B

Industry Canada Class B

EN55022 (CISPR 22) Class B

Safety

UL 1950

CSA 22.2 No. 950

EN60950 (T.V)

Warranty

Limited lifetime

Software Drivers

ODI Drivers	NetWare Server 4.11 or later
NDIS Drivers	Windows NT 4.0 Windows 98 Windows ME Windows 2000
Unix Drivers	Linux 2.2.X or later

SPECIFICATIONS

GLOSSARY

10BASE-T

IEEE 802.3 specification for 10 Mbps Ethernet over two pairs of Category 3, 4, or 5 UTP cable.

100BASE-TX

IEEE 802.3u specification for 100 Mbps Fast Ethernet over two pairs of Category 5 UTP cable.

1000BASE-T

IEEE 802.3ab specification for Gigabit Ethernet over four pairs of Category 5 UTP cable.

Bandwidth

The difference between the highest and lowest frequencies available for network signals. Also synonymous with wire speed, the actual speed of the data transmission along the cable.

Collision

A condition in which packets transmitted over the cable interfere with each other. Their interference makes both signals unintelligible.

Collision Domain

Single CSMA/CD LAN segment.

CSMA/CD

CSMA/CD (Carrier Sense Multiple Access/Collision Detect) is the communication method employed by Ethernet and Fast Ethernet.

End Station

A workstation, server, switch, bridge or router.

Ethernet

A network communication system developed and standardized by DEC, Intel, and Xerox, using baseband transmission, CSMA/CD access, logical bus topology, and coaxial cable. The successor IEEE 802.3 standard provides for integration into the OSI model and extends the physical layer and media with repeaters and implementations that operate on fiber, thin coax and twisted-pair cable.

Fast Ethernet

A 100 Mbps network communication system based on Ethernet and the CSMA/CD access method.

Gigabit Ethernet

A 1000 Mbps network communication system based on Ethernet and the CSMA/CD access method.

Full Duplex

Transmission method that allows two network devices to transmit and receive concurrently, effectively doubling the bandwidth of that link.

IEEE 802.3

Defines carrier sense multiple access with collision detection (CSMA/CD) access method and physical layer specifications.

IEEE 802.3u

Defines CSMA/CD access method and physical layer specifications for 100BASE-TX Fast Ethernet.

IEEE 802.3ab

Defines CSMA/CD access method and physical layer specifications for 1000BASE-T Gigabit Ethernet over Category 5 UTP cable.

Local Area Network (LAN)

A group of interconnected computer and support devices.

LAN Segment

Separate LAN or collision domain.

LED

Light emitting diode used for monitoring a device or network condition.

Local Area Network

A group of interconnected computers and support devices.

Media Access Control (MAC)

A portion of the networking protocol that governs access to the transmission medium, facilitating the exchange of data between network nodes.

MII

Media Independent Interface, the standard interface for Fast Ethernet—similar to the AUI interface for traditional Ethernet.

Network Diameter

Wire distance between two end stations in the same collision domain.

Switched Ports

Ports that are on separate collision domains or LAN segments.

Transmission Control Protocol/Internet Protocol (TCP/IP)

Protocol suite that includes TCP as the primary transport protocol, and IP as the network layer protocol.

UTP

Unshielded twisted-pair cable.

INDEX

A

Auto-Negotiation 2-2

B

BIOS requirements 1-5, A-1

bus-mastering 1-5, A-1

C

cable

adjusting Category 5 cable 1-8

guidelines 1-7

RJ-45 pin assignments B-3

specifications B-1

card installation 1-5

Category 5 cable 1-8

checklist of contents 1-4

compliances i

configuration

Linux 2-10

Windows 98 2-14

Windows NT 2-4

connection

guidelines 1-7

connections

Category 5 cable 1-8

UTP cable 1-9

contents of package 1-4

D

driver diskette 1-4

driver files 1-4, 1-7

driver installation 2-1

new or updated 1-7

other 2-16

Windows 95 2-14

Windows 98 2-14

E

EMC/safety compliance i

F

files on driver diskette 1-4

H

hardware, troubleshooting A-3

host requirements 1-5

I

indicators 1-3

installation

instructions 1-5

Linux 2-10

NetWare Server 5.0 2-6

other systems 2-16

problems A-3

Windows 2000 2-5

Windows 98 2-14

L

LED indicators

Model SMC9462TX 1-3

LEDs 1-3

Linux driver installation 2-10

N

NetWare Installation 2-6
NetWare Server 5.0 2-6
network status LEDs 1-3

P

package contents 1-4
PC requirements 1-5
PCI
 bus specification 1-5
 compatibility A-1
 configuration 1-7
pin assignments B-1

R

RELEASE.TXT file 1-7
requirements of system 1-5
RJ-45 connector 1-2, B-2
RJ-45 ports
 pinouts B-3

S

specifications
 cable B-1
static electricity warning 1-5
SuperDisk 1-4, 1-7, 2-16
system requirements 1-5

T

TCP/IP installation 2-2
EZ Card 1000 models 1-2

troubleshooting
 common problems A-3
 hardware problems A-3
 network connection A-4
 PCI compatibility A-1
twisted-pair cable B-1

U

UTP cable
 pin assignments B-1
 specifications B-1

W

Web site, SMC 2-16
Windows 2000 installation 2-5
Windows 95 drivers 2-14
Windows 98 installation 2-14

FOR TECHNICAL SUPPORT, CALL:

From U.S.A. and Canada (8:30 AM - 8:00 PM Pacific Time)
(800) SMC-4-YOU; (949) 707-2400; (949) 707-2460 (Fax)
From Europe (8:00 AM - 5:30 PM UK Greenwich Mean Time)
44 (0) 1189 748740; 44 (0) 1189 748741 (Fax)

INTERNET

E-mail addresses:

techsupport@smc.com
european.techsupport@smc-europe.com

Driver updates:

<http://www.smc.com/support.html>

World Wide Web:

<http://www.smc.com/>

FTP Site:

<ftp.smc.com>

FOR LITERATURE OR ADVERTISING RESPONSE, CALL:

U.S.A. and Canada:	(800) SMC-4-YOU;	Fax (949) 707-2460
Spain:	34-93-477-4920;	Fax 34-93-477-3774
UK:	44 (0) 1189 748700;	Fax 44 (0) 1189 748701
Southern Europe:	33 (1) 41.18.68.68;	Fax 33 (1) 41.18.68.69
Central/Eastern Europe:	49 (0) 89 92861-200;	Fax 49 (0) 89 92861-230
Nordic:	46 (8) 564 33145;	Fax 46 (8) 87 62 62
Middle East:	971-4-8818410;	Fax 971-4-8817993
South Africa:	27 (0) 11-3936491;	Fax 27 (0) 11-3936491
PRC:	86-10-6235-4958;	Fax 86-10-6235-4962
Taiwan:	886-2-2747-4780;	Fax 886-2-2747-9220
Asia Pacific:	(65) 238 6556;	Fax (65) 238 6466
Korea:	82-2-553-0860;	Fax 82-2-553-7202
Japan:	81-45-224-2332;	Fax 81-45-224-2331
Australia:	61-2-9416-0437;	Fax 61-2-9416-0474
India:	91-22-8204437;	Fax 91-22-8204443

SMC[®]

Networks

6 Hughes

Irvine, CA 92618

Phone: (949) 707-2400

Model Number: SMC9462TX

Publication Number: 150416-102 E032001-R01

SMC[®]
N e t w o r k s

6 Hughes

Irvine, CA 92618

Phone: (949) 707-2400

