

SmartLink 4020

SmartLink Analog VoIP SoHo Router

Getting Started Guide



Sales Office: +1 (301) 975-1000
Technical Support: +1 (301) 975-1007
E-mail: support@patton.com
WWW: www.patton.com



Patton Electronics Company, Inc.

7622 Rickenbacker Drive
Gaithersburg, MD 20879 USA
Tel: +1 (301) 975-1000
Fax: +1 (301) 869-9293
Support: +1 (301) 975-1007
Web: www.patton.com
E-mail: support@patton.com

Trademark Statement

The terms *SmartLink*, *SmartNode*, *SmartWare*, and *SmartView* are trademarks of Patton Electronics Company. All other trademarks presented in this document are the property of their respective owners.

Copyright © 2005, Patton Electronics Company. All rights reserved.

The information in this document is subject to change without notice. Patton Electronics assumes no liability for errors that may appear in this document.

Warranty Information

Patton Electronics warrants all SmartLink router components to be free from defects, and will—at our option—repair or replace the product should it fail within one year from the first date of the shipment.

This warranty is limited to defects in workmanship or materials, and does not cover customer damage, abuse or unauthorized modification. If the product fails to perform as warranted, your sole recourse shall be repair or replacement as described above. Under no condition shall Patton Electronics be liable for any damages incurred by the use of this product. These damages include, but are not limited to, the following: lost profits, lost savings and incidental or consequential damages arising from the use of or inability to use this product. Patton Electronics specifically disclaims all other warranties, expressed or implied, and the installation or use of this product shall be deemed an acceptance of these terms by the user.

Firmware Revision Information

This version of the Getting Started Guide is based on firmware revision (1026).

Summary Table of Contents

1	General information	19
2	SmartLink installation	21
3	Home	24
4	Network—WAN	27
5	Network—LAN	39
6	Telephony	45
7	System	62
8	Documentation	81
9	Logout	83
10	Contacting Patton for assistance	86
A	Compliance information	89
B	Specifications	91
C	Dial plans	94
D	Calling Features	97

Table of Contents

Summary Table of Contents	3
Table of Contents	4
List of Figures	13
List of Tables	15
About this guide	16
Audience.....	16
Structure.....	16
Precautions.....	17
Safety when working with electricity	17
General observations	18
Typographical conventions used in this document.....	18
General conventions	18
1 General information.....	19
SmartLink 4020 overview.....	20
2 SmartLink installation.....	21
Installing the router.....	22
3 Home.....	24
System information	25
System Uptime	25
WAN IP Address	25
LAN IP Address	25
MAC address	25
Application Version	26
Config Date	26
Security	26
Application Code Version	26
Downloader Code Version	26
System Status.....	26
SIP Messages Sent	26
SIP Messages Received	26
SIP Bytes Sent	26
SIP Bytes Received	26
RTP Packets Sent	26
RTP Packets Received	26
RTP Bytes Sent	26
RTP Bytes Received	26
4 Network—WAN.....	27
Status.....	29
Interface Status	29

Enabled	29
Service	29
Protocol	29
Interface Status	29
Network Settings	29
Dynamic IP Assignment	29
IP address	29
MAC address	30
Subnet Mask	30
Default Gateway	30
Domain name	30
DNS address	30
DynDNS address	30
VLAN	30
Priority Tag	30
Settings.....	30
Internet Configuration	31
Device Operating Mode	31
Obtain WAN configuration dynamically	31
Specify fixed WAN configuration	31
WAN PPPoE Configuration	32
Enable PPPoE	32
Authentication	32
Settings	32
Idle Timeout	32
Echo Timeout	32
Echo Count	32
Service Name	32
AC Name	32
Dynamic DNS	32
Configuring Dynamic DNS	33
MAC Spoofing Configuration	33
WAN MAC Address (Spoofed)	33
MTU Size	34
MTU (Maximum Transfer Unit) Size	34
WAN VLAN Configuration	34
WAN VLAN Tag (IEEE 802.1q)	34
WAN Priority Tag (IEEE 802.1q)	34
Saving your work	34
QoS (Quality of Service).....	35
Enable Voice QoS	35
Assured Bandwidth for Voice	35
Maximum Uplink Bandwidth Allowed	35
Saving your work	35

ToS/DiffServ	35
Saving your work	36
IPSec Configuration	36
Select Tunnel to view/modify	36
Enable tunnel 1	36
Remote IP Address range	36
Remote security gateway	36
Security Mode	36
Outbound AH SPI (DEC)	36
Outbound AH Authentication Algorithm	37
Outbound AH Authentication Key (HEX)	37
Outbound ESP SPI (DEC)	37
Outbound ESP Encryption Algorithm	37
Outbound ESP Authentication Algorithm	37
Outbound ESP Encryption Key (HEX)	37
Outbound ESP Authentication Key (HEX)	37
Inbound AH SPI (DEC)	37
Inbound AH Authentication Algorithm	37
Inbound AH Authentication Key (HEX)	37
Inbound ESP SPI (DEC)	37
Inbound ESP Encryption Algorithm	37
Inbound ESP Authentication Algorithm	37
Inbound ESP Encryption Key (HEX)	37
Inbound ESP Authentication Key (HEX)	38
Saving your work	38
5 Network—LAN	39
Settings	40
Network Settings	40
Saving your work	40
DHCP	40
Server Settings	41
Client IP Address Range	41
Client Network Information	41
Domain Name	41
DNS Server	41
Static Address Assignment	41
Viewing the DCHP Client Table	41
Saving your work	41
Routing	42
Dynamic Routing	42
Static Routing	42
Viewing the Routing Table	42
Saving your work	42

Port Forwarding	43
Reserved Ports	43
Port Forwarding to LAN	43
De-Militarized Zone	43
Saving your work	43
IP Filtering	43
Filter IP Range	44
Saving your work	44
6 Telephony	45
VoIP Status	48
VoIP Server Registration Status	48
Current Server	48
Domain	48
Base RTP Port	48
Phone Line Status	48
Registration Status	48
User Name	49
Caller ID Setting	49
Subscribed for Voicemail	49
Messages waiting	49
SIP	49
SIP Configuration	50
SIP Server Settings	50
Gateway Settings	50
Dial Plan	50
SIP Extensions	51
Support PRACK method	51
Encode SIP URI with user parameter	51
Send INVITE with Timer header	51
Call Hold using C=0.0.0	51
Send NOTIFY	51
RTP Telephone Event Configuration	51
VoIP VLAN Configuration	51
SIP Parameters	52
Hook Flash MIME Type	52
SIP Timer Values (milliseconds)	52
SIP T1	52
SIP T2	52
SIP T4	52
RTP Parameters	52
NAT Traversal	53
Outbound Proxy IP	53
Outbound Proxy Port	53

Stun Server IP	53
Stun Server Port	53
UPnP	53
NONE	53
Saving your work	53
Audio/CODEC Configuration	54
CODECS	54
Packetization	54
Jitter Buffer	54
FAX without T.38 (Use G.711 fax)	55
Saving your work	55
Phone 1 & Phone 2	55
User Information	56
Phone Number	56
User Name	56
Port	56
CallerID Name	56
Password	56
Supplementary Service Activation	56
Call Forward All	57
Selective Call Forward	57
Three-Way Conferencing	57
Incoming Call Block	57
Distinctive Ring	57
Call Transfer	57
Dialing by IP Address	57
Speed Dial	57
Message Waiting Indicator	57
Call Forward on Busy	58
Conditional Call Forward	58
Call Waiting	58
Anonymous Call Reject	58
Caller ID	58
Call Return	58
Do Not Disturb	58
Self Caller ID Block	58
Outgoing Call Block	58
Dial Out Type	58
Dial Out Type	58
Hot Line Number	58
Warm Line Number	59
Call Forward Settings	59
Cfwd All Dest	59
Cfwd Busy Dest	59

Selective Call Forward Settings	59
Incoming caller #1–8	59
Forward destination #1–8	59
Incoming Call Block	60
Block Caller ID	60
Outgoing Call Block	60
Digit Pattern	60
HTTP Digest Setting	60
Saving your work	60
Speed Dial	61
Line 1 Speed Dial Settings	61
Speed Dial Serv	61
Speed Dial 1–8 Phone Number/IP Dialing	61
Line 2 Speed Dial Settings	61
Speed Dial Serv	61
Speed Dial 1–8 Phone Number/IP Dialing	61
Saving your work	61
7 System	62
Set Security Password	65
Web Page Protect	65
New Root Password	65
New User Password	65
Confirm new password	66
Saving your work	66
Configuration	66
Logging	66
Enable Syslog	66
Syslog Server	66
Enable Debug	67
Debug Server	67
Debug Connect Port	67
Saving your work	67
Service Access	68
Enable HTTP	68
Enable Ping Reply	68
Saving your work	68
Localization	68
Call Progress Tones	69
Dial Tone	69
Prompt Tone	69
Confirm Tone	69
Holding Tone	69
Busy Tone	70

Ring Back Tone	70
Off Hook Warning	70
Distinctive Ring Setting 1-8	70
Supplementary Service Keys	71
Call forward All	72
Call forward on Busy	72
Call forward selective	72
Call Waiting	72
Incoming Call Block	72
Block Anonymous Calls	72
Distinctive Ring	72
Warm Line	72
Do Not Disturb	72
IP Dialing	72
Speed Dialing	73
Income Caller ID	73
Self Caller ID Block	73
Calling Prefix Keys	73
Call Return	73
Warm Line	73
Speed Dial	73
Call Forward All	74
IP Dialing	74
Call Hold	74
Call Waiting (call alternative)	74
Call Conference	74
Call Conference Drop	74
Call Transfer	74
Voicemail access	74
Call Forward Busy Destination	74
Hotline	75
Control Timer Values	75
Hook Flash Timer	75
SIP Session Timer value	75
Conditional Call Forwarding Timer	75
Warm Line Delay	75
Interdigit Timer	76
Offhook Idle Time	76
Offhook Warning tone time	76
FXS Port	76
FXS port Input Gain	76
FXS port Output Gain	76
Caller ID Method	76
“Call Progress Tones” Synchronization	76

Ring Setting	76
Ring Waveform	76
Ring Frequency	77
Ring Voltage	77
FXS Port Polarity Configuration	77
Idle Polarity	77
Caller Conn Polarity	77
Saving your work	77
SNMP Configuration	77
SNMP Trap Configuration	77
IP address	77
Trap Community	77
SNMP Community Configuration	78
Read Community	78
Write Community	78
SNMP System Configuration	78
System Description	78
System Object Id	78
Saving your work	78
Auto Upgrade.....	78
Routine Upgrade every xxx day(s)	78
Enable Auto Upgrade	79
Auto Upgrade Protocol	79
Upgrade Server	79
Auto Upgrade URL	79
Saving your work	79
Manual Upgrade.....	79
Reload	80
8 Documentation	81
Introduction	82
9 Logout.....	83
Introduction	84
10 Contacting Patton for assistance	86
Introduction	87
Contact information	87
Patton support headquarters in the USA	87
Alternate Patton support for Europe, Middle East, and Africa (EMEA)	87
Warranty Service and Returned Merchandise Authorizations (RMAs).....	87
Warranty coverage	87
Out-of-warranty service	88
Returns for credit	88
Return for credit policy	88
RMA numbers	88

Shipping instructions	88
A Compliance information	89
Compliance	90
EMC Compliance:	90
Safety Compliance	90
Radio and TV Interference	90
CE notice (Declaration of Conformity)	90
B Specifications	91
Voice Connectivity	92
Connectivity	92
Voice Processing (signalling dependent)	92
Fax and Modem Support	92
Voice Services/Features	93
IP Services	93
Management	93
Operating Environment	93
System	93
C Dial plans	94
Introduction	95
Sample Dial Plans	95
Simple Dial Plan	95
Non-dialed Line Dial Plan	95
Complex Dial Plan	95
D Calling Features	97
Introduction	98

List of Figures

1	SmartLink 4020	20
2	SmartLink 4020 installation diagram	22
3	Router front panel LEDs	23
4	SmartLink VoIP download and configuration Home page	25
5	Internet Status window	29
6	Internet Configuration section of the Settings window	31
7	WAN PPPoE Configuration section of the Settings window	32
8	Dynamic DNS Service window	33
9	MAC Spoofing Configuration section of the Settings window	33
10	MTU section of the Settings window	34
11	WAN VLAN Configuration section of the Settings window	34
12	QoS window	35
13	TOS/DiffServ window	35
14	IPSec Configuration window	36
15	Network Settings window	40
16	DHCP Server Configuration window	40
17	DHCP Client Table window	41
18	Router Configuration window	42
19	Routing Table window	42
20	Port Forwarding Configuration window	43
21	IP Filtering window	43
22	VoIP Status window	48
23	SIP Configuration section of the SIP window	50
24	Gateway Settings section of the SIP window	50
25	SIP Extensions section of the SIP window	51
26	RTP Telephone Event Configuration section of the SIP window	51
27	VoIP VLAN Configuration section of the SIP window	52
28	SIP Parameters section of the SIP window	52
29	NAT Traversal section of the SIP window	53
30	Audio/CODEC Configuration window	54
31	User Information section of Phone 1 or Phone 2 window	56
32	Supplementary Service Settings section of Phone 1 or Phone 2 window	57
33	Dial Out Type section of Phone 1 or Phone 2 window	58
34	Call Forward Settings section of Phone 1 or Phone 2 window	59
35	Selective Call Forward Settings section of Phone 1 or Phone 2 window	59
36	Incoming Call Block section of Phone 1 or Phone 2 window	60
37	Incoming Call Block section of Phone 1 or Phone 2 window	60
38	HTTP Digest Setting section of Phone 1 or Phone 2 window	60
39	Speed Dial window	61
40	Set Security Password window	65
41	Configuration window	66
42	Service Access window	68
43	Call Progress Tones section of Localization window	69
44	Distinctive Ring Setting section of Localization window	70
45	Supplementary Service Keys section of Localization Window	72
46	Calling Prefix Keys section of Localization Window	73
47	Control Timer Values section of Localization window	75

48	FXS Port Polarity Configuration section of Localization window	76
49	Ring Setting section of Localization window	76
50	FXS Port Polarity section of Localization window	77
51	SNMP Configuration window	77
52	AutoUpgrade window	78
53	Manual Upgrade window	79
54	Reload window	80
55	Documentation link	82
56	Logout window	84
57	Password verification page	84

List of Tables

1	General conventions	18
2	Bellcore standard ring cadence patterns	71
3	Calling features	98

About this guide

This guide describes using the SmartLink 4020 router.

Audience

This guide is intended for the following users:

- Operators
- Installers
- Maintenance technicians

Structure

This guide contains the following chapters and appendices:

- [Chapter 1](#) on page 19 provides information about router features and capabilities
- [Chapter 2](#) on page 21 provides hardware installation procedures
- [Chapter 3](#) on page 24 describes the Home section settings
- [Chapter 4](#) on page 27 describes the WAN section settings
- [Chapter 5](#) on page 39 describes the LAN section settings
- [Chapter 6](#) on page 45 describes the Telephony section settings
- [Chapter 7](#) on page 62 describes the System section settings
- [Chapter 8](#) on page 81 describes how to download and display the SmartLink 4020 router user guide
- [Chapter 9](#) on page 83 describes how to log out of the router management system
- [Chapter 10](#) on page 86 contains information on contacting Patton technical support for assistance
- [Appendix A](#) on page 89 contains compliance information for the router
- [Appendix B](#) on page 91 contains specifications for the router
- [Appendix C](#) on page 94 describes dialing plans and contains sample plans
- [Appendix D](#) on page 97 describes the calling features that can be accessed from phones attached to the SmartLink 4020

For best results, read the contents of this guide *before* you install the router.

Precautions

Notes, cautions, and warnings, which have the following meanings, are used throughout this guide to help you become aware of potential problems. **Warnings** are intended to prevent safety hazards that could result in personal injury. **Cautions** are intended to prevent situations that could result in property damage or impaired functioning.

Note A note presents additional information or interesting sidelights.



The alert symbol and **IMPORTANT** heading calls attention to important information.



The alert symbol and **CAUTION** heading indicate a potential hazard. Strictly follow the instructions to avoid property damage.



The shock hazard symbol and **CAUTION** heading indicate a potential electric shock hazard. Strictly follow the instructions to avoid property damage caused by electric shock.



The alert symbol and WARNING heading indicate a potential safety hazard. Strictly follow the warning instructions to avoid personal injury.



The shock hazard symbol and WARNING heading indicate a potential electric shock hazard. Strictly follow the warning instructions to avoid injury caused by electric shock.

Safety when working with electricity



The SmartLink contains no user serviceable parts. The equipment shall be returned to Patton Electronics for repairs, or repaired by qualified service personnel.



Mains Voltage: Do not open the case when the power cord is attached. For systems without a power switch, line voltages are present within the power supply when the power cords are connected. The mains outlet that is utilized to power the SmartLink shall be within 10 feet (3 meters) of the device, shall be easily accessible, and protected by a circuit breaker.



For AC powered units, ensure that the power cable meets all applicable standards for the country in which it is to be installed, and that it is connected to a wall outlet which has earth ground.



Do not work on the system or connect or disconnect cables during periods of lightning activity.



Ultimate disposal of this equipment must be handled according to all applicable national laws and regulations.

General observations

- Clean the case with a soft slightly moist anti-static cloth
- Place the unit on a flat surface and ensure free air circulation
- Avoid exposing the unit to direct sunlight and other heat sources
- Protect the unit from moisture, vapors, and corrosive liquids

Typographical conventions used in this document

This section describes the typographical conventions and terms used in this guide.

General conventions

The procedures described in this manual use the following text conventions:

Table 1. General conventions

Convention	Meaning
Garamond blue type	Indicates a cross-reference hyperlink that points to a figure, graphic, table, or section heading. Clicking on the hyperlink jumps you to the reference. When you have finished reviewing the reference, click on the Go to Previous View button  in the Adobe® Acrobat® Reader toolbar to return to your starting point.
Garamond bold type	Indicates the names of command buttons that execute an action.
< >	Angle brackets indicate function and keyboard keys, such as <SHIFT>, <CTRL>, <C>, and so on.

Chapter 1 **General information**

Chapter contents

SmartLink 4020 overview.....	20
------------------------------	----

SmartLink 4020 overview

The SmartLink VoIP SoHo Router (see [figure 1](#)) provides transparent connectivity for analog phones and faxes to the world of Internet voice. Connecting to any analog phone, fax or PBX, the SmartLink product is an effective and flexible solution for small offices and telecommuters to access Internet-based telephone services and corporate intranet systems across established LAN and Internet connections like xDSL and cable modems.



Figure 1. SmartLink 4020

The SmartLink Model 4021 provides two RJ-45 Ethernet ports and one FXS (RJ-11) analog phone port. The SmartLink Model 4022 provides two RJ-45 Ethernet ports and two FXS (RJ-11) analog phone ports. Front panel LEDs quickly show at-a-glance the status of the system, LAN, WAN, and phone ports.

A full suite of IP features (DHCP, NAT/PAT, NTP and VPN) are available to LAN devices attached downstream. VLAN tagging and prioritization enables voice traffic to be handled before data traffic. Support for PPPoE and IPSEC tunneling simplifies extending corporate intranet services to remote teleworkers.

The web interface offers two levels of configuration access for the network operator and end user. The friendly web interface and product labeling (Phone, LAN, WAN etc.) to help ensure a trouble-free installation for the end user. Configuration and firmware can be downloaded from a TFTP server or HTTP server.

Chapter 2 **SmartLink installation**

Chapter contents

Installing the router	22
-----------------------------	----

Installing the router

Do the following:




Figure 2. SmartLink 4020 installation diagram

- Place the unit on a desktop or similar sturdy, flat surface that offers easy access to the cables. The unit should be installed in a dry environment with sufficient space to allow air circulation for cooling.

Note For proper ventilation, leave at least 2 inches (5 cm) of clearance at the sides, front, and rear of the unit.

- Set your LAN Local Area Connection Properties for Internet Protocol (TCP/IP) to *Obtain an IP address automatically* and to *Obtain DNS server address automatically*.



Do not work on the system or connect or disconnect cables during periods of lightning activity.



The Interconnecting cables shall be acceptable for external use and shall be rated for the proper application with respect to voltage, current, anticipated temperature, flammability, and mechanical serviceability

- Plug in the telephone or telephones (see figure 2).
- Plug in the PC or LAN, or a LAN hub/switch.

Note The SmartLink has automatic MDX (auto-crossover) detection and configuration on all Ethernet ports. Any of the ports can be connected to a host or hub/switch with a straight-through wired cable.

- 5 Connect to the Internet service provider.



The external router power supply automatically adjusts to accept an input voltage from 100 to 240 VAC (50/60 Hz).

Verify that the proper voltage is present before plugging the power cord into the receptacle. Failure to do so could result in equipment damage.

- 6 Verify that the AC power cord included with your router is compatible with local standards. If it is not, refer to “[Contacting Patton for assistance](#)” on page 86 to find out how to replace it with a compatible power cord. Plug the power adapter into the *12V DC, 1.0A* port on the SmartLink 4020. Connect the other end of the power cord to an appropriate AC power outlet.
- 7 Wait 30 seconds after powering the SmartLink 4020 on, then verify that the green *Power LED* is lit (see [figure 3](#)). At this point, you should be able to use your browser to surf the Internet.

Note Follow the directions of your voice service provider to set up voice services.




Figure 3. Router front panel LEDs

Chapter 3 **Home**

Chapter contents

System information	25
System Uptime	25
WAN IP Address	25
LAN IP Address	25
MAC address	25
Application Version	26
Config Date	26
Security	26
Application Code Version	26
Downloader Code Version	26
System Status.....	26
SIP Messages Sent	26
SIP Messages Received	26
SIP Bytes Sent	26
SIP Bytes Received	26
RTP Packets Sent	26
RTP Packets Received	26
RTP Bytes Sent	26
RTP Bytes Received	26

System information




Figure 4. SmartLink VoIP download and configuration Home page

System Uptime

Shows how long the SmartLink 4020 has been operating since the last time it was reloaded (either by powering the unit off and then on again, or by selecting *System > Reload*).

WAN IP Address

The IP address of the SmartLink 4020 on the WAN interface.

LAN IP Address

The IP address of the SmartLink 4020. If (*Static*) is shown next to the address, it means the IP address was assigned to the SmartLink 4020 under the WAN Settings. (*Dynamic*) indicates the IP address was learned via DHCP.

MAC address

The media access control (MAC) address of the Ethernet interface in the SmartLink.

Application Version

The SmartLink firmware version number.

Config Date

The date of the configuration file that was downloaded from an auto-upgrade server.

Security

Indicates that the SmartLink web interface utility has been secured with a password. To configure a password, see section “Set Security Password” on page 65.

Application Code Version

Shows the application code version being used.

Downloader Code Version

Shows the downloader code version being used.

System Status

Shows VoIP statistics for the period of time since the SmartLink 4020 was last reloaded (either by powering the unit off and then on again, or by selecting *System > Reload*).

SIP Messages Sent

Total number of VoIP SIP messages sent (including retransmissions).

SIP Messages Received

Total number of VoIP SIP messages received (including retransmissions).

SIP Bytes Sent

Total number of bytes of VoIP SIP messages sent (including retransmissions).

SIP Bytes Received

Total number of bytes of VoIP SIP messages received (including retransmissions).

RTP Packets Sent

Total number of VoIP RTP packets sent (including redundant packets).

RTP Packets Received

Total number of VoIP RTP packets received (including redundant packets).

RTP Bytes Sent

Total number of VoIP RTP bytes sent.

RTP Bytes Received

Total number of VoIP RTP bytes received.

Chapter 4 Network—WAN

Chapter contents

Status.....	29
Interface Status	29
Enabled	29
Service	29
Protocol	29
Interface Status	29
Network Settings	29
Dynamic IP Assignment	29
IP address	29
MAC address	30
Subnet Mask	30
Default Gateway	30
Domain name	30
DNS address	30
DynDNS address	30
VLAN	30
Priority Tag	30
Settings.....	30
Internet Configuration	31
Device Operating Mode	31
Obtain WAN configuration dynamically	31
Specify fixed WAN configuration	31
WAN PPPoE Configuration	32
Enable PPPoE	32
Authentication	32
Settings	32
Idle Timeout	32
Echo Timeout	32
Echo Count	32
Service Name	32
AC Name	32
Dynamic DNS	32
Configuring Dynamic DNS	33
MAC Spoofing Configuration	33
WAN MAC Address (Spoofed)	33
MTU Size	34
MTU (Maximum Transfer Unit) Size	34
WAN VLAN Configuration	34
WAN VLAN Tag (IEEE 802.1q)	34

WAN Priority Tag (IEEE 802.1q)	34
Saving your work	34
QoS (Quality of Service).....	35
Enable Voice QoS	35
Assured Bandwidth for Voice	35
Maximum Uplink Bandwidth Allowed	35
Saving your work	35
ToS/DiffServ	35
Saving your work	36
IPSec Configuration	36
Select Tunnel to view/modify	36
Enable tunnel 1	36
Remote IP Address range	36
Remote security gateway	36
Security Mode	36
Outbound AH SPI (DEC)	36
Outbound AH Authentication Algorithm	37
Outbound AH Authentication Key (HEX)	37
Outbound ESP SPI (DEC)	37
Outbound ESP Encryption Algorithm	37
Outbound ESP Authentication Algorithm	37
Outbound ESP Encryption Key (HEX)	37
Outbound ESP Authentication Key (HEX)	37
Inbound AH SPI (DEC)	37
Inbound AH Authentication Algorithm	37
Inbound AH Authentication Key (HEX)	37
Inbound ESP SPI (DEC)	37
Inbound ESP Encryption Algorithm	37
Inbound ESP Authentication Algorithm	37
Inbound ESP Encryption Key (HEX)	37
Inbound ESP Authentication Key (HEX)	38
Saving your work	38

Status

Shows the status of key WAN network settings as configured under *WAN settings*

Interface Status



Figure 5. Internet Status window

Enabled

Yes indicates the WAN interface is enabled and ready to be used.

Service

Either *Routed* or *Bridged*, displays whether the SmartLink's WAN interface connection is operating in a routed or bridged mode.

Protocol

Indicates that the Ethernet protocol is being used to transfer data.

Interface Status

Either *Up* or *Down*.

Network Settings

These are the details of your WAN network settings.

Dynamic IP Assignment

Displays *Yes* (*via DHCP*) if you are using a dynamic IP address or *No* if a dynamic IP address is not being used.

IP address

The IP address of the SmartLink on the WAN interface.

MAC address

The MAC address of the WAN Ethernet interface in the SmartLink.

Subnet Mask

The subnet mask is 32-bit number that filters a destination IP address to determine to which subnet it belongs. For example, a subnet mask of *255.255.0.0* for a network ID of *192.5.0.0* tells the switch to accept traffic destined for IP addresses that begin with *192.5*—all other packets are ignored.

Default Gateway

The IP address of the gateway. The gateway IP address can be retrieved automatically in DHCP mode or be set up manually with a fixed IP address.

Domain name

The network domain name of the SmartLink.

DNS address

Refers to the address of your domain name server that was defined under WAN settings or that was learned dynamically through DHCP.

DynDNS address

The IP address of the dynamic DNS server that will be notified when the SmartLink 4020's dynamic IP address changes.

VLAN

VLAN tag value encoded in the WAN Ethernet header in all outgoing packets

Priority Tag

Priority tag value encoded in the WAN Ethernet header in outgoing packets.

Settings

The **Settings** window contains the following sections:

- Internet Configuration (see [figure 6](#) on page 31)
- WAN PPPoE Configuration (see [figure 7](#) on page 32)
- MAC Spoofing Configuration (see [figure 9](#) on page 33)
- MTU (see [figure 10](#) on page 34)
- Internet VLAN Configuration (see [figure 9](#) on page 33)

Note After configuring the sections, click the **Save Internet Settings** button (see [figure 5](#) on page 29) to save the new configuration.

Internet Configuration




Figure 6. Internet Configuration section of the Settings window

Device Operating Mode

Choose *Router* or *Bridged* depending on your operation.

Obtain WAN configuration dynamically

Select this option if appropriate. If you choose *Obtain WAN configuration dynamically*, the information is detected automatically through DHCP.

Specify fixed WAN configuration

Select this option if you will not be using DHCP. If you choose *Specify fixed WAN configuration*, you will have to enter the following information:

- IP address.
- IP of the netmask.
- IP of the gateway.
- IP of the DNS Server, if applicable.
- Host name (the name will identify the computer on the Internet, such as *SL4020.patton.com*).
- Domain name (the name that will identify one or more IP addresses). For example, the *patton.com* domain is used by Patton Electronics Company. That domain can include multiple hostnames (such as *SL4020.patton.com*, *ftp.patton.com*, and so on) that point to individual computers on the Patton network. In short, for the hostname URL *http://www.patton.com*, the domain name is *patton.com*.

WAN PPPoE Configuration

The screenshot shows the 'WAN PPPoE Configuration' section of a configuration interface. It includes the following fields:

- Enable PPPoE:** A dropdown menu set to "No".
- Authentication:**
 - Username:
 - Password:
- Settings:**
 - Idle Timeout: minutes
 - Echo Timeout: seconds
 - Echo Count:
 - Service Name:
 - AC Name:

Figure 7. WAN PPPoE Configuration section of the Settings window

Enable PPPoE

Select *Yes* to enable PPPoE or *No* to disable PPPoE.

Authentication

Enter the username and password provided by your ISP.

Settings

Idle Timeout. Idle timeout before PPP connection is closed due to inactivity

Echo Timeout. The duration between sending PPP echo requests to server.

Echo Count. The number of unanswered PPP echo requests before the PPP connection is closed.

Service Name. PPPoE Service name

AC Name. PPPoE access concentrator (AC) name

Dynamic DNS

The SL4020 supports Dynamic DNS for use in environments where the IP address of WAN IP interface is not assigned statically (i.e. permanently) but instead is assigned dynamically using protocols like DHCP.

With a statically assigned IP addresses, DNS is used to establish a fixed relationship between an IP address and a DNS name (example: 209.22.110.3 = joephone@patton.com). The DNS name allows the IP device, like a phone attached to an SL4020, to be found by the DNS name (joephone@patton.com) anywhere on the Internet.

Prior to Dynamic DNS, dynamically assigned IP address changes could not be automatically reflected in DNS. As a result, VoIP devices like the SL4020 could not always be located on the Internet by DNS name. This is especially true for cable modem and ADSL services that use DHCP to assign addresses to customers.

With Dynamic DNS, the SmartLink 4020 will inform the dynamic DNS server of its IP address when it receives a new or dynamically assigned IP address from the network. This allows the SL4020 to always be

found using a fixed DNS name when the IP address changes. With Dynamic DNS cable modem and ADSL users can be found on the Internet using a DNS name.

The DNS server used for registration is operated by Dynamic Network Services, Inc., Dynamic DNS (DynDNS). You can find detailed information about the company and the services it offers on the webpage www.dyndns.org. The company offers different levels of service. The basic services are offered free of charge, while the more advanced services are fee-based.



Figure 8. Dynamic DNS Service window

Configuring Dynamic DNS

1. Select *System > Configuration*.
2. **Choose Sever:** To enable DynamicDNS, select the name of the DYNDNS service from the drop-down menu (see [figure 8](#)).
3. **Host Name:** The host name is the name of the SL4020 as registered on the DYNDNS service.
4. **Username:** The user name is the user name as registered on the Dynamic DNS service.
5. **Password:** The password is the password as registered on the Dynamic DNS service.

MAC Spoofing Configuration

 A screenshot of a web-based configuration interface titled "MAC Spoofing Configuration". It includes sections for "WAN MAC Address (Spoofed)" (with a text input field), "MTU" (with a "MTU Size" field set to 1500 bytes), "WAN VLAN Configuration" (with "WAN VLAN Tag" and "WAN Priority Tag" fields), and a "Save Internet Settings" button at the bottom.

Figure 9. MAC Spoofing Configuration section of the Settings window

WAN MAC Address (Spoofed)

Only available when the unit is using the router mode. The spoofed MAC address to be used by the device's WAN interfaces, the Ethernet address of the outgoing packets from the WAN interface would be replaced with this address. If blank, the WAN interfaces will use the hardware value of MAC

MTU Size




Figure 10. MTU section of the Settings window

MTU (Maximum Transfer Unit) Size

The size limit (bytes) of the packet for all outgoing packets.

WAN VLAN Configuration

The SmartLink 4020 can mark outgoing Ethernet frames on the WAN interface with VLAN and priority tags. Other devices on the LAN can use the tags to control how frames from the SmartLink 4020 are processed. All data leaving the SmartLink 4020 will be marked with the specific value unless overridden on the telephony VLAN configuration settings.



Figure 11. WAN VLAN Configuration section of the Settings window

WAN VLAN Tag (IEEE 802.1q)

IEEE 802.1q Ethernet VLAN tag for all outgoing packets on WAN Ethernet interface. The value should be between 0 and 4094.

WAN Priority Tag (IEEE 802.1q)

IEEE 802.1q Ethernet Priority tag for all outgoing packets on WAN Ethernet interface. The value should be between 0 and 7.

Saving your work

When you are finished configuring the VLAN settings, click the **Save Internet Settings** button (see [figure 9](#) on page 33) to save all changes.

QoS (Quality of Service)

The screenshot shows a configuration window titled "QoS". It contains three main settings:

- Enable Voice QoS:** A dropdown menu set to "NO".
- Assured Bandwidth for Voice:** A text input field containing "48 (kbits/sec)".
- Maximum Uplink Bandwidth Allowed (kbits/sec):** A text input field containing "512 (kbits/sec)".

At the bottom of the window is a "Save Settings" button.

Figure 12. QoS window

Enable Voice QoS

Enable or disable the voice quality of service function. When QoS is enabled, the SmartLink 4020 will prioritize and rate-limit the introduction of voice and data traffic onto the WAN interface.

Assured Bandwidth for Voice

This parameter defines the guaranteed bandwidth for voice traffic on the WAN interface (in kbits/sec).

Maximum Uplink Bandwidth Allowed

The maximum uplink bandwidth that can be allocated to voice traffic.

Saving your work

When you are finished configuring settings, click the **Save Settings** button to save the changes.

ToS/DiffServ

This sub-page is used to configure the Type-of-Service/Diffserv byte values which are to be used in the IP header of all transmitted SIP signaling packets and RTP packets. The ToS/DiffServ byte values are entered as two-digit hexadecimal values. If no special ToS/DiffServ value is to be used for a particular traffic type, enter **00** or leave the setting empty.

The screenshot shows a configuration window titled "ToS/DiffServ". It contains two settings for packet types:

- Call Signalling Packets:** An input field with a placeholder "(2 Hex digit byte value)".
- RTP Packets:** An input field with a placeholder "(2 Hex digit byte value)".

At the bottom of the window is a "Save ToS/DiffServ Settings" button.

Figure 13. TOS/DiffServ window

Saving your work

When you are finished configuring ToS/DiffServ settings, click the **Save ToS/DiffServ Settings** button to save the changes.

IPSec Configuration

This page allows configuration of the device's IPSec (IP security) settings.

The screenshot shows the 'IPSec Configuration' window with 'Tunnel 1' selected. The window contains various configuration fields for both Outbound and Inbound tunnels, including dropdown menus for security mode, AH SPI, and authentication algorithms, and input fields for IP address ranges and keys.

Setting	Value
Select Tunnel to view/modify:	Tunnel 1
Enable tunnel 1:	No
Remote IP Address range:	[Input Field]
Remote security gateway:	[Input Field]
Security mode:	Tunnel
Outbound AH SPI (DEC):	[Input Field]
Outbound AH Authentication Algorithm:	HMAC-SHA1
Outbound AH Authentication Key (HEX):	[Input Field]
Outbound ESP SPI (DEC):	[Input Field]
Outbound ESP Encryption Algorithm:	NULL
Outbound ESP Authentication Algorithm:	NULL
Outbound ESP Encryption Key (HEX):	[Input Field]
Outbound ESP Authentication Key (HEX):	[Input Field]
Inbound AH SPI (DEC):	[Input Field]
Inbound AH Authentication Algorithm:	HMAC-SHA1
Inbound AH Authentication Key (HEX):	[Input Field]
Inbound ESP SPI (DEC):	[Input Field]
Inbound ESP Encryption Algorithm:	NULL
Inbound ESP Authentication Algorithm:	NULL
Inbound ESP Encryption Key (HEX):	[Input Field]
Inbound ESP Authentication Key (HEX):	[Input Field]

Figure 14. IPSec Configuration window

Select Tunnel to view/modify

Select the desired tunnel from the pop-up menu (up to 8 tunnels can be configured). The following sections and examples assume *Tunnel 1* was selected.

Enable tunnel 1

Enable/disable tunnel 1 IP sec

Remote IP Address range

Start and end of remote IP address range.

Remote security gateway

Remote security gateway IP address

Security Mode

IPSec mode (tunneling/transport)

Outbound AH SPI (DEC)

Outbound AH security parameter index number.

Outbound AH Authentication Algorithm

HMAC-MD5 or HMAC-SHA1

Outbound AH Authentication Key (HEX)

Hex number up to 40 nibbles

Outbound ESP SPI (DEC)

Outbound ESP security parameter index number

Outbound ESP Encryption Algorithm

3DES-CBC or DES-CBC

Outbound ESP Authentication Algorithm

HMAC-MD5 or HMAC-SHA1

Outbound ESP Encryption Key (HEX)

Hex number up to 48 nibbles

Outbound ESP Authentication Key (HEX)

Hex number up to 40 nibbles

Inbound AH SPI (DEC)

Inbound AH security parameter index number

Inbound AH Authentication Algorithm

HMAC-MD5 or HMAC-SHA1

Inbound AH Authentication Key (HEX)

Hex number up to 40 nibbles

Inbound ESP SPI (DEC)

Inbound ESP security parameter index number

Inbound ESP Encryption Algorithm

3DES-CBC or DES-CBC

Inbound ESP Authentication Algorithm

HMAC-MD5 or HMAC-SHA1

Inbound ESP Encryption Key (HEX)

Hex number up to 48 nibbles

Inbound ESP Authentication Key (HEX)

Hex number up to 40 nibbles

Saving your work

When you are finished configuring tunnel settings, click the **Save Tunnel Settings** button to save the changes.

Chapter 5 **Network—LAN**

Chapter contents

Settings	40
Network Settings	40
Saving your work	40
DHCP	40
Server Settings	41
Client IP Address Range	41
Client Network Information	41
Domain Name	41
DNS Server	41
Static Address Assignment	41
Viewing the DCHP Client Table	41
Saving your work	41
Routing	42
Dynamic Routing	42
Static Routing	42
Viewing the Routing Table	42
Saving your work	42
Port Forwarding	43
Reserved Ports	43
Port Forwarding to LAN	43
De-Militarized Zone	43
Saving your work	43
IP Filtering	43
Filter IP Range	44
Saving your work	44

Settings




Figure 15. Network Settings window

Network Settings

Enter the IP address and subnet mask of your LAN network.

Saving your work

When you are finished, click the **Save Settings** button to save the changes.

DHCP

These configuration parameters are for the SmartLink 4020's internal DHCP server that will provide IP network information to LAN attached devices.

The screenshot shows the 'DHCP Server Configuration' page. It includes sections for 'Server Settings' (Enabled radio button selected, Client IP Address Range: 192.168.1.100-131), 'Client Network Information' (Domain Name: [] and DNS Server 1: 80.0.0.1, 2: []), and 'Static Address Assignments' (Identify Using: Hostname dropdown, Host Identifier: [] and Internal Address: 192.168.1.1, Save Internet Settings button). At the bottom are 'Save DHCP Settings' and 'View DHCP Table' buttons.

Figure 16. DHCP Server Configuration window

Server Settings

Select *Yes* to enable or *No* disable DHCP. When enabled, the SmartLink 4020 will act as a DHCP server to devices connected to the SmartLink 4020 LAN port.

Client IP Address Range

Minimum and maximum limits on the range of IP addresses that will be allocated by DHCP to LAN attached devices. The IP addresses included in the block should not be statically assigned to non-DHCP devices on the LAN. The network portion of the *Client IP Address Range* is determined by the IP address and subnet mask specified under *Network—LAN* settings.

Client Network Information

Domain Name

LAN domain name provided to DHCP clients during the DHCP OFFER process.

DNS Server

This statically assigned DNS server IP address will be provided to clients during the DHCP OFFER process.

Static Address Assignment

Up to eight static DHCP address assignments can be configured. To add a static IP assignment, enter as host identifier the LAN device's host name (must be unique in the private network) and/or MAC address. Specify the IP address to be assigned and press the **Add** button.

Viewing the DHCP Client Table

Click the **View DHCP Table** button to display the *DHCP Client Table* (see figure 17).

DHCP Client Table		
Computer Name	Client ID	IP Address

Update **Close** **Clear client binding table**

Figure 17. DHCP Client Table window

The **Update** button refreshes the displayed DHCP client table.

The **Close** button closes the open window and returns to the main menu.

The **Clear client binding table** button clears all dynamically assigned IP addresses on the SmartLink 4020 DHCP server.

Saving your work

When you are finished configuring DHCP server settings, click the **Save DHCP Settings** button (see figure 16 on page 40) to save the changes.

Routing

These configuration parameters are for the internal router.

Note These parameters only apply when the *Device Operating Mode* is set to *Router* (see section “[Device Operating Mode](#)” on page 31).




Figure 18. Router Configuration window

Dynamic Routing

Whether or not dynamic routing on the interfaces is enabled/disabled.

Static Routing

Under *Static Routing*, you can specify the routing paths of your internal network.

Viewing the Routing Table

Click the **View Routing Table** button to display the *Routing Table* (see figure 19).


Routing Table						
Subnet Mask	Gateway IP	Dest IP Address	Metric	Interface	Flags	
0.0.0.0	209.49.110.1	209.49.110.1	3	IF1	SD	
0.0.0.0	209.49.110.1	0.0.0.0	2	IF1	RD	
Update Close						

Figure 19. Routing Table window

Saving your work

When you are finished configuring Router settings, click the **Save Router Settings** button (see figure 18 on page 42) to save the changes.

Port Forwarding



The screenshot shows the 'Port Forwarding Configuration' window. It includes sections for 'Reserved Ports' (listing ports 68, 5060-5070, 1900, 2828, 2929, 7001-7003, 8000-8015, 5555), 'Port Forwarding to LAN' (with fields for Port Range, Protocol, Destination Address, and a 'Save Internet Settings' button), and 'DeMilitarized Zone' (specifying 192.168.1.1). A 'Save NAPT Settings' button is also present.

Figure 20. Port Forwarding Configuration window

Reserved Ports

Specifies reserved ports that cannot be forwarded to the LAN.

Port Forwarding to LAN

In this section, you enter the specifications, which you will be forwarding to the LAN, including port range, protocol (*Both*, *TCP* or *UDP*), and destination IP address.


De-Militarized Zone

Packets which are not listed above will be forwarded to the DMZ host you specify.

Saving your work

When you are finished configuring Port Forwarding settings, click the **Save NAPT Settings** button to save the changes.

IP Filtering



The screenshot shows the 'IP Filtering' window. It includes a 'Filter IP Range' section (specifying 192.168.1.1 - 192.168.1.254 and a 'Save Internet Settings' button), and a 'Save DHCP Settings' button.

Figure 21. IP Filtering window

Filter IP Range

A computer having an IP address that falls within the specified IP address range will not be allowed to access the WAN interface. Typically this is used to block access to the Internet

Saving your work

When you are finished configuring settings, click the **Save Settings** button to save the changes.

Chapter 6 **Telephony**

Chapter contents

VoIP Status	48
VoIP Server Registration Status	48
Current Server	48
Domain	48
Base RTP Port	48
Phone Line Status	48
Registration Status	48
User Name	49
Caller ID Setting	49
Subscribed for Voicemail	49
Messages waiting	49
SIP	49
SIP Configuration	50
SIP Server Settings	50
Gateway Settings	50
Dial Plan	50
SIP Extensions	51
Support PRACK method	51
Encode SIP URI with user parameter	51
Send INVITE with Timer header	51
Call Hold using C=0.0.0.0	51
Send NOTIFY	51
RTP Telephone Event Configuration	51
VoIP VLAN Configuration	51
SIP Parameters	52
Hook Flash MIME Type	52
SIP Timer Values (milliseconds)	52
SIP T1	52
SIP T2	52
SIP T4	52
RTP Parameters	52
NAT Traversal	53
Outbound Proxy IP	53
Outbound Proxy Port	53
Stun Server IP	53
Stun Server Port	53
UPnP	53
NONE	53
Saving your work	53

Audio/CODEC Configuration.....	54
CODECS	54
Packetization	54
Jitter Buffer	54
FAX without T.38 (Use G.711 fax)	55
Saving your work	55
Phone 1 & Phone 2.....	55
User Information	56
Phone Number	56
User Name	56
Port	56
CallerID Name	56
Password	56
Supplementary Service Activation	56
Call Forward All	57
Selective Call Forward	57
Three-Way Conferencing	57
Incoming Call Block	57
Distinctive Ring	57
Call Transfer	57
Dialing by IP Address	57
Speed Dial	57
Message Waiting Indicator	57
Call Forward on Busy	58
Conditional Call Forward	58
Call Waiting	58
Anonymous Call Reject	58
Caller ID	58
Call Return	58
Do Not Disturb	58
Self Caller ID Block	58
Outgoing Call Block	58
Dial Out Type	58
Dial Out Type	58
Hot Line Number	58
Warm Line Number	59
Call Forward Settings	59
Cfwd All Dest	59
Cfwd Busy Dest	59
Selective Call Forward Settings	59
Incoming caller #1–8	59
Forward destination #1–8	59
Incoming Call Block	60
Block Caller ID	60

Outgoing Call Block	60
Digit Pattern	60
HTTP Digest Setting	60
Saving your work	60
Speed Dial	61
Line 1 Speed Dial Settings	61
Speed Dial Serv	61
Speed Dial 1–8 Phone Number/IP Dialing	61
Line 2 Speed Dial Settings	61
Speed Dial Serv	61
Speed Dial 1–8 Phone Number/IP Dialing	61
Saving your work	61

VoIP Status



Figure 22. VoIP Status window

VoIP Server Registration Status

Current Server

Shows the current VoIP server that has been pre-defined or has been discovered using DNS service records (DNS-SRV).

Domain

The VoIP domain name is the domain name that is hosting the VoIP server.

Base RTP Port

Displays the base RTP port number for the RTP-RTCP port pair.

Phone Line Status

The *Phone Line Status* table shows the current operational status of phones 1 and 2. It displays the VoIP registration status, the configured VoIP usernames, if the usernames are subscribed to voicemail and have messages waiting, and the caller ID setting. The messages waiting will indicate the number of new messages, old messages, new urgent messages and old urgent messages.

Registration Status

Shows the currently operational status of the phones 1 and phones 2. The following registration status values may be displayed:

- **Online**—The phone line is online, registered with the SIP server and ready to send and receive phone calls using the SIP server.
- **Registering**—The SmartLink 4020 is in the process of registering with the VoIP server.

- **No Registration**—The SmartLink 4020 is not attempting to register with the SIP server because “Send Registration Request” is not checked on SIP sever setting screen.
- **Error: Not Authorized**—A SIP final status message status of 401 or 407 has been received from the SIP server.
- **Error: Forbidden**—SIP final status message status of 401 or 407 has been received from the SIP server.
- **Error 408: Request timeout**— A SIP final status message status of 408 has been received from the SIP server.
- **Response: xxx**—A SIP final status message status of *xxx* has been received from the SIP server.

User Name

The authentication username that was specified under section “[Phone 1 & Phone 2](#)” on page 55. This user name will be used to register with the VoIP server.

Caller ID Setting

The Caller ID name setting that was specified under section “[Phone 1 & Phone 2](#)” on page 55. This is the display name that others will see as your caller id when you make a call.

Subscribed for Voicemail

Shows if the SIP Subscribe message was successful for this phone line. If “Yes”, then the subscription process was successful. The number of voicemail messages in the queue will not be provided if the subscription for voice mail fails.

Messages waiting

After successful subscription to the SIP server, the SIP server/Internet Telephony service provider should send the number of voicemail messages that are queued up for the user using the SIP Notify message. The messages waiting shows the number of normal priority new messages, normal priority old (listened to) messages, number of urgent priority new voicemail messages and the number of old (listened to) urgent priority voicemail messages as reported to the SmartLink 4020 by the VoIP SIP server.

SIP

The *SIP* window contains the following sections:

- SIP Configuration (see [figure 23](#) on page 50)
- SIP Extensions (see [figure 25](#) on page 51)
- RTP Telephone Event Configuration (see [figure 26](#) on page 51)
- VoIP VLAN Configuration (see [figure 27](#) on page 52)
- SIP Parameters (see [figure 28](#) on page 52)
- NAT Traversal (see [figure 29](#) on page 53)

Note After configuring the sections, click the **Save SIP Settings** button (see [figure 29](#) on page 53) to save the new configuration.

SIP Configuration

SIP Configuration

SIP Server Settings (Current Server: [patsip.patton.com : 5060](#) ; Domain: [patton.com](#); Base RTP Port:)

- * SIP Registration Server Address:
- SIP Port:
- SIP Domain: yourdomain.com
- Voice Port:

* Leaving a setting blank will force the unit to use the information obtained via DHCP and/or DNS

- Send Registration Request with Expire Time: 3600
- Send Unregistration at boot
- Send SUBSCRIBE.

SUBSCRIBE Server IP or FQDN(defaults to registration server):

Figure 23. SIP Configuration section of the SIP window

SIP Server Settings

The SmartLink 4020 will automatically attempt to locate the VoIP server by using the domain name specified in the WAN interface or the server will be discovered via DHCP on the WAN interface. When found, the discovered server will be listed as the *Current Server*.

Enter the following information:

- Server address—The IP address or domain name hosting the VoIP SIP server
- Port—The UDP port of the VoIP SIP server. The default is *5060*.
- Domain name—The VoIP domain name (realm) is used for validation of each phone's username
- Send Registration Request with Expire Time—if selected, determines the amount of time (in seconds) that the SIP registration will be valid for.
- Unregistration—if checked, the SmartLink will send a SIP unregister at system reload before sending a SIP registration request.
- Send SUBSCRIBE—if checked, the SmartLink will send a SIP *subscribe* to the server specified. This box must be checked for the voicemail message counted and message waiting notification to work.
- SUBSCRIBE Server IP or FQDN—The IP address or fully qualified domain name of the subscription service. If not specified, the SIP subscribes to the SIP server.

Gateway Settings

Dial Plan:

Figure 24. Gateway Settings section of the SIP window

Gateway Settings

Dial Plan. Refer to appendix C, “Dial plans” on page 94

SIP Extensions

SIP Extensions

- Support PRACK method with provisional response reliability
- Encode SIP URI with user parameter
- Send INVITE with Timer header value:
- Call Hold using c=0.0.0.0 in SDP
- send NOTIFY for REFER request

RTP Telephone Event Configuration

- Send DTMF Events Out-of-Band(RFC2833)
- RFC2833 signalling using payload value:
- Regenerate OOB DTMF tone

Figure 25. SIP Extensions section of the SIP window

Support PRACK method

Select to enable SIP provisional acknowledgement (PRACK) support as defined in RFC 3262.

Encode SIP URI with user parameter

Select to encode user=phone parameter in SIP URI.

Send INVITE with Timer header

Select to encode Timer header in all INVITE requests for ringing timeout.

Call Hold using C=0.0.0.0

When checked, calls will be held using the call hold method described in RFC 2543. If unchecked, the call hold would follow the RFC 3263 method.

Send NOTIFY

Send out SIP NOTIFY request to transferer for unattended and attended call transfer.

RTP Telephone Event Configuration

This sub-page allows configuration of the out-of-band signaling options for SIP. Select whether OOB telephone event signaling is to be done using the SIP INFO message, or to be done via RFC2833 RTP signaling. For additional information please refer RFC2833.

RTP Telephone Event Configuration

- Send DTMF Events Out-of-Band(RFC2833)
- RFC2833 signalling using payload value:
- Regenerate OOB DTMF tone

Figure 26. RTP Telephone Event Configuration section of the SIP window

VoIP VLAN Configuration

This sub-page allows configuration of specific VLAN tags that are to be applied to all SIP signalling and RTP packets used for VoIP calls. These VLAN settings will override any general VLAN settings applied to the interface.

VoIP VLAN Configuration

Call Signalling Packets

VLAN Tag:

RTP Packets

VLAN Tag:

Figure 27. VoIP VLAN Configuration section of the SIP window

SIP Parameters

SIP Parameters

Hook Flash MIME Type:

SIP Timer Values (msec)

SIP T1: SIP T2:
 SIP T4:

RTP Parameters

RTP Port Min: RTP Port Max:

Figure 28. SIP Parameters section of the SIP window

Hook Flash MIME Type

This is the MIME Type to be used in a SIP INFO message used to signal hook flash event.

SIP Timer Values (milliseconds)

SIP T1. RFC 3261 T1 value (RTT estimate). Range: 0–64000 milliseconds (default is 5000 msec or 5 seconds).

SIP T2. RFC 3261 T2 value (maximum retransmit interval for non-INVITE requests and INVITE responses). Range: 0–64000 milliseconds (default is 4000 msec or 4 seconds).

SIP T4. RFC 3261 T4 value (maximum duration a message will remain in the network). Range: 0–64 seconds (default is 5000 msec or 5 seconds).

RTP Parameters

RTP Port Min and *RTP Port Max* define a range that contains at least four even-numbered ports (100–106, for example).

NAT Traversal

The screenshot shows the 'NAT Traversal' configuration section of a SIP settings window. It includes fields for Outbound Proxy IP, Outbound Proxy Port, Stun Server IP, Stun Server Port, UPnP, and a 'NONE' option. A 'Save SIP Settings' button is at the bottom.

NAT Traversal	
<input type="radio"/> Outbound Proxy IP:	(IP or FQDN)
<input type="radio"/> Stun Server IP:	(IP or FQDN)
<input type="radio"/> UPnP	
<input checked="" type="radio"/> NONE	
Save SIP Settings	

Figure 29. NAT Traversal section of the SIP window

Outbound Proxy IP

Type the fully qualified domain name for the outbound proxy server, or type the IP address provided by your service provider.

Outbound Proxy Port

Type the outbound proxy IP port number provided by your service provider.

Stun Server IP

Enter the fully qualified domain name for the stun server, or type the IP address provided by your service provider.

Stun Server Port

Type the stun server port number provided by your service provider.

UPnP

Universal plug-and-play method. This method works with NAT routers that support UPnP gateway.

NONE

Select this if you will not be using NAT traversal methods.

Saving your work

When you are finished configuring SIP settings, click the **Save SIP Settings** button (see figure 29) to save the changes.

Audio/CODEC Configuration




Figure 30. Audio/CODEC Configuration window

CODECS

- *Selected* column: Check the codecs that are acceptable to use
- *Silence Suppression* column: Specifies whether silence suppression should be turned on in the SmartLink 4020.
- *Preferred-Codec* column: Select the codec to be used as the first choice when encoding voice

Packetization

Configure the packet sending increment.

Jitter Buffer

Configure the timing of the voice buffering:

- Selection between adaptive or fixed jitter buffer. Default = ADAPTIVE.
- Set the adaptive jitter buffer maximum playout delay. Default = 100ms or Fixed jitter buffer playout delay. Default = 40ms
- Whether or not to automatically switch from an adaptive jitter buffer to a fixed jitter buffer upon fax/modem tone detection

FAX without T.38 (Use G.711 fax)

When checked, T.38 is disabled and the SL4020 will not attempt T.38 session negotiation for fax transmissions initiated by the originator of the fax. The fax transmissions will be transported using G.711 fax pass-through. The selection of T.38 or G.711 fax pass-through for fax transmissions originated from the SL4020 will be determined by the receiving fax device. T.38 is enabled by default.

To disable T.38, go to *Telephony > CODECS* and select *FAX without T.38 (Use G.711 fax)* (see [figure 30](#) on page 54).

Saving your work

When you are finished configuring CODEC settings, click the **Save CODEC Configuration** button (see [figure 30](#) on page 54) to save the changes.

Phone 1 & Phone 2

The *Phone 1* and *Phone 2* windows contains the following sections:

- User Information (see [figure 31](#))
- Supplementary Service Settings (see [figure 32](#) on page 57)
- Dial Out Type (see [figure 33](#) on page 58)
- Call Forward Settings (see [figure 27](#) on page 52)
- Selective Call Forward Settings (see [figure 28](#) on page 52)
- Incoming Call Block (see [figure 29](#) on page 53)
- Distinctive Ring Settings (see [figure 29](#) on page 53)
- HTTP Digest Setting (see [figure 29](#) on page 53)

Note After configuring the sections, click the **Save** button (see [figure 38](#) on page 60) to save the new configuration.

User Information

User Information			
Phone Number	<input type="text" value="jerry"/>	CallerID Name	<input type="text" value="mike"/>
User Name	<input type="text" value="jerry"/>	Password	<input type="text" value="****"/>
Port	<input type="text" value="5060"/>	SIP Registration status Registered	
Supplementary Services Activation			
Service	Enable?	Service	Enable?
Call Forward All	No	Call Forward on Busy	No
Selective Call Forward	No	Conditional Call Forward	No
Three Way Conferencing	Yes	Call Waiting	Yes
Incoming Call Block	Yes	Anonymous Call Reject	No
Distinctive Ring	No	Caller ID	Yes
Call Transfer	Yes	Call Return	Yes
Dialing by IP Address	No	Do Not Disturb	No
Speed Dial	No	Self Caller ID Block	No
Message Waiting Indicator	Yes	Outgoing Call Block	Yes

Figure 31. User Information section of Phone 1 or Phone 2 window

Phone Number

Enter the telephone number or the user part of the SIP registration.

User Name

Enter the user name that will be used for validation of the VoIP SIP registration or call invitation.

Port

Specify the signaling port.

CallerID Name

Enter the caller ID name.

Password

Enter the password.

Supplementary Service Activation

These settings enable or disable each of following calling features. Most features can also be enabled or disabled by using the telephone handset (see section “[Supplementary Service Keys](#)” on page 71 for details).

Supplementary Services Activation			
Service	Enable?	Service	Enable?
Call Forward All	No	Call Forward on Busy	No
Selective Call Forward	No	Conditional Call Forward	No
Three Way Conferencing	Yes	Call Waiting	Yes
Incoming Call Block	Yes	Anonymous Call Reject	No
Distinctive Ring	No	Caller ID	Yes
Call Transfer	Yes	Call Return	Yes
Dialing by IP Address	No	Do Not Disturb	No
Speed Dial	No	Self Caller ID Block	No
Message Waiting Indicator	Yes	Outgoing Call Block	Yes

Figure 32. Supplementary Service Settings section of Phone 1 or Phone 2 window

Call Forward All

Enable call forward all service—All received calls will be forwarded to the destination specified under the call forwarding settings.

Selective Call Forward

Enable call forward no answer service—All received calls that are not answered will be forwarded to the destination specified under the call forwarding settings.

Three-Way Conferencing

Enable three way conference service—This service enables you to add a third party to an existing two-way conversation, and hold a three-party conference call.

Incoming Call Block

Enable incoming call block service—Allows for selected inbound caller IDs to be blocked.

Distinctive Ring

Enable distinctive ringing service—This service allows additional telephone numbers to be added to an existing telephone line and when a caller dials one of these “distinctive ringing” numbers, the telephone will ring in a unique pattern to indicate which number is being dialed.

Call Transfer

Enable call transfer service—This service allows you to transfer calls to another number.

Dialing by IP Address

Enable IP dialing service—This service allows user IP addresses to be used to make calls.

Speed Dial

Enable speed dial service.

Message Waiting Indicator

Enable MWI service—The message-waiting indicator (MWI) is a common feature of telephone networks and uses an audible indication (such as a special dial tone) to indicate that a voice mail message is waiting.

Call Forward on Busy

Enable call forward on busy service.

Conditional Call Forward

Enable call forward selective service.

Call Waiting

Enable call waiting service.

Anonymous Call Reject

Enable block anonymous calls service—When enabled, calls from anonymous callers will be blocked.

Caller ID

Enable caller ID service.

Call Return

Enable call return service—When enabled, allows you to return a call to the last incoming call, whether the call was answered or not.

Do Not Disturb

Enable do not disturb service.

Self Caller ID Block

Enable blocking self caller ID shown in the outgoing message.

Outgoing Call Block

Enable blocking of outgoing calls based on the digit pattern specified under outgoing call block.

Dial Out Type

Figure 33. Dial Out Type section of Phone 1 or Phone 2 window

Dial Out Type

Enable Hot-Line and Warm-Line services. To achieve this, one sequence in the dial plan must start with a pause, with a 0 delay for a Hot Line, and a non-zero delay for a Warm Line.

Hot Line Number

Input the number for Hot Line function—This number will be called immediately when the telephone goes off-hook.

Warm Line Number

Input the number for Warm Line function—The warm line function provides a delay period after the telephone goes off-hook for the user to dial a number different than that specified for the warm line. If the delay period has expired with no number being dialed, the warm line number will be dialed. The delay period is set under *System > Localization*.

Call Forward Settings

Call Forward Settings			
Cfw All/Conditional Dest:	611	Cfw Busy Dest:	211
Cfw Conditional Time:	5	sec	

Figure 34. Call Forward Settings section of Phone 1 or Phone 2 window

Cfw All Dest

Input the destination for all call forwarding.

Cfw Busy Dest

Input the destination for all busy call forwarding.

Selective Call Forward Settings

Selective Call Forward Settings			
Incoming caller #1	lukan	forward destination #1	482
Incoming caller #2	joe@yourcompany.com	forward destination #2	413
Incoming caller #3		forward destination #3	
Incoming caller #4		forward destination #4	
Incoming caller #5		forward destination #4	
Incoming caller #6		forward destination #4	
Incoming caller #7		forward destination #7	
Incoming caller #8		forward destination #8	

Figure 35. Selective Call Forward Settings section of Phone 1 or Phone 2 window

Incoming caller #1–8

Up to 8 incoming calls can be selected for call forwarding.

Forward destination #1–8

Up to 8 destinations to which incoming calls can be forwarded.

Incoming Call Block

Incoming Call Block
Block Caller ID:

Figure 36. Incoming Call Block section of Phone 1 or Phone 2 window

Block Caller ID

Specify a Caller ID for call block.

Outgoing Call Block

Outgoing call block allows for the blocking of an outbound call based on the digit pattern dialed. For example: outbound call blocking may be used to prevent an end user from dialing long distance or toll calls. Outbound call blocking uses the same digit matching process as the dial plan described in appendix C, “Dial plans” on page 94.

Outgoing Call Block
Digit Pattern:

Figure 37. Incoming Call Block section of Phone 1 or Phone 2 window

Digit Pattern

The *Digit Pattern* box is where you can specify the outgoing call block pattern.

Example: Specifying an outgoing call block pattern of *002|009|0204* will block all outbound calls to numbers 002, 009, or 0204.

HTTP Digest Setting

SIP INVITE must contain a valid Authorization header that is based on an Auth ID and a password using MD5 digest algorithm. The Auth ID must be specified in the username parameter in the Authorization header.

HTTP Digest Setting
Password:

Figure 38. HTTP Digest Setting section of Phone 1 or Phone 2 window

Saving your work

When you are finished configuring settings, click the **Save** button (see figure 38) to save the changes.

Speed Dial

Speed Dial Settings

Line 1 Speed Dial Settings

Speed Dial 1 Phone Number/IP Dialing:	bill	@	yourcompany.com	:	<input type="text"/>
Speed Dial 2 Phone Number/IP Dialing:	611	@		:	<input type="text"/>
Speed Dial 3 Phone Number/IP Dialing:		@		:	<input type="text"/>
Speed Dial 4 Phone Number/IP Dialing:		@		:	<input type="text"/>
Speed Dial 5 Phone Number/IP Dialing:		@		:	<input type="text"/>
Speed Dial 6 Phone Number/IP Dialing:		@		:	<input type="text"/>
Speed Dial 7 Phone Number/IP Dialing:		@		:	<input type="text"/>
Speed Dial 8 Phone Number/IP Dialing:		@		:	<input type="text"/>

Line 2 Speed Dial Settings

Speed Dial 1 Phone Number/IP Dialing:		@		:	<input type="text"/>
Speed Dial 2 Phone Number/IP Dialing:		@		:	<input type="text"/>
Speed Dial 3 Phone Number/IP Dialing:		@		:	<input type="text"/>
Speed Dial 4 Phone Number/IP Dialing:		@		:	<input type="text"/>
Speed Dial 5 Phone Number/IP Dialing:		@		:	<input type="text"/>
Speed Dial 6 Phone Number/IP Dialing:		@		:	<input type="text"/>
Speed Dial 7 Phone Number/IP Dialing:		@		:	<input type="text"/>
Speed Dial 8 Phone Number/IP Dialing:		@		:	<input type="text"/>

Save Settings

Figure 39. Speed Dial window

Line 1 Speed Dial Settings

Speed Dial Serv

Enable Speed Dial Service.

Speed Dial 1–8 Phone Number/IP Dialing

Target 1–8 phone number (or URL) assigned to speed dial.

Line 2 Speed Dial Settings

Speed Dial Serv

Enable Speed Dial Service.

Speed Dial 1–8 Phone Number/IP Dialing

Target 1–8 phone number (or URL) assigned to speed dial.

Saving your work

When you are finished configuring settings, click the **Save Settings** button (see figure 39) to save the changes.

Chapter 7 **System**

Chapter contents

Set Security Password	65
Web Page Protect	65
New Root Password	65
New User Password	65
Confirm new password	66
Saving your work	66
Configuration.....	66
Logging	66
Enable Syslog	66
Syslog Server	66
Enable Debug	67
Debug Server	67
Debug Connect Port	67
Saving your work	67
Service Access	68
Enable HTTP	68
Enable Ping Reply	68
Saving your work	68
Localization	68
Call Progress Tones	69
Dial Tone	69
Prompt Tone	69
Confirm Tone	69
Holding Tone	69
Busy Tone	70
Ring Back Tone	70
Off Hook Warning	70
Distinctive Ring Setting 1–8	70
Supplementary Service Keys	71
Call forward All	72
Call forward on Busy	72
Call forward selective	72
Call Waiting	72
Incoming Call Block	72
Block Anonymous Calls	72
Distinctive Ring	72
Warm Line	72
Do Not Disturb	72
IP Dialing	72

Speed Dialing	73
Income Caller ID	73
Self Caller ID Block	73
Calling Prefix Keys	73
Call Return	73
Warm Line	73
Speed Dial	73
Call Forward All	74
IP Dialing	74
Call Hold	74
Call Waiting (call alternative)	74
Call Conference	74
Call Conference Drop	74
Call Transfer	74
Voicemail access	74
Call Forward Busy Destination	74
Hotline	75
Control Timer Values	75
Hook Flash Timer	75
SIP Session Timer value	75
Conditional Call Forwarding Timer	75
Warm Line Delay	75
Interdigit Timer	76
Offhook Idle Time	76
Offhook Warning tone time	76
FXS Port	76
FXS port Input Gain	76
FXS port Output Gain	76
Caller ID Method	76
“Call Progress Tones” Synchronization	76
Ring Setting	76
Ring Waveform	76
Ring Frequency	77
Ring Voltage	77
FXS Port Polarity Configuration	77
Idle Polarity	77
Caller Conn Polarity	77
Saving your work	77
SNMP Configuration	77
SNMP Trap Configuration	77
IP address	77
Trap Community	77
SNMP Community Configuration	78
Read Community	78

Write Community	78
SNMP System Configuration	78
System Description	78
System Object Id	78
Saving your work	78
Auto Upgrade.....	78
Routine Upgrade every xxx day(s)	78
Enable Auto Upgrade	79
Auto Upgrade Protocol	79
Upgrade Server	79
Auto Upgrade URL	79
Saving your work	79
Manual Upgrade.....	79
Reload	80

Set Security Password




Figure 40. Set Security Password window

Two levels of system configuration are available: user level and system level. Access to each level is password controlled.

Web Page Protect

Enable or disable web access protection. When set to YES, a password will be required to access the SmartLink 4020 web configuration interface.

New Root Password

Type the administrator's password.

New User Password

Type the user's password.

Confirm new password

Re-enter the password for confirmation.

Saving your work

When you are finished configuring security settings, click the **Save Settings** button to save the changes.

Configuration



Figure 41. Configuration window

Logging

Enable Syslog

Enable or disable system logging. During normal operations, Syslog should be turned off. A sample Syslog record of a complete call is shown below.

SYSLOG

```
11-09-2005 11:28:17 Local0.Info 209.49.110.185 Nov 09
08:28:34 syslog: [1234] On-Hook [7190]
11-09-2005 11:28:06 Local0.Info 209.49.110.185 Nov 09
08:28:23 syslog: [1234] Call-Out [7190]
11-09-2005 11:27:50 Local0.Info 209.49.110.185 Nov 09
08:28:07 syslog: [1234] Call-Out [190]
11-09-2005 11:16:32 Local0.Info 209.49.110.185 Nov 09
08:16:49 syslog: [1234] On-Hook [555]
11-09-2005 11:16:16 Local0.Info 209.49.110.185 Nov 09
08:16:33 syslog: [1234] Call-Out [7190]
11-09-2005 11:15:38 Mail.Emerg 209.49.110.185 Jan 01
00:00:00 syslog: DownloadConfig:No, DownloadImage:No
11-09-2005 11:15:36 Local0.Info 209.49.110.185 Jan 01
00:00:00 syslog: Check Autoupgrade
```

Syslog Server

Specify the syslog server IP address or DNS name. This feature specifies the server for logging SmartLink 4020 system information and critical events.

Enable Debug

Enable or disable System Debug.

Debug Server

The debug server IP address and port. This specifies the server for logging SmartLink 4020 debug information. Debug information can be sent to a syslog server. A sample record of debug output is shown below:

```
SYSLOG

07-07-2005 14:49:09 Local17.Debug 10.10.22.13 **EndPoint State: StateConnect ==> StateOnHook
    in src/common/endpoint.c: 333
07-07-2005 14:49:09 Local10.Info 10.10.22.13 Jul 07 11:49:09 syslog: [usersjphone] On-Hook
    [100]
07-07-2005 14:49:03 Local17.Debug 10.10.22.13 !!!! Handset 349b4 received event 52 in file src/
    common/fxs/ConnectFxs.c line 466
07-07-2005 14:48:59 Local17.Debug 10.10.22.13 The EnvetString is f and length is 1.
07-07-2005 14:48:59 Local17.Debug 10.10.22.13 **EndPoint State: StateWaiting ==> StateConnect
    in src/common/fxs/WaitingFxs.c: 116
07-07-2005 14:48:59 Local17.Debug 10.10.22.13 call 468bc ==>CallChangeState():: from
    CALL_ALERT to CALL_CONNECT in file src/common/fxs/WaitingFxs.c line 114
07-07-2005 14:48:59 Local17.Debug 10.10.22.13 APP rcv rsp 200 of req 32769
07-07-2005 14:48:59 Local17.Debug 10.10.22.13 call 468bc ==>CallChangeState():: from
    CALL_OUTGOING to CALL_ALERT in file src/common/fxs/WaitingFxs.c line 58
07-07-2005 14:48:59 Local17.Debug 10.10.22.13 APP rcv rsp 180 of req 32769
07-07-2005 14:48:58 Local17.Debug 10.10.22.13 !!!! Handset 349b4 received event 26 in file src/
    common/fxs/WaitingFxs.c line 212
07-07-2005 14:48:58 Local17.Debug 10.10.22.13 APP rcv rsp 100 of req 32769
07-07-2005 14:48:58 Local17.Debug 10.10.22.13 **EndPoint State: StateOffHook ==> StateWaiting
    in src/common/fxs/OffHookFxs.c: 418
07-07-2005 14:48:58 Local17.Debug 10.10.22.13 Dial numbers is 100
07-07-2005 14:48:58 Local10.Info 10.10.22.13 Jul 07 11:48:58 syslog: [usersjphone] Call-Out
    [100]
07-07-2005 14:48:58 Local17.Debug 10.10.22.13 call 0 ==>CallChangeState():: from CALL_IDLE to
    CALL_OUTGOING in file src/common/call.c line 80
07-07-2005 14:48:58 Local17.Debug 10.10.22.13 Codec[2]=8
07-07-2005 14:48:58 Local17.Debug 10.10.22.13 Codec[1]=18
07-07-2005 14:48:58 Local17.Debug 10.10.22.13 Codec[0]=0
07-07-2005 14:48:54 Local17.Debug 10.10.22.13 The EnvetString is 100 and length is 3.
07-07-2005 14:48:53 Local17.Debug 10.10.22.13 The EnvetString is 10 and length is 2.
07-07-2005 14:48:53 Local17.Debug 10.10.22.13 The EnvetString is 1 and length is 1.
07-07-2005 14:48:51 Local17.Debug 10.10.22.13 **EndPoint State: StateOnHook ==> StateOffHook
    in src/common/fxs/OnHookFxs.c: 55
```

Debug Connect Port

The port number of the debug server to be used for receiving debug messages from the SmartLink 4020. Use port 412 to send debug output to a syslog server.

Saving your work

When you are finished configuring settings, click the **Save** button to save the changes.

Service Access




Figure 42. Service Access window

Enable HTTP

When checked access to the web configuration interface (HTTP) of the SmartLink 4020 through the WAN interface port is enabled.

Note If the *Enable HTTP* option is not checked, your WAN service provider will no longer be able to access the SmartLink 4020 to make configuration changes.

Enable Ping Reply

When checked, the SmartLink 4020 will reply to ping requests received on the WAN port. If the option is not checked, the SmartLink 4020 will not respond to ping requests received on the WAN port.

Saving your work

When you are finished configuring settings, click the **Save Service Access Settings** button to save the changes.

Localization

The *Localization* window contains the following sections:

- Call Progress Tones (see [figure 43](#) on page 69)
- Distinctive Ring Setting (see [figure 44](#) on page 70)
- Supplementary Service Keys (see [figure 45](#) on page 72)
- Control Timer Values (see [figure 47](#) on page 75)
- FXS Port (see [figure 48](#) on page 76)
- Ring Setting (see [figure 49](#) on page 76)
- FXS Port Polarity (see [figure 50](#) on page 77)

Note After configuring the sections, click the **Save** button (see [figure 50](#) on page 77) to save the new configuration.

Call Progress Tones

The dialtone, confirmation, busy, ringback and offhook warning call progress tones that are played to the handset can be set manually or the tones will be set automatically to the country specified under *Call ID method* if the checkbox, *Call Progress Tones synchronization* has been selected.

To set the call progress tones manually specify:

```
[frequency 1]@[Energy 1]+[frequency 2]@[Energy 2]#ON([ms]),OFF([ms]),R
```

Where:

- *Frequency 1* and *frequency 2* are the frequency of the tone to be played.
- *Energy 1* and *energy 2* are the energy level of the tone to be played in dBm.
- *ON(ms)* is the duration that the tone will be played in milliseconds.
- *OFF(ms)* is the duration of the pause between cycles of playing the tone.
- *R* indicates the tone should be repeated using the ON and OFF durations specified

To specify a 350-Hz and 480-Hz tone that will be played at 15 dB for one second and then pause for 0.5 seconds, you would specify:

```
350@-15+480@-15#ON(1000),OFF(500),R
```

The following example would repeat playing of a tone of 280 Hz at -8 dBm for 0.3 seconds with a pause of 0.1 second and a tone of 550 Hz for 0.8 seconds with a pause of 0.15 seconds.

```
280@-8+550@-20#ON(300),OFF(100),ON(800),OFF(150),R
```

Localization	
Call Progress Tones	
DIALTONE	330@-13+440@-13#ON(1000),R
CONFIRM	350@-13+440@-13#[ON(100),OFF(100)]3,OFF(1000),R
BUSY	440@-13#ON(500),OFF(500),R
RINGBACK	440@-13#ON(1500),OFF(3500),R
OFF HOOK WARNING	1400@-3+2060@-3+2450@-3+2600@-3#ON(100),OFF(100),R

Figure 43. Call Progress Tones section of Localization window

Dial Tone

Played when prompting the user to enter a phone number.

Prompt Tone

Played when prompting the user to enter a call forward phone number.

Confirm Tone

This should be a brief tone to notify the user that the last input value has been accepted.

Holding Tone

Indicate to the local user that the far end has placed the call on hold.

Busy Tone

Played when a 486 RSC is received for an outbound call.

Ring Back Tone

Played for an outbound call when the far end is ringing.

Off Hook Warning

Played when the subscriber does not place the handset on the cradle properly.

Distinctive Ring Setting 1–8

The SmartLink 4020 Distinctive Ring Settings window (see [figure 44](#)) enables you to specify up to 8 sets of distinctive ring cadences.




Figure 44. Distinctive Ring Setting section of Localization window

The following is a sample ring cadence pattern configuration:

```

Timeval ::= time in milliseconds
Repeatval ::= # of cycles to repeat
Tonename ::= "RING_0" | "RING_1" | "RING_2" | "RING_3" | "RING_4"
| "RING_5" | "RING_6" | "RING_7" | "RING_8" | "RING_9"
Idle ::= "IDLE"
Active ::= "ON" | "OFF"
Inactive ::= Idle "(" Timeval ")"
Active ::= Active "(" Timeval ")"
Sequence ::= Active | Active "," Sequence
Repetition ::= "[" Sequence "]" Repeatval
Repeat ::= "R"
Cycle ::= Sequence | Repetition
Fullsequence ::= Cycle | Cycle "," Fullsequence
Cadence ::= Fullsequence | Fullsequence "," Repeat | Fullsequence
"," Inactive "," Repeat
Ring ::= Cadence

```

Note The Bellcore standard ring cadence patterns are shown in [table 2](#).

Table 2. Bellcore standard ring cadence patterns

Name	Value
RING_0	ON(2000), IDLE(4000), R
RING_1	ON(800), OFF(400), ON(800), IDLE(4000), R
RING_2	ON(400), OFF(200)]2, ON(800), IDLE(4000), R
RING_3	ON(300), OFF(200), ON(1000), OFF(200), ON(300), IDLE(4000), R
RING_4	ON(500)
RING_5	

Supplementary Service Keys

Supplementary Service Keys are key sequences that can enable and disable certain calling features from an analog phone handset attached to the SmartLink 4020.

Note The supplementary service keys must begin with a '*' or '#' character, or f (flash hook) and follow a 1 or 2 numeric digit(s).

Supplementary Service Keys		
	Enable Sequence	Disable Sequence
Call forward All	*97	#97
Call forward on Busy	*98	#98
Call forward selective	*96	#96
Call Waiting	*91	#91
Incoming Call Block	*95	#95
Block Anonymous Calls	*94	#94
Distinct Ring	*90	#90
Warm Line	*99	#99
Do Not Disturb	*82	#82
IP Dialing	*80	#80
Speed Dialing	*81	#81
Incoming Caller ID	*92	#92
Self Caller ID Block	*93	#93

Figure 45. Supplementary Service Keys section of Localization Window

Call forward All

Enables or disables the unconditional call forwarding feature.

Call forward on Busy

Enables or disables the call forwarding on busy feature.

Call forward selective

Enables or disables the call forwarding on busy feature.

Call Waiting

Enables or disables the call waiting feature.

Incoming Call Block

Enables or disables the blocking of incoming calls based on the phone number of the caller feature.

Block Anonymous Calls

Enables or disables the blocking of incoming calls that are using the anonymous caller ID feature.

Distinctive Ring

Enables or disables the distinctive ring tones based on the phone number of the calling party feature.

Warm Line

Enables or disables the warm line calling feature.

Do Not Disturb

Enables or disables the do not disturb feature.

IP Dialing

Enables or disables dialing by IP address.

Speed Dialing

Enables or disables the speed dialing feature.

Incoming Caller ID

Enables or disables the display of incoming caller ID feature.

Self Caller ID Block

Enables or disables the blocking of transmission of caller ID feature for outgoing calls.

Calling Prefix Keys

Calling Prefix Keys and other configuration parameters define the behavior of the calling feature.

Note Following function key must be start by '*', '#' character, or f (flash hook) and follow a 1 or 2 numeric digit(s).

Calling Prefix Keys			
Call Return	*60	Warm Line	*70
Speed Dial	*71	IP Dialing	*72
Call Forward All Destination	*73	Call Forward Busy Destination	*74
Hotline	*75	Call Hold	f1
Call Alternative	f*	Call Conference	f7
Call Conference drop	f8	Call Transfer	f4
VoiceMail dial	*86		
[Note] (f)=Flash hook			

Figure 46. Calling Prefix Keys section of Localization Window

Call Return

Automatically places a call to the number of the last call received.

Warm Line

Configures the number to call automatically after a delay period once the telephone goes off hook. To configure the warm line number enter the calling prefix key (*70 is the factory default), the number to dial and then on hook the phone. You will hear a second dial tone after entering the calling prefix key. Before using warm-line calling it must be enabled using the activate sequence defined in the supplementary service table.

Example:

*7013019751000 and on-hook the phone. When the handset is lifted, 301951000 will be called if another number is not entered within the delay period specified under *System > Localization*.

Speed Dial

Configures speed dialing keys. To configure speed dialing numbers enter the calling prefix key (*71 is the factory default), the speed dial key, the number to dial and then on hook the phone. You will hear a second dial tone after entering the calling prefix key. Speed dial calling must be enabled using the activate sequence defined in the supplementary service table.

Example:

*7123019751000 and on-hook the phone. When 2 is pressed on the telephone key pad, 3019751000 will be called.

Call Forward All

Configures the number to unconditionally forward all calls to. To configure call forward all enter the calling prefix key (*73 is the factory default), the number to dial and then on hook the phone. You will hear a second dial tone after entering the calling prefix key. Before using, *Call Forward All* must be enabled using the activate sequence defined in the supplementary service table.

Example:

*733019751000 and on-hook the phone. All calls received will forward to 3019751000.

IP Dialing

Allows direct calling using an IP address. To use calling by IP address enter the calling prefix key (*72 is the factory default), the * key, the IP address using the * key to between octets of the IP address, the * key and the port number. You will hear a second dial tone after entering the calling prefix key. Before using direct IP address dialing must be enabled using the activate sequence defined in the supplementary service table.

Example:

To place a call to IP address 192.168.1.20:5061 enter *73*192*168*1*20*5060.

Call Hold

Configures the key sequence to place a call on call on hold – The factory default is flash hook 1.

Call Waiting (call alternative)

Configures the key sequence to switch between calls. The factory default is flash hook *.

Call Conference

Configures the key sequence to conference two calls together. The factory default is flash hook 7.

Call Conference Drop

Configures the key sequence to drop the last call that was added to the conference the conference. The factory default is flash hook 8.

Call Transfer

Configures the key sequence for call transfer. The factory default is flash hook 4.

Voicemail access

Configures the key sequence for call for voicemail access. The factory default is flash hook *86. If the voicemail key sequence is entered on the phone a call will automatically be placed to the configured service provider using the configured authentication information.

Call Forward Busy Destination

Configures the number to forward calls to when busy. To configure call forward busy enter the calling prefix key (*74 is the factory default), the number to dial and then on hook the phone. You will hear a second dial

tone after entering the calling prefix key. Before using, call forward busy must be enabled using the activate sequence defined in the supplementary service table.

Example:

*743019751000 and on-hook the phone. All calls received will forward to 3019751000 when the phone is busy.

Hotline

Configures the number to call when the telephone goes off hook. To configure the hotline number enter the calling prefix key (*75 is the factory default), the number to dial and then on hook the phone. You will hear a second dial tone after entering the calling prefix key. Before using hotline calling it must be enabled using the activate sequence defined in the supplementary service table.

Example:

*753019751000 and on-hook the phone. When the handset is lifted, 3019751000 will immediately be called.

Control Timer Values

Control Timer Values				
Hook Flash Timer: (100 ~ 1100 ms)	<input type="text" value="1100"/>	ms	SIP Session Timer value:	<input type="text"/>
Conditional Call Forwarding Timer:	<input type="text" value="10"/>	sec	Warm Line Delay:	<input type="text" value="6000"/> ms
Interdigit Timer:	<input type="text" value="4000"/>	ms	Offhook Idle Time:	<input type="text" value="8000"/> ms
Offhook Warning Tone Time:	<input type="text" value="12000"/>	ms		

Figure 47. Control Timer Values section of Localization window

Hook Flash Timer

Maximum on-hook time before off-hook to qualify as hookflash. More than this value and the on-hook event is treated as on-hook (hanging up the call).

Minimum on-hook time before off-hook to qualify as hookflash. At less than this value, the on-hook event is ignored.

SIP Session Timer value

The amount of time the SmartLink 4020 will wait during an active call to send repeated re-invites on active calls to allow the SIP server to determine the status of a call.

Conditional Call Forwarding Timer

Specified a time period as a call forward condition. After the number of seconds specified, the conditional call forwarding process will be performed.

Warm Line Delay

Specify a time period as a delay time for warm line dialing. If warm line is enabled, then the SmartLink 4020 will wait this amount of time after the handset is off-hook before dialing the warm line phone number.

Interdigit Timer

The number of seconds the SmartLink 4020 will wait for the caller to input a subsequent digit of the dialed number. If the timer value is exceeded before the dial plan is matched (see section “[Gateway Settings](#)” on page 50), the busy tone will be played to the caller.

Offhook Idle Time

If the handset is off-hook with no dialing activity for longer than the time specified, then the busy tone will be played. The default is 6000 ms (6 seconds).

Offhook Warning tone time

If the handset is off-hook with no dialing activity for longer than the time specified, then the off-hook warning tone will be played. The default is 12000 ms (12 seconds). This value should be greater than the off-hook idle time (see section “[Offhook Idle Time](#)”).

FXS Port

Choose the correct country for a proper impedance match.

FXS Port	
FXS Port Input Gain:	<input type="text"/> db (-12 ~ 18)
FXS Port Output Gain:	<input type="text"/> db (-12 ~ 18)
Caller ID Method:	<input type="text"/> France
<input checked="" type="checkbox"/> "Call Progress Tones" Synchronization	

Figure 48. FXS Port Polarity Configuration section of Localization window

FXS port Input Gain

Adjust the input gain level for FXS port.

FXS port Output Gain

Adjust the output gain level for FXS port.

Caller ID Method

Specifies the country-specific Caller ID format.

"Call Progress Tones" Synchronization

When “*Call Progress Tones*” *Synchronization* is selected, the Caller ID presentation method value is used to automatically set the county-specific call progress tones.

Ring Setting

Ring Setting		
Ring Waveform:	<input type="text"/> Sinusoid	Ring Frequency:
Ring Voltage:	<input type="text"/>	

Figure 49. Ring Setting section of Localization window

Ring Waveform

Specify the ring tone waveform.

Ring Frequency

Specify the ring tone frequency.

Ring Voltage

Specify the ring tone voltage.

FXS Port Polarity Configuration

FXS Port Polarity Configuration	
Idle Polarity:	Forward
Caller Conn Polarity:	Forward
<input type="button" value="save"/>	

Figure 50. FXS Port Polarity section of Localization window

Idle Polarity

Polarity before call connected.

Caller Conn Polarity

Polarity after outbound call connected.

Saving your work

When you are finished configuring settings, click the **Save** button (see [figure 50](#)) to save the changes.

SNMP Configuration

SNMP Configuration	
SNMP Trap Configuration	
IP address:	<input type="text"/>
Trap Community:	<input type="text"/>
SNMP Community Configuration	
Read Community:	<input type="text" value="public"/>
Write Community:	<input type="text" value="private"/>
SNMP System Configuration	
System Description:	<input type="text"/>
System ObjectId:	<input type="text" value="4528"/>
<input type="button" value="Save SNMP Settings"/>	

Figure 51. SNMP Configuration window

SNMP Trap Configuration***IP address***

Trap host IP address.

Trap Community

The community name used by the SNMP manager to verify traps. The default value is *public*.

SNMP Community Configuration

Read Community

The community name used by the SNMP manager when reading SNMP data items from a client MIB. The default value is *public*.

Write Community

The community name used by the SNMP manager when setting SNMP data items in a client's MIB. The default value is *public*.

SNMP System Configuration

System Description

Description of the unit (e.g. "John's phone")

System Object Id

A vendor's enterprise ID

Saving your work

When you are finished configuring settings, click the **Save SNMP Settings** button to save the changes.

Auto Upgrade

The Smartlink 4020 family includes a configuration and firmware download manager server that allows for the updating of large numbers of SmartLink 4020s from a central location. By factory default, all SmartLink 4020 units are set with auto-update on and to access the Patton auto-update server. Many of Patton's carrier customers have chosen to setup their own auto-update server to provide service specific information for their end users. Patton recommends that end users do not change the auto-update server or set "Enable auto-upgrade" to "NO" without consulting with their service provider.

AutoUpgrade

Routine Upgrade every day(s)

Enable Auto Upgrade:

Auto Upgrade Protocol:

Upgrade Server:

Auto Upgrade URL:

Figure 52. AutoUpgrade window

Routine Upgrade every xxx day(s)

If selected, the Smartlink 4020 will check for automatically check for updates at system reload time and on a periodic basis based on the number of days selected.

Enable Auto Upgrade

Enable or disable auto upgrade—if enabled, the SmartLink 4020 will automatically check the upgrade server on a periodic basis for new system firmware and software upon reload or power cycle.

Auto Upgrade Protocol

Select the protocol for auto upgrade

Upgrade Server

Specify the auto upgrade server IP address

Auto Upgrade URL

Specify the auto upgrade server by URL. This field is dependent on the auto upgrade service package installation. The default value is **iadmgr**.

Saving your work

When you are finished configuring settings, click the **Save AutoUpgrade** button to save the changes.

Manual Upgrade

For both HTTP and TFTP methods, the device will reboot itself into the downloader mode if the main application is executing, and proceed with the ROM file download and permanent write of the application to the device's flash memory. During download of new firmware images, the LEDs on the SmartLink 4020 will flash sequentially. Typically, HTTP downloads take about 5–10 minutes. After the download is completed, the download status page will be displayed.

The screenshot shows a web-based manual upgrade interface. At the top, a warning message states: "Warning! The download process will reset the unit into the download mode. This will terminate all network connections and reset your browser connection." Below this, there are two sections: "TFTP Download method (Select remote TFTP server IP address and filename)" and "HTTP Download method (Select filename on local browser machine)". The TFTP section contains fields for "TFTP Server IP:" and "Filename:", along with a "Start TFTP Download" button. The HTTP section contains a "Filename:" field with a "Browse..." button and a "Start HTTP Download" button. A large empty area at the bottom is likely for displaying download progress or status.

Figure 53. Manual Upgrade window

Reload




Figure 54. Reload window



Reloading the system will terminate all network connections and restart your browser connection.

CAUTION

Chose the *Reload and execute Main Application* option, for execution of the main application which you have configured, once you reload the system.

Chose the *Reload and execute Downloader Application* option, to begin downloading, once you reload the system.

Chapter 8 **Documentation**

Chapter contents

Introduction	82
--------------------	----

Introduction

Clicking the **Documentation** link (see [figure 55](#)) connects to the Patton website to display the most current version of the *SmartLink 4020 Getting Started Guide* in portable document format (PDF).



Figure 55. Documentation link

Chapter 9 **Logout**

Chapter contents

Introduction	84
--------------------	----

Introduction

Clicking **Logout** (see [figure 56](#)) displays *Logout—Sure to Logout?*.

If you want to exit from the SmartLink management utility, click the **Logout** button (see [figure 56](#)).




Figure 56. Logout window

You will be returned to the password verification page (see [figure 57](#)).

A screenshot of a password verification page. It contains the text "This unit is password protected" and "Please enter the correct password to access the web pages". Below this is a password input field and an "Authenticate" button.

Figure 57. Password verification page

Chapter 10 **Contacting Patton for assistance**

Chapter contents

Introduction	87
Contact information	87
Patton support headquarters in the USA	87
Alternate Patton support for Europe, Middle East, and Africa (EMEA)	87
Warranty Service and Returned Merchandise Authorizations (RMAs)	87
Warranty coverage	87
Out-of-warranty service	88
Returns for credit	88
Return for credit policy	88
RMA numbers	88
Shipping instructions	88

Introduction

This chapter contains the following information:

- “[Contact information](#)”—describes how to contact Patton technical support for assistance.
- “[Warranty Service and Returned Merchandise Authorizations \(RMAs\)](#)”—contains information about the RAS warranty and obtaining a return merchandise authorization (RMA).

Contact information

Patton Electronics offers a wide array of free technical services. If you have questions about any of our other products we recommend you begin your search for answers by using our technical knowledge base. Here, we have gathered together many of the more commonly asked questions and compiled them into a searchable database to help you quickly solve your problems.

Patton support headquarters in the USA

- Online support: available at www.patton.com
- E-mail support: e-mail sent to support@patton.com will be answered within 1 business day
- Telephone support: standard telephone support is available five days a week—from **8:00 am** to **5:00 pm** EST (1300 to 2200 UTC/GMT)—by calling +1 (301) 975-1007
- Fax: +1 (253) 663-5693

Alternate Patton support for Europe, Middle East, and Africa (EMEA)

- Online support: available at www.patton-inalp.com
- E-mail support: e-mail sent to support@patton-inalp.com will be answered within 1 business day
- Telephone support: standard telephone support is available five days a week—from **8:00 am** to **5:00 pm** CET (0900 to 1800 UTC/GMT)—by calling +41 (0)31 985 25 55
- Fax: +41 (0)31 985 25 26

Warranty Service and Returned Merchandise Authorizations (RMAs)

Patton Electronics is an ISO-9001 certified manufacturer and our products are carefully tested before shipment. All of our products are backed by a comprehensive warranty program.

Note If you purchased your equipment from a Patton Electronics reseller, ask your reseller how you should proceed with warranty service. It is often more convenient for you to work with your local reseller to obtain a replacement. Patton services our products no matter how you acquired them.

Warranty coverage

Our products are under warranty to be free from defects, and we will, at our option, repair or replace the product should it fail within one year from the first date of shipment. Our warranty is limited to defects in workmanship or materials, and does not cover customer damage, lightning or power surge damage, abuse, or unauthorized modification.

Out-of-warranty service

Patton services what we sell, no matter how you acquired it, including malfunctioning products that are no longer under warranty. Our products have a flat fee for repairs. Units damaged by lightning or other catastrophes may require replacement.

Returns for credit

Customer satisfaction is important to us, therefore any product may be returned with authorization within 30 days from the shipment date for a full credit of the purchase price. If you have ordered the wrong equipment or you are dissatisfied in any way, please contact us to request an RMA number to accept your return. Patton is not responsible for equipment returned without a Return Authorization.

Return for credit policy

- Less than 30 days: No Charge. Your credit will be issued upon receipt and inspection of the equipment.
- 30 to 60 days: We will add a 20% restocking charge (crediting your account with 80% of the purchase price).
- Over 60 days: Products will be accepted for repairs only.

RMA numbers

RMA numbers are required for all product returns. You can obtain an RMA by doing one of the following:

- Completing a request on the RMA Request page in the *Support* section at www.patton.com
- By calling **+1 (301) 975-1007** and speaking to a Technical Support Engineer
- By sending an e-mail to returns@patton.com

All returned units must have the RMA number clearly visible on the outside of the shipping container. Please use the original packing material that the device came in or pack the unit securely to avoid damage during shipping.

Shipping instructions

The RMA number should be clearly visible on the address label. Our shipping address is as follows:

Patton Electronics Company

RMA#: xxxx

7622 Rickenbacker Dr.

Gaithersburg, MD 20879-4773 USA

Patton will ship the equipment back to you in the same manner you ship it to us. Patton will pay the return shipping costs.

Appendix A **Compliance information**

Chapter contents

Compliance	90
EMC Compliance:	90
Safety Compliance	90
Radio and TV Interference	90
CE notice (Declaration of Conformity)	90

Compliance

EMC Compliance:

FCC Part 15, Class B

EN55022, Class B

EN55024

Safety Compliance

EN60950-1

Radio and TV Interference

The SmartLink router generates and uses radio frequency energy, and if not installed and used properly—that is, in strict accordance with the manufacturer's instructions—may cause interference to radio and television reception. The SmartLink router have been tested and found to comply with the limits for a Class B computing device in accordance with specifications in Subpart B of Part 15 of FCC rules, which are designed to provide reasonable protection from such interference in a commercial installation. However, there is no guarantee that interference will not occur in a particular installation. If the SmartLink router does cause interference to radio or television reception, which can be determined by disconnecting the unit, the user is encouraged to try to correct the interference by one or more of the following measures: moving the computing equipment away from the receiver, re-orienting the receiving antenna and/or plugging the receiving equipment into a different AC outlet (such that the computing equipment and receiver are on different branches).

CE notice (Declaration of Conformity)

We certify that the apparatus identified in this document conforms to the requirements of Council Directive 1999/5/EC on the approximation of the laws of the member states relating to Radio and Telecommunication Terminal Equipment and the mutual recognition of their conformity.

The safety advice in the documentation accompanying this product shall be obeyed. The conformity to the above directive is indicated by the CE sign on the device.

Appendix B **Specifications**

Chapter contents

Voice Connectivity	92
Connectivity	92
Voice Processing (signalling dependent)	92
Fax and Modem Support	92
Voice Services/Features	93
IP Services	93
Management	93
Operating Environment	93
System	93

Voice Connectivity

2-wire Loopstart, RJ-11/12

Short haul loop 1.1 km @3REN

Caller-ID Type-1/2 FSK and ITU V.23/Bell 202 generation

Connectivity

2 10/100 Full Duplex/Autosensing Ethernet RJ-45

Voice Processing (signalling dependent)

SIP

MGCP

- Packet Cable NCS 1.0
- IETF MGCP 1.0

Voice codes

- G.711 A-Law/μ-Law (64 kbps)
- G.726 (ADPCM 40, 32, 24, 16 kbps)
- G.723.1 (5.3 or 6.3 kbps)
- G.729ab (8 kbps)

G.168 echo cancellation

4 parallel voice connections

DTMF detection and generation

Carrier tone detection and generation

Silence suppression and comfort noise

Configurable dejitter buffer

DTFM in-band & out-of-band

Configurable transmit packet length

RTP/RTCP (RFC 1889)

Fax and Modem Support

G.711 transparent FAX

T.38 Fax relay (9.6 k, 14.4 k)

Voice Services/Features

Call forwarding
Call transfer
Call hold
Call waiting
3-way calling

IP Services

IPv4 router; RIPv1, v2 (RFC 1058 and 2453)
IP filtering
NAPT
NTP
DHCP client & server
PPPoE
IPSEC VPN
Programmable static routes
ICMP redirect (RFC 792); Packet fragmentation
DiffServe/ToS set or queue per header bits
VLAN support 802.1p/q
AES/DES/3DES Encryption

Management

Browser configuration interface
TFTP configuration & firmware loading
SNMP v2 agent (MIB II and private MIB)

Operating Environment

Operating temperature: 0–40°C (32–104°F)
Operating humidity: 5–80% (non condensing)

System

Power: 100–240 VAC (50/60 Hz)

Appendix C **Dial plans**

Chapter contents

Introduction	95
Sample Dial Plans.....	95
Simple Dial Plan	95
Non-dialed Line Dial Plan	95
Complex Dial Plan	95

Introduction

The MGCP and SIP code will allow provisioning (via web browser) of the dial plan. A dial plan gives the unit a map to determine when a complete number has been entered and should be passed to the SIP server or gatekeeper for resolution into a destination IP address. Dial plans are expressed using the same syntax as used by MGCP NCS specification.

The formal syntax of the dial plan is described by the following notation:

```

Digit ::= "0" | "1" | "2" | "3" | "4" | "5" | "6" | "7" | "8" | "9"
Timer ::= "T" | "t"
Letter ::= Digit | Timer | "#" | "*" | "A" | "a" | "B" | "b" | "C" | "c" | "D" | "d"
Range ::= "X" | "x" -- matches any digit
| "[" Letters "]" -- matches any of the specified letters
Letters ::= Subrange | Subrange Letters
Subrange ::= Letter -- matches the specified letter
| Digit "-" Digit -- matches any digit between first and last
Position ::= Letter | Range
StringElement ::= Position -- matches any occurrence of the position
| Position "." -- matches an arbitrary number of occurrences
including 0
String ::= StringElement | StringElement String
StringList ::= String | String "|" StringList
DialPlan ::= String | "(" StringList ")"

```

A dial plan, according to this syntax, is defined either by a (case insensitive) string or by a list of strings. Regardless of the above syntax a timer is only allowed if it appears in the last position in a string (12T3 is not valid). Each string is an alternate numbering scheme. The unit will process the dial plan by comparing the current dial string against the dial plan, if the result is under qualified (partial matches at least one entry) then it will do nothing further. If the result matches or is over-qualified (no further digits could possibly produce a match) then send the string to the gatekeeper and clear the dial string. The Timer T is activated when it is all that is required to produce a match. The period of timer T is 4 seconds. For example a dial plan of (xxxT|xxxxxx) will match immediately if 5 digits are entered, it will also match after a 4 second pause when 3 digits are entered.

Sample Dial Plans

Simple Dial Plan

Allows dialing of 7-digit numbers (e.g. 5551234) or an operator on 0. Dial plan is (0T|xxxxxxxx)

Non-dialed Line Dial Plan

As soon as handset is lifted the unit contacts the gatekeeper (used for systems where DTMF detection is done in-call). Dial plan is (x.) i.e. match against 0 (or more) digits. Note: the dot ‘.’

Complex Dial Plan

- Local operator on 0, long distance operator on 00
- 4-digit local extension number starting with 3, 4, or 5
- 7-digit local numbers are prefixed by an 8

- 2-digit star services (e.g. 69)
- 10-digit long distance prefixed by 91
- International numbers starting with 9011+variable number of digits.

Dial plan for this is:

```
(0T|00T|[3-5]xxx|8xxxxxxxx|*xx|91xxxxxxxxx|9011x.T)
```

Appendix D **Calling Features**

Chapter contents

Introduction	98
--------------------	----

Introduction

The SmartLink 4020 family supports advanced calling features that can be turned on and off from phones attached to the SmartLink 4020 (see [table 3](#)).

Note Your telephony service provider must enable your service for these calling features to work.

Note F in [table 3](#) refers to the *hook flash* event.

Table 3. Calling features

Feature	Keypad	Feature	Keypad
Call Hold	F1	Call Retrieve	F*
Conference	F7	Conference Drop	F8
Call Transfer	F4		
Do not Disturb ON	*82	Do not Disturb OFF	#82
Distinctive ON	*90	Distinctive OFF	#90
Call Waiting ON	*91	Call Waiting OFF	#91
Incoming Caller ID Display ON	*92	Incoming Caller ID Display OFF	#92
Self Caller ID Block Service ON	*93	Self Caller ID Block Service OFF	#93
Anonymous Call Reject ON	*94	Anonymous Call Reject OFF	#94
Incoming Call Block ON	*95	Incoming Call Block OFF	#95
Call Forward Selective ON	*96	Call Forward Selective OFF	#96
Call Forward All ON	*97	Call Forward All OFF	#97
Call Forward Busy ON	*98	Call Forward Busy OFF	#98
Warm Line ON	*99	Warm Line OFF	#99
IP Dialing ON	*80	IP Dialing OFF	#80
Speed Dialing ON	*81	Speed Dialing OFF	#81
Call Return	*60		
Config Warm Line Number (*70yyyy where yyyy = number to call)	*70		
Config Speed Dialing Number (*71xyyyy where x = speed dial key and yyyy = number to call)	*71		
Config IP Dialing (*72xxx*xxx*xxx*xxx*yyyy where xxx = IP address and yyyy = optional port number)	*72		
Set Call Forward Number (Wait for 3 short confirmation tones before hanging up)	*73		
Access Voicemail	*86		