

**Feedback on the
ATM Switch Router
Quick Software
Configuration Guide**

78-6897-01

Thank you for taking the time to fill out this response card. Your input is important to us and helps us to provide you with better documentation.

If you have comments about this document, please complete this self-addressed response card and mail it to us.

We also encourage you to make copies of this blank response card to complete and send to us whenever you have comments about this document. You can mail copies of this card to:

Cisco Systems, Inc.
Attn: Document
Resource Connection
170 West Tasman Drive
San Jose, CA 95134-9883

You can also send us your comments by e-mail to bug-doc@cisco.com, or fax your comments to us at (408)527-8089.

You can also submit comments electronically on the World Wide Web. Click **Feedback** in the toolbar and select **Documentation**. After you complete the form, click **Submit** to send it to Cisco. We appreciate your comments.



Documentation Response Card

Feedback on the ATM Switch Router Quick Software Configuration Guide, 78-6897-01

Please respond to the following statements by checking a number from 1 to 5:

- 5 Strongly agree
- 4 Somewhat agree
- 3 Neutral
- 2 Somewhat disagree
- 1 Strongly disagree

Overall, I am satisfied with this document.

Strongly agree 5 4 3 2 1 Strongly disagree

This document is accurate and free of errors.

Strongly agree 5 4 3 2 1 Strongly disagree

I can find the information I need in this document.

Strongly agree 5 4 3 2 1 Strongly disagree

This document is complete and offers enough relevant information for me to do my job.

Strongly agree 5 4 3 2 1 Strongly disagree

This document is written at the correct level of complexity for the subject matter.

Strongly agree 5 4 3 2 1 Strongly disagree

This document is useful to me in doing my job.

Strongly agree 5 4 3 2 1 Strongly disagree

Would you like us to contact you? Yes No

Additional Information

Mailing Information

Date

Company Name

Contact Name

Mailing Address

City State/Province

Zip/Postal Code Country

Phone () Extension

Fax () E-mail

ATM Switch Router Quick Software Configuration Guide

For the Catalyst 8540 MSR, Catalyst 8510 MSR,
and LightStream 1010

Corporate Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 526-4100

Customer Order Number: DOC-786897=
Text Part Number: 78-6897-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The following information is for FCC compliance of Class A devices: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to correct the interference at their own expense.

The following information is for FCC compliance of Class B devices: The equipment described in this manual generates and may radiate radio-frequency energy. If it is not installed in accordance with Cisco's installation instructions, it may cause interference with radio and television reception. This equipment has been tested and found to comply with the limits for a Class B digital device in accordance with the specifications in part 15 of the FCC rules. These specifications are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

Modifying the equipment without Cisco's written authorization may result in the equipment no longer complying with FCC requirements for Class A or Class B digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

You can determine whether your equipment is causing interference by turning it off. If the interference stops, it was probably caused by the Cisco equipment or one of its peripheral devices. If the equipment causes interference to radio or television reception, try to correct the interference by using one or more of the following measures:

- Turn the television or radio antenna until the interference stops.
- Move the equipment to one side or the other of the television or radio.
- Move the equipment farther away from the television or radio.
- Plug the equipment into an outlet that is on a different circuit from the television or radio. (That is, make certain the equipment and the television or radio are on circuits controlled by different circuit breakers or fuses.)

Modifications to this product not authorized by Cisco Systems, Inc. could void the FCC approval and negate your authority to operate the product.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Access Registrar, AccessPath, Any to Any, AtmDirector, CCDA, CCDE, CCDP, CCIE, CCNA, CCNP, CCSI, CD-PAC, the Cisco logo, Cisco Certified Internetwork Expert logo, *CiscoLink*, the Cisco Management Connection logo, the Cisco NetWorks logo, the Cisco Powered Network logo, Cisco Systems Capital, the Cisco Systems Capital logo, Cisco Systems Networking Academy, the Cisco Technologies logo, ConnectWay, ControlStream, Fast Step, FireRunner, GigaStack, IGX, JumpStart, Kernel Proxy, MGX, Natural Network Viewer, NetSonar, Network Registrar, New World, *Packet*, PIX, Point and Click Internetworking, Policy Builder, Precept, RouteStream, Secure Script, ServiceWay, SlideCast, SMARTnet, StreamView, *The Cell*, TrafficDirector, TransPath, ViewRunner, VirtualStream, VisionWay, VlanDirector, Workgroup Director, and Workgroup Stack are trademarks; Changing the Way We Work, Live, Play, and Learn, Empowering the Internet Generation, The Internet Economy, and The New Internet Economy are service marks; and Asist, BPX, Catalyst, Cisco, Cisco IOS, the Cisco IOS logo, Cisco Systems, the Cisco Systems logo, the Cisco Systems Cisco Press logo, Enterprise/Solver,

EtherChannel, EtherSwitch, FastHub, FastLink, FastPAD, FastSwitch, IOS, IP/TV, IPX, LightStream, LightSwitch, MICA, NetRanger, Registrar, StrataView Plus, Stratm, TeleRouter, and VCO are registered trademarks of Cisco Systems, Inc. in the U.S. and certain other countries. All other trademarks mentioned in this document are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any of its resellers. (9906R)

ATM Switch Router Quick Software Configuration Guide

Copyright © 1999, Cisco Systems, Inc.

All rights reserved.

About This Guide ix

Purpose	ix
Audience	ix
Organization	x
Related Documentation	x
Conventions	xi
Cisco Connection Online	xii
Documentation CD-ROM	xiii

Chapter 1 Using the Command-Line Interface 1-1

Getting Help	1-2
Understanding Command Modes	1-2
Understanding Interface Numbering	1-3
Card Numbering	1-4
Subcard Numbering	1-5
Processor Card Numbering	1-6
Port Numbering	1-6
Example of Interface Numbering	1-7
Undoing a Command or Feature	1-8
Displaying the Configuration	1-8
Saving Configuration Changes	1-9
Where to Go Next	1-10

Chapter 2 Getting Started 2-1

Naming the ATM Switch Router	2-1
Assigning a Password	2-3
Setting Up Remote Administrative Access	2-4

Chapter 3	Configuring SVCs, PVCs, SoftPVCs, PVPs, and VPTunnels	3-1
	Configuring SVCs	3-1
	Configuring the Router	3-2
	Configuring Signaling on the Routers	3-3
	Configuring the IP Address and ESI Address	3-4
	Determining the NSAP Address	3-6
	Configure a Map Group and Map List	3-7
	Configuring PVCs	3-9
	Configuring the ATM Switch Router	3-10
	Configuring the Router	3-12
	Configuring Soft PVCs	3-13
	Configuring the ATM Switch Router	3-14
	Determining the Destination ATM Switch Router NSAP Address	3-15
	Configuring the Source ATM Switch Router	3-16
	Configuring the Router	3-17
	Configuring PVPs	3-19
	Configuring VP Tunnels	3-21
Chapter 4	Configuring LANE	4-1
	Understanding LANE on ATM	4-2
	Understanding LANE Components	4-2
	Implementing LANE	4-3
	Supporting LAN Protocols	4-3
	Addressing	4-3
	Assigning Components to Interfaces and Subinterfaces	4-4
	Configuring LANE Router and LAN Switch Requirements	4-4
	Configuring a LEC	4-5
	Configuring the LECS	4-6
	Configuring the ATM Address of the LECS	4-6
	Configuring the LECS Database	4-7
	Configuring the LES/BUS	4-8

LANE Configuration Examples	4-9
Verifying Connectivity	4-15
Confirming Connectivity between the ATM Switch Router and the Routers	4-16
Displaying the LANE Client Configuration on the ATM Switch Router	4-17

Chapter 5 Configuring Tag Switching 5-1

Software Restrictions	5-1
Configuring Tag Switching on an ATM Switch Router	5-2
Enabling Tag Switching on the ATM Interface	5-2
Configuring the Routing Protocol	5-4
Configuring Tag Switching on a Router	5-6
Tag Switching Configuration Example	5-7

Index



About This Guide

This preface describes the purpose, audience, organization, and conventions of this *ATM Switch Router Quick Software Configuration Guide*, and provides information on how to obtain related documentation.

Purpose

This guide is intended as a starting place for configuring the ATM switch router. Only a small subset of features are described in this guide. For complete configuration information, refer to the *ATMSwitch Router Software Configuration Guide*.

Audience

This guide provides quick configuration instructions for experienced network administrators or engineers who are responsible for the initial configuration of the ATM switch router.

Organization

This guide is organized as follows:

Chapter	Title	Description
Chapter 1	Using the Command-Line Interface	Describes what you need to know about the Cisco IOS software before you begin to configure the ATM switch router
Chapter 2	Getting Started	Describes how to name the ATM switch router, assign a password, and set up remote administrative access
Chapter 3	Configuring SVCs, PVCs, SoftPVCs, PVPs, and VPTunnels	Describes how to configure the following virtual connections: SVCs ¹ , PVCs ² , soft PVCs, PVPs, and VP tunnels
Chapter 4	Configuring LANE	Describes how to configure LANE ³
Chapter 5	Configuring Tag Switching	Describes how to configure tag switching

1 SVCs = switched virtual circuits.

2 PVCs = permanent virtual circuits.

3 LANE = LAN Emulation.

Related Documentation

This guide is part of the ATM switch router software documentation set, which includes:

- *Guide to ATM Technology*
- *ATM Switch Router Software Configuration Guide*
- *ATM Switch Router Command Reference*

Conventions

This document uses the following conventions:

Convention	Description
boldface font	Commands and keywords are in boldface .
<i>italic font</i>	Arguments for which you supply values are in <i>italics</i> .
[]	Elements in square brackets are optional.
{ x y z }	Alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
screen font	Terminal sessions and information the system displays are in <i>screen font</i> .
boldface screen font	Information you must enter is in boldface screen font .
<i>italic screen font</i>	Arguments for which you supply values are in <i>italic screen font</i> .
—■	This pointer highlights an important line of text in an example.
^	The symbol ^ represents the key labeled Control—for example, the key combination ^D in a screen display means hold down the Control key while you press the D key.
< >	Nonprinting characters, such as passwords are in angle brackets.

Notes use the following conventions:

Note Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the publication.

Timesavers use the following conventions:



Timesaver Means *the described action saves time*. You can save time by performing the action described in the paragraph.

Tips use the following conventions:



Tips
Means *the following are useful tips*.

Cautions use the following conventions:



Caution Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Cisco Connection Online

Cisco Connection Online (CCO) is Cisco Systems' primary, real-time support channel. Maintenance customers and partners can self-register on CCO to obtain additional information and services.

Available 24 hours a day, 7 days a week, CCO provides a wealth of standard and value-added services to Cisco's customers and business partners. CCO services include product information, product documentation, software updates, release notes, technical tips, the Bug Navigator, configuration notes, brochures, descriptions of service offerings, and download access to public and authorized files.

CCO serves a wide variety of users through two interfaces that are updated and enhanced simultaneously: a character-based version and a multimedia version that resides on the World Wide Web (WWW). The character-based CCO supports Zmodem, Kermit, Xmodem, FTP, and Internet e-mail, and it is excellent for quick access to information over lower bandwidths. The WWW version of CCO provides richly formatted documents with photographs, figures, graphics, and video, as well as hyperlinks to related information.

You can access CCO in the following ways:

- WWW: <http://www.cisco.com>
- WWW: <http://www-europe.cisco.com>
- WWW: <http://www-china.cisco.com>
- Telnet: cco.cisco.com
- Modem: From North America, 408526-8070; from Europe, 33164464082. Use the following terminal settings: VT100 emulation; databits: 8; parity: none; stop bits: 1; and connection rates up to 28.8kbps.

For a copy of CCO's Frequently Asked Questions (FAQ), contact cco-help@cisco.com. For additional information, contact cco-team@cisco.com.

Note If you are a network administrator and need personal technical assistance with a Cisco product that is under warranty or covered by a maintenance contract, contact Cisco's Technical Assistance Center (TAC) at 800553-2447, 408526-7209, or tac@cisco.com. To obtain general information about Cisco Systems, Cisco products, or upgrades, contact 800553-6387, 408526-7208, or cs-rep@cisco.com.

Documentation CD-ROM

Cisco documentation and additional literature are available in a CD-ROM package, which ships with your product. The Documentation CD-ROM, a member of the Cisco Connection Family, is updated monthly. Therefore, it might be more current than printed documentation. To order additional copies of the Documentation CD-ROM, contact your local sales representative or call customer service. The CD-ROM package is available as a single package or as an annual subscription. You can also access Cisco documentation on the World Wide Web at <http://www.cisco.com>, <http://www-china.cisco.com>, or <http://www-europe.cisco.com>.

If you are reading Cisco product documentation on the World Wide Web, you can submit comments electronically. Click **Feedback** in the toolbar and select **Documentation**. After you complete the form, click **Submit** to send it to Cisco. We appreciate your comments.

Using the Command-Line Interface

This chapter describes what you need to know about the Cisco IOS software (the software that runs the ATM switch router) before you begin to configure it, and includes the following sections:

- Getting Help
- Understanding Command Modes
- Understanding Interface Numbering
- Undoing a Command or Feature
- Displaying the Configuration
- Saving Configuration Changes

Understanding these concepts will save you time later on. If you have never used the Cisco IOS software or need a refresher, take a few minutes to read this chapter before you proceed to the next chapter.

If you are already familiar with the CiscoIOS software, skip this chapter and proceed to the next chapter, “Getting Started.”

Note This document assumes you have already connected all necessary external devices to the ATM switch router and configured your PC terminal emulation program for 9600baud, 8 data bits, no parity, and 2 stop bits.

Getting Help

You can use the question mark (?) and arrow keys to help you enter commands.

For a list of available commands, type the question mark:

```
Switch> ?
```

To complete a command, type a few known characters followed by the question mark (with no space):

```
Switch> s?
```

For a list of command variables, type the command followed by a space and a question mark:

```
Switch> show ?
```

To redisplay a command you previously entered, press the up arrow key. Continue to press the up arrow key for more commands.

Understanding Command Modes

You use many different command modes when you configure the ATM switch router. Each command mode restricts you to a subset of commands.

In the following example, notice how the prompt changes after each command to indicate a new command mode:

```
Switch> enable
Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)# line vty 1 4
Switch(config-line)# atm router pnni
Switch(config-atm-router)# exit
Switch(config)# end
Switch#
```



Tips

If you are having difficulty entering a command, check the prompt and then enter the question mark (?) for a list of available commands. You might be in the wrong command mode or using the wrong syntax.

Understanding Interface Numbering

Before you can configure a software interface, you need to know how the physical location of the port adapter or interface module in the chassis corresponds to how it is addressed (referred to) in the software. In interface configuration mode, you must enter the *card/subcard/port* number to configure an interface:

- *card*—Card number
- *subcard*—Subcard number
- *port*—Port number

Card, subcard, and port numbering all start at 0 and increment by 1, from top to bottom, and from left to right.

Note In the subsections that follow, the Catalyst8540MSR chassis is shown because it is the most robust system. The Catalyst8540MSR chassis has 13 slots and supports redundant route processors and switch cards. The Catalyst8510MSR and LightStream1010 chassis have only 5 slots and do not support redundant route processors or switch cards. But the numbering scheme concept is the same, regardless of which chassis you have.

Card Numbering

Card numbering starts at 0 and increments by 1 from top to bottom, as shown in Figure1-1. The card number slots are silkscreened on the left side of each slot.

Figure1-1 Card Numbering (Catalyst8540MSR Shown)



Subcard Numbering

Subcards are numbered from 0 to 1, left to right. Subcards include half-width port adapters and full-width interface modules (such as an OC-12 interface module).

Two half-width port adapters can occupy one chassis slot. Figure 1-2 shows that the two half-width port adapters in slot 0 are numbered subcards 0 and 1, from left to right. The port adapter in the left slot is numbered subcard 0, and the port adapter in the right slot is numbered subcard 1.

When you apply this numbering scheme to full-width interface modules, the subcard number is 0, because only one full-width interface module fits in a card slot. See Figure 1-2.

So, the *subcard* portion of the *card/subcard/port* CLI variable is either 0 or 1 for half-width port adapters, and 0 only for full-width interface modules. For example, in 0/0/1 the second 0 represents subcard 0.

Figure 1-2 Subcard Numbering



Processor Card Numbering

The CPU interface on the processor card is addressed as either **ethernet 0** or **atm 0**, depending on the type of configuration. The other interfaces on the processor card start with 0 and increment by 1. See Figure 1-3.

Figure1-3 Processor Card Numbering (Catalyst8540MSR Route Processor Shown)



Port Numbering

Port numbering for each subcard starts with 0 and increments by 1, from left to right, as shown in Figure 1-4.

Figure1-4 Port Numbering



Example of Interface Numbering

Figure1-5 shows a Catalyst8540MSR chassis populated with several half-width port adapters and full-width interface modules. In this example, 12/0/3 is called out in the last interface module installed in the chassis. The 12/0/3 interface number is derived by:

- Card (12)—The interface module is in the thirteenth slot of the chassis; therefore, the card number is 12. (Card numbering starts at 0 and increments by 1 from top to bottom.)
- Subcard (0)—The full-width interface module is the only subcard within the twelfth slot; therefore, the subcard number is 0.
- Port (3)—The callout points to the fourth port on the interface module; therefore, the port number is 3. (Port numbering starts at 0 and increments by 1 from left to right.)

Figure1-5 **Interface Numbering Example (Catalyst8540MSR Shown)**



Undoing a Command or Feature

If you want to undo a command you entered or disable a feature, you can enter the keyword **no** before most commands; for example, **no atm router pnni**.

Displaying the Configuration

You can display various aspects of the ATM switch router configuration by entering **more** commands. You can only use **more** commands in user EXEC and privileged EXEC modes.

To display the current running (unsaved) configuration, enter the **more system:running-config** command:

```
Switch# more system:running-config
Building configuration...

Current configuration:
!
version XX.X
<<Information omitted>>
!
line con 0
line vty 0 4
no login
!
end
```

To display the saved configuration (stored in nonvolatile random-access memory [NVRAM]), enter the **more nvram:startup-config** command.

To see a complete list of available **more** commands, enter the **more ?** command:

```
Switch# more ?
  access-lists      List access lists
  accounting         Accounting data for active sessions
  aliases            Display alias commands
  arp                ARP table
  async              Information on terminal lines used as router
interfaces
  atm                ATM information
  boot               Boot and related environment variable
  buffers            Buffer pool statistics
  calendar           Display the hardware calendar
  cdp                CDP information
<<Information omitted.>>
```

Saving Configuration Changes

Enter the **copy system:running-config nvram:startup-config** command to save your configuration changes to NVRAM so that they will not be lost if there is a system reload or power outage:

```
Switch# copy system:running-config nvram:startup-config
Building configuration...
```

Depending on the size and complexity of the configuration file, it might take a minute or two to save the configuration to NVRAM. After the configuration has been saved, the following displays:

```
[OK]
Switch#
```

The ATM switch router contains two types of configuration files: the running configuration and the startup configuration. The running configuration is the current (unsaved) configuration that reflects the most recent configuration changes. The startup configuration is the saved configuration in NVRAM and is used when the system initializes. The two configuration files provide a safeguard against configuration mistakes. If you make a mistake while configuring the ATM switch router, you can revert back to the saved startup configuration by entering the **copy nvram:startup-config system:running-config** command. Or you can reboot the ATM switch router (without saving the configuration changes) to use the startup configuration in NVRAM.

Where to Go Next

Now that you have learned some CiscoIOS software basics, you can begin to configure the ATM switch router.

Remember that:

- You can use the question mark (?) and arrow keys to help you enter commands.
- Each command mode restricts you to a set of commands. If you have difficulty entering a command, check the prompt and then enter the question mark (?) for a list of available commands. You might be in the wrong command mode or using the wrong syntax.
- If you want to disable a feature, enter the keyword **no** before the command; for example, **no atm router pnni**.
- You need to save your configuration changes to NVRAM so that they will not be lost if a system reload or power outage occurs.

Proceed to the next chapter, “Getting Started,” to begin configuring the ATM switch router.

Getting Started

This chapter describes basic software configuration of the ATM switch router, and includes the following sections:

- Naming the ATM Switch Router
- Assigning a Password
- Setting Up Remote Administrative Access

Note For more software configuration information, refer to the *ATM Switch Router Software Configuration Guide*. Refer to the *ATM Switch Router Command Reference* publication for command syntax.

Naming the ATM Switch Router

You can name the ATM switch router to distinguish it from other Cisco devices in your network. This feature is especially useful when you have multiple console windows open and you need to distinguish one Cisco device from another. Naming the switch changes the default prompt (Switch>) to a prompt name of your choice; for example, Nevada_Switch>.

Naming the ATM Switch Router

Take these steps:

Step	Command	Purpose
1	Switch> enable	Enter privileged EXEC mode.
2	Switch# configure terminal Switch(config)#	Enter global configuration mode.
3	Switch(config)# hostname <i>name</i> Name(config)#	Enter the host name for the switch. Note that the prompt changes to match the host name. Note The pound sign (#) that follows the host name indicates the current mode of operation and is added automatically.
4	Name(config)# end Name#	Return to privileged EXEC mode.

Example

```
Switch> enable
Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)# hostname Nevada_Switch
Nevada_Switch(config)#
```

Verify

```
Switch# more system:running-config
!
version xx.x
no service pad
service timestamps debug uptime
service timestamps log uptime
no service password-encryption
!
-----■ hostname Nevada_Switch
!
<<Information omitted.>>
```

Assigning a Password

Configure an administrative password on the ATM switch router to prevent unauthorized configuration changes.

Take these steps:

Step	Command	Purpose
1	Switch> enable	Enter privileged EXEC mode.
2	Switch# configure terminal Switch(config)#	Enter global configuration mode.
3	Switch(config)# enable password password	Enter the enable password.
4	Switch(config)# exit Switch#	Return to privileged EXEC mode.

Example

```
Switch> enable
Switch# configure terminal
Switch(config)# enable password guessme
Switch(config)# exit
Switch#
```

Verify

```
Switch# exit
Switch con0 is now available
Press RETURN to get started.
Switch> enable
Password: guessme
Switch#
```

Setting Up Remote Administrative Access

You can configure the Ethernet interface on the processor card (CPU card) so that you can Telnet to the ATM switch router and configure it remotely. This section describes how to configure the Ethernet port for remote administrative access.

Note For local administrative access, connect a PC or workstation to the console port on the processor card. This requires *physical* access to the ATM switch router.

Take these steps:

Step	Command	Purpose
1	Switch> enable	Enter privileged EXEC mode.
2	Switch# configure terminal Switch(config)#	Enter global configuration mode.
3	Switch(config)# ip route prefix mask ethernet 0[.subinterface]	Configure a static route on the Ethernet interface. If your management station or TFTP ¹ server is on a different subnet than the switch, you must configure a static IP route. ²
4	Switch(config)# interface ethernet 0 Switch(config-if)#	Enter interface configuration mode on the Ethernet interface.
5	Switch(config-if)# ip address address	Configure an IP address on the Ethernet interface.
6	Switch(config)# end Switch#	Return to privileged EXEC mode.

1 TFTP = Trivial File Transfer Protocol.

2 If you fail to configure a static IP route before installing a new image, you might lose remote administrative access to the switch. If this happens, you can regain access from a direct console connection, although this requires physical access to the console port on the processor card.

Example

```
Switch> enable
Switch# configure terminal
Switch(config)# ip route 172.20.52.0 255.255.255.0 ethernet 0
Switch(config)# interface ethernet 0
Switch(config-if)# ip address 172.20.52.20
Switch(config-if)# end
Switch#
```

Verify

```
Switch# show interface ethernet 0
Ethernet0 is up, line protocol is up
  Hardware is SonicT, address is 00e0.4fac.b400 (bia 00e0.4fac.b400)
  — Internet address is 172.20.52.20/26
  MTU 1500 bytes, BW 10000 Kbit, DLY 1000 usec, rely 255/255, load 1/255
  Encapsulation ARPA, loopback not set, keepalive set (10 sec)
  ARP type: ARPA, ARP Timeout 04:00:00
  Last input 00:00:00, output 00:00:00, output hang never
  Last clearing of "show interface" counters never
  Queueing strategy: fifo
  Output queue 0/40, 0 drops; input queue 0/75, 0 drops
  5 minute input rate 1000 bits/sec, 2 packets/sec
  5 minute output rate 0 bits/sec, 1 packets/sec
    897 packets input, 55088 bytes, 0 no buffer
    Received 337 broadcasts, 0 runts, 0 giants, 0 throttles
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    0 input packets with dribble condition detected
    20731 packets output, 2024862 bytes, 0 underruns
    0 output errors, 0 collisions, 1 interface resets
    0 babbles, 0 late collision, 0 deferred
    0 lost carrier, 0 no carrier
    0 output buffer failures, 0 output buffers swapped out
Switch#
```

Setting Up Remote Administrative Access

Configuring SVCs, PVCs, Soft PVCs, PVPs, and VP Tunnels

This chapter describes how to configure switched virtual circuits (SVCs), permanent virtual circuits (PVCs), soft PVCs, permanent virtual paths (PVPs), and VP tunnels, and includes the following sections:

- Configuring SVCs
- Configuring PVCs
- Configuring Soft PVCs
- Configuring PVPs
- Configuring VP Tunnels

Note For more software configuration information, refer to the *ATM Switch Router Software Configuration Guide*. Refer to the *ATM Switch Router Command Reference* publication for command syntax.

Configuring SVCs

An SVC is a logical connection established using signaling messages, which reduces the amount of manual configuration required. SVCs are established on demand and torn down when a release message is generated either by signaling messages or by the application.

On the ATM switch router, no configuration is necessary to set up a transit SVC (an SVC that does not terminate on the ATM switch router). The signaling channels are set up by default and do not require manual configuration.

Configuring SVCs

If the SVC terminates on a router, however, configuration *is* required on the router where the SVC terminates. For your convenience, the router configuration is described in this section.

Figure3-1 shows an example network that illustrates how to set up SVCs. This example network is used throughout this section.

Figure3-1 Example Network for Configuring SVCs



Configuring the Router

Perform the following tasks on both routers that terminate the SVC:

- Configure PVCs for QSAAL and ILMI signaling
- Configure IP and ESI addresses and subnet masks
- Determine the NSAP address
- Configure a map group and map list

The following subsections describe these procedures in detail.

Tips Open two Telnet windows for both the source and destination routers.

Configuring Signaling on the Routers

Configure PVCs for QSAAL and ILMI signaling on the main ATM interfaces of both the source and destination routers that terminate the SVC.

Note On the ATM switch router, the signaling and ILMI channels are set up by default and do not require manual configuration.

Take these steps:

Step	Command	Purpose
1	Router> enable Router#	Enter privileged EXEC mode.
2	Router# configure terminal Router(config)#	Enter global configuration mode.
3	Router(config)# interface atm <i>port[/slot]</i> Router(config-if)#	Enter interface configuration mode on the ATM interface.
4	Router(config-if)# atm pvc <i>number 0 5 qsaal</i>	Configure a PVC for QSAAL ¹ signaling.
5	Router(config-if)# atm pvc <i>number 0 16 ilmi</i>	Configure a PVC for ILMI signaling.
6	Router(config-if)# end Router#	Return to privileged EXEC mode.
7	(No command.)	Repeat this procedure on the other router.

1 QSAAL = Q.2931 protocol over signaling ATM adaptation layer

Configuring SVCs

Example

```
Router> enable
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# interface atm 0
Router(config-if)# atm pvc 1 0 5 qsaal
Router(config-if)# atm pvc 2 0 16 ilmi
Router(config-if)# end
Router#
```

Verify

```
Switch# show atm vc interface atm 0
VCD /
Interface Name VPI VCI Type Encaps Peak Kbps Avg/Min Kbps Burst Cells Sts
0 1 0 5 PVC SAAL 155000 155000
0 2 0 16 PVC ILMI 155000 155000 UP
Switch#
```

Configuring the IP Address and ESI Address

On an ATM subinterface, configure the IP address and an ESI address.

Take these steps:

Step	Command	Purpose
1	Router> enable Router#	Enter privileged EXEC mode.
2	Router# configure terminal Router(config)#	Enter global configuration mode.
3	Router(config-if)# interface atm <i>port[/slot][.subinterface]</i> multipoint	Configure an ATM subinterface.
4	Router(config-subif)# ip address <i>address mask</i>	Configure an IP address on the subinterface.

Step	Command	Purpose
5	Router(config-subif)# atm esi-address address	Configure a 14-digit ESI address on the subinterface (for example, 1111122222.00). After ILMI address registration is complete, an NSAP address is automatically created based on the ESI address you entered.
6	Router(config-subif)# end Router#	Return to privileged EXEC mode.
7	(No command.)	Repeat this procedure on the other router.

Example

```
Router> enable
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# interface atm 0.1 multipoint
Router(config-subif)# ip address 193.153.185.33 255.255.255.224
Router(config-subif)# atm esi-address 999999888888.00
Router(config-subif)# end
Router#
```

Verify

```
Switch# show interface atm 0.1
ATM0.1 is up, line protocol is up
  Hardware is ATMizer BX-50
  Internet address is 193.153.185.33/27
  MTU 4470 bytes, BW 155520 Kbit, DLY 100 usec, rely 255/255, load 1/255
  NSAP address: 47.0091810000000061E5BC01.999999888888.00
  Encapsulation ATM
Switch#
```

Configuring SVCs

Determining the NSAP Address

Determine the ATM network service access point (NSAP) address for both the source and destination routers. The NSAP addresses is required to complete the SVC.

Step	Command	Purpose
1	Router# <code>show interface atm port[/slot][.subinterface]</code>	Display the 20-byte NSAP address of the router port on which the SVC terminates. Enter the address in Table3-1. The NSAP address does not display in certain modes. In this case, you must enter an NSAP address that meets the following criteria: <ul style="list-style-type: none">• It must be unique in the network.• It must <i>not</i> be a broadcast or multicast MAC address.
2	(No command.)	Repeat this procedure to display the NSAP address of the other router.

Enter the 20-byte NSAP address of each router in the space provided below in Table3-1.

Table3-1 NSAP Addresses

Router	NSAP Address
Source router ¹	
Destination router ²	

1 In Figure3-1, the source router is router A.

2 In Figure3-1, the destination router is router D.

Example

```
Switch# show interface atm 0.1
ATM0.1 is up, line protocol is up
  Hardware is ATMizer BX-50
  Internet address is 192.153.185.65/27
  MTU 4470 bytes, BW 155520 Kbit, DLY 100 usec, rely 255/255, load 1/255
  NSAP address: 47.0091810000000061E5B5C01.555555555555.00
  Encapsulation ATM
Switch#
```

Verify

Not applicable.

Configure a Map Group and Map List

On an ATM subinterface, configure the map group and a map list.

Take these steps:

Step	Command	Purpose
1	Router> enable Router#	Enter privileged EXEC mode.
2	Router# configure terminal Router(config)#	Enter global configuration mode.
3	Router(config-if)# interface atm <i>port[/slot][.subinterface]</i> multipoint	Configure an ATM subinterface.
4	Router(config-subif)# map-group <i>name</i>	Enter the map group name on the ATM subinterface. The map group name is used to associate a map list to the subinterface.
5	Router(config-subif)# no shutdown	Enable the interface. Enter this command even if the interface is already up. This command enables the SAR ¹ process to use the newly configured parameters.
6	Router(config-subif)# exit Router(config)#	Return to global configuration mode.

Configuring SVCs

Step	Command	Purpose
7	Router(config)# map-list name	Create a map list to define an ATM map statement for the SVC. The name you enter here must match the map group name you specified in Step 4.
8	Router(config-map-list)# ip <i>dest-ipaddress atm-nsap</i> <i>dest-nsapaddrsss</i>	Add the destination router IP address and ATM NSAP address to the map list. Enter the addresses you noted in Table3-1 in the section "Determining the NSAP Address."
9	Router(config-map-list)# end Router#	Return to privileged EXEC mode.
10	(No command.)	Repeat this procedure on the other router.

1 SAR = Segmentation and Reassembly.

Example

```
Router> enable
Router# configure terminal
Router(config)# interface atm 0.1 multipoint
Router(config-subif)# map-group hawaii
Router(config-subif)# no shutdown
Router(config-subif)# exit
Router(config)# map-list hawaii
Router(config-map-list)# ip 192.153.185.65 atm-nsap
47.0091810000000061E5B5C01.555555555555.00
Router(config-map-list)# end
Router#
```

Verify

```
Router# ping 192.153.185.65
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echoes to 192.153.185.65, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/2/4 ms
```

Configuring PVCs

A PVC is a permanent logical connection that you must configure manually, from source to destination, through the ATM network. Once configured, the ATM network maintains the connection at all times, regardless of traffic flow. That is, the connection is always up whether there is traffic to send or not.

Figure3-2 shows an example PVC between ATM-capable router A and router D. This example network is used throughout this section to describe how to set up PVCs.

Figure3-2 Example Network for Configuring PVCs



When configuring a PVC, the virtual path identifiers/virtual channel identifiers (VPIs/VCI) must match between devices, as shown in Figure3-2 between:

- Source router A and ATM switch router B, which both use VPI=0, VCI=50
- ATM switch routers B and C, which both use VPI=2, VCI=100
- ATM switch router C and destination router D, which both use VPI=50, VCI=255

The VPI/VCI that create an internal crossconnect within a switch can differ, as shown in:

- ATM switch router B between interfaces 3/0/1 (VPI=0, VCI=50) and 3/0/2 (VPI=2, VCI=100)
- ATM switch router C between interfaces 0/1/1 (VPI=2, VCI=100) and 0/0/1 (VPI=50, VCI=255)

Configuring PVCs

Table3-2 describes the in and out interfaces and associated VPIs/VCI for the PVC shown in Figure 3-2.

Table3-2 VPI/VCIs for the Example PVC

	Router A	Switch B	Switch B	Switch C	Switch C	Router D
	Out	In	Out	In	Out	In
Interface	0.10	3/0/1	3/0/2	0/1/1	0/0/1	0.12
VPI/VCI	0/50	0/50	2/100	2/100	50/255	50/255

Configuring the ATM Switch Router

Take these steps:

Step	Command	Purpose
1	Switch> enable Switch#	Enter privileged EXEC mode.
2	Switch# configure terminal Switch(config)#	Enter global configuration mode.
3	Switch(config)# interface atm <i>card/subcard/port[.subinterface]</i> Switch(config-if)#	Select the interface to configure.
4	Switch(config-if)# atm pvc vpi vci interface atm <i>card/subcard/port[.vpt#] vpi vci</i>	Configure the PVC. When configuring PVCs, configure the lowest available VPI and VCI numbers first. Note VCIs 0 to 31 on all VPIs are reserved.
5	Switch(config-if)# end Switch#	Return to privileged EXEC mode.

Note If the PVC terminates on an ATM switch router, you must terminate the connection on the route processor interface ATM 0. The **atm pvc 0 any-vci** command allocates the next available VCI value on the route processor interface ATM 0, although you can specify the VCI value if you choose. An example follows:

```
Switch(config-if)# atm pvc 2 100 interface atm 0 0 any-vci
```

Example

The following example shows how to configure the internal crossconnect (within the switch) PVC on ATM switch router B between interface 3/0/1, VPI = 0, VCI = 50, and interface 3/0/2, VPI = 2, VCI = 100 (see Figure3-2):

```
Switch> enable
Switch# configure terminal
Switch(config)# interface atm 3/0/1
Switch(config-if)# atm pvc 0 50 interface atm 3/0/2 2 100
Switch(config-if)# end
Switch#
```

Verify

```
Switch# show atm vc interface atm 3/0/1
Interface      VPI   VCI   Type   X-Interface  X-VPI  X-VCI  Encap  Status
ATM3/0/1      0     5     PVC    ATM0         0      55     QSAAL  UP
ATM3/0/1      0    16     PVC    ATM0         0      39     ILMI   UP
ATM3/0/1      0    18     PVC    ATM0         0      74     PNNI   UP
ATM3/0/1      0    50     PVC    ATM3/0/2    2     100     UP
Switch#
```

Configuring the Router

If the PVC terminates on a router, you must configure a PVC from the router to the ATM switch router.

Take these steps:

Step	Command	Purpose
1	Router> enable Router#	Enter privileged EXEC mode.
2	Router# configure terminal Router(config)#	Enter global configuration mode.
3	Router(config)# interface atm <i>port[/slot][,subinterface]</i> Router(config-subif)#	Enter subinterface configuration mode on the main ATM interface.
4	Router(config-subif)# ip address <i>address mask</i>	Configure an IP address and subnet mask on the subinterface.
5	Router(config-subif)# atm pvc <i>vcd vpi vci aal-encap</i>	Create the PVC. Note VCIs 0 to 31 on all VPIs are reserved.
6	Router(config-subif)# map-group <i>name</i>	Assign a map group to this interface. This command references a map list that you create in the next step.
7	Router(config-subif)# exit Router(config)#	Return to global configuration mode.
8	Router(config)# map-list <i>name</i>	Create a map list. Match the name you enter here to the name in Step 6.
9	Router(config-map-list)# ip <i>dest-address atm-vc vcd</i> broadcast	Add the destination router IP address. The VCD ¹ number must match the VCD number you assigned in Step 5. This configuration allows the VC to receive routing updates.

Step	Command	Purpose
10	Router(config-map-list)# end Router#	Return to privileged EXEC mode.
11	(No command.)	Repeat this procedure on the other router.

1 VCD = virtual circuit descriptor.

Example

```
Router> enable
Router# configure terminal
Router(config)# interface atm 0.10 multipoint
Router(config-subif)# ip address 192.153.185.33 255.255.255.224 (source router)
Router(config-subif)# atm pvc 2 0 50 aal5snap
Router(config-subif)# map-group cal
Router(config-subif)# exit
Router(config)# map-list cal
Router(config-map-list)# ip 192.153.185.65 atm-vc 2 broadcast (destination router)
Router(config-map-list)# end
Router#
```

Verify

```
Router# ping 192.153.185.65
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echoes to 192.153.185.65, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/1/1 ms
```

Configuring Soft PVCs

Soft PVCs are a combination of SVCs and PVCs. SVCs are set up on the inside of the path among ATM switch routers, and PVCs are set up between an edge ATM switch router and the terminating device (such as a router).

Soft PVCs require less manual configuration than PVCs. With soft PVCs, you need to configure only the destination ATM switch router in the path and PVCs on the devices that terminate the softPVC (such as a router).

Configuring Soft PVCs

Figure3-3 illustrates how to set up soft PVCs. This example network is used throughout this section.

Figure3-3 Example Network for Configuring Soft PVCs



Configuring the ATM Switch Router

Perform the following tasks on the ATM switch router to set up a soft PVC:

- Determine the destination ATM switch router NSAP address
- Configure the source ATM switch router

The subsections that follow describe these procedures in detail.

Determining the Destination ATM Switch Router NSAP Address

Determine the destination ATM switch router NSAP address for the interface. See the ATM switch router C in Figure3-3.

Take these steps:

Step	Command	Purpose
1	Switch# show atm addresses	On the <i>destination</i> ATM switch router, display the destination ATM address. You need this address to complete the soft PVC. Write the address in the space provided below (or copy it to memory):
2	(No command.)	Proceed to the next section, "Configuring the Source ATM Switch Router" to complete the soft PVC.

Example

```
Switch# show atm address
```

```
Switch Address(es):
```

```
47.00918100000000E04FACB401.00E04FACB401.00 active
```

```
Soft VC Address(es):
```

```
47.0091.8100.0000.00e0.4fac.b401.4000.0c84.9030.00 ATM-P9/1/3
```

```
— 47.0091.8100.0000.0061.E5B5.C011.1111.1122.2222.00 ATM0/0/1
```

```
47.0091.8100.0000.00e0.4fac.b401.4000.0c85.0020.00 ATM0/1/0
```

```
47.0091.8100.0000.00e0.4fac.b401.4000.0c85.0030.00 ATM0/1/1
```

```
ILMI Switch Prefix(es):
```

```
47.0091.8100.0000.00e0.4fac.b401
```

```
ILMI Configured Interface Prefix(es):
```

```
LECS Address(es):
```

```
47.0091.8100.0000.00e0.4fac.b401.00e0.4fac.b405.00
```

```
Switch#
```

Configuring Soft PVCs

Verify

Not applicable.

Configuring the Source ATM Switch Router

Most of the configuration for the soft PVC occurs on the source switch. See the ATM switch router B in Figure3-3.

Take these steps:

Step	Command	Purpose
1	Switch# configure terminal Switch(config)#	Enter global configuration mode.
2	Switch(config)# interface atm <i>card/subcard/port</i> Switch(config-if)#	Enter interface configuration mode on the interface from which you want the soft PVC to originate (that is, the starting point).
3	Switch(config-if)# atm soft-vc <i>src-vpi src-vci dest-address</i> <i>dest_address dest-vpi dest-vci</i>	Enter the soft PVC VPI/VCIs for the interface on the source switch and the destination ATM address and destination VPI/VCIs.
4	Switch(config-if)# end Switch#	Return to privileged EXEC mode.
5	(No command.)	Proceed to the section “ <i>Configuring the Router</i> ” to complete the soft PVC.

Example

```
Switch# configure terminal
Switch(config)# interface atm 3/0/1
Switch(config-if)# atm soft-vc 0 50 dest-address
47.0091.8100.0000.0061.E5BC.0000.1111.1112.2222.00 1 60
Switch(config-if)# end
Switch#
```

Verify

The following example displays the soft VC configuration of switch B, on interface 3/0/1 out to the ATM network:

```
Switch# show atm vc interface atm 0/0/0
Interface      VPI   VCI   Type   X-Interface  X-VPI X-VCI  Encap  Status
ATM0/0/0       0     5     PVC    ATM0         0     52    QSAAL  DOWN
ATM0/0/0       0     16    PVC    ATM0         0     32    ILMI   DOWN
ATM3/0/1       0     50    SoftVC ATM0/0/1     1     60                UP
Switch#
```

Configuring the Router

If the soft PVC terminates on a router, you must configure a PVC from the router to the ATM switch router.

Take these steps:

Step	Command	Purpose
1	Router> enable Router#	Enter privileged EXEC mode.
2	Router# configure terminal Router(config)#	Enter global configuration mode.
3	Router(config)# interface atm <i>port[/slot][.subinterface]</i> Router(config-subif)#	Enter subinterface configuration mode on the ATM interface.
4	Router(config-subif)# ip address <i>address mask</i>	Configure an IP address and subnet mask on the subinterface.
5	Router(config-subif)# atm pvc <i>vcd vpi vci aal-enacap</i>	Create the PVC. Note VCIs 0 to 31 on all VPIs are reserved.
6	Router(config-subif)# map-group <i>name</i>	Assign a map group to this interface. This command references a map list that you create in the next step.
7	Router(config-subif)# exit Router(config)#	Return to global configuration mode.

Configuring Soft PVCs

Step	Command	Purpose
8	Router(config-subif)# map-list <i>name</i>	Create a map list. The name you enter here should match the name you specified in Step 6.
9	Router(config-map-list)# ip <i>dest-address atm-vc vcd</i> broadcast	Add the destination router IP address. The VCD number must match the VCD number you assigned in Step 5.
10	Router(config-map-list)# end Router#	Return to privileged EXEC mode.
11	(No command.)	Repeat this procedure on the other router.

Example

```
Router> enable
Router# configure terminal
Router(config)# interface atm 0.10
Router(config-subif)# ip address 192.153.185.33 255.255.255.224 (source router)
Router(config-subif)# atm pvc 2 0 50 aal5snap
Router(config-subif)# map-group cal
Router(config-subif)# exit
Router(config)# map-list cal
Router(config-map-list)# ip 192.153.185.65 atm-vc 2 broadcast (destination router)
Router(config-map-list)# end
Router#
```

Verify

```
Router# ping 192.153.185.65
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echoes to 192.153.185.65, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/1/1 ms
```

Configuring PVPs

A VP connection is like a bundle of VCs, transporting all cells with a common VPI, rather than a specific VPI and VCI. A PVP is a provisioned VP (like a PVC).

Figure3-4 illustrates how to set up PVPs. This example network is used throughout this section.

Figure3-4 Example Network for Configuring PVPs



Table3-3 describes the in and out interfaces and associated VPIs for the PVP shown in Figure3-4. Between ATM switch routers, the VPIs for the out port and the in port must match. For example, in Figure3-4, the VPIs match between ATM switch routers A and B (VPI=3).

Note The VPIs for the internal crossconnects do not have to match. For example, in Figure3-4, the VPIs do not match in ATM switch router A for the internal crossconnect between ports 3/0/1 (VPI=2) and 3/0/2 (VPI=3).

Table3-3 VPIs for the Example PVP

	Switch A	Switch B	Switch B	Switch C	Switch C	Switch D
	Out	In	Out	In	Out	In
Interface	3/0/2	0/0/0	1/1/1	3/1/1	1/0/0	0/1/1
VPI	3	3	5	5	8	8

Configuring PVPs

Take these steps:

Step	Command	Purpose
1	Switch> enable Switch#	Enter privileged EXEC mode.
2	Switch# configure terminal Switch(config)#	Enter global configuration mode.
3	Switch(config)# interface atm <i>card/subcard/port</i> Router(config-if)#	Enter interface configuration mode on the ATM interface.
4	Switch(config-subif)# atm pvp <i>vpi-A</i> interface <i>card/subcard/port vpi-B</i>	Configure the PVP. Note When configuring PVP connections, use the lowest available VPI numbers first.
5	Switch(config-subif)# end Switch#	Return to privileged EXEC mode.

Example

The following example shows how to configure the internal cross connect (within the switch) PVP on ATM switch router B between interface 3/0/1, VPI = 2 and interface 3/0/2, VPI = 3:

```
Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)# interface atm 3/0/1
Switch(config-if)# atm pvp 2 interface atm 3/0/2 3
Switch(config-if)# end
Switch#
```

Verify

```
Switch# show atm vp
Interface   VPI   Type  X-Interface  X-VPI  Status
ATM3/0/1   2     PVP   ATM3/0/2     3      UP
ATM3/0/2   3     PVP   ATM3/0/1     2      UP
Switch#
```

Configuring VP Tunnels

A VP tunnel is a method of linking two private ATM networks across a public network that does not support SVCs. The VP tunnel provides a permanent path through the public network. The public network transparently trunks the entire collection of virtual channels in the virtual path between the two private networks. Signaling traffic is mapped into the PVP and the switches allocate a virtual channel connection (VCC) on that VP, instead of the default VP 0. This mapping allows the signaling traffic to pass transparently through the public network.

Figure3-5 illustrates how to set up VP tunnels. This example network is used throughout this section.

Figure3-5 Example Network for Configuring VP Tunnels



Table3-4 describes the interfaces and associated VPIs and VPTs for the VP tunnel shown in Figure3-5. Between the source and destination ATM switch routers, the VPIs and VPTs must match. For example, in Figure 3-5, the VPIs and VPTs (99) match between ATM switch routers A and B.

Table3-4 VPIs and VPTs for the Example VP Tunnel

	Switch A	Switch B
Interface	3/0/2.99	0/0/0.99
VPI	99	99
VPT	99	99

Configuring VP Tunnels

Take these steps:

Step	Command	Purpose
1	Switch> enable Switch#	Enter privileged EXEC mode.
2	Switch# configure terminal Switch(config)#	Enter global configuration mode.
3	Switch(config)# interface atm <i>card/subcard/port</i> Switch(config-if)#	Enter interface configuration mode on the ATM interface.
4	Switch(config-if)# atm pvp vpi	Configure a PVP leg.
5	Switch(config-if)# interface <i>card/subcard/port.vpt#</i> Switch(config-subif)#	Create a VP tunnel using a VPT number that matches the PVP leg VPI you configured in Step 4.
6	Switch(config-subif)# end Switch#	Return to privileged EXEC mode.
7	(No command.)	Repeat this procedure on the other ATM switch router.

Example

The following example shows how to configure the VP tunnel on VPI=99.

```
Switch# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Switch(config)# interface atm 3/0/2
Switch(config-if)# atm pvp 99
Switch(config-if)# interface atm 3/0/2.99
Switch(config-subif)# end
Switch#
```

Verify

When the VP tunnel is configured on both ends and the connection is up, the AutoCfgState displays “completed.”

```
Switch# show atm interface atm 3/0/2.99

Interface:      ATM3/0/2.99      Port-type:      vp tunnel
IF Status:     UP              Admin Status:   up
Auto-config:   enabled          AutoCfgState:   completed
IF-Side:       Network        IF-type:        NNI
Uni-type:      not applicable  Uni-version:    not applicable
<Information omitted.>
Switch#

Switch# show atm vp
Interface      VPI  Type  X-Interface      X-VPI  Status
ATM3/0/2      99   PVP   TUNNEL
Switch#
```

Configuring VP Tunnels

Configuring LANE

This chapter describes how to configure LAN Emulation (LANE) on the ATM switch router, and includes the following sections:

- Understanding LANE on ATM
- Understanding LANE Components
- Implementing LANE
- Configuring a LEC
- Configuring the LECS
- Configuring the LES/BUS
- LANE Configuration Examples

Note For more software configuration information about LANE, refer to the *ATMSwitch Router Software Configuration Guide*. Refer to the *ATMSwitch Router Command Reference* publication for command syntax.

Understanding LANE on ATM

LANE is a protocol that allows devices attached to traditional LANs (such as Ethernet and Token Ring) to connect to ATM networks. That is, LANE allows legacy LAN users to take advantage of the benefits of ATM without modifying end station hardware or software.

LANE services provide connectivity between ATM-attached devices and LAN-attached devices. Two primary applications of LANE follow:

- Connectivity between LAN-attached stations across a high-speed ATM transport backbone.
- Connectivity between ATM-attached hosts and LAN-attached hosts. Centralized hosts with high-speed ATM port adapters provide services (such as Domain Name Service [DNS]) to traditional LAN-attached devices.

Understanding LANE Components

A single emulated LAN (ELAN) includes the following components:

- LANE client (LEC)—A software client that resides in an end station (such as a workstation, LAN switch, or router). The LEC performs data forwarding and receiving, address resolution, and other control functions for a single endpoint in a single ELAN. A router or switch can have multiple LANE clients, each connecting with different ELANs. The LANE client registers its MAC and ATM address with the LES.
- LANE configuration server (LECS)—A server that assigns individual LECs to particular ELANs by providing to the LECs the ATM address of the LES. The LECS maintains a database of ELAN names and the corresponding addresses of the LESs. A LECS can serve multiple ELANs. One LECS must be configured for each LANE cloud.

Note The LECS is also used for security by restricting ELAN membership to certain LECs, based on their MAC addresses.

- LANE server (LES)—A server that registers LECs to join the ELAN. In LANE 1.0, without Simple Server Redundancy Protocol (SSRP), each ELAN has only one Cisco LES, which handles LAN Emulation Address Resolution Protocol (LE_ARP) requests.
- Broadcast-and-unknown server (BUS)—A server that floods unknown destination addresses and forwards multicast and broadcast traffic to clients within an ELAN. In LANE 1.0 without SSRP, one Cisco BUS exists per ELAN.

Implementing LANE

The following sections describe specific information and considerations you might need to consider prior to LANE implementation:

- Supporting LAN Protocols
- Addressing
- Assigning Components to Interfaces and Subinterfaces

Supporting LAN Protocols

The ATM switch router supports both Ethernet and Token Ring LANE. This chapter describes only Ethernet configuration information. For Token Ring configuration information, refer to the *ATMSwitch Router Software Configuration Guide*.

Addressing

On a LAN, packets are addressed by the MAC-layer address of the destination and source stations. To provide similar functionality for LANE, every LANE client must have a MAC address. In addition, every LANE component (LES, LEC, BUS, and LECS) must have a unique ATM address.

All LANE clients on the same interface have the same automatically assigned MAC address, which is also used as the end-system identifier (ESI) part of the ATM address. Although client MAC addresses are not unique, all ATM addresses are unique.

Assigning Components to Interfaces and Subinterfaces

The following rules apply to assigning LANE components to the major ATM interface and its subinterfaces:

- The LECS always runs on the major ATM interface.

If you assign any other component to the major interface, it is identical to assigning that component to the 0 subinterface.

- Configure the LES/BUS and the LEC of the *same* ELAN on the same subinterface.
 - You cannot configure LECs of two *different* ELANs on the same subinterface.
 - You cannot configure LESs/BUSs of two *different* ELANs on the same subinterface.

Note On the ATM switch router, you can configure LAN components only on the processor card (CPU) interface or on one of its subinterfaces.

Configuring LANE Router and LAN Switch Requirements

You must manually configure QSAAL and ILMI signaling PVCs on routers and edge LAN switches to run LANE.

Note These PVCs are configured automatically on the ATM switch router.

At least one ATM switch router is required to run LANE. For example, you cannot run LANE on routers connected back-to-back.

Configuring a LEC

This section describes how to configure a LANE client connection from a remote ATM switch router to the processor card (CPU) of a local switch. This connection allows you to configure the ATM switch router remotely.

Note This connection is for switch management only.

Take these steps:

Step	Command	Purpose
1	Switch> enable Switch#	Enter privileged EXEC mode.
2	Switch# configure terminal Switch(config)#	Enter global configuration mode.
3	Switch(config)# interface atm 0[.subinterface] Switch(config-if)#	Select the processor card (CPU) subinterface. Note We recommend that you configure LECs on subinterfaces (atm 0.1), not main interfaces (atm 0).
4	Switch(config-if)# lane client-atm-address <i>atm-address-template</i>	Specify an ATM address (and override the automatic ATM address assigned to the LANE client).
5	Switch(config-if)# lane client ethernet <i>elan-name</i>	Configure a LANE client on the specified subinterface.
6	Switch(config-if)# end Switch#	Return to privileged EXEC mode.

For examples of these commands, see the section “LANE Configuration Examples” at the end of this chapter.

Configuring the LECS

This section describes how to configure the LECS, and includes the following procedures:

- Configuring the ATM Address of the LECS
- Configuring the LECS Database

You must configure the ATM address of the LECS on the ATM switch router.

Configuring the ATM Address of the LECS

The ATM switch router comes with a default unique prefix. To see the default prefix, enter the **show lane default atm address** command. You can use the default prefix or assign a new one. If you want to use the default prefix, skip this section and proceed to the next section.

This section describes how to change the default prefix and configure a new one. All attached LANE entities use the prefix to create their own ATM network service access point (NSAP) addresses.

Take these steps:

Step	Command	Purpose
1	Switch> enable Switch#	Enter privileged EXEC mode.
2	Switch# configure terminal Switch(config)#	Enter global configuration mode.
3	Switch(config)# interface atm 0	Select the ATM interface on the processor card (CPU).
4	Switch(config)# atm lecs-address <i>lecsaddress</i>	Configure the LECS address on the ATM switch router.
5	Switch(config)# atm lecs-address-default <i>address</i> <i>[sequence#]</i>	Configure a redundant LECS address and sequence number for the entire switch. The sequence number specifies the order of the address in the LECS address table. If you do not specify a sequence number, the addresses are used in the order entered.

Step	Command	Purpose
6	Switch(config)# atm address <i>address</i>	Configure a new ATM address.
7	Switch(config)# no atm address <i>address</i>	Disable the old default ATM address. Note Enter the show atm addresses command to display the default ATM addresses.

For examples of these commands, see the section “LANE Configuration Examples” at the end of this chapter.

Configuring the LECS Database

Take these steps:

Step	Command	Purpose
1	Switch> enable Switch#	Enter privileged EXEC mode.
2	Switch# configure terminal Switch(config)#	Enter global configuration mode.
3	Switch(config)# lane database <i>database-name</i>	Create a named database for the LECS.
4	Switch(lane-config-database)# name <i>elan-name</i> server-atm-address <i>atm-address</i>	In the configuration database, bind the name of the ELAN to the ATM address of the LES. Note Enter the show lane default-atm-address for the ATM address of the server for the ELAN.
5	Switch(config)# name <i>elan-name</i> server-atm-address <i>address</i> index <i>n</i>	Specify redundant LES/BUSs, or simple server replication. Enter the command for each LES address for the same ELAN. The index determines the priority. Zero (0) is the highest priority.

Configuring the LES/BUS

Step	Command	Purpose
6	Switch(lane-config-database)# default-name <i>elan-name</i>	In the configuration database, assign an ELAN to the LECs to join without specifying an ELAN name.
7	Switch(lane-config-database)# end Switch#	Return to privileged EXEC mode.

For examples of these commands, see the section “LANE Configuration Examples” at the end of this chapter.

Configuring the LES/BUS

In Cisco’s implementation of LANE, the LES and BUS are treated as one LANE component. You configure the LES and BUS together as one component (the LES/BUS), instead of two separate LANE components.

Take these steps:


Step	Command	Purpose
1	Switch> enable Switch#	Enter privileged EXEC mode.
2	Switch# configure terminal Switch(config)#	Enter global configuration mode.
3	Switch(config)# interface ethernet 0[.subinterface] Switch(config-if)#	Specify the subinterface for the first ELAN.
4	Switch(config-if)# lane server-bus ethernet <i>elan-name1</i>	Enable a LES/BUS for the first ELAN.
5	Switch(config-if)# ip address <i>address mask</i>	Assign an IP address to the subinterface.
6	Switch(config-if)# end Switch#	Return to privileged EXEC mode.

LANE Configuration Examples

The following examples show how to configure one Cisco 7505 router, one ATM switch router, and one Catalyst 5500 switch for a single ELAN.

The ATM switch router contains the LECS, LES, BUS, and a LEC. The remaining router and Catalyst5500 switch each contain an LEC for the ELAN. This example uses all LANE default settings. For example, it does not explicitly set ATM addresses for the different LANE components that are collocated on the ATM switch router. Membership in this LAN is not restricted (see Figure4-1).

Figure4-1 **Single ELAN Example Network**



LANE Configuration Examples

ATM Switch Router

```
ATM_Switch# show lane default-atm-addresses
interface ATM0:
LANE Client:          47.00918100000000E04FACB401.00E04FACB402.**
LANE Server:         47.00918100000000E04FACB401.00E04FACB403.**
LANE Bus:            47.00918100000000E04FACB401.00E04FACB404.**
LANE Config Server: 47.00918100000000E04FACB401.00E04FACB405.00
note: ** is the subinterface number byte in hex

ATM_Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ATM_Switch(config)# atm lecs-address-default
47.00918100000000E04FACB401.00E04FACB405.00
ATM_Switch(config)# end
ATM_Switch#
ATM_Switch# copy system:running-config nvram:startup-config
Building configuration...
[OK]
ATM_Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ATM_Switch(config)# lane database eng_dbase
ATM_Switch(lane-config-database)# name eng_elan server-atm-address
47.00918100000000E04FACB401.00E04FACB403.01
ATM_Switch(lane-config-database)# default-name eng_elan
ATM_Switch(lane-config-database)# end
ATM_Switch# show lane database

LANE Config Server database table 'eng_dbase'
default elan: eng_elan
elan 'eng_elan': un-restricted
  server 47.00918100000000E04FACB401.00E04FACB403.01 (prio 0)

ATM_Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ATM_Switch(config)# interface atm 0
ATM_Switch(config-if)# lane config database eng_dbase
ATM_Switch(config-if)# lane config auto-config-atm-address
ATM_Switch(config-if)# exit
ATM_Switch(config)# end
```

LANE Configuration Examples

```
ATM_Switch# show lane config
LE Config Server ATM0 config table: eng_dbase
Admin: up State: operational
LECS Mastership State: active master
list of global LECS addresses (42 seconds to update):
47.00918100000000E04FACB401.00E04FACB405.00
ATM Address of this LECS: 47.00918100000000E04FACB401.00E04FACB405.00
(auto)
cumulative total number of unrecognized packets received so far: 0
cumulative total number of config requests received so far: 0
cumulative total number of config failures so far: 0

ATM_Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ATM_Switch(config)# interface atm 0.1
ATM_Switch(config-subif)# lane server-bus ethernet eng_elan
ATM_Switch(config-subif)# ip address 172.16.0.4 255.255.0.0
ATM_Switch(config-subif)# end
ATM_Switch# show lane
LE Config Server ATM0 config table: eng_dbase
Admin: up State: operational
LECS Mastership State: active master
list of global LECS addresses (46 seconds to update):
47.00918100000000E04FACB401.00E04FACB405.00
ATM Address of this LECS: 47.00918100000000E04FACB401.00E04FACB405.00
(auto)
vcd rxCnt txCnt callingParty
  82      0      0 47.00918100000000E04FACB401.00E04FACB403.01 LES
eng_elan 0 active
cumulative total number of unrecognized packets received so far: 0
cumulative total number of config requests received so far: 0
cumulative total number of config failures so far: 0

LE Server ATM0.1 ELAN name: eng_elan Admin: up State: operational
type: ethernet Max Frame Size: 1516
ATM address: 47.00918100000000E04FACB401.00E04FACB403.01
LECS used: 47.00918100000000E04FACB401.00E04FACB405.00 connected, vcd 81

LE BUS ATM0.1 ELAN name: eng_elan Admin: up State: operational
type: ethernet Max Frame Size: 1516
ATM address: 47.00918100000000E04FACB401.00E04FACB404.01
```

LANE Configuration Examples

```
ATM_Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ATM_Switch(config)# interface atm 0.1
ATM_Switch(config-subif)# lane client ethernet eng_elan
ATM_Switch(config-subif)# end
ATM_Switch# show lane client
LE Client ATM0.1 ELAN name: eng_elan Admin: up State: operational
Client ID: 1 LEC up for 30 seconds
ELAN ID: 0
Join Attempt: 1
HW Address: 00e0.4fac.b402 Type: ethernetMax Frame Size: 1516
ATM Address: 47.00918100000000E04FACB401.00E04FACB402.01

VCD rxFrames txFrames Type ATM Address
0 0 0 configure
47.00918100000000E04FACB401.00E04FACB405.00
87 1 2 direct
47.00918100000000E04FACB401.00E04FACB403.01
90 1 0 distribute
47.00918100000000E04FACB401.00E04FACB403.01
91 0 1 send
47.00918100000000E04FACB401.00E04FACB404.01
94 0 0 forward
47.00918100000000E04FACB401.00E04FACB404.01

ATM_Switch# copy system:running-config nvram:startup-config
Building configuration...
[OK]
ATM_Switch#
```

Router 1

```
router1# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
router1(config)# interface atm 3/0
router1(config-if)# atm pvc 1 0 5 qsaal
router1(config-if)# atm pvc 2 0 16 ilmi
router1(config-if)# interface atm 3/0.1
router1(config-subif)# ip address 172.16.0.1 255.255.0.0
router1(config-subif)# lane client ethernet eng_elan
router1(config-subif)# end
router1# more system:running-config
Building configuration...
```

```
Current configuration:
!
version 12.0

<Information deleted>

!
interface ATM3/0
 no ip address
 atm pvc 1 0 5 qsaal
 atm pvc 2 0 16 ilmi
!
interface ATM3/0.1 multipoint
 lane client ethernet eng_elan
!

<Information deleted>

!
end

router1# show inter atm 3/0.1
ATM3/0.1 is up, line protocol is up
  Hardware is cxBus ATM
  MTU 1500 bytes, BW 156250 Kbit, DLY 80 usec, rely 255/255, load 1/255
  Encapsulation ATM-LANE
  ARP type: ARPA, ARP Timeout 04:00:00
router1#
```

Catalyst 5500 Switch 1

```
Switch1> session 4
Trying ATM-4...
Connected to ATM-4.
Escape character is '^]'.
ATM> enable
ATM# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
ATM(config)# interface atm 0
ATM(config-if)# lane server-bus ethernet eng_elan
ATM(config-if)# end
ATM# copy system:running-config nvram:startup-config
Building configuration...
[OK]
```

LANE Configuration Examples

```
ATM# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
ATM(config)# interface atm 0
ATM(config-if)# atm pvc 1 0 5 qsaal
ATM(config-if)# atm pvc 2 0 16 ilmi
ATM(config-if)# end
ATM#
ATM# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
ATM(config)# interface atm 0.1
ATM(config-subif)# lane client ethernet 1 eng_elan
ATM(config-subif)# end
ATM# show lane client
LE Client ATM0.1  ELAN name: eng_elan  Admin: up  State: operational
Client ID: 3          LEC up for 24 seconds
Join Attempt: 11
HW Address: 00e0.4fac.b030  Type: ethernetMax Frame Size: 1516
VLANID: 1
ATM Address: 47.00918100000000E04FACB401.00E04FACB030.01

VCD  rxFrames  txFrames  Type      ATM Address
  0          0          0  configure
47.00918100000000E04FACB401.00E04FACB405.00
  27         1          14  direct
47.00918100000000E04FACB401.00E04FACB403.01
  29         13          0  distribute
47.00918100000000E04FACB401.00E04FACB403.01
  30         0          15  send
47.00918100000000E04FACB401.00E04FACB404.01
  31         0          0  forward
47.00918100000000E04FACB401.00E04FACB404.01

ATM# copy system:running-config nvram:startup-config
Building configuration...
[OK]
ATM#
```

Verifying Connectivity

The following example shows how to use the **show lane** and **ping** commands to confirm the connection between the ATM switch router, routers, and LAN switches:

ATM Switch Router

```
Switch# show lane
LE Config Server ATM0 config table: eng_dbase
Admin: up State: operational
LECS Mastership State: active master
list of global LECS addresses (31 seconds to update):
47.00918100000000E04FACB401.00E04FACB405.00 <----- me
ATM Address of this LECS: 47.00918100000000E04FACB401.00E04FACB405.00
(auto)
vcd rxCnt txCnt callingParty
  82   2   2 47.00918100000000E04FACB401.00E04FACB403.01 LES
eng_elan 0 active
cumulative total number of unrecognized packets received so far: 0
cumulative total number of config requests received so far: 4
cumulative total number of config failures so far: 0

LE Server ATM0.1 ELAN name: eng_elan Admin: up State: operational
type: ethernet Max Frame Size: 1516
ATM address: 47.00918100000000E04FACB401.00E04FACB403.01
LECS used: 47.00918100000000E04FACB401.00E04FACB405.00 connected, vcd 81
control distribute: vcd 89, 2 members, 2 packets

proxy/ (ST: Init, Conn, Waiting, Adding, Joined, Operational, Reject,
Term)
lecid ST vcd pkts Hardware Addr ATM Address
  1 O 88 2 00e0.4fac.b402
47.00918100000000E04FACB401.00E04FACB402.01
  2 O 96 2 0080.1c93.8060
47.00918100000000E04FACB401.00801C938060.01

LE BUS ATM0.1 ELAN name: eng_elan Admin: up State: operational
type: ethernet Max Frame Size: 1516
ATM address: 47.00918100000000E04FACB401.00E04FACB404.01
data forward: vcd 93, 2 members, 95 packets, 0 unicasts

lecid vcd pkts ATM Address
  1 92 95 47.00918100000000E04FACB401.00E04FACB402.01
  2 97 42 47.00918100000000E04FACB401.00801C938060.01
```

LANE Configuration Examples

```
LE Client ATM0.1 ELAN name: eng_elan Admin: up State: operational
Client ID: 1 LEC up for 1 hour 34 minutes 46 seconds
ELAN ID: 0
Join Attempt: 1
HW Address: 00e0.4fac.b402 Type: ethernetMax Frame Size: 1516
ATM Address: 47.00918100000000E04FACB401.00E04FACB402.01
```

```
VCD rxFrames txFrames Type ATM Address
0 0 0 configure
47.00918100000000E04FACB401.00E04FACB405.00
87 1 2 direct
47.00918100000000E04FACB401.00E04FACB403.01
90 2 0 distribute
47.00918100000000E04FACB401.00E04FACB403.01
91 0 95 send
47.00918100000000E04FACB401.00E04FACB404.01
94 42 0 forward
47.00918100000000E04FACB401.00E04FACB404.01
```

```
ATM_Switch# ping 172.16.0.1
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 172.16.0.1, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/202/1000
ms
ATM_Switch# ping 172.16.0.3
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 172.16.0.2, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/202/1000
ms
ATM_Switch#
```

Confirming Connectivity between the ATM Switch Router and the Routers

The following example shows how to use the **ping** command to confirm the connection between the ATM switch router and routers:

```
ATM_Switch# ping 172.16.0.1

Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 172.16.0.1, timeout is 2 seconds:
!!!!
```

```

Success rate is 100 percent (5/5), round-trip min/avg/max = 1/202/1000
ms
ATM_Switch# ping 172.16.0.3

Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 172.16.0.3, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/202/1000
ms

```

Displaying the LANE Client Configuration on the ATM Switch Router

The following example shows the **show lane client** command display for the Ethernet LANE client in the ATM switch router:

```

ATM_Switch# show lane client
LE Client ATM0.1 ELAN name: eng Admin: up State: operational
Client ID: 3 LEC up for 4 minutes 58 seconds
Join Attempt: 1
HW Address: 0060.3e7b.2002 Type: ethernet Max Frame Size:
1516
ATM Address: 47.00918100000000603E7B2001.00603E7B2002.01

VCD rxFrames txFrames Type ATM Address
0 0 0 configure
47.00918100000000603E7B2001.00000C407575.00
52 1 4 direct
47.00918100000000603E7B2001.00000C407573.01
53 9 0 distribute
47.00918100000000603E7B2001.00000C407573.01
54 0 13 send
47.00918100000000603E7B2001.00000C407574.01
55 19 0 forward
47.00918100000000603E7B2001.00000C407574.01
56 11 10 data
47.00918100000000603E7B2001.00000C407572.01
57 6 5 data
47.00918100000000603E7B2001.00000C407C02.02

Switch#

```

LANE Configuration Examples

Configuring Tag Switching

This chapter describes how to configure tag switching, and includes the following sections:

- Software Restrictions
- Configuring Tag Switching on an ATM Switch Router
- Configuring Tag Switching on a Router
- Tag Switching Configuration Example

Note For more software configuration information about tag switching, refer to the *ATM Switch Router Software Configuration Guide*. Refer to the *ATMSwitch Router Command Reference* publication for command syntax.

Software Restrictions

The software restrictions for tag switching follow:

- Open Shortest Path First (OSPF) is the only routing protocol currently supported
- IP is the only network layer protocol currently supported.

Configuring Tag Switching on an ATM Switch Router

This section describes how to configure tag switching on an ATM switch router, and includes the following procedures:

- Enabling Tag Switching on the ATM Interface
- Configuring the Routing Protocol

Enabling Tag Switching on the ATM Interface

Note Configure all parallel interfaces between switches for either IP unnumbered or with a specific IP address. Unnumbering some parallel interfaces and assigning specific IP addresses to others might cause Tag Distribution Protocol (TDP) sessions to restart on some parallel interfaces when another parallel interface is shut down. Therefore, we highly recommend that you unnumber all parallel interfaces to loopback.

Take these steps:

Step	Command	Purpose
1	Switch(config)# interface atm <i>card/subcard/port</i> Switch(config-if)#	Enter interface configuration mode on the specified ATM interface.
2	Switch(config-if)# ip unnumbered <i>type number</i>	Enable IP unnumbered on the ATM interface and assign the unnumbered interface to an interface that has an IP address. We recommend enabling IP unnumbered because it allows you to conserve IP addresses and reduces the number of TVCs ¹ terminating on the switch.
	or	or
	Switch(config-if)# ip address <i>ip-address mask</i>	Assign an IP address and subnet mask to the ATM interface.

Enabling Tag Switching on the ATM Interface

Step	Command	Purpose
3	Switch(config-if)# tag-switching ip	Enable tag switching of IP packets on the interface.
4	Switch(config-if)# exit Switch(config)#	Return to global configuration mode.

1 TVCs = tag virtual channels.

Examples

```
Switch(config-if)# interface atm 1/0/1
Switch(config-if)# ip unnumbered loopback 0
Switch(config-if)# tag-switching ip
Switch(config-if)# exit
Switch(config)#
```

```
Switch(config)# interface atm 0/0/3
Switch(config-if)# ip address 1.3.11.3 255.255.0.0
Switch(config-if)# tag-switching ip
Switch(config-if)# exit
Switch(config)#
```

Verify

```
Switch# show tag-switching interfaces
Interface          IP      Tunnel  Operational
ATM0/0/3           Yes    No      No          (ATM tagging)
ATM1/0/1           Yes    No      No          (ATM tagging)
Switch#
```

Configuring the Routing Protocol

Enable the routing protocol (OSPF) on the ATM switch router so that it can create routing tables, which identify routes through the network. Then add the addresses and associated routing areas to the routing process so that it can propagate the addresses to other ATM switches and routers.

Take these steps:

Step	Command	Purpose
1	Switch(config)# router ospf <i>process_number</i>	Enable the routing protocol and assign it a process number. The process number is any positive integer.
2	Switch(config-router)# network <i>address wildcard-mask area</i> <i>area-id</i>	Define the network prefix, a wildcard subnet mask, and the associated area number on which to run the routing protocol. An area number is an identification number for an address range. Repeat this command for each additional area you want to add to the routing process. Caution Ethernet interface 0 on the processor card (CPU card) is used for system management only (for example, downloading system images or configuration files from a TFTP ¹ server). Do not add this interface to the routing process.
3	Switch(config-router)# exit Switch(config)#	Return to global configuration mode.

1 TFTP = Trivial File Transfer Protocol

Example

Note An IP address of 1.1.1.1 with a subnet mask of 255.255.255.0 is entered as an IP network prefix of 1.1.1.0 with a subnet mask of 0.0.0.255. Likewise, an IP address of 1.2.1.1 with a subnet mask of 255.255.255.0 is entered as an IP network prefix of 1.2.1.0 with a subnet mask of 0.0.0.255.

```
Switch(config)# router ospf 10000
Switch(config-router)# network 1.1.1.0 0.0.0.255 area 0
Switch(config-router)# network 1.2.1.0 0.0.0.255 area 0
Switch(config-router)# network 1.3.0.0 0.0.255.255 area 0
Switch(config-router)# network 200.2.2.0 0.0.0.255 area 0
Switch(config-router)# network 1.0.1.0 0.0.0.255 area 0
Switch(config-router)# network 1.18.0.0 0.0.255.255 area 0
Switch(config-router)# exit
Switch(config)#
```

Verify

```
Switch# show ip ospf
Routing Process "ospf 10000" with ID 1.0.1.11
Supports only single TOS(TOS0) routes
SPF schedule delay 5 secs, Hold time between two SPFs 10 secs
Number of DCbitless external LSA 0
Number of DoNotAge external LSA 0
Number of areas in this router is 1. 1 normal 0 stub 0 nssa
Area BACKBONE(0) (Inactive)
  Number of interfaces in this area is 4
  Area has no authentication
  SPF algorithm executed 2 times
  Area ranges are
  Link State Update Interval is 00:30:00 and due in 00:14:42
  Link State Age Interval is 00:20:00 and due in 00:14:10
  Number of DCbitless LSA 0
  Number of indication LSA 0
  Number of DoNotAge LSA 0

Switch#
```

Configuring Tag Switching on a Router

This section describes how to configure tag switching between a router and an ATM switch router.

Take these steps:

Step	Command	Purpose
1	Router# configure terminal Router(config)#	Enter global configuration mode.
2	Router(config)# interface type <i>port[/slot][.subinterface]</i> Router(config-subif)#	Select the subinterface to configure.
3	Router(config-subif)# ip address <i>address subnet</i>	Enter the IP address and subnet mask for the interface.
4	Router(config-subif)# tag-switching ip	Enable tag switching of IP packets on an interface.
5	Router(config-subif)# no shutdown	Enable the interface.
6	Router(config-subif)# exit Router(config)#	Return to global configuration mode.
7	Router(config)# interface type <i>port[/slot]</i> Router(config-if)#	Enter interface configuration on the main interface you selected in Step 2.
8	Router(config-if)# no shutdown	Enable the interface.

Example

```
Router# configure terminal
Router(config)# interface atm 2/0.1
Router(config-subif)# ip address 189.26.11.15 255.255.0.0
Router(config-subif)# tag-switching ip
Router(config-subif)# no shutdown
Router(config-subif)# exit
Router(config)# interface atm 2.0
Router(config-if)# no shutdown
```

Verify

```
Router# show tag-switching interface
Interface          IP      Tunnel  Operational
ATM2/0.1           Yes     No      Yes          (ATM tagging)
```

Tag Switching Configuration Example

Figure5-1 shows an example tag switching network.

Figure5-1 Example Network for Tag Switching



Router 5-1 Configuration

The configuration of router R5-1, interface e0/1, follows:

```
router_R5-1# configure terminal
router_R5-2(config)# ip cef switch
router_R5-1(config)# tag-switching advertise-tags
router_R5-1(config)# interface e0/1
router_R5-1(config-if)# tag-switching ip
router_R5-1(config-if)# exit
router_R5-1#(config)#
```

Tag Switching Configuration Example

Router 5-2 Configuration

The configuration between router R5-1, interface e0/1, and R5-2, interface e0/1, follows:

```
router_R5-2# configure terminal
router_R5-2(config)# ip cef switch
router_R5-2(config)# tag-switching advertise-tags
router_R5-2(config)# interface e0/1
router_R5-2(config-if)# tag-switching ip
router_R5-2(config-if)# exit
router_R5-2#(config)#
```

The configuration between router R5-2, interface e0/2, and R5-3, interface e0/2, follows:

```
route_R5-2(config)# interface e0/2
route_R5-2(config-if)# tag-switching ip
route_R5-2(config-if)# exit
```

The configuration of router R5-2, interface a2/0.1, follows:

```
router_R5-2(config-if)# interface a2/0.1
router_R5-2(config-subif)# ip address 189.26.11.15 255.255.0.0
router_R5-2(config-subif)# tag-switching ip
router_R5-2(config-subif)# no shutdown
router_R5-2(config-subif)# exit
router_R5-2(config)# interface a2/0
router_R5-2(config)# no shutdown
```

Router 5-3 Configuration

The configuration of router R5-3, interface e0/2, follows:

```
router_R5-3# configure terminal
router_R5-3(config)# ip cef switch
router_R5-3(config)# tag-switching advertise-tags
router_R5-3(config)# interface e0/2
router_R5-3(config-if)# tag-switching ip
router_R5-3(config-if)# exit
```

The configuration of router R5-3, interface e0/5 follows:

```
router_R5-3(config)# interface e0/5
router_R5-3(config-if)# tag-switching ip
router_R5-3(config-if)# exit
```

The configuration of router R5-3, interface a2/0.1, follows:

```
router_R5-3# configure terminal
router_R5-3(config)# interface a2/0.1
router_R5-3(config-if)# ip address 189.25.12.13 255.255.0.0
router_R5-3(config-if)# tag-switching ip
router_R5-3(config-if)# no shutdown
router_R5-3(config-if)# exit
router_R5-3(config-if)# interface a2/0
router_R5-3(config)# no shutdown
```

ATM Switch Router A5-4 Configuration

The configuration of ATM switch router A5-4, interfaces a0/1/1 and 0/0/3, follows:

```
atm_A5-4# configure terminal
atm_A5-4(config)# interface a0/1/1
atm_A5-4(config-if)# no shutdown
atm_A5-4(config-if)# ip address 189.24.15.12 255.255.0.0
atm_A5-4(config-if)# tag-switching ip
atm_A5-4(config-if)# exit
atm_A5-4(config)# tag-switching ip
atm_A5-4(config)# interface a0/0/3
atm_A5-4(config-if)# no shutdown
atm_A5-4(config-if)# ip address 189.25.15.11 255.255.0.0
atm_A5-4(config-if)# tag-switching ip
atm_A5-4(config-if)# exit
atm_A5-4(config)# tag-switching ip
```

Router 5-5 Configuration

The configuration of router R5-5, interface e0/2, follows:

```
router_R5-5# configure terminal
router_R5-5(config)# ip cef switch
router_R5-5(config)# tag-switching advertise-tags
router_R5-5(config)# interface e0/2
router_R5-5(config-if)# tag-switching ip
router_R5-5(config-if)# exit
```

Tag Switching Configuration Example

ATM Switch Router A6-4 Configuration

The configuration of ATM switch router A6-4, interface a0/1/1, follows:

```
atm_A6-4# configure terminal
atm_A6-4(config)# interface a0/1/1
atm_A6-4(config-if)# no shutdown
atm_A6-4(config-if)# ip address 189.24.14.12 255.255.0.0
atm_A6-4(config-if)# tag-switching ip
atm_A6-4(config-if)# exit
```

The configuration of ATM switch router A6-4, interface a0/0/3, follows:

```
atm_A6-4# configure terminal
atm_A6-4(config)# interface a0/0/3
atm_A6-4(config-if)# no shutdown
atm_A6-4(config-if)# ip address 189.26.14.11 255.255.0.0
atm_A6-4(config-if)# tag-switching ip
atm_A6-4(config-if)# exit
```

A

administrative access, configuring 2-4

B

baud rate, for terminal emulation 1-1
 BUS 4-3, 4-8

C

card/subcard/port, defined 1-3
 changes, saving 1-9
 CLI, using 1-1 to 1-10
 command modes, understanding 1-2
 CPU card 2-4

D

data bits, for terminal emulation 1-1
 disabling a command or feature 1-8
 displaying the configuration 1-8

E

ELAN 4-2
 ESI 4-3
 Ethernet
 LANE support 4-3
 switch configuration, LANE 4-13

example configurations

 LANE 4-9
 PVCs 3-9
 PVPs 3-19, 3-21
 soft PVCs 3-14
 SVCs 3-2
 tag switching 5-7

H

help
 online command-line interface 1-2
 using the question mark 1-2

I

interface numbering 1-3
 IP address, configuring for remote Telnet access 2-4

L

LANE
 addressing considerations 4-3
 BUS 4-3
 components 4-2
 configuration examples 4-9
 Ethernet and Token Ring support 4-3
 example configurations 4-9
 LEC 4-2
 LECS 4-2
 LES 4-3
 router and LAN switch requirements 4-4
 rules for configuration 4-4
 LE_ARP 4-3

LEC 4-2, 4-5
LECS 4-2, 4-6
LES 4-3, 4-8
LES/BUS 4-8

M

MAC addresses 4-2
modes, command 1-2

N

naming the ATM switch router 2-1
numbering, card/subcard/port 1-3

O

OSPF 5-1

P

parity, for terminal emulation 1-1
password, creating 2-3
port numbering 1-3
processor card 2-4
prompt, changing 2-1
PVCs
 ATM switch router configuration 3-10
 router configuration 3-12
PVPs 3-19, 3-21

R

remote administrative access, configuring 2-4
restricting access, creating a password 2-3
router configuration
 LANE 4-12
 PVCs 3-12
 soft PVCs 3-17
 SVCs 3-2
 tag switching 5-6, 5-7, 5-8, 5-9

S

saving changes 1-9
security, creating a password 2-3
slot numbering 1-3
soft PVCs
 ATM switch router configuration 3-14
 router configuration 3-17
SSRP 4-3
stop bits, for terminal emulation 1-1
SVCs
 ATM switch router configuration 3-1
 router configuration 3-2

T

tag switching
 ATM switch router configuration 5-2to 5-5
 example configuration 5-7
 requirements, hardware and software 5-1
 router configuration 5-6
TDP 5-2
Telnet access, configuring 2-4
terminal emulation, recommended settings 1-1
Token Ring, LANE support 4-3
tunnels, VP 3-21

U

unauthorized access, preventing 2-3
undo
 See disabling

V

viewing the configuration 1-8
VP tunnels 3-21

