


Cat. No. 17-7021
OWNER'S MANUAL

PRO ENCORE!™
PG 202 Numeric Pager

Please read before using this pager.



Radio Shack

INTRODUCTION

Your Radio Shack Pro Encore PG 202 Numeric Pager lets you keep in touch with family and friends everywhere you go (in the PageMart coverage area you choose) and is easy to operate. It can store up to 16 20-digit messages in memory, and you can protect important messages so you do not accidentally erase them.


Be sure you thoroughly read these instructions to ensure that you fully understand how to use your pager.

© 1995 Tandy Corporation.
All Rights Reserved.
PRO ENCORE! is a trademark of Motorola, Inc.
Radio Shack is a registered trademark
used by Tandy Corporation.

INSTALLING THE BATTERY

Your pager requires one AAA battery. For the best performance, we recommend an alkaline battery, such as Radio Shack Cat. No. 23-555.

1. Slide the battery compartment lock up and slide the battery door in the direction of the arrow. The pager's door hinges open. If you accidentally lift it so far that it pops off of the pager, simply snap it back into place.



2. Insert the battery's positive end first, as indicated by the polarity symbol (+) marked outside the compartment.

3. Close the battery door and slide the battery compartment lock down to secure it.

Notes:

- To conserve battery power, turn the pager off when you are not using it.
- The battery should provide about 850 to 950 hours of continuous use.


A low battery alert sounds and the pager displays **LO CELL** when the battery's power is low. When this occurs, replace the battery.


Notes:


- To save battery power, all pager alerts change to 2 seconds in length when battery power is low.
- When you replace the battery, the pager keeps all messages and the time and date.


OPERATION

A LOOK AT YOUR PAGER




 — turns the pager on/off, lets you read messages and select the displayed function.



 — press once to light the screen; press again to re-set to the standby screen.

 — scrolls through menus.


TURNING ON THE PAGER



Press  to turn on your pager. Your pager alerts with either a tone or vibration.

TURNING OFF THE PAGER

Repeatedly press  until the pager displays **PAGeR OFF?**. Press  to turn off the pager. Previously received messages are not erased. However if you are paged while the pager is off, you do not receive the page.

SELECTING AUDIBLE/SILENT ALERT





From the date/time display, press  until the pager displays either **SILENT?** or **AUDIO?**.

- If the pager displays **SILENT?**, it is set to sound an alert tone. Press  to make your pager vibrate when it receives a page.
- If the pager displays **AUDIO?**, it is set to vibrate. Press  to make your pager sound an alert tone when it receives a page.

Set your pager to the silent mode when you are in meetings, church, or the theater, to avoid disturbing others with the tone. The silent feature is also handy if you are at a concert or in any noisy environment where it might be difficult to hear the tone.








ALERT TONES

Your pager has five different alert tones. If you selected the audible alert, follow these steps to select an alert tone.

1. Repeatedly press  until the pager displays **SET ALerT?**.
2. Press . The pager sounds the currently selected alert tone.
3. Repeatedly press  until the pager sounds the alert tone you want.
4. Press .

SETTING THE TIME

You must set the time so the pager can time stamp your messages.










1. Repeatedly press  until the pager displays **SET TIME?**.
2. Press . The hour digits flash. Within 8 seconds, repeatedly press  to set the hour.
3. Press . The first minute digit flashes. Within 8 seconds, repeatedly press  to set the first minute digit.
4. Press . The second minute digit flashes. Within 8 seconds, repeatedly press  to set the second minute digit.


5. Press . **A** or **P** flashes in the display. Within 8 seconds, press to set the time of day to AM or PM.
6. Press twice. The pager displays the time and date.

SETTING THE DATE

1. Repeatedly press until the pager displays **SET dATE?**.
2. Press . The month flashes. Within 8 seconds, repeatedly press to set the month.
3. Press . The day flashes. Within 8 seconds, repeatedly press to set the day.
4. Press twice. The pager displays the time and date.


SETTING THE ALARM

1. Repeatedly press  until the pager displays **SET ALArM?**.
2. Press . **ON** or **OFF** flashes in the display. Within 8 seconds, press  to turn the alarm on or off.
3. Press . The hour digits flash. Within 8 seconds, repeatedly press  to set the hour.
4. Press . The first minute digit flashes. Within 8 seconds, repeatedly press  to set the first minute digit.
5. Press . The second minute digit flashes. Within 8 seconds, repeatedly press  to set the second minute digit.






6. Press . **A** or **P** flashes in the display. Within 8 seconds, press to set the time of day to AM or PM.
7. Press twice. The time and date appear on the display.

The pager displays when you turn on the alarm. The pager gives a 20-second alert and displays **ALARM** at the set alarm time. The alarm sounds even if the pager is off. Press any button to stop the alert.





RECEIVING PAGES AND READING MESSAGES

When the pager receives a page, it alerts for 8 seconds. Press any button to stop the alert. The number of unread messages appears on the display.

Press  to display your message. If the pager displays , there is more information on the next screen. The pager automatically displays the next screen after 1 minute, or you can press  to advance sooner.

After you view your message, the pager displays the time stamp to show the time you received the message and the message position number (the order in which it was received).








Press  to scroll through other messages. After you read all the messages, the time and date appear on the display.

Note: If you do not read a message, the pager alerts every 2 minutes and displays the number of unread messages (for example, **1 PAGE**).

PROTECTING/UNPROTECTING MESSAGES



You can protect messages so they are not removed when you receive more messages than the available memory can store.



To protect a message, press  while the pager displays the message you want to protect. The pager displays **PrOTECT?**. Press  to protect the message. The pager displays .

To unprotect a message, press  while the pager displays the message you want to unprotect. The pager displays **UNPrOTECT?**. Press  to unprotect the message.

ERASING MESSAGES

There are two ways to erase messages: erase all and erase one.

To erase all messages, repeatedly press  until the pager displays **ErASE ALL?**. Press . All read, unlocked messages are erased from memory, and all other messages are moved to the first message slots.

To erase one message, select the message, then press  twice. The pager displays **dELETE?**. Press  to erase the message.

Note: You cannot erase a message that you have not read or that is protected.

SPECIAL MESSAGES

The pager has the following special messages.

OVERFLOW—appears when the number of unread messages received is greater than the available memory. When this occurs, any new message you receive *bumps* the oldest message out of memory.

DUPLICATE—appears when the same message is received more than once. The new message remains with the latest time stamp and the older message is deleted.

tone only—appears when a page is received without numeric data.

PAGER IDEAS

Give your pager number to friends and family. When they call your pager number, they can use their phone's touch-tone keypad to enter the number where you can reach them. Your pager displays this number when you receive the page. You are in touch wherever you go in your PageMart coverage area.

- Include your pager number on your telephone answering machine greeting. This way you can immediately receive important messages.
- Leave your pager number at your children's school and with the babysitter so you can always be reached in an emergency.
- Establish *code* messages with your family and friends. For example, your children can page you with the code 3333 to tell you they got home from school. Your spouse can send 07734 to say hello! (Read it upside-down.)

- If you have a cellular phone, give out your pager number instead of your cellular number. Then you can decide who to call back on your cellular phone, without paying for incoming cellular calls. This can drastically reduce your monthly cellular bill.

CARE AND MAINTENANCE

- Keep the pager dry. If it gets wet, wipe it dry immediately. Liquids can contain minerals that corrode the electronic circuits.
- Use and store the pager only in normal temperature environments. Temperature extremes can shorten the life of electronic devices and distort or melt plastic parts.
- Handle the pager gently and carefully. Dropping it can damage circuit boards and cases and can cause the pager to work improperly.
- Keep the pager away from dust and dirt, which can cause premature wear of parts.
- Wipe the pager with a damp cloth occasionally to keep it looking new. Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the pager.

FCC INFORMATION

This pager might cause TV/radio interference even when it is operating properly. To determine whether your pager is causing the interference, turn it off. If the interference goes away, your pager is causing the interference. Try to eliminate the interference by moving your pager away from the receiver or by contacting your local Radio Shack store for help. If you cannot eliminate the interference, the FCC requires that you stop using your pager.



Modifying or tampering with your pager's internal components can cause a malfunction and might invalidate the warranty and void your FCC authorization to operate it. If your pager is not performing as it should, contact your local Radio Shack store or PageMart at 1-800-864-HELP.

This device complies with Part 15 of *FCC Rules*. Operation is subject to the following conditions:

- (1) This device may not cause any harmful interference, and
- (2) This device must accept interference received, including interference that may cause undesired operation.



NOTES



RADIO SHACK LIMITED WARRANTY

This product is warranted against defects for 90 days from date of purchase from Radio Shack company-owned stores and authorized Radio Shack franchisees and dealers. Within this period, we will repair it without charge for parts and labor. Simply **bring your Radio Shack sales slip** as proof of purchase date to any Radio Shack store. Warranty does not cover transportation costs. Nor does it cover a product subjected to misuse or accidental damage. EXCEPT AS PROVIDED HEREIN, RADIO SHACK MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. Some states do not permit limitation or exclusion of implied warranties; therefore, the aforesaid limitation(s) or exclusion(s) may not apply to the purchaser.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

We Service What We Sell

9/94

RADIO SHACK
A Division of Tandy Corporation
Fort Worth, Texas 76102

8/95

Printed in the USA