

***Personal
Digital Assistant***

User's Guide

Contents

License Agreement	2
Notice	3
Getting Started	4
Understanding the Display	6
Using the Clocks	9
Entering a Phone Record	14
Entering a Schedule record	16
Entering a Todo	18
Entering a Memo Record	20
Entering an Internet Record	21
Searching and Editing Records	22
Using the Calculator	24
Using the Converters	26
Replacing the Batteries	30
Using a Password	31
Specifications	33
Limited Warranty (outside U.S.)	33
FCC Notice	34
Limited Warranty (U.S. only)	35

License Agreement

READ THIS LICENSE AGREEMENT BEFORE USING THE ELECTRONIC REFERENCE. YOUR USE OF THE ELECTRONIC REFERENCE DEEMS THAT YOU ACCEPT THE TERMS OF THIS LICENSE. IF YOU DO NOT AGREE WITH THESE TERMS, YOU MAY RETURN THIS PACKAGE WITH PURCHASE RECEIPT TO THE DEALER FROM WHICH YOU PURCHASED THE ELECTRONIC REFERENCE AND YOUR PURCHASE PRICE WILL BE REFUNDED. ELECTRONIC REFERENCE means the software product and documentation found in this package and FRANKLIN means Franklin Electronic Publishers, Inc.

Limited Use License

All rights in the ELECTRONIC REFERENCE remain the property of FRANKLIN. Through your purchase, FRANKLIN grants you a personal and nonexclusive licensed to use this ELECTRONIC REFERENCE. You may not make any copies of the ELECTRONIC REFERENCE or of the data stored therein, whether in electronic or print format. Such copying would be in violation of applicable copyright laws. Further, you may not modify, adapt, disassemble, decompile, translate, create derivative works of, or in any way reverse engineer the ELECTRONIC REFERENCE. You may not export or reexport, directly or indirectly, the ELECTRONIC REFERENCE without compliance with appropriate governmental regulations. The ELECTRONIC REFERENCE contains Franklin's confidential and proprietary information which you agree to take adequate steps to protect from unauthorized disclosure or use. This license is effective until terminated. This license terminates immediately without notice from FRANKLIN if you fail to comply with any provision of this license.

Notice

Recommendations

- The manufacturer strongly recommends that separate permanent written records be kept of all important data. Data may be lost or altered in virtually any electronic memory product under certain circumstances. Therefore, the manufacturer assumes no responsibility for data lost or otherwise rendered unusable whether as a result of improper use, repairs, defects, battery replacement, use after the specified battery life has expired, or any other cause.
- The manufacturer assumes no responsibility, directly or indirectly, for financial losses or claims from third parties resulting from the use of this product and any of its functions, such as stolen credit card numbers, the loss or alteration of stored data, etc.
- The information provided in this manual is subject to change without notice.

Cautions

- Do not carry the organizer in the back pocket of your slacks or trousers.
- Do not drop the organizer or apply excessive force to it.
- Do not subject the organizer to extreme temperatures.
- Clean only with a soft, dry cloth.
- Since this product is not waterproof, do not use it or store it where fluids can splash onto it. Raindrops, water spray, juice, coffee, steam, perspiration, etc. will also cause the organizer to malfunction.




Getting Started

Using the Organizer for the First Time

The first time you use this organizer, you should perform a system reset. **Warning!** A system reset erases any user-entered information and clears all settings.

1. Turn the organizer over and carefully pull the battery insulation sheet to remove it.
2. Press ON/OFF to turn the organizer off.
3. Use a paper clip to gently press the reset button on the back of the organizer.
4. Tap ENTER to reset the organizer.

Selecting a Language

1. Tap  and then tap LANG to the bottom right of the screen.
ENGLISH? appears on the screen.
2. Tap  or  to cycle through the seven available languages: English, Español, Français, Deutsch, Nederlands, Italiano, Português.
3. Tap ENTER when you see the one you want.

About Screen Illustrations

Some screen illustrations in this User's Guide may vary slightly from what you see on the screen. This does not mean that your organizer is malfunctioning. English is the selected message language for screen illustrations.

Auto-Shut Off

When none of the keys have been pressed for approximately seven minutes, the organizer automatically turns the power off to save the battery. Press **ON/OFF** to resume. The actual life of the battery depends on the usage.


Keyboards

ABC/123 at bottom right of screen controls the keyboards. Tap this to toggle between the letter/number keyboards. The Calculator function icons and **SYML** appear only in the numeric keyboard.

Symbols

You can enter 19 symbols such as @, \$, etc., and 29 accented characters such as Ä, É, etc. To enter a symbol or special character when tapping letters, first tap **ABC/123**, then tap **SYML** on bottom left of screen repeatedly to cycle through the 48 available symbols and characters. Tap **ABC/123** to return to the letter keyboard.

Low Battery Indicator

When the power in the battery runs low,  appears in the top row of the screen to alert you. Please replace the battery soon to avoid losing data. For instructions on how to change your batteries, please see “Changing the Batteries.”

Understanding the Display

Several icons appear on the top row of the screen to indicate active modes. These are indicator icons only and perform no function when tapped.

Note: ▼ ▲ on the top row indicate data in fields other than the one currently being viewed. Tap ▼ ▲ on the bottom right of the screen to view the other fields with data.

◀ ▶ on the top row indicates data extending beyond the current screen. Tap ◀ ▶ to scroll left and right and read all the available data.

The bottom half of the screen contains the function icons, directions arrows, letters, numbers and other icons that you can tap to perform a number of functions.

Note: The display is dependent on the mode you are in. For example, the Calculator function keys are displayed only in the Calculator.

Function Icons

The function icons appear in a row beneath the data display.



Toggles between the Business 1 and Business 2 phone directories



Goes to the Personal phone directory



Goes to the Internet directory

Understanding the Display



TIME

Toggles between Home Time and World Time



ALARM

Goes to the daily alarm mode



SCHD

Goes to the Schedule



TODO

Goes to the Todos



MEMO

Goes to the Memos



CALC

Cycles between the Calculator, Metric converter and Currency Converter



EURO

Goes to the Euro Converter



Sync

Goes to the Data Synchronization Screen. This is useful only if you have the PC Sync program.

Other Icons



Moves cursor in the indicated direction



Searches up through records



Searches down through records

Understanding the Display



Jumps directly to the e-mail field in a phone record



Enables/disables the alarms



Enables/disables the keytone






Goes to the Enter Password screen



Enters a hard return

Using the Clocks

After a system reset, each time you press **ON/OFF** or tap , you see the Home Time screen.  on the top row indicates Home Time. You can perform the following functions in Home Time.

1. Tap  to go to World Time.

 on the top row indicates World Time.

2. Tap MD/DM on bottom left of screen to toggle between the month/day and day/month formats.

3. Tap 12/24 on bottom center of screen to toggle between 12- and 24-hour displays for the clock.

4. Tap DST on bottom right of screen to enable/disable daylight savings time.


 on the top row indicates DST is enabled.

5. Tap  to enable/disable the keytone.


The keytone is the beep that sounds when you touch the screen.

 on the top row indicates the keytone is enabled.

6. Tap  to enable/disable the hourly chime.

 on the top row indicates the hourly chime is enabled.

7. Tap  to see the Password entry screen.

 on the top row indicates the password is activated.


Using the Clocks


8. Tap **DATA SYNC** to start data synchronization with your PC.

The PC sync is to be purchased separately.

9. Tap **M.CHK** to see the percent of available memory.
10. Tap **▲▼** to adjust the LCD contrast.
11. Tap **LANG** to go to the Language selection screen.
12. Tap **EDIT** to go to the Home Time edit screen.

Setting Home Time

1. Tap  **TIME** once to go to the Home Time screen.



 on the top row indicates Home Time.

Using the Clocks

2. Tap **EDIT**.

3. Edit the year, day and month.

You can edit the year, day, month, city, hour and minute in that sequence.

Tap **ABC/123** at the bottom right of the screen to toggle between letter and number input.

Tap **▲▼◀▶** to move the cursor in the indicated direction.

4. At the city name, tap **▲** or **▼** to cycle through the available city names.

Tap letters **A-Z** to edit a city name. This will be your Home city.

5. Edit the hour and minute.

Tap **AM/PM** at bottom center of screen to toggle between a.m. and p.m. in the 12-hour format.


6. Tap **ENTER** at bottom right corner of screen to store the time.

Seconds are updated automatically.




Viewing World Time

You must set your home time before viewing World Time. There are 43 built-in cities. The list is available at the end of this User's Guide.

Using the Clocks


1. Tap  **TIME** twice to go to World Time.




-  on the top row indicates World Time.
2. Tap  or  to cycle through the available city times.



Tap **12/24** at bottom of screen to toggle between the 12- and 24-hour time format.






Tap **DST** on bottom right of screen to enable/disable daylight savings time.

 on the top row indicates daylight savings time is enabled.






3. Tap  **TIME** again to return to Home Time.

Setting the Daily Alarm

When the set time is reached, the alarm sounds for 20 seconds. Tap any key other than  to activate the snooze function and stop the sound. When the snooze function is activated, the alarm sounds every eight minutes. Tap  to stop the sound and de-activate the snooze function. To set the daily alarm, do the following:




1. Tap  **ALARM**.
2. Tap **EDIT** at bottom of screen.
Tap **0-9** to edit the hour and minute.
Tap   to move the cursor in the indicated direction.
Tap **AM/PM** at bottom of screen to toggle between a.m. and p.m.
3. Tap **ENTER** at bottom right of screen to store your settings.
4. Tap  on bottom left of screen to disable/re-enable the daily alarm.
 on the top row indicates the daily alarm is enabled.

Entering a Phone Record


There are three telephone directories: Personal, Business 1 and Business 2. Each directory has 10 fields in which to enter data. Some of the fields have corresponding icons that are displayed on the top row of the screen. The fields appear in the following sequence: Name () , Company () , Address () , Home phone, Work phone, Fax, Cellular, Pager, E-mail () and Note () . Each field has a character limit. Please see table below.

Field	Character Limit
NAME	40
COMPANY	18
ADDRESS	80
HOME PHONE	18
WORK PHONE	18
FAX	18
CELLULAR	18
PAGER	18
EMAIL	40
NOTE	60

To enter a phone record, do the following:

1. Tap  to go to the **Personal phone directory**. *PERSONAL* flashes on the screen briefly.
Tap  once to go to the Business 1 phone directory. Tap  twice to go to the Business 2 phone directory. *BUSINESS* flashes on the screen briefly.
2. Tap **A-Z** to enter a name.

Entering a Phone Record



Name is the first field.

You **MUST** enter a name if you want to save the record.

3. Tap ▼ to enter data in each successive field.

You need not enter data in every field.

Tap ▲ to return to the previous field.

Tap **ABC/123** to toggle between the letter/number keyboards.

Note ([N]) is the last field.

4. Tap ENTER to save the record.

Entering a Schedule Record

There are five fields in the Schedule: Start Date, Start Time, End Date, End Time, Message (Description). You can set a Schedule alarm which sounds for 20 seconds. You can enable/disable the alarm, and stop the sound at any time. To enter a Schedule record, do the following:

1. Tap  SCHD.



SCHEDULE flashes on the screen briefly and you go to the Start Date field.

2. Tap 0-9 to enter a Start Date.

The date format is what you set in Home Time.

You **MUST** enter a Start Date if you want to save the record.

Tap ◀▶ to move the cursor left or right.

3. Tap ▼ to enter data in each successive field.

Entering a Schedule Record

You need not enter data in every field.

Tap **▲** to return to the previous field.

At the Start time field, tap **((∞))** to enable the Schedule alarm.

((∞)) on the top row indicates the Schedule alarm is activated.

At the Start Time and End Time fields, tap **AM/PM** at bottom of screen to toggle between a.m. and p.m. in the 12-hour format.

If you enter an invalid date or time, you are prompted for a correction.

Message is the last field. You can enter up to 300 characters in this field.

Note: In the date and time fields, only the number keyboard is available. In the Message field, tap **ABC/123** to toggle between the letter/number keyboards.

Tap **A-Z** or **0-9** to enter your data.

Tap **SYML** to cycle through the list of available symbols.

Tap **SPACE** to insert a space.

Tap **DEL** to delete a character.

The character at the cursor is deleted.

Tap **INS** to insert a character.

4. Tap **ENTER** to store your data.

Entering a Todo

There are four fields in the Todo book: Date Due, Message (description), Date Done and Priority. You can set priority levels of one to three. To enter a Todo record, do the following:

1. Tap  **TODO**.



TODO flashes on the screen briefly and you go to the Date Due field.

2. Tap **0-9** to enter the due date for the Todo.

The date format is what you set in Home Time.

You **MUST** enter a due date if you want to save the record.

If you enter an invalid date, you are prompted for a correction.

Tap   to move the cursor left or right.

Entering a Todo

3. Tap ▼ to go to the Message field.

You can enter a maximum of 108 characters.

Note: In the date and priority fields, only the number keyboard is available. In the Message field, tap **ABC/123** to toggle between the letter/number keyboards.

Tap ▲ to return to the previous field.

Tap **A-Z** or **0-9** to enter your data.

Tap **SYML** to cycle through the list of available symbols.

Tap **SPACE** to insert a space.

Tap **DEL** to delete a character.

Tap **INS** to insert a character.

4. Tap ▼ to go to the Date Done field.

Tap **0-9** to enter the completed date

The Todos are sorted by the due date.

5. Tap ▼ to go to the Priority field.

Tap **1-3** to set a priority level for your todo.

6. Tap ENTER to store your data.

Entering a Memo Record

Each Memo record consists of a Message field in which you can enter a maximum of 300 characters. To enter a Memo do the following:

1. Tap  **MEMO**.



MEMO flashes briefly on the screen.

2. Tap **A-Z** or **0-9** to enter your data.

Tap **SYML** to cycle through the list of available symbols.

Tap **SPACE** to insert a space.

Tap **DEL** to delete a character.

Tap **INS** to insert a character.

Tap   to move the cursor.

3. Tap **ENTER** to store your record.

Entering an Internet Record

Each Internet record has three fields: Message (description), Internet (address) and Note. You can enter descriptions of your favorite websites, the addresses and a note. You can enter a maximum of 108 characters in the Message and Note fields and 80 characters in the Internet field. To enter an Internet record, do the following:

1. Tap  .

INTERNET flashes briefly on the screen and you go to the Message screen.

2. Tap **A-Z** or **0-9** to enter your description.

You must enter data in this field if you want to save the record.

Tap **SYML** to cycle through the list of available symbols.

Tap **SPACE** to insert a space.

Tap **DEL** to delete a character.

Tap **INS** to insert a character.

Tap **◀▶** to move the cursor.

3. Tap **▼** to go to the Internet (address) field.

4. Enter the internet address and tap **▼** to go to the note field.

Enter a note if you want.



5. Tap **ENTER** to store the data.



Searching and Editing Records

Phone, Memo and Internet records are sorted alphabetically. Schedule and Todo records are sorted chronologically. You can search for them either directly or sequentially. You can review your records, edit them or delete them.

Searching for a Record

Tap the icon of the directory you want to search.



Tap  or  to view the records in the order they appear.

In the Telephone, Memo and Internet directories, enter the first few letters of a record to find it quickly. The first record starting with the input letters is displayed if it exists. You can then tap  or  to view the records. If no matching record is found, “**NOT FOUND**” is displayed.

You can also do a wildcard search using *. For example to find all the records ending in “ant” tap **SYML** repeatedly until you see *, then enter “ant”.

Note: Only records matching the entered keywords or wildcards are displayed.

Viewing a Record

1. Find the record you want to view as described above.
2. Tap   to view other fields in the record.

Searching and Editing Records

The field name is displayed briefly and then the data is displayed.

Except for the email field, all other fields with no data are skipped.

3. Tap ◀▶ to scroll back and forth and view data beyond the screen limits.

In a phone record, tap  to go directly to the e-mail field.

Editing a Record

1. Find the record you want to edit.

To learn how, read “Searching for a Record”.

2. Tap EDIT on bottom center of screen.

Edit your records just as you entered them.

3. Tap ▲▼ to go through the fields in the record.

4. Tap ENTER on bottom right of screen to store the edits.

Deleting a Record

1. Find the record you want to delete.

To learn how, read “Searching for a Record”.

2. Tap DEL on bottom center of screen.


3. Tap ENTER to confirm the deletion.

Tap any other icon to cancel the deletion.

Using the Calculator

Making a Calculation

1. Tap  **CALC** once.



The numeric keypad appears.

2. Tap **0-9, . or +/-** to enter the numbers you want.

You can enter a maximum of 10 characters .

3. Tap **+, -, x or ÷** to perform an addition, subtraction, multiplication or division.

Tap  to erase a character to the left of the cursor.

Tap  to calculate the square root.

4. Enter another number.
5. Tap **=** on bottom right of screen to do the calculation.

Using the Calculator

Or tap **%(B)** to calculate the percentage.

6. Tap **C/CE** on bottom left of screen to clear the calculations.

Note: If there is an error or overflow, **E** is displayed on the screen and you will not be able to do any further calculations. Tap **C/CE** to clear the error screen and return to the Calculator.

Using the Calculator Memory

1. In the Calculator, make a calculation or type a number.
2. To add the number on the screen to the number stored in memory, tap **M+** on lower left of screen.

To subtract the number on the screen from the number stored in memory, tap **M-** on lower left of screen.

M on top row indicates the number is stored in memory.

Note: The number is retained in memory even when you turn the unit off.

3. To retrieve the number from memory, tap **MRC** once.
4. To clear the memory, tap **MRC** twice.






Using the Converters

There are three converters: Metric, Currency and Euro.

Doing Metric Conversions

Use the Metric converter to do any of the eight built-in conversions.

INCH	↔	CM
YARD	↔	M
MILE	↔	KM
C	↔	F
FT	↔	M
OZ	↔	GRAM
LB	↔	KG
GAL	↔	L

1. Tap  **CALC** twice to enter the **Metric converter**.
METRIC flashes on the screen briefly and the first conversion screen appears.
The conversion rate is displayed to the right of the screen.
2. Tap  or  to cycle through the available conversions.
3. Stop when you see the one you want.
4. Tap   to select the conversion direction.


Using the Converters

Note the rate change on the right.

5. Tap **0-9** to enter the numbers you want.
6. Tap **ENTER** to do the conversion.

Setting Currency Rates

Once you set currency rates, you can do currency conversions. You can set four currency rates. The default currency settings are USD \longleftrightarrow USD and the default rate is 1. To set a conversion rate, do the following:

1. Tap  **CALC** three times to enter the **Currency converter**.

CURRENCY flashes on the screen briefly and the first conversion screen appears.

2. Tap **EDIT** on the bottom center of the screen.

The first letter on the left flashes.

3. Tap **A-Z** to enter an abbreviation first for the currency name on the left, then for the currency name on the right.

You can enter a maximum of 3 letters for each name.

Tap **▲▼** to move the cursor.

4. Tap **ENTER** to edit the rate.

Using the Converters

5. Tap 0-9 and . to enter a rate.

You can enter a maximum of six numbers (five if using a .) for the rate.

6. Tap ENTER to save the setting.

7. Tap to go to the next conversion screen.

Once you enter your currencies and rates, you can do currency conversions in the same way you do metric conversions.

Doing Euro Conversions

Use the Euro converter to do any of the 11 built-in conversions. Note that the rates are set and cannot be changed. In the table below, the rate shown is that for 1 Euro.





Currency	Display	Rate
Belgian Francs	EUR ↔ BEF	40.3399
German Marks	EUR ↔ DEM	1.95583
Spanish Pesetas	EUR ↔ ESP	166.386
French Francs	EUR ↔ FRF	6.55957
Irish Pounds	EUR ↔ IEP	0.787564
Italian Lire	EUR ↔ ITL	1936.27
Luxemburg Francs	EUR ↔ LUF	40.3399
Dutch Guilders	EUR ↔ NLG	2.20371
Austrian Schillings	EUR ↔ ATS	13.7603
Portuguese Escudos	EUR ↔ PTE	200.482
Finnish Marks	EUR ↔ FIM	5.94573

Using the Converters

1. Tap  EURO .




EURO flashes on the screen briefly and the first conversion screen appears.

2. Tap  or  to find the conversion you want.
The rate is displayed to the right of the screen.
3. Tap 0-9 and . to enter the number you want.
4. Tap   to change the direction of the conversion.
5. Tap ENTER to convert.

Replacing the Batteries

This organizer uses two CR-2032 lithium batteries.



The battery on the left is the main battery and is the one that needs to be replaced when you see  on the top row of the display. The battery on the right is a back-up battery. Change this once a year to guard against data loss. Follow these steps to change either battery. Before you follow these steps you should have a small Phillips screwdriver and the new batteries at hand.

- 1. Turn the organizer off and turn it over.**
- 2. With the Phillips screwdriver, remove the screw to the battery cover and then remove the cover.**

Do not remove the screws at the sides of the organizer.

- 3. Remove the old batteries and quickly replace them with the new ones, with the positive (+) side up.**
- 4. Replace the battery cover.**

Warning! This organizer stores your information as long as the batteries supply power. If the batteries lose power or are removed, all your information will be lost. Always keep written copies of your important information.

Using a Password

You can lock your organizer so that only the Clock, Calculator and Converter can be used without supplying the password. **Note:** You do not need to set a password to use this organizer.

Warning! Please keep written records of your data. If you forget your password, you will not be able to recover any of the data stored in your organizer. To bypass the password, you will have to perform a system reset, which will clear the password but will also erase all the data stored in memory. To learn how to perform a system reset, read "Getting Started."

Setting a Password


1. Tap  until  is displayed.

2. Tap .

3. Enter a password.

You can use a maximum of 6 digits.

4. Tap **ENTER** to store your password.

 is displayed on the top bar.

Accessing Secret Data

When your password is activated, each time you tap

 **BUSI**,  **PERS**,  **WWW**,  **SCHD**, or  **MEMO**, you are prompted to

enter your password.




Using a Password

Tap your password and tap **ENTER**.

If you enter the wrong password, "OPEN ERROR" is displayed on the screen and you are again prompted to enter your password.

Once you enter the correct password, you can enter new data or view existing data.

Changing or Deactivating the Password

1. Tap  until  is displayed.
2. Tap .
3. Type your old password and then tap **ENTER**.
You are prompted to enter a new password.
4. To change your password, type a new password and tap **ENTER**.
To deactivate your password, tap **ENTER** without entering a password.
5. Re-enter your password to confirm it.
6. Tap **ENTER** to store it.

This unit may change operating modes due to Electro-static discharge. Normal operation of this unit can be re-established by pressing the reset key, ON/OFF or by removing/replacing batteries.

Specifications

- Model: RF-8110 • Size: 10.4 X 8.0 X 1.17 cm
 - Weight: 2.8 oz • Battery: 2 CR-2032 Lithium
- Storage Capacity: 192K
ISBN: 1-56712-693-6

Cleaning this Product

To clean this product, spray a mild glass cleaner onto a cloth and wipe its surface. Don't spray liquids directly onto the unit. Don't use or store your organizer in extreme or prolonged heat, cold, humidity, or other adverse conditions.

FOR HOME OR OFFICE USE

Customer Support in U.S. (609) 386-8997

Copyrights, Trademarks and Patents

© 2001 Franklin Electronic Publishers, Inc., Burlington, N.J. 08016-4907 USA. All rights reserved.

ROLODEX® is a registered trademark of Berol Corporation, a subsidiary of Newell Rubbermaid, Inc. Patents pending.

Limited Warranty (outside U.S.)

This product, excluding batteries is guaranteed by Franklin for a period of one year from the date of purchase. It will be repaired or replaced with an equivalent product (at Franklin's option) free of charge for any defect due to faulty workmanship or materials.

Products purchased outside the United States that are returned under warranty should be returned to the original vendor with proof of purchase and description of fault.

Charges will be made for all repairs unless valid proof of purchase is provided.

This warranty explicitly excludes defects due to misuse, accidental damage, or wear and tear. This guarantee does not affect the consumer's statutory rights.

FCC Notice

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This unit was tested with shielded cables on the peripheral devices. Shielded cables must be used with the unit to insure compliance.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Limited Warranty (U.S. only)

LIMITED WARRANTY, DISCLAIMER OF WARRANTIES AND LIMITED REMEDY

(A) LIMITED WARRANTY. FRANKLIN WARRANTS TO THE ORIGINAL END USER THAT FOR A PERIOD OF ONE (1) YEAR FROM THE ORIGINAL DATE OF PURCHASE AS EVIDENCED BY A COPY OF YOUR RECEIPT, YOUR FRANKLIN PRODUCT SHALL BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP. THIS LIMITED WARRANTY DOES NOT INCLUDE DAMAGE DUE TO ACTS OF GOD, ACCIDENT, MISUSE, ABUSE, NEGLIGENCE, MODIFICATION, UNSUITABLE ENVIRONMENT OR IMPROPER MAINTENANCE. THE SOLE OBLIGATION AND LIABILITY OF FRANKLIN, AND YOUR EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY, WILL BE REPAIR OR REPLACEMENT WITH THE SAME OR AN EQUIVALENT PRODUCT OF THE DEFECTIVE PORTION OF THE PRODUCT, AT THE SOLE OPTION OF FRANKLIN IF IT DETERMINES THAT THE PRODUCT WAS DEFECTIVE AND THE DEFECTS AROSE WITHIN THE DURATION OF THE LIMITED WARRANTY. THIS REMEDY IS YOUR EXCLUSIVE REMEDY FOR BREACH OF THIS WARRANTY. THIS WARRANTY GIVES YOU CERTAIN RIGHTS; YOU MAY ALSO HAVE OTHER LEGISLATED RIGHTS THAT MAY VARY FROM JURISDICTION TO JURISDICTION.

(B) DISCLAIMER OF WARRANTIES AND LIMITATION OF LIABILITY. EXCEPT FOR THE LIMITED WARRANTIES EXPRESSLY RECITED ABOVE, THIS FRANKLIN IS PROVIDED ON AN "AS IS" BASIS, WITHOUT ANY OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR THOSE ARISING BY LAW, STATUTE, USAGE OF TRADE, OR COURSE OF DEALING. THIS WARRANTY APPLIES ONLY TO PRODUCTS MANUFACTURED BY FRANKLIN AND DOES NOT INCLUDE BATTERIES, CORROSION OF BATTERY CONTACTS OR ANY OTHER DAMAGE CAUSED BY BATTERIES. NEITHER FRANKLIN NOR OUR DEALERS OR SUPPLIERS SHALL HAVE ANY LIABILITY TO YOU OR ANY OTHER PERSON OR ENTITY FOR ANY INDIRECT, INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING, BUT NOT LIMITED TO, LOSS OF REVENUE OR PROFIT, LOST OR DAMAGED DATA OR OTHER COMMERCIAL OR ECONOMIC LOSS,

Limited Warranty (U.S. only)

EVEN IF WE HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR THEY ARE OTHERWISE FORESEEABLE. WE ARE ALSO NOT RESPONSIBLE FOR CLAIMS BY A THIRD PARTY. OUR MAXIMUM AGGREGATE LIABILITY TO YOU, AND THAT OF OUR DEALERS AND SUPPLIERS, SHALL NOT EXCEED THE AMOUNT PAID BY YOU FOR THE FRANKLIN PRODUCT AS EVIDENCED BY YOUR PURCHASE RECEIPT. YOU ACKNOWLEDGE THAT THIS IS A REASONABLE ALLOCATION OF RISK. SOME STATES/COUNTRIES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. IF THE LAWS OF THE RELEVANT JURISDICTION DO NOT PERMIT FULL WAIVER OF IMPLIED WARRANTIES, THEN THE DURATION OF IMPLIED WARRANTIES AND CONDITIONS ARE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY GRANTED HEREIN.

(C) WARRANTY SERVICE: UPON DISCOVERING A DEFECT, YOU MUST CALL FRANKLIN'S CUSTOMER SERVICE DESK, 1-800-266-5626, TO REQUEST A RETURN MERCHANDISE AUTHORIZATION ("RMA") NUMBER, BEFORE RETURNING THE PRODUCT (TRANSPORTATION CHARGES PREPAID) TO:

FRANKLIN ELECTRONIC PUBLISHERS, INC.

ATTN: SERVICE DEPARTMENT

ONE FRANKLIN PLAZA

BURLINGTON, NJ 08016-4907

IF YOU RETURN A FRANKLIN PRODUCT, PLEASE INCLUDE A NOTE WITH THE RMA, YOUR NAME, ADDRESS, TELEPHONE NUMBER, A BRIEF DESCRIPTION OF THE DEFECT AND A COPY OF YOUR SALES RECEIPT AS PROOF OF YOUR ORIGINAL DATE OF PURCHASE. YOU MUST ALSO WRITE THE RMA PROMINENTLY ON THE PACKAGE IF YOU RETURN THE PRODUCT, OTHERWISE THERE MAY BE A LENGTHY DELAY IN THE PROCESSING OF YOUR RETURN. WE STRONGLY RECOMMEND USING A TRACKABLE FORM OF DELIVERY TO FRANKLIN FOR YOUR RETURN.

CITY NAME	ABBREVIATION	CITY NAME	ABBREVIATION
LONDON	LON	TOKYO	TYO
LISBON	LIS	ADELAIDE	ADL
PARIS	PAR	SYDNEY	SYD
BERLIN	BER	NOUMEA	NOU
ROME	ROM	WELLINGTON	WLG
AMSTERDAM	AMS	TONGA	TNG
BARCELONA	BCN	MIDWAY ISLAND	MID
HELSINKI	HEL	HONOLULU	HNL
CAIRO	CAI	ANCHORAGE	ANC
MOSCOW	MOW	LOS ANGELES	LAX
RIYADH	RUH	DENVER	DEN
TEHRAN	THR	CHICAGO	CHI
DUBAI	DXB	NEW YORK	NYC
KABUL	KBL	TORONTO	YYZ
KARACHI	KHI	CARACAS	CCS
DELHI	DEL	RIO DE JANEIRO	RIO
DHAKA	DAC	-----	-2H
YANGON	RGN	AZORES ISLANDS	AZO
BANGKOK	BKK	AUCKLAND	AKL
BEIJING	BEI	GUAM	GUM
HONG KONG	HKG	MID ATLANTIC	MAT
SINGAPORE	SIN		

<p>Technical Support/Ayuda técnica /Technische Hilfe/Aiuto tecnico/Aide technique/Technische Steun</p>	
<p>Deutschland Österreich</p>	<p>Bitte schicken Sie dieses Produkt im Garantiefall mit Kaufbeleg an folgende Service-Adresse: Franklin Electronic Publishers (Deutschland) GmbH, Kapellenstrasse 13, D-85622 Feldkirchen. Den technischen Support erreichen Sie unter Tel. +49-89-90899-116. Bestellinformationen erhalten Sie unter Tel. +49-89-908990 oder im Internet unter www.franklin.com/de</p>
<p>Mexico</p>	<p>Para Soporte Técnico llamar al tel. 01 800 710 5938</p>
<p>USA & Canada</p>	<p>Technical Support is open from 9AM to 5PM EST Monday through Friday. Please call (609) 386-8997 and choose option 3, or fax (609) 387-1787 or visit us at www.franklin.com</p>
<p>All other countries Todos los otros países Alle anderen Länder Altri paesi Tous les autres pays Alle Overige Landen Todos os outros países Για όλες τις άλλες χώρες</p>	<p>www.franklin.com</p>

Franklin[®]

Electronic Publishers

www.franklin.com